

**Quick Installation Guide
for 16/24/32 ports
Dual Speed Hub**

ADH16SB

ADH24SB

ADH32SB



FCC COMPLIANCE STATEMENT

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the instructions provided with the equipment, may cause interference to radio and TV reception. The equipment has been tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart B of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference in a commercial environment. However, there is no guarantee that interference will not occur in a particular installation.

If you suspect this equipment is causing interference, turn your hub on and off while your radio or TV is showing interference to determine the source of the interference.

You can try to correct the interference by one or more of the following measures:

1. Reorient the receiving radio or TV antenna where this may be done safely.
2. To the extent possible, relocate the radio, TV or the other receiver away from the equipment.
3. Plug the computer which has the equipment installed into a different power outlet so that equipment and the receiver are on different branch circuits.

If necessary, you should consult the place of purchase or an experienced radio/ television technician for additional suggestion.

CAUTION : The phonejack cannot be connected to telephone system.

Contents

Chapter 1 Introduction	1
Chapter 2 Features & Specifications	3
Chapter 3 Package Contents	5
Chapter 4 Physical Description	6
Chapter 5 Installation	9
Chapter 6 Troubleshooting	12

1 Introduction

Congratulations on your purchase of this rackmount stackable dual-speed hub. Migrating from traditional 10Mbps Ethernet to 100Mbps Fast Ethernet is now simple and affordable with these dual-speed hubs. These high performance 16-port, 24-Port, 32-port 10/100Mbps stackable dual-speed hubs are equipped with 16, 24, 32 RJ45 dual-speed ports, one uplink port and one internal 2-port switch.

Typically a dual-speed hub has two independent internal network segments: 10Mbps segment and 100Mbps segment. Depending on the speed of attached network devices, each individual port of a dual-speed hub provides Auto-Negotiation capability which automatically senses and selects optimum speed at 10Mbps or 100Mbps. A 10Mbps network device attached to the dual-speed hub will be able to communicate with other network devices attached to the hub running at 10Mbps. On the other hand, a 100Mbps network device attached to the dual-speed hub will be able to communicate with other devices attached to the hub running at 100Mbps. Therefore, dual-speed hub can be 10Base-T hub when all the connecting nodes are running at 10Mbps as illustrated in Figure 1-1, or can be 100Base-TX hub when all the connecting nodes are running at 100Mbps as illustrated in Figure 1-2. These stackable dual-speed hubs are the ideal hubs for both 10Base-T and 100Base-TX networks.




Figure 11 10Mbps segment connecting 10Mbps devices




Figure 12 100Mbps segment connecting 100Mbps devices

Dual-Speed hub with internal switching function automatically switches data traffic between devices running at different speed, which allows communications between ports running at 10Mbps and ports running at 100Mbps. Dual-Speed hub with internal switching function can save money by eliminate the need to purchase expensive Switches for users with mixed speed network environment. The connection of the Dual-Speed hub with internal switching function is illustrated as in Figure 1-3:




Figure 13 Internal switch links 10Mbps and 100Mbps segments

When you ready to expand your network, the Uplink port provides an easy way to connect to another hub with regular straight-through Category 5 cable

These Dual Speed Hubs provide the stackable feature. They can stack together up to 6 hubs to form a logically Big dual-speed Hub.

These Dual-Speed hubs can be set up as stand-alone units or it can be mounted on a standard 19" rack (rack mounting kits are included with the unit).

2 Features & Specifications

(1) Features

- Consists of one internal 10Mbps Ethernet segment and one internal 100Mbps Fast Ethernet segment.
- Supports Auto-Sensing RJ45 ports which automatically sense and select optimum speed and route data traffic to corresponding internal segments.
- Built-in Uplink selection for the last port to connect with regular straight-through cable to another hub.
- Network Utilization LEDs provides simple reading on hub's traffic status.
- Built-in internal switching function automatically switches data traffic between devices running at different speed establishes communications between ports running at 10Mbps and 100Mbps.
- Support stackable function for stacking up to 6 hubs to form a logically single dual-speed hub.
- Standard 19" Rack Mountable
- Two-year warranty


(2) Specifications

- Standards : IEEE 802.3 & 802.3u
- 10/100Mbps Ports : RJ45 x 16 (16-Port Rackmount Dual Speed Hub) or
RJ45 x 24 (24-Port Rackmount Dual Speed Hub) or
RJ45 x 32 (32-Port Rackmount Dual Speed Hub)
- Hub LEDs : Power, Internal Switch
- Segment LEDs : Collision, Utilization
- Port LEDs : Speed Status (10 or 100), Link/Activity Status
- Internal Switch : 1K MAC Address Table
256KB Buffer Memory
- Dimensions : 17.3 x 7.9 x 1.75 in./440 x 201 x 45 mm
- Weight : 5.1 lb./2.3kg
- Power : 100-240V AC, 50-60Hz internal full-range switching power
- Operating Temperature : 32-131^oF (0-55^oC)
- Operating Humidity : 10-95% (Noncondensing)
- Emission : FCC Class B & CE


3 Package Contents

- One Stackable DualSpeed Hub
- One power cord
- User's manual
- Stacking Cable
- Rackmount accessories

16-Port Rackmount Dual Speed hub



24-Port Rackmount Dual Speed hub



32-Port Rackmount Dual Speed hub




Figure 31 Package contents

4 Physical Description

(1) Panel




Figure 41 Panel description

32-Port Rackmount Dual Speed Hub




Figure 41 Panel description (cont.)

(2) LED

LED	Color	Status	Description	Number of LED
PWR (Power)	Green	Lit	Power is supplied	One for the whole Hub
		Off	No power	
Switch (Internal Switch)	Green	Lit	The internal switch is active	One for the whole Hub
		Off	The internal switch is inactive	
COL (Segment Collision)	Yellow	Lit	Collision detected in this segment	One for 10Mbps segment and one for 100Mbps segment
		Off	No Collision	
UTIL. (Segment Utilization)	Green	Lit	Indicate network utilization	One set for 10Mbps segment and one set for 100Mbps segment
LNK/ACT (Link/Activity)	Green	Lit	A valid link is established	One for each port
		Flash	Data packets received	
		Off	No link is established	
100Mbps	Green	Lit	This port runs at 100Mbps	One for each port
		Off	Not connected or runs at 10M	

Table 4-1 LED description

5 Installation

1. Operating Environment

These Dual Speed Hubs must be installed and operated within the limits of specified operating temperature and humidity (see previous section under Specifications). Do not place objects on top of the unit. Do not obstruct any vents at the sides of the unit. Do not position the hub near any heating source such as heater, radiator, or direct exposure to sun. Prevent entering of water and moisture into the unit. If necessary, use dehumidifier to reduce humidity.

2. Connecting to network devices

Connect one end of the network cable to any of the RJ45 ports on the front panel, and connect the other end of the network cable to the RJ45 port of the network device. The network cables must comply with EIA/TIA 568 specifications and Category 5 standard for 100Mbps data rate or minimum Category 3 for 10Mbps data rate. Maximum length between the hub and any network devices is 100 meters (300ft). Once the network cable is connected on both ends and the attached network devices are powered on, the green Link Status LED should be lit. If the connected network devices are running at 100Mbps, the green Speed LED (100M) should also be lit.




Figure 51 Connect the hub and network device

3. Uplink to Another Hub

Use the uplink port (the last port) to connect to another hub as illustrated in Figure 5-2. Connecting cable must comply with EIA/TIA 568 specifications and Category 5 (100Mbps) standards to connect the hubs. The Uplink port of the Dual-Speed hub supports Auto-Sensing function which will automatically sense the speed of the connected hub and operates at either 100Mbps or 10Mbps speed. If the connected hub is another Dual-Speed hub or 100Base-TX hub, the transmission speed between the two hubs will be set at 100Mbps and the green Speed (100M) LED should be lit. The maximum length of the cable should not exceed 5 meters (15ft) when connecting two hubs running at 100Mbps and 100 meters (300ft) when connecting two hubs running at 10Mbps.




Figure 52 Uplink to another hub

4. Stacking Hubs Together

These Dual Speed Hubs provide two stacking ports. Users may connect two hubs using the supplied stacking cable. Connect one end of the stacking cable to the IN stacking connector of the hub and the other end of the stacking cable to another hub OUT stacking connector. You may stack up to 10 hubs. The hubs cascaded together through stacking ports are in one collision domain and therefore considered as one logical dual speed hub.




Figure 53 Stack 6 hubs together

When you have two or more hubs stacked together, only one hub's internal switch is active, the others are inactive. Such design will eliminate a Loop in the network that might cause the whole network to malfunction.

5. Connecting the power

Connect the powercord to the power socket on the rear panel of the unit. Connect the powercord to the power outlet and turn on powerswitch. The green Power LED on the front panel should be lit.




Figure 54 Connect the power cable

6 Troubleshooting

1. Power LED is not lit

- Check if the power cord is properly connected to the power outlet and the hub. Make sure the power switch on the hub is turned ON. .

2. Link Status LED is not lit

- Check the power switch of the network devices attached to the hub, make sure they are turned ON.
- Check the network cable, make sure it is properly connected to the hub and the network device.
- Check the network cable, make sure the cable complies with EIA/TIA 568 specification. Use straight-through Category 5 cables for 100Mbps connection and Category 3 or higher cables for 10Mbps connection.
- Check the slide switch and make sure it is in normal position when you use the last port on the hub to connect to workstations or file servers.

3. The last port's Link Status LED is not lit when it is uplinked to another hub

- Make sure the cable is connected to the "uplink" connector.
- Check the network cable, make sure it is properly connected to both hubs. One end of the cable should be connected to uplink port while the other end of the cable should be connected to a regular port. Do not connect the cable to both uplink ports.
- Check the network cable, make sure the cable complies with EIA/TIA 568 specification. Use Category 5 cables for 100Mbps connection.
- Check the network cable, make sure the maximum length does not exceed 5 meters (15ft) in 100Mbps connection and 100 meters (300ft) in 10Mbps connection.

4. Collision LED flashes constantly

- Remove all the network cables, connect the cables back one by one to isolate the source of the collision.
- Check the network cable, inferior cable quality will result in excessive collision and error packets.

[!] Contact your dealer if problem persists.