

# Remote User Guide



dish

## Safety Instructions

You must keep safety in mind while using this device. Keep these and any other instructions for future reference.

**Observe Warnings:** Carefully follow all warnings on the device and in the operating instructions.

**Heat:** Do NOT place the device near heat sources such as radiators, stoves, heat registers, or other appliances that produce heat.

## Care and Use

**Cleaning:** Do NOT use liquid, abrasive, solvent, or aerosol cleaners. Use a damp cloth for cleaning.

**When Not in Use:** Remove the batteries if this device is to be left unattended or unused for a long period of time.



Refer servicing to qualified personnel when a solid object or liquid has fallen onto or into the device.



Do NOT attempt to service this device. Refer all servicing to qualified personnel. Opening covers other than the battery cover will void the warranty.

## Publishing Information

Copyright © 2013. EchoStar Technologies L.L.C., Englewood, Colorado 80112. All rights reserved.

The information in this *User Guide* may change without notice. Revisions may be issued to tell you about such changes.

Send comments or questions about this *User Guide* to [techpubs@echostar.com](mailto:techpubs@echostar.com) or Technical Publications, EchoStar Technologies L.L.C., 90 Inverness Drive Circle East, Englewood, Colorado 80112.

Document Number: 199935  
Printed in

DISH is a registered trademark of DISH Network L.L.C.

All product names, trade names, or corporate names mentioned in this *User Guide* are acknowledged to be the proprietary property of the registered owners.

# Configuring the 5.4 Remote

The 5.4 remote does not require any configuration. Go to *Insert the Batteries* (page 4).

# Configuring the 6.4 Remote

Complete the following steps to configure the 6.4 remote.

## Selecting the Remote Key

- 1 Confirm your receiver model and select the right key.

Look on both key sides to find the right key.






















RECEIVERS	KEYS
<p><b>ViP®722 DVR</b></p>  <p><b>ViP®222 and ViP®622 DVR</b></p> 	 <p>OR</p>  <p>IR</p> <p>UHF</p>  <p>UHF</p>
<p><b>ViP®612 DVR</b></p>  <p><b>DISH 811</b></p> 	

Table continued on next page

# Configuring the 6.4 Remote, continued

## Selecting the Remote Key, continued

- 1 Confirm your receiver model and select the right key, continued.

RECEIVERS	KEYS
<p><b>DISH 411 and ViP®211</b></p>  <p><b>ViP®211k</b></p> 	
<p><b>DISH Player-DVR 522 and DISH Player-DVR 625</b></p> 	<p> IR</p> <p>OR</p> <p> UHF</p> <p> UHF</p>
<p><b>DISH 512 DVR</b></p> 	
<p><b>DISH 501, DISH 508, and DISH Player-DVR 510</b></p> 	

# Configuring the 6.4 Remote, continued

## Selecting the Remote Key, continued

2



Decide if the remote is being used for TV1 or TV2. If it is being used for TV1, determine whether to use IR or UHF signals for the remote. Use UHF signals if you do not have a clear line of sight between the remote and the receiver.

Pull the remote battery cover off.

3



If your remote shows a “1” or a “2” on the bottom, you can pull out this key and flip it to the other number (2 to 1 and 1 to 2). To separate the key from the remote, insert your thumbnail or a coin in the crease at the bottom of the remote.

4



Remove the key by grasping at the bottom.

5



Insert the key you wish to use to designate the remote and slide into place. Usually a 1 = TV1 and a 2 = TV2. Use the green 1 (no UHF Pro markings) for TV1 IR. Use the green 1 UHF Pro for TV1 UHF.

Continue to  
*Insert the Batteries* on page 4.

# Insert the Batteries


1



Pull the remote battery cover off.



2



Insert 4 AAA batteries, making sure to match the plus (+) ends with the plus markings on the battery compartment.

3



Replace the remote battery cover.


# Making 5.4 and 6.4 IR Remote Work with Receiver

## For 5.4 and 6.4 IR

Use the following instructions to configure your remote while using IR signals.




1



Turn your receiver and TV on, and press **SYSTEM INFO** on the front of the receiver.

2



Confirm that you see the **System Info** screen.

3



Press **RECORD** on your remote. The receiver then matches the remote's address.

4



Confirm that your remote operates your receiver by pressing remote buttons.

If this is not working, return to step 3.

# Making 6.4 UHF Remote Work with Receiver

## For 6.4 UHF

Use the following instructions if you have configured your remote to use UHF signals.

1



If you installed one of these keys, continue to step 2.



If you installed this key, continue to page 10, *Making the 6.4 UHF Remote Work with DISH-Player DVR 522 and DISH-Player DVR 625 Receivers.*

2



Verify the UHF antenna is installed on the back of the receiver.

3



Turn your receiver and TV on, and press SYSTEM INFO on the front of the receiver.



# Making 6.4 UHF Remote Work with Receiver, continued


For 6.4 UHF, continued

4



Confirm that you see the **System Info** screen.

5



Press **RECORD** on your remote. The receiver then matches the remote's address.

6



Confirm that your remote operates your receiver by pressing remote buttons. If your remote has a blue number 2 key, you may need to confirm your remote operates the receiver for **2**. If this is not working, return to step 5.

# Changing the UHF Frequency for the ViP222, ViP622, and ViP722

## Only for ViP222, ViP622, and ViP722 Receivers



Only use this procedure if you are using two UHF remotes. All other receivers must use Band A position or the remote does not control the receiver.


Your remote has a switch to change the UHF frequency. The remote comes preset to the Band A position. You can change the setting to the Band B position to reduce the possibility of another UHF remote interfering with your UHF remote.

**1**



Pull the remote battery cover off.

**2**



Use a small screwdriver or a paperclip to carefully change the remote frequency from the Band A position to the Band B position.

**3**



Replace the remote battery cover.



# Making the 6.4 UHF Remote Work with DISH-Player DVR 522 and 625 Receivers

## Only For DISH-Player DVR 522 and DISH-Player DVR 625 Receivers

Use the following instructions if you are using the green number 1 UHF key to control TV1.

DISH Player-DVR 522 and  
DISH Player-DVR 625



1




Verify the correct key is installed. Verify the key is green, has no stripe, and includes the UHF Pro symbol.

2



Verify the UHF antenna is installed on the back of the receiver.

3



Turn your receiver and TV on, and press MENU on the front of the receiver.

4



Select the **System Setup** screen.

5



Then select the **Installation** screen.

# Making the 6.4 UHF Remote Work with DISH-Player DVR 522 & 625 Receivers, con't.

6




Select the **TV1 UHF Pro Setup** screen and select **Enable**.

7



Select **System Info** and confirm that you see the **System Info** screen.

8



Use the **ARROW** buttons to highlight the **Rem Addr** box.


**Note:** If you do not move the highlight, the remote changes the receiver's **Rem Addr** box and causes the remote to control the TV2 side of the receiver.

9



Press the **RECORD** button on the green TV1 remote control. If you receive a warning to pick another remote address, continue to the next step. If no warning appears, go to step 16.


10



Select **OK** on the front of the receiver to clear the warning message and return to the **System Info** screen.

# Making the 6.4 UHF Remote Work with DISH-Player DVR 522 & 625 Receivers, con't.

11



Press and hold the SAT Mode button until all Mode buttons light up. Release the SAT Mode button. The SAT Mode button flashes.

12




Use the NUMBER PAD to enter a number (between 1 and 16) that is different from the address shown for TV2. Write down the TV1 address that is shown. \_\_\_\_\_

13




Press and release POUND (#). The SAT Mode button flashes three times.

14



Use the ARROW buttons to highlight the **TV Rem Addr** box.

15




Press RECORD.

16



Verify the **System Info** screen shows UHF and the current remote address.

17




Select **Done** to close the **System Info** screen. If nothing happens, use the front panel buttons to highlight the **TV Rem Addr** box. Press the RECORD button and select **Done**.

# SAT Mode

SAT

To use the features described in this section, make sure you are in SAT mode by pressing the SAT Mode button. Use SAT Mode to control your receiver.

**Note:** Some features may not be available depending on your receiver model.




**Note:** Remote key may be different than what is shown here

# TV Mode

TV

To use the features described in this section, make sure you are in TV mode by pressing the TV Mode button. Remote programming is required.

**Note:** Some features may not be available depending on your receiver model or TV device code.



**Note:** Remote operation is different on DISH TVs. See your DISH TV User's Guide for proper operation.




# DVD/VCR Mode

DVD

To use the features described in this section, make sure you are in DVD mode by pressing the DVD Mode button. You can use this mode to operate a Blu-ray Disc™ player or VCR. Remote programming is required.

**Note:** Some features may not be available depending on your receiver model.



**Note:** Remote key may be different than what is shown here

# Programming Remote to Control Another Device

## Entering a Code

1



Turn the device and receiver on.

2



Find the brand name of the device listed in the code tables that start on page 32.

3



Press and hold the correct Mode button until all Mode buttons light up. Release the Mode button. Mode button lights flash.

**For AUX Mode only** 

Press

- 0 for second TV
- 1 for a second DVD/VCR/BD
- 2 for a tuner, amplifier, or audio receiver
- 3 for a second satellite receiver

# Programming Remote to Control Another Device

## Entering a Code, continued

4



Enter one of the three-digit device codes from the table, found in step 2, using buttons on the number pad, such as device code 560. Press 1 after the device code if you want to program Limited Mode. See *Placing Remote in Limited Mode and Removing Limited Mode* on page 21 for more information.

5



Press POUND (#). The Mode button flashes three times.

6



Press POWER to test if the code works for the device. If it does, the device turns off.

7



Turn device on and try other buttons to make sure the device responds the way you expect. If you want to try another code, begin from Step 1 again.

8



If you are unable to find a code that works, try the instructions for *Scanning the Remote Database* on page 18.

# Programming Remote to Control Another Device

## Scanning the Remote Database


**Note:** Only use *Scanning the Remote Database* if you were unable to find a code using *Entering a Code*. This procedure can take several minutes.

1



Turn the device and receiver on.

2



Press and hold the correct Mode button for the device until all Mode buttons light up. Release the Mode button. The Mode button flashes. If programming TV or DVD Mode buttons, go to step 4. If programming AUX Mode button, continue to step 3.

3



### For AUX Mode only

Press

- 0 for second TV
- 1 for second DVD/VCR/BD
- 2 for tuner, amplifier, or audio receiver

Press the STAR (\*) button.

◀/FORMAT



4

POWER



Press POWER.

# Programming Remote to Control Another Device

## Scanning the Remote Database, continued

5




Pointing the remote at the device the entire time, press and release UP ARROW slowly. The Mode button light goes out and comes back on. When the device turns off, continue to Step 6. If the device remains on, continue pressing UP ARROW. When all codes have been tried, the Mode button flashes eight times.

6



Press and release POUND (#). The Mode button flashes three times.

7



Turn the device on and try other buttons to make sure the device responds the way you expect. If not, try another code by returning to Step 1.

# Displaying Device Code and Remote Address

To identify the device code that your remote control is using or to display the remote control address, complete the following steps:

1



Press and hold the Mode button for the device until all the Mode buttons light up. Release. The selected Mode button flashes. To display the remote control address, press and hold the SAT Mode button until all the Mode buttons light up. Release. SAT flashes.

2



Press and release POUND (#) twice.

3



The Mode button flashes a number of times corresponding to the value of the stored device code. If Limited Mode is used, the last flash represents Limited Mode. For example, if the stored device code is 593, the Mode button flashes five times, pauses, flashes nine times, pauses, and flashes three times. A quick flash is for zero.

If SAT was pressed to display the remote address, the SAT Mode button flashes 1 to 16 times, giving the remote address.



**For AUX mode:** The first group of flashes tells you what the AUX mode controls, then the following flashes tell you each digit of the device's code.

- 0 for second TV
- 1 for second DVD/VCR/BD
- 2 for tuner, amplifier, or audio receiver

4



(Optional)

Record the stored device code in the Reference Table on the inside back cover.

# Placing Remote in Limited Mode and Removing Limited Mode


Limited Mode locks out all the device mode operations except for the device's Power, Mute, and Volume. This prevents you from accidentally tuning away from satellite programming.




If TV Mode is put into Limited Mode, this means that when the TV Mode button is pressed, the remote does not stay in TV Mode but returns to the last Mode selected.

To place the remote in Limited Mode or to remove Limited Mode from TV Mode, follow the steps below.

**Note:** Limited Mode cannot be used with audio amplifiers.

1



Press and hold the TV , DVD , or AUX  Mode button until all Mode buttons light up.

2



Press PAGE UP to activate.

Press PAGE DOWN to take the remote out of Limited Mode.

3



Press POUND (#).

# SAT Auto-Tune

SAT Auto-Tune programs into the remote control the correct TV channel used for watching TV. If you are experiencing fuzzy, snowy, blue, or black screens, it might be due to the TV being set to the wrong channel. Using the SAT Auto-Tune feature helps prevent these screen issues from occurring on TVs connected to the receiver's modulated output (usually TV2). Use SAT Auto-Tune to program the correct TV channel for satellite viewing into the remote control. When SAT is pressed and released, the remote sends that channel to the TV, ensuring that the TV is on the correct channel for watching TV.

This feature is enabled by default; however, if you want to use this feature, the channel must be programmed by following the steps in *Setting SAT Auto-Tune Channel*.


## Setting SAT Auto-Tune Channel

1



Make sure the remote control operates your TV.

2



Press and hold TV until all four Mode buttons are lit.

3

◀/FORMAT



Press STAR (\*).

4



Enter the channel used for viewing (two or three digits in range of 002 to 125), for example channel "10" or "010."

5

SEARCH



Press POUND (#). The Mode button flashes three times to indicate programming was successful.

6




Press SAT. The channel changes.



# Enabling and Disabling SAT Auto-Tune

**Note:** SAT Auto-Tune is enabled by default; however, the channel must be set (see *Setting SAT Auto-Tune Channel* on page 22).

1




Press and hold SAT until all four Mode buttons are lit.

2



Press STAR (\*).

3



Press VOLUME UP to enable SAT Auto-Tune or VOLUME DOWN to disable.


4



Press POUND (#). SAT flashes three times to indicate SAT Auto-Tune is enabled or disabled.

## Removing SAT Auto-Tune Channel

1




Press and hold the TV Mode button until all four Mode buttons are lit.

2



Press STAR (\*).

3



Enter 00 or 000.

4



Press POUND (#). TV Mode button flashes three times to indicate SAT Auto-Tune has been removed.

# Setting Auto-Tune for DVD/VCR

You can set Auto-Tune for your DVD and/or VCR. Auto-Tune allows you to return to the channel for your DVD/VCR output when you accidentally change the channel or video input.


**Note:** This feature is only used while recovering your picture. See *Recovering your Picture* on page 26.

1



Make sure the remote control operates your DVD/VCR.

2



Press and hold DVD until all four Mode buttons are lit.

3



Press STAR (\*).

4



Enter the channel used for viewing (two or three digits in range of 002 to 125), for example channel "03" or "004."

5




Press POUND (#). The DVD Mode button flashes three times to indicate programming was successful.

# Removing Auto-Tune for DVD/VCR

If you want to remove Auto-Tune for your DVD and/or VCR, follow the steps below.

1




Press and hold DVD until all Mode buttons are lit.

2



Press STAR (\*).

3



Enter 00 or 000.

4



Press POUND (#).


# Recovering Your Picture



Use the RECOVER button to return to watching satellite programming if you accidentally change channels or inputs on your TV, DVD, and/or VCR. To best use this feature, you must set up SAT Auto-Tune for your TV (see page 22) and for your DVD/VCR (see *Setting Auto-Tune for DVD/VCR* on page 24).

**Note:** RECOVER only works if the remote control has been set up to control the TV and/or DVD/VCR, if connected. If the RECOVER button is used, the TV channel programmed for SAT Auto-Tune is also the channel that is sent to the TV. If SAT Auto-Tune is not programmed, RECOVER first tries to tune your TV to channel 3, then channel 4, and then other video inputs with each press of the RECOVER button. If SAT Auto-Tune is programmed, RECOVER tries to tune your TV to the channel given in SAT Auto-Tune and then other video inputs with each press of the RECOVER button. You may need to press the RECOVER button up to 30 times to recover your satellite TV video. If SAT Auto-Tune is not set up, RECOVER only tries channels 3 and 4.

1




Press and hold RECOVER until all Mode buttons light up.

2



If you see the **System Info** screen, proceed to step 4. Otherwise, continue to step 3.

3



Press RECOVER again and wait until the Mode lights stop flashing. If you see the **System Info** screen, go to step 4. If not, repeat this step until you see the **System Info** screen.

4




Press SELECT to resume watching TV.

# Control Amplifier Volume

When the remote control is set up to operate your TV, the MUTE and VOLUME buttons adjust your TV volume when in SAT mode. To use the remote to adjust the volume of a remote-controllable audio receiver or amplifier instead of adjusting the TV's volume setting, use the steps on this page.

1




Press and hold AUX until all Mode buttons are lit, then release it. The AUX mode button flashes.

2



Press POUND (#).

3



Press the plus (+) side of the VOLUME button.

4



Press the 0 number button.

5



Press POUND (#). The AUX mode button flashes three times.


***Make sure the remote adjusts the amplifier's volume in other modes:***

6



Press SAT.

7



Press the plus (+) and minus (-) sides of the VOLUME button.

8




Your tuner/amplifier's volume changes, and the AUX mode button lights.

# Control TV Volume

Use this procedure to change from having the remote adjust the volume of an audio receiver or amplifier to having the remote adjust the TV's volume. When the remote control is set up to operate your TV, the MUTE and VOLUME buttons adjust your TV volume when in SAT mode.

**Note:** It is only necessary to do these steps if the remote had been set up to control the volume on an audio device and now you want the remote to adjust the volume of a TV.

1




Press and hold TV until all Mode buttons are lit, then release it. The TV mode button flashes.

2



Press POUND (#).

3



Press the plus (+) side of the VOLUME button.

4



Press the 0 number button.

5



Press POUND (#). The TV mode button flashes three times.


**Make sure the remote adjusts the TV's volume in other modes:**

6



Press SAT.

7



Press the plus (+) and minus (-) sides of the VOLUME button.

8



Your TV's volume changes, and the TV mode button lights.

# Programming Remote to Control Second Receiver in AUX Mode

If you have another DISH receiver installed, you can use this remote control in AUX mode to operate your new receiver. AUX mode uses only IR signals, so the line of sight from the remote to the second receiver must be unobstructed. You can program the remote control to operate any other DISH receiver except where UHF is used, such as TV2 on DISH receivers.

1




Turn on the second receiver and open **System Info** screen.

2



Write down the TV1 address that is shown. \_\_\_\_\_

3



Press and hold AUX until all Mode buttons light up, then release the button. AUX flashes.

4



Use the Number Pad on the remote control to enter a 3, followed by the address in step 2.

5



Press POUND (#). AUX flashes three times.

6



Press RECORD to verify that the address in the remote control now matches the address for the receiver.

# Discrete Codes


Discrete On and Off IR-only remote-control commands are used by installers when programming macro commands into universal remotes. Using an On-only or Off-only command is more effective than a toggle On/Off command when trying to ensure the receiver is reliably in one state or the other.

1



Program the DISH remote to the desired remote address (see *Changing the Remote and Receiver Address*, page 31).

2




Hold SAT until all Mode buttons light, then release.

3



Press POWER (not TV POWER).

4



Press VOLUME UP for discrete power on. Press VOLUME DOWN for discrete power off.

5



Press any other button to end this procedure.



# Changing the Remote and Receiver Address

Sometimes the receiver picks up UHF interference from another receiver in the house or even a neighbor's. If you notice that your receiver is changing channels or opening menus but you are not using the remote control, changing the address should fix the problem.

1




Press **SYSTEM INFO** on the receiver's front panel.

2



Write down the TV2 remote address shown on the **System Info** screen.

3



Press and hold **SAT** on your remote control, until all the Mode buttons light up, and then release **SAT**.

4



Add one to the address that you wrote down in step 2, and use the **NUMBER PAD** to enter that number (between 1 and 16).

5



Press **POUND (#)**.

6



Press **RECORD**.

7



Press several buttons on the remote to make sure it is working as expected.

# TV Codes

TV

This table contains the manufacturer codes for programming the remote control to operate your TV. If your TV brand is not listed or if the codes do not work, the remote may not control your TV. In some cases, codes may operate some, but not all buttons, shown in this guide.

**Note:** If programming a second TV in AUX mode, press 0 before entering the TV code.

<b>Abex</b> 730	<b>Curtis Mathes</b> 506 516 526
<b>Action</b> 662	573 590 641 645 650 652 654
<b>Admiral</b> 521 605 675	658 680 683 703 708
<b>Aiko</b> 727	<b>CXC</b> 541 657 662
<b>Akai</b> 570 573 906 907 908	<b>Cytron</b> 903 904
<b>Alleron</b> 682	<b>Daewoo</b> 505 524 526 529 530
<b>A-Mark</b> 620	531 573 630 652 653 654 658
<b>Amtron</b> 657	684 698 719 727 816
<b>Anam National</b> 509 541 620	<b>Daytron</b> 526 627 652 654 658
651 657 698	<b>Dell</b> 772 773 774
<b>AOC</b> 505 506 519 520 573 620	<b>Dimensia</b> 645 650
627 652 653 654	<b>Dixi</b> 566 620
<b>Apex</b> 743 744 745 757 814	<b>Dumont</b> 501 627 652
815	<b>EchoStar</b> 722
<b>Archer</b> 620	<b>Electrohome</b> 526 573 651 652
<b>Audiovox</b> 620 657 662	654 656 709 728
<b>Baycraft</b> 536	<b>Emerson</b> 526 534 536 541 573
<b>Belcor</b> 652	590 627 636 642 648 652 654
<b>Bell &amp; Howell</b> 590 675 683	655 657 658 662 682 683 692
<b>Bradford</b> 657	696 699 720 816
<b>Brockwood</b> 627 652	<b>Envision</b> 506 573 652 654
<b>Broksonic</b> 562 748 752	<b>Fisher</b> 542 590 683
<b>Candle</b> 506 523 525 536 627	<b>Fortress</b> 573
652 654	<b>Fujitsu</b> 534 682 694
<b>Candle/Citizen</b> 573	<b>Funai</b> 534 541 657 662 682
<b>Capehart</b> 519 627	694
<b>Circuit City</b> 627	<b>Futuretech</b> 541 657 694
<b>Citizen</b> 506 516 523 524 525	<b>General Electric</b> 508 509 543
526 590 652 654 657 658 680	544 627 630 645 646 650 651
727	652 654 676 690 691 698 701
<b>Colortyme</b> 573 627 652 654	715 716 725 728 742 779 809
<b>Concerto</b> 523 652 654	859
<b>Contec/Cony</b> 541 655 657	<b>Gibraltar</b> 501 652
662 726	<b>Goldstar</b> 505 523 526 545 546
<b>Craig</b> 536 541 657 662 694	566 573 652 653 654 655 656
<b>Crown</b> 526 536 657	658 693 730

*Table continued on next page*

# TV Codes, continued

TV

- Granada** 627  
**Grand** 627  
**Grunpy** 657 682  
**Hallmark** 627 652 654  
**Harman/Kardon** 561  
**Harvard** 657  
**Hinari** 534  
**Hisense** 759  
**Hitachi** 523 526 548 549 553  
554 555 585 597 626 636 638  
643 648 652 654 655 702 718  
726 786 788 789 790 791 792  
801 802  
**HP** 911 912  
**IMA** 657  
**Infinity** 566  
**JBL** 566  
**JC Penney** 505 506 516 525  
526 543 546 631 645 646 650  
652 653 654 658 676 680 690  
691 701 725 726 728 730  
**Jensen** 556 573 652 654  
**JVC** 508 557 559 642 649 655  
676 726 735 736 737 812 817  
**Kawasho** 548 561 573 652 654  
**Kenwood** 506 573 652 654 656  
**Kloss** 561 610  
**Kloss Novabeam** 657 698 723  
724  
**KTV** 526 541 573 657 658 662  
696  
**LG** 653 766  
**Lloyd's** 627  
**Lloytron** 526  
**Loewe** 566  
**Logik** 675  
**Luxman** 523 652 654  
**LXI** 563 566 590 595 617 631  
635 645 646 650 654 683 691  
701 725  
**M. Wards** 500 505 506 534  
543 567 568  
**Magnasonic** 573  
**Magnavox** 506 520 525 536  
566 567 568 573 610 652 654  
656 723 724 729 762 818 887  
888  
**Majestic** 675  
**Marantz** 506 566 573 652 654  
**Megatron** 627 654  
**Memorex** 590 627 653 654  
675 683 720  
**MGA** 504 505 506 542 571 573  
627 652 653 654 656 728  
**Midland** 501 646 658 676 725  
730  
**Mitsubishi** 504 505 542 570  
571 572 573 597 623 627 652  
653 654 656 705 728 787 799  
804  
**Mitsui** 769  
**Montgomery Ward** 500 505  
506 534 543 567 568 675  
**Motorola** 521 605 651  
**MTC** 505 506 516 523 573 627  
652 653 654 680  
**Multitech** 657  
**NAD** 502 617 627 631 635 637  
654  
**National** 509  
**NEC** 505 506 507 517 523 573  
627 651 652 653 654 731 732  
**Nikkai** 612  
**Nikko** 654 727  
**Normandic** 717  
**Novabeam** 561  
**NTC** 727  
**Nyon** 701  
**Olevia** 910  
**Onwa** 541 657  
**Optimus** 637  
**Optonica** 521 605 607  
**Orion** 694  
**Osaki** 612

Table continued on next page

# TV Codes, continued

TV

**Panasonic** 508 509 512 566  
644 651 662 676 685 689 698  
700 716 734 761 765 780 784  
811 819 820 821 822 823 867  
868 869 870 871 872 873 874  
875 876 877 878 879 880 881  
882 883 884 885 886 889 890  
900

**Philco** 505 506 525 536 568  
573 610 651 652 653 654 655  
656 723 724 729

**Philips** 525 566 651 652 655  
656 690 723 724 729 770 782  
824 825 826 827 828 891 892  
893 894

**Philips Magnavox** 782 826  
827 828 829

**Pilot** 652 658

**Pioneer** 502 548 576 636 637  
648 652 654 708

**Polaroid** 766

**Portland** 505 526 573 652 653  
654 658 727

**Price Club** 680

**Prism** 676

**Proscan** 645 646 650 691 725  
742 857

**Proton** 513 519 526 536 585  
627 652 654 655

**Proview** 902

**Pulsar** 501 652

**Quasar** 508 509 651 676 698  
700 860 861 862 895 896

**Radio Shack** 526 541 590 607  
612 645 662 683 698

**Radio Shack/Realistic** 590  
607 650 652 654 655 657 658  
683 730

**RCA** 503 505 548 630 633 634  
636 641 645 646 648 650 651  
652 653 654 656 691 698 701  
708 715 716 725 742 749 776  
805 830 831 832 863 864

**Realistic** 590 645 683

**Runco** 501

**Sampo** 506 519 652 654 658  
698 730 746

**Samsung** 505 506 516 523  
526 566 573 612 627 647 652  
653 654 655 656 658 680 704  
717 730 738 755 833 858 897

**Samwon** 620

**Sansui** 754 834

**Sanyo** 542 590 652 683

**SBR** 566

**Schneider** 566

**Scotch** 654

**Scott** 526 534 541 600 652  
654 655 657 662 682 696 701

**Sears** 523 534 542 563 590  
595 601 604 617 627 631 635  
645 646 650 652 654 656 682  
683 688 691 703 725 726

**Seimitsu** 627

**Sharp** 521 526 585 605 607  
628 629 652 654 655 658 739  
740 741 777 794 803 835 836  
898 913

**Shogun** 652

**Signature** 675

**Silver** 573

**Simpson** 525

**Solavox** 612

**Sony** 500 640 690 758 781  
783 795 796 797 798 806 807  
808 810 837 838 839 840 841  
842 843 844 845

**Soundesign** 525 536 541 627  
652 654 657 682

**Spectricon** 520 620

**Squareview** 694

**SSS** 505 541 573 652 657

**Starlite** 657

**Supra** 523

**SVA** 901 905

*Table continued on next page*

# TV Codes, continued

TV

**Sylvania** 506 525 536 566

568 569 573 600 610 652 654

656 723 724 729 733 756 764

**Symphonic** 632 657 662 692

694 846

**Tandy** 521 605

**Tatung** 509 651 698

**Technics** 508 676

**Techwood** 523 573 652 654 676

**Teknika** 504 505 512 516 523

524 525 526 534 536 541 573

644 652 653 654 655 657 658

662 675 680 682 685 726 727

**Tera** 513

**Thomas** 627

**Thompson** 709

**TMK** 523 573 627 652 654

**Toshiba** 516 590 617 631 635

680 683 688 750 771 785 793

847 848 849 850 851 852 853

854 855 856 865 866 909

**Totevision** 526 658

**Toyomenko** 627

**Universal** 543 690

**Vector Research** 506

**Victor** 557

**Video Concepts** 570

**Vidtech** 505 573 627 652 653

654

**Viewsonic** 760

**Vizio** 766

**Wards** 536 573 607 645 650

652 653 654 656 675 682 690

715 723 724 729

**White Westinghouse** 816

**Yamaha** 505 506 573 652 653

654 656

**York** 627

**Zenith** 501 520 639 652 675

693 775 778 813 899

**Zonda** 620

# VCR Codes

DVD

This table contains the manufacturer codes for programming the remote control to operate your VCR. If your VCR brand is not listed or if the codes do not work, the remote may not control your VCR. In some cases, codes may operate some, but not all, buttons shown in this guide.

**Note:** If programming your VCR in AUX mode, press 1 before entering the VCR code.

<b>Adventura</b> 588	<b>Funai</b> 588
<b>Aiwa</b> 588 622 623	<b>Garrard</b> 588
<b>Akai</b> 513 515 516 517 518 568 682	<b>General Electric</b> 551 552 554 572 591 605 607 675 678
<b>American High</b> 678	<b>Go Video</b> 557 558 620
<b>Amstrad</b> 588	<b>Goldstar</b> 592 594 676
<b>ASA</b> 556	<b>Goodmans</b> 585
<b>Asha</b> 675	<b>Gradiente</b> 588
<b>Audio Dynamics</b> 592	<b>Granada</b> 549 581
<b>Audiovox</b> 676	<b>Grundig</b> 556
<b>Beaumarck</b> 675	<b>Harley Davidson</b> 588
<b>Bell &amp; Howell</b> 581	<b>Harman/Kardon</b> 568 592
<b>Broksonic</b> 559	<b>Headquarter</b> 581
<b>Calix</b> 676	<b>Hitachi</b> 536 538 539 540 588 595 597 682
<b>Candle</b> 534 594 675 676	<b>Instant Replay</b> 678
<b>Canon</b> 554 678	<b>ITT</b> 518
<b>Citizen</b> 534 591 592 594 675 676	<b>JC Penney</b> 554 581 591 592 594 595 675 676 678
<b>Colortyme</b> 592	<b>JCL</b> 678
<b>Craig</b> 591 675 676	<b>Jensen</b> 595 682
<b>Curtis Mathes</b> 554 592 594 605 607 675 678	<b>JVC</b> 561 562 581 592 594 682
<b>Cybernex</b> 675	<b>Kenwood</b> 562 581 592 594 682
<b>Daewoo</b> 534 547 559 588	<b>Kodak</b> 676 678
<b>DBX</b> 592	<b>LG</b> 676
<b>Dimensia</b> 607	<b>Lloyd's</b> 588
<b>Dumont</b> 549	<b>Luxor</b> 518
<b>Dynatech</b> 588	<b>LXI</b> 676
<b>Electrohome</b> 512 676	<b>M. Wards</b> 512 554 585 590 591
<b>Electroponic</b> 676	<b>Magnavox</b> 533 554 556 678 797 798
<b>Emerson</b> 505 508 509 511 512 518 534 559 568 588 590 618 676 678	<b>Magnin</b> 676
<b>Finlandia</b> 549	<b>Marantz</b> 554 556 581 585 592 594 678
<b>Finlux</b> 549 556 588	<b>Marta</b> 676
<b>Fisher</b> 549 581 584 588 610	<b>Matsushita</b> 678
<b>Fuji</b> 678	

*Table continued on next page*

# VCR Codes, continued

DVD

- MEI** 554 678  
**Memorex** 533 549 554 566  
581 585 588 675 676 678  
**MGA** 512 567 568  
**MGN Technology** 675  
**Midland** 579  
**Minolta** 595  
**Mitsubishi** 512 562 567 568  
570 595  
**Montgomery Wards** 512 554  
585 590 591  
**Motorola** 678  
**MTC** 544 588 675  
**Multitech** 579 588 591 675  
**NEC** 562 581 592 594 682  
**Nikko** 676  
**Noblex** 675  
**Olympus** 678  
**Optimus** 676  
**Optonica** 585  
**Panasonic** 554 614 628 633  
678 777 780 781 782 783 784  
785 786 787 788 789 790 791  
792 793 794 795 796 799 808  
809  
**Pentax** 592 595  
**Pentax Research** 594  
**Perdio** 588  
**Philco** 554 678  
**Philips** 554 556 585 678 801  
802 803 804  
**Pilot** 676  
**Pioneer** 562 574 575 576  
**Proscan** 605 607  
**Pulsar** 533  
**Quarter** 581  
**Quartz** 581  
**Quasar** 554 678 770 771 772  
805 806  
**Radio Shack** 512 607 610 676  
**Radio Shack/Realistic** 581  
584 588 675 676 678  
**Radix** 676  
**Randex** 676  
**RCA** 518 525 591 595 605 607  
615 649 675 678 773 774 775  
**Realistic** 534 549 554 581 584  
585 588 675 676 678  
**Ricoh** 502  
**Runco** 533  
**Salora** 567 581  
**Samsung** 515 517 534 579  
591 675 755 807  
**Sanky** 533  
**Sansui** 544 562 682  
**Sanyo** 549 581 583 675  
**SBR** 556  
**Scott** 508 534 559 590  
**Sears** 549 581 584 595 610  
676 678  
**Sharp** 512 585 595 607  
**Shintom** 595  
**Shogun** 675  
**Singer** 678  
**Sony** 500 501 502 768 778  
**STS** 678  
**Sylvania** 554 556 567 588 678  
756  
**Symphonic** 588 594  
**Tandy** 581 588  
**Tashiko** 676  
**Tatung** 594 682  
**Teac** 588 594 682  
**Technics** 554 633 678  
**Teknika** 554 588 676 678  
**TMK** 675  
**Toshiba** 534 535 567 584 590  
769 776  
**Totevision** 591 675 676  
**Unitech** 675  
**Vector Research** 534 592  
**Victor** 561 562  
**Video Concepts** 534 568 592  
**Videosonic** 591 675  
**Wards** 534 588 595 675 676  
678  
**XR-1000** 588 678  
**Yamaha** 581 592 594 682  
**Zenith** 500 501 533 779

# DVD Player Codes

DVD

This table contains the manufacturer codes for programming the remote control to operate your DVD or Blu-ray Disc™ Player. If your DVD Player brand is not listed or if the codes do not work, the remote may not control your DVD Player. In some cases, codes may operate some, but not all, buttons shown in this guide. **Note:** If programming a DVD Player in AUX mode, press 1 before entering the DVD Player code.

<b>Aiwa</b> 634 694	<b>Philips</b> 766 874
<b>Alpine</b> 653	<b>Pioneer</b> 665 719 812 876 877
<b>Apex</b> 654 655 744 757 835	878 879 880
839	<b>Proscan</b> 720
<b>Archos</b> 885	<b>Qwestar</b> 723
<b>BOSE</b> 758 811	<b>RCA</b> 666 690 749 816 842 854
<b>Broksonic</b> 656 752	<b>Sampo</b> 724
<b>Clarion</b> 696	<b>Samsung</b> 652 667 668 691
<b>Classic</b> 695	705 740 741 820 821 844 845
<b>CyberHome</b> 833	866 875 881
<b>CYTRON</b> 904	<b>Sansui</b> 725 754
<b>Daewoo</b> 657 859	<b>Sanyo</b> 643
<b>Denon</b> 697 699 700	<b>Sharp</b> 669 865
<b>EchoStar</b> 722	<b>Sony</b> 617 645 670 671 729
<b>Emerson</b> 658	730 731 817 818 830 831 832
<b>Fisher</b> 659	836 837 838 843 847 848 849
<b>Funai</b> 658	851 852 853 857 858 864 883
<b>General Electric</b> 702 703	884
<b>Go Video</b> 692 693 822	<b>Sylvania</b> 658 764 829
<b>GPX</b> 704	<b>Teac</b> 732
<b>Hitachi</b> 660 668 705 706 707	<b>Technics</b> 733
740 823 860	<b>Techwood</b> 664
<b>JVC</b> 689 711 850 861 862 863	<b>Toshiba</b> 616 646 672 735 736
<b>Konka</b> 637 638 753	814 815 819 825 826 827 828
<b>Koss</b> 745	834 846
<b>Magnavox</b> 661	<b>Yamaha</b> 737 739
<b>Memorex</b> 709	<b>Zenith</b> 673 824
<b>Mintek</b> 710	
<b>Mitsubishi</b> 767 867	
<b>Norcent</b> 711	
<b>Oritron</b> 723	
<b>Panasonic</b> 639 663 699 714	
715 716 734 737 765 813 840	
841 855 856 868 869 870 871	
872 873 882	



# Tuner/Amplifier Codes

AUX

This table contains the manufacturer codes for programming the remote control to operate your tuner/amplifier. If your tuner/amplifier is not listed or if the codes do not work, the remote may not control your tuner/amplifier. In some cases, codes may operate some, but not all, buttons shown in this guide. **Note:** If programming a tuner/amplifier in AUX mode, press 2 before entering the Tuner/Amplifier code.

**Aiwa** 636 641 656 687 718  
720 725 726

**BOSE** 761 780

**Carver** 653

**Citizen** 709

**Denon** 647 674 759 760 762  
807 809 814 835

**Fisher** 653

**General Electric** 711

**Goldstar** 677 690

**Harman/Kardon** 640 672 751

**Hitachi** 717

**JBL** 640

**JVC** 637 703 725 786 827

**Kenwood** 676 691 726 728  
774 795 828 829 830 831 832  
840 842

**Magnavox** 654 705

**Marantz** 651 764 845

**Nakamichi** 671

**NEC** 716

**Onkyo** 642 660 662 678 785 788  
790 791 792 796 801 846

**Optimus** 648 664

**Panasonic** 643 644 652 783  
797 798 799 808 810 815 816  
817 818 819 820 821 822 824  
825 826 833 836 837 838 839

**Pioneer** 667 668 679 702 767  
770 772 779 802 806 844

**Proton** 654 705

**Quasar** 652

**RCA** 635 638 704 727

**Sharp** 712 713 714 715

**Sherwood** 646 670

**Sony** 639 645 687 728 729 730  
765 766 769 771 773 775 776  
777 778 781 782 784 787 789  
793 794 803 811 812 813

**Soundmatters** 763

**Teac** 684

**Technics** 643 644 652 768 804  
805 843

**Toshiba** 710

**Victor** 703

**Yamaha** 663 730 731 732 733  
823 834 841

# Combo Codes

The following tables contain the manufacturer codes for programming the remote control to operate combined devices. If your combined device brand is not listed or if the codes do not work, the remote may not control your combined device. In some cases, codes may operate some, but not all, buttons shown in this guide.

## TV/VCR Codes



**Note:** Program the remote control in TV mode using the TV code and then in DVD/VCR mode (or in AUX—press 1 before entering the VCR code) using the VCR code.

### Magnavox

TV Code 887 888

VCR Code 797 798

### Philips

TV Code 891 892 893  
894

VCR Code 801 802 803  
804

### Quasar

TV Code 860 861 862  
895 896

VCR Code 770 771 772  
805 806

### RCA

TV Code 863 864

VCR Code 773 774

### Samsung

TV Code 755 897

VCR Code 755 807

### Sylvania

TV Code 756

VCR Code 756

# Combo Codes, continued

## TV/DVD Codes

TV

DVD

**Note:** Program the remote control in TV mode using the TV code and then in DVD/VCR mode (or in AUX—press 1 before entering the DVD code) using the DVD code.

### **Apex**

TV Code 757

DVD Code 757

### **Broksonic**

TV Code 752

DVD Code 752

### **CYTRON**

TV Code 904

DVD Code 904

### **Panasonic**

TV Code 734 765

DVD Code 734 765

### **RCA**

TV Code 749

DVD Code 749

### **Sansui**

TV Code 754

DVD Code 754

### **Sylvania**

TV Code 764

DVD Code 764

### **Toshiba**

TV Code 865 866

DVD Code 814 815

# Combo Codes, continued

## DVD/VCR Codes



**Note:** Program the remote control in DVD/VCR mode using one of the listed DVD codes, and then in AUX mode, first pressing 1 and then using the listed VCR code.

### **Go Video**

DVD Code 692 693 822

VCR Code No Code

### **JVC**

DVD Code 689

VCR Code No Code

### **RCA**

DVD Code 690

VCR Code No Code

### **Samsung**

DVD Code 667 691 820 821

VCR Code No Code

### **Sony**

DVD Code 817 818

VCR Code 768 778

### **Toshiba**

DVD Code 819

VCR Code No Code

### **Zenith**

DVD Code No code

VCR Code 779

# Combo Codes, continued

## TV/VCR/Tuner Codes

TV

DVD

AUX

**Note:** Program the remote control in TV mode using the TV code and then in DVD/VCR mode and then in AUX mode (press 2 before entering the tuner code) using the tuner code.

### Panasonic

TV Code	867 868 869 870 871 872 873 874 875 876 877 878 879 880 881 882 883 884 885 889
VCR Code	780 781 782 783 784 785 786 787 788 789 790 791 792 793 794 795 796 799 808 809
Tuner Code	797 798 799 808 815 816 817 818 819 820 821 822 824 825 826 833 836 837 838 839

## TV/DVD/VCR Codes

TV

DVD

AUX

**Note:** Program the remote control in TV mode using the TV code and then in DVD/VCR mode using the DVD code, and then in AUX mode (press 1 before entering the VCR code) using the VCR code.

### Panasonic

TV Code	900
DVD Code	882
VCR Code	810

# Troubleshooting

Use this information if you have a problem using the remote. To solve a particular problem, do the following:

- Find the information that relates to the problem you are experiencing. Try the suggested solution for that problem.
- Make sure your remote control has fresh batteries. If you see the Remote Battery Low warning on your TV screen, it is time to change the batteries. Follow the instructions on page 4.
- Make sure you have a direct line of sight between the remote and the receiver.
- Visit [www.mydish.com](http://www.mydish.com).

## **While performing a remote control procedure, the remote control stops working.**

**What to do:** Start over again. If you don't press a button for 20 seconds in a programming sequence, the remote shuts off its programming function.

## **When you press a button on the remote control, the equipment doesn't do what you expect.**

**What to do:** Point the remote control directly at the TV, with no objects blocking the signal path. The remote control uses IR signals to control the receiver. IR signals travel less than 40 feet and cannot go through walls or other solid objects.

If the batteries are missing or dead, replace them with new AAA-size batteries. If the remote has new batteries, check whether you put them in correctly. If you didn't, take them out and put them in the right way.

## **When you try to enter TV programming mode, all the mode LEDs flash.**

**What to do:** Replace the batteries (see page 4).

# Troubleshooting, continued

## **Your remote control does not work well.**

**What to do:** Move your receiver to different locations. For best results, place the receiver as high as possible, above all other equipment in your entertainment center. There may be IR interference from objects near the receiver.

## **Your picture is snowy (or black or blue).**

**What to do:** If SAT Auto-Tune has been enabled, press SAT to return to watching TV.

Make sure your TV is tuned to the correct channel. You may have accidentally changed the channel on your TV. Check the Reference Table to see what channel your TV is tuned to. Program SAT Auto-Tune to avoid this in the future (see *SAT Auto-Tune* on page 22).

## **When you press the remote control MUTE or VOLUME button, nothing happens.**

**What to do:** Program the remote to control your TV. See *Programming Remote to Control Another Device* on page 16.

## **The receiver does things even though you have not pressed any remote control buttons.**

**What to do:** See *Changing the Remote and Receiver Address* on page 31 for instructions to correct the possibility of UHF signals from a neighbor's remote controlling your receiver.

## **Your remote control isn't working.**

**What to do:** Make sure the remote control is in the correct mode (SAT, TV, DVD, or AUX).

Make sure you are using the correct remote control (TV1 or TV2) for your locations (applicable to multi-room receivers only).

Change the batteries as described on page 4.

# Troubleshooting, continued

## **Your UHF Pro remote control does not work well from far away.**

**What to do:** Make sure the UHF antenna is connected to the receiver and not touching anything else.

Vary the angle of the receiver's UHF antenna.

Locate the UHF antenna tip away from other electronics equipment or metal surfaces, even if separated by wooden shelving.

Move the receiver to different locations. For best results, place the receiver as high as possible, above all other equipment in your entertainment center.

Place the UHF antenna outside the entertainment center by using a coaxial cable to connect it to the receiver.

Move any nearby off-air antenna away from the UHF remote antenna. Do not place an off-air antenna on your receiver.

## **Your remote control returns to the previously pressed Mode button every time the TV Mode button is pressed.**

**What to do:** Take the remote control out of Limited Mode, following the instructions on page 21, *Placing Remote in Limited Mode and Removing Limited Mode*.

## **You cannot find the key(s) shown on page 1 or 2.**

**What to do:** Turn the keys over until you find the correct key.

## **The PIP (Picture-in-Picture) button is not working.**

**What to do:** If available, press the MODE button on the front panel to put the receiver in Single Mode. If not available, upgrade to a receiver with this feature.



# Limited Warranty



This Limited Warranty is a legal document. Keep it in a safe place. Remember to retain your Bill of Sale for warranty service! Any items returned without a copy of the Proof of Purchase will be considered out of warranty.

This warranty extends only to the original user ("you," "your") of the DISH remote control and is limited to the purchase price of the remote control. DISH Network L.L.C. and its affiliated companies ("DISH," "we," "our," "us") warrant this remote control system against defects in materials or workmanship as follows.

For one year from the original date of purchase, if we find the remote control is defective subject to the limits of this warranty, we will replace the remote at no charge for parts or labor. We warrant any such work done against defects in materials or workmanship for the remaining part of the original warranty period.

This warranty does not cover installation of the DISH Network System; consumer instruction; physical set up or adjustment of any consumer electronic equipment; remote control batteries; signal reception problems; loss of use of the equipment; unused programming charges due to equipment malfunction; cosmetic damage; damage due to lightning, electrical or telephone line surges, fire, flood, or other acts of Nature; accident; misuse; abuse; repair or alteration by other than our factory service; negligence; commercial or institutional use; improper or neglected maintenance; equipment sold AS IS or WITH ALL FAULTS; equipment removal or reinstallation; shipping damage if the equipment was not packed and shipped in the manner we prescribe; nor equipment purchased, serviced, or operated outside the contiguous United States of America.

REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY. WE SHALL NOT BE HELD LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESSED OR IMPLIED WARRANTY ON THIS DEVICE, NOR FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGE RESULTING FROM THE USE OF, OR INABILITY TO USE, THIS DEVICE. SOME STATES MAY LIMIT OR EXCLUDE THE FOREGOING LIMITATION, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL OUR LIABILITY, IF ANY, EXCEED THE PURCHASE PRICE PAID FOR THIS DEVICE. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS DEVICE IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG A STATUTORY OR IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. WE RESERVE THE RIGHT TO REFUSE TO HONOR THIS WARRANTY IF WE DETERMINE ANY OF THE ABOVE EXCEPTIONS TO HAVE CAUSED THIS SYSTEM NOT TO HAVE PERFORMED PROPERLY. THIS WARRANTY SHALL BE VOID IF ANY FACTORY-APPLIED IDENTIFICATION MARK, INCLUDING BUT NOT LIMITED TO SERIAL OR CONDITIONAL ACCESS NUMBERS, HAS BEEN ALTERED OR REMOVED. THIS WARRANTY SHALL ALSO BE VOID IF THE DEVICE HAS BEEN OPENED BY AN UNAUTHORIZED PERSON (with the exception of opening the battery cover).

# DISH's Exchange Programs

DISH offers two options if you need to replace your remote control—the Advanced Exchange Program and the Post Receipt Exchange Program.

## **Advanced Exchange Program**

Advanced Exchange Program allows you to have a replacement remote shipped immediately to you. Depending upon where you live, the remote should arrive within three to five business days. You will not have to return your defective remote to DISH using this program.

A shipping charge will be applied for shipping the replacement remote. This is a one-time fee based on DISH's competitive bulk shipping rates (additional charges may apply outside the continental U.S.). This fee will be charged to your billing account or valid credit card.

## **Post Receipt Exchange Program**

The Post Receipt Exchange Program does require that you send the defective remote control at your cost to DISH to determine if the equipment is covered under warranty. To provide faster service, upon receipt of your equipment, you will be shipped a replacement. Your original equipment will not be available for return.

If your equipment is not covered under warranty and can be repaired, your billing account or credit card will be charged the standard repair fee for the replacement. If damage to the defective equipment is found, which DISH in its sole discretion determines has voided the warranty or makes the equipment unrepairable, your billing account or credit card will be charged the market price of the replacement.

## Accessory Warranty

An accessory is any DISH-branded equipment, displaying the DISH logo, excluding the receiver, Smart Card, cables and hookups, and non-mechanical components. A one-year warranty becomes effective upon the activation of the DISH system or date of purchase, if bought separately. A proof of purchase is required to verify the purchase date. If an accessory has an expired warranty, no exchange will be issued. You may purchase replacement accessories from DISH or your local retailer.

## If You Need Help

1. Review this *User Guide*.
2. See *Troubleshooting* on page 44.
3. Visit [www.mydish.com/chat](http://www.mydish.com/chat) for 24/7 support.
4. Call the Customer Service Center at **1-800-333-DISH (3474)**.

# Regulatory Factors

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by following one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Do not make changes or modifications to this equipment. This could void the user's authority to operate the equipment.

If none of the remedies stops the radio interference, you should contact a licensed radio/television technician, your satellite dealer, or call the Customer Service Center at 1-800-333-DISH (3474) for assistance.

# Notes

# Notes

# Reference Table

Write down your remote address, channel numbers/inputs, TV, VCR, DVD player, and stereo equipment codes as you program them for future reference.



Remote Address

--	--



Channel or Input for Cable Programming

--

If you enter a "1" as the last number of your code, your remote is in Limited Mode (see page 21 for more details).

TV Code

TV

			1
--	--	--	---

(Optional)

DVD/BD/VCR Player Code

DVD

			1
--	--	--	---

(Optional)

Auxiliary Equipment Code

AUX

				1
--	--	--	--	---

(Optional)

To read out your remote codes, see page 20 for instructions.

For all your customer needs,  
go to [mydish.com/chat](https://mydish.com/chat) or call the  
Customer Service center at  
**1-800-333-DISH (3474)**

**dish**®



**199935**