

Part No. NN47250-100
June 2008

4655 Great America Parkway
Santa Clara, CA 95054

Nortel WLAN Security Switch 2300 Series Command Line Reference

NORTEL

Copyright © 2007-2008 Nortel Networks. All rights reserved.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

Trademarks and Service Marks

*Nortel, Nortel Networks, the Nortel logo, and the Globemark are trademarks of Nortel Networks.

*Microsoft, MS, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

*Adobe and Adobe Reader are trademarks of Adobe Systems Incorporated.

All other trademarks and registered trademarks are the property of their respective owners.



Restricted rights legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

Statement of conditions

In the interest of improving internal design, operational function, and/or reliability, Nortel Networks reserves the right to make changes to the products described in this document without notice.

Nortel Networks does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product may be Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

Nortel Networks software license agreement

This Software License Agreement (“License Agreement”) is between you, the end-user (“Customer”) and Nortel Corporation and its subsidiaries and affiliates (“Nortel Networks”). PLEASE READ THE FOLLOWING CAREFULLY. YOU MUST ACCEPT THESE LICENSE TERMS IN ORDER TO DOWNLOAD AND/OR USE THE SOFTWARE. USE OF THE SOFTWARE CONSTITUTES YOUR ACCEPTANCE OF THIS LICENSE AGREEMENT. If you do not accept these terms and conditions, return the Software, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

“Software” is owned or licensed by Nortel, its parent or one of its subsidiaries or affiliates, and is copyrighted and licensed, not sold. Software consists of machine-readable instructions, its components, data, audio-visual content (such as images, text, recordings or pictures) and related licensed materials including all whole or partial copies. Nortel grants you a license to use the Software only in the country where you acquired the Software. You obtain no rights other than those granted to you under this License Agreement. You are responsible for the selection of the Software and for the installation of, use of, and results obtained from the Software.

1.Licensed Use of Software. Nortel Networks grants Customer a nonexclusive license to use a copy of the Software on only one machine at any one time or to the extent of the activation or authorized usage level, whichever is applicable. To the extent Software is furnished for use with designated hardware or Customer furnished equipment (“CFE”), Customer is granted a nonexclusive license to use Software only on such hardware or CFE, as applicable. Software contains trade secrets and Customer agrees to treat Software as confidential information using the same care and discretion Customer uses with its own similar information that it does not wish to disclose, publish or disseminate. Customer will ensure that anyone who uses the Software does so only in compliance with the terms of this Agreement. Customer shall not a) use, copy, modify, transfer or distribute the Software except as expressly authorized; b) reverse assemble, reverse compile, reverse engineer or otherwise translate the Software; c) create derivative works or modifications unless expressly authorized; or d) sublicense, rent or lease the Software. Licensors of intellectual property to Nortel are beneficiaries of this provision. Upon termination or breach of the license by Customer or in the event designated hardware or CFE is no longer in use, Customer will promptly return the Software to Nortel or certify its destruction. Nortel may audit by remote polling or other reasonable means to determine Customer’s Software activation or usage levels. If suppliers of third party software included in Software require Nortel to include additional or different terms, Customer agrees to abide by such terms provided by Nortel with respect to such third party software.

2.Warranty. Except as may be otherwise expressly agreed to in writing between Nortel Networks and Customer, Software is provided “AS IS” without any warranties (conditions) of any kind. NORTEL NETWORKS DISCLAIMS ALL WARRANTIES (CONDITIONS) FOR THE SOFTWARE, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ANY WARRANTY OF NON-INFRINGEMENT. Nortel Networks is not obligated to provide support of any kind for the Software. Some jurisdictions do not allow exclusion of implied warranties, and, in such event, the above exclusions may not apply.

3.Limitation of Remedies. IN NO EVENT SHALL NORTEL OR ITS AGENTS OR SUPPLIERS BE LIABLE FOR ANY OF THE FOLLOWING: a) DAMAGES BASED ON ANY THIRD PARTY CLAIM; b) LOSS OF, OR DAMAGE TO, CUSTOMER’S RECORDS, FILES OR DATA; OR c) DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), WHETHER IN CONTRACT, TORT OR OTHERWISE (INCLUDING NEGLIGENCE) ARISING OUT OF YOUR USE OF THE SOFTWARE, EVEN IF NORTEL NETWORKS, ITS AGENTS OR SUPPLIERS HAVE BEEN ADVISED OF THEIR POSSIBILITY. The forgoing limitations of remedies also apply to any developer and/or supplier of the Software. Such

developer and/or supplier is an intended beneficiary of this Section. Some jurisdictions do not allow these limitations or exclusions and, in such event, they may not apply.

4. General

a) If Customer is the United States Government, the following paragraph shall apply: All Nortel Software available under this License Agreement is commercial computer software and commercial computer software documentation and, in the event Software is licensed for or on behalf of the United States Government, the respective rights to the software and software documentation are governed by Nortel standard commercial license in accordance with U.S. Federal Regulations at 48 C.F.R. Sections 12.212 (for non-DoD entities) and 48 C.F.R. 227.7202 (for DoD entities).

b) Customer may terminate the license at any time. Nortel may terminate the license if Customer fails to comply with the terms and conditions of this license. In either event, upon termination, Customer must either return the Software to Nortel or certify its destruction.

c) Customer is responsible for payment of any taxes, including personal property taxes, resulting from Customer's use of the Software. Customer agrees to comply with all applicable laws including all applicable export and import laws and regulations.

d) Neither party may bring an action, regardless of form, more than two years after the cause of the action arose.

e) The terms and conditions of this License Agreement form the complete and exclusive agreement between Customer and Nortel.

f) This License Agreement is governed by the laws of the country in which Customer acquires the Software. If the Software is acquired in the United States, then this License Agreement is governed by the laws of the state of New York.

Legal Information

This section includes the following legal information:

- [“Trademarks and Service Marks” on page 2](#)
- [“Limited Product Warranty” on page 4](#)
- [“Software License Agreement” on page 6](#)
- [“SSH Source Code Statement” on page 8](#)
- [“OpenSSL Project License Statements” on page 9](#)

Limited Product Warranty

The following sections describe the Nortel standard Product Warranty for End Users.

Products

Nortel WLAN—Security Switch 2300 Series

Nortel WLAN — Access Point (2330/2330A/2330B and Series 2332)

Limited Warranty

Nortel standard warranty for hardware is one (1) year. Nortel warrants software materials to be defect free for 90 Days from time of purchase. Nortel requires purchasing the software subscription if a customer would like to receive new versions of Nortel WLAN—Security Switch 2300 Series and Nortel WLAN — Management System software. This limited warranty extends only to you the original purchaser of the Product.

Exclusive Remedy

Your sole remedy under the limited warranty described above is, at Nortel's sole option and expense, the repair or replacement of the non-conforming Product or refund of the purchase price of the non-conforming Products. Nortel's obligation under this limited warranty is subject to compliance with Nortel's then-current Return Material Authorization ("RMA") procedures. All replaced Products will become the property of Nortel. Exchange Products not returned to Nortel will be invoiced at full Product list prices. Replacement Products may be new, reconditioned or contain refurbished materials. In connection with any warranty services hereunder, Nortel may in its sole discretion modify the Product at no cost to you to improve its reliability or performance.

Warranty Claim Procedures

Should a Product fail to conform to the limited warranty during the applicable warranty period as described above, Nortel must be notified during the applicable warranty period in order to have any obligation under the limited warranty.

The End Customer or their designated reseller must obtain a Return Material Authorization number (RMA number) from Nortel for the non-conforming Product and the non-conforming Product must be returned to Nortel according to the then-current RMA procedures. The End Customer or their designated reseller is responsible to ensure that the shipments are insured, with the transportation charges prepaid and that the RMA number is clearly marked on the outside of the package. Nortel will not accept collect shipments or those returned without an RMA number clearly visible on the outside of the package.

Exclusions and Restrictions

Nortel shall not be responsible for any software, firmware, information or memory data contained in, stored on or integrated with any Product returned to Nortel pursuant to any warranty or repair.

Upon return of repaired or replaced Products by Nortel, the warranty with respect to such Products will continue for the remaining unexpired warranty or sixty (60) days, whichever is longer. Nortel may provide out-of-warranty repair for the Products at its then-prevailing repair rates.

The limited warranty for the Product does not apply if, in the judgment of Nortel, the Product fails due to damage from shipment, handling, storage, accident, abuse or misuse, or it has been used or maintained in a manner not conforming to Product manual instructions, has been modified in any way, or has had any Serial Number removed or defaced. Repair by anyone other than Nortel or an approved agent will void this warranty.

EXCEPT FOR ANY EXPRESS LIMITED WARRANTIES FROM Nortel SET FORTH ABOVE, THE PRODUCT IS PROVIDED "AS IS", AND NORTEL AND ITS SUPPLIERS MAKE NO WARRANTY, EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, WITH RESPECT TO PRODUCT OR ANY PART THEREOF, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF TITLE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT, OR THOSE ARISING FROM COURSE OF PERFORMANCE, DEALING, USAGE OR TRADE. NORTEL'S SUPPLIERS MAKE NO DIRECT WARRANTY OF ANY KIND TO END CUSTOMER FOR THE LICENSED MATERIALS. NEITHER Nortel NOR ANY OF ITS SUPPLIERS WARRANT THAT THE LICENSED MATERIALS OR ANY PART THEREOF WILL MEET END CUSTOMER'S REQUIREMENTS OR BE UNINTERRUPTED, OR ERROR-FREE, OR THAT ANY ERRORS IN THE PRODUCT WILL BE CORRECTED. SOME STATES/JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES SO THE ABOVE EXCLUSIONS MAY NOT APPLY TO END CUSTOMER. THIS LIMITED WARRANTY GIVES END CUSTOMER SPECIFIC LEGAL RIGHTS.

END CUSTOMER MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE/JURISDICTION TO STATE/JURISDICTION.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL NORTEL OR ITS SUPPLIERS BE LIABLE FOR THE COST OF PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, LOSS OF PROFITS, OR FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, PUNITIVE OR INDIRECT DAMAGES (OR DIRECT DAMAGES IN THE CASE OF NORTEL'S SUPPLIERS) ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, TORT (INCLUDING WITHOUT LIMITATION NEGLIGENCE), STRICT LIABILITY OR OTHERWISE ARISING OUT OF OR RELATED TO THE PRODUCT OR ANY USE OR INABILITY TO USE THE PRODUCT. Nortel'S TOTAL LIABILITY ARISING OUT OF OR RELATED TO THE PRODUCT, OR USE OR INABILITY TO USE THE PRODUCT, WHETHER IN CONTRACT, TORT (INCLUDING WITHOUT LIMITATION NEGLIGENCE), STRICT LIABILITY OR OTHERWISE, SHALL NOT EXCEED THE PRICE PAID FOR THE PRODUCT. THE LIMITATIONS SET FORTH IN THIS SECTION SHALL APPLY EVEN IF Nortel AND/OR ITS SUPPLIERS ARE ADVISED OF THE POSSIBILITY OF SUCH DAMAGE, AND NOTWITHSTANDING THE FAILURE OF ESSENTIAL PURPOSE OF ANY LIMITED REMEDY. Nortel NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS.

Software License Agreement

PLEASE READ THIS SOFTWARE LICENSE AGREEMENT ("AGREEMENT") CAREFULLY BEFORE USING THE SOFTWARE AND ASSOCIATED DOCUMENTATION THAT IS PROVIDED WITH THIS AGREEMENT ("SOFTWARE," "DOCUMENTATION," AND COLLECTIVELY, "LICENSED MATERIALS").

BY USING ANY LICENSED MATERIALS, YOU ACKNOWLEDGE THAT YOU HAVE READ AND UNDERSTOOD ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT AND YOU WILL BE CONSENTING TO BE BOUND BY THEM. IF YOU DO NOT ACCEPT THESE TERMS AND CONDITIONS, DO NOT USE THE LICENSED MATERIALS AND RETURN THE LICENSED MATERIALS AND ANY EQUIPMENT PROVIDED BY Nortel IN CONNECTION THEREWITH ("EQUIPMENT") UNUSED IN THE ORIGINAL SHIPPING CONTAINER TO THE PLACE OF PURCHASE FOR A FULL REFUND.

Software may be provided by Nortel on a standalone basis ("Standalone Software") or it may be provided embedded in Equipment ("Embedded Software").

1. License.

(a) Subject to the terms and conditions of this Agreement, Nortel ("Nortel"), grants to you ("Licensee") a limited, non-exclusive, non-transferable license, without the right to sublicense: (i) to install and use the Standalone Software, in object code format only, on computer hardware for which all corresponding license fees have been paid; (ii) use one (1) copy of the Embedded Software, in object code format only, solely as embedded in Equipment, each solely in accordance with the Documentation for Licensee's internal business purposes.

(b) The license set forth above does not include any rights to and Licensee shall not (i) reproduce (except as set forth in Section 1(c)), modify, translate or create any derivative work of all or any portion of the Licensed Materials or Equipment, (ii) sell, rent, lease, loan, provide, distribute or otherwise transfer all or any portion of the Licensed Materials (except as set forth in Section 1(f)), (iii) reverse engineer, reverse assemble or otherwise attempt to gain access to the source code of all or any portion of the Licensed Materials or Equipment, (iv) use the Licensed Materials for third-party training, commercial time-sharing or service bureau use, (v) remove, alter, cover or obfuscate any copyright notices, trademark notices or other proprietary rights notices placed or embedded on or in the Licensed Materials or Equipment, (vi) use any component of the Software or Equipment other than solely in conjunction with operation of the Software and as applicable, Equipment, (vii) unbundle any component of the Software or Equipment, (viii) use any component of the Software for the development of or in conjunction with any software application intended for resale that employs any such component, (ix) use the Licensed Materials or Equipment in life support systems, human implantation, nuclear facilities or systems or any other application where failure could lead to a loss of life or catastrophic property damage, or (x) cause or permit any third party to do any of the foregoing.

If Licensee is a European Union resident, Licensee acknowledges that information necessary to achieve interoperability of the Software with other programs is available upon request.

(c) Licensee may make a single copy of the Standalone Software and Documentation solely for its back-up purposes; provided that any such copy is the exclusive property of Nortel and its suppliers and includes all copyright and other intellectual property right notices that appear on the original.

(d) Nortel may provide updates, corrections, enhancements, modifications or bug fixes for the Licensed Materials ("Updates") to Licensee. Any such Update shall be deemed part of the Licensed Materials and subject to the license and all other terms and conditions hereunder.

(e) Nortel shall have the right to inspect and audit Licensee's use, deployment, and exploitation of the Licensed Materials for compliance with the terms and conditions of this Agreement.

(f) Licensee shall have the right to transfer the Embedded Software as embedded in Equipment in connection with a transfer of all of Licensee's right, title and interest in such Equipment to a third party; provided, that, Licensee transfers the Embedded Software and any copies thereof subject to the terms and conditions of this Agreement and such third party agrees in writing to be bound by all the terms and conditions of this Agreement.

(g) Notwithstanding anything to the contrary herein, certain portions of the Software are licensed under and Licensee's use of such portions are only subject to the GNU General Public License version 2. If Licensee or any third party sends a request in writing to Nortel at 110 Nortech Parkway, San Jose CA 95134, ATTN: Contracts Administration, Nortel will provide a complete machine-readable copy of the source code of such portions for a nominal cost to cover Nortel's cost in physically providing such code.

2. Ownership. Nortel or its suppliers own and shall retain all right, title and interest (including without limitation all intellectual property rights), in and to the Licensed Materials and any Update, whether or not made by Nortel. Licensee acknowledges that the licenses granted under this Agreement do not provide Licensee with title to or ownership of the Licensed Materials, but only a right of limited use under the terms and conditions of this Agreement. Except as expressly set forth in Section 1, Nortel reserves all rights and grants Licensee no licenses of any kind hereunder. All information or feedback provided by Licensee to Nortel with respect to the Software or Equipment shall be Nortel's property and deemed confidential information of Nortel.

3. Confidentiality. Licensee agrees that the Licensed Materials contain confidential information, including trade secrets, know-how, and information pertaining to the technical structure or performance of the Software, that is the exclusive property of Nortel as between Licensee and Nortel. In addition, Nortel's confidential information includes any confidential or trade secret information related to the Licensed Materials. During the period this Agreement is in effect and at all times thereafter, Licensee shall maintain Nortel's confidential information in confidence and use the same degree of care, but in no event less than reasonable care, to avoid disclosure of Nortel's confidential information as it uses with respect to its own confidential and proprietary information of similar type and importance. Licensee agrees to only disclose Nortel's confidential information to its directors, officers and employees who have a bona fide need to know solely to exercise Licensee's rights under this Agreement and to only use Nortel's confidential information incidentally in the customary operation of the Software and Equipment. Licensee shall not sell, license, sublicense, publish, display, distribute, disclose or otherwise make available Nortel's confidential information to any third party nor use such information except as authorized by this Agreement. Licensee agrees to immediately notify Nortel of the unauthorized disclosure or use of the Licensed Materials and to assist Nortel in remedying such unauthorized use or disclosure. It is further understood and agreed that any breach of this Section 3 or Section 1(b) is a material breach of this Agreement and any such breach would cause irreparable harm to Nortel and its suppliers, entitling Nortel or its suppliers to injunctive relief in addition to all other remedies available at law.

4. Limited Warranty & Disclaimer. Any limited warranty for the Licensed Materials and Nortel's sole and exclusivity liability hereunder is as set forth in Nortel's standard warranty documentation. In addition, any limited warranty for the Software does not apply to any component of the Software but only to the Software as a whole. EXCEPT FOR ANY EXPRESS LIMITED WARRANTIES FROM Nortel IN SUCH DOCUMENTATION, THE LICENSED MATERIALS ARE PROVIDED "AS IS", AND Nortel AND ITS SUPPLIERS MAKE NO WARRANTY, EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, WITH RESPECT TO LICENSED MATERIALS OR ANY PART THEREOF, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF TITLE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT, OR THOSE ARISING FROM COURSE OF PERFORMANCE, DEALING, USAGE OR TRADE. Nortel'S SUPPLIERS MAKE NO DIRECT WARRANTY OF ANY KIND TO LICENSEE FOR THE LICENSED MATERIALS. NEITHER Nortel NOR ANY OF ITS SUPPLIERS WARRANT THAT THE LICENSED MATERIALS OR ANY PART THEREOF WILL MEET LICENSEE'S REQUIREMENTS OR BE UNINTERRUPTED, OR ERROR-FREE, OR THAT ANY ERRORS IN THE LICENSED MATERIALS WILL BE CORRECTED. SOME STATES/JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES SO THE ABOVE EXCLUSIONS MAY NOT APPLY TO LICENSEE. THIS LIMITED WARRANTY GIVES LICENSEE SPECIFIC LEGAL RIGHTS. LICENSEE MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE/JURISDICTION TO STATE/JURISDICTION.

5. Term and Termination. This Agreement is effective until terminated. Licensee may terminate this Agreement at any time by destroying all copies of the Software. This Agreement and all licenses granted hereunder will terminate immediately without notice from Nortel if Licensee fails to comply with any provision of this Agreement. Upon any termination, Licensee must destroy all copies of the Licensed Materials. Sections 1(b), 2, 3, 4(b), 5, 6, 7, 8, 9 and 10 shall survive any termination of this Agreement.

6. Export. The Software is specifically subject to U.S. Export Administration Regulations. Licensee agrees to strictly comply with all export, re-export and import restrictions and regulations of the Department of Commerce or other agency or authority of the United States or other applicable countries, and not to transfer, or authorize the transfer of, directly or indirectly, the Software or any direct product thereof to a prohibited country or otherwise in violation of any such restrictions or regulations. Licensee's failure to comply with this Section is a material breach of this Agreement. Licensee acknowledges that Licensee is not a national of Cuba, Iran, Iraq, Libya, North Korea, Sudan or Syria or a party listed in the U.S. Table of Denial Orders or U.S. Treasury Department List of Specially Designated Nationals.

7. Government Restricted Rights. As defined in FAR section 2.101, DFAR section 252.227-7014(a)(1) and DFAR section 252.227-7014(a)(5) or otherwise, the Software provided in connection with this Agreement are "commercial items," "commercial computer software" and/or "commercial computer software documentation." Consistent with DFAR section 227.7202, FAR section 12.212 and other sections, any use, modification, reproduction, release, performance, display, disclosure or distribution thereof by or for the U.S. Government shall be governed solely by the terms of this Agreement and shall be prohibited except to the extent expressly permitted by the terms of this Agreement. Any technical data provided

that is not covered by the above provisions shall be deemed "technical data-commercial items" pursuant to DFAR section 227.7015(a). Any use, modification, reproduction, release, performance, display or disclosure of such technical data shall be governed by the terms of DFAR section 227.7015(b).

8. **Limitation of Liability.** TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL Nortel OR ITS SUPPLIERS BE LIABLE FOR THE COST OF PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, LOSS OF PROFITS, OR FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, PUNITIVE OR INDIRECT DAMAGES (OR DIRECT DAMAGES IN THE CASE OF Nortel 'S SUPPLIERS) ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, TORT (INCLUDING WITHOUT LIMITATION NEGLIGENCE), STRICT LIABILITY OR OTHERWISE ARISING OUT OF OR UNDER THIS AGREEMENT OR ANY USE OR INABILITY TO USE THE LICENSED MATERIALS OR EQUIPMENT, OR FOR BREACH OF THIS AGREEMENT. Nortel 'S TOTAL LIABILITY ARISING OUT OF OR UNDER THIS AGREEMENT, OR USE OR INABILITY TO USE THE LICENSED MATERIALS OR EQUIPMENT, OR FOR BREACH OF THIS AGREEMENT, WHETHER IN CONTRACT, TORT (INCLUDING WITHOUT LIMITATION NEGLIGENCE), STRICT LIABILITY OR OTHERWISE, SHALL NOT EXCEED THE PRICE PAID FOR THE SOFTWARE (FOR THE STANDALONE SOFTWARE) AND THE PRICE PAID FOR THE EQUIPMENT (FOR THE EMBEDDED SOFTWARE AND EQUIPMENT). THE LIMITATIONS SET FORTH IN THIS SECTION SHALL APPLY EVEN IF Nortel AND/OR ITS SUPPLIERS ARE ADVISED OF THE POSSIBILITY OF SUCH DAMAGE, AND NOTWITHSTANDING THE FAILURE OF ESSENTIAL PURPOSE OF ANY LIMITED REMEDY.

9. **Third Party Beneficiaries.** Nortel's suppliers are intended third party beneficiaries of this Agreement. The terms and conditions herein are made expressly for the benefit of and are enforceable by Nortel's suppliers; provided, however, that Nortel's suppliers are not in any contractual relationship with Licensee. Nortel's suppliers include without limitation: (a) Hifn, Inc., a Delaware corporation with principal offices at 750 University Avenue, Los Gatos, California; and (b) Wind River Systems, Inc. and its suppliers.

10. **General.** This Agreement is governed and interpreted in accordance with the laws of the State of California, U.S.A. without reference to conflicts of laws principles and excluding the United Nations Convention on Contracts for the Sale of Goods. The parties consent to the exclusive jurisdiction of, and venue in, Santa Clara County, California, U.S.A. Licensee shall not transfer, assign or delegate this Agreement or any rights or obligations hereunder, whether voluntarily, by operation of law or otherwise, without the prior written consent of Nortel (except as expressly set forth in Section 1(f)). Subject to the foregoing, the terms and conditions of this Agreement shall be binding upon and inure to the benefit of the parties to it and their respective heirs, successors, assigns and legal representatives. This Agreement constitutes the entire agreement between Nortel and Licensee with respect to the subject matter hereof, and merges all prior negotiations and drafts of the parties with regard thereto. No modification of or amendment to this Agreement, nor any waiver of any rights under this Agreement, by Nortel shall be effective unless in writing. If any of the provisions of this Agreement is held by a court of competent jurisdiction to be invalid or unenforceable under any applicable statute or rule of law, such provision shall, to that extent, be deemed omitted.

SSH Source Code Statement

C 1995 - 2004 SAFENET, Inc. This software is protected by international copyright laws. All rights reserved. SafeNet is a registered trademark of SAFENET, Inc., in the United States and in certain other jurisdictions. SAFENET and the SAFENET logo are trademarks of SAFENET, Inc., and may be registered in certain jurisdictions. All other names and marks are property of their respective owners.

Copyright (c) 1983, 1990, 1992, 1993, 1995 The Regents of the University of California. All rights reserved.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Components of the software are provided under a standard 2-term BSD licence with the following names as copyright holders:

- o Markus Friedl
- o Theo de Raadt
- o Niels Provos
- o Dug Song
- o Aaron Campbell
- o Damien Miller
- o Kevin Steves
- o Daniel Kouril
- o Per Allansson

THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

OpenSSL Project License Statements

Copyright (c) 1998-2002 The OpenSSL Project. All rights reserved.

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT ``AS IS'' AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com). All rights reserved.

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

How to get help	3
Introducing the Nortel WLAN 2300 System	5
Nortel WLAN 2300 System	5
Documentation	6
Safety and Advisory Notices	7
Text and Syntax Conventions	8
Using the Command-Line Interface	9
CLI Conventions	9
Command Prompts	10
Syntax Notation	11
Text Entry Conventions and Allowed Characters	11
MAC Address Notation	12
IP Address and Mask Notation	12
Subnet Masks	12
Wildcard Masks	12
User Wildcards, MAC Address Wildcards, and VLAN Wildcards	12
User Wildcards	12
MAC Address Wildcards	13
VLAN Wildcards	13
Matching Order for Wildcards	14
Port Lists	14
Virtual LAN Identification	14
Command-Line Editing	15
Using CLI Help	16
Understanding Command Descriptions	17
Access Commands	19
Port Commands	23
System Services Commands	53
VLAN Commands	73
Quality of Service Commands	93

IP Services Commands	97
AAA Commands	165
Mobility Domain Commands	217
Network Domain Commands	225
AP Commands	233
STP Commands	389
IGMP Snooping Commands	415
Session Management Commands	435
Security ACL Commands	449
Cryptography Commands	469
RADIUS and Server Groups Commands	483
802.1X Management Commands	495
RF Detection Commands	511
File Management Commands	535
Trace Commands	559
Snoop Commands	565
System Log Commands	575
Boot Prompt Commands	585
Command Index	601

How to get help

This section explains how to get help for Nortel products and services.

Getting help from the Nortel web site

The best way to get technical support for Nortel products is from the Nortel Technical Support Web site:

<http://www.nortel.com/support>

This site provides quick access to software, documentation, bulletins, and tools to address issues with Nortel products. More specifically, the site enables you to:

- download software, documentation, and product bulletins
- search the Technical Support Web site and the Nortel Knowledge Base for answers to technical issues
- sign up for automatic notification of new software and documentation for Nortel equipment
- open and manage technical support cases

Getting help over the phone from a Nortel solutions center

If you do not find the information you require on the Nortel Technical Support Web site, and have a Nortel support contract, you can also get help over the phone from a Nortel Solutions Center.

In North America, call 1-800-4NORTEL (1-800-466-7835).

Outside North America, go to the following Web site to obtain the phone number for your region:

<http://www.nortel.com/callus>

Getting help from a specialist by using an express routing code

To access some Nortel Technical Solutions Centers, you can use an Express Routing Code (ERC) to quickly route your call to a specialist in your Nortel product or service. To locate the ERC for your product or service, go to:

<http://www.nortel.com/erc>

Getting help through a Nortel distributor or reseller

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller.

Introducing the Nortel WLAN 2300 System

Nortel WLAN 2300 System	5
Documentation	6

This command reference explains WLAN Security Switch 2300 Series (WSS Software) command line interface (CLI) commands that you enter on a WLAN—Security Switch to configure and manage the Nortel WLAN 2300 System wireless LAN (WLAN).

Read this reference if you are a network administrator responsible for managing WLAN—Security Switch (WSS) and Access Points (APs) in a network.

Nortel WLAN 2300 System

The Nortel WLAN 2300 System is an enterprise-class WLAN solution that seamlessly integrates with an existing wired enterprise network. The Nortel system provides secure connectivity to both wireless and wired users in large environments such as office buildings, hospitals, and university campuses and in small environments such as branch offices.

The Nortel WLAN 2300 System fulfills the three fundamental requirements of an enterprise WLAN: It eliminates the distinction between wired and wireless networks, allows users to work safely from anywhere (*secure mobility*), and provides a comprehensive suite of intuitive tools for planning and managing the network before and after deployment, greatly easing the operational burden on IT resources.

The Nortel WLAN 2300 System consists of the following components:

- **WLAN Management Software tool suite**—A full-featured graphical user interface (GUI) application used to plan, configure, deploy, and manage a WLAN and its users
- **One or more WLAN—Security Switch (WSS)**—Distributed, intelligent machines for managing user connectivity, connecting and powering Access Points (APs), and connecting the WLAN to the wired network backbone
- **Multiple Access Points (APs)**—Wireless APs that transmit and receive radio frequency (RF) signals to and from wireless users and connect them to a WSS
- **WLAN Security Switch 2300 Series (WSS Software)**—The operating system that runs all WSSs and APs in a WLAN, and is accessible through a command-line interface (CLI), the Web View interface, or the WLAN Management Software GUI

Documentation

Consult the following documents to plan, install, configure, and manage a Nortel WLAN 2300 System.

Planning, Configuration, and Deployment

- [Nortel WLAN Management Software 2300 Series User Guide](#). Instructions for planning, configuring, deploying, and managing the entire WLAN with the WLAN Management Software tool suite. Read this guide to learn how to plan wireless services, how to configure and deploy Nortel equipment to provide those services, and how to optimize and manage your WLAN.
- [Nortel WLAN Management Software 2300 Series Reference Guide](#). Detailed instructions and information for all WLAN Management Software planning, configuration, and management features.

Installation

- [Nortel WLAN—Security Switch 2300 Series Installation and Basic Configuration Guide](#). Instructions and specifications for installing a WSS
- [Nortel WLAN—Security Switch 2300 Series Quick Start Guide](#). Instructions for performing basic setup of secure (802.1X) and guest (Web-based AAA) access, and for configuring a Mobility Domain for roaming
- [Nortel WLAN—Access Point 2330/2330A/2330B Installation Guide](#). Instructions and specifications for installing an AP and connecting it to a WSS
- [Nortel WLAN—Series 2332 Access Point Installation Guide](#). Instructions and specifications for installing a Series 2332 AP and connecting it to a WSS

Configuration and Management

- [Nortel WLAN Management Software 2300 Series Reference Guide](#) (this document). Instructions for planning, configuring, deploying, and managing the entire WLAN with the WLAN Management Software tool suite
- [Nortel WLAN Security Switch 2300 Series Configuration Guide](#). Instructions for configuring and managing the system through the WSS Software CLI
- [Nortel WLAN Security Switch 2300 Series Command Line Reference](#). Functional and alphabetic reference to all WSS Software commands supported on WSSs and APs

Safety and Advisory Notices

The following kinds of safety and advisory notices appear in this manual.



Caution! This situation or condition can lead to data loss or damage to the product or other property.



Note. This information is of special interest.

Text and Syntax Conventions

Nortel manuals use the following text and syntax conventions:

Convention	Use
Monospace text	Sets off command syntax or sample commands and system responses.
Bold text	Highlights commands that you enter or items you select.
<i>Italic text</i>	Designates command variables that you replace with appropriate values, or highlights publication titles or words requiring special emphasis.
Menu Name > Command	Indicates a menu item that you select. For example, File > New indicates that you select New from the File menu.
[] (square brackets)	Enclose optional parameters in command syntax.
{ } (curly brackets)	Enclose mandatory parameters in command syntax.
(vertical bar)	Separates mutually exclusive options in command syntax.

Using the Command-Line Interface

CLI Conventions	9
Command-Line Editing	15
Using CLI Help	16
Understanding Command Descriptions	17

WLAN Security Switch 2300 Series (WSS Software) operates a Nortel WLAN 2300 System wireless LAN (WLAN) consisting of WLAN Management Software, WLAN—Security Switch (WSS), and Access Points (APs). WSS Software has a command-line interface (CLI) on the WSS that you can use to configure and manage the switch and its attached APs.

You configure the WSS and APs primarily with **set**, **clear**, and **show** commands. Use **set** commands to change parameters. Use **clear** commands to reset parameters to their defaults. In many cases, you can overwrite a parameter with another **set** command. Use **show** commands to display the current configuration and monitor the status of network operations.

The WSS supports two connection modes:

- Administrative access mode, which enables the network administrator to connect *to* the WSS and configure the network
- Network access mode, which enables network users to connect *through* the WSS to access the network

CLI Conventions

Be aware of the following WSS Software CLI conventions for command entry:

- [“Command Prompts” on page 10](#)
- [“Syntax Notation” on page 11](#)
- [“Text Entry Conventions and Allowed Characters” on page 11](#)
- [“User Wildcards, MAC Address Wildcards, and VLAN Wildcards” on page 12](#)
- [“Port Lists” on page 14](#)
- [“Virtual LAN Identification” on page 14](#)

Command Prompts

By default, the WSS Software CLI provides the following prompt for restricted users. The *mm* portion shows the WSS model number (for example, *2360*) and the *nnnnnn* portion shows the last 6 digits of the switch's media access control (MAC) address.

WSS-*mmmm-nnnnnn*>

WSS-*2360-01b09a*>

After you become enabled as an administrative user by typing **enable** and supplying a suitable password, WSS Software displays the following prompt:

WSS-*mmmm-nnnnnn*#

For ease of presentation, this manual shows the restricted and enabled prompts as follows:

WSS>

WSS#

For information about changing the CLI prompt on a WSS, see **set prompt on page 62**.

Syntax Notation

The WSS Software CLI uses standard syntax notation:

- Bold monospace font identifies the command and keywords you must type. For example:

```
set enablepass
```

- Italic monospace font indicates a placeholder for a value. For example, you replace *vlan-id* in the following command with a virtual LAN (VLAN) ID:

```
clear interface vlan-id ip
```

- Curly brackets ({ }) indicate a mandatory parameter, and square brackets ([]) indicate an optional parameter. For example, you must enter **dynamic** or **port** and a port list in the following command, but a VLAN ID is optional:

```
clear fdb {dynamic | port port-list} [vlan vlan-id]
```

- A vertical bar (|) separates mutually exclusive options within a list of possibilities. For example, you enter either **enable** or **disable**, not both, in the following command:

```
set port {enable | disable} port-list
```

Text Entry Conventions and Allowed Characters

Unless otherwise indicated, the WSS Software CLI accepts standard ASCII alphanumeric characters, except for tabs and spaces, and is case-insensitive.

The CLI has specific notation requirements for MAC addresses, IP addresses, and masks, and allows you to group usernames, MAC addresses, virtual LAN (VLAN) names, and ports in a single command.

Nortel recommends that you do not use the same name with different capitalizations for VLANs or access control lists (ACLs). For example, do not configure two separate VLANs with the names *red* and *RED*.

The CLI does not support the use of special characters including the following in any named elements such as SSIDs and VLANs: ampersand (&), angle brackets (<>), number sign (#), question mark (?), or quotation marks ("").

In addition, the CLI does not support the use of international characters such as the accented *É* in *DÉCOR*.

MAC Address Notation

WSS Software displays MAC addresses in hexadecimal numbers with a colon (:) delimiter between bytes—for example, 00:01:02:1a:00:01. You can enter MAC addresses with either hyphen (-) or colon (:) delimiters, but colons are preferred.

For shortcuts:

- You can exclude leading zeros when typing a MAC address. WSS Software displays of MAC addresses include all leading zeros.
- In some specified commands, you can use the single-asterisk (*) wildcard character to represent from 1 byte to 5 bytes of a MAC address. (For more information, see [“MAC Address Wildcards” on page 13.](#))

IP Address and Mask Notation

WSS Software displays IP addresses in dotted decimal notation—for example, 192.168.1.111. WSS Software makes use of both subnet masks and wildcard masks.

Subnet Masks

Unless otherwise noted, use classless interdomain routing (CIDR) format to express subnet masks—for example, 192.168.1.112/24. You indicate the subnet mask with a forward slash (/) and specify the number of bits in the mask.

Wildcard Masks

Security access control lists (ACLs) use source and destination IP addresses and wildcard masks to determine whether the WSS filters or forwards IP packets. Matching packets are either permitted or denied network access. The ACL checks the bits in IP addresses that correspond to any 0s (zeros) in the mask, but does not check the bits that correspond to 1s (ones) in the mask. You specify the wildcard mask in dotted decimal notation.

For example, the address 10.0.0.0 and mask 0.255.255.255 match all IP addresses that begin with 10 in the first octet.

The ACL mask must be a contiguous set of zeroes starting from the first bit. For example, 0.255.255.255, 0.0.255.255, and 0.0.0.255 are valid ACL masks. However, 0.255.0.255 is not a valid ACL mask.

User Wildcards, MAC Address Wildcards, and VLAN Wildcards

Name “wildcarding” is a way of using a wildcard pattern to expand a single element into a list of elements that match the pattern. WSS Software accepts user wildcards, MAC address wildcards, and VLAN wildcards. The order in which wildcards appear in the configuration is important, because once a wildcard is matched, processing stops on the list of wildcards.

User Wildcards

A user wildcard is shorthand method for matching an authentication, authorization, and accounting (AAA) command to either a single user or a set of users.

A user wildcard can be up to 80 characters long and cannot contain spaces or tabs. The double-asterisk (**) wildcard characters with no delimiter characters match *all* usernames. The single-asterisk (*) wildcard character matches any

number of characters up to, but not including, a delimiter character in the wildcard. Valid user wildcard delimiter characters are the *at* (@) sign and the period (.).

For example, the following wildcards identify the following users:

User Wildcard	User(s) Designated
jose@example.com	User <i>jose</i> at example.com
*@example.com	All users at example.com whose usernames do not contain periods—for example, jose@example.com and tamara@example.com, but <i>not</i> nin.wong@example.com, because nin.wong contains a period
*@marketing.example.com	All marketing users at example.com whose usernames do not contain periods
.@marketing.example.com	All marketing users at example.com whose usernames contain periods
*	All users with usernames that have no delimiters
EXAMPLE*	All users in the Windows Domain EXAMPLE with usernames that have no delimiters
EXAMPLE*.*	All users in the Windows Domain EXAMPLE whose usernames contain periods
**	All users

MAC Address Wildcards

A media access control (MAC) address wildcard is a similar method for matching some authentication, authorization, and accounting (AAA) and forwarding database (FDB) commands to one or more 6-byte MAC addresses. In a MAC address wildcard, you can use a single asterisk (*) as a wildcard to match *all* MAC addresses, or as follows to match from 1 byte to 5 bytes of the MAC address:

```
00:*
00:01:*
00:01:02:*
00:01:02:03:*
00:01:02:03:04:*
```

For example, the MAC address wildcard 02:06:8c* represents all MAC addresses starting with 02:06:8c. Specifying only the first 3 bytes of a MAC address allows you to apply commands to MAC addresses based on an organizationally unique identity (OUI).

VLAN Wildcards

A VLAN wildcard is a method for matching one of a set of local rules on a WSS, known as the location policy, to one or more users. WSS Software compares the VLAN wildcard, which can optionally contain wildcard characters, against the VLAN-Name attribute returned by AAA, to determine whether to apply the rule.

24 Using the Command-Line Interface

To match all VLANs, use the double-asterisk (**) wildcard characters with no delimiters. To match any number of characters up to, but not including, a delimiter character in the wildcard, use the single-asterisk (*) wildcard. Valid VLAN wildcard delimiter characters are the *at* (@) sign and the period (.

For example, the VLAN wildcard *bldg4.** matches *bldg4.security* and *bldg4.hr* and all other VLAN names with *bldg4.* at the beginning.

Matching Order for Wildcards

In general, the order in which you enter AAA commands determines the order in which WSS Software matches the user, MAC address, or VLAN to a wildcard. To verify the order, view the output of the **show aaa** or **show config** command. WSS Software checks wildcards that appear higher in the list before items lower in the list and uses the first successful match.

Port Lists

The physical Ethernet ports on a WSS can be set for connection to APs, authenticated wired users, or the network backbone. You can include a single port or multiple ports in one WSS Software CLI command by using the appropriate list format.

The ports on a WSS are numbered 1 through 22. No port 0 exists on the switch. You can include a single port or multiple ports in a command that includes **port** *port-list*. Use one of the following formats for *port-list*:

- A single port number. For example:

```
WSS# set port enable 16
```

- A comma-separated list of port numbers, with no spaces. For example:

```
WSS# show port poe 1,2,4,13
```

- A hyphen-separated range of port numbers, with no spaces. For example:

```
WSS# reset port 12-16
```

- Any combination of single numbers, lists, and ranges. Hyphens take precedence over commas. For example:

```
WSS# show port status 1-3,14
```

Virtual LAN Identification

The *names* of virtual LANs (VLANs), which are used in Mobility Domain™ communications, are set by you and can be changed. In contrast, VLAN ID *numbers*, which the WSS uses locally, are determined when the VLAN is first configured and cannot be changed. Unless otherwise indicated, you can refer to a VLAN by either its VLAN name or its VLAN number. CLI **set** and **show** commands use a VLAN's name or number to uniquely identify the VLAN within the WSS.

Command-Line Editing

WSS Software editing functions are similar to those of many other network operating systems.

Keyboard Shortcuts

The following table lists the keyboard shortcuts for entering and editing CLI commands:

Keyboard Shortcut(s)	Function
Ctrl+A	Jumps to the first character of the command line.
Ctrl+B or Left Arrow key	Moves the cursor back one character.
Ctrl+C	Escapes and terminates prompts and tasks.
Ctrl+D	Deletes the character at the cursor.
Ctrl+E	Jumps to the end of the current command line.
Ctrl+F or Right Arrow key	Moves the cursor forward one character.
Ctrl+K	Deletes from the cursor to the end of the command line.
Ctrl+L or Ctrl+R	Repeats the current command line on a new line.
Ctrl+N or Down Arrow key	Enters the next command line in the history buffer.
Ctrl+P or Up Arrow key	Enters the previous command line in the history buffer.
Ctrl+U or Ctrl+X	Deletes characters from the cursor to the beginning of the command line.
Ctrl+W	Deletes the last word typed.
Esc B	Moves the cursor back one word.
Esc D	Deletes characters from the cursor forward to the end of the word.
Delete key or Backspace key	Erases mistake made during command entry. Reenter the command after using this key.

History Buffer

The history buffer stores the last 63 commands you entered during a terminal session. You can use the Up Arrow and Down Arrow keys to select a command that you want to repeat from the history buffer.

Tabs

The WSS Software CLI uses the Tab key for command completion. You can type the first few characters of a command and press the Tab key to display the command(s) that begin with those characters. For example:

```
WSS# show i <Tab>
ifm    Show interfaces maintained by the interface manager
igmp   Show igmp information
interface Show interfaces
ip     Show ip information
```

Single-Asterisk (*) Wildcard Character

You can use the single-asterisk (*) wildcard character in wildcarding. (For details, see [“User Wildcards, MAC Address Wildcards, and VLAN Wildcards” on page 12.](#))

Double-Asterisk (**) Wildcard Characters

The double-asterisk (**) wildcard character matches all usernames. For details, see [“User Wildcards” on page 12.](#)

Using CLI Help

The CLI provides online help. To see the full range of commands available at your access level, type the **help** command.

For example: WSS# **help**

Commands:

```
-----
clear          Clear, use 'clear help' for more information
commit        Commit the content of the ACL table
copy          Copy from filename (or url) to filename (or url)
crypto        Crypto, use 'crypto help' for more information
delete        Delete url
dir           Show list of files on flash device
disable       Disable privileged mode
exit          Exit from the Admin session
help         Show this help screen
history       Show contents of history substitution buffer
load         Load, use 'load help' for more information
logout        Exit from the Admin session
monitor       Monitor, use 'monitor help' for more information
ping         Send echo packets to hosts
quit         Exit from the Admin session
reset        Reset, use 'reset help' for more information
rollback     Remove changes to the edited ACL table
save         Save the running configuration to persistent storage
set          Set, use 'set help' for more information
show         Show, use 'show help' for more information
telnet       telnet IP address [server port]
traceroute   Print the route packets take to network host
```

For more information on help, see **help on page 56.**

To see a subset of the online help, type the command for which you want more information. For example, to display all the commands that begin with the letter *i*, type the following command:

```
WSS# show i?
ifm          Show interfaces maintained by the interface manager
igmp        Show igmp information
interface    Show interfaces
ip           Show ip information
```

To see all the variations, type one of the commands followed by a question mark (?). For example:

```
WSS# show ip ?
alias        Show ip aliases
dns          show DNS status
https        show ip https
route        Show ip route table
telnet       show ip telnet
```

To determine the port on which Telnet is running, type the following command:

```
WSS# show ip telnet
Server Status      Port
-----
Enabled            23
```

Understanding Command Descriptions

Each command description in the *Nortel WLAN Security Switch 2300 Series Command Reference* contains the following elements:

- A command name, which shows the keywords but not the variables. For example, the following command name appears at the top of a command description and in the index:

```
set {ap} name
```

The **set {ap} name** command has the following complete syntax:

```
set {ap port-list | ap-num} name name
```

- A brief description of the command's functions.
- The full command syntax.
- Any command defaults.
- The command access, which is either *enabled* or *all*. *All* indicates that anyone can access this command. *Enabled* indicates that you must enter the enable password before entering the command.
- The command history, which identifies the WSS Software version in which the command was introduced and the version numbers of any subsequent updates.
- Special tips for command usage. These are omitted if the command requires no special usage.
- One or more examples of the command in context, with the appropriate system prompt and response.
- One or more related commands.

Access Commands

Use access commands to control access to the WLAN Security Switch 2300 Series (WSS Software) (CLI). This chapter presents access commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Access Privileges	enable on page 19
	set enablepass on page 20
	disable on page 19
	quit on page 20

disable

Changes the CLI session from enabled mode to restricted access.

Syntax **disable**

Defaults None.

Access Enabled.

Examples The following command restricts access to the CLI for the current session:

```
WSS# disable  
WSS>
```

See Also **enable on page 19**

enable

Places the CLI session in enabled mode, which provides access to all commands required for configuring and monitoring the system.

Syntax **enable**

Access All.

Usage WSS Software displays a password prompt to challenge you with the enable password. To enable a session, your or another administrator must have configured the enable password to this WSS with the **set enablepass** command.

Examples The following command plus the enable password provides enabled access to the CLI for the current sessions:

```
WSS> enable
```

```
Enter password: password  
WSS#
```

See Also

- **set enablepass** on page 20
- **set confirm** on page 60

quit

Exit from the CLI session.

Syntax `quit`

Defaults None.

Access All.

Examples To end the administrator's session, type the following command:

```
WSS> quit
```

set enablepass

Sets the password that provides enabled access (for configuration and monitoring) to the WSS.



Note. The enable password is case-sensitive.

Syntax `set enablepass`

Defaults None.

Access Enabled.

Usage After typing the **set enablepass** command, press Enter. If you are entering the first enable password on this WSS, press Enter at the *Enter old password* prompt. Otherwise, type the old password. Then type a password of up to 32 alphanumeric characters with no spaces, and reenter it at the *Retype new password* prompt.



Caution! Be sure to use a password that you will remember. If you lose the enable password, the only way to restore it causes the system to return to its default settings and wipes out the configuration.

Examples The following example illustrates the prompts that the system displays when the enable password is changed. The passwords you enter are not displayed.

```
WSS# set enablepass
```

```
Enter old password: old-password
```

```
Enter new password: new-password
```

```
Retype new password: new-password
```

```
Password changed
```

See Also

- **disable on page 19**
- **enable on page 19**

Port Commands

Use port commands to configure and manage individual ports and load-sharing port groups. This chapter presents port commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Port Type	<ul style="list-style-type: none"> set port type ap on page 41 set ap on page 33 set port type wired-auth on page 44 clear port type on page 27 clear ap on page 24
Name	<ul style="list-style-type: none"> set port name on page 38 clear port name on page 26
State	<ul style="list-style-type: none"> set port on page 35 reset port on page 32 show port status on page 51
Gigabit interface type	<ul style="list-style-type: none"> show port media-type on page 48 set port media-type on page 36 clear port media-type on page 25
Speed	<ul style="list-style-type: none"> set port speed on page 40
Autonegotiation	<ul style="list-style-type: none"> set port negotiation on page 39
PoE	<ul style="list-style-type: none"> set port poe on page 39 show port poe on page 49
SNMP	<ul style="list-style-type: none"> set port trap on page 41
Port Groups	<ul style="list-style-type: none"> set port-group on page 35 show port-group on page 47 clear port-group on page 25
Port Mirroring	<ul style="list-style-type: none"> set port mirror on page 37

Statistics

show port mirror on page 49
clear port mirror on page 26
show port counters on page 46
monitor port counters on page 28
clear port counters on page 24

clear ap



Caution! When you clear a AP, WSS Software ends user sessions that are using the AP.

Removes a AP.

Syntax `clear ap ap-num`

ap-num Number of the AP(s) you want to remove.

Defaults None.

Access Enabled.

Examples The following command clears AP 1:

WSS# clear ap 1

This will clear specified AP devices. Would you like to continue? (y/n) [n]y

See Also

- [set ap on page 33](#)
- [set port type ap on page 41](#)

clear port counters

Clears port statistics counters and resets them to 0.

Syntax `clear port counters`

Defaults None.

Access Enabled.

Examples The following command clears all port statistics counters and resets them to 0:

WSS# clear port counters

success: cleared port counters

See Also

- **monitor port counters on page 28**
- **show port counters on page 46**

clear port-group

Removes a port group.

Syntax `clear port-group name name`

name *name* Name of the port group.

Defaults None.

Access Enabled.

Examples The following command clears port group *server1*:

WSS# clear port-group name server1

success: change accepted.

See Also

- **set port-group on page 35**
- **show port-group on page 47**

clear port media-type

Disables the copper interface and reenables the fiber interface on a 2380 gigabit Ethernet port.

Syntax `clear port media-type port-list`

port-list List of physical ports. WSS Software disables the copper interface and reenables the fiber interface on all the specified ports.

Defaults The GBIC (fiber) interface is enabled, and the copper interface is disabled, by default.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage This command applies only to the 2380. This command does not affect a link that is already active on the port.

Examples The following command disables the copper interface and reenables the fiber interface on port 2:

2380# clear port media-type 2

See Also

- **set port media-type on page 36**
- **show port media-type on page 48**

clear port mirror

Removes a port mirroring configuration.

Syntax `clear port mirror`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command clears the port mirroring configuration from the switch:

```
WSS# clear port mirror
```

See Also

- **set port mirror on page 37**
- **show port mirror on page 49**

clear port name

Removes the name assigned to a port.

Syntax `clear port port-list name`

port-list

List of physical ports. WSS Software removes the names from all the specified ports.

Defaults None.

Access Enabled.

Examples The following command clears the names of ports 17 through 20:

```
WSS# clear port 17-20 name
```

See Also

- **set port name on page 38**
- **show port status on page 51**

clear port type



Caution! When you clear a port, WSS Software ends user sessions that are using the port.

Removes all configuration settings from a port and resets the port as a network port.

Syntax `clear port type port-list`

port-list List of physical ports. WSS Software resets and removes the configuration from all the specified ports.

Defaults The cleared port becomes a network port but is not placed in any VLANs.

Access Enabled.

Usage Use this command to change a port back to a network port. All configuration settings specific to the port type are removed. For example, if you clear an AP port, all AP-specific settings are removed. [Table 1](#) lists the default network port settings that WSS Software applies when you clear a port's type.

Table 1: Network Port Defaults

Port Parameter	Setting
VLAN membership	None. Note: Although the command changes a port to a network port, the command does not place the port in any VLAN. To use the port in a VLAN, you must add the port to the VLAN.
Spanning Tree Protocol (STP)	Based on the VLAN(s) you add the port to.
802.1X	No authorization.
Port groups	None.
Internet Group Management Protocol (IGMP) snooping	Enabled as port is added to VLANs.
Access point and radio parameters	Not applicable
Maximum user sessions	Not applicable

Examples The following command clears port 5:

WSS# clear port type 5

This may disrupt currently authenticated users. Are you sure? (y/n) [n]y

success: change accepted.

See Also

- **set port type ap on page 41**
- **set port type wired-auth on page 44**

monitor port counters

Displays and continually updates port statistics.

Syntax `monitor port counters [octets | packets | receive-errors | transmit-errors | collisions | receive-etherstats | transmit-etherstats]`

octets	Displays octet statistics first.
packets	Displays packet statistics first.
receive-errors	Displays errors in received packets first.
transmit-errors	Displays errors in transmitted packets first.
collisions	Displays collision statistics first.
receive-etherstats	Displays Ethernet statistics for received packets first.
transmit-etherstats	Displays Ethernet statistics for transmitted packets first.

Defaults All types of statistics are displayed for all ports. WSS Software refreshes the statistics every 5 seconds. This interval cannot be configured. Statistics types are displayed in the following order by default:

- Octets
- Packets
- Receive errors
- Transmit errors
- Collisions
- Receive Ethernet statistics
- Transmit Ethernet statistics

Access All.

Usage Each type of statistic is displayed separately. Press the Spacebar to cycle through the displays for each type.

If you use an option to specify a statistic type, the display begins with that statistic type. You can use one statistic option with the command.

Use the keys listed in [Table 2](#) to control the monitor display.

Table 2: Key Controls for Monitor Port Counters Display

Key	Effect on Monitor Display
Spacebar	Advances to the next statistic type.
Esc	Exits the monitor. WSS Software stops displaying the statistics and displays a new command prompt.
c	Clears the statistics counters for the currently displayed statistics type. The counters begin incrementing again.

For error reporting, the cyclic redundancy check (CRC) errors include misalignment errors. Jumbo packets with valid CRCs are not counted. A short packet can be reported as a short packet, a CRC error, or an overrun. In some circumstances, the transmitted octets counter might increment a small amount for a port with nothing attached.

Examples The following command starts the port statistics monitor beginning with octet statistics (the default):

WSS# monitor port counters

As soon as you press Enter, WSS Software clears the window and displays statistics at the top of the window.

```
Port Status          Rx Octets          Tx Octets
=====
1 Up                27965420          34886544
...
```

To cycle the display to the next set of statistics, press the Spacebar. In this example, packet statistics are displayed next:

```
Port Status  Rx Unicast  Rx NonUnicast  Tx Unicast  Tx NonUnicast
=====
1 Up        54620       62144          68318       62556
...
```

Table 3 describes the port statistics displayed by each statistics option. The Port and Status fields are displayed for each option.

Table 3: Output for monitor port counters

Statistics Option	Field	Description
Displayed for All Options	Port	Port the statistics are displayed for.
	Status	Port status. The status can be Up or Down.
octets	Rx Octets	Total number of octets received by the port. This number includes octets received in frames that contained errors.
	Tx Octets	Total number of octets received. This number includes octets received in frames that contained errors.
packets	Rx Unicast	Number of unicast packets received. This number does not include packets that contain errors.
	Rx NonUnicast	Number of broadcast and multicast packets received. This number does not include packets that contain errors.
	Tx Unicast	Number of unicast packets transmitted. This number does not include packets that contain errors.
	Tx NonUnicast	Number of broadcast and multicast packets transmitted. This number does not include packets that contain errors.
receive-errors	Rx Crc	Number of frames received by the port that had the correct length but contained an invalid frame check sequence (FCS) value. This statistic includes frames with misalignment errors.
	Rx Error	Total number of frames received in which the Physical layer (PHY) detected an error.
	Rx Short	Number of frames received by the port that were fewer than 64 bytes long.
	Rx Overrun	Number of frames received by the port that were valid but were longer than 1518 bytes. This statistic does not include jumbo packets with valid CRCs.

Table 3: Output for monitor port counters (continued)

Statistics Option	Field	Description
transmit-errors	Tx Crc	Number of frames transmitted by the port that had the correct length but contained an invalid FCS value.
	Tx Short	Number of frames transmitted by the port that were fewer than 64 bytes long.
	Tx Fragment	Total number of frames transmitted that were less than 64 octets long and had invalid CRCs.
	Tx Abort	Total number of frames that had a link pointer parity error.
collisions	Single Coll	Total number of frames transmitted that experienced one collision before 64 bytes of the frame were transmitted on the network.
	Multiple Coll	Total number of frames transmitted that experienced more than one collision before 64 bytes of the frame were transmitted on the network.
	Excessive Coll	Total number of frames that experienced more than 16 collisions during transmit attempts. These frames are dropped and not transmitted.
	Total Coll	Best estimate of the total number of collisions on this Ethernet segment.
receive-etherstats	Rx 64	Number of packets received that were 64 bytes long.
	Rx 127	Number of packets received that were from 65 through 127 bytes long.
	Rx 255	Number of packets received that were from 128 through 255 bytes long.
	Rx 511	Number of packets received that were from 256 through 511 bytes long.
	Rx 1023	Number of packets received that were from 512 through 1023 bytes long.
	Rx 1518	Number of packets received that were from 1024 through 1518 bytes long.

Table 3: Output for monitor port counters (continued)

Statistics Option	Field	Description
transmit-etherstats	Tx 64	Number of packets transmitted that were 64 bytes long.
	Tx 127	Number of packets transmitted that were from 65 through 127 bytes long.
	Tx 255	Number of packets transmitted that were from 128 through 255 bytes long.
	Tx 511	Number of packets transmitted that were from 256 through 511 bytes long.
	Tx 1023	Number of packets transmitted that were from 512 through 1023 bytes long.
	Tx 1518	Number of packets transmitted that were from 1024 through 1518 bytes long.

See Also [show port counters on page 46](#)

reset port

Resets a port by toggling its link state and Power over Ethernet (PoE) state.

Syntax `reset port port-list`

port-list List of physical ports. WSS Software resets all the specified ports.

Defaults None.

Access Enabled.

Usage The `reset` command disables the port's link and PoE (if applicable) for at least 1 second, then reenables them. This behavior is useful for forcing an AP that is connected to two WSSs to reboot over the link to the other switch.

Examples The following command resets port 5:

WSS# `reset port 5`

See Also **set port** on page 35

set ap

Configures a AP for an AP that is indirectly connected to the WSS through an intermediate Layer 2 or Layer 3 network.



Note. Before configuring an AP, you must use the **set system countrycode** command to set the IEEE 802.11 country-specific regulations on the WSS. See **set system countrycode** on page 63.

Note. For a complete listing of the models in the WLAN Series 2332 and their respective countries of operation, please visit the Nortel Support website. <http://www.nortel.com/support>. The Series 2332 access point has been region-locked to meet geographic regulatory restrictions. Each model is associated to a specific regulatory domain and subsequent country of operation. During installation, the access point model and wireless security switch regulatory domain must match or the access point will not operate.



Note. For an AP that is directly connected to the WSS, use the **set port type ap** command to configure an AP access port.



Note. The WLAN Series 2332 Access Points consist of the following models: 2332-A1, 2332-A2, 2332-A3, 2332-A4, 2332-A5, 2332-A6, 2332-E1, 2332-E2, 2332-E3, 2332-E4, 2332-E5, 2332-E6, 2332-E7, 2332-E8, 2332-E9, and 2332-J1.

Syntax **set ap** *ap-num* **serial-id** *serial-ID*
model { 2330 | 2330A | 2330B | 2332-A1 | 2332-A2 | 2332-A3 | 2332-A4 | 2332-A5 |
 2332-A6 | 2332-E1 | 2332-E2 | 2332-E3 | 2332-E4 | 2332-E5 | 2332-E6 | 2332-E7 |
 2332-E8 | 2332-E9 | 2332-J1 }
 [radiotype { 11a | 11b | 11g }]

<i>ap-num</i>	Number for the AP. The range of valid connection numbers depends on the WSS model: <ul style="list-style-type: none">• 2382—1 to 320• 2380—1 to 300• 2360/61—1 to 30• 2350—1 to 8
serial-id <i>serial-ID</i>	AP serial ID. The serial ID is listed on the AP case. To display the serial ID using the CLI, use the show version details command.
model { 2330 2330A 2330B 2332-A1 2332-A2 2332-A3 2332-A4 2332-A5 2332-A6 2332-E1 2332-E2 2332-E3 2332-E4 2332-E5 2332-E6 2332-E7 2332-E8 2332-E9 2332-J1 }	AP model.
radiotype 11a 11b 11g	Radio type: <ul style="list-style-type: none">• 11a—802.11a• 11b—802.11b• 11g—802.11g <p>Note: This option applies only to single-radio models.</p>

Defaults The default vales are the same as the defaults for the **set port type ap** command.

Access Enabled.

History

Version 4.1	New values for model option added: <ul style="list-style-type: none">• 2330• 2330A
Version 5.0.11	New values for model option added: <ul style="list-style-type: none">• 2330B
Version 6.0	Option dap removed New value for model option added: 2332-A1, 2332-A2, 2332-A3, 2332-A4, 2332-A5, 2332-A6, 2332-E1, 2332-E2, 2332-E3, 2332-E4, 2332-E5, 2332-E6, 2332-E7, 2332-E8, 2332-E9, and 2332-J1.

Examples The following command configures apAP 1 for AP model AP-2330A with serial-ID 0322199999:

```
WSS# set ap 1 serial-id 0322199999 model 2330A
success: change accepted.
```

The following command removes AP 1:

```
WSS# clear ap 1
```

This will clear specified AP devices. Would you like to continue? (y/n) [n]y

See Also

- [clear ap on page 24](#)
- [clear port type on page 27](#)
- [set port type ap on page 41](#)
- [set system countrycode on page 63](#)

set port

Administratively disables or reenables a port.

```
Syntax set port {enable | disable} port-list
```

enable Enables the specified ports.

disable Disables the specified ports.

port-list List of physical ports. WSS Software disables or reenables all the specified ports.

Defaults All ports are enabled.

Access Enabled.

Usage A port that is administratively disabled cannot send or receive packets. This command does not affect the link state of the port.

Examples The following command disables port 16:

```
WSS# set port disable 16
```

```
success: set "disable" on port 16
```

The following command reenables the port:

```
WSS# set port enable 16
```

```
success: set "enable" on port 16
```

See Also [reset port on page 32](#)

set port-group

Configures a load-sharing port group. All ports in the group function as a single logical link.

Syntax `set port-group name group-name port-list mode {on | off}`

name <i>group-name</i>	Alphanumeric string of up to 255 characters, with no spaces.
<i>port-list</i>	List of physical ports. All the ports you specify are configured together as a single logical link.
mode {on off}	State of the group. Use on to enable the group or off to disable the group. The group is enabled by default.

Defaults Once configured, a group is enabled by default.

Access Enabled.

Usage Do not use dashes or hyphens in a port group name. If you do, WSS Software will not display or save the port group.

You can configure up to 16 ports in a port group, in any combination of ports. The port numbers do not need to be contiguous and you can use 10/100 Ethernet ports and gigabit Ethernet ports in the same port group.

After you add a port to a port group, you cannot configure port parameters on the individual port. Instead, change port parameters on the entire group. Specify the group name instead of an individual port name or number in port configuration commands.

To add or remove ports in a group that is already configured, change the mode to **off**, add or remove the ports, then change the mode to **on**.

Examples The following command configures a port group named *server1* containing ports 1 through 5, and enables the link:

```
WSS# set port-group name server1 1-5 mode on
success: change accepted.
```

The following commands disable the link for port group *server1*, change the list of ports in the group, and reenables the link:

```
WSS# set port-group name server1 1-5 mode off
success: change accepted.
```

```
WSS# set port-group name server1 1-4,7 mode on
success: change accepted.
```

See Also

- `clear port-group` on page 25
- `show port-group` on page 47

set port media-type

Disables the fiber interface and enables the copper interface on a 2380 gigabit Ethernet port.

Syntax `set port media-type port-list rj45`

port-list List of physical ports. WSS Software sets the preference on all the specified ports.

rj45 Uses the copper interface.

Defaults The GBIC (fiber) interface is enabled, and the copper interface is disabled, by default.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage This command applies only to the 2380.

If you set the port interface to RJ-45 on a port that already has an active fiber link, WSS Software immediately changes the link to the copper interface.

Examples The following command disables the fiber interface and enables the copper interface on port 2:

```
2380# set port media-type 2 rj45
```

See Also

- [clear port media-type on page 25](#)
- [show port media-type on page 48](#)

set port mirror

Configures port mirroring. Port mirroring is a troubleshooting feature that copies (mirrors) traffic sent or received by a WSS port (the source port) to another port (the observer) on the same WSS. You can attach a protocol analyzer to the observer port to examine the source port's traffic. Both traffic directions (send and receive) are mirrored.

Syntax `set port mirror source-port observer observer-port`

source-port Number of the port whose traffic you want to analyze. You can specify only one port.

observer-port Number of the port to which you want the switch to copy the source port's traffic.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage The switch can have one port mirroring pair (one source port and one observer port) at a time. The source port can be a network port, AP access port, or wired authentication port. However, the observer port must be a network port, and cannot be a member of any VLAN or port group.

Examples The following command sets port 2 to monitor port 1's traffic:

```
WSS# set port 1 observer 2
```

See Also

- [clear port mirror on page 26](#)
- [show port mirror on page 49](#)

set port name

Assigns a name to a port. After naming a port, you can use the port name or number in other CLI commands.

Syntax `set port port name name`

<i>port</i>	Number of a physical port. You can specify only one port.
name <i>name</i>	Alphanumeric string of up to 16 characters, with no spaces.

Defaults None.

Access Enabled.

Usage To simplify configuration and avoid confusion between a port's number and its name, Nortel recommends that you do not use numbers as port names.

Examples The following command sets the name of port 17 to *adminpool*:

```
WSS# set port 17 name adminpool
success: change accepted.
```

See Also

- [clear port name on page 26](#)
- [show port status on page 51](#)

set port negotiation

Disables or reenables autonegotiation on gigabit Ethernet or 10/100 Ethernet ports.

Syntax `set port negotiation port-list {enable | disable}`

<i>port-list</i>	List of physical ports. WSS Software disables or reenables autonegotiation on all the specified ports.
enable	Enables autonegotiation on the specified ports.
disable	Disables autonegotiation on the specified ports.

Defaults Autonegotiation is enabled on all Ethernet ports by default.

Access Enabled.

Usage The gigabit Ethernet ports operate at 1000 Mbps only. They do not change speed to match 10-Mbps or 100-Mbps links.
2382, 2360/2361 10/100 Ethernet ports support half-duplex and full-duplex operation.

Nortel recommends that you do not configure the mode of a WSS port so that one side of the link is set to autonegotiation while the other side is set to full-duplex. Although WSS Software allows this configuration, it can result in slow throughput on the link. The slow throughput occurs because the side that is configured for autonegotiation falls back to half-duplex. A stream of large packets sent to a WSS port in such a configuration can cause forwarding on the link to stop.

Examples The following command disables autonegotiation on ports 3, 8, and 16 through 18:

WSS# set port negotiation 3,8,16-18 disable

The following command enables autonegotiation on port 21:

WSS# set port negotiation 21 enable

set port poe

Enables or disables Power over Ethernet (PoE) on ports connected to APs.



Caution! When you set the port type for AP use, you can enable PoE on the port. Use the WSS's PoE to power Nortel APs only. If you enable PoE on ports connected to other devices, damage can result.

Syntax `set port <portnum> poe {enable|disable}`

<i>port-list</i>	List of physical ports. WSS Software disables or reenables PoE on all the specified ports.
enable	Enables PoE on the specified ports.
disable	Disables PoE on the specified ports.

Defaults PoE is disabled on network and wired authentication ports. The state on AP ports depends on whether you enabled or disabled PoE when setting the port type. See **set port type ap on page 41**.

Access Enabled.

Usage This command does not apply to any gigabit Ethernet ports or to ports 7 and 8 on the 2360 and 2382 switch.

Examples The following command disables PoE on ports 7 and 9, which are connected to an AP:

WSS# set port poe 7,9 disable

If you are enabling power on these ports, they must be connected only to approved PoE devices with the correct wiring. Do you wish to continue? (y/n) [n]y

The following command enables PoE on ports 7 and 9:

WSS# set port poe 7,9 enable

If you are enabling power on these ports, they must be connected only to approved PoE devices with the correct wiring. Do you wish to continue? (y/n) [n]y

See Also

- **set port type ap on page 41**
- **set port type wired-auth on page 44**

set port speed

Changes the speed of a port.

Syntax **set port speed** *port-list* { **10** | **100** | **1000** | **auto** }

<i>port-list</i>	List of physical ports. WSS Software sets the port speed on all the specified ports.
10	Sets the port speed of a 10/100 Ethernet port to 10 Mbps and sets the operating mode to full-duplex.
100	Sets the port speed of a 10/100 Ethernet port to 100 Mbps and sets the operating mode to full-duplex.
1000	Sets the port speed of a gigabit Ethernet port to 1000 Mbps and sets the operating mode to full-duplex.
auto	Enables a port to detect the speed and operating mode of the traffic on the link and set itself accordingly.

Defaults All ports are set to **auto**.

Access Enabled.

Usage Nortel recommends that you do not configure the mode of a WSS port so that one side of the link is set to autonegotiation while the other side is set to full-duplex. Although WSS Software allows this configuration, it can result in slow throughput on the link. The slow throughput occurs because the side that is configured for autonegotiation falls back to half-duplex. A stream of large

packets sent to a WSS port in such a configuration can cause forwarding on the link to stop.

Do not set the port speed of a gigabit port to **auto**. Although the CLI allows this setting, it is invalid. If you set the port speed of a gigabit port to **auto**, the link will stop working.

Examples The following command sets the port speed on ports 1, 7 through 11, and 14 to 10 Mbps and sets the operating mode to full-duplex:

```
WSS# set port speed 1,7-11,14 10
```

set port trap

Enables or disables Simple Network Management Protocol (SNMP) linkup and linkdown traps on an individual port.

Syntax `set port trap port-list {enable | disable}`

<i>port-list</i>	List of physical ports.
enable	Enables the Telnet server.
disable	Disables the Telnet server.

Defaults SNMP linkup and linkdown traps are disabled by default.

Access Enabled.

Usage The `set port trap` command overrides the global setting of the `set snmp trap` command.

The `set port type` command does not affect the global trap information displayed by the `show snmp status` command. For example, if you globally enable linkup and linkdown traps but then disable the traps on a single port, the `show snmp status` command still indicates that the traps are globally enabled.

Examples The following command enables SNMP linkup and linkdown traps on ports 17 and 18:

```
WSS# set port trap 17-18 enable
```

See Also

- [set ip snmp server on page 118](#)
- [set snmp community on page 123](#)
- [set snmp notify target on page 131](#)
- [show snmp status on page 159](#)

set port type ap

Configures a WSS port for an AP.



Caution! When you set the port type for AP use, you must specify the PoE state (enable or disable) of the port. Use the WSS's PoE to power Nortel APs only. If you enable PoE on a port connected to another device, physical damage to the device can result.



Note. Before configuring a port as an AP port, you must use the **set system countrycode** command to set the IEEE 802.11 country-specific regulations on the WSS. See **set system countrycode on page 63**.



Note. For Series 2332 access points, be sure the system country code is supported for the selected access point model.



Note. For an AP that is indirectly connected to the WSS through an intermediate Layer 2 or Layer 3 network, use the **set ap** command to configure a AP.



Note. Before changing the port type from **ap** to **wired-auth** or from **wired-auth** to **ap**, you must reset the port with the **clear port type** command.

Syntax **set port type ap** *port-list*
model { 2330 | 2330A | 2330B | 2332-A1 | 2332-A2 | 2332-A3 | 2332-A4 | 2332-A5 |
2332-A6 | 2332-E1 | 2332-E2 | 2332-E3 | 2332-E4 | 2332-E5 | 2332-E6 | 2332-E7 |
2332-E8 | 2332-E9 | 2332-J1 }
poe { enable | disable }
[radiotype { 11a | 11b | 11g }]

port-list

List of physical ports.

model { 2330 | 2330A | 2330B | 2332-A1 | 2332-A2 | 2332-A3 | 2332-A4 |
2332-A5 | 2332-A6 | 2332-E1 | 2332-E2 |
2332-E3 | 2332-E4 | 2332-E5 | 2332-E6 |
2332-E7 | 2332-E8 | 2332-E9 | 2332-J1 }

AP model.

poe enable | **disable**

Power over Ethernet (PoE) state.

radiotype 11a | 11b | 11g

Radio type:

- **11a**—802.11a
- **11b**—802.11b
- **11g**—802.11g

Note: This option applies only to single-radio models.

Defaults All WSS ports are network ports by default.

Model AP-2330, AP-2330A, AP-2330B, and Series 2332 APs have two radios. On two-radio models, one radio is always 802.11a. The other radio is 802.11b/g, but can be configured for 802.11b or 802.11g exclusively. If the country of operation specified by the **set system countrycode** command does not allow 802.11g, the default is 802.11b.

Model AP-2330, AP-2330A, AP-2330B and Series 2332 APs have internal antennas but also have connectors for optional use of external antennas. (Antenna support on a specific model is limited to the antennas certified for use with that model.) To specify the antenna model, use the **set {ap} radio antennatype** command.

Access Enabled.

History

Version 4.1	New values for model option added: <ul style="list-style-type: none"> • 2330 • 2330A
Version 5.0.11	New values for model option added: <ul style="list-style-type: none"> • 2330B
Version 6.0	New values for model option added: <ul style="list-style-type: none"> • 2332-A1, 2332-A2, 2332-A3, 2332-A4, 2332-A5, 2332-A6, 2332-E1, 2332-E2, 2332-E3, 2332-E4, 2332-E5, 2332-E6, 2332-E7, 2332-E8, 2332-E9, and 2332-J1.

Usage You cannot set a port's type if the port is a member of a port VLAN. To remove a port from a VLAN, use the **clear vlan** command. To reset a port as a network port, use the **clear port type** command.

When you change port type, WSS Software applies default settings appropriate for the port type. [Table 4](#) lists the default settings that WSS Software applies when you set a port's type to **ap**.

Table 4: AP Access Port Defaults

Port Parameter	Setting
VLAN membership	Removed from all VLANs. You cannot assign an AP access port to a VLAN. WSS Software automatically assigns AP access ports to VLANs based on user traffic.
Spanning Tree Protocol (STP)	Not applicable
802.1X	Uses authentication parameters configured for users.
Port groups	Not applicable
IGMP snooping	Enabled as users are authenticated and join VLANs.
Maximum user sessions	Not applicable

This command does not apply to any gigabit Ethernet ports or to ports 7 and 8 on the 2360/2361 switch and port 3 on the 2382.

To manage an AP on a switch model that does not have 10/100 Ethernet ports, use the **set ap** command to configure a AP connection on the switch.

Examples The following commands set port 2 for AP model 2330, enable PoE on the port, and specify external antenna model 24453 for the 802.11b/g radio:

```
WSS# set port type ap 2 model 2330 poe enable
```

This may affect the power applied on the configured ports. Would you like to continue?

(y/n) [n]y

success: change accepted.

```
WSS# set ap 1 radio 1 antennatype 24453
```

success: change accepted.

The following command sets ports 4 through 6 for AP model 2330 and enables PoE on the ports:

```
WSS# set port type ap 4-6 model 2330 poe enable
```

This may affect the power applied on the configured ports. Would you like to continue?

(y/n) [n]y

success: change accepted.

The following command resets port 5 by clearing it:

```
WSS# clear port type 5
```

This may disrupt currently authenticated users. Are you sure? (y/n) [n]y

success: change accepted.

See Also

- [clear ap on page 24](#)
- [clear port type on page 27](#)
- [set ap radio antennatype on page 263](#)
- [set ap on page 33](#)
- [set port type wired-auth on page 44](#)
- [set system countrycode on page 63](#)

set port type wired-auth

Configures a WSS port for a wired authentication user.



Note. Before changing the port type from **ap** to **wired-auth** or from **wired-auth** to **ap**, you must reset the port with the **clear port type** command.

Syntax `set port type wired-auth port-list [tag tag-list] [max-sessions num]
[auth-fall-thru {last-resort | none | web-portal}]`

<i>port-list</i>	List of physical ports.
<i>tag-list</i>	One or more numbers between 1 and 4094 that subdivide a wired authentication port into virtual ports.
<i>num</i>	Maximum number of simultaneous user sessions supported.
last-resort	Automatically authenticates the user, without requiring a username and password.
none	Denies authentication and prohibits the user from accessing the network over this port.
web-portal	Serves the user a web page from the WSS's nonvolatile storage for secure login to the network.

Defaults The default tag-list is null (no tag values). The default number of sessions is 1. The default fallthru authentication type is **none**.

Access Enabled.

History

Version 4.0 Option for Web-based AAA fallthru authentication type changed from **web-auth** to **web-portal**.

Usage You cannot set a port's type if the port is a member of a port VLAN. To remove a port from a VLAN, use the **clear vlan** command. To reset a port as a network port, use the **clear port type** command.

When you change port type, WSS Software applies default settings appropriate for the port type. [Table 5](#) lists the default settings that WSS Software applies when you set a port's type to **ap**.

Table 5: Wired Authentication Port Defaults

Port Parameter	Setting
VLAN membership	Removed from all VLANs. You cannot assign an AP access port to a VLAN. WSS Software automatically assigns AP access ports to VLANs based on user traffic.
Spanning Tree Protocol (STP)	Not applicable
802.1X	Uses authentication parameters configured for users.
Port groups	Not applicable
IGMP snooping	Enabled as users are authenticated and join VLANs.
Maximum user sessions	1 (one).
Fallthru authentication type	None.

For 802.1X clients, wired authentication works only if the clients are directly attached to the wired authentication port, or are attached through a hub that does not block forwarding of packets from the client to the PAE group address (01:80:c2:00:00:03). Wired authentication works in accordance with the 802.1X specification, which prohibits a client from sending traffic directly to an authenticator's MAC address until the client is authenticated. Instead of sending traffic to the authenticator's MAC address, the client sends packets to the PAE group address. The 802.1X specification prohibits networking devices from forwarding PAE group address packets, because this would make it possible for multiple authenticators to acquire the same client.

For non-802.1X clients, who use MAC authentication, Web-based AAA, or last-resort authentication, wired authentication works if the clients are directly attached or indirectly attached.

Examples The following command sets port 10 for a wired authentication user:

```
WSS# set port type wired-auth 10
```

```
success: change accepted
```

Examples The following command sets port 7 for a wired authentication user and specifies a maximum of three simultaneous user sessions:

```
WSS# set port type wired-auth 7 max-sessions 3
```

```
success: change accepted
```

See Also

- [clear port type on page 27](#)
- [set port type ap on page 41](#)

show port counters

Displays port statistics.

```
Syntax show port counters [octets | packets | receive-errors | transmit-errors | collisions | receive-etherstats | transmit-etherstats] [port port-list]
```

octets	Displays octet statistics.
packets	Displays packet statistics.
receive-errors	Displays errors in received packets.
transmit-errors	Displays errors in transmitted packets.
collisions	Displays collision statistics.
receive-etherstats	Displays Ethernet statistics for received packets.
transmit-etherstats	Displays Ethernet statistics for transmitted packets.
port <i>port-list</i>	List of physical ports. If you do not specify a port list, WSS Software displays statistics for all ports.

Defaults None.

Access All.

Usage You can specify one statistic type with the command.

Examples The following command shows octet statistics for port 3:

WSS> **show port counters octets port 3**

Port	Status	Rx Octets	Tx Octets
3	Up	27965420	34886544

This command's output has the same fields as the **monitor port counters** command. For descriptions of the fields, see [Table 3 on page 30](#).

See Also

- [clear port counters on page 24](#)
- [monitor port counters on page 28](#)

show port-group

Displays port group information.

Syntax **show port-group** [*name group-name*]

name *group-name* Displays information for the specified port group.

Defaults None.

Access All.

History

Version 4.1 Option **all** removed for simplicity. You can display information for all groups by entering the command without specifying a group name.

Examples The following command displays the configuration of port group *server2*:

WSS# **show port-group name server2**

Port group: server2 is up

Ports: 15, 17

[Table 6](#) describes the fields in the **show port-group** output.

Table 6: Output for show port-group

Field	Description
Port group	Name and state (enabled or disabled) of the port group.
Ports	Ports contained in the port group.

See Also

- **clear port-group on page 25**
- **set port-group on page 35**

show port media-type

Displays the enabled interface types on a 2380 switch's gigabit Ethernet ports.

Syntax `show port media-type [port-list]`

port-list List of physical ports. WSS Software displays the enabled interface types for all the specified ports.

Defaults None.

Access All.

History Introduced in WSS Software Version 4.0.

Usage This command applies only to the 2380.

Examples The following command displays the enabled interface types on all four ports of an 2380 switch:

2380# show port media-type

Port Media Type

```
=====
 1 GBIC
 2 RJ45
 3 GBIC
 4 GBIC
```

[Table 7](#) describes the fields in this display.

Table 7: Output for show port media-type

Field	Description
Port	Port number.
Preference	Preference setting: <ul style="list-style-type: none">• GBIC—The GBIC (fiber) interface is enabled.• RJ45—The RJ-45 (copper) interface is enabled.

See Also

- **clear port media-type on page 25**
- **set port media-type on page 36**

show port mirror

Displays the port mirroring configuration.

Syntax `show port mirror`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command displays the port mirroring configuration on the switch:

```
WSS# show port mirror
Port 1 is mirrored to port 2
```

If port mirroring is not configured, the message in the following example is displayed instead:

```
WSS# show port mirror
No ports are mirrored
```

See Also

- [clear port mirror on page 26](#)
- [set port mirror on page 37](#)

show port poe

Displays status information for ports on which Power over Ethernet (PoE) is enabled.

Syntax `show port poe [port-list]`

port-list List of physical ports. If you do not specify a port list, PoE information is displayed for all ports.

Defaults None.

Access All.

Examples The following command displays PoE information for all ports on a 22-port WSS:

```
WSS# show port poe
```

Port Name	Link Status	Port Type	PoE config	PoE Draw
1 1	up	-	disabled	off
2 2	down	-	disabled	off
3 3	down	-	disabled	off
4 4	down	-	disabled	off
5 5	down	-	disabled	off
6 6	down	-	disabled	off
7 7	down	-	disabled	off
8 8	down	-	disabled	off

```

 9 9      up      AP      enabled  1.44
10 10     up      -       disabled off
11 11     down    -       disabled off
12 12     down    -       disabled off
13 13     down    -       disabled off
14 14     down    -       disabled off
15 15     down    -       disabled off
16 16     down    -       disabled off
17 17     down    -       disabled off
18 18     down    -       disabled off
19 19     down    -       disabled off
20 20     down    -       disabled off
21 21     down    -       disabled invalid
22 22     down    -       disabled invalid

```

Table 8 describes the fields in this display.

Table 8: Output for show port poe

Field	Description
Port	Port number.
Name	Port name. If the port does not have a name, the port number is listed.
Link status	Link status of the port: <ul style="list-style-type: none"> • up—The port is connected. • down—The port is not connected.
Port type	Port type: <ul style="list-style-type: none"> • AP—The port is an access port. • - (The port is not an AP.)
PoE config	PoE state: <ul style="list-style-type: none"> • enabled • disabled
PoE Draw	Power draw on the port, in watts. For 10/100 Ethernet ports on which PoE is disabled, this field displays <i>off</i> . For gigabit Ethernet ports, this field displays <i>invalid</i> , because PoE is not supported on gigabit Ethernet ports. The value <i>overcurrent</i> indicates a PoE problem such as a short in the cable.

See Also set port poe on page 39

show port status

Displays configuration and status information for ports.

Syntax `show port status [port-list]`

port-list List of physical ports. If you do not specify a port list, information is displayed for all ports.

Defaults None.

Access All.

Examples The following command displays information for all ports on a 22-port WSS:

```
WSS# show port status
Port Name      Admin      Oper       Config     Actual     Type       Media
=====
=
 1 1           up        up         auto       100/full   network    10/100BaseTx
 2 2           up        down       auto       100/full   network    10/100BaseTx
 3 3           up        down       auto       100/full   network    10/100BaseTx
 4 4           up        down       auto       100/full   network    10/100BaseTx
 5 5           up        down       auto       100/full   network    10/100BaseTx
 6 6           up        down       auto       100/full   network    10/100BaseTx
 7 7           up        down       auto       100/full   network    10/100BaseTx
 8 8           up        down       auto       100/full   network    10/100BaseTx
 9 9           up        up         auto       100/full   ap         10/100BaseTx
10 10          up        up         auto       100/full   network    10/100BaseTx
11 11          up        down       auto       100/full   network    10/100BaseTx
12 12          up        down       auto       100/full   network    10/100BaseTx
13 13          up        down       auto       100/full   network    10/100BaseTx
14 14          up        down       auto       100/full   network    10/100BaseTx
15 15          up        down       auto       100/full   network    10/100BaseTx
16 16          up        down       auto       100/full   network    10/100BaseTx
17 17          up        down       auto       100/full   network    10/100BaseTx
18 18          up        down       auto       100/full   network    10/100BaseTx
19 19          up        down       auto       100/full   network    10/100BaseTx
20 20          up        down       auto       100/full   network    10/100BaseTx
21 21          up        down       auto       100/full   network    no connector
22 22          up        down       auto       100/full   network    no connector
```

Table 9 describes the fields in this display.

Table 9: Output for show port status

Field	Description
Port	Port number.
Name	Port name. If the port does not have a name, the port number is listed.

Table 9: Output for show port status (continued)

Field	Description
Admin	Administrative status of the port: <ul style="list-style-type: none">• up—The port is enabled.• down—The port is disabled.
Oper	Operational status of the port: <ul style="list-style-type: none">• up—The port is operational.• down—The port is not operational.
Config	Port speed configured on the port: <ul style="list-style-type: none">• 10—10 Mbps.• 100—100 Mbps.• 1000—1000 Mbps.• auto—The port sets its own speed.
Actual	Speed and operating mode in effect on the port.
Type	Port type: <ul style="list-style-type: none">• ap—AP port• network—Network port• wa—Wired authentication port
Media	Link type: <ul style="list-style-type: none">• 10/100BaseTX—10/100BASE-T.• GBIC—1000BASE-SX or 1000BASE-LX GBIC.• 1000BaseT—1000BASE-T.• No connector—GBIC slot is empty.

See Also

- **clear port type on page 27**
- **set port on page 35**
- **set port name on page 38**
- **set port negotiation on page 39**
- **set port speed on page 40**
- **set port type ap on page 41**
- **set port type wired-auth on page 44**

System Services Commands

Use system services commands to configure and monitor system information for a WLAN—Security Switch (WSS). This chapter presents system services commands alphabetically. Use the following table to located commands in this chapter based on their use.

Configuration	quickstart on page 57
Auto-Config	set auto-config on page 57
Display	clear banner motd on page 54 set banner motd on page 59 show banner motd on page 67 set confirm on page 60 set length on page 60
System Identification	set prompt on page 62 set system name on page 66 set system location on page 65 set system contact on page 62 set system countrycode on page 63 set system idle-timeout on page 64 set system ip-address on page 65 show load on page 67 show system on page 68 clear system on page 55 clear prompt on page 55
Help	help on page 56
History	history on page 57 clear history on page 54
License	set license on page 61

Technical Support

[show licenses on page 67](#)

[show tech-support on page 70](#)

clear banner motd

Deletes the message-of-the-day (MOTD) banner that is displayed before the login prompt for each CLI session on the WSS.

Syntax `clear banner motd`

Defaults None.

Access Enabled.

Examples To clear a banner, type the following command:

```
WSS# clear banner motd
success: change accepted
```



Note. As an alternative to clearing the banner, you can overwrite the existing banner with an empty banner by typing the following command: `set banner motd ^^`

See Also

- [set banner motd on page 59](#)
- [show banner motd on page 67](#)

clear history

Deletes the command history buffer for the current CLI session.

Syntax `clear history`

Defaults None.

Access All.

Examples To clear the history buffer, type the following command:

```
WSS# clear history
success: command buffer was flushed.
```

See Also [history on page 57](#)

clear prompt

Resets the system prompt to its previously configured value. If the prompt was not configured previously, this command resets the prompt to its default.

Syntax `clear prompt`

Defaults None.

Access Enabled.

Examples To reset the prompt, type the following command:

```
wildebeest# clear prompt
```

```
success: change accepted.
```

```
WSS#
```

See Also [set prompt on page 62](#). (For information about default prompts, see [“Command Prompts” on page 10](#).)

clear system

Clears the system configuration of the specified information.



Caution! If you change the IP address, any currently configured Mobility Domain operations cease. You must reset the Mobility Domain.

Syntax `clear system [contact | countrycode | idle-timeout | ip-address | location | name]`

contact	Resets the name of contact person for the WSS to null.
countrycode	Resets the country code for the WSS to null.
idle-timeout	Resets the number of seconds a CLI management session can remain idle to the default value (3600 seconds).
ip-address	Resets the IP address of the WSS to null.
location	Resets the location of the WSS to null.
name	Resets the name of the WSS to the default system name, which is <i>WSS-mm-nnnnnn</i> , where <i>mm</i> is the model number and <i>nnnnnn</i> is the last 6 digits of the switch’s MAC address.

Defaults None.

Access Enabled.

History

Version 4.1 Option **idle-timeout** added.

Examples To clear the location of the WSS, type the following command:

```
WSS# clear system location
success: change accepted.
```

See Also

- **set system contact on page 62**
- **set system countrycode on page 63**
- **set system idle-timeout on page 64**
- **set system ip-address on page 65**
- **set system location on page 65**
- **show config on page 553**
- **show system on page 68**

help

Displays a list of commands that can be used to configure and monitor the WSS.

Syntax help

Defaults None.

Access All.

Examples Use this command to see a list of available commands. If you have restricted access, you see fewer commands than if you have enabled access. To display a list of CLI commands available at the enabled access level, type the following command at the enabled access level:

WSS# help

Commands:

```
-----
clear          Clear, use 'clear help' for more information
commit        Commit the content of the ACL table
copy          Copy from filename (or url) to filename (or url)
crypto        Crypto, use 'crypto help' for more information
delete        Delete url
dir           Show list of files on flash device
disable       Disable privileged mode
exit          Exit from the Admin session
help         Show this help screen
history       Show contents of history substitution buffer
hit-sample-rate Set NP hit-counter sample rate
load         Load, use 'load help' for more information
logout       Exit from the Admin session
monitor      Monitor, use 'monitor help' for more information
ping         Send echo packets to hosts
quit         Exit from the Admin session
reset        Reset, use 'reset help' for more information
rollback     Remove changes to the edited ACL table
save         Save the running configuration to persistent storage
set          Set, use 'set help' for more information
show         Show, use 'show help' for more information
telnet       telnet IP address [server port]
```

traceroute Print the route packets take to network host

See Also [“Using CLI Help” on page 16](#)

history

Displays the command history buffer for the current CLI session.

Syntax **history**

Defaults None.

Access All.

Examples To show the history of your session, type the following command:

WSS> history

Show History (most recent first)

[00] show config

[01] show version

[02] enable

See Also **clear history on page 54**

quickstart

Runs a script that interactively helps you configure a new switch.

(For information, see the “CLI quickstart Command” section of the “WSS Setup Methods” chapter in the [Nortel WLAN Security Switch 2300 Series Configuration Guide](#).)



Caution! The **quickstart** command is for configuration of a new switch only. After prompting you for verification, the command erases the switch’s configuration before continuing. If you run this command on a switch that already has a configuration, the configuration will be erased. In addition, error messages such as *Critical AP Notice* for directly connected APs can appear.

set auto-config

Enables a WSS to contact a WLAN Management Software server for its configuration.

Syntax `set auto-config {enable | disable}`

enable Enables the switch to contact a WLAN Management Software server to request a configuration.

disable Disables the auto-config option.

Defaults The auto-config option is automatically enabled on an unconfigured 2350 when the factory reset switch is pressed during power on. However, auto-config is disabled by default on other models.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage A network administrator at the corporate office can preconfigure the switch in a WLAN Management Software network plan. The switch configuration must have a name for the switch, the model must be 2350, and the serial number must match the switch's serial number. The configuration should also include all other settings required for the deployment, including AP configuration, SSIDs, AAA settings, and so on.

When the WLAN Management Software server in the corporate network receives the configuration request, the server looks in the currently open network plan for a switch configuration with the same model and serial number as the one in the configuration request.

- If the network plan contains a configuration with a matching model and serial number, WLAN Management Software sends the configuration to the switch and restarts the switch. The switch boots using the configuration it received from WLAN Management Software.
- If the network plan does not have a configuration with a matching model and serial number, a verification warning appears in WLAN Management Software. The warning lists the switch's serial number and IP address. The network administrator can upload the switch into the network plan, configure switch parameters, and deploy the configuration to the switch.

To use the auto-config option with a new (unconfigured) 2350, insert a paperclip or similar object into the 2350's factory reset hole to press the switch. The factory reset switch must be held for about 3 seconds while the factory reset LED (the right LED above port 1) is lit. Normally, this LED remains solidly lit for 3 seconds after power on. However, when the factory reset switch is pressed, the LED flashes for 3 seconds instead.

If you want another WSS model to be able to access a WLAN Management Software server for a configuration, you also must preconfigure the WSS with the following information:

- IP address
- Default router (gateway) address
- Domain name and DNS server address

You can enable the switch to use the WSS Software DHCP client to obtain this information from a DHCP server in the local network where the switch will be deployed. Alternatively, you can statically configure the information.

The IP address and DNS information are configured independently. You can configure the combination of settings that work with the network resources available at the deployment site. The following examples show some of the combinations you can configure.

Examples The following commands stage a WSS to use the auto-config option. The network where the switch is installed has a DHCP server, so the switch is configured to use the WSS Software DHCP client to obtain an IP address, default router address, DNS domain name, and DNS server IP addresses.

- 1 Configure a VLAN:


```
2360# set vlan 1 port 7
success: change accepted.
```
- 2 Enable the DHCP client on VLAN 1:


```
WSS# set interface 1 ip dhcp-client enable
success: change accepted.
```
- 3 Enable the auto-config option:


```
WSS# set auto-config enable
success: change accepted.
```
- 4 Save the configuration changes:


```
WSS# save config
success: configuration saved.
```

See Also

- [crypto generate key on page 472](#)
- [crypto generate self-signed on page 475](#)
- [save config on page 548](#)
- [set interface dhcp-client on page 110](#)
- [set vlan port on page 80](#)

set banner motd

Configures the banner string that is displayed before the beginning of each login prompt for each CLI session on the WSS.

Syntax `set banner motd ^text^`

<code>^</code>	Delimiting character that begins and ends the message.
<code>text</code>	Up to 2000 alphanumeric characters, including tabs and carriage returns, but <i>not</i> the delimiting character (^). The maximum number of characters is approximately 24 lines by 80 characters.

Defaults None.

Access Enabled.

Usage Type a caret (^), then the message, then another caret.

Do not use the following characters with commands in which you set text to be displayed on the WSS, such as message-of-the-day (MOTD) banners:

- Ampersand (&)
- Angle brackets (<>)
- Double quotation marks (""')

- Number sign (#)
- Question mark (?)
- Single quotation mark (')

Examples To create a banner that says *Update meeting at 3 p.m.*, type the following command:

```
WSS# set banner motd ^Update meeting at 3 p.m.^
success: change accepted.
```

See Also

- **clear banner motd on page 54**
- **show banner motd on page 67**

set confirm

Enables or disables the display of confirmation messages for commands that might have a large impact on the network.

Syntax `set confirm {on | off}`

on	Enables confirmation messages.
off	Disables confirmation messages.

Defaults Configuration messages are enabled.

Access Enabled.

Usage This command remains in effect for the duration of the session, until you enter an **exit** or **quit** command, or until you enter another **set confirm** command.

WSS Software displays a message requiring confirmation when you enter certain commands that can have a potentially large impact on the network. For example:

```
WSS# clear vlan red
```

```
This may disrupt user connectivity. Do you wish to continue? (y/n) [n]
```

Examples To turn off these confirmation messages, type the following command:

```
WSS# set confirm off
```

```
success: Confirm state is off
```

set length

Defines the number of lines of CLI output to display between paging prompts. WSS Software displays the set number of lines and waits for you to press any key to display another set, or type **q** to quit the display.

Syntax `set length number-of-lines`

number-of-lines Number of lines of text to display between paging prompts. You can specify from 0 to 512. The 0 value disables the paging prompt action entirely.

Defaults WSS Software displays 24 lines by default.

Access All.

Usage Use this command if the output of a CLI command is greater than the number of lines allowed by default for a terminal type.

Examples To set the number of lines displayed to 100, type the following command:

WSS# set length 100

success: screen length for this session set to 100

set license

Installs an upgrade license key on a 2380 or 2382 switch.

The 2380 can boot and manage up to 40 APs by default. You can increase the AP support to 80 APs or 120 APs, by installing one or two activation keys. You can install a 40-AP upgrade or an 80-AP upgrade. If you have already installed a 40-AP upgrade, you can install an additional 40-AP upgrade.

The 2382 can boot and manage up to 32 APs by default. You can increase the AP support to 64 APs, 96 AP's or 128 APs, by installing one, two or three activation keys. You can install combinations of 32-AP upgrade or 64-AP upgrades. If you have already installed a 32-AP upgrade, you can install an additional 32-AP or 64 AP upgrade.

Syntax `set license activation-key`

activation-key Hexadecimal digits generated by the Nortel license server or otherwise provided by Nortel for your switch.
The activation key is based on the switch's serial number.
You can enter the number in either of the following formats:
xxxx-xxxx-xxxx-xxxx-xxxx
xxxxxxxxxxxxxxxxxxxxxx

Defaults None.

Access Enabled.

Usage This command applies only to the 2380 and 2382.

Examples To install an activation key for an additional 32 AP's for 2382 (or 80 APs for the 2380) type the following command:

WSS# set license 3B02-D821-6C19-CE8B-F20E

success: license accepted

See Also [show licenses on page 67](#)

set prompt

Changes the CLI prompt for the WSS to a string you specify.

Syntax `set prompt string`

string Alphanumeric string up to 32 characters long. To include spaces in the prompt, you must enclose the string in double quotation marks (“”).

Defaults The factory default for the WSS name is `WSS-mm-nnnnnn`, where *mm* is the model number and *nnnnnn* is the last 6 digits of the 12-digit system MAC address.

Access Enabled.

Usage When you first log in for the initial configuration of the WSS, the CLI provides a `WSS-mm-nnnnnn>` prompt. After you become enabled by typing **enable** and giving a suitable password, the `WSS-mm-nnnnnn#` prompt is displayed.

If you use the **set system name** command to change the default system name, WSS Software uses that name in the prompt, unless you also change the prompt with **set prompt**.

Examples The following example sets the prompt from WSS to *happy_days*:

```
WSS# set prompt happy_days
success: change accepted.
happy_days#
```

See Also

- [clear prompt on page 55](#)
- [set system name on page 66](#)
- [show config on page 553](#)

set system contact

Stores a contact name for the WSS.

Syntax `set system contact string`

string Alphanumeric string up to 256 characters long and blank spaces are accepted.

Defaults None.

Access Enabled.

To view the system contact string, type the **show system** command.

Examples The following command sets the system contact information to *tamara@example.com*:

```
23x0#set system contact tamara@example.com
```

success: change accepted.

See Also

- **clear system on page 55**
- **set system location on page 65**
- **set system name on page 66**
- **show system on page 68**

set system countrycode

Defines the country-specific IEEE 802.11 regulations to enforce on the WSS.

Syntax `set system countrycode code`

code

For the two-letter country code, refer to the approved list of country codes "Approved Countries for the WLAN 2300 Series Components" located at <http://www.nortel.com/support>.



Note. For a complete listing of the models in the WLAN Series 2332 and their respective countries of operation, please visit <http://www.nortel.com/support>.

The Series 2332 access point has been region-locked to meet geographic regulatory restrictions. Each model is associated to a specific regulatory domain and subsequent country of operation. During installation, the access point model and wireless security switch regulatory domain must match or the access point will not operate.

Defaults The factory default country code is *None*.

Access Enabled.

Usage You must set the system county code to a valid value before using any **set ap** commands to configure an Access Point (AP).

Examples To set the country code to Canada, type the following command:

```
23x0#set system country code CA
```

success: change accepted.

See Also [show config on page 553](#)



Note. For Series 2332 access points, be sure the system country code is supported for the selected access point model.

set system idle-timeout

Specifies the maximum number of seconds a CLI management session with the switch can remain idle before WSS Software terminates the session.

Syntax `set system idle-timeout seconds`

seconds Number of seconds a CLI management session can remain idle before WSS Software terminates the session. You can specify from 0 to 86400 seconds (one day). If you specify 0, the idle timeout is disabled. The timeout interval is in 30-second increments. For example, the interval can be 0, or 30 seconds, or 60 seconds, or 90 seconds, and so on. If you enter an interval that is not divisible by 30, the CLI rounds up to the next 30-second increment. For example, if you enter 31, the CLI rounds up to 60.

Defaults 3600 seconds (one hour).

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage This command applies to all types of CLI management sessions: console, Telnet, and SSH. The timeout change applies to existing sessions only, not to new sessions.

Examples The following command sets the idle timeout to 1800 seconds (one half hour):

```
WSS# set system idle-timeout 1800
success: change accepted.
```

See Also

- [clear system on page 55](#)
- [show system on page 68](#)

set system ip-address

Sets the system IP address so that it can be used by various services in the WSS.



Caution! Any currently configured Mobility Domain operations cease if you change the IP address. If you change the address, you must reset the Mobility Domain.

Syntax `set system ip-address ip-addr`

ip-addr IP address, in dotted decimal notation.

Defaults None.

Access Enabled.

Examples The following command sets the IP address of the WSS to 192.168.253.1:

```
WSS# set system ip-address 192.168.253.1
success: change accepted.
```

See Also

- [clear system on page 55](#)
- [set interface on page 109](#)
- [show system on page 68](#)

set system location

Stores location information for the WSS.

Syntax `set system location string`

string Alphanumeric string up to 256 characters long and blank spaces are accepted.

Defaults None.

Access Enabled.

Usage You cannot include spaces in the system location string.

To view the system location string, type the **show system** command.

Examples To store the location of the WSS in the switch's configuration, type the following command:

```
WSS# set system location first-floor-bldg3
success: change accepted.
```

See Also

- **clear system on page 55**
- **set system contact on page 62**
- **set system name on page 66**
- **show system on page 68**

set system name

Changes the name of the WSS from the default system name and also provides content for the CLI prompt, if you do not specify a prompt.

Syntax `set system name string`

string Alphanumeric string up to 256 characters long, with no blank spaces. WLAN Management Software requires unique WSS names.

Defaults By default, the system name and command prompt have the same value. The factory default for both is *WSS-*mmmm*-*nnnnnn**, where *mm* is the model number and *nnnnnn* is the last 6 digits of the 12-digit system MAC address.

Access Enabled.

Usage Entering `set system name` with no string resets the system name to the factory default.

To view the system name string, type the `show system` command.

Examples The following example sets the system name to a name that identifies the WSS:

```
WSS# set system name WSS-bldg3
success: change accepted.
WSS-bldg3#
```

See Also

- **clear system on page 55**
- **set prompt on page 62**
- **set system contact on page 62**
- **set system location on page 65**
- **show system on page 68**

show banner motd

Shows the banner that was configured with the **set banner motd** command.

Syntax **show banner motd**

Defaults None.

Access Enabled.

Examples To display the banner with the message of the day, type the following command:

```
WSS# show banner motd
hello world
```

See Also

- **clear banner motd on page 54**

show licenses

Displays information about the license key(s) currently installed on a 2380 or 2382 switch.

Syntax **show licenses**

Defaults None.

Access All.

Usage This command applies only to the 2380 or 2382.

Examples To view license keys, type the following command:

```
WSS# show licenses
Feature   : 80 additional APs
```

See Also **set license on page 61**

show load

Displays CPU usage on a WSS.

Syntax **show load**

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples To display the CPU load recorded from the time the WSS was booted, as well as from the previous time the **show load** command was run, type the following command:

```
WSS# show load
System Load: overall: 2% delta: 5%
```

The overall field shows the CPU load as a percentage from the time the WSS was booted. The delta field shows CPU load as a percentage from the last time the **show load** command was entered.

See Also [show system](#) on page 68

show system

Displays system information.

Syntax `show system`

Defaults None.

Access Enabled.

History

Version 4.0 License field removed. To display license information, use the **show license** command.

Examples To show system information, type the following command:

WSS# show system

```
=====
=
Product Name:      WSS
System Name:       WSS-bldg3
System Countrycode:  US
System Location:   first-floor-bldg3
System Contact:    tamara@example.com
System IP:         192.168.12.7
System idle timeout: 3600
System MAC:        00:0B:0E:00:04:30
=====
=
Boot Time:         2003-11-07 15:45:49
Uptime:           13 days 04:29:10
=====
=
Fan status:        fan1 OK fan2 OK fan3 OK
Temperature:       temp1 ok temp2 ok temp3 ok
PSU Status:        Lower Power Supply DC ok AC ok Upper Power Supply missing
Memory:           97.04/744.03 (13%)
Total Power Over   29.000
Ethernet :         29.000
=====
=
```

[Table 10](#) describes the fields of **show system** output.

Table 1: show system output

Field	Description
Product Name	WSS model number.
System Name	System name (factory default, or optionally configured with set system name).
System Countrycode	Country-specific 802.11 code required for AP operation (configured with set system countrycode).
System Location	Record of WSS's physical location (optionally configured with set system location).
System Contact	Contact information about the system administrator or another person to contact about the system (optionally configured with set system contact).
System IP	Common interface, source, and default IP address for the WSS, in dotted decimal notation (configured with set system ip-address).
System idle timeout	Number of seconds WSS Software allows a CLI management session (console, Telnet, or SSH) to remain idle before terminating the session. (The system idle timeout can be configured using the set system idle-timeout command.)
System MAC	WSS media access control (MAC) machine address set at the factory, in 6-byte hexadecimal format.
Boot Time	Date and time of the last system reboot.
Uptime	Number of days, hours, minutes, and seconds that the WSS has been operating since its last restart.
Fan status	<p>Operating status of the three WSS cooling fans:</p> <ul style="list-style-type: none"> • OK—Fan is operating. • Failed—Fan is not operating. WSS Software sends an alert to the system log every 5 minutes until this condition is corrected. <p>Fan 1 is located nearest the front of the chassis, and fan 3 is located nearest the back.</p>
Temperature	<p>Status of temperature sensors at three locations in the WSS:</p> <ul style="list-style-type: none"> • ok—Temperature is within the acceptable range of 0° C to 50° C (32° F to 122° F). • Alarm—Temperature is above or below the acceptable range. WSS Software sends an alert to the system log every 5 minutes until this condition is corrected.

Table 1: show system output (continued)

Field	Description
PSU Status	Status of the lower and upper power supply units: <ul style="list-style-type: none">• missing—Power supply is not installed or is inoperable.• DC ok—Power supply is producing DC power.• DC output failure—Power supply is not producing DC power. WSS Software sends an alert to the system log every 5 minutes until this condition is corrected.• AC ok—Power supply is receiving AC power.• AC not present—Power supply is not receiving AC power.
Memory	Current size (in megabytes) of nonvolatile memory (NVRAM) and synchronous dynamic RAM (SDRAM), plus the percentage of total memory space in use, in the following format: <i>NVRAM size / SDRAM size (percent of total)</i>
Total Power Over Ethernet	Total power that the WSS is currently supplying to its directly connected APs, in watts.

See Also

- **clear system on page 55**
- **set system contact on page 62**
- **set system countrycode on page 63**
- **set system idle-timeout on page 64**
- **set system ip-address on page 65**
- **set system location on page 65**
- **set system name on page 66**

show tech-support

Provides an in-depth snapshot of the status of the WSS, which includes details about the boot image, the version, ports, and other configuration values. This command also displays the last 100 log messages.

Syntax `show tech-support [file [subdirname/]filename]`

[subdirname/]filename

Optional subdirectory name, and a string up to 32 alphanumeric characters. The command's output is saved into a file with the specified name in nonvolatile storage.

Defaults None.

Access Enabled.

Usage Enter this command before calling the Nortel Enterprise Technical Support (NETS). See [“How to get help” on page 3](#) for more information.

See Also

- **show boot on page 551**
- **show config on page 553**
- **show licenses on page 67**
- **show system on page 68**
- **show version on page 554**

VLAN Commands

Use virtual LAN (VLAN) commands to configure and manage parameters for individual port VLANs on network ports, and to display information about clients roaming within a mobility domain. This chapter presents VLAN commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Creation	set vlan name on page 79
Ports	set vlan port on page 80
	clear vlan on page 76
	show vlan config on page 89
Roaming and Tunnels	show roaming station on page 84
	show roaming vlan on page 85
	show tunnel on page 88
Restriction of Client Layer 2 Forwarding	set security l2-restrict on page 78
	show security l2-restrict on page 87
	clear security l2-restrict on page 75
	clear security l2-restrict counters on page 75
Tunnel Affinity	set vlan tunnel-affinity on page 81
FDB Entries	set fdb on page 77
	show fdb on page 81
	show fdb count on page 84
	clear fdb on page 74
FDB Aging Timeout	set fdb agingtime on page 78
	show fdb agingtime on page 83

clear fdb

Deletes an entry from the forwarding database (FDB).

Syntax `clear fdb {perm | static | dynamic | port port-list} [vlan vlan-id] [tag tag-value]`

perm	Clears permanent entries. A permanent entry does not age out and remains in the database even after a reboot, reset, or power cycle. You must specify a VLAN name or number with this option.
static	Clears static entries. A static entry does not age out, but is removed from the database after a reboot, reset, or power cycle. You must specify a VLAN name or number with this option.
dynamic	Clears dynamic entries. A dynamic entry is automatically removed through aging or after a reboot, reset, or power cycle. You are not required to specify a VLAN name or number with this option.
port <i>port-list</i>	Clears dynamic entries that match destination ports in the port list. You are not required to specify a VLAN name or number with this option.
vlan <i>vlan-id</i>	VLAN name or number—required for removing permanent and static entries. For dynamic entries, specifying a VLAN removes entries that match only that VLAN. Otherwise, dynamic entries that match all VLANs are removed.
tag <i>tag-value</i>	VLAN tag value that identifies a virtual port. If you do not specify a tag value, WSS Software deletes only entries that match untagged interfaces. Specifying a tag value deletes entries that match only the specified tagged interface.

Defaults None.

Access Enabled.

Usage You can delete forwarding database entries based on entry type, port, or VLAN. A VLAN name or number is required for deleting permanent or static entries.

Examples The following command clears all static forwarding database entries that match VLAN *blue*:

```
WSS# clear fdb static vlan blue
```

```
success: change accepted.
```

The following command clears all dynamic forwarding database entries that match all VLANs:

```
WSS# clear fdb dynamic
```

```
success: change accepted.
```

The following command clears all dynamic forwarding database entries that match ports 3 and 5:

```
WSS# clear fdb port 3,5
```

```
success: change accepted.
```

See Also

- [set fdb on page 77](#)
- [show fdb on page 81](#)

clear security I2-restrict

Removes one or more MAC addresses from the list of destination MAC addresses to which clients in a VLAN are allowed to send traffic at Layer 2.

Syntax `clear security I2-restrict vlan vlan-id [permit-mac mac-addr [mac-addr] | all]`

<i>vlan-id</i>	VLAN name or number.
permit-mac <i>mac-addr</i> [<i>mac-addr</i>]	List of MAC addresses. WSS Software no longer allows clients in the VLAN to send traffic to the MAC addresses at Layer 2.
all	Removes all MAC addresses from the list.

Defaults If you do not specify a list of MAC addresses or **all**, all addresses are removed.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage If you clear all MAC addresses, Layer 2 forwarding is no longer restricted in the VLAN. Clients within the VLAN will be able to communicate directly.

There can be a slight delay before functions such as pinging between clients become available again after Layer 2 restrictions are lifted. Even though packets are passed immediately once Layer 2 restrictions are gone, it can take 10 seconds or more for upper-layer protocols to update their ARP caches and regain their functionality.

To clear the statistics counters without removing any MAC addresses, use the **clear security I2-restrict counters** command instead.

Examples The following command removes MAC address aa:bb:cc:dd:ee:ff from the list of addresses to which clients in VLAN *abc_air* are allowed to send traffic at Layer 2:

```
WSS# clear security I2-restrict vlan abc_air permit-mac aa:bb:cc:dd:ee:ff
success: change accepted.
```

See Also

- [clear security I2-restrict counters on page 75](#)
- [set security I2-restrict on page 78](#)
- [show security I2-restrict on page 87](#)

clear security I2-restrict counters

Clear statistics counters for Layer 2 forwarding restriction.

Syntax `clear security I2-restrict counters [vlan vlan-id | all]`

<i>vlan-id</i>	VLAN name or number.
all	Clears Layer 2 forwarding restriction counters for all VLANs.

Defaults If you do not specify a VLAN or **all**, counters for all VLANs are cleared.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage To clear MAC addresses from the list of addresses to which clients are allowed to send data, use the **clear security l2-restrict** command instead.

Examples The following command clears Layer 2 forwarding restriction statistics for VLAN *abc_air*:

```
WSS# clear security l2-restrict counters vlan abc_air
success: change accepted.
```

See Also

- **clear security l2-restrict** on page 75
- **set security l2-restrict** on page 78
- **show security l2-restrict** on page 87

clear vlan

Removes physical or virtual ports from a VLAN or removes a VLAN entirely.



Caution! When you remove a VLAN, WSS Software completely removes the VLAN from the configuration and also removes all configuration information that uses the VLAN. If you want to remove only a specific port from the VLAN, make sure you specify the port number in the command.

Syntax **clear vlan** *vlan-id* [**port** *port-list* [**tag** *tag-value*]]

<i>vlan-id</i>	VLAN name or number.
port <i>port-list</i>	List of physical ports. WSS Software removes the specified ports from the VLAN. If you do not specify a list of ports, WSS Software removes the VLAN entirely.
tag <i>tag-value</i>	Tag number that identifies a virtual port. WSS Software removes only the specified virtual port from the specified physical ports.

Defaults None.

Access Enabled.

Usage If you do not specify a *port-list*, the entire VLAN is removed from the configuration.



Note. You cannot delete the default VLAN but you can remove ports from it. To remove ports from the default VLAN, use the **port** *port-list* option.

Examples The following command removes port 1 from VLAN *green*:

WSS# clear vlan green port 1

This may disrupt user connectivity. Do you wish to continue? (y/n) [n]y
success: change accepted.

The following command removes port 4, which uses tag value 69, from VLAN *red*:

WSS# clear vlan red port 4 tag 69

This may disrupt user connectivity. Do you wish to continue? (y/n) [n]y
success: change accepted.

The following command completely removes VLAN *marigold*:

WSS# clear vlan marigold

This may disrupt user connectivity. Do you wish to continue? (y/n) [n]y
success: change accepted.

See Also

- **set vlan port on page 80**
- **show vlan config on page 89**

set fdb

Adds a permanent or static entry to the forwarding database.

Syntax **set fdb** {**perm** | **static**} *mac-addr* **port** *port-list*
vlan *vlan-id* [**tag** *tag-value*]

perm	Adds a permanent entry. A permanent entry does not age out and remains in the database even after a reboot, reset, or power cycle.
static	Adds a static entry. A static entry does not age out, but is removed from the database after a reboot, reset, or power cycle.
<i>mac-addr</i>	Destination MAC address of the entry. Use colons to separate the octets (for example, 00:11:22:aa:bb:cc).
port <i>port-list</i>	List of physical destination ports for which to add the entry. A separate entry is added for each port you specify.
vlan <i>vlan-id</i>	Name or number of a VLAN of which the port is a member. The entry is added only for the specified VLAN.
tag <i>tag-value</i>	VLAN tag value that identifies a virtual port. You can specify a number from 1 through 4093. If you do not specify a tag value, an entry is created for an untagged interface only. If you specify a tag value, an entry is created only for the specified tagged interface.

Defaults None.

Access Enabled.

Usage You cannot add a multicast or broadcast address as a permanent or static FDB entry.

Examples The following command adds a permanent entry for MAC address 00:11:22:aa:bb:cc on ports 3 and 5 in VLAN *blue*:

```
WSS# set fdb perm 00:11:22:aa:bb:cc port 3,5 vlan blue
success: change accepted.
```

The following command adds a static entry for MAC address 00:2b:3c:4d:5e:6f on port 1 in the *default* VLAN:

```
WSS# set fdb static 00:2b:3c:4d:5e:6f port 1 vlan default
success: change accepted.
```

See Also

- **clear fdb on page 74**
- **show fdb on page 81**

set fdb agingtime

Changes the aging timeout period for dynamic entries in the forwarding database.

Syntax `set fdb agingtime vlan-id age seconds`

<i>vlan-id</i>	VLAN name or number. The timeout period change applies only to entries that match the specified VLAN.
age seconds	Value for the timeout period, in seconds. You can specify a value from 0 through 1,000,000. If you change the timeout period to 0, aging is disabled.

Defaults The aging timeout period is 300 seconds (5 minutes).

Access Enabled.

Examples The following command changes the aging timeout period to 600 seconds for entries that match VLAN *orange*:

```
WSS# set fdb agingtime orange age 600
success: change accepted.
```

See Also **show fdb agingtime on page 83**

set security l2-restrict

Restricts Layer 2 forwarding between clients in the same VLAN. When you restrict Layer 2 forwarding in a VLAN, WSS Software allows Layer 2 forwarding only between a client and a set of MAC addresses, generally the VLAN's default routers. Clients within the VLAN are not permitted to communicate among themselves directly. To communicate with another client, the client must use one of the specified default routers.

Syntax `set security l2-restrict vlan vlan-id`
`[mode {enable | disable}] [permit-mac mac-addr [mac-addr]]`

vlan-id VLAN name or number.

mode {enable | disable} Enables or disables restriction of Layer 2 forwarding.

permit-mac *mac-addr* [*mac-addr*] MAC addresses to which clients are allowed to forward data at Layer 2. You can specify up to four addresses.

Defaults Layer 2 restriction is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage You can specify multiple addresses by listing them on the same command line or by entering multiple commands. To change a MAC address, use the **clear security l2-restrict** command to remove it, then use the **set security l2-restrict** command to add the correct address.

Restriction of client traffic does not begin until you enable the permitted MAC list. Use the **mode enable** option with this command.

Examples The following command restricts Layer 2 forwarding of client data in VLAN *abc_air* to the default routers with MAC address aa:bb:cc:dd:ee:ff and 11:22:33:44:55:66:

```
WSS# set security l2-restrict vlan abc_air mode enable permit-mac aa:bb:cc:dd:ee:ff
11:22:33:44:55:66
success: change accepted.
```

See Also

- [clear security l2-restrict on page 75](#)
- [clear security l2-restrict counters on page 75](#)
- [show security l2-restrict on page 87](#)

set vlan name

Creates a VLAN and assigns a number and name to it.

Syntax `set vlan vlan-num name name`

vlan-num VLAN number. You can specify a number from 2 through 4093.

name String up to 16 alphabetic characters long.

Defaults VLAN 1 is named *default* by default. No other VLANs have default names.

Access Enabled.

Usage You must assign a name to a VLAN (other than the default VLAN) before you can add ports to the VLAN.

Nortel recommends that you do not use the name *default*. This name is already used for VLAN 1. Nortel also recommends that you do not rename the default VLAN.

You cannot use numbers in the VLAN name. Nortel recommends that you do not use the same name with different capitalizations for VLANs. For example, do not configure two separate VLANs with the names *red* and *RED*.

VLAN names are case-sensitive for RADIUS authorization when a client roams to a WSS. If the switch is not configured with the VLAN the client is on, but is configured with a VLAN that has the same spelling but different capitalization, authorization for the client fails. For example, if the client is on VLAN *red* but the WSS to which the client roams has VLAN *RED* instead, RADIUS authorization fails.

Examples The following command assigns the name *marigold* to VLAN 3:

```
WSS# set vlan 3 name marigold
success: change accepted.
```

See Also [set vlan port on page 80](#)

set vlan port

Assigns one or more network ports to a VLAN. You also can add a virtual port to each network port by adding a tag value to the network port.

Syntax `set vlan vlan-id port port-list [tag tag-value]`

<i>vlan-id</i>	VLAN name or number.
port <i>port-list</i>	List of physical ports.
tag <i>tag-value</i>	Tag value that identifies a virtual port. You can specify a value from 1 through 4093.

Defaults By default, no ports are members of any VLANs. A WSS cannot forward traffic on the network until you configure VLANs and add network ports to the VLANs.

Access Enabled.

Usage You can combine this command with the **set port name** command to assign the name and add the ports at the same time.

If you do not specify a tag value, the WSS sends untagged frames for the VLAN. If you do specify a tag value, the switch sends tagged frames only for the VLAN.

If you do specify a tag value, Nortel recommends that you use the same value as the VLAN number. WSS Software does not require the VLAN number and tag value to be the same but some other vendors' devices do.

Examples The following command assigns the name *beige* to VLAN 11 and adds ports 1 through 3 to the VLAN:

```
WSS# set vlan 11 name beige port 1-3
success: change accepted.
```

The following command adds port 16 to VLAN *beige* and assigns tag value 86 to the port:

```
WSS# set vlan beige port 16 tag 86
success: change accepted.
```

See Also

- [clear vlan on page 76](#)
- [set vlan name on page 79](#)
- [show vlan config on page 89](#)

set vlan tunnel-affinity

Changes a WSS's preferability within a mobility domain for tunneling user traffic for a VLAN. When a user roams to a WSS that is not a member of the user's VLAN, the switch can forward the user traffic by tunneling to another WSS that is a member of the VLAN.

Syntax `set vlan vlan-id tunnel-affinity num`

<i>vlan-id</i>	VLAN name or number.
<i>num</i>	Preference of this switch for forwarding user traffic for the VLAN. You can specify a value from 1 through 10. A higher number indicates a greater preference.

Defaults Each VLAN on a WSS's network ports has an affinity value of 5 by default.

Access Enabled.

Usage Increasing a switch's affinity value increases the switch's preferability for forwarding user traffic for the VLAN.

If more than one WSS has the highest affinity value, WSS Software randomly selects one of the switches for the tunnel.

Examples The following command changes the VLAN affinity for VLAN *beige* to 10:

```
WSS# set vlan beige tunnel-affinity 10
success: change accepted.
```

See Also

- [show roaming vlan on page 85](#)
- [show vlan config on page 89](#)

show fdb

Displays entries in the forwarding database.

Syntax `show fdb [mac-addr-wildcard [vlan vlan-id]]`

`show fdb {perm | static | dynamic | system | all} [port port-list | vlan vlan-id]`

<i>mac-addr-wildcard</i>	A single MAC address or set of MAC addresses. Specify a MAC address, or use the wildcard character (*) to specify a set of MAC addresses. (For details, see “MAC Address Wildcards” on page 13.)
vlan <i>vlan-id</i>	Name or number of a VLAN for which to display entries.
perm	Displays permanent entries. A permanent entry does not age out and remains in the database even after a reboot, reset, or power cycle.
static	Displays static entries. A static entry does not age out, but is removed from the database after a reboot, reset, or power cycle.
dynamic	Displays dynamic entries. A dynamic entry is automatically removed through aging or after a reboot, reset, or power cycle.
system	Displays system entries. A system entry is added by WSS Software. For example, the authentication protocols can add entries for wired and wireless authentication users.
all	Displays all entries in the database, or all the entries that match a particular port or ports or a particular VLAN.
port <i>port-list</i>	Destination port(s) for which to display entries.

Defaults None.

Access All.

Usage To display the entire forwarding database, enter the **show fdb** command without options. To display only a portion of the database, use optional parameters to specify the types of entries you want to display.

Examples The following command displays all entries in the forwarding database:

WSS# show fdb all

* = Static Entry. + = Permanent Entry. # = System Entry.

VLAN TAG	Dest MAC/Route	Des [CoS]	Destination Ports	[Protocol Type]
1	00:01:97:13:0b:1f		1	[ALL]
1	aa:bb:cc:dd:ee:ff	*	3	[ALL]
1	00:0b:0e:02:76:f5		1	[ALL]

Total Matching FDB Entries Displayed = 3

The top line of the display identifies the characters to distinguish among the entry types.

The following command displays all entries that begin with the MAC address wildcard 00:

WSS# show fdb 00:*

* = Static Entry. + = Permanent Entry. # = System Entry.

VLAN TAG	Dest MAC/Route	Des [CoS]	Destination Ports	[Protocol Type]
1	00:01:97:13:0b:1f		1	[ALL]
1	00:0b:0e:02:76:f5		1	[ALL]

Total Matching FDB Entries Displayed = 2

Table 11 describes the fields in the **show fdb** output.

Table 1: Output for show fdb

Field	Description
VLAN	VLAN number.
TAG	VLAN tag value. If the interface is untagged, the TAG field is blank.
Dest MAC/Route Des	MAC address of this forwarding entry's destination.
CoS	Type of entry. The entry types are explained in the first row of the command output. Note: This Class of Service (CoS) value is not associated with WSS Software quality of service (QoS) features.
Destination Ports	WSS port associated with the entry. A switch sends traffic to the destination MAC address through this port.
Protocol Type	Layer 3 protocol address types that can be mapped to this entry.
Total Matching FDB Entries Displayed	Number of entries displayed by the command.

See Also

- **clear fdb on page 74**
- **set fdb on page 77**

show fdb agingtime

Displays the aging timeout period for forwarding database entries.

Syntax `show fdb agingtime [vlan vlan-id]`

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, the aging timeout period for each VLAN is displayed.

Defaults None.

Access All.

Examples The following command displays the aging timeout period for all VLANs:

```
WSS# show fdb agingtime
VLAN 2 aging time = 600 sec
VLAN 1 aging time = 300 sec
```

Because the forwarding database aging timeout period can be configured only on an individual VLAN basis, the command lists the aging timeout period for each VLAN separately.

See Also [set fdb agingtime on page 78](#)

show fdb count

Lists the number of entries in the forwarding database.

Syntax `show fdb count {perm | static | dynamic} [vlan vlan-id]`

perm	Lists the number of permanent entries. A permanent entry does not age out and remains in the database even after a reboot, reset, or power cycle.
static	Lists the number of static entries. A static entry does not age out, but is removed from the database after a reboot, reset, or power cycle.
dynamic	Lists the number of dynamic entries. A dynamic entry is automatically removed through aging or after a reboot, reset, or power cycle.
vlan <i>vlan-id</i>	VLAN name or number. Entries are listed for only the specified VLAN.

Defaults None.

Access All.

Examples The following command lists the number of dynamic entries that the forwarding database contains:

```
WSS# show fdb count dynamic
```

```
Total Matching Entries = 2
```

See Also [show fdb on page 81](#)

show roaming station

Displays a list of the stations roaming to the WSS through a VLAN tunnel.

Syntax `show roaming station [vlan vlan-id] [peer ip-addr]`

vlan <i>vlan-id</i>	Output is restricted to stations using this VLAN.
peer <i>ip-addr</i>	Output is restricted to stations tunnelling through this peer WSS in the Mobility Domain.

Defaults None.

Access Enabled.

History

Version 4.0	Old AP MAC field removed.
-------------	---------------------------

Usage The output displays roaming stations within the previous 1 second.

Examples To display all stations roaming to the WSS, type the following command:

```
WSS# show roaming station
User Name      Station Address  VLAN      State
-----
redsqa         10.10.10.5      violet     Up
```

Table 12 describes the fields in the display.

Table 2: Output for show roaming station

Field	Description
User Name	Name of the user. This is the name used for authentication. The name resides in a RADIUS server database or the local user database on a WSS.
Station Address	IP address of the user device.
VLAN	Name of the VLAN to which the RADIUS server or WSS local user database assigned the user.
State	State of the session: <ul style="list-style-type: none"> • Setup—Station is attempting to roam to this WSS. This switch has asked the WSS from which the station is roaming for the station's session information and is waiting for a reply. • Up—WSS Software has established a tunnel between the WSSs and the station has successfully roamed to this WSS over the tunnel. • Chck—This WSS is in the process of accepting a reassociation request from the roaming peer WSS for a station currently roaming to the peer switch. • TChck—This WSS is in the process of accepting a reassociation request from the roaming peer WSS for a station currently roaming to this switch. • WInd—This WSS is waiting for network congestion to clear before sending the roaming indication to the roaming peer WSS. • WResp—This WSS is waiting for network congestion to clear before sending the roaming response to the roaming peer WSS.

See Also [show roaming vlan on page 85](#)

show roaming vlan

Shows all VLANs in the mobility domain, the WSSs servicing the VLANs, and their tunnel affinity values configured on each switch for the VLANs.

Syntax `show roaming vlan`

Defaults None.

Access Enabled.

Examples The following command shows the current roaming VLANs:

WSS# `show roaming vlan`

VLAN	WSS	Affinity
-----	-----	-----
vlan-cs	192.168.14.2	5
vlan-eng	192.168.14.4	5
vlan-fin	192.168.14.2	5
vlan-it	192.168.14.4	5
vlan-it	192.168.14.2	5
vlan-pm	192.168.14.2	5
vlan-sm	192.168.14.2	5
vlan-tp	192.168.14.4	5
vlan-tp	192.168.14.2	5

Table 13 describes the fields in the display.

Table 3: Output for show roaming vlan

Field	Description
VLAN	VLAN name.
WSS	System IP address of the WSS on which the VLAN is configured.
Affinity	Preference of this switch for forwarding user traffic for the VLAN. A higher number indicates a greater preference.

See Also

- **show roaming station** on page 84
- **show vlan config** on page 89

show security l2-restrict

Displays configuration information and statistics for Layer 2 forwarding restriction.

Syntax `show security l2-restrict [vlan vlan-id | all]`

<i>vlan-id</i>	VLAN name or number.
all	Displays information for all VLANs.

Defaults If you do not specify a VLAN name or **all**, information is displayed for all VLANs.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command shows Layer 2 forwarding restriction information for all VLANs:

```
WSS# show security l2-restrict
VLAN Name      En Drops  Permit MAC      Hits
-----
 1 default      Y        0 00:0b:0e:02:53:3e 5947
                00:30:b6:3e:5c:a8  9
 2 vlan-2      Y        0 04:04:04:04:04:04  0
```

Table 14 describes the fields in the display.

Table 4: Output for show security l2-restrict

Field	Description
VLAN	VLAN number.
Name	VLAN name.
En	Enabled state of the feature for the VLAN: <ul style="list-style-type: none"> Y—Enabled. Forwarding of Layer 2 traffic from clients is restricted to the MAC address(es) listed under Permit MAC. N—Disabled. Layer 2 forwarding is not restricted.
Drops	Number of packets dropped because the destination MAC address was not one of the addresses listed under Permit MAC.
Permit MAC	MAC addresses to which clients in the VLAN are allowed to send traffic at Layer 2.
Hits	Number of packets whose source MAC address was a client in this VLAN, and whose destination MAC address was one of those listed under Permit MAC.

See Also

- [clear security l2-restrict on page 75](#)
- [clear security l2-restrict counters on page 75](#)
- [set security l2-restrict on page 78](#)

show tunnel

Displays the tunnels from the WSS where you type the command.

Syntax `show tunnel`

Defaults None.

Access Enabled

Examples To display all tunnels from a WSS to other switches in the Mobility Domain, type the following command.

WSS# show tunnel

```
VLAN      Local Address  Remote Address  State      Port  LVID  RVID
-----
vlan-eng  192.168.14.2   192.168.14.4   DORMANT   1024  4096  130
```

Table 15 describes the fields in the display.

Table 5: Output for show tunnel

Field	Description
VLAN	VLAN name.
Local Address	IP address of the local end of the tunnel. This is the system IP address of the WSS where you enter the command.
Remote Address	IP address of the remote end of the tunnel. This is the system IP address of another WSS in the mobility domain.
State	Tunnel state: <ul style="list-style-type: none"> • Up • Dormant
Port	Tunnel port ID.
LVID	Local VLAN ID.
RVID	Remote VLAN ID.

See Also [show vlan config on page 89](#)

show vlan config

Displays VLAN information.

Syntax `show vlan config [vlan-id]`

vlan-id VLAN name or number. If you do not specify a VLAN, information for all VLANs is displayed.

Defaults None.

Access All.

Examples The following command displays information for VLAN *burgundy*:

```

WSS# show vlan config burgundy
      Admin  VLAN  Tunl      Port
VLAN Name Status  State  Affin Port  Tag  State
-----
 2 burgundy  Up    Up      5
      2      none  Up
      3      none  Up
      4      none  Up
      6      none  Up
      11     none  Up
      t:10.10.40.4  none  Up

```

Table 16 describes the fields in this display.

Table 6: Output for show vlan config

Field	Description
VLAN	VLAN number.
Name	VLAN name.
Admin Status	Administrative status of the VLAN: <ul style="list-style-type: none"> Down—The VLAN is disabled. Up—The VLAN is enabled.
VLAN State	Link status of the VLAN: <ul style="list-style-type: none"> Down—The VLAN is not connected. Up—The VLAN is connected.
Tunl Affin	Tunnel affinity value assigned to the VLAN.
Port	Member port of the VLAN. The port can be a physical port or a virtual port. <ul style="list-style-type: none"> Physical ports are 10/100 Ethernet or gigabit Ethernet ports on the switch, and are listed by port number. Virtual ports are tunnels to other switches in a mobility domain, and are listed as follows: <i>t:ip-addr</i>, where <i>ip-addr</i> is the system IP address of the WSS at the other end of the tunnel. <p>Note: This field can include AP access ports and wired authentication ports, because WSS Software dynamically adds these ports to a VLAN when handling user traffic for the VLAN.</p>
Tag	Tag value assigned to the port.
Port State	Link state of the port: <ul style="list-style-type: none"> Down—The port is not connected. Up—The port is connected.

See Also

- **clear vlan on page 76**
- **set vlan name on page 79**
- **set vlan port on page 80**
- **set vlan tunnel-affinity on page 81**

Quality of Service Commands

Use Quality of Service (QoS) commands to configure packet prioritization in WSS Software. Packet prioritization ensures that WSSs and APs give preferential treatment to high-priority traffic such as voice and video.

(To override the prioritization for specific traffic, use access controls lists [ACLs] to set the Class of Service [CoS] for the packets. See [Chapter , “Security ACL Commands,” on page 449.](#))

This chapter presents QoS commands alphabetically. Use the following table to locate commands in this chapter based on their use.

QoS Settings	show qos on page 95
	show qos dscp-table on page 96
	set qos cos-to-dscp-map on page 94
	set qos dscp-to-cos-map on page 95
	clear qos on page 93

clear qos

Resets the switch’s mapping of Differentiated Services Code Point (DSCP) values to internal QoS values.

The switch’s internal QoS map ensures that prioritized traffic remains prioritized while transiting through the WSS. A WSS uses the QoS map to do the following:

- Classify inbound packets by mapping their DSCP values to one of eight internal QoS values
- Classify outbound packets by marking their DSCP values based on the switch’s internal QoS values

Syntax **clear qos**
[cos-to-dscp-map [from-qos] | dscp-to-cos-map [from-dscp]]

cos-to-dscp-map [from-qos] Resets the mapping between the specified internal QoS value and the DSCP values with which WSS Software marks outbound packets.
 QoS values are from 0 to 7.

dscp-to-cos-map [from-dscp] Resets the mapping between the specified range of DSCP values and internal QoS value with which WSS Software classifies inbound packets.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage To reset all mappings to their default values, use the **clear qos** command without the optional parameters.

Examples The following command resets all QoS mappings:

WSS# clear qos

success: change accepted.

The following command resets the mapping used to classify packets with DSCP value 44:

WSS# clear qos dscp-to-qos-map 44

success: change accepted.

set qos cos-to-dscp-map

Changes the value to which WSS Software maps an internal QoS value when marking outbound packets.

Syntax `set qos cos-to-dscp-map level dscp dscp-value`

level Internal CoS value. You can specify a number from 0 to 7.

dscp dscp-value DSCP value. You can specify the value as a decimal number. Valid values are 0 to 63.

Defaults The defaults are listed by the `show qos` command.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command maps internal CoS value 5 to DSCP value 50:

WSS# set qos cos-to-dscp-map 5 dscp 50

warning: cos 5 is marked with dscp 50 which will be classified as cos 6

If the change results in a change to CoS, WSS Software displays a warning message indicating the change. In this example, packets that receive CoS 5 upon ingress will be marked with a DSCP value equivalent to CoS 6 upon egress.

See Also

- [set qos dscp-to-cos-map on page 95](#)
- [show qos on page 95](#)

set qos dscp-to-cos-map

Changes the internal QoS value to which WSS Software maps a packet's DSCP value when classifying inbound packets.

Syntax `set qos dscp-to-cos-map dscp-range cos level`

<i>dscp-range</i>	DSCP range. You can specify the values as decimal numbers. Valid decimal values are 0 to 63. To specify a range, use the following format: 40-56. Specify the lower number first.
<i>cos level</i>	Internal QoS value. You can specify a number from 0 to 7.

Defaults The defaults are listed by the `show qos` command.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command maps DSCP values 40-56 to internal CoS value 6:

```
WSS# set qos dscp-to-cos-map 40-56 cos 6
warning: cos 5 is marked with dscp 63 which will be classified as cos 7
warning: cos 7 is marked with dscp 56 which will be classified as cos 6
```

As shown in this example, if the change results in a change to CoS, WSS Software displays a warning message indicating the change.

See Also

- [set qos cos-to-dscp-map on page 94](#)
- [show qos on page 95](#)

show qos

Displays the switch's QoS settings.

Syntax `show qos [default]`

default	Displays the default mappings.
----------------	--------------------------------

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command displays the default QoS settings:

```
WSS# show qos default
```

Ingress QoS Classification Map (dscp-to-cos)

Ingress DSCP	CoS Level									
00-09	0	0	0	0	0	0	0	0	1	1
10-19	1	1	1	1	1	1	2	2	2	2
20-29	2	2	2	2	3	3	3	3	3	3
30-39	3	3	4	4	4	4	4	4	4	4
40-49	5	5	5	5	5	5	5	5	6	6
50-59	6	6	6	6	6	6	7	7	7	7
60-63	7	7	7	7						

Egress QoS Marking Map (cos-to-dscp)

CoS Level	0	1	2	3	4	5	6	7
Egress DSCP	0	8	16	24	32	40	48	56
Egress ToS byte	0x00	0x20	0x40	0x60	0x80	0xA0	0xC0	0xE0

See Also [show qos dscp-table on page 96](#)

show qos dscp-table

Displays a table that maps Differentiated Services Code Point (DSCP) values to their equivalent combinations of IP precedence values and IP ToS values.

Syntax `show qos dscp-table`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0 as the `show security acl dscp` command and renamed in WSS Software Version 4.1.

Examples The following command displays the table:

WSS# `show qos dscp-table`

DSCP	TOS	precedence	tos
dec hex	dec hex		
0 0x00	0 0x00	0	0
1 0x01	4 0x04	0	2
2 0x02	8 0x08	0	4
...			
63 0x3f	252 0xfc	7	14

See Also [show qos on page 95](#)

IP Services Commands

Use IP services commands to configure and manage IP interfaces, management services, the Domain Name Service (DNS), Network Time Protocol (NTP), and aliases, and to ping a host or trace a route. This chapter presents IP services commands alphabetically. Use the following table to locate commands in this chapter based on their use.

IP Interface	set interface on page 109
	set interface dhcp-client on page 110
	set interface status on page 112
	show interface on page 149
	show dhcp-client on page 145
System IP Address	clear interface on page 99
	set system ip-address on page 141
IP Route	clear system ip-address on page 106
	set ip route on page 116
	show ip route on page 153
SSH Management	clear ip route on page 101
	set ip ssh server on page 119
Telnet Management	set ip ssh on page 118
	set ip telnet on page 120
	set ip telnet server on page 120
HTTPS Management	show ip telnet on page 155
	clear ip telnet on page 102
	set ip https server on page 116
DNS	show ip https on page 152
	set ip dns on page 113
	set ip dns domain on page 114
	set ip dns server on page 115
	show ip dns on page 151
IP Alias	clear ip dns domain on page 100
	clear ip dns server on page 101
	set ip alias on page 113
	show ip alias on page 150
	clear ip alias on page 100

Time and Date	set timedate on page 142 set timezone on page 143 set summertime on page 140 show timedate on page 161 show timezone on page 161 show summertime on page 160 clear timezone on page 106 clear summertime on page 105
NTP	set ntp on page 121 set ntp server on page 122 set ntp update-interval on page 122 show ntp on page 156 clear ntp server on page 102 clear ntp update-interval on page 103
ARP	set arp on page 108 set arp agingtime on page 109 show arp on page 144
SNMP	set snmp protocol on page 135 set snmp security on page 136 set snmp community on page 123 set snmp usm on page 136 set snmp notify profile on page 125 set snmp notify target on page 131 set ip snmp server on page 118 show snmp status on page 159 show snmp community on page 158 show snmp usm on page 160 show snmp notify profile on page 158 show snmp notify target on page 159 show snmp counters on page 158

Ping	clear snmp community on page 103
Telnet client	clear snmp usm on page 105
Traceroute	clear snmp notify profile on page 104
DHCP server	clear snmp notify target on page 104
	ping on page 107
	telnet on page 162
	traceroute on page 163
	set interface dhcp-server on page 111
	show dhcp-server on page 147

clear interface

Removes an IP interface.

Syntax `clear interface vlan-id ip`

vlan-id VLAN name or number.

Defaults None.

Access Enabled.

Usage If the interface you want to remove is configured as the system IP address, removing the address can interfere with system tasks that use the system IP address, including the following:

- Mobility domain operations
- Topology reporting for dual-homed APs
- Default source IP address used in unsolicited communications such as AAA accounting reports and SNMP traps

Examples The following command removes the IP interface configured on VLAN *mauve*:

```
WSS# clear interface mauve ip
success: cleared ip on vlan mauve
```

See Also

- **set interface on page 109**
- **set interface status on page 112**
- **show interface on page 149**

clear ip alias

Removes an alias, which is a string that represents an IP address.

Syntax `clear ip alias name`

name Alias name.

Defaults None.

Access Enabled.

Examples The following command removes the alias *server1*:

WSS# clear ip alias server1
success: change accepted.

See Also

- [set ip alias on page 113](#)
- [show ip alias on page 150](#)

clear ip dns domain

Removes the default DNS domain name.

Syntax `clear ip dns domain`

Defaults None.

Access Enabled.

Examples The following command removes the default DNS domain name from a WSS:

WSS# clear ip dns domain
Default DNS domain name cleared.

See Also

- [clear ip dns server on page 101](#)
- [set ip dns on page 113](#)
- [set ip dns domain on page 114](#)
- [set ip dns server on page 115](#)
- [show ip dns on page 151](#)

clear ip dns server

Removes a DNS server from a WSS configuration.

Syntax `clear ip dns server ip-addr`

ip-addr IP address of a DNS server.

Defaults None.

Access Enabled.

Examples The following command removes DNS server 10.10.10.69 from a WSS's configuration:

```
WSS# clear ip dns server 10.10.10.69
success: change accepted.
```

See Also

- [clear ip dns domain on page 100](#)
- [set ip dns on page 113](#)
- [set ip dns domain on page 114](#)
- [set ip dns server on page 115](#)
- [show ip dns on page 151](#)

clear ip route

Removes a route from the IP route table.

Syntax `clear ip route { default | ip-addr mask | ip-addr/mask-length } default-router`

default Default route.

Note: **default** is an alias for IP address 0.0.0.0/0.

ip-addr mask IP address and subnet mask for the route destination, in dotted decimal notation (for example, 10.10.10.10 255.255.255.0).

ip-addr/mask-length IP address and subnet mask length in CIDR format (for example, 10.10.10.10/24).

default-router IP address, DNS hostname, or alias of the next-hop router.

Defaults None.

Access Enabled.

Examples The following command removes the route to destination 10.10.10.68/24 through router 10.10.10.1:

```
WSS# clear ip route 10.10.10.68/24 10.10.10.1
success: change accepted.
```

See Also

- [set ip route on page 116](#)
- [show ip route on page 153](#)

clear ip telnet

Resets the Telnet server's TCP port number to its default value. A WSS listens for Telnet management traffic on the Telnet server port.

Syntax `clear ip telnet`

Defaults The default Telnet port number is 23.

Access Enabled.

Examples The following command resets the TCP port number for Telnet management traffic to its default:

```
WSS# clear ip telnet
success: change accepted.
```

See Also

- [set ip https server on page 116](#)
- [set ip telnet on page 120](#)
- [set ip telnet server on page 120](#)
- [show ip https on page 152](#)
- [show ip telnet on page 155](#)

clear ntp server

Removes an NTP server from a WSS configuration.

Syntax `clear ntp server {ip-addr | all}`

ip-addr IP address of the server to remove, in dotted decimal notation.

all Removes all NTP servers from the configuration.

Defaults None.

Access Enabled.

Examples The following command removes NTP server 192.168.40.240 from a WSS configuration:

```
WSS# clear ntp server 192.168.40.240
success: change accepted.
```

See Also

- [clear ntp update-interval on page 103](#)

- [set ntp on page 121](#)
- [set ntp server on page 122](#)
- [set ntp update-interval on page 122](#)
- [show ntp on page 156](#)

clear ntp update-interval

Resets the NTP update interval to the default value.

Syntax `clear ntp update-interval`

Defaults The default NTP update interval is 64 seconds.

Access Enabled.

Examples To reset the NTP interval to the default value, type the following command:

```
WSS# clear ntp update-interval
success: change accepted.
```

See Also

- [clear ntp server on page 102](#)
- [set ntp on page 121](#)
- [set ntp server on page 122](#)
- [set ntp update-interval on page 122](#)
- [show ntp on page 156](#)

clear snmp community

Clears an SNMP community string.

Syntax `clear snmp community name comm-string`

comm-string Name of the SNMP community you want to clear.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command clears community string *setswitch2*:

```
WSS# clear snmp community name setswitch2
success: change accepted.
```

See Also

- **set snmp community on page 123**
- **show snmp community on page 158**

clear snmp notify profile

Clears an SNMP notification profile.

Syntax `clear snmp notify profile profile-name`

profile-name Name of the notification profile you are clearing.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command clears notification profile *snmpprof_rfdetect*:

```
WSS# clear snmp notify profile snmpprof_rfdetect
success: change accepted.
```

See Also

- **set snmp notify profile on page 125**
- **show snmp notify profile on page 158**

clear snmp notify target

Clears an SNMP notification target.

Syntax `clear snmp notify target target-num`

target-num ID of the target.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command clears notification target 3:

```
WSS# clear snmp notify target 3
success: change accepted.
```

See Also

- [set snmp notify target on page 131](#)
- [show snmp notify target on page 159](#)

clear snmp usm

Clears an SNMPv3 user.

Syntax `clear snmp usm usm-username`

usm-username Name of the SNMPv3 user you want to clear.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command clears SNMPv3 user *snmpmgr1*:

WSS# clear snmp usm snmpmgr1

success: change accepted.

See Also

- [set snmp usm on page 136](#)
- [show snmp usm on page 160](#)

clear summertime

Clears the summertime setting from a WSS.

Syntax `clear summertime`

Defaults None.

Access Enabled.

Examples To clear the summertime setting from a WSS, type the following command:

WSS# clear summertime

success: change accepted.

See Also

- [clear timezone on page 106](#)
- [set summertime on page 140](#)
- [set timedate on page 142](#)
- [set timezone on page 143](#)
- [show summertime on page 160](#)

- **show timedate on page 161**
- **show timezone on page 161**

clear system ip-address

Clears the system IP address.



Caution! Clearing the system IP address disrupts the system tasks that use the address.

Syntax `clear system ip-address`

Defaults None.

Access Enabled.

Usage Clearing the system IP address can interfere with system tasks that use the system IP address, including the following:

- Mobility Domain operations
- Topology reporting for dual-homed APs
- Default source IP address used in unsolicited communications such as AAA accounting reports and SNMP traps

Examples To clear the system IP address, type the following command:

```
WSS# clear system ip-address
success: change accepted.
```

See Also

- **set system ip-address on page 141**
- **show system on page 68**

clear timezone

Clears the time offset for the WSS's real-time clock from Coordinated Universal Time (UTC). UTC is also know as Greenwich Mean Time (GMT).

Syntax `clear timezone`

Defaults None.

Access Enabled.

Examples To return the WSS's real-time clock to UTC, type the following command:

```
WSS# clear timezone
success: change accepted.
```

See Also

- **clear summertime on page 105**
- **set summertime on page 140**
- **set timedate on page 142**
- **set timezone on page 143**
- **show summertime on page 160**
- **show timedate on page 161**
- **show timezone on page 161**

ping

Tests IP connectivity between a WSS and another device. WSS Software sends an Internet Control Message Protocol (ICMP) echo packet to the specified device and listens for a reply packet.

Syntax `ping host [count num-packets] [dnf] [flood] [interval time] [size size] [source-ip ip-addr | vlan-name]`

<i>host</i>	IP address, MAC address, hostname, alias, or user to ping.
count <i>num-packets</i>	Number of ping packets to send. You can specify from 0 through 2,147,483,647. If you enter 0, WSS Software pings continuously until you interrupt the command.
dnf	Enables the Do Not Fragment bit in the ping packet to prevent the packet from being fragmented.
flood	Sends new ping packets as quickly as replies are received, or 100 times per second, whichever is greater. Note: Use the flood option sparingly. This option creates a lot of traffic and can affect other traffic on the network.
interval <i>time</i>	Time interval between ping packets, in milliseconds. You can specify from 100 through 10,000.
size <i>size</i>	Packet size, in bytes. You can specify from 56 through 65,507. Note: Because the switch adds header information, the ICMP packet size is 8 bytes larger than the size you specify.
source-ip <i>ip-addr</i>	IP address, in dotted decimal notation, to use as the source IP address in the ping packets.
source-ip <i>vlan-name</i>	VLAN name to use as the ping source. WSS Software uses the IP address configured on the VLAN as the source IP address in the ping packets.

Defaults

- **count**—5.
- **dnf**—Disabled.

- **interval**—100 (one tenth of a second)
- **size**—56.

Access Enabled.

Usage To stop a **ping** command that is in progress, press Ctrl+C.

A WSS cannot ping itself. WSS Software does not support this.

Examples The following command pings a device that has IP address 10.1.1.1:

WSS# ping 10.1.1.1

```
PING 10.1.1.1 (10.1.1.1) from 10.9.4.34 : 56(84) bytes of data.
```

```
64 bytes from 10.1.1.1: icmp_seq=1 ttl=255 time=0.769 ms
```

```
64 bytes from 10.1.1.1: icmp_seq=2 ttl=255 time=0.628 ms
```

```
64 bytes from 10.1.1.1: icmp_seq=3 ttl=255 time=0.676 ms
```

```
64 bytes from 10.1.1.1: icmp_seq=4 ttl=255 time=0.619 ms
```

```
64 bytes from 10.1.1.1: icmp_seq=5 ttl=255 time=0.608 ms
```

```
--- 10.1.1.1 ping statistics ---
```

```
5 packets transmitted, 5 packets received, 0 errors, 0% packet loss
```

See Also [traceroute on page 163](#)

set arp

Adds an ARP entry to the ARP table.

Syntax **set arp** {**permanent** | **static** | **dynamic**} *ip-addr mac-addr*

permanent Adds a permanent entry. A permanent entry does not age out and remains in the database even after a reboot, reset, or power cycle.

static Adds a static entry. A static entry does not age out, but the entry does not remain in the database after a reboot, reset, or power cycle.

dynamic Adds a dynamic entry. A dynamic entry is automatically removed if the entry ages out, or after a reboot, reset, or power cycle.

ip-addr IP address of the entry, in dotted decimal notation.

mac-addr MAC address to map to the IP address. Use colons to separate the octets (for example, 00:11:22:aa:bb:cc).

Defaults None.

Access Enabled.

Examples The following command adds a static ARP entry that maps IP address 10.10.10.1 to MAC address 00:bb:cc:dd:ee:ff:

WSS# set arp static 10.10.10.1 00:bb:cc:dd:ee:ff

```
success: added arp 10.10.10.1 at 00:bb:cc:dd:ee:ff on VLAN 1
```


Defaults None.

Access Enabled.

Usage You can assign one IP interface to each VLAN.

If an interface is already configured on the VLAN you specify, this command replaces the interface. If you replace an interface that is in use as the system IP address, replacing the interface can interfere with system tasks that use the system IP address, including the following:

- Mobility domain operations
- Topology reporting for dual-homed APs
- Default source IP address used in unsolicited communications such as AAA accounting reports and SNMP traps

Examples The following command configures IP interface 10.10.10.10/24 on VLAN *default*:

```
WSS# set interface default ip 10.10.10.10/24
```

```
success: set ip address 10.10.10.10 netmask 255.255.255.0 on vlan default
```

The following command configures IP interface 10.10.20.10 255.255.255.0 on VLAN *mauve*:

```
WSS# set interface mauve ip 10.10.20.10 255.255.255.0
```

```
success: set ip address 10.10.20.10 netmask 255.255.255.0 on vlan mauve
```

See Also

- [clear interface on page 99](#)
- [set interface status on page 112](#)
- [show interface on page 149](#)

set interface dhcp-client

Configures the DHCP client on a VLAN, to allow the VLAN to obtain its IP interface from a DHCP server.

Syntax `set interface vlan-id ip dhcp-client {enable | disable}`

<i>vlan-id</i>	VLAN name or number.
enable	Enables the DHCP client on the VLAN.
disable	Disables the DHCP client on the VLAN.

Defaults The DHCP client is enabled by default on an unconfigured 2350 when the factory reset switch is pressed and held during power on.

The DHCP client is disabled by default on all other switch models, and is disabled on a 2350 if the switch is already configured or the factory reset switch is not pressed and held during power on.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage You can enable the DHCP client on one VLAN only. You can configure the DHCP client on more than one VLAN, but the client can be active on only one VLAN.

WSS Software also has a configurable DHCP server. (See **set interface dhcp-server** on page 111.) You can configure a DHCP client and DHCP server on the same VLAN, but only the client or the server can be enabled. The DHCP client and DHCP server cannot both be enabled on the same VLAN at the same time.

Examples The following command enables the DHCP client on VLAN *corpvlan*:

```
WSS# set interface corpvlan ip dhcp-client enable
success: change accepted.
```

See Also

- **clear interface** on page 99
- **show dhcp-client** on page 145
- **show interface** on page 149

set interface dhcp-server

Configures the WSS Software DHCP server.



Note. Use of the WSS Software DHCP server to allocate client addresses is intended for temporary, demonstration deployments and not for production networks. Nortel recommends that you do not use the WSS Software DHCP server to allocate client addresses in a production network.

Syntax `set interface vlan-id ip dhcp-server [enable | disable] [start ip-addr1 stop ip-addr2] [dns-domain domain-name] [primary-dns ip-addr [secondary-dns ip-addr]] [default-router ip-addr]`

<i>vlan-id</i>	VLAN name or number.
enable	Enables the DHCP server.
disable	Disables the DHCP server.
start <i>ip-addr1</i>	Specifies the beginning address of the address range (also called the address <i>pool</i>).
stop <i>ip-addr2</i>	Specifies the ending address of the address range.
dns-domain <i>domain-name</i>	Name of the DHCP client's default DNS domain.
primary-dns <i>ip-addr</i> [secondary-dns <i>ip-addr</i>]	IP addresses of the DHCP client's DNS servers.
default-router <i>ip-addr</i>	IP address of the DHCP client's default router.

Defaults The DHCP server is enabled by default on a new (unconfigured) 2350 or 2360, 2382 in order to provide an IP address to the host connected to the switch for access to the Web Quick Start. On all switch models, the DHCP server is enabled and cannot be disabled for directly connected APs.

The DHCP server is disabled by default for any other use.

Access Enabled.

History

Version 4.0 Command introduced

Version 5.0 New options added:

- **dns-domain**
- **primary-dns** and **secondary-dns**
- **default-router**

Usage By default, all addresses except the host address of the VLAN, the network broadcast address, and the subnet broadcast address are included in the range. If you specify the range, the start address must be lower than the stop address, and all addresses must be in the same subnet. The IP interface of the VLAN must be within the same subnet but is not required to be within the range.

Specification of the DNS domain name, DNS servers, and default router are optional. If you omit one or more of these options, the WSS Software DHCP server uses oath values configured elsewhere on the switch:

- DNS domain name—If this option is not set with the **set interface dhcp-server** command's **dns-domain** option, the WSS Software DHCP server uses the value set by the **set ip dns domain** command.
- DNS servers—If these options are not set with the **set interface dhcp-server** command's **primary-dns** and **secondary-dns** options, the WSS Software DHCP server uses the values set by the **set ip dns server** command.
- Default router—If this option is not set with the **set interface dhcp-server** command's **default-router** option, the WSS Software DHCP server can use the value set by the **set ip route** command. A default route configured by **set ip route** can be used if the route is in the DHCP client's subnet. Otherwise, the WSS Software DHCP server does not specify a router address.

Examples The following command enables the DHCP server on VLAN *red-vlan* to serve addresses from the 192.168.1.5 to 192.168.1.25 range:

```
WSS# set interface red-vlan ip dhcp-server enable start 192.168.1.5 stop 192.168.1.25
success: change accepted.
```

See Also

- [set ip dns domain on page 114](#)
- [set ip dns server on page 115](#)
- [show dhcp-server on page 147](#)

set interface status

Administratively disables or reenables an IP interface.

Syntax **set interface** *vlan-id* **status** {**up** | **down**}

vlan-id VLAN name or number.

up Enables the interface.

down Disables the interface.

Defaults IP interfaces are enabled by default.

Access Enabled.

Examples The following command disables the IP interface on VLAN *mauve*:

```
WSS# set interface mauve status down
success: set interface mauve to down
```

See Also

- **clear interface on page 99**
- **set interface on page 109**
- **show interface on page 149**

set ip alias

Configures an alias, which maps a name to an IP address. You can use aliases as shortcuts in CLI commands.

Syntax `set ip alias name ip-addr`

name String of up to 32 alphanumeric characters, with no spaces.

ip-addr IP address in dotted decimal notation.

Defaults None.

Access Enabled.

Examples The following command configures the alias *HR1* for IP address 192.168.1.2:

```
WSS# set ip alias HR1 192.168.1.2
success: change accepted.
```

See Also

- **clear ip alias on page 100**
- **show ip alias on page 150**

set ip dns

Enables or disables DNS on a WSS.

Syntax `set ip dns {enable | disable}`

enable Enables DNS.

disable Disables DNS.

Defaults DNS is disabled by default.

Access Enabled.

Examples The following command enables DNS on a WSS:

```
WSS# set ip dns enable
Start DNS Client
```

See Also

- [clear ip dns domain on page 100](#)
- [clear ip dns server on page 101](#)
- [set ip dns domain on page 114](#)
- [set ip dns server on page 115](#)
- [show ip dns on page 151](#)

set ip dns domain

Configures a default domain name for DNS queries. The WSS appends the default domain name to domain names or hostnames you enter in commands.

Syntax `set ip dns domain name`

name Domain name of between 1 and 64 alphanumeric characters with no spaces (for example, example.org).

Defaults None.

Access Enabled.

Usage To override the default domain name when entering a hostname in a CLI command, enter a period at the end of the hostname. For example, if the default domain name is *example.com*, enter **chris.** if the fully qualified hostname is *chris* and not *chris.example.com*.

Aliases take precedence over DNS. When you enter a hostname, WSS Software checks for an alias with that name first, before using DNS to resolve the name.

Examples The following command configures the default domain name *example.com*:

```
WSS# set ip dns domain example.com
Domain name changed
```

See Also

- [clear ip dns domain on page 100](#)
- [clear ip dns server on page 101](#)
- [set ip dns on page 113](#)
- [set ip dns server on page 115](#)
- [show ip dns on page 151](#)

set ip dns server

Specifies a DNS server to use for resolving hostnames you enter in CLI commands.

Syntax `set ip dns server ip-addr {primary | secondary}`

<i>ip-addr</i>	IP address of a DNS server, in dotted decimal or CIDR notation.
primary	Makes the server the primary server, which WSS Software always consults first for resolving DNS queries.
secondary	Makes the server a secondary server. WSS Software consults a secondary server only if the primary server does not reply.

Defaults None.

Access Enabled.

Usage You can configure a WSS to use one primary DNS server and up to five secondary DNS servers.

Examples The following commands configure a WSS to use a primary DNS server and two secondary DNS servers:

WSS# set ip dns server 10.10.10.50/24 primary

success: change accepted.

WSS# set ip dns server 10.10.20.69/24 secondary

success: change accepted.

WSS# set ip dns server 10.10.30.69/24 secondary

success: change accepted.

See Also

- [clear ip dns domain on page 100](#)
- [clear ip dns server on page 101](#)
- [set ip dns on page 113](#)
- [set ip dns domain on page 114](#)
- [show ip dns on page 151](#)

set ip https server

Enables the HTTPS server on a WSS. The HTTPS server is required for Web View access to the switch.



Caution! If you disable the HTTPS server, Web View access to the switch is disabled.

Syntax `set ip https server {enable | disable}`

enable Enables the HTTPS server.

disable Disables the HTTPS server.

Defaults The HTTPS server is disabled by default.

Access Enabled.

Examples The following command enables the HTTPS server on a WSS:

```
WSS# set ip https server enable
success: change accepted.
```

See Also

- [clear ip telnet on page 102](#)
- [set ip telnet on page 120](#)
- [set ip telnet server on page 120](#)
- [show ip https on page 152](#)
- [show ip telnet on page 155](#)

set ip route

Adds a static route to the IP route table.

Syntax `set ip route {default | ip-addr mask | ip-addr/mask-length} default-router metric`

default Default route. A WSS uses the default route if an explicit route is not available for the destination.

Note: **default** is an alias for IP address 0.0.0.0/0.

ip-addr mask IP address and subnet mask for the route destination, in dotted decimal notation (for example, 10.10.10.10 255.255.255.0).

ip-addr/mask-length IP address and subnet mask length in CIDR format (for example, 10.10.10.10/24).

<i>default-router</i>	IP address, DNS hostname, or alias of the next-hop router.
<i>metric</i>	Cost for using the route. You can specify a value from 0 through 2,147,483,647. Lower-cost routes are preferred over higher-cost routes.

Defaults None.

Access Enabled.

Usage WSS Software can use a static route only if a direct route in the route table resolves the static route. WSS Software adds routes with next-hop types Local and Direct when you add an IP interface to a VLAN, if the VLAN is up. If one of these added routes can resolve the static route, WSS Software can use the static route.

Before you add a static route, use the **show interface** command to verify that the switch has an IP interface in the same subnet as the route's next-hop router. If not, the VLAN:Interface field of the **show ip route** command output shows that the route is down.

You can configure a maximum of 4 routes per destination. This includes default routes, which have destination 0.0.0.0/0. Each route to a given destination must have a unique router address. When the route table contains multiple default or explicit routes to the same destination, WSS Software uses the route with the lowest cost. If two or more routes to the same destination have the lowest cost, WSS Software selects the first route in the route table.

When you add multiple routes to the same destination, WSS Software groups the routes and orders them from lowest cost at the top of the group to highest cost at the bottom of the group. If you add a new route that has the same destination and cost as a route already in the table, WSS Software places the new route at the top of the group of routes with the same cost.

Examples The following command adds a default route that uses default router 10.5.4.1 and gives the route a cost of 1:

```
WSS# set ip route default 10.5.4.1 1  
success: change accepted.
```

The following commands add two default routes, and configure WSS Software to always use the route through 10.2.4.69 when the WSS interface to that default router is up:

```
WSS# set ip route default 10.2.4.69 1  
success: change accepted.
```

```
WSS# set ip route default 10.2.4.17 2  
success: change accepted.
```

The following command adds an explicit route from a WSS to any host on the 192.168.4.x subnet through the local router 10.5.4.2, and gives the route a cost of 1:

```
WSS# set ip route 192.168.4.0 255.255.255.0 10.5.4.2 1  
success: change accepted.
```

The following command adds another explicit route, using CIDR notation to specify the subnet mask:

```
WSS# set ip route 192.168.5.0/24 10.5.5.2 1  
success: change accepted.
```

- [clear ip route on page 101](#)
- [show interface on page 149](#)
- [show ip route on page 153](#)

set ip snmp server

Enables or disables the SNMP service on the WSS.

Syntax `set ip snmp server {enable | disable}`

enable Enables the SNMP service.

disable Disables the SNMP service.

Defaults The SNMP service is disabled by default.

Access Enabled.

Examples The following command enables the SNMP server on a WSS:

```
WSS# set ip snmp server enable
success: change accepted.
```

See Also

- [clear snmp notify target on page 104](#)
- [set port trap on page 41](#)
- [set snmp community on page 123](#)
- [set snmp notify profile on page 125](#)

set ip ssh

Changes the TCP port number on which a WSS listens for Secure Shell (SSH) management traffic.



Caution! If you change the SSH port number from an SSH session, WSS Software immediately ends the session. To open a new management session, you must configure the SSH client to use the new TCP port number.

Syntax `set ip ssh port port-num`

port-num TCP port number.

Defaults The default SSH port number is 22.

Access Enabled.

Examples The following command changes the SSH port number on a WSS to 6000:

```
WSS# set ip ssh port 6000
success: change accepted.
```

See Also

- [set ip ssh server on page 119](#)
- [set ip ssh server on page 119](#)
- [set ip ssh server on page 119](#)

set ip ssh server

Disables or reenables the SSH server on a WSS.



Caution! If you disable the SSH server, SSH access to the WSS is also disabled.

Syntax `set ip ssh server {enable | disable}`

enable Enables the SSH server.

disable Disables the SSH server.

Defaults The SSH server is enabled by default.

Access Enabled.

Usage SSH requires an SSH authentication key. You can generate one or allow WSS Software to generate one. The first time an SSH client attempts to access the SSH server on a WSS, the switch automatically generates a 1024-byte SSH key. If you want to use a 2048-byte key instead, use the **crypto generate key ssh 2048** command to generate one.

The maximum number of SSH sessions supported on a WSS is eight. If Telnet is also enabled, the switch can have up to eight Telnet or SSH sessions, in any combination, and one Console session.

See Also

- [crypto generate key on page 472](#)
- [set ip ssh on page 118](#)
- [set ip ssh server on page 119](#)
- [set ip ssh server on page 119](#)

set ip telnet

Changes the TCP port number on which a WSS listens for Telnet management traffic.



Caution! If you change the Telnet port number from a Telnet session, WSS Software immediately ends the session. To open a new management session, you must Telnet to the switch with the new Telnet port number.

Syntax `set ip telnet port-num`

port-num TCP port number.

Defaults The default Telnet port number is 23.

Access Enabled.

Examples The following command changes the Telnet port number on a WSS to 5000:

```
WSS# set ip telnet 5000
success: change accepted.
```

See Also

- [clear ip telnet on page 102](#)
- [set ip https server on page 116](#)
- [set ip telnet server on page 120](#)
- [show ip https on page 152](#)
- [show ip telnet on page 155](#)

set ip telnet server

Enables the Telnet server on a WSS.



Caution! If you disable the Telnet server, Telnet access to the WSS is also disabled.

Syntax `set ip telnet server {enable | disable}`

enable Enables the Telnet server.

disable Disables the Telnet server.

Defaults The Telnet server is disabled by default.

Access Enabled.

Usage The maximum number of Telnet sessions supported on a WSS is eight. If SSH is also enabled, the switch can have up to eight Telnet or SSH sessions, in any combination, and one console session.

Examples The following command enables the Telnet server on a WSS:

```
WSS# set ip telnet server enable
success: change accepted.
```

See Also

- **clear ip telnet on page 102**
- **set ip https server on page 116**
- **set ip telnet on page 120**
- **show ip https on page 152**
- **show ip telnet on page 155**

set ntp

Enables or disables the NTP client on a WSS.

Syntax `set ntp {enable | disable}`

enable Enables the NTP client.

disable Disables the NTP client.

Defaults The NTP client is disabled by default.

Access Enabled.

Usage If NTP is configured on a system whose current time differs from the NTP server time by more than 10 minutes, convergence of the WSS time can take many NTP update intervals. Nortel recommends that you set the time manually to the NTP server time before enabling NTP to avoid a significant delay in convergence.

Examples The following command enables the NTP client:

```
WSS# set ntp enable
success: NTP Client enabled
```

See Also

- **clear ntp server on page 102**
- **clear ntp update-interval on page 103**
- **set ntp server on page 122**
- **set ntp update-interval on page 122**
- **show ntp on page 156**

set ntp server

Configures a WSS to use an NTP server.

Syntax `set ntp server ip-addr`

ip-addr IP address of the NTP server, in dotted decimal notation.

Defaults None.

Access Enabled.

Usage You can configure up to three NTP servers. WSS Software queries all the servers and selects the best response based on the method described in RFC 1305, *Network Time Protocol (Version 3) Specification, Implementation and Analysis*.

To use NTP, you also must enable the NTP client with the **set ntp** command.

Examples The following command configures a WSS to use NTP server 192.168.1.5:

```
WSS# set ntp server 192.168.1.5
```

See Also

- **clear ntp server on page 102**
- **clear ntp update-interval on page 103**
- **set ntp on page 121**
- **set ntp update-interval on page 122**
- **show ntp on page 156**

set ntp update-interval

Changes how often WSS Software sends queries to the NTP servers for updates.

Syntax `set ntp update-interval seconds`

seconds Number of seconds between queries. You can specify from 16 through 1024 seconds.

Defaults The default NTP update interval is 64 seconds.

Access Enabled.

Examples The following command changes the NTP update interval to 128 seconds:

```
WSS# set ntp update-interval 128
success: change accepted.
```

See Also

- **clear ntp server** on page 102
- **clear ntp update-interval** on page 103
- **set ntp** on page 121
- **set ntp server** on page 122
- **show ntp** on page 156

set snmp community

Configures a community string for SNMPv1 or SNMPv2c.



Note. For SNMPv3, use the **set snmp usm** command to configure an SNMPv3 user. SNMPv3 does not use community strings.

Syntax **set snmp community name** *comm-string*
access { **read-only** | **read-notify** | **notify-only** | **read-write** | **notify-read-write** }

<i>comm-string</i>	Name of the SNMP community. Specify between 1 and 32 alphanumeric characters, with no spaces.
read-only	Allows an SNMP management application using the string to get (read) object values on the switch but not to set (write) them.
read-notify	Allows an SNMP management application using the string to get object values on the switch but not to set them. The switch can use the string to send notifications.
notify-only	Allows the switch to use the string to send notifications.
read-write	Allows an SNMP management application using the string to get and set object values on the switch.
notify-read-write	Allows an SNMP management application using the string to get and set object values on the switch. The switch also can use the string to send notifications.

Defaults None.

Access Enabled.

History

Version 4.0 Default strings removed. There are no default strings in WSS Software Version 4.0.

New access types added for SNMPv3:

- **read-notify**
- **notify-only**
- **notify-read-write**

Usage SNMP community strings are passed as clear text in SNMPv1 and SNMPv2c. Nortel recommends that you use strings that cannot easily be guessed by unauthorized users. For example, do not use the well-known strings *public* and *private*.

If you are using SNMPv3, you can configure SNMPv3 users to use authentication and to encrypt SNMP data.

Examples The following command configures the read-write community *good_community*:

```
WSS# set snmp community read-write good_community
success: change accepted.
```

The following command configures community string *switchmgr1* with access level **notify-read-write**:

```
WSS# set snmp community name switchmgr1 notify-read-write
success: change accepted.
```

See Also

- **clear snmp community on page 103**
- **set ip snmp server on page 118**
- **set snmp notify target on page 131**
- **set snmp notify profile on page 125**
- **set snmp protocol on page 135**
- **set snmp security on page 136**
- **set snmp usm on page 136**
- **show snmp community on page 158**

set snmp notify profile

Configures an SNMP notification profile. A *notification profile* is a named list of all the notification types that can be generated by a switch, and for each notification type, the action to take (drop or send) when an event occurs.

You can configure up to ten notification profiles.

Syntax `set snmp notify profile { default | profile-name }
{ drop | send } { notification-type | all }`

default | *profile-name* Name of the notification profile you are creating or modifying. The *profile-name* can be up to 32 alphanumeric characters long, with no spaces.

To modify the default notification profile, specify **default**.

drop | **send** Specifies the action that the SNMP engine takes with regard to the notifications you specify with *notification-type* or **all**.

notification-type

Name of the notification type:

- **APBootTraps**—Generated when an AP boots.
- **ApNonOperStatusTraps**—Generated to indicate an AP radio is nonoperational.
- **ApOperRadioStatusTraps**—Generated when the status of an AP radio changes.
- **APTimeoutTraps**—Generated when an AP fails to respond to the WSS.
- **AuthenTraps**—Generated when the WSS’s SNMP engine receives a bad community string.
- **AutoTuneRadioChannelChangeTraps**—Generated when the RF Auto-Tuning feature changes the channel on a radio.
- **AutoTuneRadioPowerChangeTraps**—Generated when the RF Auto-Tuning feature changes the power setting on a radio.
- **ClientAssociationFailureTraps**—Generated when a client’s attempt to associate with a radio fails.
- **ClientAuthorizationSuccessTraps**—Generated when a client is successfully authorized.
- **ClientAuthenticationFailureTraps**—Generated when authentication fails for a client.
- **ClientAuthorizationFailureTraps**—Generated when authorization fails for a client.
- **ClientClearedTraps**—Generated when a client’s session is cleared.
- **ClientDeAssociationTraps**—Generated when a client is dissociated from a radio.
- **ClientDot1xFailureTraps**—Generated when a client experiences an 802.1X failure.
- **ClientRoamingTraps**—Generated when a client roams.
- **CounterMeasureStartTraps**—Generated when WSS Software begins countermeasures against a rogue access point.

notification-type
(cont.)

- **CounterMeasureStopTraps**—Generated when WSS Software stops countermeasures against a rogue access point.
- **DAPConnectWarningTraps**—Generated when a Distributed AP whose fingerprint has not been configured in WSS Software establishes a management session with the switch.
- **DeviceFailTraps**—Generated when an event with an Alert severity occurs.
- **DeviceOkayTraps**—Generated when a device returns to its normal state.
- **LinkDownTraps**—Generated when the link is lost on a port.
- **LinkUpTraps**—Generated when the link is detected on a port.
- **MichaelMICFailureTraps**—Generated when two Michael message integrity code (MIC) failures occur within 60 seconds, triggering Wi-Fi Protected Access (WPA) countermeasures.
- **MobilityDomainJoinTraps**—Generated when the WSS is initially able to contact a mobility domain seed member, or can contact the seed member after a timeout.
- **MobilityDomainTimeoutTraps**—Generated when a timeout occurs after a WSS has unsuccessfully tried to communicate with a seed member.
- **PoEFailTraps**—Generated when a serious PoE problem, such as a short circuit, occurs.
- **RFDetectAdhocUserTraps**—Generated when WSS Software detects an ad-hoc user.
- **RFDetectRogueAPTraps**—Generated when WSS Software detects a rogue access point.
- **RFDetectRogueDisappearTraps**—Generated when a rogue access point is no longer being detected.
- **RFDetectClientViaRogueWiredAPTraps**—Generated when WSS Software detects, on the wired part of the network, the MAC address of a wireless client associated with a third-party AP.

notification-type
(cont.)

- **RFDetectDoSPortTraps**—Generated when WSS Software detects an associate request flood, reassociate request flood, or disassociate request flood.
- **RFDetectDoSTraps**—Generated when WSS Software detects a DoS attack other than an associate request flood, reassociate request flood, or disassociate request flood.
- **RFDetectInterferingRogueAPTraps**—Generated when an interfering device is detected.
- **RFDetectInterferingRogueDisappearTraps**—Generated when an interfering device is no longer detected.
- **RFDetectSpoofedMacAPTraps**—Generated when WSS Software detects a wireless packet with the source MAC address of a Nortel AP, but without the spoofed AP's signature (fingerprint).
- **RFDetectSpoofedSsidAPTraps**—Generated when WSS Software detects beacon frames for a valid SSID, but sent by a rogue AP.
- **RFDetectUnauthorizedAPTraps**—Generated when WSS Software detects the MAC address of an AP that is on the attack list.
- **RFDetectUnauthorizedOuiTraps**—Generated when a wireless device that is not on the list of permitted vendors is detected.
- **RFDetectUnauthorizedSsidTraps**—Generated when an SSID that is not on the permitted SSID list is detected.

all Sends or drops all notifications.

Defaults A default notification profile (named *default*) is already configured in WSS Software. All notifications in the default profile are dropped by default.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command changes the action in the default notification profile from **drop** to **send** for all notification types:

WSS# set snmp notify profile default send all
success: change accepted.

The following commands create notification profile *snmpprof_rfdetect*, and change the action to **send** for all RF detection notification types:

WSS# set snmp notify profile snmpprof_rfdetect send RFDetectAdhocUserTraps
success: change accepted.

**WSS# set snmp notify profile snmpprof_rfdetect send
RFDetectClientViaRogueWiredAPTraps**
success: change accepted.

WSS# set snmp notify profile snmpprof_rfdetect send RFDetectDoSTraps
success: change accepted.

WSS# set snmp notify profile snmpprof_rfdetect send RFDetectAdhocUserTraps
success: change accepted.

WSS# set snmp notify profile snmpprof_rfdetect send RFDetectInterferingRogueAPTraps
success: change accepted.

**WSS# set snmp notify profile snmpprof_rfdetect send
RFDetectInterferingRogueDisappearTraps**
success: change accepted.

WSS# set snmp notify profile snmpprof_rfdetect send RFDetectRogueAPTraps
success: change accepted.

WSS# set snmp notify profile snmpprof_rfdetect send RFDetectRogueDisappearTraps
success: change accepted.

WSS# set snmp notify profile snmpprof_rfdetect send RFDetectSpoofedMacAPTraps
success: change accepted.

WSS# set snmp notify profile snmpprof_rfdetect send RFDetectSpoofedSsidAPTraps
success: change accepted.

WSS# set snmp notify profile snmpprof_rfdetect send RFDetectUnauthorizedAPTraps
success: change accepted.

WSS# set snmp notify profile snmpprof_rfdetect send RFDetectUnauthorizedOuiTraps
success: change accepted.

WSS# set snmp notify profile snmpprof_rfdetect send RFDetectUnauthorizedSsidTraps
success: change accepted.

See Also

- [clear snmp notify profile on page 104](#)
- [set ip snmp server on page 118](#)
- [set snmp community on page 123](#)
- [set snmp notify target on page 131](#)
- [set snmp protocol on page 135](#)
- [set snmp security on page 136](#)
- [set snmp usm on page 136](#)

- **show snmp notify profile on page 158**

set snmp notify target

Configures a notification target for notifications from SNMP.

A notification target is a remote device to which WSS Software sends SNMP notifications. You can configure the WSS Software SNMP engine to send confirmed notifications (informs) or unconfirmed notifications (traps). Some of the command options differ depending on the SNMP version and the type of notification you specify. You can configure up to 10 notification targets.

SNMPv3 with Informs

To configure a notification target for informs from SNMPv3, use the following command:

```
Syntax set snmp notify target target-num ip-addr[:udp-port-number]
usm inform user username
snmp-engine-id { ip | hex hex-string }
[profile profile-name]
[security { unsecured | authenticated | encrypted } ]
[retries num]
[timeout num]
```

<i>target-num</i>	ID for the target. This ID is local to the WSS and does not need to correspond to a value on the target itself. You can specify a number from 1 to 10.
<i>ip-addr[:udp-port-number]</i>	IP address of the server. You also can specify the UDP port number to send notifications to.
<i>username</i>	USM username. This option is applicable only when the SNMP version is usm . If the user will send informs rather than traps, you also must specify the snmp-engine-id of the target.
snmp-engine-id { ip hex <i>hex-string</i> }	SNMP engine ID of the target. Specify ip if the target's SNMP engine ID is based on its IP address. If the target's SNMP engine ID is a hexadecimal value, use hex <i>hex-string</i> to specify the value.
profile <i>profile-name</i>	Notification profile this SNMP user will use to specify the notification types to send or drop.
security { unsecured authenticated encrypted }	Specifies the security level, and is applicable only when the SNMP version is usm : <ul style="list-style-type: none"> • unsecured—Message exchanges are not authenticated, nor are they encrypted. This is the default. • authenticated—Message exchanges are authenticated, but are not encrypted. • encrypted—Message exchanges are authenticated and encrypted.

retries <i>num</i>	Specifies the number of times the WSS Software SNMP engine will resend a notification that has not been acknowledged by the target. You can specify from 0 to 3 retries.
timeout <i>num</i>	Specifies the number of seconds WSS Software waits for acknowledgement of a notification. You can specify from 1 to 5 seconds.

SNMPv3 with Traps

To configure a notification target for traps from SNMPv3, use the following command:

```
Syntax set snmp notify target target-num ip-addr[:udp-port-number]  
usm trap user username  
[profile profile-name]  
[security { unsecured | authenticated | encrypted }]
```

<i>target-num</i>	ID for the target. This ID is local to the WSS and does not need to correspond to a value on the target itself. You can specify a number from 1 to 10.
<i>ip-addr[:udp-port-number]</i>	IP address of the server. You also can specify the UDP port number to send notifications to.
<i>username</i>	USM username. This option is applicable only when the SNMP version is usm .
profile <i>profile-name</i>	Notification profile this SNMP user will use to specify the notification types to send or drop.
security { unsecured authenticated encrypted }	Specifies the security level, and is applicable only when the SNMP version is usm : <ul style="list-style-type: none">• unsecured—Message exchanges are not authenticated, nor are they encrypted. This is the default.• authenticated—Message exchanges are authenticated, but are not encrypted.• encrypted—Message exchanges are authenticated and encrypted.

SNMPv2c with Informs

To configure a notification target for informs from SNMPv2c, use the following command:

```
Syntax set snmp notify target target-num ip-addr[:udp-port-number]
v2c community-string inform
[profile profile-name]
[retries num]
[timeout num]
```

<i>target-num</i>	ID for the target. This ID is local to the WSS and does not need to correspond to a value on the target itself. You can specify a number from 1 to 10.
<i>ip-addr[:udp-port-number]</i>	IP address of the server. You also can specify the UDP port number to send notifications to.
<i>community-string</i>	Community string.
profile <i>profile-name</i>	Notification profile this SNMP user will use to specify the notification types to send or drop.
retries <i>num</i>	Specifies the number of times the WSS Software SNMP engine will resend a notification that has not been acknowledged by the target. You can specify from 0 to 3 retries.
timeout <i>num</i>	Specifies the number of seconds WSS Software waits for acknowledgement of a notification. You can specify from 1 to 5 seconds.

SNMPv2c with Traps

To configure a notification target for traps from SNMPv2c, use the following command:

```
Syntax set snmp notify target target-num ip-addr[:udp-port-number]
v2c community-string trap
[profile profile-name]
```

<i>target-num</i>	ID for the target. This ID is local to the WSS and does not need to correspond to a value on the target itself. You can specify a number from 1 to 10.
<i>ip-addr[:udp-port-number]</i>	IP address of the server. You also can specify the UDP port number to send notifications to.
<i>community-string</i>	Community string.
profile <i>profile-name</i>	Notification profile this SNMP user will use to specify the notification types to send or drop.

SNMPv1 with Traps

To configure a notification target for traps from SNMPv1, use the following command:

```
Syntax set snmp notify target target-num ip-addr[:udp-port-number]  
v1 community-string  
[profile profile-name]
```

<i>target-num</i>	ID for the target. This ID is local to the WSS and does not need to correspond to a value on the target itself. You can specify a number from 1 to 10.
<i>ip-addr[:udp-port-number]</i>	IP address of the server. You also can specify the UDP port number to send notifications to.
<i>community-string</i>	Community string.
profile <i>profile-name</i>	Notification profile this SNMP user will use to specify the notification types to send or drop.

Defaults The default UDP port number on the target is 162. The default minimum required security level is **unsecured**. The default number of retries is 0 and the default timeout is 2 seconds.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage The **inform** or **trap** option specifies whether the WSS Software SNMP engine expects the target to acknowledge notifications sent to the target by the WSS. Use **inform** if you want acknowledgements. Use **trap** if you do not want acknowledgements. The **inform** option is applicable to SNMP version **v2c** or **usm** only.

Examples The following command configures a notification target for acknowledged notifications:

```
WSS# set snmp notify target 1 10.10.40.9 usm inform user securesnmpmgr1 snmp-  
engine-id ip  
success: change accepted.
```

This command configures target 1 at IP address 10.10.40.9. The target's SNMP engine ID is based on its address. The WSS Software SNMP engine will send notifications based on the default profile, and will require the target to acknowledge receiving them.

The following command configures a notification target for unacknowledged notifications:

```
WSS# set snmp notify target 2 10.10.40.10 v1 trap  
success: change accepted.
```

See Also

- **clear snmp notify target on page 104**

- [set ip snmp server on page 118](#)
- [set snmp community on page 123](#)
- [set snmp notify profile on page 125](#)
- [set snmp protocol on page 135](#)
- [set snmp security on page 136](#)
- [set snmp usm on page 136](#)
- [show snmp notify target on page 159](#)

set snmp protocol

Enables an SNMP protocol. WSS Software supports SNMPv1, SNMPv2c, and SNMPv3.

Syntax `set snmp protocol { v1 | v2c | usm | all } { enable | disable }`

v1	SNMPv1
v2c	SNMPv2c
usm	SNMPv3 (with the user security model)
all	Enables all supported versions of SNMP.
enable	Enables the specified SNMP version(s).
disable	Disables the specified SNMP version(s).

Defaults All SNMP versions are disabled by default.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage SNMP requires the switch's system IP address to be set. SNMP will not work without the system IP address.

You also must enable the SNMP service using the **set ip snmp server** command.

Examples The following command enables all SNMP versions:

```
WSS# set snmp protocol all enable
success: change accepted.
```

See Also

- [set ip snmp server on page 118](#)
- [set snmp community on page 123](#)
- [set snmp notify target on page 131](#)
- [set snmp notify profile on page 125](#)
- [set snmp security on page 136](#)
- [set snmp usm on page 136](#)
- [show snmp status on page 159](#)

set snmp security

Sets the minimum level of security WSS Software requires for SNMP message exchanges.

Syntax `set snmp security`
{ **unsecured** | **authenticated** | **encrypted** | **auth-req-unsec-notify** }

unsecured	SNMP message exchanges are not secure. This is the only value supported for SNMPv1 and SNMPv2c.
authenticated	SNMP message exchanges are authenticated but are not encrypted.
encrypted	SNMP message exchanges are authenticated and encrypted.
auth-req-unsec-notify	SNMP message exchanges are authenticated but are not encrypted, and notifications are neither authenticated nor encrypted.

Defaults By default, WSS Software allows nonsecure (**unsecured**) SNMP message exchanges.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage SNMPv1 and SNMPv2c do not support authentication or encryption. If you plan to use SNMPv1 or SNMPv2c, leave the minimum level of SNMP security set to **unsecured**.

Examples The following command sets the minimum level of SNMP security allowed to authentication *and* encryption:

```
WSS# set snmp security encrypted
success: change accepted.
```

See Also

- [set ip snmp server on page 118](#)
- [set snmp community on page 123](#)
- [set snmp notify target on page 131](#)
- [set snmp notify profile on page 125](#)
- [set snmp protocol on page 135](#)
- [set snmp usm on page 136](#)
- [show snmp status on page 159](#)

set snmp usm

Creates a USM user for SNMPv3.



Note. This command does not apply to SNMPv1 or SNMPv2c. For these SNMP versions, use the **set snmp community** command to configure community strings.

```

Syntax set snmp usm usm-username
snmp-engine-id {ip ip-addr | local | hex hex-string}
access {read-only | read-notify | notify-only | read-write | notify-read-write}
auth-type {none | md5 | sha}
{auth-pass-phrase string | auth-key hex-string}
encrypt-type {none | des | 3des | aes}
{encrypt-pass-phrase string | encrypt-key hex-string}

```

usm-username

Name of the SNMPv3 user. Specify between 1 and 32 alphanumeric characters, with no spaces.

snmp-engine-id {ip *ip-addr* | local | hex *hex-string*}

Specifies a unique identifier for the SNMP engine.

To send informs, you must specify the engine ID of the inform receiver. To send traps and to allow get and set operations and so on, specify **local** as the engine ID.

- **hex** *hex-string*—ID is a hexadecimal string.
- **ip** *ip-addr*—ID is based on the IP address of the station running the management application. Enter the IP address of the station. WSS Software calculates the engine ID based on the address.
- **local**—Uses the value computed from the switch's system IP address.

access { **read-only** | **read-notify** | **notify-only** |
read-write | **notify-read-write** }

Specifies the access level of the user:

- **read-only**—An SNMP management application using the string can get (read) object values on the switch but cannot set (write) them.
- **read-notify**—An SNMP management application using the string can get object values on the switch but cannot set them. The switch can use the string to send notifications.
- **notify-only**—The switch can use the string to send notifications.
- **read-write**—An SNMP management application using the string can get and set object values on the switch.
- **notify-read-write**—An SNMP management application using the string can get and set object values on the switch. The switch can use the string to send notifications.

auth-type { **none** | **md5** | **sha** } { **auth-pass-phrase** *string* | **auth-key** *hex-string* }

Specifies the authentication type used to authenticate communications with the remote SNMP engine. You can specify one of the following:

- **none**—No authentication is used.
- **md5**—Message-digest algorithm 5 is used.
- **sha**—Secure Hashing Algorithm (SHA) is used.

If the authentication type is **md5** or **sha**, you can specify a passphrase or a hexadecimal key.

- To specify a passphrase, use the **auth-pass-phrase** *string* option. The string can be from 8 to 32 alphanumeric characters long, with no spaces.
- To specify a key, use the **auth-key** *hex-string* option.

encrypt-type { **none** | **des** | **3des** | **aes** } { **encrypt-pass-phrase** *string* | **encrypt-key** *hex-string* }

Specifies the encryption type used for SNMP traffic. You can specify one of the following:

- **none**—No encryption is used. This is the default.
- **des**—Data Encryption Standard (DES) encryption is used.
- **3des**—Triple DES encryption is used.
- **aes**—Advanced Encryption Standard (AES) encryption is used.

If the encryption type is **des**, **3des**, or **aes**, you can specify a passphrase or a hexadecimal key.

- To specify a passphrase, use the **encrypt-pass-phrase** *string* option. The string can be from 8 to 32 alphanumeric characters long, with no spaces.
- To specify a key, use the **encrypt-key** *hex-string* option.

Defaults No SNMPv3 users are configured by default. When you configure an SNMPv3 user, the default access is **read-only**, and the default authentication and encryption types are both **none**.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command creates USM user *snmpmgr1*, associated with the local SNMP engine ID. This user can send traps to notification receivers.

```
WSS# set snmp usm snmpmgr1 snmp-engine-id local
success: change accepted.
```

The following command creates USM user *securesnmpmgr1*, which uses SHA authentication and 3DES encryption with passphrases. This user can send informs to the notification receiver that has engine ID 192.168.40.2.

```
WSS# set snmp usm securesnmpmgr1 snmp-engine-id ip 192.168.40.2 auth-type sha
auth-pass-phrase myauthpassword encrypt-type 3des encrypt-pass-phrase
mycryptpassword
success: change accepted.
```

See Also

- **clear snmp usm** on page 105
- **set ip snmp server** on page 118
- **set snmp community** on page 123
- **set snmp notify target** on page 131
- **set snmp notify profile** on page 125
- **set snmp protocol** on page 135
- **set snmp security** on page 136
- **show snmp usm** on page 160

set summertime

Offsets the real-time clock of a WSS by +1 hour and returns it to standard time for daylight savings time or a similar summertime period that you set.

Syntax **set summertime** *summer-name* [**start** *week weekday month hour min* **end** *week weekday month hour min*]

<i>summer-name</i>	Name of up to 32 alphanumeric characters that describes the summertime offset. You can use a standard name or any name you like.
start	Start of the time change period.
<i>week</i>	Week of the month to start or end the time change. Valid values are first , second , third , fourth , or last .
<i>weekday</i>	Day of the week to start or end the time change. Valid values are sun , mon , tue , wed , thu , fri , and sat .
<i>month</i>	Month of the year to start or end the time change. Valid values are jan , feb , mar , apr , may , jun , jul , aug , sep , oct , nov , and dec .
<i>hour</i>	Hour to start or end the time change—a value between 0 and 23 on the 24-hour clock.

<i>min</i>	Minute to start or end the time change—a value between 0 and 59.
end	End of the time change period.

Defaults If you do not specify a start and end time, the system implements the time change starting at 2:00 a.m. on the first Sunday in April and ending at 2:00 a.m. on the last Sunday in October, according to the North American standard.

Access Enabled.

Usage You must first set the time zone with the **set timezone** command for the offset to work properly without the start and end values.

Configure summertime *before* you set the time and date. Otherwise, summertime's adjustment of the time will make the time incorrect, if the date is within the summertime period.

Examples To enable summertime and set the summertime time zone to *PDT* (Pacific Daylight Time), type the following command:

```
23x0# set summertime PDT
success: change accepted
```

See Also

- **clear summertime on page 105**
- **clear timezone on page 106**
- **set timedate on page 142**
- **set timezone on page 143**
- **show summertime on page 160**
- **show timedate on page 161**
- **show timezone on page 161**

set system ip-address

Configures the system IP address. The system IP address determines the interface or source IP address WSS Software uses for system tasks, including the following:

- Mobility domain operations
- Topology reporting for dual-homed APs
- Default source IP address used in unsolicited communications such as AAA accounting reports and SNMP traps

Syntax **set system ip-address** *ip-addr*

ip-addr IP address, in dotted decimal notation. The address must be configured on one of the WSS's VLANs.

Defaults None.

Access Enabled.

Usage You must use an address that is configured on one of the WSS's VLANs.

To display the system IP address, use the **show system** command.

Examples The following commands configure an IP interface on VLAN *taupe* and configure the interface to be the system IP address:

```
WSS# set interface taupe ip 10.10.20.20/24
```

```
success: set ip address 10.10.20.20 netmask 255.255.255.0 on vlan taupe
```

```
WSS# set system ip-address 10.10.20.20
```

```
success: change accepted.
```

See Also

- **clear system ip-address on page 106**
- **set interface on page 109**
- **show system on page 68**

set timedate

Sets the time of day and date on the WSS.

Syntax **set timedate** {**date** *mmm dd yyyy* [**time** *hh:mm:ss*]}

date *mmm dd yyyy*

System date:

- *mmm*—month.
- *dd*—day.
- *yyyy*—year.

time *hh:mm:ss*

System time, in hours, minutes, and seconds.

Defaults None.

Access Enabled.

Usage The day of week is automatically calculated from the day you set. The time displayed by the CLI after you type the command might be slightly later than the time you enter due to the interval between when you press Enter and when the CLI reads and displays the new time and date.

Configure summertime *before* you set the time and date. Otherwise, summertime's adjustment of the time will make the time incorrect, if the date is within the summertime period.

Examples The following command sets the date to March 13, 2003 and time to 11:11:12:

```
WSS# set timedate date feb 29 2004 time 23:58:00
```

```
Time now is: Sun Feb 29 2004, 23:58:02 PST
```

See Also

- **clear summertime on page 105**

- **clear timezone on page 106**
- **set summertime on page 140**
- **set timezone on page 143**
- **show summertime on page 160**
- **show timedate on page 161**
- **show timezone on page 161**

set timezone

Sets the number of hours, and optionally the number of minutes, that the WSS's real-time clock is offset from Coordinated Universal Time (UTC). These values are also used by Network Time Protocol (NTP), if it is enabled.

Syntax `set timezone zone-name [-hours [minutes]]`

<i>zone-name</i>	Time zone name of up to 32 alphabetic characters. You can use a standard name or any name you like.
-	Minus time to indicate hours (and minutes) to be subtracted from UTC. Otherwise, hours and minutes are added by default.
<i>hours</i>	Number of hours to add or subtract from UTC.
<i>minutes</i>	Number of minutes to add or subtract from UTC.

Defaults If this command is not used, then the default time zone is UTC.

Access Enabled.

Examples To set the time zone for Pacific Standard Time (PST), type the following command:

```
23x0# set timezone PST -8
```

Timezone is set to 'PST', offset from UTC is -8:0 hours.

See Also

- **clear summertime on page 105**
- **clear timezone on page 106**
- **set summertime on page 140**
- **set timedate on page 142**
- **show summertime on page 160**
- **show timedate on page 161**
- **show timezone on page 161**

show arp

Displays the ARP table.

Syntax `show arp [ip-addr]`

ip-addr IP address.

Defaults If you do not specify an IP address, the whole ARP table is displayed.

Access All.

Examples The following command displays ARP entries:

WSS# show arp

ARP aging time: 1200 seconds

Host	HW Address	VLAN	Type	State
10.5.4.51	00:0b:0e:02:76:f5	1	DYNAMIC	RESOLVED
10.5.4.53	00:0b:0e:02:76:f7	1	LOCAL	RESOLVED

[Table 17](#) describes the fields in this display.

Table 1: Output for show arp

Field	Description
ARP aging time	Number of seconds a dynamic entry can remain unused before WSS Software removes the entry from the ARP table.
Host	IP address, hostname, or alias.
HW Address	MAC address mapped to the IP address, hostname, or alias.
VLAN	VLAN the entry is for.

Table 1: Output for show arp (continued)

Field	Description
Type	Entry type: <ul style="list-style-type: none"> • DYNAMIC—Entry was learned from network traffic and ages out if unused for longer than the ARP aging timeout. • LOCAL—Entry for the WSS MAC address. Each VLAN has one local entry for the switch MAC address. • PERMANENT—Entry does not age out and remains in the configuration even following a reboot. • STATIC—Entry does not age out but is removed after a reboot.
State	Entry state: <ul style="list-style-type: none"> • RESOLVING—WSS Software sent an ARP request for the entry and is waiting for the reply. • RESOLVED—Entry is resolved.

See Also

- [set arp on page 108](#)
- [set arp agingtime on page 109](#)

show dhcp-client

Displays DHCP client information for all VLANs.

Syntax `show dhcp-client`

Defaults None.

Access All.

History Introduced in WSS Software Version 4.0.

Examples The following command displays DHCP client information:

```
WSS# show dhcp-client
Interface:      corpvlan(4)
Configuration Status: Enabled
DHCP State:     IF_UP
Lease Allocation: 65535 seconds
Lease Remaining: 65532 seconds
IP Address:     10.3.1.110
Subnet Mask:    255.255.255.0
Default Gateway: 10.3.1.1
DHCP Server:    10.3.1.4
DNS Servers:    10.3.1.29
DNS Domain Name: mycorp.com
```

Table 18 describes the fields in this display.

Table 2. Output for show dhcp-client

Field	Description
Interface	VLAN name and number.
Configuration Status	Status of the DHCP client on this VLAN: <ul style="list-style-type: none">• Enabled• Disabled
DHCP State	State of the IP interface: <ul style="list-style-type: none">• IF_UP• IF_DOWN
Lease Allocation	Duration of the address lease.
Lease Remaining	Number of seconds remaining before the address lease expires.
IP Address	IP address received from the DHCP server.
Subnet Mask	Network mask of the IP address received from the DHCP server.
Default Gateway	Default router (gateway) IP address received from the DHCP server. If the address is 0.0.0.0, the server did not provide an address.
DHCP Server	IP address of the DHCP server.
DNS Servers	DNS server IP address(es) received from the DHCP server.
DNS Domain Name	Default DNS domain name received from the DHCP server.

See Also [set interface dhcp-client on page 110](#)

show dhcp-server

Displays WSS Software DHCP server information.

Syntax `show dhcp-server [interface vlan-id] [verbose]`

interface *vlan-id* Displays the IP addresses leased by the specified VLAN.

verbose Displays configuration and status information for the WSS Software DHCP server.

Defaults None.

Access All.

History Introduced in WSS Software Version 4.0.

Examples The following command displays the addresses leased by the WSS Software DHCP server:

```
WSS# show dhcp-server
VLAN Name      Address      MAC          Lease Remaining (sec)
-----
1 default      10.10.20.2   00:01:02:03:04:05  12345
1 default      10.10.20.3   00:01:03:04:06:07  2103
2 red-vlan     192.168.1.5  00:01:03:04:06:08  102
2 red-vlan     192.168.1.7  00:01:03:04:06:09  16789
```

The following command displays configuration and status information for each VLAN on which the DHCP server is configured:

```
WSS# show dhcp-server verbose
Interface:      0 (Direct AP)
Status:         UP
Address Range:  10.0.0.1-10.0.0.253

Interface:      default(1)
Status:         UP
Address Range:  10.10.20.2-10.10.20.254
Hardware Address: 00:01:02:03:04:05
State:          BOUND
Lease Allocation: 43200 seconds
Lease Remaining: 12345 seconds
IP Address:     10.10.20.2
Subnet Mask:    255.255.255.0
Default Router: 10.10.20.1
DNS Servers:    10.10.20.4 10.10.20.5
DNS Domain Name: mycorp.com
```

[Table 19](#) and [Table 20](#) describe the fields in these displays.

Table 3. Output for show dhcp-server

Field	Description
VLAN	VLAN number.
Name	VLAN name.
Address	IP address leased by the server.
MAC Address	MAC address of the device that holds the lease for the address.
Lease Remaining	Number of seconds remaining before the address lease expires.

Table 4. Output for show dhcp-server verbose

Field	Description
Interface	VLAN name and number.
Status	Status of the interface: <ul style="list-style-type: none">• UP• DOWN
Address Range	Range from which the server can lease addresses.
Hardware Address	MAC address of the DHCP client.
State	State of the address lease: <ul style="list-style-type: none">• SUSPEND—WSS Software is checking for the presence of another DHCP server on the subnet. This is the initial state of the WSS Software DHCP server. The WSS Software DHCP server remains in this state if another DHCP server is detected.• CHECKING—WSS Software is using ARP to verify whether the address is available.• OFFERING—WSS Software offered the address to the client and is waiting for the client to send a DHCPREQUEST for the address.• BOUND—The client accepted the address.• HOLDING—The address is already in use and is therefore unavailable.
Lease Allocation	Duration of the address lease, in seconds.
Lease Remaining	Number of seconds remaining before the address lease expires.
IP Address	IP address leased to the client.

Table 4. Output for show dhcp-server verbose (continued)

Field	Description
Subnet Mask	Network mask of the IP address leased to the client.
Default Router	Default router IP address included in the DHCP Offer to the client.
DNS Servers	DNS server IP address(es) included in the DHCP Offer to the client.
DNS Domain Name	Default DNS domain name included in the DHCP Offer to the client.

See Also **set interface dhcp-server** on page 111

show interface

Displays the IP interfaces configured on the WSS.

Syntax `show interface [vlan-id]`

vlan-id VLAN name or number.

Defaults If you do not specify a VLAN ID, interfaces for all VLANs are displayed.

Access All.

History

Version 4.0 RIB field added.

Usage The IP interface table flags an address assigned by a DHCP server with an asterisk (*).

Examples The following command displays all the IP interfaces configured on a WSS:

WSS# show interface

VLAN Name	Address	Mask	Enabled	State	RIB
1 default	10.10.10.10	255.255.255.0	YES	Up	ipv4
2 mauve	10.10.20.10	255.255.255.0	NO	Down	ipv4
4 corpvlan	*10.3.1.110	255.255.255.0	YES	Up	ipv4

Table 21 describes the fields in this display.

Table 5: Output for show interface

Field	Description
VLAN	VLAN number
Name	VLAN name
Address	IP address
Mask	Subnet mask
Enabled	Administrative state: <ul style="list-style-type: none">• YES (enabled)• NO (disabled)
State	Link state: <ul style="list-style-type: none">• Up (operational)• Down (unavailable)
RIB	Routing Information Base

See Also

- [clear interface on page 99](#)
- [set interface on page 109](#)
- [set interface status on page 112](#)

show ip alias

Displays the IP aliases configured on the WSS.

Syntax `show ip alias [name]`

name Alias string.

Defaults If you do not specify an alias name, all aliases are displayed.

Access Enabled.

Examples The following command displays all the aliases configured on a WSS:

WSS# show ip alias

```
Name            IP Address
-----
HR1            192.168.1.2
payroll       192.168.1.3
radius1       192.168.7.2
```


Table 22 describes the fields in this display.

Table 6: Output for show ip alias

Field	Description
Name	Alias string.
IP Address	IP address associated with the alias.

See Also

- **clear ip alias on page 100**
- **set ip alias on page 113**

show ip dns

Displays the DNS servers the WSS is configured to use.

Syntax `show ip dns`

Defaults None.

Access All.

Examples The following command displays the DNS information:

WSS# show ip dns

Domain Name: example.com

DNS Status: enabled

IP Address Type

```
-----
10.1.1.1           PRIMARY
10.1.1.2           SECONDARY
10.1.2.1           SECONDARY
```

Table 23 describes the fields in this display.

Table 7: Output for show ip dns

Field	Description
Domain Name	Default domain name configured on the WSS
DNS Status	Status of the switch's DNS client: <ul style="list-style-type: none"> • Enabled • Disabled

Table 7: Output for show ip dns (continued)

Field	Description
IP Address	IP address of the DNS server
Type	Server type: <ul style="list-style-type: none">• PRIMARY• SECONDARY

See Also

- **clear ip dns domain on page 100**
- **clear ip dns server on page 101**
- **set ip dns on page 113**
- **set ip dns domain on page 114**
- **set ip dns server on page 115**

show ip https

Displays information about the HTTPS management port.

Syntax `show ip https`

Defaults None.

Access All.

Examples The following command shows the status and port number for the HTTPS management interface to the WSS:

```
WSS> show ip https
```

```
HTTPS is enabled
```

```
HTTPS is set to use port 443
```

```
Last 10 Connections:
```

```
IP Address   Last Connected   Time Ago (s)
```

```
-----  
10.10.10.56  2003/05/09 15:51:26 pst    349
```

[Table 24](#) describes the fields in this display.

Table 8: Output for show ip https

Field	Description
HTTPS is enabled/disabled	State of the HTTPS server: <ul style="list-style-type: none"> • Enabled • Disabled
HTTPS is set to use port	TCP port number on which the WSS listens for HTTPS connections.
Last 10 connections	List of the last 10 devices to establish connections to the WSS's HTTPS server.
IP Address	IP address of the device that established the connection. Note: If a browser connects to a WSS from behind a proxy, then only the proxy IP address is shown. If multiple browsers connect using the same proxy, the proxy address appears only once in the output.
Last Connected	Time when the device established the HTTPS connection to the switch.
Time Ago (s)	Number of seconds since the device established the HTTPS connection to the switch.

See Also

- **clear ip telnet on page 102**
- **set ip https server on page 116**
- **set ip telnet on page 120**
- **set ip telnet server on page 120**
- **show ip telnet on page 155**

show ip route

Displays the IP route table.

Syntax `show ip route [destination]`

destination Route destination IP address, in dotted decimal notation.

Defaults None.

Access All.

Usage When you add an IP interface to a VLAN that is up, WSS Software adds direct and local routes for the interface to the route table. If the VLAN is down, WSS Software does not add the routes. If you add an interface to a VLAN but the routes for that interface do not appear in the route table, use the **show vlan config** command to check the VLAN state.

If you add a static route and the route's state is shown as Down, use the **show interface** command to verify that the WSS has an IP interface in the default router's (gateway's) subnet. WSS Software cannot resolve a static route unless one of the switch's VLANs has an interface in the default router's subnet. If the switch has such an interface but the static route is still down, use the **show vlan config** command to check the state of the VLAN's ports.

Examples The following command shows all routes in a WSS's IP route table:

WSS# show ip route

Router table for IPv4

Destination/Mask	Proto	Metric	NH-Type	Gateway	VLAN:Interface
0.0.0.0/0	Static	1	Router	10.0.1.17	Down
0.0.0.0/0	Static	2	Router	10.0.2.17	vlan:2:ip
10.0.2.1/24	IP	0	Direct		vlan:2:ip
10.0.2.1/32	IP	0	Direct		vlan:2:ip:10.0.1.1/24
10.0.2.255/32	IP	0	Direct		vlan:2:ip:10.0.1.1/24
224.0.0.0/4	IP	0	Local		MULTICAST

Table 25 describes the fields in this display.

Table 9: Output for show ip route

Field	Description
Destination/Mask	IP address and subnet mask of the route destination. The 244.0.0.0 route is automatically added by WSS Software and supports the IGMP snooping feature.
Proto	Protocol that added the route to the IP route table. The protocol can be one of the following: <ul style="list-style-type: none"> • IP—WSS Software added the route. • Static—An administrator added the route.
Metric	Cost for using the route.
NH-Type	Next-hop type: <ul style="list-style-type: none"> • Local—Route is for a local interface. WSS Software adds the route when you configure an IP address on the WSS. • Direct—Route is for a locally attached subnet. WSS Software adds the route when you add an interface in the same subnet to the WSS. • Router—Route is for a remote destination. A WSS forwards traffic for the destination to the default router (gateway).

Table 9: Output for show ip route (continued)

Field	Description
Gateway	Next-hop router for reaching the route destination. Note: This field applies only to static routes.
VLAN:Interface	Destination VLAN, protocol type, and IP address of the route. Because direct routes are for local interfaces, a destination IP address is not listed. The destination for the IP multicast route is MULTICAST. For static routes, the value Down means the WSS does not have an interface to the destination's next-hop router. To provide an interface, configure an IP interface that is in the same IP subnet as the next-hop router. The IP interface must be on a VLAN containing the port that is attached to the default router.

See Also

- **clear ip route on page 101**
- **set interface on page 109**
- **set ip route on page 116**
- **show interface on page 149**
- **show vlan config on page 89**

show ip telnet

Displays information about the Telnet management port.

Syntax `show ip telnet`

Defaults None.

Access All.

Examples The following command shows the status and port number for the Telnet management interface to the WSS:

WSS> show ip telnet

```

Server Status      Port
-----
Enabled           23

```

[Table 26](#) describes the fields in this display.

Table 10: Output for show ip telnet

Field	Description
Server Status	State of the HTTPS server: <ul style="list-style-type: none">• Enabled• Disabled
Port	TCP port number on which the WSS listens for Telnet management traffic.

See Also

- **clear ip telnet on page 102**
- **set ip https server on page 116**
- **set ip telnet on page 120**
- **set ip telnet server on page 120**
- **show ip https on page 152**

show ntp

Displays NTP client information.

Syntax `show ntp`

Defaults None.

Access All.

Examples To display NTP information for a WSS, type the following command:

```
WSS> show ntp
NTP client: enabled
Current update-interval: 20(secs)
Current time: Fri Feb 06 2004, 12:02:57
Timezone is set to 'PST', offset from UTC is -8:0 hours.
Summertime is enabled.
Last NTP update: Fri Feb 06 2004, 12:02:46
NTP Server      Peer state      Local State
-----
192.168.1.5     SYSPEER        SYNCED
```

[Table 27](#) describes the fields in this display.

Table 11: Output for show ntp

Field	Description
NTP client	State of the NTP client. The state can be one of the following: <ul style="list-style-type: none"> • Enabled • Disabled
Current update-interval	Number of seconds between queries sent by the WSS to the NTP servers for updates.
Current time	System time that was current on the WSS when you pressed Enter after typing the show ntp command.
Timezone	Time zone configured on the switch. WSS Software offsets the time reported by the NTP server based on the time zone. Note: This field is displayed only if you change the time zone.
Summertime	Summertime period configured on the switch. WSS Software offsets the system time +1 hour and returns it to standard time for daylight savings time or a similar summertime period that you set. Note: This field is displayed only if you enable summertime.
Last NTP update	Time when the switch received the most recent update from an NTP server.
NTP Server	IP address of the NTP server.
Peer state	State of the NTP session from the point of view of the NTP server: <ul style="list-style-type: none"> • CORRECT • REJECT • SELCAND • SYNCCAND • SYSPEER
Local state	State of the NTP session from the point of view of the WSS's NTP client: <ul style="list-style-type: none"> • INITED • START • SYNCED

See Also

- **clear ntp server on page 102**
- **clear summertime on page 105**
- **clear timezone on page 106**
- **set ntp on page 121**

- [set ntp server on page 122](#)
- [set summertime on page 140](#)
- [set timezone on page 143](#)
- [show timezone on page 161](#)

show snmp community

Displays the configured SNMP community strings.

Syntax `show snmp community`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

See Also

- [clear snmp community on page 103](#)
- [set snmp community on page 123](#)

show snmp counters

Displays SNMP statistics counters.

Syntax `show snmp counters`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

show snmp notify profile

Displays SNMP notification profiles.

Syntax `show snmp notify profile`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

- [clear snmp notify profile on page 104](#)
- [set snmp notify profile on page 125](#)

show snmp notify target

Displays SNMP notification targets.

Syntax `show snmp notify target`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

See Also

- [clear snmp notify target on page 104](#)
- [set snmp notify target on page 131](#)

show snmp status

Displays SNMP version and status information.

Syntax `show snmp status`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

See Also

- [set snmp community on page 123](#)
- [set snmp notify target on page 131](#)
- [set snmp notify profile on page 125](#)
- [set snmp protocol on page 135](#)
- [set snmp security on page 136](#)
- [set snmp usm on page 136](#)
- [show snmp community on page 158](#)
- [show snmp counters on page 158](#)
- [show snmp notify profile on page 158](#)
- [show snmp notify target on page 159](#)
- [show snmp usm on page 160](#)

show snmp usm

Displays information about SNMPv3 users.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

See Also

- **clear snmp usm on page 105**
- **show snmp usm on page 160**

show summertime

Shows a WSS's offset from its real-time clock.

Syntax **show summertime**

Defaults There is no summertime offset by default.

Access All.

Examples To display the summertime setting on a WSS, type the following command:

23x0# show summertime

Summertime is enabled, and set to 'PDT'.

Start : Sun Apr 04 2004, 02:00:00

End : Sun Oct 31 2004, 02:00:00

Offset : 60 minutes

Recurring : yes, starting at 2:00 am of first Sunday of April
and ending at 2:00 am on last Sunday of October.

See Also

- **clear summertime on page 105**
- **clear timezone on page 106**
- **set summertime on page 140**
- **set timedate on page 142**
- **set timezone on page 143**
- **show timedate on page 161**
- **show timezone on page 161**

show timedate

Shows the date and time of day currently set on a WSS's real-time clock.

Syntax `show timedate`

Defaults None.

Access All.

Examples To display the time and date set on a WSS's real-time clock, type the following command:

23x0# show timedate

Sun Feb 29 2004, 23:59:02 PST

See Also

- [clear summertime on page 105](#)
- [clear timezone on page 106](#)
- [set summertime on page 140](#)
- [set timedate on page 142](#)
- [set timezone on page 143](#)
- [show summertime on page 160](#)
- [show timezone on page 161](#)

show timezone

Shows the time offset for the real-time clock from UTC on a WSS.

Syntax `show timezone`

Defaults None.

Access All.

Examples To display the offset from UTC, type the following command:

WSS# show timezone

Timezone set to 'pst', offset from UTC is -8 hours

See Also

- [clear summertime on page 105](#)
- [clear timezone on page 106](#)
- [set summertime on page 140](#)
- [set timedate on page 142](#)
- [set timezone on page 143](#)
- [show summertime on page 160](#)
- [show timedate on page 161](#)

telnet

Opens a Telnet client session with a remote device.

Syntax `telnet {ip-addr | hostname} [port port-num]`

ip-addr IP address of the remote device.
hostname Hostname of the remote device.
port port-num TCP port number on which the TCP server on the remote device listens for Telnet connections.

Defaults WSS Software attempts to establish Telnet connections with TCP port 23 by default.

Access Enabled.

Usage To end a Telnet session from the remote device, press Ctrl+t or type **exit** in the management session on the remote device. To end a client session from the local device, use the **clear sessions telnet client** command.

If the configuration of the WSS from which you enter the **telnet** command has an ACL that denies Telnet client traffic, the ACL also denies access by the **telnet** command.

Examples In the following example, an administrator establishes a Telnet session with another WSS and enters a command on the remote switch:

```
WSS# telnet 10.10.10.90
Session 0 pty tty2.d Trying 10.10.10.90...
Connected to 10.10.10.90
Disconnect character is '^t'
```

Copyright (c) 2002, 2003
Nortel, Inc.

Username: *username*
Password: *password*

WSS-remote> show vlan

VLAN Name	Admin Status	VLAN State	Tunl Affin	Port	Tag	Port State
1 default	Up	Up	5			
3 red	Up	Up	5		none	Up
10 backbone	Up	Up	5			
			21		none	Up
			22		none	Up

When the administrator presses Ctrl+t to end the Telnet connection, the management session returns to the local WSS prompt:

```
WSS-remote> Session 0 pty tty2.d terminated tt name tty2.d
```

```
WSS#
```

See Also

- [clear sessions on page 435](#)
- [show sessions on page 437](#)

traceroute

Traces the route to an IP host.

Syntax `traceroute host [dnf] [no-dns] [port port-num] [queries num] [size size] [ttl hops] [wait ms]`

<i>host</i>	IP address, hostname, or alias of the destination host. Specify the IP address in dotted decimal notation.
dnf	Sets the Do Not Fragment bit in the ping packet to prevent the packet from being fragmented.
no-dns	Prevents WSS Software from performing a DNS lookup for each hop to the destination host.
port <i>port-num</i>	TCP port number listening for the traceroute probes.
queries <i>num</i>	Number of probes per hop.
size <i>size</i>	Probe packet size in bytes. You can specify from 40 through 1460.
ttl <i>hops</i>	Maximum number of hops, which can be from 1 through 255.
wait <i>ms</i>	Probe wait in milliseconds. You can specify from 1 through 100,000.

Defaults

- **dnf**—Disabled
- **no-dns**—Disabled
- **port**—33434
- **queries**—3
- **size**—38
- **ttl**—30
- **wait**—5000

Access All.

Usage To stop a `traceroute` command that is in progress, press Ctrl+C.

Examples The following example traces the route to host `server1`:

WSS# traceroute server1

```
traceroute to server1.example.com (192.168.22.7), 30 hops max, 38 byte packets
1 engineering-1.example.com (192.168.192.206) 2 ms 1 ms 1 ms
2 engineering-2.example.com (192.168.196.204) 2 ms 3 ms 2 ms
3 gateway_a.example.com (192.168.1.201) 6 ms 3 ms 3 ms
4 server1.example.com (192.168.22.7) 3 ms * 2 ms
```

The first row of the display indicates the target host, the maximum number of hops, and the packet size. Each numbered row displays information about one hop. The rows are displayed in the order in which the hops occur, beginning with the hop closest to the WSS.

The row for a hop lists the total time in milliseconds for each ICMP packet to reach the router or host, plus the time for the ICMP *Time Exceeded* message to return to the host.

An exclamation point (!) following any of these values indicates that the *Port Unreachable* message returned by the destination has a maximum hop count of 0 or 1. This can occur if the destination uses the maximum hop count value from the arriving packet as the maximum hop count in its ICMP reply. The reply does not arrive at the source until the destination receives a traceroute packet with a maximum hop count equal to the number of hops between the source and destination.

An asterisk (*) indicates that the timeout period expired before WSS Software received a *Time Exceeded* message for the packet.

If Traceroute receives an ICMP error message other than a *Time Exceeded* or *Port Unreachable* message, WSS Software displays one of the error codes described in [Table 28](#) instead of displaying the round-trip time or an asterisk (*).

[Table 28](#) describes the **traceroute** error messages.

Table 12: Error Messages for traceroute

Field	Description
!N	No route to host. The network is unreachable.
!H	No route to host. The host is unreachable.
!P	Connection refused. The protocol is unreachable.
!F	Fragmentation needed but Do Not Fragment (DNF) bit was set.
!S	Source route failed.
!A	Communication administratively prohibited.
?	Unknown error occurred.

See Also ping on page 107

AAA Commands

Use authentication, authorization, and accounting (AAA) commands to provide a secure network connection and a record of user activity. Location policy commands override any virtual LAN (VLAN) or security ACL assignment by AAA or the local WSS database to help you control access locally.

(Security ACLs are packet filters. For command descriptions, see [“Security ACL Commands” on page 449.](#))

This chapter presents AAA commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Authentication	set authentication console on page 183
	set authentication admin on page 182
	set authentication dot1x on page 185
	set authentication mac on page 189
	set authentication proxy on page 190
	clear authentication admin on page 167
	clear authentication console on page 168
	clear authentication dot1x on page 169
	clear authentication mac on page 170
	clear authentication proxy on page 170
Local Authorization for Password Users	clear authentication web on page 171
	set user on page 206
	clear user on page 175
	set user attr on page 207
	clear user attr on page 176
	set usergroup on page 208
	clear usergroup on page 177
	set user group on page 208
	clear user group on page 177
	clear usergroup attr on page 178
Local Authorization for MAC Users	set mac-user on page 195
	clear mac-user on page 172
	set mac-user attr on page 197
	clear mac-user attr on page 172
	set mac-usergroup attr on page 203

	clear mac-usergroup attr on page 174
	clear mac-user group on page 173
	clear mac-usergroup on page 174
Web authorization	set web-portal on page 209
Accounting	set accounting {admin console} on page 178
	set accounting {dot1x mac web last-resort} on page 179
	set accounting system on page 181
	show accounting statistics on page 212
	clear accounting on page 166
AAA information	show aaa on page 210
Mobility Profiles	set mobility-profile on page 204
	set mobility-profile mode on page 205
	show mobility-profile on page 215
	clear mobility-profile on page 175
Location Policy	set location policy on page 193
	show location policy on page 215
	clear location policy on page 171

clear accounting

Removes accounting services for specified wireless users with administrative access or network access.

Syntax **clear accounting** { **admin** | **dot1x** | **system** } {*user-wildcard*}

admin	Users with administrative access to the WSS through a console connection or through a Telnet or Web View connection.
dot1x	Users with network access through the WSS. Users with network access are authorized to use the network through either an IEEE 802.1X method or their media access control (MAC) address.

system Disables sending of Accounting-On and Accounting-Off messages to a RADIUS server, if previously enabled.
When this command is entered, an Accounting-Off message is generated and sent to the server or server group specified with the **set accounting system** command.

user-wildcard Single user or set of users with administrative access or network access. Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character—either an *at* sign (@) or a period (.). (For details, see “[User Wildcards](#)” on page 12.)

Defaults None.

Access Enabled.

History

Version 5.0 **system** option added

Examples The following command removes accounting services for authorized network user Nin:

```
WSS# clear accounting dot1x Nin
```

success: change accepted.

See Also

- **set accounting {admin | console}** on page 178
- **set accounting system** on page 181
- **show accounting statistics** on page 212

clear authentication admin

Removes an authentication rule for administrative access through Telnet or Web View.

Syntax **clear authentication admin** *user-wildcard*

user-wildcard A single user or set of users. Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character, either an *at* sign (@) or a period (.). (For details, see “[User Wildcards](#)” on page 12.)

Defaults None.

Access Enabled.



Note. The syntax descriptions for the **clear authentication** commands have been separated for clarity. However, the options and behavior for the **clear authentication admin** command are the same as in previous releases.

Examples The following command clears authentication for administrator Jose:

```
WSS# clear authentication admin Jose
success: change accepted.
```

See Also

- [clear authentication console on page 168](#)
- [clear authentication dot1x on page 169](#)
- [clear authentication mac on page 170](#)
- [clear authentication web on page 171](#)
- [set authentication admin on page 182](#)
- [show aaa on page 210](#)

clear authentication console

Removes an authentication rule for administrative access through the Console.

Syntax `clear authentication console user-wildcard`

user-wildcard

A single user or set of users.

Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character, either an *at* sign (@) or a period (.). (For details, see [“User Wildcards” on page 12.](#))

Defaults None.

Access Enabled..



Note. The syntax descriptions for the **clear authentication** commands have been separated for clarity. However, the options and behavior for the **clear authentication console** command are the same as in previous releases.

Examples The following command clears authentication for administrator Regina:

```
WSS# clear authentication console Regina
```

success: change accepted.

See Also

- [clear authentication admin on page 167](#)
- [clear authentication dot1x on page 169](#)
- [clear authentication mac on page 170](#)
- [clear authentication web on page 171](#)
- [set authentication console on page 183](#)
- [show aaa on page 210](#)

clear authentication dot1x

Removes an 802.1X authentication rule.

Syntax `clear authentication dot1x {ssid ssid-name | wired} user-wildcard`

ssid *ssid-name* SSID name to which this authentication rule applies.

wired Clears a rule used for access over a WSS's wired-authentication port.

user-wildcard User-wildcard associated with the rule you are removing.

Defaults None.

Access Enabled.

Examples The following command removes 802.1X authentication for network users with usernames ending in `@thiscorp.com` who try to access SSID `finance`:

WSS# `clear authentication dot1x ssid finance *@thiscorp.com`

See Also

- [clear authentication admin on page 167](#)
- [clear authentication console on page 168](#)
- [clear authentication mac on page 170](#)
- [clear authentication web on page 171](#)
- [set authentication dot1x on page 185](#)
- [show aaa on page 210](#)

clear authentication last-resort

Deprecated in WSS Software Version 5.0. The *last-resort* user is not required or supported in WSS Software Version 5.0. Instead, a user who accesses the network on an SSID by using the fallthru access type **last-resort** is automatically a *last-resort* user. The authorization attributes assigned to the user come from the default authorization attributes set on the SSID.

clear authentication mac

Removes a MAC authentication rule.

Syntax `clear authentication mac {ssid ssid-name | wired} mac-addr-wildcard`

ssid *ssid-name* SSID name to which this authentication rule applies.
wired Clears a rule used for access over a WSS's wired-authentication port.
mac-addr-wildcard MAC address wildcard associated with the rule you are removing.

Defaults None.

Access Enabled.

Examples The following command removes a MAC authentication rule for access to SSID *thatcorp* by MAC addresses beginning with *aa:bb:cc*:

WSS# `clear authentication mac ssid thatcorp aa:bb:cc*`

See Also

- [clear authentication admin on page 167](#)
- [clear authentication console on page 168](#)
- [clear authentication dot1x on page 169](#)
- [clear authentication web on page 171](#)
- [set authentication mac on page 189](#)
- [show aaa on page 210](#)

clear authentication proxy

Removes a proxy rule for third-party AP users.

Syntax `clear authentication proxy ssid ssid-name user-wildcard`

ssid *ssid-name* SSID name to which this authentication rule applies.
user-wildcard User-wildcard associated with the rule you are removing.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.0.

Examples The following command removes the proxy rule for SSID *mycorp* and userwildcard ******:

WSS# `clear authentication proxy ssid mycorp **`

See Also

- [set authentication proxy on page 190](#)
- [show aaa on page 210](#)

clear authentication web

Removes a Web-based AAA rule.

Syntax `clear authentication web {ssid ssid-name | wired} user-wildcard`

ssid *ssid-name* SSID name to which this authentication rule applies.

wired Clears a rule used for access over a WSS's wired-authentication port.

user-wildcard User-wildcard associated with the rule you are removing.

Defaults None.

Access Enabled.

Examples The following command removes Web-based AAA for SSID *research* and userwildcard *temp*@thiscorp.com*:

WSS# `clear authentication web ssid research temp*@thiscorp.com`

See Also

- [clear authentication admin on page 167](#)
- [clear authentication console on page 168](#)
- [clear authentication dot1x on page 169](#)
- [clear authentication mac on page 170](#)
- [set authentication web on page 191](#)
- [show aaa on page 210](#)

clear location policy

Removes a rule from the location policy on a WSS.

Syntax `clear location policy rule-number`

rule-number Index number of a location policy rule to remove from the location policy.

Defaults None.

Access Enabled.

Usage To determine the index numbers of location policy rules, use the **show location policy** command. Removing all the ACEs from the location policy disables this function on the WSS.

Examples The following command removes location policy rule 4 from a WSS's location policy:

```
WSS# clear location policy 4
success: clause 4 is removed.
```

See Also

- [set location policy on page 193](#)
- [show location policy on page 215](#)

clear mac-user

Removes a user profile from the local database on the WSS, for a user who is authenticated by a MAC address.

(To remove a user profile in RADIUS, see the documentation for your RADIUS server.)

Syntax **clear mac-user** *mac-addr*

mac-addr MAC address of the user, in hexadecimal numbers separated by colons (:). You can omit leading zeros.

Defaults None.

Access Enabled.

Usage Deleting a MAC user's profile from the database deletes the assignment of any attributes in the profile to the user.

Examples The following command removes the user profile for a user at MAC address 01:02:03:04:05:06:

```
WSS# clear mac-user 01:02:03:04:05:06
success: change accepted.
```

See Also

- [set mac-usergroup attr on page 203](#)
- [set mac-user attr on page 197](#)
- [show aaa on page 210](#)

clear mac-user attr

Removes an authorization attribute from the user profile in the local database on the WSS, for a user who is authenticated by a MAC address.

(To remove an authorization attribute in RADIUS, see the documentation for your RADIUS server.)

Syntax `clear mac-user mac-addr attr attribute-name`

mac-addr MAC address of the user, in hexadecimal numbers separated by colons (:). You can omit leading zeros.

attribute-name Name of an attribute used to authorize the MAC user for a particular service or session characteristic. (For a list of authorization attributes, see [Table 29 on page 198](#).)

Defaults None.

Access Enabled.

Examples The following command removes an access control list (ACL) from the profile of a user at MAC address 01:02:03:04:05:06:

WSS# clear mac-user 01:02:03:04:05:06 attr filter-id
success: change accepted.

See Also

- [set mac-user attr on page 197](#)
- [show aaa on page 210](#)

clear mac-user group

Removes a user profile from a MAC user group in the local database on the WSS, for a user who is authenticated by a MAC address.

(To remove a MAC user group profile in RADIUS, see the documentation for your RADIUS server.)

Syntax `clear mac-user mac-addr group`

mac-addr MAC address of the user, in hexadecimal numbers separated by colons (:). You can omit leading zeros.

Defaults None.

Access Enabled.

Usage Removing a MAC user from a MAC user group removes the group name from the user's profile, but does not delete the user group from the local WSS database. To remove the group, use **clear mac-usergroup**.

Examples The following command deletes the user profile for a user at MAC address 01:02:03:04:05:06 from its user group:

WSS# clear mac-user 01:02:03:04:05:06 group
success: change accepted.

See Also

- [clear mac-usergroup on page 174](#)
- [set mac-user on page 195](#)
- [show aaa on page 210](#)

clear mac-usergroup

Removes a user group from the local database on the WSS, for a group of users who are authenticated by a MAC address.

(To delete a MAC user group in RADIUS, see the documentation for your RADIUS server.)

Syntax `clear mac-usergroup group-name`

group-name Name of an existing MAC user group.

Defaults None.

Access Enabled.

Usage To remove a user from a MAC user group, use the **clear mac-user group** command.

Examples The following command deletes the MAC user group *eastcoasters* from the local database:

```
WSS# clear mac-usergroup eastcoasters
success: change accepted.
```

See Also

- **clear mac-usergroup attr** on page 174
- **set mac-usergroup attr** on page 203
- **show aaa** on page 210

clear mac-usergroup attr

Removes an authorization attribute from a MAC user group in the local database on the WSS, for a group of users who are authenticated by a MAC address.

(To unconfigure an authorization attribute in RADIUS, see the documentation for your RADIUS server.)

Syntax `clear mac-usergroup group-name attr attribute-name`

group-name Name of an existing MAC user group.

attribute-name Name of an attribute used to authorize the MAC users in the user group for a particular service or session characteristic. (For a list of authorization attributes, see [Table 29 on page 198](#).)

Defaults None.

Access Enabled.

Usage To remove the group itself, use the **clear mac-usergroup** command.

Examples The following command removes the members of the MAC user group *eastcoasters* from a VLAN assignment by deleting the VLAN-Name attribute from the group:

WSS# clear mac-usergroup eastcoasters attr vlan-name
success: change accepted.

See Also

- **clear mac-usergroup on page 174**
- **set mac-usergroup attr on page 203**
- **show aaa on page 210**

clear mobility-profile

Removes a Mobility Profile entirely.

Syntax **clear mobility-profile** *name*

name Name of an existing Mobility Profile.

Defaults None.

Access Enabled.

Examples The following command removes the Mobility Profile for user Nin:

WSS# clear mobility-profile Nin
success: change accepted.

See Also

- **set mobility-profile on page 204**
- **set mobility-profile mode on page 205**
- **show mobility-profile on page 215**

clear user

Removes a user profile from the local database on the WSS, for a user with a password.

(To remove a user profile in RADIUS, see the documentation for your RADIUS server.)

Syntax **clear user** *username*

username Username of a user with a password.

Defaults None.

Access Enabled.

Usage Deleting the user's profile from the database deletes the assignment of any attributes in the profile to the user.

Examples The following command deletes the user profile for user Nin:

WSS# clear user Nin

success: change accepted.

See Also

- **set user on page 206**
- **show aaa on page 210**

clear user attr

Removes an authorization attribute from the user profile in the local database on the WSS, for a user with a password.

(To remove an authorization attribute from a RADIUS user profile, see the documentation for your RADIUS server.)

Syntax **clear user** *username attr attribute-name*

username

Username of a user with a password.

attribute-name

Name of an attribute used to authorize the user for a particular service or session characteristic. (For a list of authorization attributes, see [Table 29 on page 198.](#))

Defaults None.

Access Enabled.

Examples The following command removes the Session-Timeout attribute from Hosni's user profile:

WSS# clear user Hosni attr session-timeout

success: change accepted.

See Also

- **set user attr on page 207**
- **show aaa on page 210**

clear user group

Removes a user with a password from membership in a user group in the local database on the WSS.

(To remove a user from a user group in RADIUS, see the documentation for your RADIUS server.)

Syntax `clear user username group`

username Username of a user with a password.

Defaults None.

Access Enabled.

Usage Removing the user from the group removes the group name from the user's profile, but does not delete either the user or the user group from the local WSS database. To remove the group, use **clear usergroup**.

Examples The following command removes the user Nin from the user group Nin is in:

WSS# clear user Nin group

success: change accepted.

See Also

- **clear usergroup on page 177**
- **set user group on page 208**
- **show aaa on page 210**

clear usergroup

Removes a user group and its attributes from the local database on the WSS, for users with passwords.

(To delete a user group in RADIUS, see the documentation for your RADIUS server.)

Syntax `clear usergroup group-name`

group-name Name of an existing user group.

Defaults None.

Access Enabled.

Usage Removing a user group from the local WSS database does not remove the user profiles of the group's members from the database.

Examples The following command deletes the *cardiology* user group from the local database:

WSS# clear usergroup cardiology

success: change accepted.

See Also

- **clear usergroup attr on page 178**

- **set usergroup** on page 208
- **show aaa** on page 210

clear usergroup attr

Removes an authorization attribute from a user group in the local database on the WSS.

(To remove an authorization attribute in RADIUS, see the documentation for your RADIUS server.)

Syntax `clear usergroup group-name attr attribute-name`

<i>group-name</i>	Name of an existing user group.
<i>attribute-name</i>	Name of an attribute used to authorize all the users in the group for a particular service or session characteristic. (For a list of authorization attributes, see Table 29 on page 198.)

Defaults None.

Access Enabled.

Examples The following command removes the members of the user group *cardiology* from a network access time restriction by deleting the Time-Of-Day attribute from the group:

```
WSS# clear usergroup cardiology attr time-of-day
success: change accepted.
```

See Also

- **clear usergroup** on page 177
- **set usergroup** on page 208
- **show aaa** on page 210

set accounting { admin | console }

Sets up accounting services for specified wireless users with administrative access, and defines the accounting records and where they are sent.

Syntax `set accounting { admin | console } {user-wildcard} {start-stop | stop-only} method1 [method2] [method3] [method4]`

admin	Users with administrative access to the WSS through Telnet or Web View.
console	Users with administrative access to the WSS through a console connection.

<i>user-wildcard</i>	Single user or set of users with administrative access or network access. Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character—either an <i>at</i> sign (@) or a period (.). (For details, see “ User Wildcards ” on page 12.)
	Note: This option does not apply if mac is specified. For mac , specify a <i>mac-addr-wildcard</i> . (See “ MAC Address Wildcards ” on page 13.)
start-stop	Sends accounting records at the start and end of a network session.
stop-only	Sends accounting records only at the end of a network session.
<i>method1</i>	At least one of up to four methods that WSS Software uses to process accounting records. Specify one or more of the following methods in priority order. If the first method does not succeed, WSS Software tries the second method, and so on. A method can be one of the following:
<i>method2</i>	
<i>method3</i>	
<i>method4</i>	
	<ul style="list-style-type: none"> • local—Stores accounting records in the local database on the WSS. When the local accounting storage space is full, WSS Software overwrites older records with new ones. • <i>server-group-name</i>—Stores accounting records on one or more Remote Authentication Dial-In User Service (RADIUS) servers. You can also enter the names of existing RADIUS server groups as methods.

Defaults Accounting is disabled for all users by default.

Access Enabled.

Usage For network users with start-stop accounting whose records are sent to a RADIUS server, WSS Software sends interim updates to the RADIUS server when the user roams.

Examples The following command issues start-and-stop accounting records at the local WSS database for administrator Natasha, when she accesses the switch using Telnet or Web View:

```
WSS# set accounting admin Natasha start-stop local
success: change accepted.
```

See Also

- [clear accounting on page 166](#)
- [show accounting statistics on page 212](#)

set accounting {dot1x | mac | web | last-resort}

Sets up accounting services for specified wireless users with network access, and defines the accounting records and where they are sent.

Syntax `set accounting {dot1x | mac | web | last-resort} {ssid ssid-name | wired} {user-wildcard | mac-addr-wildcard} {start-stop | stop-only} method1 [method2] [method3] [method4]`

dot1x	Users with network access through the WSS who are authenticated by 802.1X.
mac	Users with network access through the WSS who are authenticated by MAC authentication
web	Users with network access through the WSS who are authenticated by Web-based AAA
ssid <i>ssid-name</i>	SSID name to which this accounting rule applies. To apply the rule to all SSIDs, type any .
wired	Applies this accounting rule specifically to users who are authenticated on a wired authentication port.
<i>user-wildcard</i>	Single user or set of users with administrative access or network access. Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character—either an <i>at</i> sign (@) or a period (.). (For details, see “ User Wildcards ” on page 12.) Note: This option does not apply if mac or last-resort is specified. For mac , specify a <i>mac-addr-wildcard</i> .
<i>mac-addr-wildcard</i>	A single user or set of users with access via a MAC address. Specify a MAC address, or use the wildcard (*) character to specify a set of MAC addresses. (For details, see “ MAC Address Wildcards ” on page 13.) This option applies only when mac is specified.
start-stop	Sends accounting records at the start and end of a network session.
stop-only	Sends accounting records only at the end of a network session.
<i>method1</i> <i>method2</i> <i>method3</i> <i>method4</i>	At least one of up to four methods that WSS Software uses to process accounting records. Specify one or more of the following methods in priority order. If the first method does not succeed, WSS Software tries the second method, and so on. A method can be one of the following: <ul style="list-style-type: none">• local—Stores accounting records in the local database on the WSS. When the local accounting storage space is full, WSS Software overwrites older records with new ones.• <i>server-group-name</i>—Stores accounting records on one or more Remote Authentication Dial-In User Service (RADIUS) servers. You can also enter the names of existing RADIUS server groups as methods.

Defaults Accounting is disabled for all users by default.

Access Enabled.

Usage For network users with start-stop accounting whose records are sent to a RADIUS server, WSS Software sends interim updates to the RADIUS server when the user roams.

Examples The following command issues stop-only records to the RADIUS server group *sg2* for network user *Nin*, who is authenticated by *802.1X*:

```
WSS# set accounting dot1x Nin stop-only sg2
success: change accepted.
```

See Also

- **clear accounting on page 166**
- **show accounting statistics on page 212**

set accounting system

Configures WSS Software to send Accounting-On and Accounting-Off messages to a specified RADIUS server group.

Syntax `set accounting system method1 [method2] [method3] [method4]`

<i>method1</i>	At least one of up to four methods that WSS Software uses to process accounting records. Specify one or more methods in priority order. If the first method does not succeed, WSS Software tries the second method, and so on.
<i>method2</i>	
<i>method3</i>	
<i>method4</i>	

Note: The **local** method is not valid for this command.

Defaults By default WSS Software does not send Accounting-On or Accounting-Off messages.

Access Enabled.

History Introduced in WSS Software 5.0.

Usage Use this command to configure WSS Software to send an Accounting-On message (Acct-Status-Type = 7) to a RADIUS server when the WSS starts, and an Accounting-Off message (Acct-Status-Type = 8) to the RADIUS server when the WSS is administratively shut down.

When you enable this command, an Accounting-On message is generated and sent to the specified server or server group. Subsequent Accounting-On messages are generated each time the WSS starts. When the WSS is administratively shut down, an Accounting-Off message is generated.

Accounting-Off messages are sent only when the WSS is administratively shut down, not when a critical failure causes the WSS to reset. The WSS does not wait for a RADIUS server to acknowledge the Accounting-Off message; the switch makes one attempt to send the Accounting-Off message, then shuts down.

Examples The following command causes Accounting-On and Accounting-Off messages to be sent to RADIUS server group *shorebirds*:

```
WSS# set accounting system shorebirds
success: change accepted.
```

See Also

- **clear accounting** on page 166
- **show accounting statistics** on page 212

set authentication admin

Configures authentication and defines where it is performed for specified users with administrative access through Telnet or Web View.

Syntax `set authentication admin user-wildcard
method1 [method2] [method3] [method4]`

user-wildcard

Single user or set of users with administrative access over the network through Telnet or Web View.

Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character—either an *at* sign (@) or a period (.). (For details, see [“User Wildcards” on page 12.](#))

method1

method2

method3

method4

At least one of up to four methods that WSS Software uses to handle authentication. Specify one or more of the following methods in priority order. WSS Software applies multiple methods in the order you enter them.

A method can be one of the following:

- **local**—Uses the local database of usernames and user groups on the WSS for authentication.
- *server-group-name*—Uses the defined group of RADIUS servers for authentication. You can enter up to four names of existing RADIUS server groups as methods.
- **none**—*For users with administrative access only*, WSS Software performs no authentication, but prompts for a username and password and accepts any combination of entries, including blanks.

Note: The authentication method **none** you can specify for administrative access is different from the fallthru authentication type **none**, which applies only to network access. The authentication method **none** allows access to the WSS by an administrator. The fallthru authentication type **none** denies access to a network user. (See [“set service-profile auth-fallthru” on page 308.](#))

For more information, see “Usage.”

Defaults By default, authentication is deactivated for all admin users. The default authentication method in an admin authentication rule is **local**. WSS Software checks the local WSS database for authentication.

Access Enabled..



Note. The syntax descriptions for the **set authentication** commands have been separated for clarity. However, the options and behavior for the **set authentication admin** command are the same as in previous releases.

Usage You can configure different authentication methods for different groups of users. (For details, see “[User Wildcards, MAC Address Wildcards, and VLAN Wildcards](#)” on page 12.)

If you specify multiple authentication methods in the **set authentication console** command, WSS Software applies them in the order in which they appear in the command, with these results:

- If the first method responds with pass or fail, the evaluation is final.
- If the first method does not respond, WSS Software tries the second method, and so on.
- However, if **local** appears first, followed by a RADIUS server group, WSS Software ignores any failed searches in the local WSS database and sends an authentication request to the RADIUS server group.



Note. If a AAA rule specifies local as a secondary AAA method, to be used if the RADIUS servers are unavailable, and WSS Software authenticates a client with the local method, WSS Software starts again at the beginning of the method list when attempting to authorize the client. This can cause unexpected delays during client processing and can cause the client to time out before completing logon.

Examples The following command configures administrator Jose, who connects via Telnet, for authentication on RADIUS server group *sg3*:

```
WSS# set authentication admin Jose sg3
success: change accepted.
```

See Also

- [clear authentication admin on page 167](#)
- [set authentication console on page 183](#)
- [set authentication dot1x on page 185](#)
- [set authentication mac on page 189](#)
- [set authentication web on page 191](#)
- [show aaa on page 210](#)

set authentication console

Configures authentication and defines where it is performed for specified users with administrative access through a console connection.

Syntax `set authentication console user-wildcard
method1 [method2] [method3] [method4]`

user-wildcard Single user or set of users with administrative access through the switch's console.

Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character—either an *at* sign (@) or a period (.). (For details, see “[User Wildcards](#)” on page 12.)

method1
method2
method3
method4

At least one of up to four methods that WSS Software uses to handle authentication. Specify one or more of the following methods in priority order. WSS Software applies multiple methods in the order you enter them.

A method can be one of the following:

- **local**—Uses the local database of usernames and user groups on the WSS for authentication.
- *server-group-name*—Uses the defined group of RADIUS servers for authentication. You can enter up to four names of existing RADIUS server groups as methods.
- **none**—*For users with administrative access only*, WSS Software performs no authentication, but prompts for a username and password and accepts any combination of entries, including blanks.

Note: The authentication method **none** you can specify for administrative access is different from the fallthru authentication type **none**, which applies only to network access. The authentication method **none** allows access to the WSS by an administrator. The fallthru authentication type **none** denies access to a network user. (See “[set service-profile auth-fallthru](#)” on page 308.)

For more information, see “Usage.”

Defaults By default, authentication is deactivated for all console users, and the default authentication method in a console authentication rule is **none**. WSS Software requires no username or password, by default. These users can press Enter at the prompts for administrative access.



Note. Nortel recommends that you change the default setting unless the WSS is in a secure physical location.

Access Enabled..



Note. The syntax descriptions for the **set authentication** commands have been separated for clarity. However, the options and behavior for the **set authentication console** command are the same as in previous releases.

Usage You can configure different authentication methods for different groups of users. (For details, see “User Wildcards, MAC Address Wildcards, and VLAN Wildcards” on page 12.)

If you specify multiple authentication methods in the **set authentication console** command, WSS Software applies them in the order in which they appear in the command, with these results:

- If the first method responds with pass or fail, the evaluation is final.
- If the first method does not respond, WSS Software tries the second method, and so on.
- However, if **local** appears first, followed by a RADIUS server group, WSS Software ignores any failed searches in the local WSS database and sends an authentication request to the RADIUS server group.

Examples To set the console port so that it does *not* enforce username-password authentication for administrators, type the following command:

```
WSS# set authentication console * none
success: change accepted.
```

See Also

- **clear authentication console** on page 168
- **set authentication admin** on page 182
- **set authentication dot1x** on page 185
- **set authentication mac** on page 189
- **set authentication web** on page 191
- **show aaa** on page 210

set authentication dot1x

Configures authentication and defines how and where it is performed for specified wireless or wired authentication clients who use an IEEE 802.1X authentication protocol to access the network through the WSS.

Syntax **set authentication dot1x** {**ssid** *ssid-name* | **wired**} *user-wildcard* [**bonded**] *protocol method1* [*method2*] [*method3*] [*method4*]

ssid *ssid-name* SSID name to which this authentication rule applies. To apply the rule to all SSIDs, type **any**.

wired Applies this authentication rule specifically to users connected to a wired authentication port.

- user-wildcard* A single user or a set of users with 802.1X network access. Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character—either an at sign (@) or a period (.). (For details, see [“User Wildcards” on page 12.](#))
- bonded** Enables Bonded Auth™ (bonded authentication). When this feature is enabled, WSS Software authenticates the user only if the machine the user is on has already been authenticated.

protocol

Protocol used for authentication. Specify one of the following:

- **eap-md5**—Extensible Authentication Protocol (EAP) with message-digest algorithm 5. *For wired authentication clients:*
 - Uses challenge-response to compare hashes
 - Provides *no* encryption or integrity checking for the connection

Note: The **eap-md5** option does not work with Microsoft wired authentication clients.

- **eap-tls**—EAP with Transport Layer Security (TLS):
 - Provides mutual authentication, integrity-protected negotiation, and key exchange
 - Requires X.509 public key certificates on both sides of the connection
 - Provides encryption and integrity checking for the connection
 - Cannot be used with RADIUS server authentication (requires user information to be in the switch's local database)
- **peap-mschapv2**—Protected EAP (PEAP) with Microsoft Challenge Handshake Authentication Protocol version 2 (MS-CHAP-V2). *For wireless clients:*
 - Uses TLS for encryption and data integrity checking and server-side authentication
 - Provides MS-CHAP-V2 mutual authentication
 - Only the server side of the connection needs a certificate.

The wireless client authenticates using TLS to set up an encrypted session. Then MS-CHAP-V2 performs mutual authentication using the specified AAA method.

- **pass-through**—WSS Software sends all the EAP protocol processing to a RADIUS server.

method1
method2
method3
method4

At least one and up to four methods that WSS Software uses to handle authentication. Specify one or more of the following methods in priority order. WSS Software applies multiple methods in the order you enter them.

A method can be one of the following:

- **local**—Uses the local database of usernames and user groups on the WSS for authentication.
- *server-group-name*—Uses the defined group of RADIUS servers for authentication. You can enter up to four names of existing RADIUS server groups as methods.

RADIUS servers cannot be used with the EAP-TLS protocol.

For more information, see “Usage.”

Defaults By default, authentication is unconfigured for all clients with network access through AP ports or wired authentication ports on the WSS. Connection, authorization, and accounting are also disabled for these users.

Bonded authentication is disabled by default.

Access Enabled.

Usage You can configure different authentication methods for different groups of users by “wildcarding.” (For details, see “[User Wildcards](#)” on page 12.)

You can configure a rule either for wireless access to an SSID, or for wired access through a WSS’s wired authentication port. If the rule is for wireless access to an SSID, specify the SSID name or specify **any** to match on all SSID names. If the rule is for wired access, specify **wired** instead of an SSID name.

You cannot configure client authentication that uses both the EAP-TLS protocol and one or more RADIUS servers. EAP-TLS authentication is supported only on the local WSS database.

If you specify multiple authentication methods in the **set authentication dot1x** command, WSS Software applies them in the order in which they appear in the command, with these results:

- If the first method responds with pass or fail, the evaluation is final.
- If the first method does not respond, WSS Software tries the second method, and so on.
- However, if **local** appears first, followed by a RADIUS server group, WSS Software overrides any failed searches in the local WSS database and sends an authentication request to the server group.

If the user does not support 802.1X, WSS Software attempts to perform MAC authentication for the user. In this case, if the switch’s configuration contains a **set authentication mac** command that matches the SSID the user is attempting to access and the user’s MAC address, WSS Software uses the method specified by the command. Otherwise, WSS Software uses local MAC authentication by default.

If the username does not match an authentication rule for the SSID the user is attempting to access, WSS Software uses the *fallthru* authentication type configured for the SSID, which can be **last-resort**, **web-portal** (for Web-based AAA), or **none**.

Examples The following command configures EAP-TLS authentication in the local WSS database for SSID *mycorp* and 802.1X client Geetha:

```
WSS# set authentication dot1x ssid mycorp Geetha eap-tls local
success: change accepted.
```

The following command configures PEAP-MS-CHAP-V2 authentication at RADIUS server groups *sg1* through *sg3* for all 802.1X clients at *example.com* who want to access SSID *examplecorp*:

```
WSS# set authentication dot1x ssid examplecorp *@example.com peap-mschapv2
sg1 sg2 sg3
success: change accepted.
```

See Also

- **clear authentication dot1x** on page 169
- **set authentication admin** on page 182
- **set authentication console** on page 183
- **set authentication mac** on page 189
- **set authentication web** on page 191

- [set service-profile auth-fallthru on page 308](#)
- [show aaa on page 210](#)

set authentication last-resort

Deprecated in WSS Software Version 5.0. The *last-resort* user is not required or supported in WSS Software Version 5.0. Instead, a user who accesses the network on an SSID by using the fallthru access type **last-resort** is automatically a *last-resort* user. The authorization attributes assigned to the user come from the default authorization attributes set on the SSID.

set authentication mac

Configures authentication and defines where it is performed for specified non-802.1X users with network access through a media access control (MAC) address.

Syntax `set authentication mac {ssid ssid-name | wired} mac-addr-wildcard method1 [method2] [method3] [method4]`

ssid <i>ssid-name</i>	SSID name to which this authentication rule applies. To apply the rule to all SSIDs, type any .
wired	Applies this authentication rule specifically to users connected to a wired authentication port.
<i>mac-addr-wildcard</i>	A single user or set of users with access via a MAC address. Specify a MAC address, or use the wildcard (*) character to specify a set of MAC addresses. (For details, see “MAC Address Wildcards” on page 13.)
<i>method1</i>	At least one of up to four methods that WSS Software uses to handle authentication. Specify one or more of the following methods in priority order. WSS Software applies multiple methods in the order you enter them. A method can be one of the following:
<i>method2</i>	
<i>method3</i>	
<i>method4</i>	
	<ul style="list-style-type: none"> • local—Uses the local database of usernames and user groups on the WSS for authentication. • <i>server-group-name</i>—Uses the defined group of RADIUS servers for authentication. You can enter up to four names of existing RADIUS server groups as methods.
	For more information, see “Usage.”

Defaults By default, authentication is deactivated for all MAC users, which means MAC address authentication fails by default. When using RADIUS for authentication, the default well-known password for MAC and last-resort users is *nortel*.

Access Enabled.

Usage You can configure different authentication methods for different groups of MAC addresses by “wildcarding.” (For details, see [“User Wildcards, MAC Address Wildcards, and VLAN Wildcards” on page 12.](#))

If you specify multiple authentication methods in the **set authentication mac** command, WSS Software applies them in the order in which they appear in the command, with these results:

- If the first method responds with pass or fail, the evaluation is final.
- If the first method does not respond, WSS Software tries the second method, and so on.
- However, if **local** appears first, followed by a RADIUS server group, WSS Software ignores any failed searches in the local WSS database and sends an authentication request to the RADIUS server group.

If the switch’s configuration contains a **set authentication mac** command that matches the SSID the user is attempting to access and the user’s MAC address, WSS Software uses the method specified by the command. Otherwise, WSS Software uses local MAC authentication by default.

If the username does not match an authentication rule for the SSID the user is attempting to access, WSS Software uses the *fallthru* authentication type configured for the SSID, which can be **last-resort**, **web-portal** (for Web-based AAA), or **none**.

Examples To use the local WSS database to authenticate all users who access the *mycorp2* SSID by their MAC address, type the following command:

```
WSS# set authentication ssid mycorp2 mac ** local
success: change accepted.
```

See Also

- **clear authentication mac on page 170**
- **set authentication admin on page 182**
- **set authentication console on page 183**
- **set authentication dot1x on page 185**
- **set authentication web on page 191**
- **show aaa on page 210**

set authentication proxy

Configures a proxy authentication rule for a third-party AP’s wireless users.

Syntax **set authentication proxy ssid** *ssid-name* *user-wildcard* *radius-server-group*

<i>ssid</i> <i>ssid-name</i>	SSID name to which this authentication rule applies.
<i>user-wildcard</i>	A single user or a set of users. Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character—either an <i>at</i> sign (@) or a period (.). (For details, see “User Wildcards” on page 12.)
<i>radius-server-group</i>	A group of RADIUS servers used for authentication.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.0.

Usage AAA for third-party AP users has additional configuration requirements. See the “Configuring AAA for Users of Third-Party APs” section in the “Configuring AAA for Network Users” chapter of the *Nortel WLAN Security Switch 2300 Series Configuration Guide*.

Examples The following command configures a proxy authentication rule that matches on all usernames associated with SSID *mycorp*. WSS Software uses RADIUS server group *svrgrp1* to proxy RADIUS requests and hence to authenticate and authorize the users.

```
WSS# set authentication proxy ssid mycorp ** svrgrp1
```

See Also

- [clear authentication proxy on page 170](#)
- [set radius proxy client on page 489](#)
- [set radius proxy port on page 489](#)

set authentication web

Configures an authentication rule to allow a user to log in to the network using a web page served by the WSS. The rule can be activated if the user is not otherwise granted or denied access by 802.1X, or granted access by MAC authentication.

```
Syntax set authentication web {ssid ssid-name | wired} user-wildcard  
method1 [method2] [method3] [method4]
```

<i>user-wildcard</i>	A single user or a set of users. Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character—either an at sign (@) or a period (.). (For details, see “ User Wildcards ” on page 12.)
ssid <i>ssid-name</i>	SSID name to which this authentication rule applies. To apply the rule to all SSIDs, type any .

wired Applies this authentication rule specifically to users connected to a wired authentication port.

method1
method2
method3
method4 At least one and up to four methods that WSS Software uses to handle authentication. Specify one or more of the following methods in priority order. WSS Software applies multiple methods in the order you enter them. A method can be one of the following:

- **local**—Uses the local database of usernames and user groups on the WSS for authentication.
- *server-group-name*—Uses the defined group of RADIUS servers for authentication. You can enter up to four names of existing RADIUS server groups as methods.
RADIUS servers cannot be used with the EAP-TLS protocol.

For more information, see “Usage.”

Defaults By default, authentication is unconfigured for all clients with network access through AP ports or wired authentication ports on the WSS. Connection, authorization, and accounting are also disabled for these users.

Access Enabled.

Usage You can configure different authentication methods for different groups of users by “wildcarding.” (For details, see “User Wildcards” on page 12.)

You can configure a rule either for wireless access to an SSID, or for wired access through a WSS’s wired authentication port. If the rule is for wireless access to an SSID, specify the SSID name or specify **any** to match on all SSID names. If the rule is for wired access, specify **wired** instead of an SSID name.

If you specify multiple authentication methods in the **set authentication web** command, WSS Software applies them in the order in which they appear in the command, with these results:

- If the first method responds with pass or fail, the evaluation is final.
- If the first method does not respond, WSS Software tries the second method, and so on.
- However, if **local** appears first, followed by a RADIUS server group, WSS Software overrides any failed searches in the local WSS database and sends an authentication request to the server group.

WSS Software uses a Web-based AAA rule only under the following conditions:

- The client is not denied access by 802.1X or does not support 802.1X.
- The client’s MAC address does not match a MAC authentication rule.
- The fallthru type is **web-portal**. (For a wireless authentication rule, the fallthru type is specified by the **set service-profile auth-fallthru** command. For a wired authentication rule, the type is specified by the **auth-fall-thru** option of the **set port type wired-auth** command.)

Examples The following command configures a Web-based AAA rule in the local WSS database for SSID *ourcorp* and userwildcard *rnd**:

```
WSS# set authentication web ssid ourcorp rnd* local
success: change accepted.
```

See Also

- **clear authentication web on page 171**

- **set authentication admin** on page 182
- **set authentication console** on page 183
- **set authentication dot1x** on page 185
- **show aaa** on page 210

set location policy

Creates and enables a location policy on a WSS. A location policy enables you to locally set or change authorization attributes for a user after the user is authorized by AAA, without making changes to the AAA server.

Syntax **set location policy deny if** {**ssid operator ssid-name** | **vlan operator vlan-wildcard** | **user operator user-wildcard** | **port port-list** | **ap ap-num**} [**before rule-number** | **modify rule-number**]

Syntax **set location policy permit** {**vlan vlan-name** | **inacl inacl-name** | **outacl outacl-name**} **if** {**ssid operator ssid-name** | **vlan operator vlan-wildcard** | **user operator user-wildcard** | **port port-list** | **ap ap-num**} [**before rule-number** | **modify rule-number**]

deny Denies access to the network to users with characteristics that match the location policy rule.

permit Allows access to the network or to a specified VLAN, and/or assigns a particular security ACL to users with characteristics that match the location policy rule.

Action options—For a permit rule, WSS Software changes the attributes assigned to the user to the values specified by the following options:

vlan *vlan-name* Name of an existing VLAN to assign to users with characteristics that match the location policy rule.

inacl *inacl-name* Name of an existing security ACL to apply to packets *sent to* the WSS with characteristics that match the location policy rule. Optionally, you can add the suffix **.in** to the name.

outacl *outacl-name* Name of an existing security ACL to apply to packets *sent from* the WSS with characteristics that match the location policy rule. Optionally, you can add the suffix **.out** to the name.

Condition options—WSS Software takes the action specified by the rule if all conditions in the rule are met. You can specify one or more of the following conditions:

ssid operator ssid-name SSID with which the user is associated. The *operator* must be **eq**, which applies the location policy rule to all users associated with the SSID. Asterisks (wildcards) are not supported in SSID names. You must specify the complete SSID name.

vlan <i>operator vlan-wildcard</i>	<p>VLAN-Name attribute assigned by AAA and condition by which to determine if the location policy rule applies. Replace <i>operator</i> with one of the following operands:</p> <ul style="list-style-type: none">• eq—Applies the location policy rule to all users assigned VLAN names matching <i>vlan-wildcard</i>.• neq—Applies the location policy rule to all users assigned VLAN names <i>not</i> matching <i>vlan-wildcard</i>. <p>For <i>vlan-wildcard</i>, specify a VLAN name, use the double-asterisk wildcard character (**) to specify all VLAN names, or use the single-asterisk wildcard character (*) to specify a set of VLAN names up to or following the first delimiter character, either an <i>at</i> sign (@) or a period (.). (For details, see “VLAN Wildcards” on page 13.)</p>
user <i>operator user-wildcard</i>	<p>Username and condition by which to determine if the location policy rule applies. Replace <i>operator</i> with one of the following operands:</p> <ul style="list-style-type: none">• eq—Applies the location policy rule to all usernames matching <i>user-wildcard</i>.• neq—Applies the location policy rule to all usernames <i>not</i> matching <i>user-wildcard</i>. <p>For <i>user-wildcard</i>, specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character, either an <i>at</i> sign (@) or a period (.). (For details, see “User Wildcards” on page 12.)</p>
before <i>rule-number</i>	<p>Inserts the new location policy rule in front of another rule in the location policy. Specify the number of the existing location policy rule. (To determine the number, use the show location policy command.)</p>
modify <i>rule-number</i>	<p>Replaces the rule in the location policy with the new rule. Specify the number of the existing location policy rule. (To determine the number, use the show location policy command.)</p>
port <i>port-list</i>	<p>List of physical port(s) by which to determine if the location policy rule applies.</p>

Defaults By default, users are permitted VLAN access and assigned security ACLs according to the VLAN-Name and Filter-Id attributes applied to the users during normal authentication and authorization.

Access Enabled.

Usage Only a single location policy is allowed per WSS. The location policy can contain up to 150 rules. Once configured, the location policy becomes effective immediately. To disable location policy operation, use the **clear location policy** command.

Conditions within a rule are ANDed. All conditions in the rule must match in order for WSS Software to take the specified action. If the location policy contains multiple rules, WSS Software compares the user information to the rules one at a time, in the order the rules appear in the switch’s configuration file, beginning with the rule at the top of the list. WSS Software continues comparing until a user matches all conditions in a rule or until there are no more rules.

The order of rules in the location policy is important to ensure users are properly granted or denied access. To position rules within the location policy, use **before rule-number** and **modify rule-number** in the **set location policy** command, and the **clear location policy rule-number** command.

When applying security ACLs:

- Use **inacl** *inacl-name* to filter traffic that enters the switch from users via an AP access port or wired authentication port, or from the network via a network port.
- Use **outacl** *outacl-name* to filter traffic sent from the switch to users via an AP access port or wired authentication port, or from the network via a network port.
- You can optionally add the suffixes **.in** and **.out** to *inacl-name* and *outacl-name* so that they match the names of security ACLs stored in the local WSS database.

Examples The following command denies network access to all users at *.theirfirm.com, causing them to fail authorization:

```
WSS# set location policy deny if user eq *.theirfirm.com
```

The following command authorizes access to the *guest_1* VLAN for all users who are not at *.wodefirm.com:

```
WSS# set location policy permit vlan guest_1 if user neq *.wodefirm.com
```

The following command authorizes users at *.ny.ourfirm.com to access the *bld4.tac* VLAN instead, and applies the security ACL *tac_24* to the traffic they receive:

```
WSS# set location policy permit vlan bld4.tac outacl tac_24 if user eq *.ny.ourfirm.com
```

The following command authorizes access to users on VLANs with names matching *bld4.** and applies security ACLs *svcs_2* to the traffic they send and *svcs_3* to the traffic they receive:

```
WSS# set location policy permit inacl svcs_2 outacl svcs_3 if vlan eq bldg4.*
```

The following command authorizes users entering the network on WSS ports 3 through 7 and port 12 to use the *floor2* VLAN, overriding any settings from AAA:

```
WSS# set location policy permit vlan floor2 if port 3-7,12
```

The following command places all users who are authorized for SSID *tempvendor_a* into VLAN *kiosk_1*:

```
WSS# set location policy permit vlan kiosk_1 if ssid eq tempvendor_a  
success: change accepted.
```

See Also

- **clear location policy on page 171**
- **show location policy on page 215**

set mac-user

Configures a user profile in the local database on the WSS for a user who can be authenticated by a MAC address, and optionally adds the user to a MAC user group.

(To configure a MAC user profile in RADIUS, see the documentation for your RADIUS server.)

Syntax `set mac-user mac-addr [group group-name]`

mac-addr MAC address of the user, in hexadecimal numbers separated by colons (:).
You can omit leading zeros.

group-name Name of an existing MAC user group.

Defaults None.

Access Enabled.

Usage WSS Software does not require MAC users to belong to user groups.

Users authenticated by MAC address can be authenticated only for network access through the WSS. WSS Software does not support passwords for MAC users.

Examples The following command creates a user profile for a user at MAC address 01:02:03:04:05:06 and assigns the user to the *eastcoasters* user group:

```
WSS# set mac-user 01:02:03:04:05:06 group eastcoasters
success: change accepted.
```

See Also

- **clear mac-user on page 172**
- **show aaa on page 210**

set mac-user attr

Assigns an authorization attribute in the local database on the WSS to a user who is authenticated by a MAC address.

(To assign authorization attributes through RADIUS, see the documentation for your RADIUS server.)

Syntax `set mac-user mac-addr attr attribute-name value`

<i>mac-addr</i>	MAC address of the user, in hexadecimal numbers separated by colons (:). You can omit leading zeros.
<i>attribute-name value</i>	Name and value of an attribute you are using to authorize the MAC user for a particular service or session characteristic. For a list of authorization attributes and values that you can assign to local users, see Table 29 on page 198 .

Defaults None.

Access Enabled.

History

WSS Software Version 5.0	Authorization attribute acct-interim-interval added
-----------------------------	--

Usage To change the value of an attribute, enter `set mac-user attr` with the new value. To delete an attribute, use `clear mac-user attr`.

You can assign attributes to individual MAC users and to MAC user groups. If attributes are configured for a MAC user and also for the group the MAC user is in, the attributes assigned to the individual MAC user take precedence for that user. For example, if the start-date attribute configured for a MAC user is sooner than the start-date configured for the MAC user group the user is in, the MAC user's network access can begin as soon as the user start-date. The MAC user does not need to wait for the MAC user group's start date.

Table 1: Authentication Attributes for Local Users

Attribute	Description	Valid Value(s)
encryption-type	<p>Type of encryption required for access by the client. Clients who attempt to use an unauthorized encryption method are rejected.</p> <p>Note: Encryption-Type is a Nortel vendor-specific attribute (VSA). The vendor ID is 562, and the vendor type is 233.</p>	<p>One of the following numbers that identifies an encryption algorithm:</p> <ul style="list-style-type: none"> • 1—AES_CCM (Advanced Encryption Standard using Counter with CBC-MAC) • 2—Reserved • 4—TKIP (Temporal Key Integrity Protocol) • 8—WEP_104 (the default) (Wired-Equivalent Privacy protocol using 104 bits of key strength) • 16—WEP_40 (Wired-Equivalent Privacy protocol using 40 bits of key strength) • 32—NONE (no encryption) • 64—Static WEP <p>In addition to these values, you can specify a sum of them for a combination of allowed encryption types. For example, to specify WEP_104 and WEP_40, use 24.</p>
end-date	<p>Date and time after which the user is no longer allowed to be on the network.</p>	<p>Date and time, in the following format: YY/MM/DD-HH:MM</p> <p>You can use end-date alone or with start-date. You also can use start-date, end-date, or both in conjunction with time-of-day.</p>

Table 1: Authentication Attributes for Local Users (continued)

Attribute	Description	Valid Value(s)
filter-id (network access mode only)	Security access control list (ACL), to permit or deny traffic received (input) or sent (output) by the WSS. (For more information about security ACLs, see “Security ACL Commands” on page 449.)	Name of an existing security ACL, up to 253 alphanumeric characters, with no tabs or spaces. <ul style="list-style-type: none"> Use <i>acl-name.in</i> to filter traffic that enters the switch <i>from users</i> via an AP access port or wired authentication port, or from the network via a network port. Use <i>acl-name.out</i> to filter traffic sent from the switch <i>to users</i> via an AP access port or wired authentication port, or from the network via a network port. <p>Note: If the Filter-Id value returned through the authentication and authorization process does not match the name of a committed security ACL in the WSS, the user fails authorization and is unable to authenticate.</p>
idle-timeout	This option is not implemented in the current WSS Software version.	
mobility-profile (network access mode only)	Mobility Profile attribute for the user. (For more information, see set mobility-profile on page 204 .) Note: Mobility-Profile is a Nortel vendor-specific attribute (VSA). The vendor ID is 562, and the vendor type is 232.	Name of an existing Mobility Profile, which can be up to 32 alphanumeric characters, with no tabs or spaces. Note: If the Mobility Profile feature is enabled, and a user is assigned the name of a Mobility Profile that does not exist on the WSS, the user is denied access.

Table 1: Authentication Attributes for Local Users (continued)

Attribute	Description	Valid Value(s)
service-type	Type of access the user is requesting.	<p>One of the following numbers:</p> <ul style="list-style-type: none"> • 2—Framed; for network user access • 6—Administrative; for administrative access to the WSS, with authorization to access the enabled (configuration) mode. The user must enter the enable command and the correct enable password to access the enabled mode. • 7—NAS-Prompt; for administrative access to the nonenabled mode only. In this mode, the user can still enter the enable command and the correct enable password to access the enabled mode. <p>For administrative sessions, the WSS always sends 6 (Administrative). The RADIUS server can reply with one of the values listed above. If the service-type is not set on the RADIUS server, administrative users receive NAS-Prompt access, and network users receive Framed access.</p>
session-timeout (network access mode only)	Maximum number of seconds for the user's session.	<p>Number between 0 and 4,294,967,296 seconds (approximately 136.2 years).</p> <p>Note. If the global reauthentication timeout (set by the set dot1x reauth-period command) is shorter than the session-timeout, WSS Software uses the global timeout instead.</p>
ssid (network access mode only)	SSID the user is allowed to access after authentication.	Name of the SSID you want the user to use. The SSID must be configured in a service profile, and the service profile must be used by a radio profile assigned to Nortel radios in the Mobility Domain.
start-date	Date and time at which the user becomes eligible to access the network. WSS Software does not authenticate the user unless the attempt to access the network occurs at or after the specified date and time, but before the end-date (if specified).	Date and time, in the following format: YY/MM/DD-HH:MM You can use start-date alone or with end-date . You also can use start-date , end-date , or both in conjunction with time-of-day .

Table 1: Authentication Attributes for Local Users (continued)

Attribute	Description	Valid Value(s)
time-of-day (network access mode only)	Day(s) and time(s) during which the user is permitted to log into the network. After authorization, the user's session can last until either the Time-Of-Day range or the Session-Timeout duration (if set) expires, whichever is shorter. Note: Time-Of-Day is a Nortel vendor-specific attribute (VSA). The vendor ID is 562, and the vendor type is 234.	One of the following: <ul style="list-style-type: none"> • never—Access is always denied. • any—Access is always allowed. • al—Access is always allowed. • One or more ranges of values that consist of one of the following day designations (required), and a time range in <i>hhmm-hhmm</i> 4-digit 24-hour format (optional): <ul style="list-style-type: none"> • mo—Monday • tu—Tuesday • we—Wednesday • th—Thursday • fr—Friday • sa—Saturday • su—Sunday • wk—Any day between Monday and Friday <p>Separate values or a series of ranges (except time ranges) with commas (,) or a vertical bar (). Do not use spaces.</p> <p>The maximum number of characters is 253.</p> <p>For example, to allow access only on Tuesdays and Thursdays between 10 a.m. and 4 p.m., specify the following: time-of-day tu1000-1600,th1000-1600</p>
time-of-day (network access mode only) (cont.)		To allow access only on weekdays between 9 a.m and 5 p.m., and on Saturdays from 10 p.m. until 2 a.m., specify the following: time-of-day wk0900-1700,sa2200-0200 (Also see the examples for set user attr on page 207.) Note: You can use time-of-day in conjunction with start-date , end-date , or both.

Table 1: Authentication Attributes for Local Users (continued)

Attribute	Description	Valid Value(s)
url (network access mode only)	URL to which the user is redirected after successful Web-based AAA.	<p>Web URL, in standard format. For example: <code>http://www.example.com</code></p> <p>Note: You must include the <code>http://</code> portion.</p> <p>You can dynamically include any of the variables in the URL string:</p> <ul style="list-style-type: none"> • \$u—Username • \$v—VLAN • \$s—SSID • \$p—Service profile name <p>To use the literal character <code>\$</code> or <code>?</code>, use the following:</p> <ul style="list-style-type: none"> • \$\$ • \$q
vlan-name (network access mode only)	<p>Virtual LAN (VLAN) assignment.</p> <p>Note: VLAN-Name is a Nortel vendor-specific attribute (VSA). The vendor ID is 562, and the vendor type is 231.</p> <p>Note: On some RADIUS servers, you might need to use the standard RADIUS attribute Tunnel-Pvt-Group-ID, instead of VLAN-Name.</p>	<p>Name of a VLAN that you want the user to use. The VLAN must be configured on a WSS within the Mobility Domain to which this WSS belongs.</p>
acct-interim-interval	Interval in seconds between accounting updates, if start-stop accounting mode is enabled.	<p>Number between 180 and 3,600 seconds, or 0 to disable periodic accounting updates.</p> <p>The WSS ignores the <code>acct-interim-interval</code> value and issues a log message if the value is below 60 seconds.</p> <p>Note: If both a RADIUS server and the WSS supply a value for the <code>acct-interim-interval</code> attribute, then the value from the WSS takes precedence.</p>

Examples The following command assigns input access control list (ACL) `acl-03` to filter the packets from a user at MAC address `01:02:03:04:05:06`:

```
WSS# set mac-user 01:02:03:04:05:06 attr filter-id acl-03.in
success: change accepted.
```

The following command restricts a user at MAC address 06:05:04:03:02:01 to network access between 7 p.m. on Mondays and Wednesdays and 7 a.m. on Tuesdays and Thursdays:

```
WSS# set mac-user 06:05:04:03:02:01 attr time-of-day mo1900-1159,tu0000-0700,we1900-1159,th0000-0700
success: change accepted.
```

See Also

- [clear mac-user attr on page 172](#)
- [show aaa on page 210](#)

set mac-usergroup attr

Creates a user group in the local database on the WSS for users who are authenticated by a MAC address, and assigns authorization attributes for the group.

(To configure a user group and assign authorization attributes through RADIUS, see the documentation for your RADIUS server.)

Syntax `set mac-usergroup group-name attr attribute-name value`

<i>group-name</i>	Name of a MAC user group. Specify a name of up to 32 alphanumeric characters, with no spaces. The name must begin with an alphabetic character.
<i>attribute-name value</i>	Name and value of an attribute you are using to authorize all MAC users in the group for a particular service or session characteristic. (For a list of authorization attributes, see Table 29 on page 198 .)

Defaults None.

Access Enabled.

Usage To change the value of an attribute, enter `set mac-usergroup attr` with the new value. To delete an attribute, use `clear mac-usergroup attr`.

You can assign attributes to individual MAC users and to MAC user groups. If attributes are configured for a MAC user and also for the group the MAC user is in, the attributes assigned to the individual MAC user take precedence for that user. For example, if the start-date attribute configured for a MAC user is sooner than the start-date configured for the MAC user group the user is in, the MAC user's network access can begin as soon as the user start-date. The MAC user does not need to wait for the MAC user group's start date.

Examples The following command creates the MAC user group *eastcoasters* and assigns the group members to VLAN *orange*:

```
WSS# set mac-usergroup eastcoasters attr vlan-name orange
success: change accepted.
```

See Also

- [clear mac-usergroup attr on page 174](#)

- [show aaa on page 210](#)

set mobility-profile

Creates a Mobility Profile and specifies the AP and/or wired authentication ports on the WSS through which any user assigned to the profile is allowed access.

Syntax `set mobility-profile name name`
`{port {none | all | port-list}} | {ap {none | all | ap-num}}`

<i>name</i>	Name of the Mobility Profile. Specify up to 32 alphanumeric characters, with no spaces.
none	Prevents any user to whom this profile is assigned from accessing any AP or wired authentication port on the WSS.
all	Allows any user to whom this profile is assigned to access all AP access ports and wired authentication port on the WSS.
<i>port-list</i>	List of AP access ports or wired authentication ports through which any user assigned this profile is allowed access. The same port can be used in multiple Mobility Profile port lists.
<i>ap-num</i>	List of AP connections through which any user assigned this profile is allowed access. The same AP can be used in multiple Mobility Profile port lists.

Defaults No default Mobility Profile exists on the WSS. If you do not assign Mobility Profile attributes, all users have access through all ports, unless denied access by other AAA servers or by access control lists (ACLs).

Access Enabled.

Usage To assign a Mobility Profile to a user or group, specify it as an authorization attribute in one of the following commands:

- `set user attr mobility-profile name`
- `set usergroup attr mobility-profile name`
- `set mac-user attr mobility-profile name`
- `set mac-usergroup attr mobility-profile name`

To enable the use of the Mobility Profile feature on the WSS, use the `set mobility-profile mode` command.



Caution! When the Mobility Profile feature is enabled, a user is denied access if assigned a Mobility-Profile attribute in the local WSS database or RADIUS server when no Mobility Profile of that name exists on the WSS.

To change the ports in a profile, use `set mobility-profile` again with the updated port list.

Examples The following commands create the Mobility Profile *magnolia*, which restricts user access to port 12; enable the Mobility Profile feature on the WSS; and assign the *magnolia* Mobility Profile to user *Jose*.

WSS# set mobility-profile name magnolia port 12

success: change accepted.

WSS# set mobility-profile mode enable

success: change accepted.

WSS# set user Jose attr mobility-profile magnolia

success: change accepted.

The following command adds port 13 to the *magnolia* Mobility Profile (which is already assigned to port 12):

WSS# set mobility-profile name magnolia port 12-13

success: change accepted.

See Also

- **clear mobility-profile on page 175**
- **set mac-user attr on page 197**
- **set mac-usergroup attr on page 203**
- **set mobility-profile mode on page 205**
- **set user attr on page 207**
- **set usergroup on page 208**
- **show mobility-profile on page 215**

set mobility-profile mode

Enables or disables the Mobility Profile feature on the WSS.



Caution! When the Mobility Profile feature is enabled, a user is denied access if assigned a Mobility-Profile attribute in the local WSS database or RADIUS server when no Mobility Profile of that name exists on the WSS.

Syntax `set mobility-profile mode {enable | disable}`

enable Enables the use of the Mobility Profile feature on the WSS.

disable Specifies that all Mobility Profile attributes are ignored by the WSS.

Defaults The Mobility Profile feature is disabled by default.

Access Enabled.

Examples To enable the use of the Mobility Profile feature, type the following command:

WSS# set mobility-profile mode enable

success: change accepted.

See Also

- **clear mobility-profile on page 175**
- **set mobility-profile on page 204**
- **show mobility-profile on page 215**

set user

Configures a user profile in the local database on the WSS for a user with a password.

(To configure a user profile in RADIUS, see the documentation for your RADIUS server.)

Syntax `set user username password [encrypted] string`

<i>username</i>	Username of a user with a password.
encrypted	Indicates that the password string you entered is already in its encrypted form. If you use this option, WSS Software does not encrypt the displayed form of the password string, and instead displays the string exactly as you entered it. If you omit this option, WSS Software does encrypt the displayed form of the string.
password <i>string</i>	Password of up to 32 alphanumeric characters, with no spaces.

Defaults None.

Access Enabled.

Usage The **show config** command shows the **encrypted** option with this command, even when you omit the option. The **encrypted** option appears in the configuration because WSS Software automatically encrypts the password when you create the user (unless you use the **encrypted** option when you enter the password).

Although WSS Software allows you to configure a user password for the special “last-resort” guest user, the password has no effect. Last-resort users can never access a WSS in administrative mode and never require a password.

The only valid username of the form *last-resort-** is *last-resort-wired*. The *last-resort-wired* user allows last-resort access on a wired authentication port.

Examples The following command creates a user profile for user Nin in the local database, and assigns the password *goody*:

```
WSS# set user Nin password goody
success: User Nin created
```

The following command assigns the password *chey3nne* to the **admin** user:

```
WSS# set user admin password chey3nne
success: User admin created
```


The following command changes Nin's password from *goody* to *29Jan04*:

```
WSS# set user Nin password 29Jan04
```

See Also

- [clear user on page 175](#)
- [show aaa on page 210](#)

set user attr

Configures an authorization attribute in the local database on the WSS for a user with a password.

(To assign authorization attributes in RADIUS, see the documentation for your RADIUS server.)

```
Syntax set user username attr attribute-name value
```

<i>username</i>	Username of a user with a password.
<i>attribute-name value</i>	Name and value of an attribute you are using to authorize the user for a particular service or session characteristic. For a list of authorization attributes and values that you can assign to network users, see Table 29 on page 198 .

Defaults None.

Access Enabled.

Usage To change the value of an attribute, enter **set user attr** with the new value. To delete an attribute, use **clear user attr**.

You can assign attributes to individual users and to user groups. If attributes are configured for a user and also for the group the user is in, the attributes assigned to the individual user take precedence for that user. For example, if the start-date attribute configured for a user is sooner than the start-date configured for the user group the user is in, the user's network access can begin as soon as the user start-date. The user does not need to wait for the user group's start date.

Examples The following command assigns user Tamara to VLAN *orange*:

```
WSS# set user Tamara attr vlan-name orange
success: change accepted.
```

The following command assigns Tamara to the Mobility Profile *tulip*.

```
WSS# set user Tamara attr mobility-profile tulip
success: change accepted.
```

The following command limits the days and times when user Student1 can access the network, to 5 p.m. to 2 a.m. every weekday, and all day Saturday and Sunday:

```
WSS# set user Student1 attr time-of-day Wk1700-0200,Sa,Su
success: change accepted.
```

See Also

- **clear user attr** on page 176
- **show aaa** on page 210

set user group

Adds a user to a user group. The user must have a password and a profile that exists in the local database on the WSS.

(To configure a user in RADIUS, see the documentation for your RADIUS server.)

Syntax `set user username group group-name`

username

Username of a user with a password.

group-name

Name of an existing user group for password users.

Defaults None.

Access Enabled.

Usage WSS Software does not require users to belong to user groups.

To *create* a user group, use the command **set usergroup**.

Examples The following command adds user Hosni to the *cardiology* user group:

```
WSS# set user Hosni group cardiology
```

```
success: change accepted.
```

See Also

- **clear user group** on page 177
- **show aaa** on page 210

set usergroup

Creates a user group in the local database on the WSS for users and assigns authorization attributes for the group.

(To create user groups and assign authorization attributes in RADIUS, see the documentation for your RADIUS server.)

Syntax `set usergroup group-name attr attribute-name value`

<i>group-name</i>	Name of a group for password users. Specify a name of up to 32 alphanumeric characters, with no spaces. The name must begin with an alphabetic character.
<i>attribute-name value</i>	Name and value of an attribute you are using to authorize all users in the group for a particular service or session characteristic. For a list of authorization attributes and values that you can assign to users, see Table 29 on page 198 .

Defaults None.

Access Enabled.

Usage To change the value of an attribute, enter `set usergroup attr` with the new value. To delete an attribute, use `clear usergroup attr`.

To *add* a user to a group, use the command `set user group`.

You can assign attributes to individual users and to user groups. If attributes are configured for a user and also for the group the user is in, the attributes assigned to the individual user take precedence for that user. For example, if the start-date attribute configured for a user is sooner than the start-date configured for the user group the user is in, the user's network access can begin as soon as the user start-date. The user does not need to wait for the user group's start date.

Examples The following command adds the user group *cardiology* to the local database and assigns all the group members to VLAN *crimson*:

```
WSS# set usergroup cardiology attr vlan-name crimson
success: change accepted.
```

See Also

- `clear usergroup` on page 177
- `clear usergroup attr` on page 178
- `show aaa` on page 210

set web-portal

Globally enables or disables Web-based AAA on a WSS.

Syntax `set web-portal {enable | disable}`

enable	Enables Web-based AAA on the switch.
disable	Disables Web-based AAA on the switch.

Defaults Enabled.

Access Enabled.

History

Version 4.0 Command name changed from **set web-aaa** to **set web-portal**, to match change to portal-based implementation.

Usage This command disables or reenables support for Web-based AAA. However, Web-based AAA has additional configuration requirements. For information, see the “Configuring AAA for Network Users” chapter in the *Nortel WLAN Security Switch 2300 Series Configuration Guide*.

Examples To disable Web-based AAA, type the following command:

```
WSS# set web-portal disable
success: change accepted.
```

See Also

- **clear authentication web on page 171**
- **set service-profile auth-fallthru on page 308**
- **set user on page 206**

show aaa

Displays all current AAA settings.

Syntax **show aaa**

Defaults None.

Access Enabled.

History

Version 4.0 Web Portal section added, to indicate the state of the Web-based AAA feature

Examples To display all current AAA settings, type the following command:

```
WSS# show aaa
```

Default Values

```
authport=1812 acctport=1813 timeout=5 acct-timeout=5
retrans=3 deadtime=0 key=(null) author-pass=(null)
```

Radius Servers

Server	Addr	Ports	T/o	Tries	Dead	State
rs-3	198.162.1.1	1821 1813	5	3	0	UP
rs-4	198.168.1.2	1821 1813	77	11	2	UP
rs-5	198.162.1.3	1821 1813	42	23	0	UP

Server groups

```
sg1: rs-3
sg2: rs-4
```

```
sg3: rs-5
```

Web Portal:
enabled

```
set authentication admin Jose sg3
set authentication console * none
set authentication mac ssid mycorp * local
set authentication dot1x ssid mycorp Geetha eap-tls
set authentication dot1x ssid mycorp * peap-mschapv2 sg1 sg2 sg3
set authentication dot1x ssid any ** peap-mschapv2 sg1 sg2 sg3
set accounting dot1x Nin ssid mycorp stop-only sg2
set accounting admin Natasha start-stop local
```

user Nin

```
Password = 082c6c64060b (encrypted)
Filter-Id = acl-999.in
Filter-Id = acl-999.out
```

mac-user 01:02:03:04:05:06

usergroup eastcoasters

```
session-timeout = 99
```

Table 30 describes the fields that can appear in **show aaa** output.

Table 2: show aaa Output

Field	Description
Default Values	RADIUS default values for all parameters.
authport	UDP port on the WSS for transmission of RADIUS authorization and authentication messages. The default port is 1812.
acctport	UDP port on the WSS for transmission of RADIUS accounting records. The default is port 1813.
timeout	Number of seconds the WSS waits for a RADIUS server to respond before retransmitting. The default is 5 seconds.
acct-timeout	Number of seconds the WSS waits for a RADIUS server to respond to an accounting request before retransmitting. The default is 5 seconds.
retrans	Number of times the WSS retransmits a message before determining a RADIUS server unresponsive. The default is 3 times.
deadtime	Number of minutes the WSS waits after determining a RADIUS server is unresponsive before trying to reconnect with this server. During the dead time, the RADIUS server is ignored by the WSS. The default is 0 minutes.
key	Shared secret key, or password, used to authenticate to a RADIUS server. The default is no key (null).

Table 2: show aaa Output (continued)

Field	Description
author-pass	Password used for authorization to a RADIUS server for MAC authentication. The client's MAC address is sent as the username and the author-pass string is sent as the password.
Radius Servers	Information about active RADIUS servers.
Server	Name of each RADIUS server currently active.
Addr	IP address of each RADIUS server currently active.
Ports	UDP ports that the WSS uses for authentication messages and for accounting records.
T/o	Setting of timeouts on each RADIUS server currently active.
Tries	Number of retransmissions configured for each RADIUS server currently active. The default is 3 times.
Dead	Length of time until the server is considered responsive again.
State	Current state of each RADIUS server currently active: <ul style="list-style-type: none">• UP (operating)• DOWN (unavailable)
Server groups	Names of RADIUS server groups and member servers configured on the WSS.
Web Portal	State of the Web-based AAA feature: <ul style="list-style-type: none">• enabled• disabled
set commands	List of commands used to configure AAA on the WSS.
user and user group profiles	List of user and user group profiles stored in the local database on the WSS.

See Also

- **set accounting {admin | console} on page 178**
- **set authentication admin on page 182**
- **set authentication console on page 183**
- **set authentication dot1x on page 185**
- **set authentication mac on page 189**
- **set authentication web on page 191**

show accounting statistics

Displays the AAA accounting records for wireless users. The records are stored in the local database on the WSS.

(To display RADIUS accounting records, see the documentation for your RADIUS server.)

Syntax `show accounting statistics`**Defaults** None.**Access** Enabled.**History**

Version 4.1 Formatting of output enhanced for readability

Examples To display the locally stored accounting records, type the following command:**WSS# show accounting statistics**

```

Dec 14 00:39:48
Acct-Status-Type=STOP
Acct-Authentic=0
Acct-Multi-Session-Id=SESS-3-01f82f-520236-24bb1223
Acct-Session-Id=SESS-3-01f82f-520236-24bb1223
User-Name=vineet
AAA_ACCT_SVC_ATTR=2
Acct-Session-Time=551
Event-Timestamp=1134520788
Acct-Output-Octets=3204
Acct-Input-Octets=1691
Acct-Output-Packets=20
Acct-Input-Packets=19
AAA_VLAN_NAME_ATTR=default
Calling-Station-Id=00-06-25-12-06-38
Nas-Port-Id=3/1
Called-Station-Id=00-0B-0E-00-CC-01
AAA_SSID_ATTR=vineet-dot1x

Dec 14 00:39:53
Acct-Status-Type=START
Acct-Authentic=0
User-Name=vineet
Acct-Multi-Session-Id=SESS-4-01f82f-520793-bd779517
Acct-Session-Id=SESS-4-01f82f-520793-bd779517
Event-Timestamp=1134520793
AAA_ACCT_SVC_ATTR=2
AAA_VLAN_NAME_ATTR=default
Calling-Station-Id=00-06-25-12-06-38
Nas-Port-Id=3/1
Called-Station-Id=00-0B-0E-00-CC-01
AAA_SSID_ATTR=vineet-dot1x

```

[Table 31](#) describes the fields that can appear in `show accounting statistics` output.

Table 3: show accounting statistics Output

Field	Description
Date and time	Date and time of the accounting record.
Acct-Status-Type	Type of accounting record: <ul style="list-style-type: none">• START• STOP• UPDATE
Acct-Authentic	Location where the user was authenticated (if authentication took place) for the session: <ul style="list-style-type: none">• 1—RADIUS server• 2—Local WSS database
User-Name	Username of a user with a password.
Acct-Multi-Session-Id	Unique accounting ID for multiple related sessions in a log file.
AAA_TTY_ATTR	For sessions conducted through a console or administrative Telnet connection, the Telnet terminal number.
Event-Timestamp	Time (in seconds since January 1, 1970) at which the event was triggered. (See RFC 2869 for more information.)
Acct-Session-Time	Number of seconds that the session has been online.
Acct-Output-Octets	Number of octets the WSS has sent during the session.
Acct-Input-Octets	Number of octets the WSS has received during the session.
Acct-Output-Packets	Number of packets the WSS has sent during the session.
Acct-Input-Packets	Number of packets the WSS has received during the session.
Vlan-Name	Name of the client's VLAN.
Calling-Station-Id	MAC address of the supplicant (client).
Nas-Port-Id	Number of the port and radio on the AP through which the session was conducted.
Called-Station-Id	MAC address of the AP through which the client reached the network.

See Also

- **clear accounting on page 166**
- **set accounting {admin | console} on page 178**
- **show aaa on page 210**

show location policy

Displays the list of location policy rules that make up the location policy on a WSS.

Syntax `show location policy`

Defaults None.

Access Enabled.

Examples The following command displays the list of location policy rules in the location policy on a WSS:

WSS# show location policy

Id Clauses

```
-----
1) deny if user eq *.theirfirm.com
2) permit vlan guest_1 if vlan neq *.wodefirm.com
3) permit vlan bld4.tac inacl tac_24.in if user eq *.ny.wodefirm.com
```

See Also

- [clear location policy on page 171](#)
- [set location policy on page 193](#)

show mobility-profile

Displays the named Mobility Profile. If you do not specify a Mobility Profile name, this command shows all Mobility Profile names and port lists on the WSS.

Syntax `show mobility-profile [name]`

name Name of an existing Mobility Profile.

Defaults None.

Access Enabled.

Examples The following command displays the Mobility Profile *magnolia*:

WSS# show mobility-profile magnolia

Mobility Profiles

Name	Ports
magnolia	AP 12

=====

See Also

- [clear mobility-profile on page 175](#)
- [set mobility-profile on page 204](#)

Mobility Domain Commands

Use Mobility Domain commands to configure and manage Mobility Domain groups.

A Mobility Domain is a system of WSSs and APs working together to support a roaming user (client). One WSS acts as a seed switch, which maintains and distributes a list of IP addresses of the domain members.



Note. Nortel recommends that you run the same WSS Software version on all the WSSs in a Mobility Domain.

This chapter presents Mobility Domain commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Mobility Domain	set mobility-domain mode secondary-seed domain-name seed-ip on page 222
	set domain security on page 218
	set mobility-domain member on page 219
	set mobility-domain mode member seed-ip on page 220
	set mobility-domain mode member secondary-seed-ip on page 220
	show mobility-domain on page 222
	show mobility-domain config on page 222
	clear mobility-domain member on page 218
	clear domain security on page 217
	clear mobility-domain on page 218

clear domain security

Disables WSS-WSS security.

Syntax **clear domain security**

Defaults None.

Access Enabled.

History Introduced in WSS Software 5.0.

Usage This command is equivalent to the **set domain security none** command.

Examples The following command disables WSS-WSS security on a WSS:

```
23x0# clear domain security
success: change accepted.
```

clear mobility-domain

Clears all Mobility Domain configuration and information from a WSS, regardless of whether the WSS is a seed or a member of a Mobility Domain.

Syntax `clear mobility-domain`

Defaults None.

Access Enabled.

Usage This command has no effect if the WSS is not configured as part of a Mobility Domain.

Examples To clear a Mobility Domain from a WSS within the domain, type the following command:

```
23x0# clear mobility-domain
success: change accepted.
```

See Also

- [clear mobility-domain member on page 218](#)
- [set mobility-domain member on page 219](#)
- [set mobility-domain mode member seed-ip on page 220](#)

clear mobility-domain member

On the seed WSS, removes the identified member from the Mobility Domain.

Syntax `clear mobility-domain member ip-addr`

ip-addr IP address of the Mobility Domain member, in dotted decimal notation.

Defaults None.

Access Enabled.

Usage This command has no effect if the WSS member is not configured as part of a Mobility Domain or the current WSS is not the seed.

Examples The following command clears a Mobility Domain member with the IP address 192.168.0.1:

```
23x0# clear mobility-domain member 192.168.0.1
```

See Also [set mobility-domain member on page 219](#)

set domain security

Enables **WSS-WSS** security in the WSS's Mobility Domain.

Syntax `set domain security { none | required }`

none WSS-WSS security is disabled.

required WSS-WSS security is enabled.

Defaults The default is **none**. (WSS-WSS security is disabled.)

Access Enabled.

History Introduced in WSS Software 5.0.

Usage The setting must be the same (**none** or **required**) on all switches, the seed and all members, in the Mobility Domain.

The **set domain security none** command is equivalent to the **clear domain security** command.

Examples The following command enables WSS-WSS security on a WSS:

WSS# set domain security required

success: change accepted.

set mobility-domain member

On the seed WSS, adds a member to the list of Mobility Domain members. If the current WSS is not configured as a seed, this command is rejected.

Syntax `set mobility-domain member ip-addr key hex-bytes`

ip-addr IP address of the Mobility Domain member in dotted decimal notation.

key hex-bytes Fingerprint of the public key to use for WSS-WSS security. Specify the key as 16 hexadecimal bytes. Use a colon between each byte, as in the following example:
00:11:22:33:44:55:66:77:88:99:aa:bb:cc:dd:ee:ff

Defaults None.

Access Enabled.

History

Version 5.0 Option **key hex-bytes** added.

Usage This command must be entered from the seed WSS.

Examples The following commands add three WSSs with the IP addresses 192.168.1.8, 192.168.1.9, and 192.168.1.10 as members of a Mobility Domain whose seed is the current WSS:

WSS# set mobility-domain member 192.168.1.8

success: change accepted.

WSS# set mobility-domain member 192.168.1.9

success: change accepted.

WSS# set mobility-domain member 192.168.1.10

success: change accepted.

See Also

- **clear mobility-domain member on page 218**
- **show mobility-domain config on page 222**

set mobility-domain mode member seed-ip

On a nonseed WSS, sets the IP address of the seed WSS. This command is used on a member **WSS** to configure it as a member. If the WSS is currently part of another Mobility Domain or using another seed, this command overwrites that configuration.

Syntax **set mobility-domain mode member seed-ip** *ip-addr* **key** *hex-bytes*

ip-addr IP address of the Mobility Domain member, in dotted decimal notation.

key *hex-bytes* Fingerprint of the public key to use for **WSS-WSS** security. Specify the key as 16 hexadecimal bytes. Use a colon between each byte, as in the following example:
00:11:22:33:44:55:66:77:88:99:aa:bb:cc:dd:ee:ff

Defaults None.

Access Enabled.

History

Version 5.0 Option **key** *hex-bytes* added.

Examples The following command sets the current WSS as a nonseed member of the Mobility Domain whose seed has the IP address 192.168.1.8:

WSS# set mobility-domain mode member seed-ip 192.168.1.8

mode is: member

seed IP is: 192.168.1.8

See Also

- **clear mobility-domain on page 218**
- **show mobility-domain config on page 222**

set mobility-domain mode member secondary-seed-ip

This command is used on a member **WSS** to configure it as a member of secondary seed.

Syntax `set mobility-domain mode member secondary-seed-ip secondary-seed-ip-addr`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 6.0.

Examples Following is the example of mobility-domain secondary-seed-ip.

WSS# set mobility-domain mode member secondary-seed-ip 192.168.1.8

Success: change accepted

set mobility-domain mode seed domain-name

Creates a Mobility Domain by setting the current WSS as the seed device and naming the Mobility Domain.

Syntax `set mobility-domain mode seed domain-name mob-domain-name`

mob-domain-name Name of the Mobility Domain. Specify between 1 and 32 characters with no spaces.

Defaults None.

Access Enabled.

History

Version 4.1 Maximum length of *mob-domain-name* increased to 32 characters.

Usage Before you use this command, the current WSS must have its IP address set with the **set system ip-address** command. After you enter this command, all Mobility Domain traffic is sent and received from the specified IP address.

You must explicitly configure *only one* WSS per domain as the seed. All other WSSs in the domain receive their Mobility Domain information from the seed.

Examples The following command creates a Mobility Domain named Santa Clara with the current WSS as the seed:

WSS# set mobility-domain mode seed domain-name Santa Clara

mode is: seed

domain name is: Santa Clara

See Also

- **clear mobility-domain member on page 218**
- **show mobility-domain on page 222**

set mobility-domain mode secondary-seed domain-name seed-ip

Creates a Mobility Domain by setting the current WSS as the secondary seed device and naming the Mobility Domain.

Syntax `set mobility-domain mode secondary-seed domain-name domain-name seed-ip seed-ip`

mob-domain-name Name of the Mobility Domain. Specify between 1 and 32 characters with no spaces.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 6.0.

Usage Before you use this command, the current WSS must have its IP address set with the **set system ip-address** command. After you enter this command, all Mobility Domain traffic is sent and received from the specified IP address.

Examples Following is the example of secondary-seed domain-name seed-ip

WSS# set mobility-domain mode secondary-seed domain-name spl seed-ip 198.164.1.8
Success: change accepted.

show mobility-domain config

Displays the configuration of the Mobility Domain.

Syntax `show mobility-domain config`

Defaults None.

Access Enabled.

Examples The following command displays the Mobility Domain configuration:

WSS# show mobility-domain config
This WSS is a member, with seed 192.168.14.6

See Also

- [clear mobility-domain on page 218](#)
- [set mobility-domain member on page 219](#)
- [show mobility-domain on page 222](#)

show mobility-domain

On the seed WSS, displays the Mobility Domain status and members.

Syntax `show mobility-domain`**Defaults** None.**Access** Enabled.**History** Upgraded in WSS Software Version 6.0.**Examples** To display Mobility Domain status, type the following command:**WSS# show mobility-domain**

Mobility Domain name: Santa Clara

Member	State	Type (* active)	Model	Version
192.168.253.11	STATE_DOWN	Seed	Unknown	Unknown
192.168.253.12	STATE_UP	Secondary seed *	2360	6.0.3.0

Table 32 describes the fields in the display.

Table 1: show mobility-domain Output

Field	Description
Mobility Domain name	Name of the Mobility Domain
Member	IP addresses of the seed WSS and members in the Mobility Domain
State	State of the WSS in the Mobility Domain: <ul style="list-style-type: none"> STATE_UP STATE_DOWN
Status	Role of the WSS in the Mobility Domain: <ul style="list-style-type: none"> MEMBER SEED

See Also

- [clear mobility-domain on page 218](#)
- [set mobility-domain member on page 219](#)
- [set mobility-domain mode member seed-ip on page 220](#)

Network Domain Commands

Use Network Domain commands to configure and manage Network Domain groups.

A Network Domain is a group of geographically dispersed Mobility Domains that share information among themselves over a WAN link. This shared information allows a user configured on a WSS in one Mobility Domain to establish connectivity on a WSS in another Mobility Domain elsewhere in the same Network Domain. The WSS forwards the user traffic by creating a VLAN tunnel to a WSS in the remote Mobility Domain.

In a Network Domain, one or more WSSs serve as a seed switch. At least one of the Network Domain seeds maintains a connection with each of the member WSSs in the Network Domain. The Network Domain seeds share information about the VLANs configured on their members, so that all the Network Domain seeds have a common database of VLAN information.

This chapter presents Network Domain commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Network Domain	set network-domain mode seed domain-name on page 229
	set network-domain mode member seed-ip on page 227
	set network-domain peer on page 228
	show network-domain on page 229
	clear network-domain on page 225
	clear network-domain mode on page 226
	clear network-domain peer on page 226
	clear network-domain seed-ip on page 227

clear network-domain

Clears all Network Domain configuration and information from a WSS, regardless of whether the WSS is a seed or a member of a Network Domain.

Syntax `clear network-domain`

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.1.

Usage This command has no effect if the WSS is not configured as part of a Network Domain.

Examples To clear a Network Domain from a WSS within the domain, type the following command:

23x0# clear network-domain

This will clear all network-domain configuration. Would you like to continue? (y/n) [n] y
success: change accepted.

See Also

- [set network-domain mode member seed-ip on page 227](#)
- [set network-domain peer on page 228](#)
- [set network-domain mode seed domain-name on page 229](#)

clear network-domain mode

Removes the Network Domain seed or member configuration from the WSS.

Syntax `clear network-domain mode {seed | member}`

seed	Clears the Network Domain seed configuration from the WSS.
member	Clears the Network Domain member configuration from the WSS.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.1.

Usage This command has no effect if the WSS is not configured as part of a Network Domain.

Examples The following command clears the Network Domain member configuration from the WSS:

```
23x0# clear network-domain mode member
success: change accepted.
```

The following command clears the Network Domain seed configuration from the WSS:

```
23x0# clear network-domain mode seed
success: change accepted.
```

See Also

- [set network-domain mode member seed-ip on page 227](#)
- [set network-domain mode seed domain-name on page 229](#)

clear network-domain peer

Removes the configuration of a Network Domain peer from a WSS configured as a Network Domain seed.

Syntax `clear network-domain peer {ip-addr | all}`

<i>ip-addr</i>	IP address of the Network Domain peer in dotted decimal notation.
all	Clears the Network Domain peer configuration for all peers from the WSS.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.1.

Usage This command has no effect if the WSS is not configured as a Network Domain seed.

Examples The following command clears the Network Domain peer configuration for peer 192.168.9.254 from the WSS:

```
23x0# clear network-domain peer 192.168.9.254
success: change accepted.
```

The following command clears the Network Domain peer configuration for all peers from the WSS:

```
23x0# clear network-domain peer all
success: change accepted.
```

See Also [set network-domain peer on page 228](#)

clear network-domain seed-ip

Removes the specified Network Domain seed from the WSS's configuration. When you enter this command, the Network Domain TCP connections between the WSS and the specified Network Domain seed are closed.

Syntax `clear network-domain seed-ip ip-addr`

ip-addr IP address of the Network Domain seed in dotted decimal notation.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.1.

Usage This command has no effect if the WSS is not configured as part of a Network Domain, or if the WSS is not configured as a member of a Network Domain that uses the specified Network Domain seed.

Examples The following command removes the Network Domain seed with IP address 192.168.9.254 from the WSS's configuration:

```
23x0# clear network-domain seed-ip 192.168.9.254
success: change accepted.
```

See Also [set network-domain mode member seed-ip on page 227](#)

set network-domain mode member seed-ip

Sets the IP address of a Network Domain seed. This command is used for configuring a WSS as a member of a Network Domain. You can specify multiple Network Domain seeds and configure one as the primary seed.

Syntax `set network-domain mode member seed-ip ip-addr`
`[affinity num]`

ip-addr IP address of the Network Domain seed, in dotted decimal notation.

num Preference for using the specified Network Domain seed. You can specify a value from 1 through 10. A higher number indicates a greater preference.

Defaults The default affinity for a Network Domain seed is 5.

Access Enabled.

History Introduced in WSS Software 4.1.

Usage You can specify multiple Network Domain seeds on the WSS. When the WSS needs to connect to a Network Domain seed, it first attempts to connect to the seed with the highest affinity. If that seed is unavailable, the WSS attempts to connect to the seed with the next-highest affinity. After a connection is made to a non-highest-affinity seed, the WSS then periodically attempts to connect to the highest-affinity seed.

Examples The following command sets the WSS as a member of the Network Domain whose seed has the IP address 192.168.1.8:

```
WSS# set network-domain mode member seed-ip 192.168.1.8
success: change accepted.
```

The following command sets the WSS as a member of a Network Domain whose seed has the IP address 192.168.9.254 and sets the affinity for that seed to 7. If the WSS specifies other Network Domain seeds, and they are configured with the default affinity of 5, then 192.168.9.254 becomes the primary Network Domain seed for this WSS.

```
WSS# set network-domain mode member seed-ip 192.168.9.254 affinity 7
success: change accepted.
```

See Also

- `clear network-domain` on page 225
- `show network-domain` on page 229

set network-domain peer

On a Network Domain seed, configures one or more WSSs as redundant Network Domain seeds. The seeds in a Network Domain share information about the VLANs configured on the member devices, so that all the Network Domain seeds have the same database of VLAN information.

Syntax `set network-domain peer ip-addr`

ip-addr IP address of the Network Domain seed to specify as a peer, in dotted decimal notation.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.1.

Usage This command must be entered on a WSS configured as a Network Domain seed.

Examples The following command sets the WSS with IP address 192.168.9.254 as a peer of this Network Domain seed:

```
WSS# set network-domain peer 192.168.9.254
success: change accepted.
```

See Also

- [clear network-domain on page 225](#)
- [show network-domain on page 229](#)

set network-domain mode seed domain-name

Creates a Network Domain by setting the current WSS as a seed device and naming the Network Domain.

Syntax `set network-domain mode seed domain-name net-domain-name`

net-domain-name Name of the Network Domain. Specify between 1 and 16 characters with no spaces.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.1.

Usage Before you use this command, the current WSS must have its IP address set with the **set system ip-address** command. After you enter this command, Network Domain traffic is sent and received from the specified IP address.

You can configure multiple WSSs as Network Domain seeds. If you do this, you must identify them as peers by using the **set network domain peer** command.

Examples The following command creates a Network Domain named California with the current WSS as a seed:

```
WSS# set network-domain mode seed domain-name California
success: change accepted.
```

See Also

- [clear network-domain on page 225](#)
- [show network-domain on page 229](#)

show network-domain

Displays the status of Network Domain seeds and members.

Syntax `show network-domain`

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.1.

Examples To display Network Domain status, type the following command. The output of the command differs based on whether the WSS is a member of a Network Domain or a Network Domain seed.

On a WSS that is a Network Domain member, the following output is displayed:

```
WSS# show network-domain
Member Network Domain name: California
Member      State      Mode      Mobility-Domain
-----
10.8.107.1  UP        SEED      default
```

On a WSS that is a Network Domain seed, information is displayed about the Network Domains of which the WSS is a member, as well as Network Domain seeds with which the WSS has a peer relationship. For example:

```
WSS# show network-domain
Network Domain name: California
Peer      State
-----
10.8.107.1  UP
Member      State      Mode      Mobility-Domain
-----
10.1.0.0    DOWN      SEED
Member Network Domain name:
Member      State      Mode      Mobility-Domain
-----
10.8.107.1  UP        MEMBER    default
10.1.0.0    DOWN      SEED
```

[Table 33](#) describes the fields in the display.

Table 1: show network-domain Output

Field	Description
Output if WSS is the Network Domain seed:	
Network Domain name	Name of the Network Domain for which the WSS is a seed.
Peer	IP addresses of the other seeds in the Network Domain.
State	State of the connection between the WSS and the peer Network Domain seeds: <ul style="list-style-type: none">• UP• DOWN
Member	IP addresses of the seed WSS and members in the Network Domain

Table 1: show network-domain Output (continued)

State	State of the WSS in the Network Domain: <ul style="list-style-type: none"> • UP • DOWN
Mode	Role of the WSS in the Network Domain: <ul style="list-style-type: none"> • MEMBER • SEED
Mobility-Domain	Name of the Mobility Domain of which the WSS is a member.
Output if WSS is a Network Domain member:	
Member Network Domain name	Name of the Network Domain of which the WSS is a member.
Member	IP addresses of the seed WSS and members in the Network Domain
State	State of the WSS in the Network Domain: <ul style="list-style-type: none"> • UP • DOWN
Mode	Role of the WSS in the Network Domain: <ul style="list-style-type: none"> • MEMBER • SEED
Mobility-Domain	Name of the Mobility Domain of which the WSS is a member.

See Also

- **clear network-domain on page 225**
- **set network-domain mode member seed-ip on page 227**
- **set network-domain mode seed domain-name on page 229**
- **set network-domain peer on page 228**

AP Commands

Use AP commands to configure and manage APs. Be sure to do the following before using the commands:

- Define the country-specific IEEE 802.11 regulations on the WSS. (See **set system countrycode** on page 63.)
- Install the AP and connect it to a port on the WSS. (See the *Nortel Access Point 2330/2330A/2330B Installation Guide* or *Nortel Series 2332 Access Point Installation Guide*.)
- Configure an AP access port (for a directly connected AP) or a AP. (See **set port type ap** on page 41 and **set ap** on page 33.)



Caution! Changing the system country code after AP configuration disables APs and deletes their configuration. If you change the country code on a WSS, you must reconfigure all APs.



Note. For Series 2332 access points, be sure the system country code is supported for the selected access point model.

This chapter presents AP commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Automatic Configuration of APs	set ap auto on page 245
	set ap auto mode on page 247
	set ap auto radiotype on page 248
	set ap auto persistent on page 247
	set ap bias on page 249
	set ap blink on page 250
	set ap group on page 258
	set ap radio auto-tune max-power on page 265
	set ap radio auto-tune max-retransmissions on page 266
	set ap radio mode on page 270
	set ap radio radio-profile on page 271
	set ap auto radiotype on page 248
set ap upgrade-firmware on page 275	
External Antennas	set ap radio antennatype on page 263
	set ap radio antenna-location on page 262

AP-WSS security	set ap fingerprint on page 257 set ap security on page 274
Static IP Address Assignment for APs	set ap boot-configuration ip on page 251 set ap boot-configuration switch on page 255 set ap boot-configuration vlan on page 256 clear ap boot-configuration on page 241 show ap boot-configuration on page 370
Radio Profile Assignment	set ap radio radio-profile on page 271 set radio-profile mode on page 291 clear radio-profile on page 242 set radio-profile service-profile on page 298 show radio-profile on page 376
SSID Assignment	set service-profile ssid-name on page 331 set service-profile ssid-type on page 332 set service-profile beacon on page 310
Radio Properties	set radio-profile active-scan on page 278 set radio-profile beacon-interval on page 285 set radio-profile countermeasures on page 287 set radio-profile dtim-interval on page 288 set radio-profile frag-threshold on page 289 set radio-profile max-rx-lifetime on page 290 set radio-profile max-tx-lifetime on page 290 set radio-profile preamble-length on page 294 set radio-profile rts-threshold on page 297
Authentication and Encryption	set service-profile attr on page 306 set service-profile auth-dot1x on page 307 set service-profile auth-fallthru on page 308 set service-profile web-portal-form on page 337 set service-profile web-portal-acl on page 336 set service-profile auth-psk on page 309 set service-profile wpa-ie on page 342 set service-profile rsn-ie on page 323 set service-profile cipher-ccmp on page 312 set service-profile cipher-tkip on page 313

	set service-profile cipher-wep104 on page 314
	set service-profile cipher-wep40 on page 315
	set service-profile psk-phrase on page 322
	set service-profile psk-raw on page 323
	set service-profile tkip-mc-time on page 333
	set service-profile wep active-multicast-index on page 340
	set service-profile wep active-unicast-index on page 341
	set service-profile wep key-index on page 342
	set service-profile keep-initial-vlan on page 317
	set service-profile transmit-rates on page 334
	set service-profile long-retry-count on page 319
	set service-profile short-retry-count on page 325
	set service-profile shared-key-auth on page 324
	show service-profile on page 380
	clear service-profile on page 243
QoS and VoIP	set radio-profile qos-mode on page 295
	set radio-profile wmm-powersave on page 305
	set service-profile cac-mode on page 311
	set service-profile cac-session on page 312
	set service-profile static-cos on page 332
	set service-profile cos on page 315
DHCP Restrict	set service-profile dhcp-restrict on page 316
Broadcast control	set service-profile no-broadcast on page 320
Proxy ARP	set service-profile proxy-arp on page 321
Keepalives and session timers	set service-profile idle-client-probing on page 317
	set service-profile user-idle-timeout on page 336
	set service-profile web-portal-logout on page 339
Sygate On-Demand (SODA)	set service-profile soda mode on page 329
	set service-profile soda agent-directory on page 326
	set service-profile soda enforce-checks on page 326
	set service-profile soda failure-page on page 327
	set service-profile soda remediation-acl on page 330
	set service-profile soda success-page on page 330
	set service-profile soda logout-page on page 328
Radio transmit rates	set service-profile transmit-rates on page 334

	set radio-profile rate-enforcement on page 295
Transmission retries	set service-profile long-retry-count on page 319 set service-profile short-retry-count on page 325
RF Auto-Tuning	set radio-profile auto-tune channel-config on page 279 set radio-profile auto-tune channel-holddown on page 280 set radio-profile auto-tune channel-interval on page 281 set radio-profile auto-tune channel-lockdown on page 282 set radio-profile auto-tune power-config on page 282 set radio-profile auto-tune power-interval on page 283 set radio-profile auto-tune power-lockdown on page 284 set radio-profile auto-tune power-lockdown on page 284 set ap radio auto-tune max-power on page 265 show auto-tune neighbors on page 368 show ap vlan on page 365
AeroScout tag support	set radio-profile rfid-mode on page 296
Radio State	set ap radio mode on page 270
Dual Homing	set ap bias on page 249
Load Balancing	set ap group on page 258 show ap group on page 357
RF Load Balancing	set ap radio load-balancing on page 268 set ap radio load-balancing group on page 269 clear ap radio load-balancing group on page 241 set band-preference on page 275 set load-balancing strictness on page 277 set service-profile load-balancing-exempt on page 318
AP Administration and Maintenance	set ap name on page 261 set ap blink on page 250 set ap upgrade-firmware on page 275 set ap force-image-download on page 257 reset ap on page 245 set ap radio channel on page 267 set ap radio tx-power on page 272 set ap image on page 259 clear ap image on page 237

	show ap config on page 344
	show ap status on page 358
	show ap counters on page 348
	show ap global on page 373
	show ap connection on page 371
	show ap unconfigured on page 374
	show ap qos-stats on page 354
	show ap etherstats on page 355
AP Local Switching	set ap local-switching mode on page 260
	set ap local-switching vlan-profile on page 260
	clear ap image on page 237
	show ap arp on page 343
	show ap fdb on page 353
	show ap vlan on page 365
WLAN Mesh Services	set ap boot-configuration mesh mode on page 252
	sset ap boot-configuration mesh psk-phrase on page 252
	set ap boot-configuration mesh ssid on page 254
	set service-profile mesh on page 320
	set service-profile bridging on page 310
	show ap boot-configuration on page 370
	show ap mesh-links on page 357
AirDefense Integration	set ap image on page 259
	clear ap image on page 237

clear ap image

Clears an AirDefense sensor software image file from an AP's configuration.

Syntax `clear ap ap-number image`

ap *ap-number* Index value that identifies the AP to the WSS.

Defaults None.

Access Enabled.

History

Version 5.0	Command introduced.
Version 6.0	Option dap removed.

Usage Use this command to configure an AP that had been converted to an AirDefense sensor to revert back to an AP. To load the software. When you do this, the next time the AP is booted, it becomes a Nortel Mobility Point.

Examples The following command causes the AirDefense sensor software file to be cleared from the configuration of AP 1:

```
WSS# clear ap 1 image
success: change accepted.
```

See Also [set ap image on page 259](#)

clear ap local-switching vlan-profile

Clears the VLAN profile that had been applied to an AP to use with local switching.

Syntax `clear ap ap-number local-switching vlan-profile`

ap-number Index value that identifies the AP on the WSS switch.

Defaults None.

Access Enabled.

History Introduced in WSS Version 6.0.

Usage A VLAN profile consists of a list of VLANs and tags. When a VLAN profile is applied to an AP, traffic for the VLANs specified in the VLAN profile is locally switched by the AP instead of being tunneled back to an WSS.

Use this command to reset the VLAN profile used by the AP for local switching to the *default* VLAN profile. Traffic that had been locally switched because of an entry in the cleared VLAN profile is tunneled to an WSS.

When clearing a VLAN profile causes traffic that had been locally switched by APs to be tunneled to an WSS switch, the sessions of clients associated with the APs where the VLAN profile is applied are terminated, and the clients must re-associate with the APs.

Examples The following command clears the VLAN profile that had been applied to AP 7:

```
WSS# clear ap 7 local-switching vlan-profile
success: change accepted.
```

See Also

- [set ap local-switching mode on page 260](#)

- [set ap local-switching vlan-profile on page 260](#)
- [set vlan-profile](#)

clear ap radio

Disables an AP radio and resets it to its factory default settings.

Syntax `clear {ap port-list | ap ap-num} radio {1 | 2 | all}`

ap <i>port-list</i>	List of ports connected to the AP(s) on which to reset a radio.
ap <i>ap-num</i>	Number of a AP on which to reset a radio.
radio 1	Radio 1 of the AP.
radio 2	Radio 2 of the AP. (This option does not apply to single-radio models.)
radio all	All radios on the AP.

Defaults The `clear ap radio` command resets the radio to the default settings listed in [Table 34](#) and in [Table 37 on page 291](#).

Table 1: Radio-Specific Parameters

Parameter	Default Value	Description
antenna-location	indoor	Location of the radio's antenna. Note: This parameter applies only to APs that support external antennas. Note: Be sure to select the appropriate antenna configuration that corresponds to indoor or outdoor operation.
antennatype	For most AP models, the default is internal . The default for the 802.11b/g radio on model 2330A is 24883 .	Nortel external antenna model Note: This parameter applies only to APs that support external antennas. Note: Be sure to select the appropriate antenna model for optimum indoor or outdoor operation.
auto-tune max-power	Highest setting allowed for the country of operation or highest setting supported on the hardware, whichever is lower	Maximum percentage of client retransmissions a radio can experience before RF Auto-Tuning considers changing the channel on the radio

Table 1: Radio-Specific Parameters (continued)

Parameter	Default Value	Description
channel	<ul style="list-style-type: none"> 802.11b/g—6 802.11a—Lowest valid channel number for the country of operation 	Number of the channel in which a radio transmits and receives traffic
mode	disable	Operational state of the radio.
radio-profile	None. You must add the radios to a radio profile.	802.11 settings
tx-power	Highest setting allowed for the country of operation or highest setting supported on the hardware, whichever is lower.	Transmit power of a radio, in decibels referred to 1 milliwatt (dBm)

Access Enabled

History

- Version 5.0
- Option **antenna-location** added.
 - Option **auto-tune min-client-rate** removed.
 - Option **auto-tune max-retransmissions** removed.
- Version 6.0
- Option **dap** removed for AP.

Usage When you clear a radio, WSS Software performs the following actions:

- Clears the transmit power, channel, and external antenna setting from the radio.
- Removes the radio from its radio profile and places the radio in the *default* radio profile.

This command does not affect the PoE setting.

Examples The following command disables and resets radio 2 on the AP connected to port 3:

```
WSS# clear ap 3 radio 2
```

See Also

- set ap radio mode on page 270**
- set ap radio radio-profile on page 271**
- set port type ap on page 41**

clear ap boot-configuration

Removes the static IP address configuration for a AP.

Syntax `clear ap boot-configuration ap-num`

ap *ap-num* Number of the AP for which you are clearing static IP information.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.1.
Option **dap** removed in 6.0.

Usage When the static IP configuration is cleared for a AP, the next time the AP is rebooted, it uses the standard boot process.

Examples The following command clears the static IP address configuration for AP 1.

WSS# clear ap 1 boot-configuration

This will clear specified AP devices. Would you like to continue? (y/n) [n]y
success: static info cleared.

- [set ap boot-configuration ip on page 251](#)
- [set ap boot-configuration switch on page 255](#)
- [set ap boot-configuration vlan on page 256](#)
- [show ap boot-configuration on page 370](#)

clear ap radio load-balancing group

Removes an AP radio from its load-balancing group.

Syntax `clear ap ap-number radio {1 | 2} load-balancing group`

ap *ap-number* Index value that identifies the AP on the WSS.

radio 1 Radio 1 of the AP.

radio 2 Radio 2 of the AP. (This option does not apply to single-radio models.)

Defaults None.

Access Enabled.

History Introduced in WSS Version 6.0.

Usage If an AP radio has been assigned to an RF load balancing group, you can use this command to remove the AP radio from the group.

Examples The following command clears radio 1 on AP 7 from the load balancing group to which it had been assigned:

```
WSS# clear ap 7 radio 1 load-balancing group
success : change accepted.
```

See Also

- [set load-balancing strictness on page 277](#)
- [set ap radio load-balancing on page 268](#)
- [set ap local-switching mode on page 260](#)
- [show load-balancing group on page 375](#)

clear radio-profile

Removes a radio profile or resets one of the profile's parameters to its default value.

Syntax `clear radio-profile name [parameter]`

name

Radio profile name.

parameter

Radio profile parameter:

- **beacon-interval**
- countermeasures
- **dtim-interval**
- **frag-threshold**
- **max-rx-lifetime**
- **max-tx-lifetime**
- **preamble-length**
- **rts-threshold**
- **service-profile**

(For information about these parameters, see the **set radio-profile** commands that use them.)

Defaults If you reset an individual parameter, the parameter is returned to the default value listed in [Table 37 on page 291](#).

Access Enabled.

History

Version 4.1	countermeasures parameter added.
Version 5.0	Parameters that no longer apply to radio profiles in WSS Software Version 4.1 removed: <ul style="list-style-type: none"> • long-retry • short-retry

Usage If you specify a parameter, the setting for the parameter is reset to its default value. The settings of the other parameters are unchanged and the radio profile remains in the configuration. If you do not specify a parameter, the entire radio profile is deleted from the configuration. All radios that use this profile must be disabled before you can delete the profile.

Examples The following commands disable the radios that are using radio profile *rp1* and reset the **beaconed-interval** parameter to its default value:

```
WSS# set radio-profile rp1 mode disable
```

```
WSS# clear radio-profile rp1 beacon-interval
```

success: change accepted.

The following commands disable the radios that are using radio profile *rptest* and remove the profile:

```
WSS# set radio-profile rptest mode disable
```

```
WSS# clear radio-profile rptest
```

success: change accepted.

See Also

- [set ap radio radio-profile on page 271](#)
- [set radio-profile mode on page 291](#)
- [show ap config on page 344](#)
- [show radio-profile on page 376](#)

clear service-profile

Removes a service profile or resets one of the profile's parameters to its default value.

Syntax **clear service-profile** *name*
[**soda** {**agent-directory** | **failure-page** | **remediation-acl** | **success-page** | **logout-page**}]

name

Service profile name.

soda agent-directory

Resets the directory for Sygate On-Demand (SODA) agent files to the default directory. By default, the directory name for SODA agent files is the same as the service profile name.

soda failure-page	Resets the page that is loaded when a client fails the checks performed by the SODA agent. By default, the page is generated dynamically.
soda remediation-acl	Disables use of the specified remediation ACL for the service profile. When no remediation ACL is specified, a client is disconnected from the network when it fails SODA agent checks.
soda success-page	Resets the page that is loaded when a client passes the checks performed by the SODA agent. By default, the page is generated dynamically.
soda logout-page	Resets the page that is loaded when a client logs out of the network. By default, the client is disconnected from the network without a page being loaded.

Defaults None.

Access Enabled.

History

Version 4.1 Options added to clear SODA parameters.

Usage If the service profile is mapped to a radio profile, you must remove it from the radio profile first. (After disabling all radios that use the radio profile, use the **clear radio-profile name service-profile name** command.)

Examples The following commands disable the radios that are using radio profile *rp6*, remove service-profile *svcprof6* from *rp6*, then clear *svcprof6* from the configuration.

WSS# set radio-profile rp6 mode disable

WSS# clear radio-profile rp6 service-profile svcprof6
success: change accepted.

WSS# clear service-profile svcprof6
success: change accepted.

- **clear radio-profile on page 242**
- **set radio-profile mode on page 291**
- **show service-profile on page 380**

reset ap

Restarts an AP.

Syntax `reset {ap port-list | ap ap-num}`

ap *port-list* List of ports connected to the AP to restart.

ap *ap-num* Number of a AP to reset.

Defaults None.

Access Enabled.

Usage When you enter this command, the AP drops all sessions and reboots.



Caution! Restarting an AP can cause data loss for users who are currently associated with the AP.

Examples The following command resets the AP on port 7:

WSS# reset ap 7

This will reset specified AP devices. Would you like to continue? (y/n)y

success: rebooting ap attached to port 7

set ap auto

Creates a profile for automatic configuration of APs.

Syntax `set ap auto`

Defaults None.

Access Enabled.

History

Version 4.0 Command introduced.

Version 4.1 Option **persistent** added.

Version 5.0

- Option **force-image-download** added.
- Option **radio num auto-tune min-client-rate** removed.
- Option **radio num tx-pwr** removed.

Version 6.0

- Option **dap** removed.

Usage Table 35 lists the configurable profile parameters and their defaults. The only parameter that requires configuration is the profile mode. The profile is disabled by default. To use the profile to configure APs, you must enable the profile using the **set ap auto mode enable** command.

The profile uses the *default* radio profile by default. You can change the profile using the **set ap auto radio radio-profile** command. You can use set ap auto commands to change settings for the parameters listed in Table 35. (The commands are listed in the “See Also” section.)

Table 2: Configurable Profile Parameters for APs

Parameter	Default Value
AP Parameters	
bias	high
blink (Not shown in show ap config output)	disable
force-image-download	disable (NO)
group (load balancing group)	none
mode	disabled
persistent	none
upgrade-firmware (boot-download-enable)	enable (YES)
Radio Parameters	
radio num auto-tune max-power	default
radio num mode	enabled
radio num radio-profile	default
radiotype	11g (or 11b for country codes where 802.11g is not allowed)

Examples The following command creates a profile for automatic AP configuration:

```
WSS# set ap auto
success: change accepted.
```

See Also

- **set ap auto mode** on page 247
- **set ap auto persistent** on page 247
- **set ap auto radiotype** on page 248
- **set ap bias** on page 249
- **set ap blink** on page 250
- **set ap group** on page 258

- [set ap radio auto-tune max-power on page 265](#)
- [set ap radio mode on page 270](#)
- [set ap radio radio-profile on page 271](#)
- [set ap upgrade-firmware on page 275](#)

set ap auto mode

Enables a WSS's profile for automatic AP configuration.

Syntax `set ap auto mode {enable | disable}`

enable Enables the AP configuration profile.

disable Disables the AP configuration profile.

Defaults The AP configuration profile is disabled by default.

Access Enabled.

History Introduced in WSS Software 4.0.
Option `dap` removed in 6.0

Usage You must use the `set ap auto` command to create the profile before you can enable it.

Examples The following command enables the profile for automatic AP configuration:

```
WSS# set ap auto mode enable
success: change accepted.
```

See Also

- [set ap auto on page 245](#)
- [set ap auto persistent on page 247](#)
- [set ap auto radiotype on page 248](#)
- [set ap bias on page 249](#)
- [set ap blink on page 250](#)
- [set ap group on page 258](#)
- [set ap radio auto-tune max-power on page 265](#)
- [set ap radio mode on page 270](#)
- [set ap radio radio-profile on page 271](#)
- [set ap upgrade-firmware on page 275](#)

set ap auto persistent

Converts a temporary AP configuration created by the AP configuration profile into a persistent AP configuration on the WSS.

Syntax `set ap auto persistent [ap-num | all]`

<i>ap-num</i>	Converts the configuration of the AP that has the specified connection number into a permanent configuration.
all	Converts the configurations of all Auto-APs being managed by the switch into permanent configurations.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.0.
Option **dap** removed in 6.0.

Usage To display the AP numbers assigned to Auto-APs, use the **show ap status auto** command.

Examples The following command converts the configuration of Auto-AP 10 into a permanent configuration:

```
WSS# set ap auto persistent 10
success: change accepted.
```

See Also

- [set ap auto on page 245](#)
- [set ap auto mode on page 247](#)
- [set ap auto radiotype on page 248](#)

set ap auto radiotype

Sets the radio type for single-AP radios that use the AP configuration profile.

Syntax `set ap auto [radiotype { 11a | 11b | 11g }]`

radiotype 11a | 11b | 11g

Radio type:

- **11a**—802.11a
- **11b**—802.11b
- **11g**—802.11g

Note:

Defaults The default radio type for models 2330, 2330A, 2330B, and 2332 and for the 802.11b/g radios in other models is 802.11g in regulatory domains that support 802.11g, or 802.11b in regulatory domains that do not support 802.11g.

Access Enabled.

History

Version 4.0	Command introduced.
Version 5.0	Option 11a supported.
Version 6.0	Option dap removed.

Usage If you set the radiotype to **11a** and the AP configuration profile is used to configure a two-radio AP model, radio 1 is configured as an 802.11b/g radio and radio 2 is configured as the 802.11a radio. Because this is the reverse of the standard configuration (where radio 1 is the 802.11a radio and radio 2 is the 802.11b/g radio), the radio 1 settings configured in the AP configuration profile are applied to radio 2. Likewise, the radio 2 settings configured in the profile are applied to radio 1. This behavior ensures that settings for radio 1 are always applied to the 802.11a radio, regardless of the radio number.

Examples The following command sets the radio type to 802.11b:

```
WSS# set ap auto radiotype 11b
success: change accepted.
```

See Also

- [set ap auto on page 245](#)
- [set ap auto mode on page 247](#)
- [set ap auto persistent on page 247](#)

set ap bias

Changes the bias for an AP. Bias is the priority of one WSS over other WSSs for booting and configuring the AP.

Syntax `set {ap port-list | ap {ap-num | auto}} bias {high | low}`

ap port-list	List of ports on which to change the bias for directly connected APs.
ap ap-num	Number of a AP for which to change the bias.
ap auto	Configures bias for the AP configuration profile. (See set ap auto on page 245 .)
high	High bias.
low	Low bias.

Defaults The default bias is high.

Access Enabled.

History

Version 4.0	Option auto added for configuration of the AP configuration profile.
Version 6.0	Option dap removed.

Usage High bias is preferred over low bias. Bias applies only to WSSs that are indirectly attached to the AP through an intermediate Layer 2 or Layer 3 network. An AP always attempts to boot on AP port 1 first, and if a WSS is directly attached on AP port 1, the AP always boots from it.

If AP port 1 is indirectly connected to WSSs through the network, the AP boots from the switch with the high bias for the AP. If the bias for all connections is the same, the AP selects the switch that has the greatest capacity to add more active APs. For example, if an AP is dual homed to two 2380 switches, and one of the switches has 50 active APs while the other switch has 60 active APs, the new AP selects the switch that has only 50 active APs.

If the boot request on AP port 1 fails, the AP attempts to boot over its port 2, using the same process described above.

AP selection of a WSS is *sticky*. After an AP selects a WSS to boot from, the AP continues to use that switch for its active data link even if another switch configured with high bias for the AP becomes available.

The following command changes the bias for a AP to low:

```
WSS# set ap 1 bias low  
success: change accepted.
```

See Also [show ap config on page 344](#)

set ap blink

Enables or disables LED blink mode on an AP to make it easy to identify. When blink mode is enabled on AP-xxx models, the health and radio LEDs alternately blink green and amber. When blink mode is enabled on an AP2750, the 11a LED blinks on and off. By default, blink mode is disabled.

```
Syntax set {ap port-list | ap {ap-num | auto}}  
blink {enable | disable}
```

ap port-list	List of ports connected to the APs on which to turn blink mode on or off.
ap ap-num	Number of a AP on which to turn blink mode on or off.
ap auto	Configures blink mode for the AP configuration profile. (See set ap auto on page 245 .)
enable	Enables blink mode.
disable	Disables blink mode.

Defaults LED blink mode is disabled by default.

Access Enabled.

History

Version 4.0	Option auto added for configuration of the AP configuration profile.
Version 6.0	Optional dap removed.

Usage Changing the LED blink mode does not alter operation of the AP. Only the behavior of the LEDs is affected.

Examples The following command enables LED blink mode on the AP connected to ports 3 and 4:

```
WSS# set ap 3-4 blink enable
success: change accepted.
```

set ap boot-configuration ip

Specifies static IP address information for a AP.

Syntax `set ap ap-num boot-configuration ip ip ip-addr netmask mask-addr gateway gateway-addr [mode {enable | disable}]`

Syntax `set ap ap-num boot-configuration ip mode {enable | disable}`

ap <i>ap-num</i>	Number of the AP for which you are specifying static IP information.
ip <i>ip-addr</i>	The IP address to be assigned to the AP, in dotted decimal notation (for example, 10.10.10.10).
netmask <i>mask-addr</i>	The subnet mask, in dotted decimal notation (for example, 255.255.255.0).
gateway <i>gateway-addr</i>	The IP address of the next-hop router, in dotted decimal notation.
mode {enable disable}	Enables or disables the static IP address for the AP.

Defaults By default APs use DHCP to obtain an IP address, rather than a using a manually assigned IP address.

Access Enabled.

History Introduced in WSS Software 4.1.
Option **dap** removed in 6.0.

Usage Normally, APs use DHCP to obtain IP address information. In some installations, DHCP may not be available. In this case, you can assign static IP address information to the AP, including the AP's IP address and netmask, and default gateway.

If the manually assigned IP information is incorrect, the AP uses DHCP to obtain its IP address.

Examples The following command configures AP 1 to use IP address 172.16.0.42 with a 24-bit netmask, and use 172.16.0.20 as its default gateway:

```
WSS# set ap 1 boot-configuration ip 172.16.0.42 netmask 255.255.255.0 gateway 172.16.0.20
success: change accepted.
```

See Also

- [clear ap boot-configuration on page 241](#)
- [set ap boot-configuration switch on page 255](#)
- [set ap boot-configuration vlan on page 256](#)

- [show ap boot-configuration on page 370](#)

set ap boot-configuration mesh mode

Enables WLAN mesh services on the AP.

Syntax `set ap ap-number boot-configuration mesh mode {enable | disable}`

ap *ap-number*

Index value that identifies the AP on the WSS.

mode {enable | disable}

Enables or disables WLAN mesh services for the AP.

Defaults Disabled.

Access Enabled.

History Introduced in WSS Version 6.0.

Usage Use this command to enable WLAN mesh services for an Mesh AP. Prior to deploying the Mesh AP in its final untethered location, you must connect the AP to an WSS switch and enter this command to configure the AP for mesh services.

Examples The following command enables WLAN mesh services for AP 7:

```
WSS# set ap 7 boot-configuration mesh mode enable
success: change accepted.
```

See Also

- [set ap boot-configuration mesh ssid on page 254](#)
- [set service-profile mesh on page 320](#)
- [show ap mesh-links on page 357](#)

set ap boot-configuration mesh psk-phrase

Specifies a preshared key (PSK) phrase that a Mesh AP uses for authentication to its Mesh Portal AP.

Syntax `set ap ap-number boot-configuration mesh psk-phrase passphrase`

ap *ap-number*

Index value that identifies the AP on the WSS.

passphrase

An ASCII string from 8 to 63 characters long. The string can contain blanks if you use quotation marks at the beginning and end of the string.

Defaults None.

Access Enabled.

History Introduced in WSS Version 6.0.

Usage Use this command to configure the preshared key that a Mesh AP uses to authenticate to a Mesh Portal AP. You must connect the AP to an WSS switch and enter this command to configure the AP for mesh services prior to deploying the Mesh AP in its final untethered location.

WSS converts the passphrase into a 256-bit binary number for system use and a raw hexadecimal key to store in the WSS configuration. Neither the binary number nor the passphrase itself is ever displayed in the configuration. To use PSK authentication, you must enable it and you also must enable the WPA IE.

Examples The following command configures AP 7 to use passphrase "1234567890123<>?=&% The quick brown fox jumps over the lazy sl" when authenticating with a Mesh Portal AP

```
WSS# set ap 7 boot-configuration mesh psk-phrase "1234567890123<>?=&% The
quick brown fox jumps over the lazy sl"
success: change accepted.
```

See Also

- [set ap boot-configuration mesh ssid on page 254](#)
- [set service-profile mesh on page 320](#)
- [show ap mesh-links on page 357](#)

set ap boot-configuration mesh psk-raw

Configures a raw hexadecimal preshared key (PSK) to use for authenticating a Mesh AP to a Mesh Portal AP. Radios use the PSK as a pairwise master key (PMK) to derive unique pairwise session keys for individual WPA clients.

Syntax `set ap ap-number boot-configuration mesh psk-raw hex`

ap <i>ap-number</i>	Index value that identifies the AP on the WSS.
<i>hex</i>	A 64-bit ASCII string representing a 32-digit hexadecimal number. Enter the two-character ASCII form of each hexadecimal number.

Defaults None.

Access Enabled.

History Introduced in WSS Version 6.0.

Usage Use this command to configure the preshared key that a Mesh AP uses to authenticate to a Mesh Portal AP. You must connect the AP to an WSS switch and enter this command to configure the AP for mesh services prior to deploying the Mesh AP in its final untethered location.

WSS Software converts the hexadecimal number into a 256-bit binary number for system use. WSS Software also stores the hexadecimal key in the WSS configuration. The binary number is never displayed in the configuration. To use PSK authentication, you must enable it and you also must enable WPA IE.

Examples The following command configures AP7 to use a raw PSK to authenticate with a Mesh Portal AP:

```
WSS# set ap 7 boot-configuration mesh psk-raw
c25d3fe4483e867d1df96eaacdf8b02451fa0836162e758100f5f6b87965e59d
success: change accepted.
```

See Also

- [set ap boot-configuration mesh ssid on page 254](#)
- [set service-profile mesh on page 320](#)
- [show ap mesh-links on page 357](#)

set ap boot-configuration mesh ssid

Specifies the name of the SSID a Mesh AP attempts to associate with when it is booted.

Syntax `set ap ap-number boot-configuration mesh ssid mesh-ssid`

ap <i>ap-number</i>	Index value that identifies the AP on the WSS.
<i>mesh-ssid</i>	Name of the mesh SSID (up to 32 characters).

Defaults None.

Access Enabled.

History Introduced in WSS Version 6.0.

Usage You must connect the AP to an WSS and enter this command to specify the mesh SSID prior to deploying the Mesh AP in its final untethered location. When the AP is booted its untethered location, and it determines that it has no Ethernet link to the network, it then associates with the specified mesh-ssid.



Note. When the *mesh-ssid* is specified, the regulatory domain of the WSS and the power restrictions are copied to the AP flash memory. This prevents the Mesh AP from operating outside of regulatory limits after it is booted and before it receives its complete configuration from the WSS switch. Consequently, it is important that the regulatory and antenna information specified on the WSS switch actually reflects the locale where the Mesh AP is to be deployed, in order to avoid regulatory violations.

Examples The following command configures AP 7 to attempt to associate with the SSID WLAN-mesh when booted in an untethered location:

```
WSS# set ap 7 boot-configuration mesh ssid wlan-mesh
success: change accepted.
```


- **set ap boot-configuration mesh mode** on page 252
- **set service-profile mesh** on page 320
- **show ap mesh-links** on page 357

set ap boot-configuration switch

Specifies the WSS a AP contacts and attempts to use as its boot device.

Syntax `set ap ap-num boot-configuration switch [switch-ip ip-addr] [name name dns ip-addr]
[mode {enable | disable}]`

ap <i>ap-num</i>	Number of the AP for which you are specifying static IP information.
switch-ip <i>ip-addr</i>	The IP address of the WSS the AP should boot from.
name <i>name</i>	The fully qualified domain name of the WSS the AP should boot from. When both a name and a switch-ip are specified, the AP uses the name.
dns <i>ip-addr</i>	The IP address of the DNS server used to resolve the specified name of the WSS.
mode {enable disable}	Enables or disables the AP using the specified boot device.

Defaults By default APs use the process described in “Default AP Boot Process”, in the *Nortel WLAN Security Switch 2300 Series Configuration Guide* to boot from a WSS, instead of using a manually specified WSS.

Access Enabled.

History Introduced in WSS Software 4.1.
Option **dap** removed.

Usage When you specify a boot switch for a AP to boot from, it boots using the process described in “AP Boot Process Using Static IP Configuration”, in the *Nortel WLAN Security Switch 2300 Series Configuration Guide*.

When a static IP address is specified for a AP, there is no preconfigured DNS information or DNS name for the WSS the AP attempts to use as its boot device. If you configure a static IP address for a AP, but do not specify a boot device, then the WSS must be reachable via subnet broadcast.

Examples The following command configures AP 1 to use the WSS with address 172.16.0.21 as its boot device.

```
WSS# set ap 1 boot-configuration switch switch-ip 172.16.0.21 mode enable
success: change accepted.
```

The following command configures AP 1 to use the WSS with the name 2350 as its boot device. The DNS server at 172.16.0.1 is used to resolve the name of the WSS.

```
WSS# set ap 1 boot-configuration switch name 2350 dns 172.16.0.1 mode enable
success: change accepted.
```

See Also

- **clear ap boot-configuration** on page 241
- **set ap boot-configuration ip** on page 251
- **set ap boot-configuration vlan** on page 256
- **show ap boot-configuration** on page 370

set ap boot-configuration vlan

Specifies 802.1Q VLAN tagging information for a AP.

Syntax `set ap ap-num boot-configuration vlan vlan-tag tag-value [mode {enable | disable}]`

Syntax `set ap ap-num boot-configuration vlan mode {enable | disable}`

ap <i>ap-num</i>	Number of the AP for which you are specifying VLAN information.
vlan-tag <i>tag-value</i>	The VLAN tag value. You can specify a number from 1 – 4095.
mode {enable disable}	Enables or disables use of the specified VLAN tag on the AP.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.1.
Option **dap** removed.

Usage When this command is configured, all Ethernet frames emitted from the AP are formatted with an 802.1Q tag with a specified VLAN number. Frames sent to the AP that are not tagged with this value are ignored.

Examples The following command configures AP 1 to use VLAN tag 100:

```
WSS# set ap 1 boot-configuration vlan vlan-tag 100 mode enable
success: change accepted.
```

See Also

- **clear ap boot-configuration** on page 241
- **set ap boot-configuration ip** on page 251
- **set ap boot-configuration switch** on page 255
- **show ap boot-configuration** on page 370

set ap fingerprint

Verifies an AP's fingerprint on a WSS. If AP-WSS security is required by a WSS, an AP can establish a management session with the switch only if you have verified the AP's identity by verifying its fingerprint on the switch.

Syntax `set ap num fingerprint hex`

ap <i>ap-num</i>	Number of the AP whose fingerprint you are verifying.
<i>hex</i>	The 16-digit hexadecimal number of the fingerprint. Use a colon between each digit. Make sure the fingerprint you enter matches the fingerprint used by the AP.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.0.
Option **dap** removed in 6.0.

Usage APs are configured with an encryption key pair at the factory. The fingerprint for the public key is displayed on a label on the back of the AP, in the following format:

RSA

aaaa:aaaa:aaaa:aaaa:

aaaa:aaaa:aaaa:aaaa

If an AP is already installed and operating, you can use the **show ap status** command to display the fingerprint. The **show ap config** command lists an AP's fingerprint only if the fingerprint has been verified in WSS Software. If the fingerprint has not been verified, the fingerprint information in the command output is blank.

Examples The following example verifies the fingerprint for AP 8:

```
WSS# set ap 8 fingerprint b4:f9:2a:52:37:58:f4:d0:10:75:43:2f:45:c9:52:c3
success: change accepted.
```

See Also

- **set ap security** on page 274
- **show ap config** on page 344
- **show ap status** on page 358

set ap force-image-download

Configures an AP to download its software image from the WSS instead of loading the image that is locally stored on the AP.

Syntax `set {ap port-list | ap {ap-num | auto}} force-image-download {enable | disable}`

ap <i>port-list</i>	List of AP access ports.
----------------------------	--------------------------

ap <i>ap-num</i>	Number of a AP.
-------------------------	-----------------

ap auto	Configures forced image download for the AP configuration profile. (See set ap auto on page 245.)
force-image-download enable	Enables forced image download.
force-image-download disable	Disables forced image download.

Defaults Forced image download is disabled by default.

Access Enabled.

History Introduced in WSS Software 5.0.
Optional **dap** removed 6.0.

Usage A change to the forced image download option takes place the next time the AP is restarted.

Even when forced image download is disabled (the default), the AP still checks with the WSS to verify that the AP has the latest image, and to verify that the **WSS** is running WSS Software Version 5.0 or later.

The AP loads its local image only if the **WSS** is running WSS Software Version 5.0 or later and does not have a newer AP image than the one in the AP's local storage. If the switch is not running WSS Software Version 5.0 or later, or the **WSS** has a newer version of the AP image than the version in the AP's local storage, the AP loads its image from the **WSS**.

Examples The following command enables forced image download on AP 69:

```
WSS# set ap 69 force-image-download enable  
success: change accepted.
```

See Also [show ap config on page 344](#)

set ap group

Configures a named group of APs. WSS Software automatically load balances sessions among the access points in a group. To balance the sessions, WSS Software rejects an association request for an access point's radio if that radio has at least four more active sessions than the radio of the same type with the least number of active sessions within the group.

Syntax **set** {**ap** *port-list* | **ap** {*ap-num* | **auto**}} **group name**

ap port-list	List of AP access ports to add to the group.
ap ap-num	Number of a AP to add to the group.
ap auto	Configures an AP group for the AP configuration profile. (See set ap auto on page 245.)
<i>name</i>	AP group name of up to 16 alphanumeric characters, with no spaces.

Defaults APs are not grouped by default.

Access Enabled.

History

Version 4.0	Option auto added for configuration of the AP configuration profile.
Version 6.0	Option dap removed.

Usage You can assign any subset or all of the APs connected to a WSS to a group on that switch. All access points in a group must be connected to the same WSS.

If you use the name *none*, spelled in any combination of capital or lowercase letters, the specified AP is cleared from all AP groups.

Examples The following command configures an AP group named *loadbalance1* that contains the APs on ports 1, 4, and 7:

```
WSS# set ap 1,4,7 group loadbalance1
success: change accepted.
```

The following command removes the AP on port 4 from all AP groups:

```
WSS# set ap 4 group none
success: change accepted.
```

See Also

- [show ap config on page 344](#)
- [show ap group on page 357](#)

set ap image

Loads an AirDefense image on an AP.

Syntax `set ap ap-number image filename`

ap <i>ap-number</i>	Index value that identifies the AP on the WSS.
<i>filename</i>	Name of the AirDefense sensor software image file. This file is assumed to have been copied to the WSS.

Defaults None.

Access Enabled.

History

Version 5.0	Command introduced.
Version 6.0	Option dap removed.

Usage After the AirDefense sensor software is copied to the WSS, use this command to configure an AP to load the software. When you do this, the software is transferred to the AP, which then reboots and comes up as an AirDefense sensor.

Examples The following command causes AP 1 to load the *adconvert.bin* file, then reboot as an AirDefense sensor:

```
WSS# set ap 1 image adconvert.bin
```

This will change the file a AP will boot. Would you like to continue? (y/n) [n] **y**

set ap local-switching mode

Enables local switching for a specified AP.

Syntax `set ap ap-number local-switching mode {enable | disable}`

ap-number Index value that identifies the AP on the WSS switch.

enable Enables local switching for the AP.

disable Disables local switching for the AP.

Defaults Local switching is disabled by default.

Access Enabled.

History Introduced in WSS Version 6.0.

Usage Local switching allows traffic for specified VLANs to be switched by the AP itself, instead of being tunneled back to an WSS switch. The VLANs for which local switching is performed are specified in a VLAN profile.

Local switching can be enabled on APs that are connected to the WSS switch via an intermediate Layer 2 or Layer 3 network. Local switching is not supported for APs that are directly connected to an WSS switch.

If local switching is enabled on an AP, but no VLAN profile is configured, then a default VLAN profile is used. The default VLAN profile includes a single VLAN named default that is not tagged.

Examples The following command enables local switching for AP 7:

```
WSS# set ap 7 local-switching mode enable
```

success: change accepted.

See Also

- [set ap local-switching vlan-profile on page 260](#)
- [set vlan-profile](#)

set ap local-switching vlan-profile

Applies a specified VLAN profile to an AP to use with local switching.

Syntax `set ap ap-number local-switching vlan-profile profile-name`

ap-number Index value that identifies the AP on the WSS switch.

profile-name The name of a VLAN profile configured on the WSS switch.

Defaults If local switching is enabled on an AP, but no VLAN profile is configured, then a default VLAN profile is used. The default VLAN profile includes a single VLAN named *default* that is not tagged.

Access Enabled.

History Introduced in WSS Software Version 6.0.

Usage A VLAN profile consists of a list of VLANs and tags. When a VLAN profile is applied to an AP, traffic for the VLANs specified in the VLAN profile is locally switched by the AP instead of being tunneled back to an WSS switch.

When applying a VLAN profile causes traffic that had been tunneled to an WSS switch to be locally switched by APs, or vice-versa, the sessions of clients associated with the APs where the VLAN profile is applied are terminated, and the clients must re-associate with the APs.

Examples The following command specifies that AP 7 use VLAN profile *locals*:

```
WSS# set ap 7 local-switching vlan-profile locals
success: change accepted.
```

See Also

- [set ap local-switching mode on page 260](#)
- [set ap local-switching vlan-profile on page 260](#)
- [set vlan-profile](#)

set ap name

Changes an AP name.

Syntax `set {ap port-list | ap ap-num} name name`

ap port-list List of ports connected to the AP to rename.

ap ap-num Number of a AP to rename.

name Alphanumeric string of up to 16 characters, with no spaces.

Defaults The default name of a directly attached AP is based on the port number of the AP access port attached to the AP. For example, the default name for an AP on AP access port 1 is *AP01*. The default name of a AP is based on the number you assign to it when you configure the connection. For example, the default name for AP 1 is *DAP01*.

Access Enabled.

History

Version 4.1	Default AP name changed from DAP <i>num</i> to DAP <i>num</i>
Version 6.0	Option dap removed.

Examples The following command changes the name of the AP on port 1 to *techpubs*:

```
WSS# set ap 1 name techpubs
success: change accepted.
```

See Also [show ap config on page 344](#)

set ap radio antenna-location

Specifies the location (indoors or outdoors) of an external antenna. Use this command to ensure that the proper set of channels is available on the radio. In some cases, the set of valid channels for a radio differs depending on whether the antenna is located indoors or outdoors.

Syntax `set {ap port-list | ap ap-num} antenna-location {indoors | outdoors}`

ap <i>port-list</i>	List of ports connected to the AP to rename.
ap <i>ap-num</i>	Number of a AP to rename.
indoors	Specifies that the external antenna is installed indoors (inside the building).
outdoors	Specifies that the external antenna is installed outdoors.

Defaults The default antenna location is **indoor**.

Access Enabled.

History Introduced in WSS Software 5.0.
Option **dap** removed in 6.0.

Examples The following command sets the antenna location for radio 1 on AP 22 to **outdoor**:

```
WSS# set ap 22 radio 1 antenna-location outdoor
success: change accepted.
```

See Also `set ap radio antennatype` on page 263

set ap radio antennatype

Sets the model number for the antenna to be used.

Syntax `set {ap port-list | ap ap-num} radio {1 | 2} antennatype {1 antennatype {internal | 24203 | 24403 | 24453 | 24553 | 24883 | mixed | 24143 | 24143-OUT | 24143-OUT-10 | 24143-OUT-25 | 24143-NEMA | 24143-NEMA-10 | 24143-NEMA-25 | 24123 | 24123-OUT | 24123-OUT-10 | 24123-OUT-25 | 24123-NEMA | 24123-NEMA-10 | 24123-NEMA-25 | 24113 | 24113-OUT | 24113-OUT-10 | 24113-OUT-25 | 24113-NEMA | 24113-NEMA-10 | 24113-NEMA-25 | 24493 | 24493-OUT | 24493-OUT-10 | 24493-OUT-25 | 24493-NEMA | 24493-NEMA-10 | 24493-NEMA-25 | 24883 | 24883-OUT | 24883-OUT-10 | 24883-OUT-25 | 24883-NEMA | 24883-NEMA-10 | 24883-NEMA-25} | {2 antennatype {internal | 5303 | mixed | 5133 | 5173 | 5103 | 5133-OUT | 5133-OUT-10 | 5133-OUT-25 | 5133-NEMA | 5133-NEMA-10 | 5133-NEMA-25 | 5643 | 5643-OUT | 5643-OUT-10 | 5643-OUT-25 | 5643-NEMA | 5643-NEMA-10 | 5643-NEMA-25 | 5173-OUT | 5173-OUT-10 | 5173-OUT-25 | 5173-NEMA | 5173-NEMA-10 | 5173-NEMA-25 | 5103-OUT | 5103-OUT-10 | 5103-OUT-25 | 5103-NEMA | 5103-NEMA-10 | 5103-NEMA-25}}`

ap port-list	List of ports connected to the APs on which to set the channel.
ap ap-num	Number of a AP on which to set the channel.
radio 1	Radio 1 of the AP.
radio 2	Radio 2 of the AP. (This option does not apply to single-radio models.)
antennatype { internal 24203 24403 24453 24553 mixed 24143 24143-OUT 24143-OUT-10 24143-OUT-25 24143-NEMA 24143-NEMA-10 24143-NEMA-25 24123 24123-OUT 24123-OUT-10 24123-OUT-25 24123-NEMA 24123-NEMA-10 24123-NEMA-25 24113 24113-OUT 24113-OUT-10 24113-OUT-25 24113-NEMA 24113-NEMA-10 24113-NEMA-25 24493 24493-OUT 24493-OUT-10 24493-OUT-25 24493-NEMA 24493-NEMA-10 24493-NEMA-25 24883 24883-OUT 24883-OUT-10 24883-OUT-25 24883-NEMA 24883-NEMA-10 24883-NEMA-25}	802.11b/g antenna models: <ul style="list-style-type: none">• internal - Omnidirectional puck• 24123 - Directional Panel, 90 degrees• 24113 - Directional Panel, 120 degrees• 24143 - Directional Yagi• 24203 - Omnidirectional• 24403 - Bidirectional Panel• 24453 and 24493- Omnidirectional Collinear Dipoles• 24553 - Directional Panel• 24883 - Directional Panel, 60 degrees• mixed - Dual-band, Tri-mode 802.11a/b/g Spatial Diversity Antenna• -NEMA, -NEMA-10 & -NEMA-25 (Outdoor configurations with base antenna model)• -OUT, -OUT-10 & -OUT-25 (Outdoor configurations with base antenna model)

antennatype
 {internal | 5303 | mixed | 5133 | 5173 | 5103
 | 5133-OUT | 5133-OUT-10 | 5133-OUT-25
 | 5133-NEMA | 5133-NEMA-10 | 5133-
 NEMA-25 | 5643 | 5643-OUT | 5643-OUT-
 10 | 5643-OUT-25 | 5643-NEMA | 5643-
 NEMA-10 | 5643-NEMA-25 | 5173-OUT |
 5173-OUT-10 | 5173-OUT-25 | 5173-
 NEMA | 5173-NEMA-10 |
 5173-NEMA-25 | 5103-OUT | 5103-OUT-
 10 | 5103-OUT-25 | 5103-NEMA | 5103-
 NEMA-10 | 5103-NEMA-25}

802.11a antenna models:

- internal - Omnidirectional puck
- 5303 - Wideband Squint
- 5643 - Omnidirectional Collinear Dipole
- 5133 - Directional Panel, 60 degrees
- 5173 - Directional Panel, 90 degrees
- 5103 - Directional Panel, 120 degrees
- mixed - Dual-band, Tri-mode 802.11a/b/g Spatial Diversity Antenna
- -NEMA, -NEMA-10 & -NEMA-25 (Outdoor configurations with base antenna model)
- -OUT, -OUT-10 & -OUT-25 (Outdoor configurations with base antenna model)

Defaults All radios use the internal antenna by default, if the AP model has an internal antenna.

Access Enabled.

History

Usage This command applies only to the 802.11b/g radio on model 2330.

Examples The following command configures the 802.11b/g radio on AP 1 to use antenna model 24883:

WSS# set ap 1 radio 1 antennatype 24883

success: change accepted.

See Also [show ap config on page 344](#)



Note. The options displayed are dependent upon the access point model number that this CLI command is executed against.

set ap radio auto-tune max-power

Sets the maximum power that RF Auto-Tuning can set on a radio.

Syntax `set {ap port-list | auto} radio {1 | 2} auto-tune max-power power-level`

ap port-list	List of ports connected to the AP on which to set the maximum power.
ap ap-num	Number of a AP on which to set the maximum power.
ap auto	Sets the maximum power for radios configured by the AP configuration profile. (See set ap auto on page 245 .)
radio 1	Radio 1 of the AP.
radio 2	Radio 2 of the AP. (This option does not apply to single-radio models.)
<i>power-level</i>	Maximum power setting RF Auto-Tuning can assign to the radio, expressed as the number of decibels in relation to 1 milliwatt (dBm). You can specify a value from 1 up to the maximum value allowed for the country of operation. The <i>power-level</i> can be a value from 1 to 20.

Defaults The default maximum power setting that RF Auto-Tuning can set on a radio is the highest setting allowed for the country of operation or highest setting supported on the hardware, whichever is lower.

Access Enabled.

History

Version 4.0	Option auto added for configuration of the AP configuration profile.
Version 6.0	Option dap removed.

Examples The following command sets the maximum power that RF Auto-Tuning can set on radio 1 on the AP on port 7 to 12 dBm.

WSS# set ap 7 radio 1 auto-tune max-power 12
success: change accepted.

See Also

- **set radio-profile auto-tune power-config on page 282**
- **set radio-profile auto-tune power-interval on page 283**

set ap radio auto-tune max-retransmissions

Deprecated in WSS Software Version 5.0.

set ap radio auto-tune min-client-rate

Deprecated in WSS Software Version 5.0. To configure radio transmit rates, See **set service-profile transmit-rates on page 334**.

set ap radio channel

Sets an AP radio's channel.

Syntax `set {ap port-list | ap ap-num} radio {1 | 2} channel channel-number`

ap port-list	List of ports connected to the AP on which to set the channel.
ap ap-num	Number of a AP on which to set the channel.
radio 1	Radio 1 of the AP.
radio 2	Radio 2 of the AP. (This option does not apply to single-radio models.)
channel channel-number	Channel number. The valid channel numbers depend on the country of operation.

Defaults The default channel depends on the radio type:

- The default channel number for 802.11b/g is 6.
- The default channel number for 802.11a is the lowest valid channel number for the country of operation.

Access Enabled.

History

Version 1.0	Command introduced
Version 2.0	Option dap added for APs
Version 6.0	Option dap removed.

Usage You can configure a radio's transmit power on the same command line. Use the **tx-power** option. This command is not valid if dynamic channel tuning (RF Auto-Tuning) is enabled.

Examples The following command configures the channel on the 802.11a radio on the AP connected to port 5:

```
WSS# set ap 5 radio 1 channel 36
success: change accepted.
```

The following command configures the channel and transmit power on the 802.11b/g radio on the AP connected to port 11:

```
WSS# set ap 11 radio 1 channel 1 tx-power 10
success: change accepted.
```

See Also

- **set ap radio tx-power on page 272**
- **show ap config on page 344**

set ap radio min-tx-datarate

To specify the minimum rate at which a radio is allowed to transmit traffic to clients, see **Deprecated in WSS Software Version 5.0. on page 266**.

set ap radio link-calibration

Configures an AP radio to emit link calibration packets, which can aid in positioning a Mesh AP.

Syntax `set ap ap-number radio {1 | 2} link-calibration mode {enable | disable}`

ap <i>ap-number</i>	Index value that identifies the AP on the WSS.
radio 1	Radio 1 of the AP.
radio 2	Radio 2 of the AP. (This option does not apply to single-radio models.)
enable	Enables link calibration packets for the AP radio.
disable	Disables link calibration packets for the AP radio.

Defaults Disabled.

Access Enabled.

History Introduced in WSS Software Version 6.0.

Usage A Mesh Portal AP can be configured to emit link calibration packets to assist with positioning the Mesh AP. A link calibration packet is an unencrypted 802.11 management packet of type *Action*. When enabled on an AP, link calibration packets are sent at a rate of 5 per second.

Only one radio on an AP can be configured to send link calibration packets. Link calibration packets are intended to be used only during installation of APs; they are not intended to be enabled on a continual basis.

Examples The following command enables link calibration packets for AP radio 1 on AP 7:

```
WSS# set ap 7 radio 1 link-calibration mode enable
success : anchor calibration enabled on AP 7 on radio 1.
```

See Also

- [set ap boot-configuration mesh ssid on page 254](#)
- [set service-profile mesh on page 320](#)
- [show ap mesh-links on page 357](#)

set ap radio load-balancing

Disables or enables RF load balancing for an AP radio.

Syntax `set ap ap-num radio {1 | 2} load-balancing {enable | disable}`

ap <i>ap-number</i>	Index value that identifies the AP on the WSS.
radio 1	Radio 1 of the AP.
radio 2	Radio 2 of the AP. (This option does not apply to single-radio models.)
enable	Enables RF load balancing for the AP radio.
disable	Disables RF load balancing for the AP radio.

Defaults RF load balancing is enabled by default for all AP radios.

Access Enabled.

History Introduced in WSS Software Version 6.0.

Usage By default, RF load balancing is enabled on all AP radios. Use this command to disable or re-enable RF load balancing for the specified AP radio.

RF load balancing can also be disabled or re-enabled globally with the **set load-balancing mode** command. If RF load balancing has been enabled or disabled for a specific AP radio, then the setting for the individual radio takes precedence over the global setting.

Examples The following command disables RF load balancing for AP radio 1 on AP 7:

WSS# set ap 7 radio 1 load-balancing disable

success: change accepted.

See Also

- **set load-balancing strictness on page 277**
- **clear ap radio load-balancing group on page 241**
- **set ap local-switching mode on page 260**
- **show load-balancing group on page 375**

set ap radio load-balancing group

Assigns an AP radio to a load balancing group.

Syntax `set ap ap-num radio {1 | 2} load-balancing group name [rebalance]`

ap <i>ap-number</i>	Index value that identifies the AP on the WSS.
radio 1	Radio 1 of the AP.
radio 2	Radio 2 of the AP. (This option does not apply to single-radio models.)

group <i>name</i>	Name of an RF load balancing group to which the AP radio is assigned. A radio can belong to only one group.
rebalance	Configures the AP radio to disassociate its client sessions and rebalance them whenever a new AP radio is added to the load balancing group.

Defaults By default, AP radios are not part of an RF load balancing group.

Access Enabled.

History Introduced in WSS Software Version 6.0.

Usage Assigning radios to specific load balancing groups is optional. When you do this, WSS Software considers them to have exactly overlapping coverage areas, rather than using signal strength calculations to determine their overlapping coverage. WSS Software attempts to client sessions across radios in the load balancing group evenly. A radio can be assigned to only one group.

Examples The following command assigns AP radio 1 on AP 7 to load balancing group *room1*:

```
WSS# set ap 7 radio 1 load-balancing group room1
WSS#
```

See Also

- [set load-balancing strictness on page 277](#)
- [clear ap radio load-balancing group on page 241](#)
- [set ap local-switching mode on page 260](#)
- [show load-balancing group on page 371](#)

set ap radio mode

Enables or disables a radio on an AP.

Syntax `set {ap port-list | auto} } radio {1 | 2} mode {enable | disable}`

ap *port-list* List of ports connected to the AP(s) on which to turn a radio on or off.

ap *ap-num* Number of a AP on which to turn a radio on or off.

ap auto Sets the radio mode for APs managed by the AP configuration profile. (See [set ap auto on page 245](#).)

radio 1 Radio 1 of the AP.

radio 2 Radio 2 of the AP. (This option does not apply to single-radio models.)

mode enable Enables a radio.

mode disable Disables a radio.

Defaults AP radios are disabled by default.

Access Enabled.

History

Version 4.0	Option auto added for configuration of the AP configuration profile.
Version 6.0	Option dap removed.

Usage To enable or disable one or more radios to which a profile is assigned, use the **set ap radio radio-profile** command. To enable or disable all radios that use a specific radio profile, use the **set radio-profile** command.

Examples The following command enables radio 1 on the AP connected to ports 1 through 5:

```
WSS# set ap 1-5 radio 1 mode enable
success: change accepted.
```

The following command enables radio 2 on ports 1 through 3:

```
WSS# set ap 1-3 radio 2 mode enable
success: change accepted.
```

See Also

- **clear ap image**
- **set ap radio radio-profile** on page 271
- **set radio-profile mode** on page 291
- **show ap config** on page 344

set ap radio radio-profile

Assigns a radio profile to an AP radio and enables or disables the radio.

Syntax **set {ap *port-list* | auto} radio {1 | 2} radio-profile *name* mode {enable | disable}**

ap <i>port-list</i>	List of ports.
ap <i>ap-num</i>	Number of a AP.
ap auto	Sets the radio profile for the AP configuration profile. (See set ap auto on page 245.)
radio 1	Radio 1 of the AP.
radio 2	Radio 2 of the AP. (This option does not apply to single-radio models.)
radio-profile <i>name</i>	Radio profile name of up to 16 alphanumeric characters, with no spaces.
mode enable	Enables radios on the specified ports with the parameter settings in the specified radio profile.
mode disable	Disables radios on the specified ports.

Defaults None.

Access Enabled.

History

Version 4.0	Option auto added for configuration of the AP configuration profile.
Version 6.0	Option dap removed.

Usage When you create a new profile, the radio parameters in the profile are set to their factory default values.

To enable or disable all radios that use a specific radio profile, use **set radio-profile**.

Examples The following command enables radio 1 on ports 5 through 8 assigned to radio profile *rp1*:

```
WSS# set ap 5-8 radio 1 radio-profile rp1 mode enable
success: change accepted.
```

See Also

- **clear ap image**
- **set ap radio mode on page 270**
- **set radio-profile mode on page 291**
- **show radio-profile on page 376**

set ap radio tx-power

Sets an AP radio's transmit power.

Syntax **set** {**ap** *port-list* | **ap** *ap-num*} **radio** {**1** | **2**} **tx-power** *power-level*

ap *port-list* List of ports connected to the AP on which to set the transmit power.

ap *ap-num* Number of a AP on which to set the transmit power.

radio 1 Radio 1 of the AP.

radio 2 Radio 2 of the AP. (This option does not apply to single-radio models.)

tx-power *power-level* Number of decibels in relation to 1 milliwatt (dBm). The valid values depend on the country of operation.

Note: The maximum transmit power you can configure on any Nortel radio is the maximum allowed for the country in which you plan to operate the radio *or* one of the following values if that value is less than the country maximum: on an 802.11a radio, 11 dBm for channel numbers less than or equal to 64, or 10 dBm for channel numbers greater than 64; on an 802.11b/g radio, 16 dBm for all valid channel numbers for 802.11b, or 14 dBm for all valid channel numbers for 802.11g.

Defaults The default transmit power on all AP radio types is the highest setting allowed for the country of operation or highest setting supported on the hardware, whichever is lower.

Access Enabled.

Usage You also can configure a radio's channel on the same command line. Use the **channel** option.

This command is not valid if dynamic power tuning (RF Auto-Tuning) is enabled.

Examples The following command configures the transmit power on the 802.11a radio on the AP connected to port 5:

```
WSS# set ap 5 radio 1 tx-power 10  
success: change accepted.
```

The following command configures the channel and transmit power on the 802.11b/g radio on the AP connected to port 11:

```
WSS# set ap 11 radio 1 channel 1 tx-power 10  
success: change accepted.
```

See Also

- **set ap radio channel on page 267**
- **show ap config on page 344**

set ap security

Sets security requirements for management sessions between a WSS and its APs.

This feature applies to APs only, not to directly connected APs configured on AP access ports.



Note. The maximum transmission unit (MTU) for encrypted AP management traffic is 1498 bytes, whereas the MTU for unencrypted management traffic is 1474 bytes. Make sure the devices in the intermediate network between the WSS and AP can support the higher MTU.

Syntax `set ap security {require | optional | none}`

require	Requires all APs to have encryption keys that have been verified in the CLI by an administrator. If an AP does not have an encryption key or the key has not been verified, the WSS does not establish a management session with the AP.
optional	Allows APs to be managed by the switch even if they do not have encryption keys or their keys have not been verified by an administrator. Encryption is used for APs that support it.
none	Encryption is not used, even for APs that support it.

Defaults The default setting is **optional**.

Access Enabled.

History Introduced in WSS Software 4.0.
Option **dap** removed in 6.0.

Usage This parameter applies to all APs managed by the switch. If you change the setting to **required**, the switch requires APs to have encryption keys. The switch also requires their fingerprints to be verified in WSS Software. When AP security is required, an AP can establish a management session with the **WSS** only if its fingerprint has been verified by you in WSS Software.

A change to AP security support does not affect management sessions that are already established. To apply the new setting to an AP, restart the AP.

Examples The following command configures a **WSS** to require APs to have encryption keys:

```
WSS# set ap security none  
success : change accepted.
```

See Also

- [set ap fingerprint on page 257](#)
- [show ap config on page 344](#)
- [show ap status on page 358](#)

set ap sticky-bit

This command is deprecated in WSS Software Version 4.0. WSS assignment is always sticky. If an AP fails over to another **WSS** connection, the AP stays on that connection until the connection goes down or the WSS or AP is restarted.

set ap upgrade-firmware

Disables or reenables automatic upgrade of an AP's boot firmware.

Syntax `set {ap port-list | auto} upgrade-firmware {enable | disable}`

ap port-list	List of ports connected to the AP(s) on which to allow automatic firmware upgrades.
ap ap-num	Number of a AP on which to allow automatic firmware upgrades.
ap auto	Configures firmware upgrades for the AP configuration profile. (See set ap auto on page 245.)
enable	Enables automatic firmware upgrades.
disable	Disables automatic firmware upgrades.

Defaults Automatic firmware upgrades of AP are enabled by default.

Access Enabled.

History

Version 4.0	Option auto added for configuration of the AP configuration profile.
Version 6.0	Option dap removed.

Usage When the feature is enabled on a WSS port, an AP connected to that port upgrades its boot firmware to the latest version stored on the WSS while booting.

Examples The following command disables automatic firmware upgrades on the AP connected to port 9:

WSS# set ap 9 upgrade-firmware disable

See Also [show ap config on page 344](#)

set band-preference

Configures WSS Software to steer clients that support both the 802.11a and 802.11b/g radio bands to a specific radio on an AP for the purpose of RF load balancing.

Syntax `set band-preference {none | 11bg | 11a}`

none	When a client supports both 802.11a and 802.11b/g radio bands, does not steer the client to a specific AP radio.
11bg	When a client supports both 802.11a and 802.11b/g radio bands, steers the client to the 802.11b/g radio.
11a	When a client supports both 802.11a and 802.11b/g radio bands, steers the client to the 802.11a radio.

Defaults By default, clients are not steered to specific AP radios for RF load balancing.

Access Enabled.

History Introduced in WSS Software Version 6.0.

Usage Use this command to steer clients that support both the 802.11a and 802.11b/g bands, to a specific radio on an AP for the purpose of load balancing. This global “band-preference” option controls the degree that an AP with two radios attempts to conceal one of its radios from a client with the purpose of steering the client to the other radio.

Examples The following command steers clients that support both the 802.11a and 802.11b/g bands to the 802.11a radio on an AP:

WSS# set band-preference 11a

success : change accepted.

See Also

- [set load-balancing strictness on page 277](#)
- [set load-balancing mode on page 276](#)
- [set ap radio load-balancing on page 268](#)
- [show load-balancing group on page 375](#)

set load-balancing mode

Disables or enables RF load balancing globally on the WSS.

Syntax `set load-balancing mode {enable | disable}`

enable	Enables RF load balancing globally on the WSS switch.
disable	Disables RF load balancing globally on the WSS switch.

Defaults RF load balancing is enabled by default.

Access Enabled.

History Introduced in WSS Version 6.0.

Usage By default, RF load balancing is enabled on all AP radios. Use this command to disable or re-enable RF load balancing globally for all AP radios managed by the WSS switch.

If RF load balancing has been enabled or disabled for a specific AP radio, then the setting for the individual radio takes precedence over the global setting.

Examples The following command globally disables RF load balancing for all AP radios managed by the WSS switch:

```
WSS# set load-balancing mode disable
WSS#
```

See Also

- [set load-balancing strictness on page 277](#)
- [set band-preference on page 275](#)
- [set ap radio load-balancing on page 268](#)
- [show load-balancing group on page 375](#)

set load-balancing strictness

Controls the degree to which WSS balances the client load among APs when performing RF load balancing.

Syntax `set load-balancing strictness {low | med | high | max}`

low	No clients are denied service. New clients can be steered to other APs, but only to the extent that service can be provided to all clients.
med	Overloaded radios steer new clients to other APs more strictly than the low option. Clients attempting to connect to overloaded radios may be delayed several seconds.
high	Overloaded radios steer new clients to other APs more strictly than the med option. Clients attempting to connect to overloaded radios may be delayed up to a minute.
max	RF load balancing is strictly enforced. That is, overloaded radios do not respond to new clients at all. A client would not be able to connect during times that all of the detectable AP radios are overloaded.

Defaults Low.

Access Enabled.

History Introduced in WSS Version 6.0.

Usage When performing RF load balancing, WSS Software may attempt to steer clients to less-busy radios in a load-balancing group. To do this, WSS Software makes AP radios with heavy client loads less visible to new clients, causing them to associate with AP radios that have a lighter load.

Use this command to specify how strictly WSS Software attempts to keep the client load balanced

across the AP radios in the load-balancing group. When *low* strictness is specified (the default), WSS Software makes heavily loaded AP radios less visible in order to steer clients to less-busy AP radios, but ensures that even if all the AP radios in the group are heavily loaded, clients are not denied service.

At the other end of the spectrum, when *max* strictness is specified, if an AP radio has reached its maximum client load, WSS Software makes it invisible to new clients, causing them to attempt to connect to other AP radios. In the event that all the AP radios in the group have reached their maximum client load, then no new clients would be able to connect to the network.

Examples The following command sets the RF load balancing strictness to the maximum setting:

```
WSS# set load-balancing strictness max
```

```
Success: strictness set to "MAX"
```

See Also

- **set load-balancing mode on page 276**
- **set band-preference on page 275**
- **set ap radio load-balancing group on page 269**
- **show load-balancing group on page 375**

set radio-profile 11g-only

Deprecated in WSS Software Version 4.1. To configure radio data rates, see **set service-profile transmit-rates on page 334**.

set radio-profile active-scan

Disables or reenables active RF detection scanning on the AP radios managed by a radio profile. When active scanning is enabled, AP radios look for rogue devices by sending *probe any* requests (probe requests with a null SSID name), to solicit probe responses from other access points.

Passive scanning is always enabled and cannot be disabled. During passive scanning, radios look for rogues by listening for beacons and probe responses.

Syntax `set radio-profile name active-scan { enable | disable }`

name Radio profile name.

enable Configures radios to actively scan for rogues.

disable Configures radios to scan only passively for rogues by listening for beacons and probe responses.

Defaults Active scanning is enabled by default.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage You can enter this command on any WSS in the Mobility Domain. The command takes effect only on that switch.

Examples The following command disables active scan in radio profile *radprof3*:

```
WSS# set radio-profile radprof3 active-scan disable
success: change accepted.
```

See Also [show radio-profile on page 376](#)

set radio-profile auth-dot1x

Deprecated in WSS Software Version 3.0. In 3.0, this parameter is associated with service profiles instead of radio profiles. See [set service-profile auth-dot1x on page 307](#).

set radio-profile auth-psk

Deprecated in WSS Software Version 3.0. In 3.0, this parameter is associated with service profiles instead of radio profiles. See [set service-profile auth-psk on page 309](#).

set radio-profile auto-tune channel-config

Disables or reenables dynamic channel tuning (RF Auto-Tuning) for the AP radios in a radio profile.

Syntax `set radio-profile name auto-tune channel-config {enable | disable} [no-client]`

<i>name</i>	Radio profile name.
enable	Configures radios to dynamically select their channels when the radios are started.
disable	Configures radios to use their statically assigned channels, or the default channels if unassigned, when the radios are started.
no-client	Configures radios to change channels regardless of client status. Without this option, a radio changes the channel only if the radio does not have any active clients on that channel.

Defaults Dynamic channel assignment is enabled by default.

Access Enabled.

History

Version 5.0 Option **no-client** added.

Usage If you disable RF Auto-Tuning for channels, WSS Software does not dynamically set the channels when radios are first enabled and also does not tune the channels during operation.

If RF Auto-Tuning for channels is enabled, WSS Software does not allow you to manually change channels.

Even when RF Auto-Tuning for channels is enabled, WSS Software does not change the channel on radios that have active client sessions, unless you use the **no-client** option.

RF Auto-Tuning of channels on 802.11a radios uses only the bottom eight channels in the band (36, 40, 44, 48, 52, 56, 60, and 64). To use a higher channel number, you must disable RF Auto-Tuning of channels on the radio profile the radio is in, and use the **set ap radio channel** command to statically configure the channel.

Examples The following command disables dynamic channel tuning for radios in the *rp2* radio profile:

```
WSS# set radio-profile rp2 auto-tune channel-config disable
success: change accepted.
```

See Also

- **set ap radio channel on page 267**
- **set radio-profile auto-tune channel-holddown on page 280**
- **set radio-profile auto-tune channel-interval on page 281**
- **set radio-profile auto-tune power-config on page 282**
- **show radio-profile on page 376**

set radio-profile auto-tune channel-holddown

Sets the minimum number of seconds a radio in a radio profile must remain at its current channel assignment before RF Auto-Tuning can change the channel. The channel holddown provides additional stability to the network by preventing the radio from changing channels too rapidly in response to spurious RF anomalies such as short-duration channel interference.

Syntax **set radio-profile** *name* **auto-tune channel-holddown** *holddown*

name Radio profile name.

rate Minimum number of seconds a radio must remain on its current channel setting before RF Auto-Tuning is allowed to change the channel. You can specify from 0 to 65535 seconds.

Defaults The default RF Auto-Tuning channel holddown is 900 seconds.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage The channel holddown applies even if RF anomalies occur that normally cause an immediate channel change.

Examples The following command changes the channel holddown for radios in radio profile *rp2* to 600 seconds:

```
WSS# set radio-profile rp2 auto-tune channel-holddown 600
success: change accepted.
```

See Also

- **set radio-profile auto-tune channel-config on page 279**

- [set radio-profile auto-tune channel-interval on page 281](#)
- [set radio-profile auto-tune channel-lockdown on page 282](#)
- [show radio-profile on page 376](#)

set radio-profile auto-tune channel-interval

Sets the interval at which RF Auto-Tuning decides whether to change the channels on radios in a radio profile. At the end of each interval, WSS Software processes the results of the RF scans performed during the previous interval, and changes radio channels if needed.

Syntax `set radio-profile name auto-tune channel-interval seconds`

<i>name</i>	Radio profile name.
<i>seconds</i>	Number of seconds RF Auto-Tuning waits before changing radio channels to adjust to RF changes, if needed. You can specify from 0 to 65535 seconds.

Defaults The default channel interval is 3600 seconds (one hour).

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage Nortel recommends that you use an interval of at least 300 seconds (5 minutes).

RF Auto-Tuning can change a radio's channel before the channel interval expires in response to RF anomalies. Even in this case, channel changes cannot occur more frequently than the channel holddown interval.

If you set the interval to 0, RF Auto-Tuning does not reevaluate the channel at regular intervals. However, RF Auto-Tuning can still change the channel in response to RF anomalies.

Examples The following command sets the channel interval for radios in radio profile *rp2* to 2700 seconds (45 minutes):

```
WSS# set radio-profile rp2 auto-tune channel-interval 2700
success: change accepted.
```

See Also

- [set radio-profile auto-tune channel-config on page 279](#)
- [set radio-profile auto-tune channel-holddown on page 280](#)
- [set radio-profile auto-tune channel-lockdown on page 282](#)
- [show radio-profile on page 376](#)

set radio-profile auto-tune channel-lockdown

Locks down the current channel settings on all radios in a radio profile. The channel settings that are in effect when the command is entered are changed into statically configured channel assignments on the radios. RF Auto-Tuning of channels is then disabled in the radio profile.

Syntax `set radio-profile name auto-tune channel-lockdown`

name Radio profile name.

Defaults By default, when RF Auto-Tuning of channels is enabled, channels continue to be changed dynamically based on network conditions.

Access Enabled.

History Introduced in WSS Software Version 5.0.

Usage To save this command and the static channel configuration commands created when you enter this command, save the configuration.

Examples The following command locks down the channel settings for radios in radio profile *rp2*:

```
WSS# set radio-profile rp2 auto-tune channel-lockdown
success: change accepted.
```

See Also

- [set radio-profile auto-tune channel-config on page 279](#)
- [set radio-profile auto-tune channel-holddown on page 280](#)
- [set radio-profile auto-tune channel-interval on page 281](#)
- [set radio-profile auto-tune power-lockdown on page 284](#)
- [show radio-profile on page 376](#)

set radio-profile auto-tune power-backoff-timer

Deprecated in WSS Software Version 5.0.

set radio-profile auto-tune power-config

Enables or disables dynamic power tuning (RF Auto-Tuning) for the AP radios in a radio profile.

Syntax `set radio-profile name auto-tune power-config {enable | disable}`

<i>name</i>	Radio profile name.
enable	Configures radios to dynamically set their power levels when the APs are started.
disable	Configures radios to use their statically assigned power levels, or the default power levels if unassigned, when the radios are started.

Defaults Dynamic power assignment is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage When RF Auto-Tuning for power is disabled, WSS Software does not dynamically set the power levels when radios are first enabled and also does not tune power during operation with associated clients.

When RF Auto-Tuning for power is enabled, WSS Software does not allow you to manually change the power level.

Examples The following command enables dynamic power tuning for radios in the *rp2* radio profile:

```
WSS# set radio-profile rp2 auto-tune power-config enable
success: change accepted.
```

See Also

- [set ap radio auto-tune max-power on page 265](#)
- [set radio-profile auto-tune channel-config on page 279](#)
- [set radio-profile auto-tune power-interval on page 283](#)
- [set radio-profile auto-tune power-lockdown on page 284](#)
- [set radio-profile auto-tune power-lockdown on page 284](#)
- [show radio-profile on page 376](#)

set radio-profile auto-tune power-interval

Sets the interval at which RF Auto-Tuning decides whether to change the power level on radios in a radio profile. At the end of each interval, WSS Software processes the results of the RF scans performed during the previous interval, and changes radio power levels if needed.

Syntax `set radio-profile name auto-tune power-interval seconds`

<i>name</i>	Radio profile name.
<i>seconds</i>	Number of seconds WSS Software waits before changing radio power levels to adjust to RF changes, if needed. You can specify from 1 to 65535 seconds.

Defaults The default power tuning interval is 300 seconds.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Examples The following command sets the power interval for radios in radio profile *rp2* to 240 seconds:

```
WSS# set radio-profile rp2 auto-tune power-interval 240
```

success: change accepted.

See Also

- [set ap radio auto-tune max-power on page 265](#)
- [set radio-profile auto-tune power-config on page 282](#)
- [set radio-profile auto-tune power-lockdown on page 284](#)
- [set radio-profile auto-tune power-lockdown on page 284](#)
- [set radio-profile auto-tune power-ramp-interval on page 285](#)
- [show service-profile on page 380](#)

set radio-profile auto-tune power-lockdown

Locks down the current power settings on all radios in a radio profile. The power settings that are in effect when the command is entered are changed into statically configured power settings on the radios. RF Auto-Tuning of power is then disabled in the radio profile.

Syntax `set radio-profile name auto-tune power-lockdown`

name Radio profile name.

Defaults By default, when RF Auto-Tuning of power is enabled, power settings continue to be changed dynamically based on network conditions.

Access Enabled.

History Introduced in WSS Software Version 5.0.

Usage To save this command and the static power configuration commands created when you enter this command, save the configuration.

Examples The following command locks down the power settings for radios in radio profile *rp2*:

```
WSS# set radio-profile rp2 auto-tune power-lockdown
```

success: change accepted.

See Also

- [set ap radio auto-tune max-power on page 265](#)
- [set radio-profile auto-tune channel-lockdown on page 282](#)
- [set radio-profile auto-tune power-config on page 282](#)
- [set radio-profile auto-tune power-interval on page 283](#)
- [set radio-profile auto-tune power-ramp-interval on page 285](#)
- [show radio-profile on page 376](#)

set radio-profile auto-tune power-ramp-interval

Changes the interval at which power is increased or decreased, in 1 dBm increments, on radios in a radio profile until the optimum power level calculated by RF Auto-Tuning is reached.

Syntax `set radio-profile name auto-tune power-ramp-interval seconds`

<i>name</i>	Radio profile name.
<i>seconds</i>	Number of seconds WSS Software waits before increasing or decreasing radio power by another 1 dBm. You can specify from 1 to 65535.

Defaults The default interval is 60 seconds.

Access Enabled.

History Introduced in WSS Software Version 5.0.

Examples The following command changes the power ramp interval for radios in radio profile *rp2* to 120 seconds:

```
WSS# set radio-profile rp2 auto-tune power-ramp-interval 120
success: change accepted.
```

See Also

- [set ap radio auto-tune max-power on page 265](#)
- [set radio-profile auto-tune power-config on page 282](#)
- [set radio-profile auto-tune power-interval on page 283](#)
- [set radio-profile auto-tune power-lockdown on page 284](#)
- [show radio-profile on page 376](#)

set radio-profile beacon-interval

Changes the rate at which each AP radio in a radio profile advertises its service set identifier (SSID).

Syntax `set radio-profile name beacon-interval interval`

<i>name</i>	Radio profile name.
<i>interval</i>	Number of milliseconds (ms) between beacons. You can specify from 25 ms to 8191 ms.

Defaults The beacon interval for AP radios is 100 ms by default.

Access Enabled.

Usage You must disable all radios that are using a radio profile before you can change parameters in the profile. Use the `set radio-profile mode` command.

Examples The following command changes the beacon interval for radio profile *rp1* to 200 ms:

```
WSS# set radio-profile rp1 beacon-interval 200
success: change accepted.
```

See Also

- [set radio-profile mode on page 291](#)
- [show radio-profile on page 376](#)

set radio-profile beaconed-ssid

See [set service-profile beacon on page 310](#).

set radio-profile cipher-ccmp

See [set service-profile cipher-ccmp on page 312](#).

set radio-profile cipher-tkip

See [set service-profile cipher-tkip on page 313](#).

set radio-profile cipher-wep104

See [set service-profile cipher-wep104 on page 314](#).

set radio-profile cipher-wep40

See [set service-profile cipher-wep40 on page 315](#).

set radio-profile clear-ssid

See [set service-profile ssid-name on page 331](#) and [set service-profile ssid-type on page 332](#).

set radio-profile countermeasures



Caution! Countermeasures affect wireless service on a radio. When an AP radio is sending countermeasures, the radio is disabled for use by network traffic, until the radio finishes sending the countermeasures.

Enables or disables countermeasures on the AP radios managed by a radio profile. Countermeasures are packets sent by a radio to prevent clients from being able to use rogue access points.

AP radios can also issue countermeasures against interfering devices. An interfering device is not part of the Nortel network but also is not a rogue. No client connected to the device has been detected communicating with any network entity listed in the forwarding database (FDD) of any WSS in the Mobility Domain. Although the interfering device is not connected to your network, the device might be causing RF interference with AP radios.

Syntax `set radio-profile name countermeasures {all | rogue | configured | none}`

<i>name</i>	Radio profile name.
all	Configures radios to attack rogues and interfering devices.
rogue	Configures radios to attack rogues only.
configured	Configures radios to attack only devices in the attack list on the WSS (<i>on-demand</i> countermeasures). When this option is specified, devices found to be rogues by other means, such as policy violations or by determining that the device is providing connectivity to the wired network, are not attacked.
none	Disables countermeasures for this radio profile.

Defaults Countermeasures are disabled by default.

Access Enabled.

History

Version 4.0	Command introduced.
Version 4.1	New option configured added to support on-demand countermeasures.

Examples The following command enables countermeasures in radio profile *radprof3* for rogues only:

```
WSS# set radio-profile radprof3 countermeasures rogue
success: change accepted.
```

The following command disables countermeasures in radio profile *radprof3*:

```
WSS# clear radio-profile radprof3 countermeasures
success: change accepted.
```

The following command causes radios managed by radio profile *radprof3* to issue countermeasures against devices in the WSS's attack list:

```
WSS# set radio-profile radprof3 countermeasures configured
success: change accepted.
```

Note that when you issue this command, countermeasures are then issued only against devices in the WSS's attack list, not against other devices that were classified as rogues by other means.

See Also [show radio-profile on page 376](#)

set radio-profile crypto-ssid

See [set service-profile ssid-name on page 331](#) and [set service-profile ssid-type on page 332](#).

set radio-profile dtim-interval

Changes the number of times after every beacon that each AP radio in a radio profile sends a delivery traffic indication map (DTIM). An AP sends the multicast and broadcast frames stored in its buffers to clients who request them in response to the DTIM.



Note. The DTIM interval applies to both the beacons and the nonbeacons.

Syntax `set radio-profile name dtim-interval interval`

name Radio profile name.

interval Number of times the DTIM is transmitted after every beacon. You can enter a value from 1 through 31.

Defaults By default, APs send the DTIM once after each beacon.

Access Enabled.

Usage You must disable all radios that are using a radio profile before you can change parameters in the profile. Use the `set radio-profile mode` command.

The DTIM interval does not apply to unicast frames.

Examples The following command changes the DTIM interval for radio profile *rp1* to 2:

```
WSS# set radio-profile rp1 dtim-interval 2
success: change accepted.
```

See Also

- **set radio-profile mode on page 291**
- **show radio-profile on page 376**

set radio-profile frag-threshold

Changes the fragmentation threshold for the AP radios in a radio profile. The fragmentation threshold is the threshold at which the long-retry-count is applicable instead of the short-retry-count.

The long-retry-count specifies the number of times a radio can send a unicast frame that is equal to or longer than the frag-threshold without receiving an acknowledgment.

The short-retry-count specifies the number of times a radio can send a unicast frame that is shorter than the frag-threshold without receiving an acknowledgment.

Syntax `set radio-profile name frag-threshold threshold`

<i>name</i>	Radio profile name.
<i>threshold</i>	Maximum frame length, in bytes. You can enter a value from 256 through 2346.

Defaults The default fragmentation threshold for AP radios is 2346 bytes.

Access Enabled.

Usage You must disable all radios that are using a radio profile before you can change parameters in the profile. Use the **set radio-profile mode** command.

The frag-threshold does not specify the maximum length a frame is allowed to be without being broken into multiple frames before transmission. Nortel APs do not support fragmentation upon transmission, only upon reception.

The frag-threshold does not change the RTS threshold, which specifies the maximum length a frame can be before the radio uses the RTS/CTS method to send the frame. To change the RTS threshold, use the **set radio-profile rts-threshold** command instead.

Examples The following command changes the fragmentation threshold for radio profile *rp1* to 1500 bytes:

```
WSS# set radio-profile rp1 frag-threshold 1500
success: change accepted.
```

See Also

- **set radio-profile mode on page 291**
- **set radio-profile rts-threshold on page 297**
- **set service-profile long-retry-count on page 319**
- **set service-profile short-retry-count on page 325**
- **show radio-profile on page 376**

set radio-profile long-retry

Deprecated in WSS Software Version 4.1. In 4.1, this parameter is associated with service profiles instead of radio profiles. See [set service-profile long-retry-count on page 319](#).

set radio-profile max-rx-lifetime

Changes the maximum receive threshold for the AP radios in a radio profile. The maximum receive threshold specifies the number of milliseconds that a frame *received* by a radio can remain in buffer memory.

Syntax `set radio-profile name max-rx-lifetime time`

name Radio profile name.

time Number of milliseconds. You can enter a value from 500 (0.5 second) through 250,000 (250 seconds).

Defaults The default maximum receive threshold for AP radios is 2000 ms (2 seconds).

Access Enabled.

Usage You must disable all radios that are using a radio profile before you can change parameters in the profile. Use the `set radio-profile mode` command.

Examples The following command changes the maximum receive threshold for radio profile *rp1* to 4000 ms:

```
WSS# set radio-profile rp1 max-rx-lifetime 4000
success: change accepted.
```

See Also

- [set radio-profile mode on page 291](#)
- [set radio-profile max-tx-lifetime on page 290](#)
- [show radio-profile on page 376](#)

set radio-profile max-tx-lifetime

Changes the maximum transmit threshold for the AP radios in a radio profile. The maximum transmit threshold specifies the number of milliseconds that a frame *scheduled to be transmitted* by a radio can remain in buffer memory.

Syntax `set radio-profile name max-tx-lifetime time`

name Radio profile name.

time Number of milliseconds. You can enter a value from 500 (0.5 second) through 250,000 (250 seconds).

Defaults The default maximum transmit threshold for AP radios is 2000 ms (2 seconds).

Access Enabled.

Usage You must disable all radios that are using a radio profile before you can change parameters in the profile. Use the **set radio-profile mode** command.

Examples The following command changes the maximum transmit threshold for radio profile *rp1* to 4000 ms:

```
WSS# set radio-profile rp1 max-tx-lifetime 4000
success: change accepted.
```

See Also

- [set radio-profile mode on page 291](#)
- [set radio-profile max-rx-lifetime on page 290](#)
- [show radio-profile on page 376](#)

set radio-profile mode

Creates a new radio profile, or disables or reenables all AP radios that are using a specific profile.

Syntax `set radio-profile name [mode {enable | disable}]`

radio-profile *name* Radio profile name of up to 16 alphanumeric characters, with no spaces. Use this command without the **mode enable** or **mode disable** option to create a new profile.

mode enable Enables the radios that use this profile.

mode disable Disables the radios that use this profile.

Defaults Each radio profile that you create has a set of properties with factory default values that you can change with the other **set radio-profile** commands in this chapter. [Table 37](#) lists the parameters controlled by a radio profile and their default values.

Table 4: Defaults for Radio Profile Parameters

Parameter	Default Value	Radio Behavior When Parameter Set To Default Value
active-scan	enable	Sends <i>probe any</i> requests (probe requests with a null SSID name) to solicit probe responses from other access points.
auto-tune	enable	Allows dynamic configuration of channel and power settings by WSS Software.
beacon-interval	100	Waits 100 ms between beacons.

Table 4: Defaults for Radio Profile Parameters (continued)

Parameter	Default Value	Radio Behavior When Parameter Set To Default Value
countermeasures	Not configured	Does not issue countermeasures against any device.
dtim-interval	1	Sends the delivery traffic indication map (DTIM) after every beacon.
frag-threshold	2346	Uses the short-retry-count for frames shorter than 2346 bytes and uses the long-retry-count for frames that are 2346 bytes or longer.
max-rx-lifetime	2000	Allows a received frame to stay in the buffer for up to 2000 ms (2 seconds).
max-tx-lifetime	2000	Allows a frame that is scheduled for transmission to stay in the buffer for up to 2000 ms (2 seconds).
preamble-length	short	Advertises support for short 802.11b preambles, accepts either short or long 802.11b preambles, and generates unicast frames with the preamble length specified by the client. Note: This parameter applies only to 802.11b/g radios.
qos-mode	wmm	Classifies and marks traffic based on 802.1p and DSCP, and optimizes forwarding prioritization of AP radios for Wi-Fi Multimedia (WMM).
rfid-mode	disable	Radio does not function as a location receiver in an AeroScout Visibility System.
rts-threshold	2346	Transmits frames longer than 2346 bytes by means of the Request-to-Send/Clear-to-Send (RTS/CTS) method.
service-profile	No service profiles defined	You must configure a service profile. The service profile sets the SSID name and other parameters.
wmm-powersave	disable	Requires clients to send a separate PSpoll to retrieve each unicast packet buffered by the AP radio.

Access Enabled.

History

- Version 4.1
- Parameters that no longer apply to radio profiles in WSS Software Version 4.1 removed:
 - **11g-only**
 - **long-retry**
 - short-retry
 - **wmm** parameter name changed to **qos-mode**.
- Version 5.0
- Parameters added:
- **rfid-mode**
 - **wmm-powersave**

Usage Use the command without any optional parameters to create new profile. If the radio profile does not already exist, WSS Software creates a new radio profile. Use the **enable** or **disable** option to enable or disable all the radios using a profile. To assign the profile to one or more radios, use the **set ap radio radio-profile** command.

To change a parameter in a radio profile, you must first disable all the radios in the profile. After you complete the change, you can reenble the radios.

To enable or disable specific radios without disabling all of them, use the **set ap radio** command.

Examples The following command configures a new radio profile named *rp1*:

```
WSS# set radio-profile rp1
success: change accepted.
```

The following command enables the radios that use radio profile *rp1*:

```
WSS# set radio-profile rp1 mode enable
```

The following commands disable the radios that use radio profile *rp1*, change the beacon interval, then reenble the radios:

```
WSS# set radio-profile rp1 mode disable
WSS# set radio-profile rp1 beacon-interval 200
WSS# set radio-profile rp1 mode enable
```

The following command enables the WPA IE on AP radios in radio profile *rp2*:

```
WSS# set radio-profile rp2 wpa-ie enable
success: change accepted.
```

See Also

- **set ap radio mode** on page 270
- **set ap radio radio-profile** on page 271
- **show ap config** on page 344
- **show radio-profile** on page 376

set radio-profile preamble-length

Changes the preamble length for which an 802.11b/g AP radio advertises support. This command does not apply to 802.11a.

Syntax `set radio-profile name preamble-length {long | short}`

<i>name</i>	Radio profile name.
long	Advertises support for long preambles.
short	Advertises support for short preambles.

Defaults The default is **short**.

Access Enabled.

Usage Changing the preamble length value affects only the support advertised by the radio. Regardless of the preamble length setting (**short** or **long**), an 802.11b/g radio accepts and can generate 802.11b/g frames with either short or long preambles.

If a client associated with an 802.11b/g radio uses long preambles for unicast traffic, the AP still accepts frames with short preambles but does not transmit frames with short preambles. This change also occurs if the access point overhears a beacon from an 802.11b/g radio on another access point that indicates the radio has clients that require long preambles.

You must disable all radios that use a radio profile before you can change parameters in the profile. Use the **set radio-profile mode** command.

Examples The following command configures 802.11b/g radios that use the radio profile *rp_long* to advertise support for long preambles instead of short preambles:

```
WSS# set radio-profile rp_long preamble-length long
success: change accepted.
```

See Also

- [set radio-profile mode on page 291](#)
- [show radio-profile on page 376](#)

set radio-profile psk-phrase

See [set service-profile psk-phrase on page 322](#).

set radio-profile psk-raw

See [set service-profile psk-raw on page 323](#).

set radio-profile qos-mode

Sets the prioritization mode for forwarding queues on AP radios managed by the radio profile.

Syntax `set radio-profile name qos-mode {svp | wmm}`

svp	Optimizes forwarding prioritization of AP radios for SpectraLink Voice Priority (SVP).
wmm	Classifies and marks traffic based on 802.1p and DSCP, and optimizes forwarding prioritization of AP radios for Wi-Fi Multimedia (WMM).

Defaults The default QoS mode is **wmm**.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage When SVP is enabled, AP forwarding prioritization is optimized for SpectraLink Voice Priority (SVP) instead of WMM, and the AP does not tag packets it sends to the **WSS**. Otherwise, classification and tagging remain in effect. (For information, see the “Configuring Quality of Service” chapter of the [Nortel WLAN Security Switch 2300 Series Configuration Guide](#).)

If you plan to use SVP or another non-WMM type of prioritization, you must configure ACLs to tag the packets. (See the “Enabling Prioritization for Legacy Voice over IP” section in the “Configuring and Managing Security ACLs” chapter of the [Nortel WLAN Security Switch 2300 Series Configuration Guide](#).)

Examples The following command changes the QoS mode for radio profile *rp1* to SVP:

```
WSS# set radio-profile rp1 qos-mode svp
success: change accepted.
```

See Also

- [set radio-profile mode on page 291](#)
- [show radio-profile on page 376](#)

set radio-profile rate-enforcement

Configures WSS Software to enforce data rates, which means that a connecting client must transmit at one of the mandatory or standard rates in order to associate with the AP.

Syntax `set radio-profile name rate-enforcement {enable | disable}`

<i>name</i>	Radio profile name.
enable	Enables data rate enforcement for the radios in the radio profile.
disable	Disables data rate enforcement for the radios in the radio profile.

Defaults Data rate enforcement is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 6.0.

Usage Each type of radio (802.11a, 802.11b, and 802.11g) providing service to an SSID has a set of radio rates allowed for use when sending beacons, multicast frames, and unicast data. You can configure the rate set for each type of radio and specify rates in three categories:

- **Mandatory** . Valid 802.11 transmit rates that clients must support in order to associate with the AP
- **Disabled** . Valid 802.11 transmit rates are disabled. APs do not transmit at the disabled rates
- **Standard** . Valid 802.11 transmit rates that are not disabled and are not mandatory

By default, the rate set is not enforced, meaning that a client can associate with and transmit data to the AP using a disabled data rate, although the AP does not transmit data back to the client at the disabled rate.

You can use this command to enforce the data rates, which means that a connecting client must transmit at one of the mandatory or standard rates in order to associate with the AP. When data rate enforcement is enabled, clients transmitting at the disabled rates are not allowed to associate with the AP.

This command is useful if you want to completely prevent clients from transmitting at disabled data rates. For example, you can disable slower data rates so that clients transmitting at these rates do not consume bandwidth on the channel at the expense of clients transmitting at faster rates.

Examples The following command enables data rate enforcement for radio profile rp1:

```
WSS# set radio-profile rp1 rate-enforcement mode enable
success: change accepted.
```

See Also [set service-profile transmit-rates on page 334](#)

set radio-profile rfid-mode

Enables AP radios managed by a radio profile to function as location receivers in an AeroScout Visibility System. An AeroScout Visibility System allows system administrators to track mobile assets using RFID tags.

When you enable RFID mode on a radio profile, radios in the profile can receive and process signals transmitted by RFID tags and relay them with related information to the AeroScout Engine. If the floor plan is modeled in WLAN Management Software, you also can use WLAN Management Software to display the locations of assets.

Syntax `set radio-profile name rfid-mode {enable | disable}`

<i>name</i>	Radio profile name.
enable	Enables radios to function as asset location receivers.
disable	Disables radios from functioning as asset location receivers.

Defaults The default is **disable**.

Access Enabled.

History Introduced in WSS Software Version 5.0.

Examples The following command enables radios managed by radio profile *rp1* to act as asset location receivers:

WSS# set radio-profile rfid-mode enable
success: change accepted.

See Also

- [set radio-profile mode on page 291](#)
- [show radio-profile on page 376](#)

set radio-profile rts-threshold

Changes the RTS threshold for the AP radios in a radio profile. The RTS threshold specifies the maximum length a frame can be before the radio uses the RTS/CTS method to send the frame. The RTS/CTS method clears the air of other traffic to avoid corruption of the frame due to a collision with another frame.

Syntax `set radio-profile name rts-threshold threshold`

<i>name</i>	Radio profile name.
<i>threshold</i>	Maximum frame length, in bytes. You can enter a value from 256 through 3000.

Defaults The default RTS threshold for an AP radio is 2346 bytes.

Access Enabled.

Usage You must disable all radios that are using a radio profile before you can change parameters in the profile. Use the **set radio-profile mode** command.

Examples The following command changes the RTS threshold for radio profile *rp1* to 1500 bytes:

WSS# set radio-profile rp1 rts-threshold 1500
success: change accepted.

See Also

- [set radio-profile mode on page 291](#)
- [show radio-profile on page 376](#)

set radio-profile service-profile

Maps a service profile to a radio profile. All radios that use the radio profile also use the parameter settings, including SSID and encryption settings, in the service profile.

Syntax `set radio-profile name service-profile name`

radio-profile name Radio profile name of up to 16 alphanumeric characters, with no spaces.

service-profile name Service profile name of up to 16 alphanumeric characters, with no spaces.

Defaults A radio profile does not have a service profile associated with it by default. In this case, the radios in the radio profile use the default settings for parameters controlled by the service profile. [Table 38](#) lists the parameters controlled by a service profile and their default values.

Table 5: Defaults for Service Profile Parameters

Parameter	Default Value	Radio Behavior When Parameter Set To Default Value
attr	No attributes configured	Does not assign the SSID's authorization attribute values to SSID users, even if attributes are not otherwise assigned.
auth-dot1x	enable	When the Wi-Fi Protected Access (WPA) information element (IE) is enabled, uses 802.1X to authenticate WPA clients.
auth-fallthru	none	Denies access to users who do not match an 802.1X or MAC authentication rule for the SSID requested by the user.
auth-psk	disable	Does not support using a preshared key (PSK) to authenticate WPA clients.
beacon	enable	Sends beacons to advertise the SSID managed by the service profile.
cac-mode	none	Does not limit the number of active user sessions based on Call Admission Control (CAC).
cac-session	14	If session-based CAC is enabled (cac-mode is set to session), limits the number of active user sessions on a radio to 14.

Table 5: Defaults for Service Profile Parameters (continued)

Parameter	Default Value	Radio Behavior When Parameter Set To Default Value
cipher-ccmp	disable	Does not use Counter with Cipher Block Chaining Message Authentication Code Protocol (CCMP) to encrypt traffic sent to WPA clients.
cipher-tkip	enable	When the WPA IE is enabled, uses Temporal Key Integrity Protocol (TKIP) to encrypt traffic sent to WPA clients.
cipher-wep104	disable	Does not use Wired Equivalent Privacy (WEP) with 104-bit keys to encrypt traffic sent to WPA clients.
cipher-wep40	disable	Does not use WEP with 40-bit keys to encrypt traffic sent to WPA clients.
cos	0	If static CoS is enabled (static-cos is set to enable), assigns CoS 0 to all data traffic to or from clients.
dhcp-restrict	disable	Does not restrict a client's traffic to only DHCP traffic while the client is being authenticated and authorized.
idle-client-probing	enable	Sends a keepalive packet (a null-data frame) to each client every 10 seconds.
keep-initial-vlan	disable	Reassigns the user to a VLAN after roaming, instead of leaving the roamed user on the VLAN assigned by the switch where the user logged on. Note: Enabling this option does not retain the user's initial VLAN assignment in all cases. (For information, see “set service-profile keep-initial-vlan” on page 317.)
long-retry-count	5	Sends a long unicast frame up to five times without acknowledgment.

Table 5: Defaults for Service Profile Parameters (continued)

Parameter	Default Value	Radio Behavior When Parameter Set To Default Value
no-broadcast	disable	Does not reduce wireless broadcast traffic by sending unicasts to clients for ARP requests and DHCP Offers and Acks instead of forwarding them as multicasts.
proxy-arp	disable	Does not reply on behalf of wireless clients to ARP requests for client IP addresses. Instead, the radio forwards the ARP Requests as wireless broadcasts.
psk-phrase	No passphrase defined	Uses dynamically generated keys rather than statically configured keys to authenticate WPA clients.
psk-raw	No preshared key defined	Uses dynamically generated keys rather than statically configured keys to authenticate WPA clients.
rsn-ie	disable	Does not use the RSN IE in transmitted frames. (The RSN IE is required for 802.11i. RSN is sometimes called WPA2.)
shared-key-auth	disable	Does not use shared-key authentication. This parameter does not enable PSK authentication for WPA. To enable PSK encryption for WPA, use the set radio-profile auth-psk command.
short-retry-count	5	Sends a short unicast frame up to five times without acknowledgment.
soda	disable	Sygate On Demand Agent (SODA) files are not downloaded to connecting clients.
ssid-name	trapeze	Uses the SSID name <i>trapeze</i> .
ssid-type	crypto	Encrypts wireless traffic for the SSID.
static-cos	disable	Assigns CoS based on the QoS mode (wmm or svp) or based on ACLs.

Table 5: Defaults for Service Profile Parameters (continued)

Parameter	Default Value	Radio Behavior When Parameter Set To Default Value
tkip-mc-time	60000	Uses Michael countermeasures for 60,000 ms (60 seconds) following detection of a second MIC failure within 60 seconds.
transmit-rates	802.11a: <ul style="list-style-type: none"> • mandatory: 6.0,12.0,24.0 • beacon-rate: 6.0 • multicast-rate: auto • disabled: none 802.11b: <ul style="list-style-type: none"> • mandatory: 1.0,2.0 • beacon-rate: 2.0 • multicast-rate: auto • disabled: none 802.11g: <ul style="list-style-type: none"> • mandatory: 1.0,2.0,5.5,11.0 • beacon-rate: 2.0 • multicast-rate: auto • disabled: none 	Accepts associations only from clients that support one of the mandatory rates. Sends beacons at the specified rate (6 Mbps for 802.11a, 2 Mbps for 802.11b/g). Sends multicast data at the highest rate that can reach all clients connected to the radio. Accepts frames from clients at all valid data rates. (No rates are disabled by default.)
user-idle-timeout	180	Allows a client to remain idle for 180 seconds (3 minutes) before WSS Software changes the client's session to the Disassociated state.

Table 5: Defaults for Service Profile Parameters (continued)

Parameter	Default Value	Radio Behavior When Parameter Set To Default Value
web-portal-acl	portalacl Note: This is the default only if the fallthru type on the service profile has been set to web-portal . Otherwise, the value is unconfigured.	If set to portalacl and the service profile fallthru is set to web-portal , radios use the <i>portalacl</i> ACL to filter traffic for Web Portal users during authentication. If the fallthru type is web-portal but web-portal-acl is set to an ACL other than <i>portalacl</i> , the other ACL is used. If the fallthru type is not web-portal , radios do not use the web-portal-acl setting.
web-portal-form	Not configured	For Web-based AAA users, serves the Nortel login page.
web-portal-session-timeout	5	Allows a Web Portal Web-based AAA session to remain in the Deassociated state 5 seconds before being terminated automatically.
wep key-index	No keys defined	Uses dynamic WEP rather than static WEP. Note: If you configure a WEP key for static WEP, WSS Software continues to also support dynamic WEP.
wep active-multicast-index	1	Uses WEP key 1 for static WEP encryption of multicast traffic if WEP encryption is enabled and keys are defined.
wep active-unicast-index	1	Uses WEP key 1 for static WEP encryption of unicast traffic if WEP encryption is enabled and keys are defined.
wpa-ie	disable	Does not use the WPA IE in transmitted frames.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage You must configure the service profile before you can map it to a radio profile. You can map the same service profile to more than one radio profile.

You must disable all radios that use a radio profile before you can change parameters in the profile. Use the **set radio-profile mode** command.

Examples The following command maps service-profile *wpa_clients* to radio profile *rp2*:

```
WSS# set radio-profile rp2 service-profile wpa_clients
success: change accepted.
```

See Also

- [set service-profile attr on page 306](#)
- [set service-profile auth-dot1x on page 307](#)
- [set service-profile auth-fallthru on page 308](#)
- [set service-profile auth-psk on page 309](#)
- [set service-profile beacon on page 310](#)
- [set service-profile cac-mode on page 311](#)
- [set service-profile cac-session on page 312](#)
- [set service-profile cipher-ccmp on page 312](#)
- [set service-profile cipher-tkip on page 313](#)
- [set service-profile cipher-wep104 on page 314](#)
- [set service-profile cipher-wep40 on page 315](#)
- [set service-profile cos on page 315](#)
- [set service-profile dhcp-restrict on page 316](#)
- [set service-profile idle-client-probing on page 317](#)
- [set service-profile long-retry-count on page 319](#)
- [set service-profile no-broadcast on page 320](#)
- [set service-profile proxy-arp on page 321](#)
- [set service-profile psk-phrase on page 322](#)
- [set service-profile psk-raw on page 323](#)
- [set service-profile rsn-ie on page 323](#)
- [set service-profile shared-key-auth on page 324](#)
- [set service-profile short-retry-count on page 325](#)
- [set service-profile soda mode on page 329](#)
- [set service-profile ssid-name on page 331](#)
- [set service-profile ssid-type on page 332](#)
- [set service-profile static-cos on page 332](#)
- [set service-profile tkip-mc-time on page 333](#)
- [set service-profile transmit-rates on page 334](#)
- [set service-profile user-idle-timeout on page 336](#)
- [set service-profile web-portal-form on page 337](#)
- [set service-profile web-portal-logout on page 339](#)
- [set service-profile wep active-multicast-index on page 340](#)
- [set service-profile wep active-unicast-index on page 341](#)

- **set service-profile wep key-index** on page 342
- **set service-profile wpa-ie** on page 342
- **show radio-profile** on page 376
- **show service-profile** on page 380

set radio-profile shared-key-auth

See **set service-profile shared-key-auth** on page 324.

set radio-profile short-retry

Deprecated in WSS Software Version 4.1. In 4.1, this parameter is associated with service profiles instead of radio profiles. See **set service-profile short-retry-count** on page 325.

set radio-profile tkip-mc-time

See **set service-profile tkip-mc-time** on page 333.

set radio-profile wep active-multicast-index

See **set service-profile wep active-multicast-index** on page 340.

set radio-profile wep active-unicast-index

See **set service-profile wep active-unicast-index** on page 341.

set radio-profile wep key-index

See **set service-profile wep key-index** on page 342.

set radio-profile wmm

Deprecated in WSS Software Version 4.1. To enable or disable WMM, see **set radio-profile qos-mode** on page 295.

set radio-profile wmm-powersave

Enables Unscheduled Automatic Powersave Delivery (U-APSD) on AP radios managed by the radio profile. U-APSD enables WMM clients that use powersave mode to more efficiently request buffered unicast packets from AP radios.

When U-APSD is enabled, a client can retrieve buffered unicast packets for a traffic priority enabled for U-APSD by sending a QoS data or QoS-Null frame for that priority. U-APSD can be enabled for individual traffic priorities, for individual clients, based on the client's request. A client enables U-APSD for a traffic priority by indicating this preference when (re)associating with the AP radio.

A client can but is not required to request U-APSD for all four traffic priorities. The AP radio still buffers packets for all traffic priorities even if the client does not request U-APSD for them. However, to retrieve buffered packets for priorities that are not using U-APSD, a client must send a separate PSpoll for each buffered packet.

Syntax `set radio-profile name wmm-powersave {enable | disable}`

<i>name</i>	Radio profile name.
enable	Enables U-APSD.
disable	Disables U-APSD.

Defaults U-APSD is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 5.0.

Usage U-APSD is supported only for QoS mode WMM. If WMM is not enabled on the radio profile, use the `set radio-profile qos-mode` command to enable it.

Examples The following command enables U-APSD on radio profile *rp1*:

```
WSS# set radio-profile rp1 wmm-powersave enable
success: change accepted.
```

See Also

- `set radio-profile mode` on page 291
- `set radio-profile qos-mode` on page 295
- `show radio-profile` on page 376

set radio-profile wpa-ie

See `set service-profile wpa-ie` on page 342.

set service-profile attr

Configures authorization attributes that are applied by default to users accessing the SSID managed by the service profile. These SSID default attributes are applied in addition to any supplied by the RADIUS server or from the local database.

Syntax `set service-profile name attr attribute-name value`

<i>name</i>	Service profile name.
<i>attribute-name value</i>	Name and value of an attribute you are using to authorize SSID users for a particular service or session characteristic. For a list of authorization attributes and values that you can assign to network users, see Table 29 on page 198 . All of the attributes listed in Table 29 can be used with this command except ssid .

Defaults By default, a service profile does not have any authorization attributes set.

Access Enabled.

History Introduced in WSS Software 4.1.

Usage To change the value of a default attribute for a service profile, use the **set service-profile attr** command and specify a new value.

The SSID default attributes are applied *in addition* to any attributes supplied for the user by the RADIUS server or the local database. When the same attribute is specified both as an SSID default attribute and through AAA, then the attribute supplied by the RADIUS server or the local database takes precedence over the SSID default attribute. If a location policy is configured, the location policy rules also take precedence over SSID default attributes. The SSID default attributes serve as a fallback when neither the AAA process, nor a location policy, provides them.

For example, a service profile might be configured with the **service-type** attribute set to 2. If a user accessing the SSID is authenticated by a RADIUS server, and the RADIUS server returns the **vlan-name** attribute set to *orange*, then that user will have a total of two attributes set: **service-type** and **vlan-name**.

If the service profile is configured with the **vlan-name** attribute set to *blue*, and the RADIUS server returns the **vlan-name** attribute set to *orange*, then the attribute from the RADIUS server takes precedence; the user is placed in the orange VLAN.

You can display the attributes for each connected user and whether they are set through AAA or through SSID defaults by entering the **show sessions network verbose** command. You can display the configured SSID defaults by entering the **show service-profile** command.

Examples The following command assigns users accessing the SSID managed by service profile *sp2* to VLAN *blue*:

```
WSS# set service-prof sp2 attr vlan-name blue
success: change accepted.
```

The following command assigns users accessing the SSID managed by service profile *sp2* to the Mobility Profile *tulip*.

```
WSS# set service-prof sp2 attr mobility-profile tulip
success: change accepted.
```

The following command limits the days and times when users accessing the SSID managed by service profile *sp2* can access the network, to 5 p.m. to 2 a.m. every weekday, and all day Saturday and Sunday:

```
WSS# set service-prof sp2 attr time-of-day Wk1700-0200,Sa,Su
success: change accepted.
```

See Also

- [show service-profile on page 380](#)
- [show sessions network on page 439](#)

set service-profile auth-dot1x

Disables or reenables 802.1X authentication of Wi-Fi Protected Access (WPA) clients by AP radios, when the WPA information element (IE) is enabled in the service profile that is mapped to the radio profile that the radios are using.

```
Syntax set service-profile name auth-dot1x {enable | disable}
```

<i>name</i>	Service profile name.
enable	Enables 802.1X authentication of WPA clients.
disable	Disables 802.1X authentication of WPA clients.

Defaults When the WPA IE is enabled, 802.1X authentication of WPA clients is enabled by default. If the WPA IE is disabled, the **auth-dot1x** setting has no effect.

Access Enabled.

Usage This command does not disable dynamic WEP for non-WPA clients. To disable dynamic WEP for non-WPA clients, enable the WPA IE (if not already enabled) and disable the 40-bit WEP and 104-bit WEP cipher suites in the WPA IE, if they are not already disabled.

To use 802.1X authentication for WPA clients, you also must enable the WPA IE.

If you disable 802.1X authentication of WPA clients, the only method available for authenticating the clients is preshared key (PSK) authentication. To use this, you must enable PSK support and configure a passphrase or key.

Examples The following command disables 802.1X authentication for WPA clients that use service profile *wpa_clients*:

```
WSS# set service-profile wpa_clients auth-dot1x disable
success: change accepted.
```

See Also

- [set service-profile auth-psk on page 309](#)
- [set service-profile psk-phrase on page 322](#)
- [set service-profile wpa-ie on page 342](#)
- [show service-profile on page 380](#)

set service-profile auth-fallthru

Specifies the authentication type for users who do not match an 802.1X or MAC authentication rule for an SSID managed by the service profile. When a user tries to associate with an SSID, WSS Software checks the authentication rules for that SSID for a userwildcard that matches the username. If the SSID does not have an authentication rule that matches the username, authentication for the user *falls through* to the fallthru type.

The fallthru type is a service profile parameter, and applies to all radios within the radio profiles that are mapped to the service profile.

Syntax `set service-profile name auth-fallthru {last-resort | none | web-portal}`

last-resort	Automatically authenticates the user and allows access to the SSID requested by the user, without requiring a username and password.
none	Denies authentication and prohibits the user from accessing the SSID. Note: The fallthru authentication type none is different from the authentication method none you can specify for administrative access. The fallthru authentication type none denies access to a network user. In contrast, the authentication method none allows access to the WSS by an administrator. (See “set authentication admin” on page 182 and “set authentication console” on page 183 .)
web-portal	Serves the user a web page from the WSS’s nonvolatile storage for secure login to the network.

Defaults The default fallthru authentication type is **none**.

If a username does not match a userwildcard in an authentication rule for the SSID requested by the user, the WSS that is managing the radio the user is connected to redirects the user to a web page located on the WSS. The user must type a valid username and password on the web page to access the SSID.

Access Enabled.

History

Version 4.0	Option for Web-based AAA fallthru authentication type changed from web-auth to web-portal . Default changed to none .
-------------	---

Usage The **last-resort** fallthru authentication type allows any user to access any SSID managed by the service profile. This method does not require the user to provide a username or password. Use the **last-resort** method only if none of the SSIDs managed by the service profile require secure access.

The **web-portal** authentication type also requires additional configuration items. (See the “Configuring AAA for Network Users” chapter of the *Nortel WLAN Security Switch 2300 Series Configuration Guide*.)

Examples The following command sets the fallback authentication type for SSIDS managed by the service profile *rnd_lab* to web-portal:

```
WSS# set service-profile rnd_lab auth-fallthru web-portal
success: change accepted.
```

See Also

- [set web-portal on page 209](#)
- [set service-profile web-portal-form on page 337](#)
- [show service-profile on page 380](#)

set service-profile auth-psk

Enables preshared key (PSK) authentication of Wi-Fi Protected Access (WPA) clients by AP radios in a radio profile, when the WPA information element (IE) is enabled in the service profile.

Syntax `set service-profile name auth-psk {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables PSK authentication of WPA clients.
disable	Disables PSK authentication of WPA clients.

Defaults When the WPA IE is enabled, PSK authentication of WPA clients is enabled by default. If the WPA IE is disabled, the **auth-psk** setting has no effect.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage This command affects authentication of WPA clients only.

To use PSK authentication, you also must configure a passphrase or key. In addition, you must enable the WPA IE.

Examples The following command enables PSK authentication for service profile *wpa_clients*:

```
WSS# set service-profile wpa_clients auth-psk enable
success: change accepted.
```

See Also

- [set service-profile auth-dot1x on page 307](#)
- [set service-profile psk-raw on page 323](#)
- [set service-profile wpa-ie on page 342](#)
- [show service-profile on page 380](#)

set service-profile beacon

Disables or reenables beaconing of the SSID managed by the service profile.

An AP radio responds to an 802.11 *probe any* request with only the beacons SSID(s). For a nonbeaconed SSID, radios respond only to directed 802.11 probe requests that match the nonbeaconed SSID's SSID string.

When you disable beaconing for an SSID, the radio still sends beacon frames, but the SSID name in the frames is blank.

Syntax `set service-profile name beacon {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables beaconing of the SSID managed by the service profile.
disable	Disables beaconing of the SSID managed by the service profile.

Defaults Beaconing is enabled by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Examples The following command disables beaconing of the SSID managed by service profile *sp2*:

```
WSS# set service-profile sp2 beacon disable
success: change accepted.
```

See Also

- [set radio-profile beacon-interval on page 285](#)
- [set service-profile ssid-name on page 331](#)
- [set service-profile ssid-type on page 332](#)
- [show service-profile on page 380](#)

set service-profile bridging

Enables wireless bridging for a service profile configured for WLAN mesh services.

Syntax `set service-profile mesh-service-profile bridging {enable | disable}`

<i>mesh-service-profile</i>	Mesh service profile.
Enable	Enables wireless bridging for the service profile..
Disable	Disables wireless bridging for the service profile.

Defaults None.

Access Enabled.

History Introduced in WSS Software version 6.0.

Usage WLAN mesh services can be used in a wireless bridge configuration, implementing APs as bridge endpoints in a transparent Layer 2 bridge. A typical application of wireless bridging is to provide network connectivity between two buildings using a wireless link.

A Mesh Portal AP serving as a bridge endpoint can support up to five Mesh APs serving as bridge endpoints. A Mesh AP serving as a bridge endpoint picks up packets from its wired port and transfers them to the other bridge endpoint. A simple source/destination learning mechanism is used in order to avoid forwarding packets across the bridge unnecessarily.

When wireless bridging is enabled for a service profile, the APs with the applied service profile serve as bridge peers. When a Mesh AP associates with a Mesh Portal AP through this service profile, the Mesh Portal AP automatically configures the Mesh AP to operate in bridge mode.

Examples The following command enables wireless bridging on service profile *sp1*:

```
WSS# set service-profile sp1 bridging enable
success: change accepted.
```

See Also

- [set ap boot-configuration mesh ssid on page 254](#)
- [set service-profile mesh on page 320](#)
- [show ap mesh-links on page 357](#)

set service-profile cac-mode

Configures the Call Admission Control (CAC) mode.

Syntax `set service-profile name cac-mode { none | session }`

<i>name</i>	Service profile name.
none	CAC is not used.
session	CAC is based on the number of active sessions.

Defaults The default CAC mode is **none**.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command enables session-based CAC on service profile *sp1*:

```
WSS# set service-profile sp1 cac-mode session
success: change accepted.
```

See Also

- [set service-profile cac-session on page 312](#)
- [show service-profile on page 380](#)

set service-profile cac-session

Specifies the maximum number of active sessions a radio can have when session-based CAC is enabled. When an AP radio has reached the maximum allowed number of active sessions, the radio refuses connections from additional clients.

Syntax `set service-profile name cac-session max-sessions`

name Service profile name.

max-sessions Maximum number of active sessions allowed on the radio.

Defaults The default number of sessions allowed is 14.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage This command applies only when the CAC mode is **session**. If the CAC mode is **none**, you can still change the maximum number of sessions, but the setting does not take effect until you change the CAC mode to **session**. To change the CAC mode, use the **set service-profile cac-mode** command.

Examples The following command changes the maximum number of sessions for radios used by service profile *sp1* to 10:

```
WSS# set service-profile sp1 cac-session 10
```

```
success: change accepted.
```

See Also

- [set service-profile cac-mode on page 311](#)
- [show service-profile on page 380](#)

set service-profile cipher-ccmp

Enables Counter with Cipher Block Chaining Message Authentication Code Protocol (CCMP) encryption with WPA clients, for a service profile.

Syntax `set service-profile name cipher-ccmp {enable | disable}`

name Service profile name.

enable Enables CCMP encryption for WPA clients.

disable Disables CCMP encryption for WPA clients.

Defaults CCMP encryption is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage To use CCMP, you must also enable the WPA IE.

Examples The following command configures service profile *sp2* to use CCMP encryption:

```
WSS# set service-profile sp2 cipher-ccmp enable
success: change accepted.
```

See Also

- [set service-profile cipher-tkip on page 313](#)
- [set service-profile cipher-wep104 on page 314](#)
- [set service-profile cipher-wep40 on page 315](#)
- [set service-profile wpa-ie on page 342](#)
- [show service-profile on page 380](#)

set service-profile cipher-tkip

Disables or reenables Temporal Key Integrity Protocol (TKIP) encryption in a service profile.

Syntax `set service-profile name cipher-tkip {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables TKIP encryption for WPA clients.
disable	Disables TKIP encryption for WPA clients.

Defaults When the WPA IE is enabled, TKIP encryption is enabled by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage To use TKIP, you must also enable the WPA IE.

Examples The following command disables TKIP encryption in service profile *sp2*:

```
WSS# set service-profile sp2 cipher-tkip disable
success: change accepted.
```

See Also

- [set service-profile cipher-ccmp on page 312](#)
- [set service-profile cipher-wep104 on page 314](#)
- [set service-profile cipher-wep40 on page 315](#)
- [set service-profile tkip-mc-time on page 333](#)
- [set service-profile wpa-ie on page 342](#)
- [show service-profile on page 380](#)

set service-profile cipher-wep104

Enables dynamic Wired Equivalent Privacy (WEP) with 104-bit keys, in a service profile.

Syntax `set service-profile name cipher-wep104 {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables 104-bit WEP encryption for WPA clients.
disable	Disables 104-bit WEP encryption for WPA clients.

Defaults 104-bit WEP encryption is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage To use 104-bit WEP with WPA clients, you must also enable the WPA IE.

When 104-bit WEP in WPA is enabled in the service profile, radios managed by a radio profile that is mapped to the service profile can also support non-WPA clients that use dynamic WEP.

To support WPA clients that use 40-bit dynamic WEP, you must enable WEP with 40-bit keys. Use the **set service-profile cipher-wep40** command.

Microsoft Windows XP does not support WEP with WPA. To configure a service profile to provide dynamic WEP for XP clients, leave WPA disabled and use the **set service-profile wep** commands.

To support non-WPA clients that use static WEP, you must configure static WEP keys. Use the **set service-profile wep key-index** command.

Examples The following command configures service profile *sp2* to use 104-bit WEP encryption:

```
WSS# set service-profile sp2 cipher-wep104 enable
success: change accepted.
```

See Also

- [set service-profile cipher-ccmp on page 312](#)
- [set service-profile cipher-tkip on page 313](#)
- [set service-profile cipher-wep40 on page 315](#)
- [set service-profile wep key-index on page 342](#)
- [set service-profile wpa-ie on page 342](#)
- [show service-profile on page 380](#)

set service-profile cipher-wep40

Enables dynamic Wired Equivalent Privacy (WEP) with 40-bit keys, in a service profile.

Syntax `set service-profile name cipher-wep40 {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables 40-bit WEP encryption for WPA clients.
disable	Disables 40-bit WEP encryption for WPA clients.

Defaults 40-bit WEP encryption is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage To use 40-bit WEP with WPA clients, you must also enable the WPA IE.

When 40-bit WEP in WPA is enabled in the service profile, radios managed by a radio profile that is mapped to the service profile can also support non-WPA clients that use dynamic WEP.

To support WPA clients that use 104-bit dynamic WEP, you must enable WEP with 104-bit keys in the service profile. Use the **set service-profile cipher-wep104** command.

Microsoft Windows XP does not support WEP with WPA. To configure a service profile to provide dynamic WEP for XP clients, leave WPA disabled and use the **set service-profile wep** commands.

To support non-WPA clients that use static WEP, you must configure static WEP keys. Use the **set service-profile wep key-index** command.

Examples The following command configures service profile *sp2* to use 40-bit WEP encryption:

```
WSS# set service-profile sp2 cipher-wep40 enable
success: change accepted.
```

See Also

- **set service-profile cipher-ccmp on page 312**
- **set service-profile cipher-tkip on page 313**
- **set service-profile cipher-wep104 on page 314**
- **set service-profile wep key-index on page 342**
- **set service-profile wpa-ie on page 342**
- **show service-profile on page 380**

set service-profile cos

Sets the Class-of-Service (CoS) level for static CoS.

Syntax `set service-profile name cos level`

name Service profile name.

level CoS value assigned by the AP to all traffic in the service profile.

Defaults The default static CoS level is 0.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage This command applies only when static CoS is enabled. If static CoS is disabled, prioritization is based on the QoS mode configured in the radio profile, and on any ACLs that set CoS. (See the “Configuring Quality of Service” chapter of the *Nortel WLAN Security Switch 2300 Series Configuration Guide*.) To enable static CoS, use the `set service-profile static-cos` command.

Examples The following command changes the static CoS level to 7 (voice priority):

```
WSS# set service-profile sp1 cos 7
```

success: change accepted.

See Also

- `set service-profile static-cos` on page 332
- `show service-profile` on page 380

set service-profile dhcp-restrict

Enables or disables DHCP Restrict on a service profile. DHCP Restrict filters a newly associated client’s traffic to allow DHCP traffic only, until the client has been authenticated and authorized. All other traffic is captured by the **WSS** and is not forwarded. After the client is successfully authorized, the traffic restriction is removed.

Syntax `set service-profile name dhcp-restrict {enable | disable}`

name Service profile name.

enable Enables DHCP Restrict.

disable Disables DHCP Restrict.

Defaults DHCP Restrict is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage To further reduce the overhead of DHCP traffic, use the `set service-profile no-broadcast` command to disable DHCP broadcast traffic from AP radios to clients on the service profile’s SSID.

Examples The following command enables DHCP Restrict on service profile *sp1*:

```
WSS# set service-profile sp1 dhcp-restrict enable
```

success: change accepted.

See Also

- **set service-profile no-broadcast** on page 320
- **set service-profile proxy-arp** on page 321
- **show service-profile** on page 380

set service-profile idle-client-probing

Disables or reenables periodic keepalives from AP radios to clients on a service profile's SSID. When idle-client probing is enabled, the AP radio sends a unicast null-data frame to each client every 10 seconds. Normally, a client that is still active sends an Ack in reply to the keepalive.

If a client does not send any data or respond to any keepalives before the user idle timeout expires, WSS Software changes the client's session to the Disassociated state.

Syntax `set service-profile name idle-client-probing {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables keepalives.
disable	Disables keepalives.

Defaults Idle-client probing is enabled by default.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage The length of time a client can remain idle (unresponsive to idle-client probes) is specified by the **user-idle-timeout** command.

Examples The following command disables idle-client keepalives on service profile *sp1*:

```
WSS# set service-profile sp1 idle-client-probing disable
success: change accepted.
```

See Also

- **set service-profile user-idle-timeout** on page 336
- **show service-profile** on page 380

set service-profile keep-initial-vlan

Configures AP radios managed by the radio profile to leave a roamed user on the VLAN assigned by the switch where the user logged on. When this option is disabled, a user's VLAN is reassigned by each WSS to which a user roams.

Syntax `set service-profile name keep-initial-vlan {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables radios to leave a roamed user on the same VLAN instead of reassigning the VLAN.
disable	Configures radios to reassign a roamed user's VLAN.

Defaults This option is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 5.0.

Usage Even when this option is enabled, the WSS to which a user roams (the *roamed-to* switch) can reassign the VLAN in any of the following cases:

- A location policy on the local switch reassigns the VLAN.
- The user is configured in the switch's local database and the VLAN-Name attribute is set on the user or on a user group the user is in.
- The access rule on the roamed-to switch uses RADIUS, and the VLAN-Name attribute is set on the RADIUS server.

Examples The following command enables the **keep-initial-vlan** option on service profile *sp3*:

```
WSS# set service-profile sp3 keep-initial-vlan enable
success: change accepted.
```

See Also [show service-profile on page 380](#)

set service-profile load-balancing-exempt

Exempts a service profile from performing RF load balancing.

Syntax `set service-profile name load-balancing-exempt {enable | disable}`

<i>name</i>	Service profile name.
enable	Exempts the specified service profile from RF load balancing.
disable	If a service profile has previously been exempted from RF load balancing, restores RF load balancing for the service profile.

Defaults AP radios automatically perform RF load balancing for all service profiles.

Access Enabled.

History Introduced in WSS Version 6.0.

Usage Use this command to exempt a service profile from RF load balancing. Exempting a service profile from RF load balancing means that even if an AP radio is attempting to steer clients away, it does not reduce or conceal the availability of the SSID named in the exempted service profile. Even if a radio is withholding probe responses to manage its load, the radio does respond to probes for an exempt SSID. Also, if an AP radio is withholding probe responses, and a client probes for *any* SSID, and the radio has at least one exempt SSID, the radio responds to the probe, but the response reveals only the exempt SSID(s).

Examples The following command exempts service profile *sp3* from RF load balancing:

```
WSS# set service-profile sp3 load-balancing-exempt enable
success: change accepted.
```

See Also

- [set load-balancing strictness on page 277](#)
- [set ap radio load-balancing on page 268](#)
- [set ap local-switching mode on page 260](#)
- [set ap radio load-balancing group on page 269](#)

set service-profile long-retry-count

Changes the long retry threshold for a service profile. The long retry threshold specifies the number of times a radio can send a long unicast frame without receiving an acknowledgment. A long unicast frame is a frame that is equal to or longer than the frag-threshold.

Syntax `set service-profile name long-retry-count threshold`

name Service profile name.

threshold Number of times the radio can send the same long unicast frame. You can enter a value from 1 through 15.

Defaults The default long unicast retry threshold is 5 attempts.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command changes the long retry threshold for service profile *sp1* to 8:

```
WSS# set service-profile sp1 long-retry-count 8
success: change accepted.
```

See Also

- [set radio-profile frag-threshold on page 289](#)
- [set service-profile short-retry-count on page 325](#)
- [show service-profile on page 380](#)

set service-profile mesh

Creates a service profile for use with WLAN mesh services.

Syntax `set service-profile name mesh mode {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables mesh services for the service profile.
disable	Disables mesh services for the service profile.

Defaults None.

Access Enabled.

History Introduced in WSS Software version 6.0.

Usage Use this command to configure mesh services for a service profile. Once configured, the service profile can then be mapped to a radio profile that manages a radio on the Mesh Portal AP, which then allows a Mesh Portal AP to beacon a mesh services SSID to Mesh APs.

Examples The following command enables mesh services for service profile sp1:

```
WSS# set service-profile sp1 mesh mode enable
success: change accepted.
```

See Also

- [set ap boot-configuration mesh ssid on page 254](#)
- [show ap mesh-links on page 357](#)

set service-profile no-broadcast

Disables or reenables the no-broadcast mode. The no-broadcast mode helps reduce traffic overhead on an SSID by leaving more of an SSID's bandwidth available for unicast traffic. The no-broadcast mode also helps VoIP handsets conserve power by reducing the amount of broadcast traffic sent to the phones.

When enabled, the no-broadcast mode prevents AP radios from sending DHCP or ARP broadcasts to clients on the service profile's SSID. Instead, an AP radio handles this traffic as follows:

- **ARP requests**—If the SSID has clients whose IP addresses the **WSS** does not already know, the **WSS** allows the AP radio to send the ARP request as a unicast to only those stations whose addresses the **WSS** does not know. The AP radio does not forward the ARP request as a broadcast and does not send the request as a unicast to stations whose addresses the **WSS** already knows.
- **DHCP Offers or Acks**—If the destination MAC address belongs to a client on the SSID, the AP radio sends the DHCP Offer or Ack as a unicast to that client only.

The no-broadcast mode does not affect other types of broadcast traffic and does not prevent clients from sending broadcasts.

Syntax `set service-profile name no-broadcast {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables the no-broadcast mode. AP radios are not allowed to send broadcast traffic to clients on the service profile's SSID.
disable	Disables the no-broadcast mode.

Defaults The no-broadcast mode is disabled by default. (Broadcast traffic not disabled.)

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage To further reduce ARP traffic on a service profile, use the **set service-profile proxy-arp** command to enable Proxy ARP.

Examples The following command enables the no-broadcast mode on service profile *sp1*:

```
WSS# set service-profile sp1 no-broadcast enable
success: change accepted.
```

See Also

- **set service-profile dhcp-restrict on page 316**
- **set service-profile proxy-arp on page 321**
- **show service-profile on page 380**

set service-profile proxy-arp

Enables proxy ARP. When proxy ARP is enabled, the **WSS** replies to ARP requests for client IP address on behalf of the clients. This feature reduces broadcast overhead on a service profile's SSID by eliminating ARP broadcasts from AP radios to the SSID's clients.

If the ARP request is for a client whose IP address the **WSS** does not already know, the **WSS** allows AP radios to send the ARP request to clients. If the no-broadcast mode is also enabled, the AP radios send the ARP request as a unicast to only the clients whose addresses the **WSS** does not know. However, if no-broadcast mode is disabled, the AP radios sends the ARP request as a broadcast to all clients on the SSID.

Syntax `set service-profile name proxy-arp {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables proxy ARP.
disable	Disables proxy ARP.

Defaults Proxy ARP is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage To further reduce broadcast traffic on a service profile, use the **set service-profile no-broadcast** command to disable DHCP and ARP request broadcasts.

Examples The following command enables proxy ARP on service profile *sp1*:

```
WSS# set service-profile sp1 proxy-arp enable
success: change accepted.
```

See Also

- **set service-profile dhcp-restrict** on page 316
- **set service-profile no-broadcast** on page 320
- **show service-profile** on page 380

set service-profile psk-phrase

Configures a passphrase for preshared key (PSK) authentication to use for authenticating WPA clients, in a service profile. Radios use the PSK as a pairwise master key (PMK) to derive unique pairwise session keys for individual WPA clients.

Syntax **set service-profile** *name* **psk-phrase** *passphrase*

<i>name</i>	Service profile name.
<i>passphrase</i>	An ASCII string from 8 to 63 characters long. The string can contain blanks if you use quotation marks at the beginning and end of the string.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage WSS Software converts the passphrase into a 256-bit binary number for system use and a raw hexadecimal key to store in the WSS's configuration. Neither the binary number nor the passphrase itself is ever displayed in the configuration.

To use PSK authentication, you must enable it and you also must enable the WPA IE.

Examples The following command configures service profile *sp3* to use passphrase "1234567890123<>?=&% The quick brown fox jumps over the lazy sl":

```
WSS# set service-profile sp3 psk-phrase "1234567890123<>?=&% The quick brown fox
jumps over the lazy sl"
success: change accepted.
```

See Also

- **set mac-user attr** on page 197
- **set service-profile auth-psk** on page 309
- **set service-profile psk-raw** on page 323
- **set service-profile wpa-ie** on page 342
- **show service-profile** on page 380

set service-profile psk-raw

Configures a raw hexadecimal preshared key (PSK) to use for authenticating WPA clients, in a service profile. Radios use the PSK as a pairwise master key (PMK) to derive unique pairwise session keys for individual WPA clients.

Syntax `set service-profile name psk-raw hex`

<i>name</i>	Service profile name.
<i>hex</i>	A 64-bit ASCII string representing a 32-digit hexadecimal number. Enter the two-character ASCII form of each hexadecimal number.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage WSS Software converts the hexadecimal number into a 256-bit binary number for system use. WSS Software also stores the hexadecimal key in the WSS's configuration. The binary number is never displayed in the configuration.

To use PSK authentication, you must enable it and you also must enable the WPA IE.

Examples The following command configures service profile *sp3* to use a raw PSK with PSK clients:

```
WSS# set service-profile sp3 psk-raw
      c25d3fe4483e867d1df96eaacdf8b02451fa0836162e758100f5f6b87965e59d
success: change accepted.
```

See Also

- [set mac-user attr on page 197](#)
- [set service-profile auth-psk on page 309](#)
- [set service-profile psk-phrase on page 322](#)
- [set service-profile wpa-ie on page 342](#)
- [show service-profile on page 380](#)

set service-profile rsn-ie

Enables the Robust Security Network (RSN) Information Element (IE).

The RSN IE advertises the RSN (sometimes called WPA2) authentication methods and cipher suites supported by radios in the radio profile mapped to the service profile.

Syntax `set service-profile name rsn-ie {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables the RSN IE.
disable	Disables the RSN IE.

Defaults The RSN IE is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage When the RSN IE is enabled, the default authentication method is 802.1X. There is no default cipher suite. You must enable the cipher suites you want the radios to support.

Examples The following command enables the RSN IE in service profile *sprsn*:

```
WSS# set service-profile sprsn rsn-ie enable
success: change accepted.
```

See Also

- [set service-profile auth-dot1x on page 307](#)
- [set service-profile auth-psk on page 309](#)
- [set service-profile cipher-ccmp on page 312](#)
- [set service-profile cipher-wep104 on page 314](#)
- [set service-profile cipher-wep40 on page 315](#)
- [show service-profile on page 380](#)

set service-profile shared-key-auth

Enables shared-key authentication, in a service profile.



Note. Use this command only if advised to do so by Nortel. This command does not enable preshared key (PSK) authentication for Wi-Fi Protected Access (WPA). To enable PSK encryption for WPA, use the **set service-profile auth-psk** command.

Syntax `set service-profile name shared-key-auth {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables shared-key authentication.
disable	Disables shared-key authentication.

Defaults Shared-key authentication is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage Shared-key authentication is supported only for encrypted SSIDs. In addition, if you enable shared-key authentication, RSN, WPA, TKIP, and CCMP must be disabled. By default, RSN, WPA, and CCMP are already disabled, but TKIP is enabled; you must manually disable TKIP. To disable TKIP, use the **set service-profile cipher-tkip disable** command.

Examples The following command enables shared-key authentication in service profile *sp4*:

```
WSS# set service-profile sp4 shared-key-auth enable
success: change accepted.
```

See Also

- **set radio-profile mode on page 291**
- **set service-profile cipher-tkip on page 313**
- **show service-profile on page 380**

set service-profile short-retry-count

Changes the short retry threshold for a service profile. The short retry threshold specifies the number of times a radio can send a short unicast frame without receiving an acknowledgment. A short unicast frame is a frame that is shorter than the frag-threshold.

Syntax **set service-profile** *name* **short-retry-count** *threshold*

name Service profile name.

threshold Number of times a radio can send the same short unicast frame. You can enter a value from 1 through 15.

Defaults The default short unicast retry threshold is 5 attempts.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command changes the short retry threshold for service profile *sp1* to 3:

```
WSS# set service-profile sp1 short-retry-count 3
success: change accepted.
```

See Also

- **set radio-profile frag-threshold on page 289**
- **set service-profile long-retry-count on page 319**
- **show service-profile on page 380**

set service-profile soda agent-directory

Specifies the directory on the WSS where the SODA agent files for a service profile are located.

Syntax `set service-profile name soda agent-directory directory`

name Service profile name.
directory Directory on the WSS for SODA agent files.

Defaults By default, the WSS expects SODA agent files to be located in a directory with the same name as the service profile.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage If the same SODA agent is used for multiple service profiles, you can use this command to specify a single directory for SODA agent files on the WSS, rather than placing the same SODA agent files in a separate directory for each service profile.

Examples The following command specifies *soda-agent* as the location for SODA agent files for service profile *sp1*:

```
WSS# set service-profile sp1 soda agent-directory soda-agent
success: change accepted.
```

See Also

- [install soda agent on page 542](#)
- [uninstall soda agent on page 556](#)
- [show service-profile on page 380](#)

set service-profile soda enforce-checks

Specifies whether a client is allowed access to the network after it has downloaded and run the SODA agent security checks.

Syntax `set service-profile name enforce-checks {enable | disable}`

name Service profile name.
enable SODA agent checks are performed before the client is allowed access to the network.
disable Allows the client access to the network immediately after the SODA agent is downloaded, without waiting for the checks to be run.

Defaults By default, SODA agent checks are performed before the client is allowed access to the network.

Access Enabled

History Introduced in WSS Software Version 4.1.

Usage When the SODA agent is enabled in a service profile, by default the SODA agent checks are downloaded to a client and run before the client is allowed on the network. You can use this command to disable the enforcement of the SODA security checks, so that the client is allowed access to the network immediately after the SODA agent is downloaded, rather than waiting for the security checks to be run.

When the enforce checks option is enabled, upon successful completion of the SODA agent checks, the client performs an HTTP Get operation to load the success page. Upon loading the success page, the client is granted access to the network.

In order for the client to load the success page, you must make sure the SODA agent is configured (through SODA Manager) with the correct URL of the success page, so that the WSS can serve the page to the client.

Similarly, you must make sure the SODA agent is configured with the correct URLs of the failure and logout pages, so that when the client requests these pages, the WSS can serve those pages as well.

Examples The following command allows network access to clients after they have downloaded the SODA agent, but without requiring that the SODA agent checks be completed:

```
WSS# set service-profile sp1 enforce-checks disable  
success: change accepted.
```

See Also

- **set service-profile soda mode on page 329**
- **show service-profile on page 380**

set service-profile soda failure-page

Specifies a page on the WSS that is loaded when a client fails the security checks performed by the SODA agent.

Syntax `set service-profile name soda failure-page page`

name Service profile name.

page Page that is loaded if the client fails the security checks performed by the SODA agent.

Defaults By default, the WSS dynamically generates a page indicating that the SODA agent checks have failed.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage Use this command to specify a custom page that is loaded by the client when the SODA agent checks fail. After this page is loaded, the specified remediation ACL takes effect, or if there is no remediation ACL configured, then the client is disconnected from the network.

This functionality occurs only when the `enforce checks` option is enabled for the service profile. The `enforce checks` option is enabled by default.

The page is assumed to reside in the root directory on the WSS. You can optionally specify a different directory where the page resides.

Examples The following command specifies `failure.html` as the page to load when a client fails the SODA agent checks:

```
WSS# set service-profile sp1 soda failure-page failure.html
success: change accepted.
```

The following command specifies `failure.html`, in the `soda-files` directory, as the page to load when a client fails the SODA agent checks:

```
WSS# set service-profile sp1 soda failure-page soda-files/failure.html
success: change accepted.
```

See Also

- [set service-profile soda enforce-checks on page 326](#)
- [set service-profile soda remediation-acl on page 330](#)
- [show service-profile on page 380](#)

set service-profile soda logout-page

Specifies a page on the WSS that is loaded when a client logs out of the network by closing the SODA virtual desktop.

Syntax `set service-profile name soda logout-page page`

name Service profile name.

page Page that is loaded when the client closes the SODA virtual desktop.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage When a client closes the SODA virtual desktop, the client is automatically disconnected from the network. You can use this command to specify a page that is loaded when the client closes the SODA virtual desktop.

The client can request this page at any time, to ensure that the client's session has been terminated. You can add the IP address of the WSS to the DNS server as a well-known name, and you can advertise the URL of the page to users as a logout page.

The page is assumed to reside in the root directory on the WSS. You can optionally specify a different directory where the page resides.

Note that you must also enable the HTTPS server on the WSS, so that clients can log out of the network and access the logout page using HTTPS. To do this, use the `set ip https server enable` command.

Examples The following command specifies *logout.html* as the page to load when a client closes the SODA virtual desktop:

```
WSS# set service-profile sp1 soda logout-page logout.html
success: change accepted.
```

The following command specifies *logout.html*, in the *soda-files* directory, as the page to load when a client closes the SODA virtual desktop:

```
WSS# set service-profile sp1 soda logout-page soda-files/logout.html
success: change accepted.
```

See Also

- [set ip https server on page 116](#)
- [show service-profile on page 380](#)

set service-profile soda mode

Enables or disables Sygate On-Demand (SODA) functionality for a service profile.

Syntax `set service-profile name soda mode {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables SODA functionality for the service profile.
disable	Disables SODA functionality for the service profile.

Defaults Disabled.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage When SODA functionality is enabled for a service profile, a SODA agent is downloaded to clients attempting to connect to an AP managed by the service profile. The SODA agent performs a series of security-related checks on the client; if the client passes the checks, it can be admitted to the network.

In release 4.1, SODA functionality requires that Web Portal Web-based AAA also be enabled for the service profile.

Examples The following command enables SODA functionality for service profile *sp1*:

```
WSS# set service-profile sp1 soda mode enable
success: change accepted.
```

See Also

- [install soda agent on page 542](#)
- [set service-profile soda enforce-checks on page 326](#)
- [show service-profile on page 380](#)

set service-profile soda remediation-acl

Specifies an ACL to be applied to a client if it fails the checks performed by the SODA agent.

Syntax `set service-profile name soda remediation-acl acl-name`

<i>name</i>	Service profile name.
<i>acl-name</i>	Name of an existing security ACL to use as a remediation ACL for this service profile. ACL names must start with a letter and are case-insensitive.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage If the SODA agent checks fail on a client, by default the client is disconnected from the network. Optionally, you can specify a *failure page* for the client to load (with the **set service-profile soda failure-page** command). When the failure page is loaded, you can optionally specify a *remediation ACL* to apply to the client. The remediation ACL can be used to grant the client limited access to network resources, for example. If there is no remediation ACL configured, then the client is disconnected from the network when the failure page is loaded.

This functionality occurs only when the enforce checks option is enabled for the service profile. The enforce checks option is enabled by default.

Examples The following command configures the WSS to apply *acl-1* to a client when it loads the failure page:

```
WSS# set service-profile sp1 soda remediation-acl acl-1
success: change accepted.
```

See Also

- [set service-profile soda enforce-checks on page 326](#)
- [set service-profile soda failure-page on page 327](#)
- [show service-profile on page 380](#)

set service-profile soda success-page

Specifies a page on the WSS that is loaded when a client passes the security checks performed by the SODA agent.

Syntax `set service-profile name soda success-page page`

<i>name</i>	Service profile name.
<i>page</i>	Page that is loaded if the client passes the security checks performed by the SODA agent.

Defaults By default, the WSS generates a page indicating that the client passed the SODA agent checks.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage Use this command to specify a custom page that is loaded by the client when it passes the checks performed by the SODA agent. After this page is loaded, the client is placed in its assigned VLAN and granted access to the network.

The page is assumed to reside in the root directory on the WSS. You can optionally specify a different directory where the page resides.

This functionality occurs only when the enforce checks option is enabled for the service profile. The enforce checks option is enabled by default.

Examples The following command specifies *success.html*, which resides in the root directory on the WSS, as the page to load when a client passes the SODA agent checks:

```
WSS# set service-profile sp1 soda success-page success.html
success: change accepted.
```

The following command specifies *success.html*, which resides in the *soda-files* directory on the WSS, as the page to load when a client passes the SODA agent checks:

```
WSS# set service-profile sp1 soda success-page soda-files/success.html
success: change accepted.
```

See Also

- [set service-profile soda enforce-checks on page 326](#)
- [set service-profile soda mode on page 329](#)
- [show service-profile on page 380](#)

set service-profile ssid-name

Configures the SSID name in a service profile.

Syntax `set service-profile name ssid-name ssid-name`

name Service profile name.

ssid-name Name of up to 32 alphanumeric characters.
You can include blank spaces in the name, if you delimit the name with single or double quotation marks. You must use the same type of quotation mark (either single or double) on both ends of the string.

Defaults The default SSID type is crypto (encrypted) and the default name is *trapeze*.

Access Enabled.

History

Version 4.0 Support added for blank spaces in the SSID name.

Examples The following command applies the name *guest* to the SSID managed by service profile *clear_wlan*:

```
WSS# set service-profile clear_wlan ssid-name guest
success: change accepted.
```

The following command applies the name *corporate users* to the SSID managed by service profile *mycorp_srvcprf*:

```
WSS# set service-profile mycorp_srvcprf ssid-name "corporate users"
success: change accepted.
```

See Also

- **set service-profile ssid-type on page 332**
- **show service-profile on page 380**

set service-profile ssid-type

Specifies whether the SSID managed by a service profile is encrypted or unencrypted.

```
Syntax set service-profile name ssid-type [clear | crypto]
```

<i>name</i>	Service profile name.
clear	Wireless traffic for the service profile's SSID is not encrypted.
crypto	Wireless traffic for the service profile's SSID is encrypted.

Defaults The default SSID type is *crypto*.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Examples The following command changes the SSID type for service profile *clear_wlan* to **clear**:

```
WSS# set service-profile clear_wlan ssid-type clear
success: change accepted.
```

See Also

- **set service-profile ssid-name on page 331**
- **show service-profile on page 380**

set service-profile static-cos

Enables or disables static CoS on a service profile. Static CoS assigns the same CoS level to all traffic on the service profile's SSID, regardless of 802.1p or DSCP markings in the packets themselves, and regardless of

any ACLs that mark CoS. This option provides a simple way to configure an SSID for priority traffic such as VoIP traffic.

When static CoS is enabled, the standard WSS Software prioritization mechanism is not used. Instead, the AP sets CoS as follows:

- For traffic from the AP to clients, the AP places the traffic into the forwarding queue that corresponds to the CoS level configured on the service profile. For example, if the static CoS level is set to 7, the AP radio places client traffic in its Voice queue.
- For traffic from clients to the network, the AP marks the DSCP value in the IP headers of the tunnel packets used to carry the user data from the AP to the WSS.

Syntax `set service-profile name static-cos {enable | disable}`

<i>name</i>	Service profile name.
enable	Enables static CoS on the service profile.
disable	Disables static CoS on the service profile.

Defaults Static CoS is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage The CoS level is specified by the `set service-profile cos` command.

Examples The following command enables static CoS on service profile *sp1*:

WSS# set service-profile sp1 static-cos enable

success: change accepted.

See Also

- `set service-profile cos` on page 315
- `show service-profile` on page 380

set service-profile tkip-mc-time

Changes the length of time that AP radios use countermeasures if two message integrity code (MIC) failures occur within 60 seconds. When countermeasures are in effect, AP radios dissociate all TKIP and WPA WEP clients and refuse all association and reassociation requests until the countermeasures end.

Syntax `set service-profile name tkip-mc-time wait-time`

<i>name</i>	Service profile name.
<i>wait-time</i>	Number of milliseconds (ms) countermeasures remain in effect. You can specify from 0 to 60,000.

Defaults The default countermeasures wait time is 60,000 ms (60 seconds).

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage Countermeasures apply only to TKIP and WEP clients. This includes WPA WEP clients and non-WPA WEP clients. CCMP clients are not affected.

The TKIP cipher suite must be enabled. The WPA IE also must be enabled.

Examples The following command changes the countermeasures wait time for service profile *sp3* to 30,000 ms (30 seconds):

```
WSS# set service-profile sp3 tkip-mc-time 30000
success: change accepted.
```

See Also

- [set service-profile cipher-tkip on page 313](#)
- [set service-profile wpa-ie on page 342](#)
- [show service-profile on page 380](#)

set service-profile transmit-rates

Changes the data rates supported by AP radios for a service-profile's SSID.

```
Syntax set service-profile name transmit-rates { 11a | 11b | 11g }
mandatory rate-list [disabled rate-list] [beacon-rate rate] [multicast-rate { rate | auto }]
```

<i>name</i>	Service profile name.
11a 11b 11g	Radio type.
mandatory <i>rate-list</i>	<p>Set of data transmission rates that clients are required to support in order to associate with an SSID on an AP radio. A client must support at least one of the mandatory rates.</p> <p>These rates are advertised in the basic rate set of 802.11 beacons, probe responses, and reassociation response frames sent by AP radios.</p> <p>Data frames and management frames sent by AP radios use one of the specified mandatory rates.</p> <p>The valid rates depend on the radio type:</p> <ul style="list-style-type: none">• 11a—6.0, 9.0, 12.0, 18.0, 24.0, 36.0, 48.0, 54.0• 11b—1.0, 2.0, 5.5, 11.0• 11g—1.0, 2.0, 5.5, 6.0, 9.0, 11.0, 12.0, 18.0, 24.0, 36.0, 48.0, 54.0 <p>Use a comma to separate multiple rates; for example: 6.0,9.0,12.0</p>
disabled <i>rate-list</i>	<p>Data transmission rates that AP radios will not use to transmit data. This setting applies only to data sent by the AP radios. The radios will still accept frames from clients at disabled data rates.</p> <p>The valid rates depend on the radio type and are the same as the valid rates for mandatory.</p>

beacon-rate <i>rate</i>	Data rate of beacon frames sent by AP radios. This rate is also used for probe-response frames. The valid rates depend on the radio type and are the same as the valid rates for mandatory . However, you cannot set the beacon rate to a disabled rate.
multicast-rate { <i>rate</i> auto }	Data rate of multicast frames sent by AP radios. <ul style="list-style-type: none"> • <i>rate</i>—Sets the multicast rate to a specific rate. The valid rates depend on the radio type and are the same as the valid rates for mandatory. However, you cannot set the multicast rate to a disabled rate. • auto—Sets the multicast rate to the highest rate that can reach all clients connected to the AP radio.

Defaults This command has the following defaults:

- **mandatory**:
 - 11a—**6.0,12.0,24.0**
 - 11b—**1.0,2.0**
 - 11g—**1.0,2.0,5.5,11.0**
- **disabled**—None. All rates applicable to the radio type are supported by default.
- **beacon-rate**:
 - 11a—**6.0**
 - 11b—**2.0**
 - 11g—**2.0**
- **multicast-rate**—**auto** for all radio types.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage If you disable a rate, you cannot use the rate as a mandatory rate or the beacon or multicast rate. All rates that are applicable to the radio type and that are not disabled are supported by the radio.

Examples The following command sets 802.11a mandatory rates for service profile *sp1* to 6 Mbps and 9 Mbps, disables rates 48 Mbps and 54 Mbps, and changes the beacon rate to 9 Mbps:

```
WSS# set service-profile sp1 transmit-rates 11a mandatory 6.0,9.0 disabled 48.0,54.0 beacon-rate 9.0
```

success: change accepted.

See Also [show service-profile on page 380](#)

set service-profile user-idle-timeout

Changes the number of seconds WSS Software will leave a session up for a client that is not sending data and is not responding to keepalives (idle-client probes). If the timer expires, the client's session is changed to the Dissociated state.

The timer is reset to 0 each time a client sends data or responds to an idle-client probe. If the idle-client probe is disabled, the timer is reset each time the client sends data.

Syntax `set service-profile name user-idle-timeout seconds`

<i>name</i>	Service profile name.
<i>seconds</i>	Number of seconds a client is allowed to remain idle before WSS Software changes the session to the Dissociated state. You can specify from 20 to 86400 seconds. To disable the timer, specify 0.

Defaults The default user idle timeout is 180 seconds (3 minutes).

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command increases the user idle timeout to 360 seconds (6 minutes):

```
WSS# set service-profile sp1 user-idle-timeout 360
success: change accepted.
```

See Also

- [set service-profile idle-client-probing on page 317](#)
- [set service-profile web-portal-logout on page 339](#)
- [show service-profile on page 380](#)

set service-profile web-portal-acl

Changes the ACL name WSS Software uses to filter a Web-Portal user's traffic during authentication.

Use this command if you create a custom Web-Portal ACL to allow more than just DHCP traffic during authentication. For example, if you configure an ACL that allows a Web-Portal user to access a credit card server, use this command to use the custom ACL for Web-Portal users that associate with the service profile's SSID.

Syntax `set service-profile name web-portal-acl aclname`

name Service profile name.

aclname Name of the ACL to use for filtering Web-Portal user traffic during authentication.

Defaults By default, a service profile's **web-portal-acl** option is unset. However, when you change the service profile's **auth-fallthru** option to **web-portal**, WSS Software sets the **web-portal-acl** option to *portalacl*. (WSS Software automatically creates the *portalacl* ACL the first time you set any service profile's **auth-fallthru** option to **web-portal**.)

Access Enabled.

History Introduced in WSS Software Version 5.0.

Usage The first time you set the service profile's **auth-fallthru** option to **web-portal**, WSS Software sets the **web-portal-acl** option to *portalacl*. The value remains *portalacl* even if you change the **auth-fallthru** option again. To change the **web-portal-acl** value, you must use the **set service-profile web-portal-acl** command.

The Web-Portal ACL applies only to users who log on using Web-Portal, and applies only during authentication. After a Web-Portal user is authenticated, the Web-Portal ACL no longer applies. ACLs and other user attributes assigned to the username are applied instead.

Examples The following command changes the Web-Portal ACL name to on service profile *sp3* to *creditsrvr*:

```
WSS# set service-profile sp3 web-portal-acl creditsrvr
success: change accepted.
```

See Also

- **set service-profile auth-fallthru on page 308**
- **show service-profile on page 380**

set service-profile web-portal-form

Specifies a custom login page to serve to Web-based AAA users who request the SSID managed by the service profile.

Syntax `set service-profile name web-portal-form url`

name Service profile name.

url WSS subdirectory name and HTML page name of the login page. Specify the full path. For example, *corpa-ssid/corpa.html*.

Defaults The Nortel Web login page is served by default.

Access Enabled.

History

Version 4.0 Option name changed from **web-aaa-form** to **web-portal-form**, to reflect change to portal-based implementation.

Usage Nortel recommends that you create a subdirectory for the custom page and place all the page's files in that subdirectory. Do not place the custom page in the root directory of the switch's user file area.

If the custom login page includes gif or jpg images, their path names are interpreted relative to the directory from which the page is served.



Note. To use Web-based AAA, the fallthru authentication type in the service profile that manages the SSID must be set to **web-portal**. To use Web-based AAA for a wired authentication port, edit the port configuration with the **set port type wired-auth** command.

The **web-portal** authentication type also requires additional configuration items. (See the “Configuring AAA for Network Users” chapter of the *Nortel WLAN Security Switch 2300 Series Configuration Guide*.)

Examples The following commands create a subdirectory named *corpa*, copy a custom login page named *corpa-login.html* and a jpg image named *corpa-logo.jpg* into that subdirectory, and set the Web login page for service profile *corpa-service* to *corpa-login.html*:

WSS# mkdir corpa

success: change accepted.

WSS# copy tftp://10.1.1.1/corpa-login.html corpa/corpa-login.html

success: received 637 bytes in 0.253 seconds [2517 bytes/sec]

WSS# copy tftp://10.1.1.1/corpa-logo.jpg corpa/corpa-logo.jpg

success: received 1202 bytes in 0.402 seconds [2112 bytes/sec]

WSS# dir corpa

```
=====
file:
Filename                Size      Created
file:corpa-login.html   637 bytes Aug 12 2004, 15:42:26
file:corpa-logo.jpg     1202 bytes Aug 12 2004, 15:57:11
Total:                   1839 bytes used, 206577 Kbytes free
```

WSS# set service-profile corpa-service web-portal-form corpa/corpa-login.html

success: change accepted.

See Also

- **copy on page 537**
- **dir on page 540**
- **mkdir on page 545**
- **set port type wired-auth on page 44**
- **set service-profile auth-fallthru on page 308**
- **set web-portal on page 209**
- **show service-profile on page 380**

set service-profile web-portal-logout

Changes the web portal logout mode.

Syntax `set service-profile name web-portal-logout mode {enable | disable}`

name Service profile name.
mode To enable or disable web portal logout.

Access Enabled.

History Introduced in WSS Software Version 6.0.

Examples The following command allows the web portal service to enable the web portal logout functionality.

WSS# set service-profile sp1 web-portal-logout mode enable
success: change accepted.

set service-profile web-portal-logout logout-url

The URL should be of the form https://host/logout.html.

name Service profile name.
mode To enable or disable web portal logout.

Defaults By default, the logout URL uses the IP address of the WSS as the host part of the URL. The host can be either an IP address or a hostname.

Access Enabled.

History Introduced in WSS Software Version 6.0.

Usage Specifying the logout URL is useful if you want to standardize it across your network.

Examples You can configure the logout URL on all of the WSS in the Mobility Domain as https://host/logout.html.

WSS# set service-profile spl web-portal-logout logout-url https://host/logout.html
success: change accepted.

set service-profile web-portal-session-timeout

Changes the number of seconds WSS Software allows Web Portal Web-based AAA sessions to remain in the Deassociated state before being terminated automatically.

Syntax `set service-profile name web-portal-session-timeout seconds`

name Service profile name.

seconds Number of seconds WSS Software allows Web Portal Web-based AAA sessions to remain in the Deassociated state before being terminated automatically. You can specify from 5 to 2800 seconds.

Defaults The default Web Portal Web-based AAA session timeout is 5 seconds.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage When a client that has connected through Web Portal Web-based AAA enters standby or hibernation mode, the client may be idle for longer than the User idle-timeout period. When the User idle-timeout period expires, WSS Software places the client's Web Portal Web-based AAA session in the Deassociated state. The Web Portal Web-based AAA session can remain in the Deassociated state for a configurable amount of time before being terminated automatically. This configurable amount of time is called the Web Portal Web-based AAA session timeout period. You can use this command to set the number of seconds in the Web Portal Web-based AAA session timeout period.

Note that the Web Portal Web-based AAA session timeout period applies only to Web Portal Web-based AAA sessions already authenticated with a username and password. For all other Web Portal Web-based AAA sessions, the default Web Portal Web-based AAA session timeout period of 5 seconds is used.

Examples The following command allows Web Portal Web-based AAA sessions to remain in the Deassociated state 180 seconds before being terminated automatically.

```
WSS# set service-profile sp1 web-portal-session-timeout 180
success: change accepted.
```

See Also

- [set service-profile user-idle-timeout on page 336](#)
- [show service-profile on page 380](#)

set service-profile wep active-multicast-index

Specifies the static Wired-Equivalent Privacy (WEP) key (one of four) to use for encrypting multicast frames.

Syntax `set service-profile name wep active-multicast-index num`

name Service profile name.

num WEP key number. You can enter a value from 1 through 4.

Defaults If WEP encryption is enabled and WEP keys are defined, AP radios use WEP key 1 to encrypt multicast frames, by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage Before using this command, you must configure values for the WEP keys you plan to use. Use the **set service-profile wep key-index** command.

Examples The following command configures service profile *sp2* to use WEP key 2 for encrypting multicast traffic:

```
WSS# set service-profile sp2 wep active-multicast-index 2
success: change accepted.
```

See Also

- **set service-profile wep active-unicast-index on page 341**
- **set service-profile wep key-index on page 342**
- **show service-profile on page 380**

set service-profile wep active-unicast-index

Specifies the static Wired-Equivalent Privacy (WEP) key (one of four) to use for encrypting unicast frames.

Syntax **set service-profile** *name* **wep active-unicast-index** *num*

name Service profile name.

num WEP key number. You can enter a value from 1 through 4.

Defaults If WEP encryption is enabled and WEP keys are defined, AP radios use WEP key 1 to encrypt unicast frames, by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage Before using this command, you must configure values for the WEP keys you plan to use. Use the **set service-profile wep key-index** command.

Examples The following command configures service profile *sp2* to use WEP key 4 for encrypting unicast traffic:

```
WSS# set service-profile sp2 wep active-unicast-index 4
success: change accepted.
```

See Also

- **set service-profile wep active-multicast-index on page 340**
- **set service-profile wep key-index on page 342**
- **show service-profile on page 380**

set service-profile wep key-index

Sets the value of one of four static Wired-Equivalent Privacy (WEP) keys for static WEP encryption.

Syntax `set service-profile name wep key-index num key value`

<i>name</i>	Service profile name.
key-index <i>num</i>	WEP key index. You can enter a value from 1 through 4.
key <i>value</i>	Hexadecimal value of the key. You can enter a 10-character ASCII string representing a 5-byte hexadecimal number or a 26-character ASCII string representing a 13-byte hexadecimal number. You can use numbers or letters. ASCII characters in the following ranges are supported: <ul style="list-style-type: none">• 0 to 9• A to F• a to f

Defaults By default, no static WEP keys are defined.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage WSS Software automatically enables static WEP when you define a WEP key. WSS Software continues to support dynamic WEP.

Examples The following command configures a 5-byte WEP key for key index 1 on service profile *sp2* to *aabbccdee*:

```
WSS# set service-profile sp2 wep key-index 1 key aabbccdee
success: change accepted.
```

See Also

- [set service-profile wep active-multicast-index on page 340](#)
- [set service-profile wep active-unicast-index on page 341](#)
- [show service-profile on page 380](#)

set service-profile wpa-ie

Enables the WPA information element (IE) in wireless frames. The WPA IE advertises the WPA authentication methods and cipher suites supported by radios in the radio profile mapped to the service profile.

Syntax `set service-profile name wpa-ie { enable | disable }`

<i>name</i>	Service profile name.
enable	Enables the WPA IE.
disable	Disables the WPA IE.

Defaults The WPA IE is disabled by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage When the WPA IE is enabled, the default authentication method is 802.1X. There is no default cipher suite. You must enable the cipher suites you want the radios to support.

Examples The following command enables the WPA IE in service profile *sp2*:

```
WSS# set service-profile sp2 wpa-ie enable
success: change accepted.
```

See Also

- **set service-profile auth-dot1x on page 307**
- **set service-profile auth-psk on page 309**
- **set service-profile cipher-ccmp on page 312**
- **set service-profile cipher-tkip on page 313**
- **set service-profile cipher-wep104 on page 314**
- **set service-profile cipher-wep40 on page 315**
- **show service-profile on page 380**

show ap arp

Displays the ARP table for a specified AP.

Syntax `show ap arp ap-number`

ap-number Index value that identifies the AP on the WSS switch.

Defaults None.

Access All.

History Introduced in WSS Version 6.0.

Examples The following command displays ARP entries for AP 7:

```
WSS# show ap arp 7
AP 7:
```

Host	HW Address	VLAN	State	Type
10.5.4.51	00:0b:0e:00:04:0c	1	EXPIRED	DYNAMIC
10.5.4.53	00:0b:0e:02:76:f7	1	RESOLVED	LOCAL

[Table 39](#) describes the fields in this display.

Table 6: Output for show ap arp

Field	Description
Host	IP address, hostname, or alias.
HW Address	MAC address mapped to the IP address, hostname, or alias.
VLAN	VLAN the entry is for.
State	Entry state: <ul style="list-style-type: none">• RESOLVING—WSS sent an ARP request for the entry and is waiting for the reply.• RESOLVED—Entry is resolved.• EXPIRED—Entry is expired.
Type	Entry type: <ul style="list-style-type: none">• DYNAMIC—Entry was learned from network traffic and ages out if unused for longer than the ARP aging timeout.• LOCAL—Entry for the WSS MAC address. Each VLAN has one local entry for the switch MAC address.• PERMANENT—Entry does not age out and remains in the configuration even following a reboot.• STATIC—Entry does not age out but is removed after a reboot.

See Also

- **set ap local-switching mode on page 260**
- **set vlan-profile**

show ap config

Displays global and radio-specific settings for an AP.

Syntax `show ap config [port-list [radio {1 | 2}]]`

<i>port-list</i>	List of ports connected to the AP(s) for which to display configuration settings.
<i>ap-num</i>	Number of a AP for which to display configuration settings.
radio 1	Shows configuration information for radio 1.
radio 2	Shows configuration information for radio 2. (This option does not apply to single-radio models.)

Defaults None.

Access Enabled.

History

- | | |
|-------------|---|
| Version 4.0 | <ul style="list-style-type: none"> • New field added: fingerprint <p>Note: This field applies to the display for APs only.</p> |
| Version 5.0 | <ul style="list-style-type: none"> • Field force-image-download added: • Field auto-tune min-client-rate removed. • Field auto-tune max-retransmissions removed. |
| Version 6.0 | <ul style="list-style-type: none"> • Option dap removed. |

Usage WSS Software lists information separately for each AP.

Examples The following example shows configuration information for an AP on WSS port 2:

WSS# show ap config 2

```
Port 2: AP model: 2330, POE: enable, bias: high, name: AP02
boot-download-enable: YES
force-image-download: NO
load balancing group: none
Radio 1: type: 802.11g, mode: disabled, channel: 6
tx pwr: 1, profile: default
auto-tune max-power: default
Radio 2: type: 802.11a, mode: disabled, channel: 36
tx pwr: 1, profile: default
auto-tune max-power: default
```

Examples The following example shows configuration information for a AP configured on connection 1:

WSS# show ap config 1

```
Ap 1: serial-id: 12345678, AP model: 2330, bias: high, name: AP01
fingerprint: b4:f9:2a:52:37:58:f4:d0:10:75:43:2f:45:c9:52:c3
boot-download-enable: YES
force-image-download: NO
load balancing group: none
Radio 1: type: 802.11g, mode: disabled, channel: 6
tx pwr: 1, profile: default
auto-tune max-power: default
Radio 2: type: 802.11a, mode: disabled, channel: 36
tx pwr: 1, profile: default
auto-tune max-power: default
```

[Table 40](#) describes the fields in this display.

Table 7: Output for show ap config

Field	Description
Port	WSS port number. Note: This field is applicable only if the AP is directly connected to the WSS and the WSS's port is configured as an AP access port.
AP	Connection ID for the AP. Note: This field is applicable only if the AP is configured on the WSS as a AP.
serial-id	Serial ID of the AP. Note: This field is displayed only for APs.
AP model	AP model number.
POE	PoE state on the WSS port: <ul style="list-style-type: none"> • Enable • Disable
bias	Bias of the WSS connection to the AP: <ul style="list-style-type: none"> • High • Low
name	AP name.
fingerprint	Hexadecimal fingerprint of the AP's public encryption key. Note: This field is displayed only for APs. If the field is blank, the key has not been verified yet by an administrator. (See set ap fingerprint on page 257.)
boot-download-enable	State of the firmware upgrade option: <ul style="list-style-type: none"> • YES (automatic upgrades are enabled) • NO (automatic upgrades are disabled)
force-image-download	State of the option to force the AP to o
load balancing group	Names of the AP load-balancing groups to which the AP belongs. If the value is <i>None</i> , the access point does not belong to any load balancing groups. Note: This field is displayed only if the AP is a member of a group.
Radio	Radio number. The information listed below this field applies specifically to the radio.

Table 7: Output for show ap config (continued)

Field	Description
type	Radio type: <ul style="list-style-type: none"> • 802.11a • 802.11b • 802.11g
mode	Radio state: <ul style="list-style-type: none"> • Enabled • Disabled
channel	Channel number.
antennatype	External antenna model, if applicable.
tx pwr	Transmit power, in dBm.
profile	Radio profile that manages the radio. Until you assign the radio to a radio profile, WSS Software assigns the radio to the default radio profile.
auto-tune max-power	Maximum power level the RF Auto-Tuning feature can set on the radio. <ul style="list-style-type: none"> • The value <i>default</i> means RF Auto-Tuning can set the power up to the maximum level allowed for the country of operation. • A specific numeric value means you or another administrator set the maximum value.

See Also

- [set ap on page 33](#)
- [set port type ap on page 41](#)
- [set ap bias on page 249](#)
- [set ap fingerprint on page 257](#)
- [set ap group on page 258](#)
- [set ap name on page 261](#)
- [set ap upgrade-firmware on page 275](#)
- [set ap radio mode on page 270](#)
- [set ap radio antennatype on page 263](#)
- [set ap radio channel on page 267](#)
- [set ap radio radio-profile on page 271](#)
- [set ap radio tx-power on page 272](#)
- [show ap connection on page 371](#)
- [show ap global on page 373](#)

- **show ap unconfigured** on page 374
- **show radio-profile** on page 376

show ap counters

Displays AP and radio statistics counters.

Syntax **show ap counters** [*port-list* [**radio** {**1** | **2**}]]

<i>port-list</i>	List of ports connected to the AP(s) for which to display statistics counters.
<i>ap-num</i>	Number of a AP for which to display statistics counters.
radio 1	Shows statistics counters for radio 1.
radio 2	Shows statistics counters for radio 2. (This option does not apply to single-radio models.)

Defaults None.

Access Enabled.

History

Version 4.0 New fields added:

- Radio Recv Phy Err Ct
- Transmit Retries
- Radio Adjusted Tx Pwr
- Noise Floor
- 802.3 Packet Tx Ct
- 802.3 Packet Rx Ct
- No Receive Descriptor

Version 6.0 Option **dap** removed.

Usage To display statistics counters and other information for individual user sessions, use the **show sessions network** command.

Examples The following command shows statistics counters for AP 7:

WSS# show ap counters 7

AP: 7 radio: 1

```
=====
LastPktXferRate      2      PktTxCount      73473
NumCntInPwrSave     0      MultiPktDrop     0
LastPktRxSigStrength -89    MultiBytDrop     0
LastPktSigNoiseRatio 4      User Sessions    0
TKIP Pkt Transfer Ct 0      MIC Error Ct     0
```

```

TKIP Pkt Replays      0    TKIP Decrypt Err    0
CCMP Pkt Decrypt Err  0    CCMP Pkt Replays   0
CCMP Pkt Transfer Ct  0    RadioResets         0
Radio Recv Phy Err Ct  0    Transmit Retries    60501
Radio Adjusted Tx Pwr  15   Noise Floor         -93
802.3 Packet Tx Ct    0    802.3 Packet Rx Ct  0
No Receive Descriptor  0

TxUniPkt TxUniByte RxPkt UndcrptPkt TxMultiPkt TxMultiByte RxByte UndcrptByte PhyErr
1.0:1017  0    10170    0          14    8347    0    0    3964
2.0:5643 55683  822545  8697520    3    1670    0    0    8695
5.5:0     0     0        0          5    258     0    0    4
6.0:      0     0        0          0    0       0    0    51
9.0:0     0     0        0          1    172    0    0    53
11.0:0    0     0        0          17   998    0    0    35
12.0:0    0     0        0          0    0       0    0    26
18.0:0    0     0        0          0    0       0    0    38
24.0:0    0     0        0          0    0       0    0    47
36.0:0    0     0        0          0    0       0    0    1
48.0:0    0     0        0          1    68     0    0    29
54.0:0    0     0        0          0    0       0    0    5
TOTL: 6660 55683 832715  8697520    41 11513  0    0    12948
...

```

Table 41 describes the fields in this display.

Table 8: Output for show ap counters

Field	Description
AP	AP number.
Port	WSS port number (if the AP is directly connected to the WSS and the WSS port is configured as an AP access port).
radio	Radio number.
LastPktXferRate	Data transmit rate, in Mbps, of the last packet received by the AP.
NumCntInPwrSave	Number of clients currently in power save mode.
LastPktRxSigStrength	Signal strength, in dBm, of the last packet received by the AP.
LastPktSigNoiseRatio	Signal-to-noise ratio (SNR), in decibels (dB), of the last packet received by the AP. This value indicates the strength of the radio signal above the noise floor. For example, if the noise floor is -88 and the signal strength is -68, the SNR is 20. If the value is below 10, this indicates a weak signal and might indicate a problem in the RF environment.
TKIP Pkt Transfer Ct	Total number of TKIP packets sent and received by the radio.

Table 8: Output for show ap counters (continued)

Field	Description
TKIP Pkt Replays	Number of TKIP packets that were resent to the AP by a client. A low value (under about one hundred) does not necessarily indicate a problem. However, if this counter is increasing steadily or has a very high value (in the hundreds or more), a Denial of Service (DoS) attack might be occurring. Contact Nortel TAC.
CCMP Pkt Decrypt Err	Number of times a decryption error occurred with a packet encrypted with CCMP. Occasional decryption errors do not indicate a problem. However, steadily increasing errors or a high number of errors can indicate that data loss is occurring in the network. Generally, this is caused by a key mismatch between a client and the AP. To locate the client that is experiencing decryption errors (and therefore is likely causing this counter to increment on the AP), use the show sessions network session-id session-id command for each client on the radio. After you identify the client that is causing the errors, disable and reenable the client (wireless NIC).
CCMP Pkt Transfer Ct	Total number of CCMP packets sent and received by the radio.
Radio Recv Phy Err Ct	Number of times radar caused packet errors. If this counter increments rapidly, there is a problem in the RF environment. Note: This counter increments only when radar is detected. Rate-specific Phy errors are instead counted in the PhyError columns for individual data rates.
Radio Adjusted Tx Pwr	Current power level set on the radio. If RF Auto-Tuning of power is enabled, this value is the power set by RF Auto-Tuning. If RF Auto-Tuning is disabled, this value is the statically configured power level.
802.3 Packet Tx Ct	Number of raw 802.3 packets transmitted by the radio. These are LocalTalk (AppleTalk) frames. This counter increments only if LocalTalk traffic is present.
No Receive Descriptor	Number of packets for which the AP could not create a descriptor. A descriptor describes a received packet's size and its location in AP memory. The AP buffers descriptors, and clears them during interframe spaces. This counter increments if the AP runs out of buffers for received packets. This condition can occur when a noise burst temporarily floods the air and the AP attempts to buffer the noise as packets. Buffer overruns are normal while an AP is booting. However, if they occur over an extended period of time when the AP is fully active, this can indicate RF interference.
PktTxCount	Number of packets transmitted by the radio.
MultiPktDrop	Number of multicast packets dropped by the radio due to a buffer overflow on the AP. This counter increments if there is too much multicast traffic or there is a problem with the multicast packets. Normally, this counter should be 0.
MultiBytDrop	Number of multicast bytes dropped by the radio due to a buffer overflow on the AP. (See the description for MultiPktDrop.)

Table 8: Output for show ap counters (continued)

Field	Description
User Sessions	<p>Number of clients currently associated with the radio.</p> <p>Generally, this counter is equal to the number of sessions listed for the radio in show sessions output. However, the counter can differ from the counter in show sessions output if a client is associated with the radio but has not yet completed 802.1X authentication. In this case, the client is counted by this counter but not in the show sessions output.</p> <p>Although there is no specific normal range for this counter, a high or low number relative to other radios can mean the radio is underutilized or overutilized relative to the other radios. (However, if the clients are VoIP phones, a relatively high number of clients does not necessarily mean overutilization since voice clients consume less bandwidth on average than data clients.)</p>
MIC Error Ct	<p>Number of times the radio received a TKIP-encrypted frame with an invalid MIC.</p> <p>Normally, the value of this counter should always be 0. If the value is not 0, check the system log for MIC error messages and contact Nortel TAC.</p>
TKIP Decrypt Err	<p>Number of times a decryption error occurred with a packet encrypted with TKIP.</p> <p>(See the description for CCMP Pkt Decrypt Err.)</p>
CCMP Pkt Replays	<p>Number of CCMP packets that were resent to the AP by a client.</p> <p>(See the description for TKIP Pkt Replays.)</p>
RadioResets	<p>Number of times the radio has been reset. Generally, a reset occurs as a result of RF noise. It is normal for this counter to increment a few times per day.</p>
Transmit Retries	<p>Number of times the radio retransmitted a unicast packet because it was not acknowledged. The AP uses this counter to adjust the transmit data rate for a client, in order to minimize retries.</p> <p>The ratio of transmit retries to transmitted packets (TxUniPkt) indicates the overall transmit quality. A ratio of about 1 retry to 10 transmitted packets indicates good transmit quality. A ratio of 3 or more to 10 indicates poor transmit quality.</p> <p>Note: This counter includes unacknowledged probes. Some clients do not respond to probes, which can make this counter artificially high.</p>
Noise Floor	<p>Received signal strength at which the AP can no longer distinguish 802.11 packets from ambient RF noise. A value around -90 or higher is good for an 802.11b/g radio. A value around -80 or higher is good for an 802.11a radio. Values near 0 can indicate RF interference.</p>
802.3 Packet Rx Ct	<p>Number of raw 802.3 packets received by the radio. These are LocalTalk (AppleTalk) frames. This counter increments only if LocalTalk traffic is present.</p>

Table 8: Output for show ap counters (continued)

Field	Description
The counters above are global for all data rates. The counters below are for individual data rates.	
Note: If counters for lower data rates are incrementing but counters for higher data rates are not incrementing, this can indicate poor throughput. The poor throughput can be caused by interference. If the cause is not interference or the interference cannot be eliminated, you might need to relocate the AP in order to use the higher data rates and therefore improve throughput.	
TxUniPkt	Number of unicast packets transmitted by the radio.
TxMultiPkt	Number of multicast packets transmitted by the radio.
TxUniByte	Number of unicast bytes transmitted by the radio.
TxMultiByte	Number of multicast bytes transmitted by the radio.
RxPkt	Number of packets received by the radio.
RxByte	Number of bytes received by the radio.
UnderprtPkt	Number of undecryptable packets received by the radio. It is normal for this counter to increment even in stable networks and does not necessarily indicate an attack. For example, a client might be sending incorrect key information. However, if the counter increments rapidly, there might be a problem in the network.
UnderprtByte	Number of undecryptable bytes received by the radio. (See the description for UnderprtPkt.)
PhyError	<p>Number of packets that could not be decoded by the AP. This condition can have any of the following causes:</p> <ul style="list-style-type: none"> • Collision of an 802.11 packet. • Packet whose source is too far away, thus rendering the packet unintelligible by the time it reaches the AP. • Interference caused by an 802.11b/g phone or other source. <p>It is normal for this counter to be about 10 percent of the total RxByte count. It is also normal for higher data rates to have higher Phy error counts than lower data rates.</p>

See Also [show sessions network on page 439](#)

show ap dual-home

To display connection information for APs configured on a WSS, use the **show ap global** command on one of the switches where the AP is configured.

show ap fdb

Displays the entries in a specified AP's forwarding database.

Syntax `show ap fdb ap-number`

ap-number Index value that identifies the AP on the WSS switch.

Defaults None.

Access All.

History Introduced in WSS Version 6.0.

Examples The following command displays FDB entries for AP 7:

WSS# show ap fdb 7

AP 7:

= System Entry, \$ = Authenticate Entry

VLAN TAG Dest MAC/Route Des [CoS] Destination Ports

```

-----
4095 4095 00:0b:0e:00:ca:c1 # CPU
4095 0 00:0b:0e:00:04:0c eth0

```

Table 42 describes the fields in the `show ap fdb` output.

Table 9: Output for show ap fdb

Field	Description
VLAN	VLAN number.
TAG	VLAN tag value. If the interface is untagged, the TAG field is blank.
Dest MAC/Route Des	MAC address of this forwarding entry's destination.
CoS	Type of entry. The entry types are explained in the first row of the command output.
	Note. This Class of Service (CoS) value is not associated with WSS quality of service (QoS) features.
Destination Ports	WSS switch port associated with the entry. A switch sends traffic to the destination MAC address through this port.

See Also

- `set ap local-switching mode` on page 260
- `set vlan-profile`

show ap qos-stats

Displays statistics for AP forwarding queues.

Syntax `show ap qos-stats [ap-num] [clear]`

Syntax `show ap qos-stats [port-list] [clear]`

ap-num Number of a AP for which to display QoS statistics counters.
port-list List of ports connected to the AP(s) for which to display QoS statistics counters.
clear Clears the counters after displaying their current values.

Defaults None.

Access Enabled.

History

Version 4.0 Command introduced.
Version 4.1 TxDrop field added.
Version 5.0 Option **clear** added.
Version 6.0 Option **dap** removed.

Usage Repeating this command with the **clear** option at regular intervals allows you to monitor transmission and drop rates.

Examples The following command shows statistics for the AP forwarding queues on a AP:

WSS# show ap qos-stats 4

CoS	Queue	Tx	TxDrop
=====			
AP:	4 radio:1		
1,2	Background	0	0
0,3	BestEffort	15327	278
4,5	Video	0	0
6,7	Voice	1714881	0
AP:	4 radio: 2		
1,2	Background	0	0
0,3	BestEffort	0	0
4,5	Video	0	0
6,7	Voice	0	0

[Table 43](#) describes the fields in this display.

Table 10: Output for show ap qos-stats

Field	Description
CoS	CoS value associated with the forwarding queues.
Queue	Forwarding queue.
AP or Port	AP number or AP port number.
radio	Radio number.
Tx	Number of packets transmitted to the air from the queue.
TxDrop	Number of packets dropped from the queue instead of being transmitted. Some packet drops are normal, especially if the RF environment is <i>noisy</i> . Also, it is normal for a mildly congested radio to drop low-priority packets proportionally more often than high-priority packets. However, continuous packet drops from the Voice queue can indicate over-subscription or excessive interference in the RF environment.

show ap etherstats

Displays Ethernet statistics for an AP's Ethernet ports.

Syntax `show ap etherstats [port-list | ap-num]`

port-list List of WSS ports directly connected to the AP(s) for which to display counters.

ap-num Number of a AP for which to display counters.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 3.0.
Option **dap** removed in version 6.0.

Examples The following command displays Ethernet statistics for the Ethernet ports on AP 1:

WSS# show ap etherstats 1

AP: 1 ether: 1

```
=====
RxUnicast:      75432 TxGoodFrames:  55210
RxMulticast:    18789 TxSingleColl:   32
RxBroadcast:     8 TxLateColl:      0
RxGoodFrames:  94229 TxMaxColl:     0
RxAlignErrs:     0 TxMultiColl:   47
```

```
RxShortFrames:    0 TxUnderruns:    0
RxCrcErrors:     0 TxCarrierLoss:   0
RxOverruns:      0 TxDeferred:     150
RxDiscards:      0

AP: 1            ether: 2
=====
RxUnicast:       64379 TxGoodFrames:   60621
RxMulticast:     21798 TxSingleColl:   32
RxBroadcast:     11 TxLateColl:     0
RxGoodFrames:   86188 TxMaxColl:      0
RxAlignErrs:     0 TxMultiColl:    12
RxShortFrames:   0 TxUnderruns:    0
RxCrcErrors:     0 TxCarrierLoss:   0
RxOverruns:      0 TxDeferred:     111
RxDiscards:      0
```

Table 44 describes the fields in this display.

Table 11: Output for show ap etherstats

Field	Description
RxUnicast	Number of unicast frames received.
RxMulticast	Number of multicast frames received.
RxBroadcast	Number of broadcast frames received.
RxGoodFrames	Number of frames received properly from the link.
RxAlignErrs	Number of received frames that were both misaligned and contained a CRC error.
RxShortFrames	Number of received frames that were shorter than the minimum frame length.
RxCrcErrors	Number of received frames that were discarded due to CRC errors.
RxOverruns	Number of frames known to be lost due to a temporary lack of hardware resources.
RxDiscards	Number of frames known to be lost due to a temporary lack of software resources.
TxGoodFrames	Number of frames transmitted properly on the link.
TxSingleColl	Number of transmitted frames that encountered a single collision.

Table 11: Output for show ap etherstats (continued)

Field	Description
TxLateColl	Number of frames that were not transmitted because they encountered a collision outside the normal collision window.
TxMaxColl	Number of frames that were not transmitted because they encountered the maximum allowed number of collisions. Typically, this occurs only during periods of heavy traffic on the network.
TxMultiColl	Number of transmitted frames that encountered more than one collision.
TxUnderruns	Number of frames that were not transmitted or retransmitted due to temporary lack of hardware resources.
TxCARRIERLoss	Number of frames transmitted despite the detection of a deassertion of CRS during the transmission.
TxDeferred	Number of frames deferred before transmission due to activity on the link.

show ap group

Deprecated in WSS Software Version 6.0. To display information about RF load balancing, see `show load-balancing group`

show ap mesh-links

Displays information about the links an AP has to Mesh APs and Mesh Portal APs.

Syntax `show ap mesh-links ap-number`

ap-number Index value that identifies the AP on the WSS.

Defaults None.

Access All

History Introduced in WSS Software Version 6.0.

Examples The following command mesh link information for AP 7:

WSS# show ap mesh-links 7

AP: 7 IP-addr: 1.1.1.3

Operational Mode: Mesh-Portal

Downlink Mesh-APs

BSSID: 00:0b:0e:17:bb:3f (54 Mbps)

packets bytes

TX: 307 44279
RX: 315 215046

[Table 45 on page 358](#) describes the fields in the show ap mesh-links output.

Table 12: Output for show ap mesh-links

Field	Description
AP	Identifier for the AP on the WSS.
Name	V-LAN name.
IP-addr	IP address of AP.
Operational Mode	Indicates whether the AP is a Mesh AP or Mesh Portal AP.
Downlink Mesh-APs	Information about the Mesh APs that are associated with the Mesh Portal AP.
BSSID	Indicates the BSSID of the Mesh AP.
TX	Indicates the amount of traffic (packets and bytes) transmitted to the Mesh AP.
RX	Indicates the amount of traffic (packets and bytes) transmitted to the Mesh AP.

See Also

- [set ap boot-configuration mesh ssid on page 254](#)
- [set service-profile mesh on page 320](#)

show ap status

Displays AP and radio status information.

Syntax `show ap status [terse] | [port-list | all [radio {1 | 2}]]`

terse Displays a brief line of essential status information for each AP.
port-list List of ports connected to the AP(s) for which to display status.
ap-num Number of a AP for which to display status.
all Shows status information for all directly attached APs and all APs configured on the switch.

- radio 1** Shows status information for radio 1.
- radio 2** Shows status information for radio 2. (This option does not apply to single-radio models.)

Defaults None.

Access Enabled.

History

- Version 4.0
- New option added: **terse**
 - New option added for **show ap status: all**
 - New field added: fingerprint
 - AP-WSS security status added to State field
- Note:** The fingerprint field and security state apply to the display for APs only.
- Version 4.1
- External antenna information added after the radio state information, to indicate when an antenna has been detected and to indicate the configured antenna model number.
 - *Auto* flag added to indicate operational channel or power settings that are configured by RF Auto-Tuning.
- Version 5.0
- Radar Scan* and *Radar Detected* flags added to indicate when the Dynamic Frequency Selection (DFS) feature is scanning for radar or has stopped transmitting due to detected radar. The flags apply to 802.11a radios only, and only for country codes where DFS is used.
- RFID Reports field added.
- Version 6.0
- Option **dap** removed.

Examples The following command displays the status of a AP:

WSS# show ap status 1

```
ap: 1, IP-addr: 10.2.30.5 (vlan 'vlan-corp'), AP model:2330,
  manufacturer: Nortel, name: AP01
  fingerprint: b4:f9:2a:52:37:58:f4:d0:10:75:43:2f:45:c9:52:c3
```

```
=====
State:  operational (not encrypted)
CPU info: IBM:PPC speed=266666664 Hz version=405GPr
          id=0x29c15335347f1919 ram=33554432
          s/n=0333703027 hw_rev=A3
Uptime:  18 hours, 36 minutes, 27 seconds
```

Radio 1 type: 802.11g, state: configure succeed [Enabled] (802.11b protect)
operational channel: 1 operational power: 14
base mac: 00:0b:0e:00:d2:c0
bssid1: 00:0b:0e:00:d2:c0, ssid: public
bssid2: 00:0b:0e:00:d2:c2, ssid: employee-net
bssid3: 00:0b:0e:00:d2:c4, ssid: mycorp-tkip
Radio 2 type: 802.11a, state: configure succeed [Enabled]
operational channel: 64 operational power: 14
base mac: 00:0b:0e:00:d2:c1
bssid1: 00:0b:0e:00:d2:c1, ssid: public
bssid2: 00:0b:0e:00:d2:c3, ssid: employee-net
bssid3: 00:0b:0e:00:d2:c5, ssid: mycorp-tkip
RFID Reports: Inactive

The following command displays the status of a directly connected AP:

WSS# show ap status 1

Port: 1, AP model: 2330, manufacturer Nortel, name: AP01

=====
State: operational

CPU info: IBM:PPC speed=266666664 Hz version=405GPr
id=0x28b08a1e047f1d0f ram=33554432
s/n=0333000288 hw_rev=A3

Uptime: 3 hours, 44 minutes, 28 seconds

Radio 1 type: 802.11g, state: configure succeed [Enabled] (802.11b protect)
operational channel: 1 operational power: 15
base mac: 00:0b:0e:00:d1:00
bssid1: 00:0b:0e:00:d1:00, ssid: public
bssid2: 00:0b:0e:00:d1:02, ssid: employee-net
bssid3: 00:0b:0e:00:d1:04, ssid: mycorp-tkip
Radio 2 type: 802.11a, state: configure succeed [Enabled]
operational channel: 48 operational power: 11
base mac: 00:0b:0e:00:d1:01
bssid1: 00:0b:0e:00:d1:01, ssid: public
bssid2: 00:0b:0e:00:d1:03, ssid: employee-net
bssid3: 00:0b:0e:00:d1:05, ssid: mycorp-tkip

The following command uses the **terse** option to display brief information for APs:

WSS# show ap status terse

Total number of entries: 4

Operational: 1, Image Downloading: 0, Unknown: 3, Other: 0

Flags: o = operational, b = booting, d = image downloading

c = configuring, f = configuration failed

a = auto AP, i = insecure

Port	Flg	IP Address	Model	MAC Address	Radio1	Radio2	Uptime	
3 ---		AP-372	D ?/?	D ?/?	0d	0h	0m	0s
ap 1 ---		AP-372	D ?/?	D ?/?	0d	0h	0m	0s
ap 2 ---		AP-372	D ?/?	D ?/?	0d	0h	0m	0s

ap100 oa-
10.8.255.11 AP-122 00:0b:0e:da:da:82 E 1/17 E36/11 0d 0h 0m17s

Table 46 and Table 46 describe the fields in these displays.

Table 13: Output for show ap status

Field	Description
AP	Connection ID for the AP. Note: This field is applicable only if the AP is configured on the WSS as a AP.
Port	WSS port number. Note: This field is applicable only if the AP is directly connected to the WSS and the WSS's port is configured as an AP access port.
IP-addr	IP address of the AP. The address is assigned to the AP by a DHCP server. Note: This field is applicable only if the AP is configured on the WSS as a AP.
AP model	AP model number.
manufacturer	Company that made the AP.
fingerprint	Hexadecimal fingerprint of the AP's public encryption key. Note: This field is displayed only for APs.
name	AP name.
Link	Status of this link with the AP and the AP port at the other end of the link. The status can be up or down.
AP port	AP port number connected to this WSS port.

Table 13: Output for show ap status (continued)

Field	Description
State	<p data-bbox="554 265 705 289">State of the AP:</p> <ul data-bbox="554 300 1165 817" style="list-style-type: none"> <li data-bbox="554 300 1165 357">• init—The AP has been recognized by the WSS but has not yet begun booting. <li data-bbox="554 366 1165 423">• booting—The AP has asked the WSS for a boot image. <li data-bbox="554 432 1165 489">• image downloading—The AP is receiving a boot image from the WSS. <li data-bbox="554 498 1165 555">• image downloaded—The AP has received a boot image from the WSS and is booting. <li data-bbox="554 564 1165 652">• configuring—The AP has booted and is ready to receive or is already receiving configuration parameters from the WSS. <li data-bbox="554 661 1165 749">• operational—The AP has received configuration parameters for one or more radios and is ready to accept client connections. <li data-bbox="554 758 1165 817">• configure failure—One or more of the radio parameters received from the WSS is invalid. <p data-bbox="554 826 1165 900">For APs, this field also indicates whether the AP's management traffic with the WSS is encrypted, and whether the AP's fingerprint has been verified on the WSS:</p> <ul data-bbox="554 909 1165 1182" style="list-style-type: none"> <li data-bbox="554 909 1165 966">• not encrypted—The management session is not encrypted. <li data-bbox="554 975 1165 1090">• encrypted but fingerprint not verified—The AP's management traffic is encrypted, but the AP's fingerprint has not been verified in WSS Software. <li data-bbox="554 1098 1165 1182">• encrypted and verified—The AP's management traffic is encrypted and the AP's fingerprint has been verified in WSS Software.
CPU info	<p data-bbox="554 1203 979 1227">Specifications and identification of the CPU.</p> <p data-bbox="554 1236 1165 1277">For AP models other than AP-1xx or AP-2xx, the ID portion of this field is not applicable.</p>
Uptime	Amount of time since the AP booted using this link.

Table 13: Output for show ap status (continued)

Field	Description
Radio 1 type	802.11 type and configuration state of the radio.
Radio 2 type	<ul style="list-style-type: none"> • The <i>configure succeed</i> state indicates that the AP has received configuration parameters for the radio and the radio is ready to accept client connections. • <i>802.11b protect</i> indicates that the 802.11b/g radio is sending messages to 802.11b devices, while sending 802.11g traffic at higher data rates, to inform the 802.11b devices about the 802.11g traffic and reserve bandwidth for the traffic. Protection mode remains in effect until 60 seconds after the last 802.11b traffic is detected by the 802.11b/g radio. • <i>Sweep Mode</i> indicates that a disabled radio is nonetheless participating in rogue detection scans. Even though this message appears only for disabled radios, all radios, enabled or disabled, participate in rogue detection. • <i>Countermeasures Enabled</i> indicates that the radio is sending countermeasures packets to combat a rogue. • <i>Radar Scan</i> indicates that the radio is performing the initial channel availability check for Dynamic Frequency Selection (DFS). This state lasts during the first 60 seconds an 802.11a radio is on a new channel, during which time the radio does not transmit. If the radio does not detect any radar on the channel, the radio starts using the channel for data. If the radio does detect radar, the flag changes to <i>Radar Detected</i>. (See below).

Table 13: Output for show ap status (continued)

Field	Description
Radio 1 type Radio 2 type (cont.)	<ul style="list-style-type: none"> <i>Radar Detected</i> indicates that DFS has detected radar on the channel. When this occurs, the AP stops transmitting on the channel for 30 minutes. If RF Auto-Tuning is enabled for channel assignment, the radio selects another channel and performs the initial channel availability check on the new channel, during which time the flag changes back to <i>Radar Scan</i>. <p>Note: <i>Radar Scan</i> and <i>Radar Detected</i> apply only to 802.11a radios, for country codes that use DFS.</p> <ul style="list-style-type: none"> The following information appears for external antennas: <ul style="list-style-type: none"> <i>External antenna detected, configured as antenna-model</i>—Indicates that an external antenna has been detected, and lists the antenna model configured on the radio. (WSS Software does not detect the specific model.) <i>External antenna detected, not configured</i>—Indicates that an external antenna was detected but no external antenna is configured on the radio. <i>External antenna not detected, configured as antenna-model</i>—Indicates that an external antenna is configured on the radio but no external antenna was detected.
operational channel	<p>The channel on which the radio is currently operating.</p> <p>Note: If the channel number is followed by <i>(Auto)</i>, the value was set by RF Auto-Tuning.</p>
operational power	<p>The power level at which the radio is currently operating.</p> <p>Note: If the power setting is followed by <i>(Auto)</i>, the value was set by RF Auto-Tuning.</p>
base mac	Base MAC address of the radio.

Table 13: Output for show ap status (continued)

Field	Description
bssid, ssid	SSIDs configured on the radio and their BSSIDs.
RFID Reports	Status of AeroScout asset tag support. <ul style="list-style-type: none"> Active—The AeroScout Engine has enabled the tag report mode on the AP. Inactive—The AeroScout Engine has not enabled, or has disabled, the tag report mode on the AP. <p>Note: This field is displayed only if the rfid-mode option is enabled on the radio profile that manages the radio.</p>

Table 14: Output for show ap status terse and show ap status terse

Field	Description
Port	WSS port number connected to the AP.
Flg	Operational status flags for the AP. For flag definitions, see the key in the command output.
IP Address	IP address of the AP. The address is assigned to the AP by a DHCP server. Note: This field is applicable only if the AP is configured on the WSS as a AP.
Model	AP model number.
MAC Address	MAC address of the AP.
Radio1	State, channel, and power information for radio 1: <ul style="list-style-type: none"> The state can be D (disabled) or E (enabled). The channel and power settings are shown as <i>channel/power</i>.
Radio2	State, channel, and power information for radio 2.
Uptime	Amount of time since the AP booted using this link.

show ap vlan

Displays information about the VLANs that are either locally switched by the specified AP or tunneled from the AP to an WSS switch.

Syntax `show ap vlan ap-number`

ap-number Index value that identifies the AP on the WSS switch.

Defaults None.

Access All.

History Introduced in WSS Version 6.0.

Examples The following command displays information about the VLANs switched by AP 7:

WSS# show ap vlan 7

AP 7:

VLAN Name	Mode	Port	Tag
1 default	local	1	none
2 red	local	1	2
		radio_1	20
		radio_1	21
		radio_2	22
4 green	local	1	4
		radio_1	23
5 yellow	tunnel	WSS_tun	5
		radio_1	24

[Table 42](#) describes the fields in the `show ap vlan` output.

Table 15: Output for show ap vlan

Field	Description
VLAN	VLAN number.
Name	VLAN name
Mode	Whether packets for the VLAN are locally switched by the AP, or are tunneled to an WSS switch, which places them on the VLAN.
Port	The port(s) through which traffic for the VLAN is sent.
TAG	VLAN tag value. If the interface is untagged, none is displayed in the TAG field.

- **set vlan-profile**
- **set ap local-switching mode on page 260**

show auto-tune attributes

Displays the current values of the RF attributes RF Auto-Tuning uses to decide whether to change channel or power settings.

Syntax `show auto-tune attributes`
`[ap ap-num [radio { 1 | 2 | all }]]`

Syntax `show auto-tune attributes`
`[ap ap-num [radio { 1 | 2 | all }]]`

<i>ap-num</i>	AP port connected to the AP for which to display RF attributes.
<i>ap-num</i>	Number of a AP for which to display RF attributes.
radio 1	Shows RF attribute information for radio 1.
radio 2	Shows RF attribute information for radio 2. (This option does not apply to single-radio models.)
radio all	Shows RF attribute information for both radios.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 3.0.
 Option **dap** removed in version 6.0.

Examples The following command displays RF attribute information for radio 1 on the directly connected AP on port 2:

WSS# show auto-tune attributes ap 2 radio 1

Auto-tune attributes for port 2 radio 1:

```
Noise:          -92 Packet Retransmission Count:      0
Utilization:    0 Phy Errors Count:                  0
CRC Errors count: 122
```

[Table 49](#) describes the fields in this display.

Table 16: Output for show auto-tune attributes

Field	Description
Noise	Noise threshold on the active channel. RF Auto-Tuning prefers channels with low noise levels over channels with higher noise levels.
Utilization	Number of multicast packets per second that a radio can send on a channel while continuously sending fixed size frames over a period of time. The number of packets that are successfully transmitted indicates how busy the channel is.
CRC Errors count	Number of frames received by the radio on that active channel that had CRC errors. A high CRC error count can indicate a hidden node or co-channel interference.

Table 16: Output for show auto-tune attributes (continued)

Field	Description
Packet Retransmission Count	Number of retransmitted packets sent from the client to the radio on the active channel. Retransmissions can indicate that the client is not receiving ACKs from the AP radio.
Phy Errors Count	Number of frames received by the AP radio that had physical layer errors on the active channel. Phy errors can indicate interference from a non-802.11 device.

See Also

- **set ap radio auto-tune max-power on page 265**
- **set radio-profile auto-tune channel-config on page 279**
- **set radio-profile auto-tune channel-holddown on page 280**
- **set radio-profile auto-tune channel-interval on page 281**
- **set radio-profile auto-tune power-backoff-timer on page 282**
- **set radio-profile auto-tune power-config on page 282**
- **set radio-profile auto-tune power-interval on page 283**
- **show auto-tune neighbors on page 368**
- **show radio-profile on page 376**

show auto-tune neighbors

Displays the other Nortel radios and third-party 802.11 radios that a Nortel radio can hear.

Syntax `show auto-tune neighbors`
`[ap ap-num [radio { 1 | 2 | all }]]`

<i>ap-num</i>	AP port connected to the AP for which to display neighbors.
<i>ap-num</i>	Number of a AP for which to display neighbors.
radio 1	Shows neighbor information for radio 1.
radio 2	Shows neighbor information for radio 2. (This option does not apply to single-radio models.)
radio all	Shows neighbor information for both radios.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 3.0.
 Option **dap** removed in version 6.0.

Usage For simplicity, this command displays a single entry for each Nortel radio, even if the radio is supporting multiple BSSIDs. However, BSSIDs for third-party 802.11 radios are listed separately, even if a radio is supporting more than one BSSID.

Information is displayed for a radio if the radio sends beacon frames or responds to probe requests. Even if a radio's SSIDs are unadvertised, Nortel radios detect the empty beacon frames (beacon frames without SSIDs) sent by the radio, and include the radio in the neighbor list.

Examples The following command displays neighbor information for radio 1 on the directly connected AP on port 2:

```
WSS# show auto-tune neighbors ap 2 radio 1
```

```
Total number of entries for port 2 radio 1: 5
```

```
Channel Neighbor BSS/MAC RSSI
```

```
-----
 1 00:0b:85:06:e3:60 -46
 1 00:0b:0e:00:0a:80 -78
 1 00:0b:0e:00:d2:c0 -74
 1 00:0b:85:06:dd:00 -50
 1 00:0b:0e:00:05:c1 -72
```

Table 46 describes the fields in this display.

Table 17: Output for show auto-tune neighbors

Field	Description
Channel	Channel on which the BSSID is detected.
Neighbor BSS/MAC	BSSID detected by the radio.
RSSI	Received signal strength indication (RSSI), in decibels referred to 1 milliwatt (dBm). A higher value indicates a stronger signal.

See Also

- [set ap radio auto-tune max-power on page 265](#)
- [set radio-profile auto-tune channel-config on page 279](#)
- [set radio-profile auto-tune channel-holddown on page 280](#)
- [set radio-profile auto-tune channel-interval on page 281](#)
- [set radio-profile auto-tune power-config on page 282](#)
- [set radio-profile auto-tune power-interval on page 283](#)
- [show ap vlan on page 365](#)
- [show radio-profile on page 376](#)

show ap boot-configuration

Displays information about the static IP address configuration (if any) on a AP.

Syntax `show ap boot-configuration ap-num`

ap-num Index value that identifies the AP on WSS.

Defaults None.

Access Enabled.

History

Version 4.1 Command introduced in WSS Software.

Version 6.0 Option dap removed.
Field Mesh added
Field Mesh SSID added
Field Mesh PSK added

Examples The following command displays static IP configuration information for AP 1:

WSS# show ap boot-configuration 1

Flags: 0

AP: 1

IP Address: Disabled

VLAN Tag: Disabled

Switch: Disabled

Mesh: Disabled

IP Address:

Netmask:

Gateway:

VLAN Tag:

Switch IP:

Switch Name:

DNS IP:

Mesh SSID:

Mesh PSK:

[Table 44](#) describes the fields in this display.

Table 18: Output for show ap boot-configuration

Field	Description
AP	AP number.
VLAN Tag	The VLAN tag that the AP is configured to use (if any).

Table 18: Output for show ap boot-configuration (continued)

Field	Description
Switch	Whether the AP is configured to use a manually specified WSS as its boot device.
Mesh	Whether WLAN mesh services are enabled for this AP.
IP address	The static IP address assigned to this AP.
Netmask	The subnet mask assigned to this AP.
Gateway	The IP address of the default gateway assigned to this AP.
Switch IP	The IP address of the WSS that this AP is configured to use as its boot device (if any).
Switch Name	The name of the WSS that this AP is configured to use as its boot device (if any).
DNS IP	The IP address of the DNS server that the AP uses to resolve the name of the WSS used as its boot device.
Mesh SSID	The WLAN mesh services SSID this AP is configured to use (if any).
Mesh PSK	The preshared key (PSK) the AP uses for authentication with a Mesh Portal AP (if any.)

show ap connection

Displays the system IP address of the WSS that booted a AP.

Syntax `show ap connection [ap-num | serial-id serial-ID]`

ap-num Number of a AP for which to display information about its active connection.

serial-id *serial-ID* AP serial ID.

Defaults None.

Access Enabled.

Usage The **serial-id** parameter displays the active connection for the specified AP even if that AP is not configured on this WSS. If you instead use the command with the *ap-num* parameter or without a parameter, connection information is displayed only for APs that are configured on this WSS.

This command provides information only if the AP is configured on the switch where you use the command. The switch does not need to be the one that booted the AP, but it must have the AP in its configuration. Also, the switch that booted the AP must be in the same Mobility Domain as the switch where you use the command.

If a AP is configured on this WSS (or another WSS in the same Mobility Domain) but does not have an active connection, the command does not display information for the AP. To show connection information for APs, use the **show ap global** command on one of the switches where the APs are configured.

Examples The following command displays information for all APs configured on this WSS that have active connections:

```
WSS# show ap connection
Total number of entries: 2
AP Serial Id   AP IP Address WSS IP Address
-----
2   112233      10.10.2.27   10.3.8.111
4   0333000298 10.10.3.34   10.3.8.111
```

The following command displays connection information specifically for a AP with serial ID 223344:

```
WSS# show ap connection serial-id 223344
Total number of entries: 1
AP Serial Id AP IP Address WSS IP Address
-----
9   223344      10.10.4.88   10.9.9.11
```

[Table 52](#) describes the fields in this display.

Table 19: Output for show ap connection

Field	Description
AP	Connection ID you assigned to the AP. If the connection is configured on another WSS, this field contains a hyphen (-).
Serial Id	Serial ID of the AP.
AP IP Address	IP address assigned by DHCP to the AP.
WSS IP Address	System IP address of the WSS on which the AP has an active connection. This is the switch that the AP used for booting and configuration and is using for data transfer.

See Also

- [show ap config on page 344](#)
- [show ap global on page 373](#)
- [show ap unconfigured on page 374](#)

show ap global

Displays connection information for APs configured on a WSS.

Syntax `show ap global` [*ap-num* | **serial-id** *serial-ID*]

ap-num Number of a AP for which to display configuration settings.

serial-id *serial-ID* AP serial ID.

Defaults None.

Access Enabled.

Usage Connections are shown only for the APs that are configured on the WSS from which you enter the command, and only for the Mobility Domain the switch is in.

To show information only for APs that have active connections, use the **show ap connection** command.

Examples The following command displays connection information for all the APs configured on a WSS:

```
WSS# show ap global
Total number of entries: 8
AP  Serial Id  WSS IP Address  Bias
---  -
1    11223344  10.3.8.111     HIGH
-    11223344  10.4.3.2       LOW
2    332211    10.3.8.111     LOW
-    332211    10.4.3.2       HIGH
17   0322100185 10.3.8.111     HIGH
-    0322100185 10.4.3.2       LOW
18   0321500120 10.3.8.111     LOW
-    0321500120 10.4.3.2       HIGH
```

[Table 53](#) describes the fields in this display.

Table 20: Output for show ap global

Field	Description
AP	Connection ID you assigned to the AP. Note: AP numbers are listed only for APs configured on this WSS. If the field contains a hyphen (-), the AP configuration displayed in the row of output is on another WSS.
Serial Id	Serial ID of the AP.

Table 20: Output for show ap global (continued)

Field	Description
WSS IP Address	System IP address of the WSS on which the AP is configured. A separate row of output is displayed for each WSS on which the AP is configured.
Bias	Bias of the WSS for the AP: <ul style="list-style-type: none"> • High • Low

See Also

- **set ap on page 33**
- **set ap bias on page 249**
- **show ap config on page 344**
- **show ap connection on page 371**
- **show ap unconfigured on page 374**

show ap unconfigured

Displays APs that are physically connected to the network but that are not configured on any WSSs.

Syntax `show ap unconfigured`

Defaults None.

Access Enabled.

Usage This command also displays an AP that is directly connected to a WSS, if the WSS port to which the AP is connected is configured as a network port instead of an AP access port, and if the network port is a member of a VLAN.

If a AP is configured on a WSS in another Mobility Domain, the AP can appear in the output until the AP is able to establish a connection with a WSS in its Mobility Domain. After the AP establishes a connection, the entry for the AP ages out and no longer appears in the command's output.

Entries in the command output's table age out after two minutes.

Examples The following command displays information for two APs that are not configured:

WSS# show ap unconfigured

Total number of entries: 2

Serial Id	Model	IP Address	Port	Vlan
0333001287	AP-241	10.3.8.54	5	default
0333001285	AP-252	10.3.8.57	7	vlan-eng

[Table 54](#) describes the fields in this display.

Table 21: Output for show ap unconfigured

Field	Description
Serial Id	Serial ID of the AP.
Model	AP model number.
IP Address	IP address of the AP. This is the address that the AP receives from a DHCP server. The AP uses this address to send a Find WSS message to request configuration information from WSS switches. However, the AP cannot use the address to establish a connection unless the AP first receives a configuration from a WSS.
Port	Port number on which this WSS received the AP's Find WSS message.
VLAN	VLAN on which this WSS received the AP's Find WSS message.

See Also

- **show ap connection** on page 371
- **show ap global** on page 373

show load-balancing group

Displays an RF load balancing group's member radios and current load for each radio.

Syntax `show load-balancing group {group-name | all | [ap ap-number radio {1 | 2}]}`

<i>group-name</i>	Name of an RF load-balancing group configured on the WSS switch.
all	Displays information for every load-balancing group that has a radio on this WSS switch as a member.
<i>ap-number</i>	Index value that identifies the AP on the WSS switch.
radio {1 2}	Shows status information for a radio on an AP. This option displays information about radios in the same group as the specified radio.

Defaults None.

Access Enabled.

History Introduced in WSS Version 6.0.

Usage Use this command to display information about the RF load-balancing groups configured on the WSS and the individual AP radios in the load-balancing groups.

Examples The following command displays information about the AP radios that are in the same group as radio 1 on AP 3:

```
WSS# show load-balancing group ap 3 radio 1
Radios in the same load-balancing group as: ap3/radio1
```

```
-----
IP address      AP   Radio  Overlap
-----
10.2.28.200    3    1    100/100
```

The following command displays information about RF load balancing group *blue*:

```
WSS# show load-balancing group blue
```

```
Load-balancing group: blue
IP address      AP   Radio  Clients
-----
10.2.28.200    3    1      0
```

[Table 55](#) describes the fields in displayed by the **show load-balancing group** command.

Table 22: Output for show load-balancing group

Field	Description
IP address	The IP address of the AP in the load-balancing group.
AP	AP number
Radio	Radio number
Overlap	The amount of overlapping coverage area the specified AP radio has with the AP radio in the list. An overlap of 100/100 indicates that the AP radios have exactly the same coverage area.
Clients	The current client load on the AP radio.

See Also

- [set load-balancing strictness on page 277](#)
- [set ap radio load-balancing on page 268](#)
- [set ap local-switching mode on page 260](#)

show radio-profile

Displays radio profile information.

```
Syntax show radio-profile {name | ?}
```

```
name           Displays information about the named radio profile.
?              Displays a list of radio profiles.
```

Defaults None.

Access Enabled.

History

- | | |
|-------------|--|
| Version 4.0 | <ul style="list-style-type: none"> • New fields added: <ul style="list-style-type: none"> • Countermeasures • Active-Scan • WMM enabled • Name of the backoff timer field changed from Client Backoff Timer to Power Backoff Timer |
| Version 4.1 | <ul style="list-style-type: none"> • WMM enabled field renamed to QoS Mode. • Long Retry Limit and Short Retry Limit fields moved to show service-profile output. (These options are now configurable on a service-profile basis instead of a radio-profile basis.) • Allow 802.11g clients only field removed. (This option is now configured using the set service-profile transmit-rates command.) |
| Version 5.0 | <ul style="list-style-type: none"> • New fields added: <ul style="list-style-type: none"> • Power ramp interval • RFID enabled • WMM Powersave • Power Backoff Timer field removed. |

Usage WSS Software contains a *default* radio profile. Nortel recommends that you do not change this profile but instead keep the profile for reference.

Examples The following command shows radio profile information for the *default* radio profile:

WSS# show radio-profile default

Beacon Interval:	100	DTIM Interval:	1
Max Tx Lifetime:	2000	Max Rx Lifetime:	2000
RTS Threshold:	2346	Frag Threshold:	2346
Long Preamble:	no	Tune Channel:	yes
Tune Power:	no	Tune Channel Interval:	3600
Tune Power Interval:	600	Power ramp interval:	60
Channel Holddown:	300	Countermeasures:	none
Active-Scan:	yes	RFID enabled:	no
WMM Powersave:	no	QoS Mode:	wmm

No service profiles configured.

[Table 56](#) describes the fields in this display.

Table 23: Output for show radio-profile

Field	Description
Beacon Interval	Rate (in milliseconds) at which each AP radio in the profile advertises the beaoned SSID.
DTIM Interval	Number of times after every beacon that each AP radio in the radio profile sends a delivery traffic indication map (DTIM).
Max Tx Lifetime	Number of milliseconds that a frame <i>received</i> by a radio in the radio profile can remain in buffer memory.
Max Rx Lifetime	Number of milliseconds that a frame <i>scheduled to be transmitted</i> by a radio in the radio profile can remain in buffer memory.
RTS Threshold	Minimum length (in bytes) a frame can be for a radio in the radio profile to use the RTS/CTS method to send the frame. The RTS/CTS method clears the air of other traffic to avoid corruption of the frame due to a collision with another frame.
Frag Threshold	Maximum length (in bytes) a frame is allowed to be without being fragmented into multiple frames before transmission by a radio in the radio profile.
Long Preamble	Indicates whether an 802.11b radio that uses this radio profile advertises support for frames with long preambles only: <ul style="list-style-type: none"> • YES—Advertises support for long preambles only. • NO—Advertises support for long and short preambles.
Tune Channel	Indicates whether RF Auto-Tuning is enabled for dynamically setting and tuning channels.
Tune Power	Indicates whether RF Auto-Tuning is enabled for dynamically setting and tuning power levels.
Tune Channel Interval	Interval, in seconds, at which RF Auto-Tuning decides whether to change the channels on radios in a radio profile. At the end of each interval, WSS Software processes the results of the RF scans performed during the previous interval, and changes radio channels if needed.
Tune Power Interval	Interval, in seconds, at which RF Auto-Tuning decides whether to change the power level on radios in a radio profile. At the end of each interval, WSS Software processes the results of the RF scans performed during the previous interval, and changes radio power levels if needed.
Power ramp interval	Number of seconds a radio waits before increasing or decreasing its power by 1 dBm in response to a power change from RF Auto-Tuning. After each power ramp interval, the radio increases or decreases the power by another 1 dB until the radio reaches the power level selected by RF Auto-Tuning.
Channel Holddown	Minimum number of seconds a radio in a radio profile must remain at its current channel assignment before RF Auto-Tuning can change the channel.

Table 23: Output for show radio-profile (continued)

Field	Description
Countermeasures	Indicates whether countermeasures are enabled.
Active-Scan	Indicates whether the active-scan mode of RF detection is enabled.
RFID enabled	Indicates whether AeroScout tag support is enabled.
WMM Powersave	Indicates whether U-APSD support is enabled.
QoS Mode	<p>Indicates the Quality-of-Service setting for AP radio forwarding queues:</p> <ul style="list-style-type: none"> • wmm—AP forwarding queues provide standard priority handling for WMM devices. • svp—AP forwarding queues are optimized for SpectraLink Voice Priority (SVP). <p>For information about the QoS modes, see the “Configuring Quality of Service” chapter in the Nortel WLAN Security Switch 2300 Series Configuration Guide.</p>
Service profiles	<p>Service profiles mapped to this radio profile. Each service profile contains an SSID and encryption information for that SSID.</p> <p>Note: When you upgrade from 2.x, WSS Software creates a default-dot1x service profile for encrypted SSIDs and a default-clear service profile for unencrypted SSIDs. These default service profiles contain the default encryption settings for crypto SSIDs and clear SSIDs, respectively.</p>

See Also

- [set radio-profile active-scan on page 278](#)
- [set radio-profile auto-tune channel-config on page 279](#)
- [set radio-profile auto-tune channel-holddown on page 280](#)
- [set radio-profile auto-tune channel-interval on page 281](#)
- [set radio-profile auto-tune channel-lockdown on page 282](#)
- [set radio-profile auto-tune power-config on page 282](#)
- [set radio-profile auto-tune power-interval on page 283](#)
- [set radio-profile auto-tune power-lockdown on page 284](#)
- [set radio-profile auto-tune power-ramp-interval on page 285](#)
- [set radio-profile beacon-interval on page 285](#)
- [set radio-profile countermeasures on page 287](#)
- [set radio-profile dtim-interval on page 288](#)
- [set radio-profile frag-threshold on page 289](#)
- [set radio-profile max-rx-lifetime on page 290](#)
- [set radio-profile max-tx-lifetime on page 290](#)

- **set radio-profile mode** on page 291
- **set radio-profile preamble-length** on page 294
- **set radio-profile qos-mode** on page 295
- **set radio-profile rfid-mode** on page 296
- **set radio-profile rts-threshold** on page 297
- **set radio-profile service-profile** on page 298
- **set radio-profile wmm-powersave** on page 305

show service-profile

Displays service profile information.

Syntax `show service-profile {name | ?}`

<i>name</i>	Displays information about the named service profile.
?	Displays a list of service profiles.

Defaults None.

Access Enabled.

History

Version 4.1	New fields added to indicate the configured SSID default attributes in the service profile.
-------------	---

- Version 4.1
- New fields added:
- Proxy ARP
 - DHCP restrict
 - No broadcast
 - Short retry limit (moved from **show radio-profile** output)
 - Long retry limit (moved from **show radio-profile** output)
 - Sygate On-Demand (SODA)
 - Enforce SODA checks:
 - SODA remediation ACL
 - Custom success web-page
 - Custom failure web-page
 - Custom logout web-page
 - Custom agent-directory
 - Static COS
 - COS
 - CAC mode
 - CAC sessions
 - User idle timeout
 - Idle client probing
 - Web Portal Session Timeout
 - Transmit rates for 11a / 11b / 11g:
 - beacon rate
 - multicast rate
 - mandatory rate
 - standard rates
 - disabled rates
- Version 5.0
- New fields added:
- Active call timeout
 - Keep initial vlan
 - Web Portal ACL

Examples The following command displays information for service profile *sp1*:

WSS# show service-profile sp1

```
ssid-name:          corp2  ssid-type:          crypto
Beacon:            yes   Proxy ARP:          no
DHCP restrict:     no   No broadcast:       no
Short retry limit: 5     Long retry limit:   5
Auth fallthru:     none  Sygate On-Demand (SODA):no
```

```

Enforce SODA checks: yes   SODA remediation ACL:
Custom success web-page:   Custom failure web-page:
Custom logout web-page:   Custom agent-directory:
Static COS:                no   COS:                0
CAC mode:                  none CAC sessions:        14
User idle timeout:        180 Idle client probing: yes
Keep initial vlan:        no   Web Portal Session Timeout: 5
Web Portal ACL:
WEP Key 1 value:          <none> WEP Key 2 value:          <none>
WEP Key 3 value:          <none> WEP Key 4 value:          <none>
WEP Unicast Index:        1     WEP Multicast Index:      1
Shared Key Auth:          NO
WPA enabled:
  ciphers: cipher-tkip
  authentication: 802.1X
  TKIP countermeasures time: 60000ms
vlan-name = orange
session-timeout = 300
service-type = 2
11a beacon rate:          6.0  multicast rate:          AUTO
11a mandatory rate:       6.0,12.0,24.0 standard rates: 9.0,18.0,36.0,48.0,54.0
11b beacon rate:          2.0  multicast rate:          AUTO
11b mandatory rate:       1.0,2.0 standard rates: 5.5,11.0
11g beacon rate:          2.0  multicast rate:          AUTO
11g mandatory rate:       1.0,2.0,5.5,11.0 standard rates: 6.0,9.0,12.0,18.0,24.0, 36.0,48.0,54.0

```

Table 57 describes the fields in this display.

Table 24: Output for show service-profile

Field	Description
ssid-name	Service set identifier (SSID) managed by this service profile.
ssid-type	SSID type: <ul style="list-style-type: none"> • crypto—Wireless traffic for the SSID is encrypted. • clear—Wireless traffic for the SSID is unencrypted.
Beacon	Indicates whether the radio sends beacons, to advertise the SSID: <ul style="list-style-type: none"> • no • yes
Proxy ARP	Indicates whether proxy ARP is enabled. When this feature is enabled, WSS Software answers ARP requests on behalf of wireless clients.
DHCP restrict	Indicates whether DHCP Restrict is enabled. When this feature is enabled, WSS Software allows only DHCP traffic for a new client until the client has successfully completed authentication and authorization.

Table 24: Output for show service-profile (continued)

Field	Description
No broadcast	Indicates whether broadcast restriction is enabled. When this feature is enabled, WSS Software sends ARP requests and DHCP Offers and Acks as unicasts to their target clients instead of forwarding them as broadcasts.
Short retry limit	Number of times a radio serving the service-profile's SSID can send a short unicast frame without receiving an acknowledgment.
Long retry limit	Number of times a radio serving the service-profile's SSID can send a long unicast frame without receiving an acknowledgment. A long unicast frame is a frame that is <i>equal to or longer than</i> the RTS threshold.
Auth fallthru	<p>Secondary (fallthru) encryption type when a user tries to authenticate but the WSS managing the radio does not have an authentication rule with a userwildcard that matches the username.</p> <ul style="list-style-type: none"> • last-resort—Automatically authenticates the user and allows access to the SSID requested by the user, without requiring a username and password. • none—Denies authentication and prohibits the user from accessing the SSID. • web-portal—Redirects the user to a web page for login to the SSID.
Sygate On-Demand (SODA)	Whether SODA functionality is enabled for the service profile. When SODA functionality is enabled, connecting clients download SODA agent files, which perform security checks on the client.
Enforce SODA checks	Whether a client is allowed access to the network after it has downloaded and run the SODA agent security checks. When SODA functionality is enabled, and the WSS is configured to enforce SODA checks, then a connecting client must download the SODA agent files and pass the checks in order to gain access to the network.
SODA remediation ACL	The name of the ACL to be applied to the client if it fails the SODA agent checks. If no remediation ACL is specified, then a client is disconnected from the network if it fails the SODA agent checks.
Custom success web-page	The name of the user-specified page that the client loads upon successful completion of the SODA agent checks. If no page is specified, then the success page is generated dynamically.
Custom failure web-page	The name of the user-specified page that the client loads if it fails SODA agent checks. If no page is specified, then the failure page is generated dynamically.
Custom logout web-page	The name of the user-specified page that the client loads upon logging out of the network, either by closing the SODA virtual desktop, or by requesting the page. If no page is specified, then the client is disconnected without loading a logout page.

Table 24: Output for show service-profile (continued)

Field	Description
Custom agent-directory	The name of the directory for SODA agent files on the WSS, if different from the default. By default, SODA agent files are stored in a directory with the same name as the service profile.
Static CoS	Indicates whether static CoS assignment is enabled. When this feature is enabled, APs assign the CoS value in the COS field to all user traffic forwarded by the AP.
COS	CoS value assigned by the AP to all user traffic, if static CoS is enabled. (If static CoS is disabled, WMM or ACLs are used to assign CoS.)
CAC mode	Call Admission Control mode: <ul style="list-style-type: none"> • none—CAC is disabled. • session—CAC is based on the number of active user sessions. If an AP radio reaches the maximum number of active user sessions specified in the CAC session field, the AP radio rejects new connection attempts.
CAC sessions	Maximum number of user sessions that can be active on an AP radio at one time, if the CAC mode is session. (If the CAC mode is none, this value is not used.)
User idle timeout	Indicates how many seconds a user session can remain idle (indicated by no user traffic and no reply to client keepalive probes) before the session is changed to the Disassociated state.
Idle client probing	Indicates whether client keepalive probes are enabled.
Keep initial VLAN	Indicates whether the keep-initial-vlan option is enabled.
Web Portal Session Timeout	When a Web Portal Web-based AAA session is placed in the Deassociated state, how many seconds the session can remain in that state before being terminated automatically.
Web Portal ACL	Name of the ACL used to filter traffic for Web Portal users associated with this service profile's SSID while the users are being authenticated.
WEP Key 1 value	State of static WEP key number 1. Radios can use this key to encrypt traffic with static Wired-Equivalent Privacy (WEP): <ul style="list-style-type: none"> • none—The key is not configured. • preset—The key is configured. <p>Note: The WEP parameters apply to traffic only on the encrypted SSID.</p>
WEP Key 2 value	State of static WEP key number 2: <ul style="list-style-type: none"> • none—The key is not configured. • preset—The key is configured.

Table 24: Output for show service-profile (continued)

Field	Description
WEP Key 3 value	State of static WEP key number 3: <ul style="list-style-type: none"> • none—The key is not configured. • preset—The key is configured.
WEP Key 4 value	State of static WEP key number 4: <ul style="list-style-type: none"> • none—The key is not configured. • preset—The key is configured.
WEP Unicast Index	Index of the static WEP key used to encrypt unicast traffic on an encrypted SSID.
WEP Multicast Index	Index of the static WEP key used to encrypt multicast traffic on an encrypted SSID.
Shared Key Auth	Indicates whether shared-key authentication is enabled.
WPA enabled or RSN enabled	Indicates that the Wi-Fi Protected Access (WPA) or Robust Security Network (RSN) information element (IE) is enabled. Additional fields display the settings of other WPA or RSN parameters: <ul style="list-style-type: none"> • ciphers—Lists the cipher suites advertised by radios in the radio profile mapped to this service profile. • authentication—Lists the authentication methods supported for WPA or RSN clients: <ul style="list-style-type: none"> • 802.1X—dynamic authentication • PSK—preshared key authentication • TKIP countermeasures time—Indicates the amount of time (in ms) WSS Software enforces countermeasures following a second message integrity code (MIC) failure within a 60-second period. <p>Note: These fields are displayed only when the WPA IE or RSN IE is enabled.</p>
vlan-name, session-timeout, service-type	These are examples of authorization attributes that are applied by default to a user accessing the SSID managed by this service profile (in addition to any attributes assigned to the user by a RADIUS server or the local database). Attributes are listed here only if they have been configured as default attribute settings for the service profile. See Table 29 on page 198 for a list of authorization attributes and values that can be assigned to network users.

Table 24: Output for show service-profile (continued)

Field	Description
11a / 11b / 11g transmit rate fields	<p>Data transmission rate settings for each radio type:</p> <ul style="list-style-type: none"> • beacon rate—Data rate of beacon frames sent by AP radios. • multicast rate—Data rate of multicast frames sent by AP radios. If the rate is auto, the AP sets the multicast rate to the highest rate that can reach all clients connected to the radio. • mandatory rates—Set of data transmission rates that clients are required to support in order to associate with an SSID on an AP radio. A client must support at least one of the mandatory rates. • standard rates—The set of valid rates that are neither mandatory nor disabled. These rates are supported for data transmission from the AP radios. • disabled rates—Data transmission rates that AP radios will not use to transmit data. (The radios will still accept frames from clients at disabled data rates.)

- **set service-profile attr on page 306**
- **set service-profile auth-dot1x on page 307**
- **set service-profile auth-fallthru on page 308**
- **set service-profile auth-psk on page 309**
- **set service-profile beacon on page 310**
- **set service-profile cac-mode on page 311**
- **set service-profile cac-session on page 312**
- **set service-profile cipher-ccmp on page 312**
- **set service-profile cipher-tkip on page 313**
- **set service-profile cipher-wep104 on page 314**
- **set service-profile cipher-wep40 on page 315**
- **set service-profile cos on page 315**
- **set service-profile dhcp-restrict on page 316**
- **set service-profile idle-client-probing on page 317**
- **set service-profile long-retry-count on page 319**
- **set service-profile no-broadcast on page 320**
- **set service-profile proxy-arp on page 321**
- **set service-profile psk-phrase on page 322**

- **set service-profile psk-raw on page 323**
- **set service-profile rsn-ie on page 323**
- **set service-profile shared-key-auth on page 324**
- **set service-profile short-retry-count on page 325**
- **set service-profile soda mode on page 329**
- **set service-profile ssid-name on page 331**
- **set service-profile ssid-type on page 332**
- **set service-profile static-cos on page 332**
- **set service-profile tkip-mc-time on page 333**
- **set service-profile transmit-rates on page 334**
- **set service-profile user-idle-timeout on page 336**
- **set service-profile web-portal-form on page 337**
- **set service-profile web-portal-logout on page 339**
- **set service-profile wep active-multicast-index on page 340**
- **set service-profile wep active-unicast-index on page 341**
- **set service-profile wep key-index on page 342**
- **set service-profile wpa-ie on page 342**

STP Commands

Use Spanning Tree Protocol (STP) commands to configure and manage spanning trees on the virtual LANs (VLANs) configured on a WSS, to maintain a loop-free network. This chapter presents STP commands alphabetically. Use the following table to locate commands in this chapter based on their use.

STP State	<ul style="list-style-type: none"> set spantree on page 393 show spantree on page 400 show spantree blockedports on page 404
Bridge Priority	<ul style="list-style-type: none"> set spantree priority on page 399
Port Cost	<ul style="list-style-type: none"> set spantree portcost on page 395 set spantree portvlancost on page 397 show spantree portvlancost on page 406 clear spantree portcost on page 390 clear spantree portvlancost on page 391
Port Priority	<ul style="list-style-type: none"> set spantree portpri on page 397 set spantree portvlanpri on page 398 clear spantree portpri on page 390 clear spantree portvlanpri on page 391
Timers	<ul style="list-style-type: none"> set spantree fwddelay on page 394 set spantree hello on page 394 set spantree maxage on page 395
Fast Convergence	<ul style="list-style-type: none"> set spantree portfast on page 396 show spantree portfast on page 405 set spantree backbonefast on page 393 show spantree backbonefast on page 403 set spantree uplinkfast on page 399 show spantree uplinkfast on page 412
Statistics	<ul style="list-style-type: none"> show spantree statistics on page 407 clear spantree statistics on page 392

clear spantree portcost

Resets to the default value the cost of a network port or ports on paths to the STP root bridge in all VLANs on a WSS.

Syntax `clear spantree portcost port-list`

port-list List of ports. The port cost is reset on the specified ports.

Defaults None.

Access Enabled.

Usage This command resets the cost in all VLANs. To reset the cost for only specific VLANs, use the **clear spantree portvlancost** command.

Examples The following command resets the STP port cost on ports 5 and 6 to the default value:

```
WSS# clear spantree portcost 5-6
success: change accepted.
```

See Also

- **clear spantree portvlancost on page 391**
- **set spantree portcost on page 395**
- **set spantree portvlancost on page 397**
- **show spantree on page 400**
- **show spantree portvlancost on page 406**

clear spantree portpri

Resets to the default value the priority of a network port or ports for selection as part of the path to the STP root bridge in all VLANs on a WSS.

Syntax `clear spantree portpri port-list`

port-list List of ports. The port priority is reset to 32 (the default) on the specified ports.

Defaults None.

Access Enabled.

Usage This command resets the priority in all VLANs. To reset the priority for only specific VLANs, use the **clear spantree portvlanpri** command.

Examples The following command resets the STP priority on port 9 to the default:

```
WSS# clear spantree portpri 9
success: change accepted.
```


See Also

- **clear spantree portvlanpri on page 391**
- **set spantree portpri on page 397**
- **set spantree portvlanpri on page 398**
- **show spantree on page 400**

clear spantree portvlancost

Resets to the default value the cost of a network port or ports on paths to the STP root bridge for a specific VLAN on a WSS, or for all VLANs.

Syntax `clear spantree portvlancost port-list {all | vlan vlan-id}`

<i>port-list</i>	List of ports. The port cost is reset on the specified ports.
all	Resets the cost for all VLANs.
vlan <i>vlan-id</i>	VLAN name or number. WSS Software resets the cost for only the specified VLAN.

Defaults None.

Access Enabled.

Usage WSS Software does not change a port's cost for VLANs other than the one(s) you specify.

Examples The following command resets the STP cost for port 12 in VLAN *sunflower*:

```
WSS# clear spantree portvlancost 12 vlan sunflower
success: change accepted.
```

See Also

- **clear spantree portcost on page 390**
- **set spantree portcost on page 395**
- **set spantree portvlancost on page 397**
- **show spantree on page 400**
- **show spantree portvlancost on page 406**

clear spantree portvlanpri

Resets to the default value the priority of a network port or ports for selection as part of the path to the STP root bridge, on one VLAN or all VLANs.

Syntax `clear spantree portvlanpri port-list {all | vlan vlan-id}`

port-list List of ports. The port priority is reset to 32 (the default) on the specified ports.

all Resets the priority for all VLANs.

vlan *vlan-id* VLAN name or number. WSS Software resets the priority for only the specified VLAN.

Defaults None.

Access Enabled.

Usage WSS Software does not change a port's priority for VLANs other than the one(s) you specify.

Examples The following command resets the STP priority for port 20 in VLAN *avocado*:

```
WSS# clear spantree portvlanpri 20 vlan avocado
success: change accepted.
```

See Also

- [clear spantree portpri on page 390](#)
- [set spantree portpri on page 397](#)
- [set spantree portvlanpri on page 398](#)
- [show spantree on page 400](#)

clear spantree statistics

Clears STP statistics counters for a network port or ports and resets them to 0.

Syntax `clear spantree statistics port-list [vlan vlan-id]`

port-list List of ports. Statistics counters are reset on the specified ports.

vlan *vlan-id* VLAN name or number. WSS Software resets statistics counters for only the specified VLAN.

Defaults None.

Access Enabled.

Examples The following command clears STP statistics counters for ports 5, 11, and 19 through 22, for all VLANs:

```
WSS# clear spantree statistics 5,11,19-22
success: change accepted.
```

See Also [show spantree statistics on page 407](#)

set spantree

Enables or disables STP on one VLAN or all VLANs configured on a WSS.

Syntax `set spantree {enable | disable}`
`[[all | vlan vlan-id | port port-list vlan-id]]`

enable	Enables STP.
disable	Disables STP.
all	Enables or disables STP on all VLANs.
vlan <i>vlan-id</i>	VLAN name or number. WSS Software enables or disables STP on only the specified VLAN, on all ports within the VLAN.
port <i>port-list vlan-id</i>	Port number or list and the VLAN the ports are in. WSS Software enables or disables STP on only the specified ports, within the specified VLAN.

Defaults Disabled.

Access Enabled.

Examples The following command enables STP on all VLANs configured on a WSS:

```
WSS# set spantree enable
success: change accepted.
```

The following command disables STP on VLAN *burgundy*:

```
WSS# set spantree disable vlan burgundy
success: change accepted.
```

See Also [show spantree on page 400](#)

set spantree backbonefast

Enables or disables STP backbone fast convergence on a WSS. This feature accelerates a port's recovery following the failure of an indirect link.

Syntax `set spantree backbonefast {enable | disable}`

enable	Enables backbone fast convergence.
disable	Disables backbone fast convergence.

Defaults STP backbone fast path convergence is disabled by default.

Access Enabled.

Usage If you plan to use the backbone fast convergence feature, you must enable it on all the bridges in the spanning tree.

Examples The following command enables backbone fast convergence:

```
WSS# set spantree backbonefast enable
```

success: change accepted.

See Also [show spantree backbonefast on page 403](#)

set spantree fwddelay

Changes the period of time after a topology change that a WSS which is not the root bridge waits to begin forwarding Layer 2 traffic on one or all of its configured VLANs. (The root bridge always forwards traffic.)

Syntax `set spantree fwddelay delay {all | vlan vlan-id}`

<i>delay</i>	Delay value. You can specify from 4 through 30 seconds.
all	Changes the forwarding delay on all VLANs.
vlan <i>vlan-id</i>	VLAN name or number. WSS Software changes the forwarding delay on only the specified VLAN.

Defaults The default forwarding delay is 15 seconds.

Access Enabled.

Examples The following command changes the forwarding delay on VLAN *pink* to 20 seconds:

```
WSS# set spantree fwddelay 20 vlan pink
```

success: change accepted.

See Also [show spantree on page 400](#)

set spantree hello

Changes the interval between STP hello messages sent by a WSS when operating as the root bridge, on one or all of its configured VLANs.

Syntax `set spantree hello interval {all | vlan vlan-id}`

<i>interval</i>	Interval value. You can specify from 1 through 10 seconds.
all	Changes the interval on all VLANs.
vlan <i>vlan-id</i>	VLAN name or number. WSS Software changes the interval on only the specified VLAN.

Defaults The default hello timer interval is 2 seconds.

Access Enabled.

Examples The following command changes the hello interval for all VLANs to 4 seconds:

```
WSS# set spantree hello 4 all
success: change accepted.
```

See Also [show spantree on page 400](#)

set spantree maxage

Changes the maximum age for an STP root bridge hello packet that is acceptable to a WSS acting as a designated bridge on one or all of its VLANs. After waiting this period of time for a new hello packet, the switch determines that the root bridge is unavailable and issues a topology change message.

Syntax `set spantree maxage aging-time {all | vlan vlan-id}`

<i>aging-time</i>	Maximum age value. You can specify from 6 through 40 seconds.
all	Changes the maximum age on all VLANs.
vlan <i>vlan-id</i>	VLAN name or number. WSS Software changes the maximum age on only the specified VLAN.

Defaults The default maximum age for root bridge hello packets is 20 seconds.

Access Enabled.

Examples The following command changes the maximum acceptable age for root bridge hello packets on all VLANs to 15 seconds:

```
WSS# set spantree maxage 15 all
success: change accepted.
```

See Also [show spantree on page 400](#)

set spantree portcost

Changes the cost that transmission through a network port or ports in the default VLAN on a WSS adds to the total cost of a path to the STP root bridge.

Syntax `set spantree portcost port-list cost cost`

<i>port-list</i>	List of ports. WSS Software applies the cost change to all the specified ports.
cost <i>cost</i>	Numeric value. You can specify a value from 1 through 65,535. STP selects lower-cost paths over higher-cost paths.

Defaults The default port cost depends on the port speed and link type. [Table 58](#) lists the defaults for STP port path cost.

Table 1. SNMP Port Path Cost Defaults

Port Speed	Link Type	Default Port Path Cost
1000 Mbps	Full Duplex Aggregate Link (Port Group)	19
1000 Mbps	Full Duplex	4
100 Mbps	Full Duplex Aggregate Link (Port Group)	19
100 Mbps	Full Duplex	18
100 Mbps	Half Duplex	19
10 Mbps	Full Duplex Aggregate Link (Port Group)	19
10 Mbps	Full Duplex	95
10 Mbps	Half Duplex	100

Access Enabled.

Usage This command applies only to the default VLAN (VLAN 1). To change the cost of a port in another VLAN, use the **set spantree portvlancost** command.

Examples The following command changes the cost on ports 3 and 4 to 20:

```
WSS# set spantree portcost 3,4 cost 20
```

success: change accepted.

See Also

- [clear spantree portcost on page 390](#)
- [clear spantree portvlancost on page 391](#)
- [set spantree portvlancost on page 397](#)
- [show spantree on page 400](#)
- [show spantree portvlancost on page 406](#)

set spantree portfast

Enables or disables STP port fast convergence on one or more ports on a WSS.

Syntax **set spantree portfast port** *port-list* {enable | disable}

port *port-list* List of ports. WSS Software enables the feature on the specified ports.

enable	Enables port fast convergence.
disable	Disables port fast convergence.

Defaults STP port fast convergence is disabled by default.

Access Enabled.

Usage Use port fast convergence on ports that are directly connected to servers, hosts, or other MAC stations.

Examples The following command enables port fast convergence on ports 9, 11, and 13:

```
WSS# set spantree portfast port 9,11,13 enable
success: change accepted.
```

See Also [show spantree portfast on page 405](#)

set spantree portpri

Changes the STP priority of a network port or ports for selection as part of the path to the STP root bridge in the default VLAN on a WSS.

Syntax `set spantree portpri port-list priority value`

port-list List of ports. WSS Software changes the priority on the specified ports.

priority value Priority value. You can specify a value from 0 (highest priority) through 255 (lowest priority).

Defaults The default STP priority for all network ports is 128.

Access Enabled.

Usage This command applies only to the default VLAN (VLAN 1). To change the priority of a port in another VLAN, use the `set spantree portvlanpri` command.

Examples The following command sets the priority of ports 3 and 4 to 48:

```
WSS# set spantree portpri 3-4 priority 48
success: change accepted.
```

See Also

- [clear spantree portpri on page 390](#)
- [clear spantree portvlanpri on page 391](#)
- [set spantree portvlanpri on page 398](#)
- [show spantree on page 400](#)

set spantree portvlancost

Changes the cost of a network port or ports on paths to the STP root bridge for a specific VLAN on a WSS.

Syntax `set spantree portvlancost port-list cost cost {all | vlan vlan-id}`

<i>port-list</i>	List of ports. WSS Software applies the cost change to all the specified ports.
cost <i>cost</i>	Numeric value. You can specify a value from 1 through 65,535. STP selects lower-cost paths over higher-cost paths.
all	Changes the cost on all VLANs.
vlan <i>vlan-id</i>	VLAN name or number. WSS Software changes the cost on only the specified VLAN.

Defaults The default port cost depends on the port speed and link type. (See [Table 58 on page 396](#).)

Access Enabled.

Examples The following command changes the cost on ports 3 and 4 to 20 in VLAN *mauve*:

```
WSS# set spantree portvlancost 3,4 cost 20 vlan mauve
success: change accepted.
```

See Also

- [clear spantree portcost on page 390](#)
- [clear spantree portvlancost on page 391](#)
- [set spantree portcost on page 395](#)
- [show spantree on page 400](#)
- [show spantree portvlancost on page 406](#)

set spantree portvlanpri

Changes the priority of a network port or ports for selection as part of the path to the STP root bridge, on one VLAN or all VLANs.

Syntax `set spantree portvlanpri port-list priority value {all | vlan vlan-id}`

<i>port-list</i>	List of ports. WSS Software changes the priority on the specified ports.
priority <i>value</i>	Priority value. You can specify a value from 0 (highest priority) through 255 (lowest priority).
all	Changes the priority on all VLANs.
vlan <i>vlan-id</i>	VLAN name or number. WSS Software changes the priority on only the specified VLAN.

Defaults The default STP priority for all network ports is 128.

Access Enabled.

Examples The following command sets the priority of ports 3 and 4 to 48 on VLAN *mauve*:

```
WSS# set spantree portvlanpri 3-4 priority 48 vlan mauve
success: change accepted.
```

See Also

- [clear spantree portpri on page 390](#)
- [clear spantree portvlanpri on page 391](#)
- [set spantree portpri on page 397](#)
- [show spantree on page 400](#)

set spantree priority

Changes the STP root bridge priority of a WSS on one or all of its VLANs.

Syntax `set spantree priority value {all | vlan vlan-id}`

priority value	Priority value. You can specify a value from 0 through 65,535. The bridge with the lowest priority value is elected to be the root bridge for the spanning tree.
all	Changes the bridge priority on all VLANs.
vlan vlan-id	VLAN name or number. WSS Software changes the bridge priority on only the specified VLAN.

Defaults The default root bridge priority for the switch on all VLANs is 32,768.

Access Enabled.

Examples The following command sets the bridge priority of VLAN *pink* to 69:

```
WSS# set spantree priority 69 vlan pink
success: change accepted.
```

See Also [show spantree on page 400](#)

set spantree uplinkfast

Enables or disables STP uplink fast convergence on a WSS. This feature enables a WSS with redundant links to the network backbone to immediately switch to the backup link to the root bridge if the primary link fails.

Syntax `set spantree uplinkfast {enable | disable}`

enable	Enables uplink fast convergence.
disable	Disables uplink fast convergence.

Defaults Disabled.

Access Enabled.

Usage The uplink fast convergence feature is applicable to bridges that are acting as access switches to the network core (distribution layer) but are not in the core themselves. Do not enable the feature on WSSs that are in the network core.

Examples The following command enables uplink fast convergence:

```
WSS# set spantree uplinkfast enable
```

success: change accepted.

See Also [show spantree uplinkfast on page 412](#)

show spantree

Displays STP configuration and port-state information.

Syntax `show spantree [port port-list | vlan vlan-id] [active]`

port *port-list* List of ports. If you do not specify any ports, WSS Software displays STP information for all ports.

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, WSS Software displays STP information for all VLANs.

active Displays information for only the active (forwarding) ports.

Defaults None.

Access All.

History

Version 4.1 Value *STP Off* added for STP-State and Port-State fields. This state indicates that STP is disabled on the port. The *Disabled* state is still used, but only to indicate that the port is not forwarding traffic.

Examples The following command displays STP information for VLAN *default*:

```
WSS# show spantree vlan default
```

```
VLAN 1
Spanning Tree Mode    PVST+
Spanning Tree Type    IEEE
Spanning Tree Enabled

Designated Root       00-02-4a-70-49-f7
Designated Root Priority 32768
Designated Root Path Cost 19
Designated Root Port 1
Root Max Age 20 sec Hello Time 2 sec Forward Delay 15 sec
Bridge ID MAC ADDR    00-0b-0e-02-76-f7
Bridge ID Priority     32768
```

Bridge Max Age 20 sec Hello Time 2 sec Forward Delay 15 sec

412 STP Commands

Port	Vlan	STP-State	Cost	Prio	Portfast
1	1	Forwarding	19	128	Disabled
2	1	STP Off	19	128	Disabled
3	1	Disabled	19	128	Disabled
4	1	Disabled	19	128	Disabled
5	1	Disabled	19	128	Disabled
6	1	Disabled	19	128	Disabled
7	1	Disabled	19	128	Disabled
8	1	Disabled	19	128	Disabled

Table 59 describes the fields in this display.

Table 2: Output for show spantree

Field	Description
VLAN	VLAN number.
Spanning Tree Mode	In the current software version, the mode is always <i>PVST+</i> , which means Per VLAN Spanning Tree+.
Spanning Tree Type	In the current software version, the type is always <i>IEEE</i> , which means STP is based on the IEEE 802 standards.
Spanning Tree Enabled	State of STP on the VLAN.
Designated Root	MAC address of the spanning tree's root bridge.
Designated Root Priority	Bridge priority of the root bridge.
Designated Root Path Cost	Cumulative cost from this bridge to the root bridge. If this WSS is the root bridge, then the root cost is 0.
Designated Root Port	Port through which this WSS reaches the root bridge. If this WSS is the root bridge, this field says <i>We are the root</i> .
Root Max Age	Maximum acceptable age for hello packets on the root bridge.
Root Hello Time	Hello interval on the root bridge.
Root Forward Delay	Forwarding delay value on the root bridge.
Bridge ID MAC ADDR	This WSS's MAC address.
Bridge ID Priority	This WSS's bridge priority.
Bridge Max Age	This WSS's maximum acceptable age for hello packets.
Bridge Hello Time	This WSS's hello interval.
Bridge Forward Delay	This WSS's forwarding delay value.
Port	Port number. Note: Only network ports are listed. STP does not apply to AP ports or wired authentication ports.
Vlan	VLAN ID.

Table 2: Output for show spantree (continued)

Field	Description
STP-State or Port-State	<p>STP state of the port:</p> <ul style="list-style-type: none"> • Blocking—The port is not forwarding Layer 2 traffic but is listening to and forwarding STP control traffic. • Disabled—This state can indicate any of the following conditions: <ul style="list-style-type: none"> • The port is inactive. • The port is disabled. • STP is enabled on the port but the port is not forwarding traffic. (The port is active and enabled but STP has just started to come up.) • Forwarding—The port is forwarding Layer 2 traffic. • Learning—The port is learning the locations of other devices in the spanning tree before changing state to forwarding. • Listening—The port is comparing its own STP information with information in STP control packets received by the port to compute the spanning tree and change state to blocking or forwarding. • STP Off—STP is disabled on the port.
Cost	STP cost of the port.
Prio	STP priority of the port.
Portfast	<p>State of the uplink fast convergence feature:</p> <ul style="list-style-type: none"> • Enabled • Disabled

See Also **show spantree blockedports** on page 404

show spantree backbonefast

Indicates whether the STP backbone fast convergence feature is enabled or disabled.

Syntax `show spantree backbonefast`

Defaults None.

Access All.

Examples The following example shows the command output on a WSS with backbone fast convergence enabled:

WSS# show spantree backbonefast

Backbonefast is enabled

See Also [set spantree backbonefast on page 393](#)

show spantree blockedports

Lists information about WSS ports that STP has blocked on one or all of its VLANs.

Syntax **show spantree blockedports** [**vlan** *vlan-id*]

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, WSS Software displays information for blocked ports on all VLANs.

Defaults None.

Access All.

Usage The command lists information separately for each VLAN.

Examples The following command shows information about blocked ports on a WSS for the *default* VLAN (VLAN 1):

WSS# show spantree blockedports vlan default

Port	Vlan	Port-State	Cost	Prio	Portfast

22	190	Blocking	4	128	Disabled

Number of blocked ports (segments) in VLAN 1 : 1

The port information is the same as the information displayed by the **show spantree** command. See [Table 59 on page 402](#).

See Also [show spantree on page 400](#)

show spantree portfast

Displays STP uplink fast convergence information for all network ports or for one or more network ports.

Syntax `show spantree portfast [port-list]`

port-list List of ports. If you do not specify any ports, WSS Software displays uplink fast convergence information for all ports.

Defaults None.

Access All.

Examples The following command shows uplink fast convergence information for all ports:

WSS# show spantree portfast

Port	Vlan	Portfast
-----	----	-----
1	1	disable
2	1	disable
3	1	disable
4	1	enable
5	1	disable
6	1	disable
7	1	disable
8	1	disable
10	1	disable
15	1	disable
16	1	disable
17	1	disable
18	1	disable
19	1	disable
20	1	disable
21	1	disable
22	1	disable
11	2	enable
12	2	disable
13	2	disable
14	2	enable

[Table 60](#) describes the fields in this display.

Table 3: Output for show spantree portfast

Field	Description
Port	Port number.
VLAN	VLAN number.
Portfast	State of the uplink fast convergence feature: <ul style="list-style-type: none">• Enable• Disable

See Also [set spantree portfast on page 396](#)

show spantree portvlancost

Displays the cost of a port on a path to the STP root bridge, for each of the port's VLANs.

Syntax `show spantree portvlancost port-list`

port-list List of ports.

Defaults None.

Access All.

Examples The following command shows the STP port cost of port 1:

```
WSS# show spantree portvlancost 1
port 1 VLAN 1 have path cost 19
```

See Also

- [clear spantree portcost on page 390](#)
- [clear spantree portvlancost on page 391](#)
- [set spantree portcost on page 395](#)
- [set spantree portvlancost on page 397](#)
- [show spantree on page 400](#)

show spantree statistics

Displays STP statistics for one or more WSS network ports.

Syntax `show spantree statistics [port-list [vlan vlan-id]]`

port-list List of ports. If you do not specify any ports, WSS Software displays STP statistics for all ports.

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, WSS Software displays STP statistics for all VLANs.

Defaults None.

Access All.

Usage The command displays statistics separately for each port.

Examples The following command shows STP statistics for port 1:

WSS# show spantree statistics 1

BPDU related parameters

```

Port 1          VLAN 1
spanning tree enabled for VLAN = 1
port spanning tree    enabled
state                 Forwarding
port_id               0x8015
port_number           0x15
path cost              0x4
message age (port/VLAN) 0(20)
designated_root        00-0b-0e-00-04-30
designated cost        0x0
designated_bridge      00-0b-0e-00-04-30
designated_port        38
top_change_ack        FALSE
config_pending        FALSE
port_inconsistency    none

```

Port based information statistics

```

config BPDU's xmitted(port/VLAN) 0 (1)
config BPDU's received(port/VLAN) 21825 (43649)
tcn BPDU's xmitted(port/VLAN) 0 (0)
tcn BPDU's received(port/VLAN) 2 (2)
forward transition count (port/VLAN) 1 (1)

```

scp failure count	0
root inc trans count (port/VLAN)	1 (1)
inhibit loopguard	FALSE
loop inc trans count	0 (0)

Status of Port Timers

forward delay timer	INACTIVE
forward delay timer value	15
message age timer	ACTIVE
message age timer value	0
topology change timer	INACTIVE
topology change timer value	0
hold timer	INACTIVE
hold timer value	0
delay root port timer	INACTIVE
delay root port timer value	0
delay root port timer restarted is	FALSE

VLAN based information & statistics

spanning tree type	ieee
spanning tree multicast address	1-00-0c-cc-cc-cd
bridge priority	32768
bridge MAC address	00-0b-0e-12-34-56
bridge hello time	2
bridge forward delay	15
topology change initiator:	0
last topology change occurred:	Tue Jul 01 2003 22:33:36.
topology change	FALSE
topology change time	35
topology change detected	FALSE
topology change count	1
topology change last recvd. from	00-0b-0e-02-76-f6

Other port specific info

dynamic max age transition	0
port BPDU ok count	21825
msg age expiry count	0
link loading	0
BPDU in processing	FALSE
num of similar BPDU's to process	0
received_inferior_bpdu	FALSE

```

next state                0
src MAC count             21807
total src MAC count      21825
curr_src_mac              00-0b-0e-00-04-30
next_src_mac              00-0b-0e-02-76-f6

```

Table 61 describes the fields in this display.

Table 4: Output for show spantree statistics

Field	Description
Port	Port number.
VLAN	VLAN ID.
Spanning Tree enabled for vlan	State of the STP feature on the VLAN.
port spanning tree	State of the STP feature on the port.
state	<p>STP state of the port:</p> <ul style="list-style-type: none"> • Blocking—The port is not forwarding Layer 2 traffic but is listening to and forwarding STP control traffic. • Disabled—The port is not forwarding any traffic, including STP control traffic. The port might be administratively disabled or the link might be disconnected. • Forwarding—The port is forwarding Layer 2 traffic. • Learning—The port is learning the locations of other devices in the spanning tree before changing state to forwarding. • Listening—The port is comparing its own STP information with information in STP control packets received by the port to compute the spanning tree and change state to blocking or forwarding.
port_id	STP port ID.
port_number	STP port number.
path cost	Cost to use this port to reach the root bridge. This is part of the total path cost (designated cost).
message age	Age of the protocol information for a port and the value of the maximum age parameter (shown in parenthesis) recorded by the switch.
designated_root	MAC address of the root bridge.

Table 4: Output for show spantree statistics (continued)

Field	Description
designated cost	Total path cost to reach the root bridge.
designated_bridge	Bridge to which this switch forwards traffic away from the root bridge.
designated_port	STP port through which this switch forwards traffic away from the root bridge.
top_change_ack	Value of the topology change acknowledgment flag in the next configured bridge protocol data unit (BPDU) to be transmitted on the associated port. The flag is set in reply to a topology change notification BPDU.
config_pending	Indicates whether a configured BPDU is to be transmitted on expiration of the hold timer for the port.
port_inconsistency	Indicates whether the port is in an inconsistent state.
config BPDU's xmitted	Number of BPDUs transmitted from the port. A number in parentheses indicates the number of configured BPDUs transmitted by the WSS for this VLAN's spanning tree.
config BPDU's received	Number of BPDUs received by this port. A number in parentheses indicates the number of configured BPDUs received by the WSS for this VLAN's spanning tree.
tcn BPDU's xmitted	Number of topology change notification (TCN) BPDUs transmitted on this port.
tcn BPDU's received	Number of TCN BPDUs received on this port.
forward transition count	Number of times the port state transitioned to the forwarding state.
scp failure count	Number of service control point (SCP) failures.
root inc trans count	Number of times the root bridge changed.
inhibit loopguard	State of the loop guard. In the current release, the state is always FALSE.
loop inc trans count	Number of loops that have occurred.
forward delay timer	Status of the forwarding delay timer. This timer monitors the time spent by a port in the listening and learning states.
forward delay timer value	Current value of the forwarding delay timer, in seconds.
message age timer	Status of the message age timer. This timer measures the age of the received protocol information recorded for a port.
message age timer value	Current value of the message age timer, in seconds.
topology change timer	Status of the topology change timer. This timer determines the time period during which configured BPDUs are transmitted with the topology change flag set by this WSS when it is the root bridge, after detection of a topology change.
topology change timer value	Current value of the topology change timer, in seconds.

Table 4: Output for show spantree statistics (continued)

Field	Description
hold timer	Status of the hold timer. This timer ensures that configured BPDUs are not transmitted too frequently through any bridge port.
hold timer value	Current value of the hold timer, in seconds.
delay root port timer	Status of the delay root port timer, which enables fast convergence when uplink fast convergence is enabled.
delay root port timer value	Current value of the delay root port timer.
delay root port timer restarted is	Whether the delay root port timer has been restarted.
spanning tree type	Type of spanning tree. The type is always IEEE.
spanning tree multicast address	Destination address used to send out configured BPDUs on a bridge port.
bridge priority	STP priority of this WSS.
bridge MAC address	MAC address of this WSS.
bridge hello time	Value of the hello timer interval, in seconds, when this WSS is the root or is attempting to become the root.
bridge forward delay	Value of the forwarding delay interval, in seconds, when this WSS is the root or is attempting to become the root.
topology change initiator	Port number that initiated the most recent topology change.
last topology change occurred	System time when the most recent topology change occurred.
topology change	Value of the topology change flag in configuration BPDUs to be transmitted by this WSS on VLANs for which the switch is the designated bridge.
topology change time	Time period, in seconds, during which BPDUs are transmitted with the topology change flag set by this WSS when it is the root bridge, after detection of a topology change. It is equal to the sum of the switch's maximum age and forwarding delay parameters.
topology change detected	Indicates whether a topology change has been detected by the switch.
topology change count	Number of times the topology change has occurred.
topology change last recvd. from	MAC address of the bridge from which the WSS last received a topology change.
dynamic max age transition	Number of times the maximum age parameter was changed dynamically.
port BPDU ok count	Number of valid port BPDUs received.
msg age expiry count	Number of expired messages.
link loading	Indicates whether the link is oversubscribed.
BPDU in processing	Indicates whether BPDUs are currently being processed.

Table 4: Output for show spantree statistics (continued)

Field	Description
num of similar BPDU's to process	Number of similar BPDUs received on a port that need to be processed.
received_inferior_bpdu	Indicates whether the port has received an inferior BPDU or a response to a Root Link Query (RLQ) BPDU.
next state	Port state before it is set by STP.
src MAC count	Number of BPDUs with the same source MAC address.
total src MAC count	Number of BPDUs with all the source MAC addresses.
curr_src_mac	Source MAC address of the current received BPDU.
next_src_mac	Other source MAC address from a different source.

See Also **clear spantree statistics** on page 392

show spantree uplinkfast

Displays uplink fast convergence information for one VLAN or all VLANs.

Syntax `show spantree uplinkfast [vlan vlan-id]`

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, WSS Software displays STP statistics for all VLANs.

Defaults None.

Access All.

Examples The following command shows uplink fast convergence information for all VLANs:

```
WSS# show spantree uplinkfast
```

```
VLAN port list
```

```
-----
1      1      (fwd),2,3
```

[Table 62](#) describes the fields in this display.

Table 5: Output for show spantree uplinkfast

Field	Description
VLAN	VLAN number.
port list	Ports in the uplink group. The port that is forwarding traffic is indicated by <i>fwd</i> . The other ports are blocking traffic.

See Also `set spantree uplinkfast` on page 399

IGMP Snooping Commands

Use Internet Group Management Protocol (IGMP) snooping commands to configure and manage multicast traffic reduction on a WSS. This chapter presents IGMP snooping commands alphabetically. Use the following table to locate commands in this chapter based on their use.

IGMP Snooping State	set igmp on page 416 show igmp on page 423
Proxy Reporting	set igmp proxy-report on page 419
Pseudo-querier	set igmp querier on page 421 show igmp querier on page 427
Timers	set igmp qi on page 420 set igmp oqi on page 418 set igmp qri on page 420 set igmp lmqi on page 416 set igmp rv on page 422
Router Solicitation	set igmp mrsol on page 417 set igmp mrsol mrsi on page 418
Multicast Routers	set igmp mrouter on page 417 show igmp mrouter on page 426
Multicast Receivers	set igmp receiver on page 422 show igmp receiver-table on page 429
Statistics	show igmp statistics on page 431 clear igmp statistics on page 415

clear igmp statistics

Clears IGMP statistics counters on one VLAN or all VLANs on a WSS and resets them to 0.

Syntax `clear igmp statistics [vlan vlan-id]`

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, IGMP statistics are cleared for all VLANs.

Defaults None.

Access Enabled.

Examples The following command clears IGMP statistics for all VLANs:

```
WSS# clear igmp statistics
```

IGMP statistics cleared for all vlans

See Also [show igmp statistics on page 431](#)

set igmp

Disables or reenables IGMP snooping on one VLAN or all VLANs on a WSS.

Syntax `set igmp {enable | disable} [vlan vlan-id]`

enable Enables IGMP snooping.

disable Disables IGMP snooping.

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, IGMP snooping is disabled or reenabled on all VLANs.

Defaults Disabled.

Access Enabled.

Examples The following command disables IGMP snooping on VLAN *orange*:

```
WSS# set igmp disable vlan orange
```

success: change accepted.

See Also [show igmp on page 423](#)

set igmp lmqi

Changes the IGMP last member query interval timer on one VLAN or all VLANs on a WSS.

Syntax `set igmp lmqi tenth-seconds [vlan vlan-id]`

lmqi *tenth-seconds* Amount of time (in tenths of a second) that the WSS waits for a response to a group-specific query after receiving a leave message for that group, before removing the receiver that sent the leave message from the list of receivers for the group. If there are no more receivers for the group, the switch also sends a leave message for the group to multicast routers. You can specify a value from 1 through 65,535.

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, the timer change applies to all VLANs.

Defaults The default last member query interval is 10 tenths of a second (1 second).

Access Enabled.

Examples The following command changes the last member query interval on VLAN *orange* to 5 tenths of a second:

```
WSS# set igmp lmqi 5 vlan orange
success: change accepted.
```

See Also

- [set igmp oqi on page 418](#)
- [set igmp qi on page 420](#)
- [set igmp mrouter on page 417](#)

set igmp mrouter

Adds or removes a port in a WSS's list of ports on which it forwards traffic to multicast routers. Static multicast ports are immediately added to or removed from the list of router ports and do not age out.

Syntax `set igmp mrouter port port-list { enable | disable }`

port <i>port-list</i>	Port list. WSS Software adds or removes the specified ports in the list of static multicast router ports.
enable	Adds the port to the list of static multicast router ports.
disable	Removes the port from the list of static multicast router ports.

Defaults By default, no ports are static multicast router ports.

Access Enabled.

Usage You cannot add AP access ports or wired authentication ports as static multicast ports. However, WSS Software can dynamically add these port types to the list of multicast ports based on multicast traffic.

Examples The following command adds port 9 as a static multicast router port:

```
WSS# set igmp mrouter port 9 enable
success: change accepted.
```

The following command removes port 9 from the static multicast router port list:

```
WSS# set igmp mrouter port 9 disable
success: change accepted.
```

See Also [show igmp mrouter on page 426](#)

set igmp mrsol

Enables or disables multicast router solicitation by a WSS on one VLAN or all VLANs.

Syntax `set igmp mrsol {enable | disable} [vlan vlan-id]`

enable Enables multicast router solicitation.

disable Disables multicast router solicitation.

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, multicast router solicitation is disabled or enabled on all VLANs.

Defaults Multicast router solicitation is disabled on all VLANs by default.

Access Enabled.

Examples The following command enables multicast router solicitation on VLAN *orange*:

```
WSS# set igmp mrsol enable vlan orange
```

success: change accepted.

See Also [set igmp mrsol mrsi on page 418](#)

set igmp mrsol mrsi

Changes the interval between multicast router solicitations by a WSS on one VLAN or all VLANs.

Syntax `set igmp mrsol mrsi seconds [vlan vlan-id]`

seconds Number of seconds between multicast router solicitations. You can specify a value from 1 through 65,535.

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, WSS Software changes the multicast router solicitation interval for all VLANs.

Defaults The interval between multicast router solicitations is 30 seconds by default.

Access Enabled.

Examples The following example changes the multicast router solicitation interval to 60 seconds:

```
WSS# set igmp mrsol mrsi 60
```

success: change accepted.

See Also [set igmp mrsol on page 417](#)

set igmp oqi

Changes the IGMP other-querier-present interval timer on one VLAN or all VLANs on a WSS.

Syntax `set igmp oqi seconds [vlan vlan-id]`

oqi seconds	Number of seconds that the WSS waits for a general query to arrive before electing itself the querier. You can specify a value from 1 through 65,535.
vlan vlan-id	VLAN name or number. If you do not specify a VLAN, the timer change applies to all VLANs.

Defaults The default other-querier-present interval is 255 seconds (4.25 minutes).

Access Enabled.

Usage A WSS cannot become the querier unless the pseudo-querier feature is enabled on the switch. When the feature is enabled, the switch becomes the querier for a subnet so long as the switch does not receive a query message from a router with a lower IP address than the IP address of the switch in that subnet. To enable the pseudo-querier feature, use **set igmp querier**.

Examples The following command changes the other-querier-present interval on VLAN *orange* to 200 seconds:

```
WSS# set igmp oqi 200 vlan orange
success: change accepted.
```

See Also

- **set igmp lmqi** on page 416
- **set igmp qi** on page 420
- **set igmp qri** on page 420
- **set igmp querier** on page 421
- **set igmp mrouter** on page 417
- **set igmp rv** on page 422

set igmp proxy-report

Disables or reenables proxy reporting by a WSS on one VLAN or all VLANs.

Syntax `set igmp proxy-report {enable | disable} [vlan vlan-id]`

enable	Enables proxy reporting.
disable	Disables proxy reporting.
vlan vlan-id	VLAN name or number. If you do not specify a VLAN, proxy reporting is disabled or reenabled on all VLANs.

Defaults Proxy reporting is enabled on all VLANs by default.

Access Enabled.

Usage Proxy reporting reduces multicast overhead by sending only one membership report for a group to the multicast routers and discarding other membership reports for the same group. If you disable proxy reporting, the WSS sends all membership reports to the routers, including multiple reports for the same group.

Examples The following example disables proxy reporting on VLAN *orange*:

```
WSS# set igmp proxy-report disable vlan orange
success: change accepted.
```

See Also [show igmp on page 423](#)

set igmp qi

Changes the IGMP query interval timer on one VLAN or all VLANs on a WSS.

Syntax `set igmp qi seconds [vlan vlan-id]`

qi <i>seconds</i>	Number of seconds that elapse between general queries sent by the WSS when the switch is the querier for the subnet. You can specify a value from 1 through 65,535.
vlan <i>vlan-id</i>	VLAN name or number. If you do not specify a VLAN, the timer change applies to all VLANs.

Defaults The default query interval is 125 seconds.

Access Enabled.

Usage The query interval is applicable only when the WSS is querier for the subnet. For the switch to become the querier, the pseudo-querier feature must be enabled on the switch and the switch must have the lowest IP address among all the devices eligible to become a querier. To enable the pseudo-querier feature, use the `set igmp querier` command.

Examples The following command changes the query interval on VLAN *orange* to 100 seconds:

```
WSS# set igmp qi 100 vlan orange
success: change accepted.
```

See Also

- [set igmp lmqi on page 416](#)
- [set igmp oqi on page 418](#)
- [set igmp qri on page 420](#)
- [set igmp querier on page 421](#)
- [set igmp mrouter on page 417](#)
- [set igmp rv on page 422](#)

set igmp qri

Changes the IGMP query response interval timer on one VLAN or all VLANs on a WSS.

Syntax `set igmp qri tenth-seconds [vlan vlan-id]`

qri <i>tenth-seconds</i>	Amount of time (in tenths of a second) that the WSS waits for a receiver to respond to a group-specific query message before removing the receiver from the receiver list for the group. You can specify a value from 1 through 65,535.
vlan <i>vlan-id</i>	VLAN name or number. If you do not specify a VLAN, the timer change applies to all VLANs.

Defaults The default query response interval is 100 tenths of a second (10 seconds).

Access Enabled.

Usage The query response interval is applicable only when the WSS is querier for the subnet. For the switch to become the querier, the pseudo-querier feature must be enabled on the switch and the switch must have the lowest IP address among all the devices eligible to become a querier. To enable the pseudo-querier feature, use `set igmp querier`.

Examples The following command changes the query response interval on VLAN *orange* to 50 tenths of a second (5 seconds):

```
WSS# set igmp qri 50 vlan orange
success: change accepted.
```

See Also

- `set igmp lmqi` on page 416
- `set igmp oqi` on page 418
- `set igmp qi` on page 420
- `set igmp querier` on page 421
- `set igmp rv` on page 422

set igmp querier

Enables or disables the IGMP pseudo-querier on a WSS, on one VLAN or all VLANs.

Syntax `set igmp querier {enable | disable} [vlan vlan-id]`

enable	Enables the pseudo-querier.
disable	Disables the pseudo-querier.
vlan <i>vlan-id</i>	VLAN name or number. If you do not specify a VLAN, the pseudo-querier is enabled or disabled on all VLANs.

Defaults The pseudo-querier is disabled on all VLANs by default.

Access Enabled.

Usage Nortel recommends that you use the pseudo-querier only when the VLAN contains local multicast traffic sources and no multicast router is servicing the subnet.

Examples The following example enables the pseudo-querier on the *orange* VLAN:

```
WSS# set igmp querier enable vlan orange
success: change accepted.
```

See Also [show igmp querier on page 427](#)

set igmp receiver

Adds or removes a network port in the list of ports on which a WSS forwards traffic to multicast receivers. Static multicast receiver ports are immediately added to or removed from the list of receiver ports and do not age out.

Syntax `set igmp receiver port port-list {enable | disable}`

port <i>port-list</i>	Network port list. WSS Software adds the specified ports to the list of static multicast receiver ports.
enable	Adds the port to the list of static multicast receiver ports.
disable	Removes the port from the list of static multicast receiver ports.

Defaults By default, no ports are static multicast receiver ports.

Access Enabled.

Usage You cannot add AP access ports or wired authentication ports as static multicast ports. However, WSS Software can dynamically add these port types to the list of multicast ports based on multicast traffic.

Examples The following command adds port 7 as a static multicast receiver port:

```
WSS# set igmp receiver port 7 enable
success: change accepted.
```

The following command removes port 7 from the list of static multicast receiver ports:

```
WSS# set igmp receiver port 7 disable
success: change accepted.
```

See Also [show igmp receiver-table on page 429](#)

set igmp rv

Changes the robustness value for one VLAN or all VLANs on a WSS. Robustness adjusts the IGMP timers to the amount of traffic loss that occurs on the network.

Syntax `set igmp rv num [vlan vlan-id]`

num	Robustness value. You can specify a value from 2 through 255. Set the robustness value higher to adjust for more traffic loss.
vlan <i>vlan-id</i>	VLAN name or number. If you do not specify a VLAN, WSS Software changes the robustness value for all VLANs.

Defaults The default robustness value for all VLANs is 2.

Access Enabled.

Examples The following example changes the robustness value on VLAN *orange* to 4:

```
WSS# set igmp rv 4 vlan orange
success: change accepted.
```

See Also

- [set igmp oqi on page 418](#)
- [set igmp qi on page 420](#)
- [set igmp qri on page 420](#)

show igmp

Displays IGMP configuration information and statistics for one VLAN or all VLANs.

Syntax `show igmp [vlan vlan-id]`

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, WSS Software displays IGMP information for all VLANs.

Defaults None.

Access All.

Examples The following command displays IGMP information for VLAN *orange*:

```
WSS# show igmp vlan orange
VLAN: orange
IGMP is enabled
Proxy reporting is on
Mrouter solicitation is on
Querier functionality is off
Configuration values: qi: 125 oqi: 300 qri: 100 lmqi: 10 rvalue: 2 Multicast
router information:
Port Mrouter-IPaddr Mrouter-MAC      Type TTL
-----
10 192.28.7.5 00:01:02:03:04:05 dvmrp 17
Group Port Receiver-IP Receiver-MAC TTL
-----
224.0.0.2 none none none undef
237.255.255.255 5 10.10.10.11 00:02:04:06:08:0b 258
237.255.255.255 5 10.10.10.13 00:02:04:06:08:0d 258
237.255.255.255 5 10.10.10.14 00:02:04:06:08:0e 258
237.255.255.255 5 10.10.10.12 00:02:04:06:08:0c 258
237.255.255.255 5 10.10.10.10 00:02:04:06:08:0a 258
Querier information:
Querier for vlan orange
```

```

Port Querier-IP   Querier-MAC   TTL
-----
 1 193.122.135.178 00:0b:cc:d2:e9:b4 23
IGMP vlan member ports: 10, 12, 11, 14, 16, 15, 13, 18, 17, 1, 20, 21, 2,
22, 19, 4, 6, 5, 3, 8, 7, 9
IGMP static ports: none
IGMP statistics for vlan orange:

IGMP message type   Received Transmitted Dropped
-----
General-Queries      0         0         0
GS-Queries           0         0         0
Report V1            0         0         0
Report V2            5         1         4
Leave                 0         0         0
Mrouter-Adv          0         0         0
Mrouter-Term         0         0         0
Mrouter-Sol          50        101        0
DVMRP                4         4         0
PIM V1               0         0         0
PIM V2               0         0         0
Topology notifications: 0
Packets with unknown IGMP type: 0
Packets with bad length: 0
Packets with bad checksum: 0
Packets dropped: 4

```

Table 63 describes the fields in this display.

Table 1: Output for show igmp

Field	Description
VLAN	VLAN name. WSS Software displays information separately for each VLAN.
IGMP is enabled (disabled)	IGMP state.
Proxy reporting	Proxy reporting state.
Mrouter solicitation	Multicast router solicitation state.
Querier functionality	Pseudo-querier state.
Configuration values (qi)	Query interval.
Configuration values (oqi)	Other-querier-present interval.
Configuration values (qri)	Query response interval.
Configuration values (lmqi)	Last member query interval.
Configuration values (rvalue)	Robustness value.

Table 1: Output for show igmp (continued)

Field	Description
Multicast router information	List of multicast routers and active multicast groups. The fields containing this information are described separately. The show igmp mrouter command shows the same information.
Port	Number of the physical port through which the WSS can reach the router.
Mrouter-IPaddr	IP address of the multicast router interface.
Mrouter-MAC	MAC address of the multicast router interface.
Type	How the WSS learned that the port is a multicast router port: <ul style="list-style-type: none"> • conf — Static multicast port configured by an administrator • madv—Multicast advertisement • quer—IGMP query • dvmrp—Distance Vector Multicast Routing Protocol (DVMRP) • pimv1—Protocol Independent Multicast (PIM) version 1 • pimv2—PIM version 2
TTL	Number of seconds before this entry ages out if not refreshed. For static multicast router entries, the time-to-live (TTL) value is <i>undef</i> . Static multicast router entries do not age out.
Group	IP address of a multicast group. The show igmp receiver-table command shows the same information as these receiver fields.
Port	Physical port through which the WSS can reach the group's receiver.
Receiver-IP	IP address of the client receiving the group.
Receiver-MAC	MAC address of the client receiving the group.
TTL	Number of seconds before this entry ages out if the WSS does not receive a group membership message from the receiver. For static multicast receiver entries, the TTL value is <i>undef</i> . Static multicast receiver entries do not age out.
Querier information	Information about the subnet's multicast querier. If the querier is another device, the fields described below are applicable. If the querier is the WSS itself, the output indicates how many seconds remain until the next general query message. If IGMP snooping does not detect a querier, the output indicates this. The show igmp querier command shows the same information.
Querier for vlan	VLAN containing the querier. Information is listed separately for each VLAN.
Querier-IP	IP address of the querier.
Querier-MAC	MAC address of the querier.

Table 1: Output for show igmp (continued)

Field	Description
TTL	Number of seconds before this entry ages out if the WSS does not receive a query message from the querier.
IGMP vlan member ports	Physical ports in the VLAN. This list includes all network ports configured to be in the VLAN and all ports WSS Software dynamically assigns to the VLAN when a user assigned to the VLAN becomes a receiver. For example, the list can include an AP access port that is not configured to be in the VLAN when a user associated with the AP on that port becomes a receiver for a group. When all receivers on a dynamically added port age out, WSS Software removes the port from the list.
IGMP static ports	Static receiver ports.
IGMP statistics	Multicast message and packet statistics. These are the same statistics displayed by the show igmp statistics command.

See Also

- **show igmp mrouter** on page 426
- **show igmp querier** on page 427
- **show igmp receiver-table** on page 429
- **show igmp statistics** on page 431

show igmp mrouter

Displays the multicast routers in a WSS's subnet, on one VLAN or all VLANs. Routers are listed separately for each VLAN, according to the port number through which the switch can reach the router.

Syntax **show igmp mrouter** [**vlan** *vlan-id*]

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, WSS Software displays the multicast routers in all VLANs.

Defaults None.

Access All.

Examples The following command displays the multicast routers in VLAN *orange*:

```

WSS# show igmp mrouter vlan orange
Multicast routers for vlan orange
Port  Mrouter-IPaddr  Mrouter-MAC    Type  TTL
-----
10    192.28.7.5       00:01:02:03:04:05  dvmrp  33

```

[Table 64](#) describes the fields in this display.

Table 2: Output for show igmp mrouter

Field	Description
Multicast routers for vlan	VLAN containing the multicast routers. Ports are listed separately for each VLAN.
Port	Number of the physical port through which the WSS can reach the router.
Mrouter-IPaddr	IP address of the multicast router.
Mrouter-MAC	MAC address of the multicast router.
Type	How the WSS learned that the port is a multicast router port: <ul style="list-style-type: none"> • conf — Static multicast port configured by an administrator • madv—Multicast advertisement • quer—IGMP query • dvmrp—Distance Vector Multicast Routing Protocol (DVMRP) • pimv1—Protocol Independent Multicast (PIM) version 1 • pimv2—PIM version 2
TTL	Number of seconds before this entry ages out if unused. For static multicast router entries, the TTL value is <i>undef</i> . Static multicast router entries do not age out.

See Also

- **set igmp mrouter** on page 417
- **show igmp mrouter** on page 426

show igmp querier

Displays information about the active multicast querier, on one VLAN or all VLANs. Queriers are listed separately for each VLAN. Each VLAN can have only one querier.

Syntax **show igmp querier** [**vlan** *vlan-id*]

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, WSS Software displays querier information for all VLANs.

Defaults None.

Access Enabled.

Examples The following command displays querier information for VLAN *orange*:

```
WSS# show igmp querier vlan orange
Querier for vlan orange
```

Port	Querier-IP	Querier-MAC	TTL
1	193.122.135.178	00:0b:cc:d2:e9:b4	23

The following command shows the information WSS Software displays when the querier is the WSS itself:

```
WSS# show igmp querier vlan default
```

```
Querier for vlan default:
```

```
I am the querier for vlan default, time to next query is 20
```

The output indicates how many seconds remain before the pseudo-querier on the switch broadcasts the next general query report to IP address 224.0.0.1, the multicast all-systems group.

If IGMP snooping does not detect a querier, the output indicates this finding, as shown in the following example:

```
WSS# show igmp querier vlan red
```

```
Querier for vlan red:
```

```
There is no querier present on vlan red
```

This condition does not necessarily indicate a problem. For example, election of the querier might be in progress.

[Table 65 on page 429](#) describes the fields in the display when a querier other than the WSS is present.

Table 3: Output for show igmp querier

Field	Description
Querier for vlan	VLAN containing the querier. Information is listed separately for each VLAN.
Querier-IP	IP address of the querier interface.
Querier-MAC	MAC address of the querier interface.
TTL	Number of seconds before this entry ages out if the WSS does not receive a query message from the querier.

See Also [set igmp querier on page 421](#)

show igmp receiver-table

Displays the receivers to which a WSS forwards multicast traffic. You can display receivers for all VLANs, a single VLAN, or a group or groups identified by group address and network mask.

Syntax `show igmp receiver-table [vlan vlan-id] [group group-ip-addr/mask-length]`

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, WSS Software displays the multicast receivers on all VLANs.

group *group-ip-addr/mask-length* IP address and subnet mask of a multicast group, in CIDR format (for example, 239.20.20.10/24). If you do not specify a group address, WSS Software displays the multicast receivers for all groups.

Defaults None.

Access All.

Examples The following command displays all multicast receivers in VLAN *orange*:

WSS# show igmp receiver-table vlan orange

VLAN: orange

Session	Port	Receiver-IP	Receiver-MAC	TTL
224.0.0.2	none	none	undef	
237.255.255.255	5	10.10.10.11	00:02:04:06:08:0b	179
237.255.255.255	5	10.10.10.13	00:02:04:06:08:0d	179
237.255.255.255	5	10.10.10.14	00:02:04:06:08:0e	179
237.255.255.255	5	10.10.10.12	00:02:04:06:08:0c	179
237.255.255.255	5	10.10.10.10	00:02:04:06:08:0a	179

The following command lists all receivers for multicast groups 237.255.255.1 through 237.255.255.255, in all VLANs:

WSS# show igmp receiver-table group 237.255.255.0/24

VLAN: red

Session	Port	Receiver-IP	Receiver-MAC	TTL
237.255.255.2	2	10.10.20.19	00:02:04:06:09:0d	112
237.255.255.119	3	10.10.30.31	00:02:04:06:01:0b	112

VLAN: green

Session	Port	Receiver-IP	Receiver-MAC	TTL
237.255.255.17	11	10.10.40.41	00:02:06:08:02:0c	12
237.255.255.255	6	10.10.60.61	00:05:09:0c:0a:01	111

[Table 66](#) describes the fields in this display.

Table 4: Output for show igmp receiver-table

Field	Description
VLAN	VLAN that contains the multicast receiver ports. Ports are listed separately for each VLAN.
Session	IP address of the multicast group being received.
Port	Physical port through which the WSS can reach the receiver.
Receiver-IP	IP address of the receiver.
Receiver-MAC	MAC address of the receiver.
TTL	Number of seconds before this entry ages out if the WSS does not receive a group membership message from the receiver. For static multicast receiver entries, the TTL value is <i>undef</i> . Static multicast receiver entries do not age out.

See Also [set igmp receiver on page 422](#)

show igmp statistics

Displays IGMP statistics.

Syntax `show igmp statistics [vlan vlan-id]`

vlan *vlan-id* VLAN name or number. If you do not specify a VLAN, WSS Software displays IGMP statistics for all VLANs.

Defaults None.

Access All.

Examples The following command displays IGMP statistics for VLAN *orange*:

WSS# show igmp statistics vlan orange

IGMP statistics for vlan orange:

IGMP message type Received Transmitted Dropped

```
-----
General-Queries      0      0      0
GS-Queries           0      0      0
Report V1            0      0      0
Report V2            5      1      4
Leave                 0      0      0
Mrouter-Adv          0      0      0
Mrouter-Term         0      0      0
Mrouter-Sol          50     101     0
```

```

DVMRP          4      4      0
PIM V1         0      0      0
PIM V2         0      0      0
Topology notifications: 0
Packets with unknown IGMP type: 0
Packets with bad length: 0
Packets with bad checksum: 0
Packets dropped: 4

```

Table 67 describes the fields in this display.

Table 5: Output for show igmp statistics

Field	Description
IGMP statistics for vlan	VLAN name. Statistics are listed separately for each VLAN.
IGMP message type	Type of IGMP message: <ul style="list-style-type: none"> • General-Queries—General group membership queries sent by the multicast querier (multicast router or pseudo-querier). • GS-Queries—Group-specific queries sent by the the multicast querier to determine whether there are receivers for a specific group. • Report V1—IGMP version 1 group membership reports sent by clients who want to be receivers for the groups. • Report V2—IGMP version 2 group membership reports sent by clients who want to be receivers for the groups. • Leave—IGMP version 2 leave messages sent by clients who want to stop receiving traffic for a group. Leave messages apply only to IGMP version 2. • Mrouter-Adv—Multicast router advertisement packets. A multicast router sends this type of packet to advertise the IP address of the sending interface as a multicast router interface.

Table 5: Output for show igmp statistics (continued)

Field	Description
IGMP message type	Type of IGMP message, continued: <ul style="list-style-type: none"> • Mrouter-Term—Multicast router termination messages. A multicast router sends this type of message when multicast forwarding is disabled on the router interface, the router interface is administratively disabled, or the router itself is gracefully shutdown. • Mrouter-Sol—Multicast router solicitation messages. A multicast client or a WSS sends this type of message to immediately solicit multicast router advertisement messages from the multicast routers in the subnet. • DVMRP—Distance Vector Multicast Routing Protocol (DVMRP) messages. Multicast routers running DVMRP exchange multicast information with these messages. • PIM V1—Protocol Independent Multicast (PIM) version 1 messages. Multicast routers running PIMv1 exchange multicast information with these messages. • PIM V2—PIM version 2 messages.
Received	Number of packets received.
Transmitted	Number of packets transmitted. This number includes both multicast packets originated by the WSS and multicast packets received and then forwarded by the switch.
Dropped	Number of IGMP packets dropped by the WSS.
Topology notifications	Number of Layer 2 topology change notifications received by the WSS. Note: In the current software version, the value in this field is always 0.
Packets with unknown IGMP type	Number of multicast packets received with an unrecognized multicast type.
Packets with bad length	Number of packets with an invalid length.
Packets with bad IGMP checksum	Number of packets with an invalid IGMP checksum value.
Packets dropped	Number of multicast packets dropped by the WSS.

See Also `clear igmp statistics` on page 415

Session Management Commands

Use session management commands to display and clear administrative and network user sessions. This chapter presents session management commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Administrative Sessions	show sessions on page 437 clear sessions on page 435
Network Sessions	show sessions network on page 439 clear sessions network on page 436

clear sessions

Clears all administrative sessions, or clears administrative console or Telnet sessions.

Syntax `clear sessions {admin | console | telnet [client [session-id]]}`

admin	Clears sessions for all users with administrative access to the WSS through a Telnet or SSH connection or a console plugged into the switch.
console	Clears sessions for all users with administrative access to the WSS through a console plugged into the switch.
telnet	Clears sessions for all users with administrative access to the WSS through a Telnet connection.
telnet client [session-id]	Clears all Telnet client sessions from the CLI to remote devices, or clears an individual session identified by session ID.

Defaults None.

Access Enabled.

Examples To clear all administrator sessions type the following command:

WSS# clear sessions admin

This will terminate manager sessions, do you wish to continue? (y/n) [n]y

To clear all administrative sessions through the console, type the following command:

WSS# clear sessions console

This will terminate manager sessions, do you wish to continue? (y/n) [n]y

To clear all administrative Telnet sessions, type the following command:

WSS# clear sessions telnet

This will terminate manager sessions, do you wish to continue? (y/n) [n]y

To clear Telnet client session 0, type the following command:

```
WSS# clear sessions telnet client 0
```

See Also [show sessions on page 437](#)

clear sessions network

Clears all network sessions for a specified username or set of usernames, MAC address or set of MAC addresses, virtual LAN (VLAN) or set of VLANs, or session ID.

```
Syntax clear sessions network {user user-wildcard | mac-addr mac-addr-wildcard | vlan vlan-wildcard | session-id local-session-id}
```

user <i>user-wildcard</i>	Clears all network sessions for a single user or set of users. Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character—either an <i>at</i> sign (@) or a period (.). (For details, see “User Wildcards” on page 12.)
mac-addr <i>mac-addr-wildcard</i>	Clears all network sessions for a MAC address. Specify a MAC address in hexadecimal numbers separated by colons (:), or use the wildcard character (*) to specify a set of MAC addresses. (For details, see “MAC Address Wildcards” on page 13.)
vlan <i>vlan-wildcard</i>	Clears all network sessions on a single VLAN or a set of VLANs. Specify a VLAN name, use the double-asterisk wildcard character (**) to specify all VLAN names, or use the single-asterisk wildcard character (*) to specify a set of VLAN names up to or following the first delimiter character, either an <i>at</i> sign (@) or a period (.). (For details, see “VLAN Wildcards” on page 13.)
session-id <i>local-session-id</i>	Clears the specified 802.1X network session. To find local session IDs, use the show sessions command.

Defaults None.

Access Enabled.

Usage The **clear sessions network** command clears network sessions by deauthenticating and, for wireless clients, disassociating them.

Examples To clear all sessions for MAC address 00:01:02:03:04:05, type the following command:

```
WSS# clear sessions network mac-addr 00:01:02:03:04:05
```

To clear session 9, type the following command:

```
23x0# clear sessions network session-id 9
```

```
SM Apr 11 19:53:38 DEBUG SM-STATE: localid 9, mac 00:06:25:09:39:5d,
```

```
flags 0000012fh, to change state to KILLING
```

```
Localid 9, globalid SESSION-9-893249336 moved from ACTIVE to KILLING
```

```
(client=00:06:25:09:39:5d)
```

To clear the session of user *Natasha*, type the following command:

```
23x0# clear sessions network user Natasha
```

To clear the sessions of users whose name begins with the characters *Jo*, type the following command:

```
23x0# clear sessions network user Jo*
```

To clear the sessions of all users on VLAN *red*, type the following command:

```
23x0# clear sessions network vlan red
```

See Also

- [show sessions on page 437](#)
- [show sessions network on page 439](#)

show sessions

Displays session information and statistics for all users with administrative access to the WSS, or for administrative users with either console or Telnet access.

Syntax `show sessions { admin | console | telnet [client] }`

admin	Displays sessions for all users with administrative access to the WSS through a Telnet or SSH connection or a console plugged into the switch.
console	Displays sessions for all users with administrative access to the WSS through a console plugged into the switch.
telnet	Displays sessions for all users with administrative access to the WSS through a Telnet connection.
telnet client	Displays Telnet sessions from the CLI to remote devices.

Defaults None.

Access All, except for `show sessions telnet client`, which has enabled access.

Examples To view information about sessions of administrative users, type the following command:

```
WSS> show sessions admin
```

Tty	Username	Time (s)	Type
-----	-----	-----	----
tty0		3644	Console
tty2	tech	6	Telnet
tty3	sshadmin	381	SSH

```
3 admin sessions
```

To view information about console users' sessions, type the following command:

```
WSS> show sessions console
Tty      Username      Time (s)
-----  -
console                8573
```

1 console session

To view information about Telnet users sessions, type the following command:

```
WSS> show sessions telnet
Tty      Username      Time (s)
-----  -
tty2     sea           7395
```

To view information about Telnet client sessions, type the following command:

```
WSS# show sessions telnet client
Session  Server Address  Server Port  Client Port
-----  -
0        192.168.1.81   23           48000
1        10.10.1.22     23           48001
```

[Table 68](#) describes the fields of the **show sessions admin**, **show sessions console**, and **show sessions telnet** displays.

[Table 69](#) describes the fields of the **show sessions telnet client** display.

Table 1: show sessions admin, show sessions console, and show sessions telnet Output

Field	Description
Tty	The Telnet terminal number, or <i>console</i> for administrative users connected through the console port.
Username	Up to 30 characters of the name of an authenticated user.
Time (s)	Number of seconds the session has been active.
Type	Type of administrative session: <ul style="list-style-type: none">• Console• SSH• Telnet

Table 2: show sessions telnet client Output

Field	Description
Session	Session number assigned by WSS Software when the client session is established.
Server Address	IP address of the remote device.
Server Port	TCP port number of the remote device's TCP server.
Client Port	TCP port number WSS Software is using for the client side of the session.

See Also [clear sessions on page 435](#)

show sessions network

Displays summary or verbose information about all network sessions, or network sessions for a specified username or set of usernames, MAC address or set of MAC addresses, VLAN or set of VLANs, or session ID.

Syntax `show sessions network [user user-wildcard | mac-addr mac-addr-wildcard | ssid ssid-name | vlan vlan-wildcard | session-id session-id | wired] [verbose]`

user <i>user-wildcard</i>	Displays all network sessions for a single user or set of users. Specify a username, use the double-asterisk wildcard character (**) to specify all usernames, or use the single-asterisk wildcard character (*) to specify a set of usernames up to or following the first delimiter character—either an <i>at</i> sign (@) or a period (.). (For details, see “User Wildcards” on page 12.)
mac-addr <i>mac-addr-wildcard</i>	Displays all network sessions for a MAC address. Specify a MAC address in hexadecimal numbers separated by colons (:). Or use the wildcard character (*) to specify a set of MAC addresses. (For details, see “MAC Address Wildcards” on page 13.)
ssid <i>ssid-name</i>	Displays all network sessions for an SSID.
vlan <i>vlan-wildcard</i>	Displays all network sessions on a single VLAN or a set of VLANs. Specify a VLAN name, use the double-asterisk wildcard character (**) to specify all VLAN names, or use the single-asterisk wildcard character (*) to specify a set of VLAN names up to or following the first delimiter character, either an <i>at</i> sign (@) or a period (.). (For details, see “VLAN Wildcards” on page 13.)
session-id <i>local-session-id</i>	Displays the specified network session. To find local session IDs, use the show sessions command. The verbose option is not available with this form of the show sessions network command.
wired	Displays all network sessions on wired authentication ports.
verbose	Provides detailed output for all network sessions or ones displayed by username, MAC address, or VLAN name.

Defaults None.

Access All.

History

- Version 4.1 Output added to the **show network sessions verbose** command to indicate the user's authorization attributes and whether they were supplied through AAA or through configured SSID defaults in a service profile.
- Version 5.0
- Host name field added to **show sessions network verbose** output.
 - AP serial number added to **show sessions network verbose** output.
 - The following fields added to **show sessions network session-id** output:
 - Local Id
 - SSID
 - Last Auth Time
 - Last Activity
 - Idle Time-To-Live
 - Login Type
 - Protocol
 - Session CAC
 - Authentication Method field renamed to EAP Method.
 - New values for the source of user attribute values (attributes include Vlan-Name, Start-Date, and so on.) See [Table 71 on page 443](#).

Usage WSS Software displays information about network sessions in three types of displays. See the following tables for field descriptions.

Summary display	See Table 70 on page 442 .
Verbose display	See Table 71 on page 443 .
show sessions network session-id display	See Table 72 on page 445 .

Authorization attribute values can be changed during authorization. If the values are changed, **show sessions** output shows the values that are actually in effect following any changes.

Examples To display summary information for all network sessions, type **show sessions network**. For example:

WSS> show sessions network

User Name	Sess ID	IP or MAC Address	VLAN Name	Port/ Radio
EXAMPLE\Natasha	4*	10.10.40.17	vlan-eng	3/1
host/laptop11.exmpl.com	6*	10.10.40.16	vlan-eng	3/2
nin@exmpl.com	539*	10.10.40.17	vlan-eng	1/1
EXAMPLE\hosni	302*	10.10.40.10	vlan-eng	3/1
	563	00:0b:be:15:46:56	(none)	1/2
jose@exmpl.com	380*	10.30.40.8	vlan-eng	1/1
00:30:65:16:8d:69	443*	10.10.40.19	vlan-wep	3/1
EXAMPLE\Geetha	459*	10.10.40.18	vlan-eng	3/2

8 sessions total

The following command displays summary information about the sessions for MAC address 00:05:5d:7e:98:1a:

WSS> show sessions network mac-addr 00:05:5d:7e:98:1a

User Name	Sess ID	IP or MAC Address	VLAN Name	Port/ Radio
EXAMPLE\Havel	13*	10.10.10.40	vlan-eng	1/2

The following command displays summary information about all the sessions of users whose names begin with E:

WSS> show sessions network user E*

User Name	Sess ID	IP or MAC Address	VLAN Name	Port/ Radio
EXAMPLE\Singh	12*	10.10.10.30	vlan-eng	3/2
EXAMPLE\Havel	13*	10.10.10.40	vlan-eng	1/2

2 sessions match criteria (of 3 total)

(Table 70 on page 442 describes the summary displays of **show sessions network** commands.)

The following command displays verbose output about the sessions of all current network users:

WSS> show sessions network verbose

User Name	Sess ID	IP or MAC Address	VLAN Name	Port/ Radio
SHUTTLE2\exmpl	3*	10.8.255.8	default	7/1

Client MAC: 00:0b:7d:26:b1:fb
 State: ACTIVE (prev AUTHORIZED)
 now on: **WSS** 172.16.0.1, port 10, AP/radio 0422900147/1, as of 00:00:22 ago
 from: **WSS** 172.16.0.1, port 6, AP/radio 0342900121/1, as of 00:01:07 ago
 from: **WSS** 172.16.0.1, port 2, AP/radio 0412900109/1, as of 00:01:53 ago

Host name: shuttle2_laptop
 Vlan-Name=default (service-profile)
 Service-Type=2 (service-profile)
 End-Date=52/06/07-08:57 (AAA)
 Start-Date=05/04/11-10:00 (AAA)

1 sessions total

(Table 71 on page 443 describes the additional fields of the **verbose** output of **show sessions network** commands.)

The following command displays information about network session 88:

```

WSS# show sessions network session-id 88
Local Id:          88
Global Id:        SESS-88-00040f-876766-623fd6
State:           ACTIVE
SSID:           Rack-39-PM
Port/Radio:     10/1
MAC Address:    00:0f:66:f4:71:6d
User Name:     last-resort-Rack-39-PM
IP Address:    10.2.39.217
Vlan Name:     default
Tag:           1
Session Start:  Wed Apr 12 21:19:27 2006 GMT
Last Auth Time: Wed Apr 12 21:19:26 2006 GMT
Last Activity:  Wed Apr 12 21:19:49 2006 GMT (<15s ago)
Session Timeout: 0
Idle Time-To-Live: 175
Login Type:    LAST-RESORT
EAP Method:   NONE, using server 172.16.0.1
Session statistics as updated from AP:
Unicast packets in: 31
Unicast bytes in: 3418
Unicast packets out: 18
Unicast bytes out: 2627
Multicast packets in: 0
Multicast bytes in: 0
Number of packets with encryption errors: 0
Number of bytes with encryption errors: 0
Last packet data rate: 48
Last packet signal strength: -60 dBm
Last packet data S/N ratio: 35
Protocol:      802.11
Session CAC:   disabled

```

For descriptions of the fields of **show sessions network session-id** output, see [Table 72 on page 445](#).

Table 3: show sessions network (summary) Output

Field	Description
User Name	Up to 30 characters of the name of the authenticated user of this session. Note: For a MAC-authenticated session, this value is the client device's MAC address.
Sess ID	Locally unique number that identifies this session. An asterisk (*) next to a session ID indicates that the session is fully active.

Table 3: show sessions network (summary) Output (continued)

Field	Description
IP or MAC Address	IP address of the session user, or the user's MAC address if the user has not yet received an IP address.
VLAN Name	Name of the VLAN associated with the session.
Port/Radio	Number of the port and radio through which the user is accessing this session.

Table 4: Additional show sessions network verbose Output

Field	Description
Client MAC	MAC address of the session user.
GID	Global session ID, a unique session number within a Mobility Domain.
State	<p>Status of the session:</p> <ul style="list-style-type: none"> • AUTH, ASSOC REQ—Client is being associated by the 802.1X protocol. • AUTH AND ASSOC—Client is being associated by the 802.1X protocol, and the user is being authenticated. • AUTHORIZING—User has been authenticated (for example, by the 802.1X protocol and an AAA method), and is entering AAA authorization. • AUTHORIZED—User has been authorized by an AAA method. • ACTIVE—User's AAA attributes have been applied, and the user is active on the network. • DEASSOCIATED—One of the following: <ul style="list-style-type: none"> • Wireless client has sent the WSS a disassociate message. • User associated with one of the current WSS's APs has appeared at another WSS in the Mobility Domain. • ROAMING AWAY—The WSS has been sent a request to transfer the user, who is roaming, to another WSS. • STATUS UPDATED—WSS is receiving a final update from an AP about the user, who has roamed away. • WEB_AUTHING—User is being authenticated by Web-based AAA. • WIRED AUTH'ING—User is being authenticated by the 802.1X protocol on a wired authentication port. • KILLING—User's session is being cleared, because of 802.1X authentication failure, entry of a clear command, or some other event.

**Table 4: Additional show sessions network verbose
Output (continued)**

Field	Description
now on	Shows the following information about the AP and radio the session is currently on: <ul style="list-style-type: none"> • IP address and port number of the WSS managing the AP • Serial number and radio number of the AP • Amount of time the session has been on this AP
from	Shows information about the APs from which the session has roamed. (See the descriptions above for the <i>now on</i> field.)
Host name	Host name of the user's networking device.
Vlan-Name (and other attributes if set)	<p>Authorization attributes for the user and how they were assigned (the sources of the attribute values).</p> <p>For Vlan-Name, the source of the attribute value can be one of the following:</p> <ul style="list-style-type: none"> • AAA—VLAN is from RADIUS or the local database. • initial-assignment—For a client that has roamed from one WSS to another, VLAN is the one assigned to the user on the WSS where the user first accessed the network. (This is the WSS where the client's global session in the Mobility Domain started.) <p>This authorization source (<i>initial-assignment</i>) is displayed only if the following conditions are true:</p> <ul style="list-style-type: none"> • The client roamed from another WSS. • The service profile for the SSID the user is on is configured to keep the client's initial VLAN assignment. (This means the keep-initial-vlan option is enabled on the service profile.) • The VLAN is not configured for the user on the roamed-to switch by the local database. • A Location Policy on the roamed-to WSS does not set the VLAN. • location policy—Attribute value was assigned by a Location Policy. • service-profile—Attribute value is configured on the SSID, and was not overridden by other attribute sources (such as AAA or location policy). • Web Portal—Session is for a Web Portal client.

Table 5: show sessions network session-id Output

Field	Description
Local Id	Identifier for the session on this particular switch. (This is the session ID you specify when entering the show sessions network session-id command.)
Global Id	Unique session identifier within the Mobility Domain.
State	Status of the session: <ul style="list-style-type: none"> • AUTH, ASSOC REQ—Client is being associated by the 802.1X protocol. • AUTH AND ASSOC—Client is being associated by the 802.1X protocol, and the user is being authenticated. • AUTHORIZING—User has been authenticated (for example, by the 802.1X protocol and an AAA method), and is entering AAA authorization. • AUTHORIZED—User has been authorized by an AAA method. • ACTIVE—User’s AAA attributes have been applied, and the user is active on the network.
State, cont.	<ul style="list-style-type: none"> • DEASSOCIATED—One of the following: <ul style="list-style-type: none"> • Wireless client has sent the WSS a disassociate message. • User associated with one of the current WSS’s APs has appeared at another WSS in the Mobility Domain. • ROAMING AWAY—The WSS has been sent a request to transfer the user, who is roaming, to another WSS. • STATUS UPDATED—WSS is receiving a final update from an AP about the user, who has roamed away. • WEB_AUTHING—User is being authenticated by Web-based AAA. • WIRED AUTH’ING—User is being authenticated by the 802.1X protocol on a wired authentication port. • KILLING—User’s session is being cleared, because of 802.1X authentication failure, entry of a clear command, or some other event.
SSID	Name of the SSID the user is on.
Port/Radio	Number of the port and radio through which the user is accessing this session.
MAC address	MAC address of the session user.
User Name	Name of the authenticated user of this session
IP Address	IP address of the session user.
Vlan Name	Name of the VLAN associated with the session.

Table 5: show sessions network session-id Output (continued)

Field	Description
Tag	System-wide supported VLAN tag type.
Session Start	Indicates when the session started.
Last Auth Time	Indicates when the most recent authentication of the session occurred.
Last Activity	Indicates when the last activity (transmission) occurred on the session.
Session Timeout	Assigned session timeout in seconds.
Idle Time-To-Live	Number of seconds the session can remain idle before WSS Software changes the session state to Disassociated.
Login Type	Authentication type used to log onto the network: <ul style="list-style-type: none"> • DOT1X • MAC • LAST-RESORT • WEB-PORTAL
EAP Method	Extensible Authentication Protocol (EAP) type used to authenticate the session user, and the IP address of the authentication server.
Session statistics as updated from AP	Time the session statistics were last updated from the AP, in seconds since a fixed standard date and time.
Unicast packets in	Total number of unicast packets received from the user by the WSS (64-bit counter).
Unicast bytes in	Total number of unicast bytes received from the user by the WSS (64-bit counter).
Unicast packets out	Total number of unicast packets sent by the WSS to the user (64-bit counter).
Unicast bytes out	Total number of unicast bytes sent by the WSS to the user (64-bit counter).
Multicast packets in	Total number of multicast packets received from the user by the WSS (64-bit counter).
Multicast bytes in	Total number of multicast bytes received from the user by the WSS (64-bit counter).
Number of packets with encryption errors	Total number of decryption failures.
Number of bytes with encryption errors	Total number of bytes with decryption errors.
Last packet data rate	Data transmit rate, in megabits per second (Mbps), of the last packet received by the AP.
Last packet signal strength	Signal strength, in decibels referred to 1 milliwatt (dBm), of the last packet received by the AP.
Last packet data S/N ratio	Signal-to-noise ratio of the last packet received by the AP.
Protocol	Wireless protocol used.
Session CAC	State of session-based Call Admission Control (CAC) on the SSID's service profile.

See Also `clear sessions network` on page 436

Security ACL Commands

Use security ACL commands to configure and monitor security access control lists (ACLs). Security ACLs filter packets to restrict or permit network usage by certain users or traffic types, and can assign to packets a class of service (CoS) to define the priority of treatment for packet filtering.

(Security ACLs are different from the location policy on a WSS, which helps you locally control user access. For location policy commands, see [Chapter , “AAA Commands,” on page 165.](#))

This chapter presents security ACL commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Create Security ACLs	set security acl on page 454
	show security acl editbuffer on page 462
	show security acl info on page 463
	show security acl on page 461
	clear security acl on page 449
Commit Security ACLs	commit security acl on page 452
	rollback security acl on page 453
Map Security ACLs	set security acl map on page 459
	show security acl map on page 464
	clear security acl map on page 451
Monitor Security ACLs	show security acl hits on page 462
	set security acl hit-sample-rate on page 460
	show security acl resource-usage on page 465

clear security acl

Clears a specified security ACL, an access control entry (ACE), or all security ACLs, from the edit buffer. When used with the command **commit security acl**, clears the ACE from the running configuration.

Syntax **clear security acl** { *acl-name* | **all** } [*editbuffer-index*]

<i>acl-name</i>	Name of an existing security ACL to clear. ACL names start with a letter and are case-insensitive.
all	Clears all security ACLs.
<i>editbuffer-index</i>	Number that indicates which access control entry (ACE) in the security ACL to clear. If you do not specify an ACE, all ACEs are cleared from the ACL.

Defaults None.

Access Enabled.

Usage This command deletes security ACLs only in the edit buffer. You must use the **commit security acl** command with this command to delete the ACL or ACE from the running configuration and nonvolatile storage.

The **clear security acl** command deletes a security ACL, but does not stop its current filtering function if the ACL is mapped to any virtual LANs (VLANs), ports, or virtual ports, or if the ACL is applied in a Filter-Id attribute to an authenticated user or group of users with current sessions.

Examples The following commands display the current security ACL configuration, clear *acl_133* in the edit buffer, commit the deletion to the running configuration, and redisplay the ACL configuration to show that it no longer contains *acl_133*:

```
WSS# show security acl info all
```

```
ACL information for all
```

```
set security acl ip acl_133 (hits #1 0)
```

```
-----  
1. deny IP source IP 192.168.1.6 0.0.0.0 destination IP any
```

```
set security acl ip acl_134 (hits #3 0)
```

```
-----  
1. permit IP source IP 192.168.0.1 0.0.0.0 destination IP any enable-hits
```

```
set security acl ip acl_135 (hits #2 0)
```

```
-----  
1. deny IP source IP 192.168.1.1 0.0.0.0 destination IP any enable-hits
```

```
WSS# clear security acl acl_133
```

```
WSS# commit security acl acl_133
```

```
configuration accepted
```

```
WSS# show security acl info all
```

```
ACL information for all
```

```
set security acl ip acl_134 (hits #3 0)
```

```
-----  
1. permit IP source IP 192.168.0.1 0.0.0.0 destination IP any enable-hits
```

```
set security acl ip acl_135 (hits #2 0)
```

```
-----  
1. deny IP source IP 192.168.1.1 0.0.0.0 destination IP any enable-hits
```

See Also

- **clear security acl map on page 451**
- **commit security acl on page 452**
- **set security acl on page 454**
- **show security acl info on page 463**

clear security acl map

Deletes the mapping between a security ACL and a virtual LAN (VLAN), one or more physical ports, or a virtual port. Or deletes all ACL maps to VLANs, ports, and virtual ports on a WSS.



Note. Security ACLs are applied to users or groups dynamically via the Filter-Id attribute. To delete a security ACL from a user or group in the local WSS database, use the command **clear user attr**, **clear mac-user attr**, **clear usergroup attr**, or **clear mac-usergroup attr**. To delete a security ACL from a user or group on an external RADIUS server, see the documentation for your RADIUS server.

Syntax `clear security acl map {acl-name | all} {vlan vlan-id | port port-list [tag tag-value] | ap ap-num} {in | out}`

<i>acl-name</i>	Name of an existing security ACL to clear. ACL names start with a letter and are case-insensitive.
all	Removes security ACL mapping from all physical ports, virtual ports, and VLANs on a WSS.
vlan <i>vlan-id</i>	VLAN name or number. WSS Software removes the security ACL from the specified VLAN.
port <i>port-list</i>	Port list. WSS Software removes the security ACL from the specified WSS physical port or ports.
tag <i>tag-value</i>	Tag value that identifies a virtual port in a VLAN. Specify a value from 1 through 4095. WSS Software removes the security ACL from the specified virtual port.
ap <i>ap-num</i>	One or more APs, based on their connection IDs. Specify a single connection ID, or specify a comma-separated list of connection IDs, a hyphen-separated range, or any combination, with no spaces. WSS Software removes the security ACL from the specified APs.
in	Removes the security ACL from traffic coming <i>into</i> the WSS.
out	Removes the security ACL from traffic going <i>out of</i> the WSS.

Defaults None.

Access Enabled.

Usage To clear a security ACL map, type the name of the ACL with the VLAN, physical port or ports, virtual port tag, or AP and the direction of the packets to stop filtering. This command deletes the ACL mapping, but not the ACL.

Examples To clear the mapping of security ACL *acljoe* from port 4 for incoming packets, type the following command:

```
WSS# clear security acl map acljoe port 4 in
clear mapping accepted
```

To clear all physical ports, virtual ports, and VLANs on a WSS of the ACLs mapped for incoming and outgoing traffic, type the following command:

```
WSS# clear security acl map all
success: change accepted.
```

See Also

- **clear security acl on page 449**
- **set security acl map on page 459**
- **show security acl map on page 464**

commit security acl

Saves a security ACL, or all security ACLs, in the edit buffer to the running configuration and nonvolatile storage on the WSS. Or, when used with the **clear security acl** command, **commit security acl** deletes a security ACL, or all security ACLs, from the running configuration and nonvolatile storage.

Syntax **commit security acl** {*acl-name* | **all**}

acl-name Name of an existing security ACL to commit. ACL names must start with a letter and are case-insensitive.

all Commits all security ACLs in the edit buffer.

Defaults None.

Access Enabled.

Usage Use the **commit security acl** command to save security ACLs into, or delete them from, the permanent configuration. Until you commit the creation or deletion of a security ACL, it is stored in an edit buffer and is not enforced. After you commit a security ACL, it is removed from the edit buffer.

A single **commit security acl all** command commits the creation and/or deletion of whatever **show security acl info all editbuffer** shows to be currently stored in the edit buffer.

Examples The following commands commit all the security ACLs in the edit buffer to the configuration, display a summary of the committed ACLs, and show that the edit buffer has been cleared:

```
WSS# commit security acl all
configuration accepted
```

```
WSS# show security acl
ACL table
```

ACL	Type	Class	Mapping
acl_123	IP	Static	
acl_124	IP	Static	

```
WSS# show security acl info all editbuffer
acl editbuffer information for all
```

See Also

- **clear security acl on page 449**
- **rollback security acl on page 453**
- **set security acl on page 454**
- **show security acl on page 461**
- **show security acl info on page 463**

hit-sample-rate

This command has been renamed in WSS Software Version 4.1. To configure the hit sample rate, see **set security acl hit-sample-rate on page 460**.

rollback security acl

Clears changes made to the security ACL edit buffer since it was last saved. The ACL is rolled back to its state after the last **commit security acl** command was entered. All uncommitted ACLs in the edit buffer are cleared.

Syntax **rollback security acl** {*acl-name* | **all**}

<i>acl-name</i>	Name of an existing security ACL to roll back. ACL names must start with a letter and are case-insensitive.
all	Rolls back all security ACLs in the edit buffer, clearing all uncommitted ACEs.

Defaults None.

Access Enabled.

Examples The following commands show the edit buffer before a rollback, clear any changes in the edit buffer to security *acl_122*, and show the edit buffer after the rollback:

```
WSS# show security acl info all editbuffer
```

```
ACL edit-buffer information for all
```

```
set security acl ip acl_122 (ACEs 3, add 3, del 0, modified 0)
```

```
-----
1. permit IP source IP 20.0.1.11 0.0.0.255 destination IP any enable-hits
2. deny IP source IP 20.0.2.11 0.0.0.0 destination IP any
3. deny SRC source IP 192.168.1.234 255.255.255.255 enable-hits
```

```
WSS# rollback security acl acl_122
```

```
WSS# show security acl info all editbuffer
```

```
ACL edit-buffer information for all
```

See Also **show security acl on page 461**

set security acl

In the edit buffer, creates a security access control list (ACL), adds one access control entry (ACE) to a security ACL, and/or reorders ACEs in the ACL. The ACEs in an ACL filter IP packets by source IP address, a Layer 4 protocol, or IP, ICMP, TCP, or UDP packet information.

Syntax

By source address

```
set security acl ip acl-name {permit [cos cos] | deny} {source-ip-addr mask | any}  
[[before editbuffer-index | modify editbuffer-index] [hits]
```

By Layer 4 protocol

```
set security acl ip acl-name {permit [cos cos] | deny} protocol-number  
{source-ip-addr mask | any} {destination-ip-addr mask | any}  
[[precedence precedence] [tos tos] | [dscp codepoint]] [before editbuffer-  
index | modify editbuffer-index] [hits]
```

By IP packets

```
set security acl ip acl-name {permit [cos cos] | deny} ip {source-ip-addr mask | any}  
{destination-ip-addr mask | any} [[precedence precedence] [tos tos] | [dscp codepoint]]  
[[before editbuffer-index | modify editbuffer-index] [hits]
```

By ICMP packets

```
set security acl ip acl-name {permit [cos cos] | deny} icmp {source-ip-addr mask | any}  
{destination-ip-addr mask | any} [type icmp-type] [code icmp-code]  
[[precedence precedence] [tos tos] | [dscp codepoint]] [before editbuffer-  
index | modify editbuffer-index] [hits]
```

By TCP packets

```
set security acl ip acl-name {permit [cos cos] | deny}  
tcp {source-ip-addr mask | any [operator port [port2]]} {destination-ip-addr mask | any}  
[operator port [port2]]] [[precedence precedence] [tos tos] | [dscp codepoint]]  
[[established] [before editbuffer-index | modify editbuffer-index] [hits]
```


By UDP packets

set security acl ip *acl-name* {**permit** [**cos** *cos*] | **deny**} **udp** {*source-ip-addr mask* | **any** [*operator port [port2]*]} {*destination-ip-addr mask* | **any** [*operator port [port2]*]} [[**precedence** *precedence*] [**tos** *tos*] | [**dsdp** *codepoint*]] [**before** *editbuffer-index* | **modify** *editbuffer-index*] [**hits**]

acl-name

Security ACL name. ACL names must be unique within the WSS switch, must start with a letter, and are case-insensitive. Specify an ACL name of up to 32 of the following characters:

- Letters *a* through *z* and *A* through *Z*
- Numbers 0 through 9
- Hyphen (-), underscore (_), and period (.)

Nortel recommends that you do not use the same name with different capitalizations for ACLs. For example, do not configure two separate ACLs with the names *acl_123* and *ACL_123*.

Note: In an ACL name, do *not* include the term **all**, **default-action**, **map**, **help**, or **editbuffer**.

permit

Allows traffic that matches the conditions in the ACE.

cos *cos*

For permitted packets, a class-of-service (CoS) level for packet handling. Specify a value from 0 through 7:

- **1** or **2**—Background. Packets are queued in AP forwarding queue 4.
- **0** or **3**—Best effort. Packets are queued in AP forwarding queue 3.
- **4** or **5**—Video. Packets are queued in AP forwarding queue 2.
Use CoS level 4 or 5 for voice over IP (VoIP) packets other than SpectraLink Voice Priority (SVP).
- **6** or **7**—Voice. Packets are queued in AP forwarding queue 1.
Use 6 or 7 only for VoIP phones that use SVP, not for other types of traffic

deny

Blocks traffic that matches the conditions in the ACE.

<i>protocol</i>	IP protocol by which to filter packets: <ul style="list-style-type: none">• ip• tcp• udp• icmp• A protocol number between 0 and 255. (For a complete list of IP protocol names and numbers, see www.iana.org/assignments/protocol-numbers .)
<i>source-ip-addr mask</i> any	IP address and wildcard mask of the network or host <i>from</i> which the packet is being sent. Specify both address and mask in dotted decimal notation. For more information, see “ Wildcard Masks ” on page 12 . To match on any address, specify any or 0.0.0.0 255.255.255.255 .
<i>operator port [port2]</i>	Operand and port number(s) for matching TCP or UDP packets to the number of the source or destination port on <i>source-ip-addr</i> or <i>destination-ip-addr</i> . Specify one of the following operands and the associated port: <ul style="list-style-type: none">• eq—Packets are filtered for only <i>port</i> number.• gt—Packets are filtered for all ports that are greater than <i>port</i> number.• lt—Packets are filtered for all ports that are less than <i>port</i> number.• neq—Packets are filtered for all ports except <i>port</i> number.• range—Packets are filtered for ports in the range between <i>port</i> and <i>port2</i>. To specify a port range, enter two port numbers. Enter the lower port number first, followed by the higher port number. (For a complete list of TCP and UDP port numbers, see www.iana.org/assignments/port-numbers .)
<i>destination-ip-addr mask</i> any	IP address and wildcard mask of the network or host <i>to</i> which the packet is being sent. Specify both address and mask in dotted decimal notation. For more information, see “ Wildcard Masks ” on page 12 . To match on any address, specify any or 0.0.0.0 255.255.255.255 .
type <i>icmp-type</i>	Filters ICMP messages by type. Specify a value from 0 through 255. (For a list of ICMP message type and code numbers, see www.iana.org/assignments/icmp-parameters .)
code <i>icmp-code</i>	For ICMP messages filtered by type, additionally filters ICMP messages by code. Specify a value from 0 through 255. (For a list of ICMP message type and code numbers, see www.iana.org/assignments/icmp-parameters .)

precedence <i>precedence</i>	Filters packets by precedence level. Specify a value from 0 through 7: <ul style="list-style-type: none"> • 0—routine precedence • 1—priority precedence • 2—immediate precedence • 3—flash precedence • 4—flash override precedence • 5—critical precedence • 6—internetwork control precedence • 7—network control precedence
tos <i>tos</i>	Filters packets by type of service (TOS) level. Specify one of the following values, or any sum of these values up to 15. For example, a tos value of 9 filters packets with the TOS levels minimum delay (8) and minimum monetary cost (1). <ul style="list-style-type: none"> • 8—minimum delay • 4—maximum throughput • 2—maximum reliability • 1—minimum monetary cost • 0—normal
dscp <i>codepoint</i>	Filters packets by Differentiated Services Code Point (DSCP) value. You can specify a number from 0 to 63, in decimal or binary format. <p>Note: You cannot use the dscp option along with the precedence and tos options in the same ACE. The CLI rejects an ACE that has this combination of options.</p>
established	For TCP packets only, applies the ACE only to established TCP sessions and not to new TCP sessions.
before <i>editbuffer-index</i>	Inserts the new ACE in front of another ACE in the security ACL. Specify the number of the existing ACE in the edit buffer. Index numbers start at 1. (To display the edit buffer, use show security acl editbuffer .)
modify <i>editbuffer-index</i>	Replaces an ACE in the security ACL with the new ACE. Specify the number of the existing ACE in the edit buffer. Index numbers start at 1. (To display the edit buffer, use show security acl editbuffer .)
hits	Tracks the number of packets that are filtered based on a security ACL, for all mappings.

Defaults By default, permitted packets are classified based on DSCP value, which is converted into an internal CoS value in the switch's CoS map. The packet is then marked with a DSCP value based on the internal CoS value. If the ACE contains the **cos** option, this option overrides the switch's CoS map and marks the packet based on the ACE.

Access Enabled.

History

WSS Software
Version 4.1

The **any** option is supported for the source or destination IP address and mask. This option is equivalent to **0.0.0.0 255.255.255.255**.

Note: The **any** option is shown in the configuration file as **0.0.0.0 255.255.255.255**, regardless of whether you specify **any** or **0.0.0.0 255.255.255.255** when you configure the ACE.

The **dscp codepoint** is added. This option enables you to filter based on a packet's Differentiated Services Code Point (DSCP) value.

Usage The WSS does not apply security ACLs until you activate them with the **commit security acl** command and map them to a VLAN, port, or virtual port, or to a user. If the WSS is reset or restarted, any ACLs in the edit buffer are lost.

You cannot perform ACL functions that include permitting, denying, or marking with a Class of Service (CoS) level on packets with a multicast or broadcast destination address.

The order of security ACEs in a security ACL is important. Once an ACL is active, its ACEs are checked according to their order in the ACL. If an ACE criterion is met, its action takes place and any ACEs that follow are ignored.

ACEs are listed in the order in which you create them, unless you move them. To position security ACEs within a security ACL, use **before editbuffer-index** and **modify editbuffer-index**.

Examples The following command adds an ACE to security *acl_123* that permits packets from IP address 192.168.1.11/24 and counts the hits:

```
WSS# set security acl ip acl_123 permit 192.168.1.11 0.0.0.255 hits
```

The following command adds an ACE to *acl_123* that denies packets from IP address 192.168.2.11:

```
WSS# set security acl ip acl_123 deny 192.168.2.11 0.0.0.0
```

The following command creates *acl_125* by defining an ACE that denies TCP packets from source IP address 192.168.0.1 to destination IP address 192.168.0.2 for established sessions only, and counts the hits:

```
WSS# set security acl ip acl_125 deny tcp 192.168.0.1 0.0.0.0 192.168.0.2 0.0.0.0 established hits
```

The following command adds an ACE to *acl_125* that denies TCP packets from source IP address 192.168.1.1 to destination IP address 192.168.1.2, on destination port 80 only, and counts the hits:

```
WSS# set security acl ip acl_125 deny tcp 192.168.1.1 0.0.0.0 192.168.1.2 0.0.0.0 eq 80 hits
```

Finally, the following command commits the security ACLs in the edit buffer to the configuration:

```
WSS# commit security acl all  
configuration accepted
```

See Also

- **clear security acl on page 449**
- **commit security acl on page 452**
- **show security acl on page 461**

set security acl map

Assigns a committed security ACL to a VLAN, physical port or ports, virtual port, or AP on the WSS.



Note. To assign a security ACL to a user or group in the local WSS database, use the command **set user attr**, **set mac-user attr**, **set usergroup attr**, or **set mac-usergroup attr** with the Filter-Id attribute. To assign a security ACL to a user or group with Filter-Id on a RADIUS server, see the documentation for your RADIUS server.

Syntax `set security acl map acl-name { vlan vlan-id | port port-list [tag tag-list] | ap ap-num } { in | out }`

<i>acl-name</i>	Name of an existing security ACL to map. ACL names start with a letter and are case-insensitive.
vlan <i>vlan-id</i>	VLAN name or number. WSS Software assigns the security ACL to the specified VLAN.
port <i>port-list</i>	Port list. WSS Software assigns the security ACL to the specified physical WSS port or ports.
tag <i>tag-list</i>	One or more values that identify a virtual port in a VLAN. Specify a single tag value from 1 through 4095. Or specify a comma-separated list of values, a hyphen-separated range, or any combination, with no spaces. WSS Software assigns the security ACL to the specified virtual port or ports.
ap <i>ap-num</i>	One or more APs, based on their connection IDs. Specify a single connection ID, or specify a comma-separated list of connection IDs, a hyphen-separated range, or any combination, with no spaces. WSS Software assigns the security ACL to the specified APs.
in	Assigns the security ACL to traffic coming <i>into</i> the WSS.
out	Assigns the security ACL to traffic coming <i>from</i> the WSS.

Defaults None.

Access Enabled.

Usage Before you can map a security ACL, you must use the **commit security acl** command to save the ACL in the running configuration and nonvolatile storage.

For best results, map only one input security ACL and one output security ACL to each VLAN, physical port, virtual port, or AP to filter a flow of packets. If more than one security ACL filters the same traffic, WSS Software applies only the first ACL match and ignores any other matches.

Examples The following command maps security ACL *acl_133* to port 4 for incoming packets:

```
WSS set security acl map acl_133 port 4 in
success: change accepted.
```

See Also

- [clear security acl map on page 451](#)

- **commit security acl** on page 452
- **set mac-user attr** on page 197
- **set mac-usergroup attr** on page 203
- **set security acl** on page 454
- **set user attr** on page 207
- **set usergroup** on page 208
- **show security acl map** on page 464

set security acl hit-sample-rate

Specifies the time interval, in seconds, at which the packet counter for each security ACL is sampled for display. The counter counts the number of packets filtered by the security ACL—or “hits.”

Syntax **set security acl hit-sample-rate** *seconds*

seconds Number of seconds between samples. A sample rate of 0 (zero) disables the sample process.

Defaults By default, the hits are not sampled.

Access Enabled.

History

Version 4.1 Syntax changed from **hit-sample-rate** *seconds* to **set security acl hit-sample-rate** *seconds*, to allow the command to be saved in the configuration file.

Usage To view counter results for a particular ACL, use the **show security acl info** *acl-name* command. To view the hits for all security ACLs, use the **show security acl hits** command.

Examples The first command sets WSS Software to sample ACL hits every 15 seconds. The second and third commands display the results. The results show that 916 packets matching security *acl_153* were sent since the ACL was mapped.

WSS# set security acl hit-sample-rate 15

WSS# show security acl info acl_153

ACL information for acl_153

set security acl ip acl_153 (hits #3 916)

1. permit IP source IP 20.1.1.1 0.0.0.0 destination IP any enable-hits

WSS# show security acl hits

ACL hit counters

Index Counter	ACL-name
1	0 acl_2
2	0 acl_175
3	916 acl_153

See Also

- **show security acl hits on page 462**
- **show security acl info on page 463**

show security acl

Displays a summary of the security ACLs that are mapped.

Syntax `show security acl`**Defaults** None.**Access** Enabled.

Usage This command lists only the ACLs that have been mapped to something (a user, or VLAN, or port, and so on). To list all committed ACLs, use the **show security acl info** command. To list ACLs that have not yet been committed, use the **show security acl editbuffer** command.

Examples To display a summary of the mapped security ACLs on a WSS, type the following command:

WSS# show security acl

ACL table

ACL	Type	Class	Mapping
acl_123	IP	Static	Port 2 In
acl_133	IP	Static	Port 4 In
acl_124	IP	Static	

See Also

- **clear security acl on page 449**
- **commit security acl on page 452**
- **set security acl on page 454**
- **show security acl editbuffer on page 462**
- **show security acl info on page 463**

show security acl dscp

This command has been renamed in WSS Software Version 4.1. See **show qos dscp-table on page 96**.

show security acl editbuffer

Displays a summary of the security ACLs that have not yet been committed to the configuration.

Syntax `show security acl [info all] editbuffer`

info all Displays the ACEs in each uncommitted ACL. Without this option, only the ACE names are listed.

Defaults None.

Access Enabled.

Examples To view a summary of the security ACLs in the edit buffer, type the following command:

```
WSS# show security acl editbuffer
```

```
ACL edit-buffer table
```

ACL	Type	Status
acl_111	IP	Not committed
acl-a	IP	Not committed

To view details about these uncommitted ACLs, type the following command.

```
WSS# show security acl info all editbuffer
```

```
ACL edit-buffer information for all
```

```
set security acl ip acl-111 (ACEs 3, add 3, del 0, modified 2)
```

```
-----  
1. permit IP source IP 192.168.254.12 0.0.0.0 destination IP any  
2. permit IP source IP 192.168.253.11 0.0.0.0 destination IP any  
3. deny SRC source IP 192.168.253.1 0.0.0.255  
set security acl ip acl-a (ACEs 1, add 1, del 0, modified 0)
```

```
-----  
1. permit SRC source IP 192.168.1.1 0.0.0.0
```

See Also

- [clear security acl on page 449](#)
- [commit security acl on page 452](#)
- [set security acl on page 454](#)
- [show security acl on page 461](#)
- [show security acl info on page 463](#)

show security acl hits

Displays the number of packets filtered by security ACLs (“hits”) on the WSS. Each time a packet is filtered by a security ACL, the hit counter increments.

Syntax `show security acl hits`

Defaults None.

Access Enabled.

Usage For WSS Software to count hits for a security ACL, you must specify **hits** in the **set security acl** commands that define ACE rules for the ACL.

Examples To display the security ACL hits on a WSS, type the following command:

WSS# show security acl hits

ACL hit-counters

Index Counter	ACL-name
1	0 acl_2
2	0 acl_175
3	916 acl_123

See Also

- [hit-sample-rate on page 453](#)
- [set security acl on page 454](#)

show security acl info

Displays the contents of a specified security ACL or all security ACLs that are committed—saved in the running configuration and nonvolatile storage—or the contents of security ACLs in the edit buffer before they are committed.

Syntax `show security acl info [acl-name | all] [editbuffer]`

acl-name Name of an existing security ACL to display. ACL names must start with a letter and are case-insensitive.

all Displays the contents of all security ACLs.

editbuffer Displays the contents of the specified security ACL or all security ACLs that are stored in the edit buffer after being created with **set security acl**. If you do not use this parameter, only committed ACLs are shown.

Defaults None.

Access Enabled.

History

WSS Software Version 4.1 The *acl-name | all* option is no longer required; **show security acl info** is valid and displays the same information as **security acl info all**.

Examples To display the contents of all security ACLs committed on a WSS, type the following command:

WSS# show security acl info

ACL information for all

set security acl ip acl_123 (hits #5 462)

-
1. permit IP source IP 192.168.1.11 0.0.0.255 destination IP any enable-hits
 2. deny IP source IP 192.168.2.11 0.0.0.0 destination IP any

set security acl ip acl_134 (hits #3 0)

-
1. permit IP source IP 192.168.0.1 0.0.0.0 destination IP any enable-hits

set security acl ip acl_135 (hits #2 0)

-
1. deny IP source IP 192.168.1.1 0.0.0.0 destination IP any enable-hits

The following command displays the contents of *acl_123* in the edit buffer, including the committed ACE rules 1 and 2 and the uncommitted rule 3:

WSS# show security acl info acl_123 editbuffer

ACL edit-buffer information for acl_123

set security acl ip acl_123 (ACEs 3, add 3, del 0, modified 0)

-
1. permit IP source IP 192.168.1.11 0.0.0.255 destination IP any enable-hits
 2. deny IP source IP 192.168.2.11 0.0.0.0 destination IP any
 3. deny SRC source IP 192.168.1.234 255.255.255.255 enable-hits

See Also

- **clear security acl on page 449**
- **commit security acl on page 452**
- **set security acl on page 454**

show security acl map

Displays the VLANs, ports, and virtual ports on the WSS to which a security ACL is assigned.

Syntax `show security acl map acl-name`

acl-name Name of an existing security ACL for which to show static mapping.
ACL names must start with a letter and are case-insensitive.

Defaults None.

Access Enabled.

Examples The following command displays the port to which security ACL *acl_111* is mapped:

WSS# show security acl map acl_111

ACL acl_111 is mapped to:

Port 4 in

See Also

- **clear security acl map** on page 451
- **set security acl map** on page 459
- **show security acl** on page 461

show security acl resource-usage

Displays statistics about the resources used by security ACL filtering on the WSS.

Syntax `show security acl resource-usage`

Defaults None.

Access Enabled.

Usage Use this command with the help of the Nortel Enterprise Technical Support (NETS) to diagnose an ACL resource problem. (To contact NETS, see [“How to get help” on page 3.](#))

Examples To display security ACL resource usage, type the following command:

WSS# show security acl resource-usage

ACL resources

Classifier tree counters

```

-----
Number of rules           : 2
Number of leaf nodes     : 1
Stored rule count        : 2
Leaf chain count         : 1
Longest leaf chain       : 2
Number of non-leaf nodes : 0
Uncompressed Rule Count : 2
Maximum node depth      : 1
Sub-chain count          : 0
PSCBs in primary memory : 0 (max: 512)
PSCBs in secondary memory : 0 (max: 9728)
Leaves in primary        : 2 (max: 151)
Leaves in secondary     : 0 (max 12096)
Sum node depth           : 1

```

Information on Network Processor status

```

-----
Fragmentation control    : 0
UC switchdest            : 0

```

ACL resources

```

Port number           : 0
Number of action types   : 2
LUdef in use             : 5
Default action pointer   : c8007dc

```

```

L4 global           : True
No rules            : False
Non-IP rules        : False
Root in first       : True
Static default action : False
No per-user (MAC) mapping : True
Out mapping         : False
In mapping          : True
No VLAN or PORT mapping : False
No VPORT mapping    : True

```

Table 73 explains the fields in the `show security acl resource-usage` output.

Table 1: show security acl resource-usage Output

Field	Description
Number of rules	Number of security ACEs currently mapped to ports or VLANs.
Number of leaf nodes	Number of security ACL data entries stored in the rule tree.
Stored rule count	Number of security ACEs stored in the rule tree.
Leaf chain count	Number of chained security ACL data entries stored in the rule tree.
Longest leaf chain	Longest chain of security ACL data entries stored in the rule tree.
Number of non-leaf nodes	Number of nodes with no data entries stored in the rule tree.
Uncompressed Rule Count	Number of security ACEs stored in the rule tree, including duplicates—ACEs in ACLs applied to multiple ports, virtual ports, or VLANs.
Maximum node depth	Number of data elements in the rule tree, from the root to the furthest data entry (leaf).
Sub-chain count	Sum of action types represented in all security ACL data entries.
PSCBs in primary memory	Number of pattern search control blocks (PSCBs) stored in primary node memory.
PSCBs in secondary memory	Number of PSCBs stored in secondary node memory.
Leaves in primary	Number of security ACL data entries stored in primary leaf memory.
Leaves in secondary	Number of ACL data entries stored in secondary leaf memory.
Sum node depth	Total number of security ACL data entries.
Fragmentation control	Control value for handling fragmented IP packets. Note: The current WSS Software version filters only the first packet of a fragmented IP packet and passes the remaining fragments.
UC switchdest	Control value for handling fragmented IP packets. Note: The current WSS Software version filters only the first packet of a fragmented IP packet and passes the remaining fragments.

Table 1: show security acl resource-usage Output (continued)

Field	Description
Port number	Control value for handling fragmented IP packets. Note: The current WSS Software version filters only the first packet of a fragmented IP packet and passes the remaining fragments.
Number of action types	Number of actions that can be performed by ACLs. This value is always 2, because ACLs can either <i>permit</i> or <i>deny</i> .
LUdef in use	Number of the lookup definition (LUdef) table currently in use for packet handling.
Default action pointer	Memory address used for packet handling, from which default action data is obtained when necessary.
L4 global	Security ACL mapping on the WSS: <ul style="list-style-type: none"> • True—Security ACLs are mapped. • False—No security ACLs are mapped.
No rules	Security ACE rule mapping on the WSS: <ul style="list-style-type: none"> • True—No security ACEs are mapped. • False—Security ACEs are mapped.
Non-IP rules	Non-IP security ACE mapping on the WSS: <ul style="list-style-type: none"> • True—Non-IP security ACEs are mapped. • False—Only IP security ACEs are mapped. <p>Note: The current WSS Software version supports security ACEs for IP only.</p>
Root in first	Leaf buffer allocation: <ul style="list-style-type: none"> • True—Enough primary leaf buffers are allocated in nonvolatile memory to accommodate all leaves. • False—Insufficient primary leaf buffers are allocated in nonvolatile memory to accommodate all leaves.
Static default action	Definition of a default action: <ul style="list-style-type: none"> • True—A default action types is defined. • False—No default action type is defined.
No per-user (MAC) mapping	Per-user application of a security ACL with the Filter-Id attribute, on the WSS: <ul style="list-style-type: none"> • True—No security ACLs are applied to users. • False—Security ACLs are applied to users.
Out mapping	Application of security ACLs to outgoing traffic on the WSS: <ul style="list-style-type: none"> • True—Security ACLs are mapped to outgoing traffic. • False—No security ACLs are mapped to outgoing traffic.

Table 1: show security acl resource-usage Output (continued)

Field	Description
In mapping	Application of security ACLs to incoming traffic on the WSS: <ul style="list-style-type: none">• True—Security ACLs are mapped to incoming traffic.• False—No security ACLs are mapped to incoming traffic.
No VLAN or PORT mapping	Application of security ACLs to WSS VLANs or ports on the WSS: <ul style="list-style-type: none">• True—No security ACLs are mapped to VLANs or ports.• False—Security ACLs are mapped to VLANs or ports.
No VPORT mapping	Application of security ACLs to WSS virtual ports on the WSS: <ul style="list-style-type: none">• True—No security ACLs are mapped to virtual ports.• False—Security ACLs are mapped to virtual ports.

Cryptography Commands

A digital certificate is a form of electronic identification for computers. The WSS requires digital certificates to authenticate its communications to WLAN Management Software and Web View, to Web-based AAA clients, and to Extensible Authentication Protocol (EAP) clients for which the WSS performs all EAP processing. Certificates can be generated on the WSS or obtained from a certificate authority (CA). Keys contained within the certificates allow the WSS, its servers, and its wireless clients to exchange information secured by encryption.



Note. If the switch does not already have certificates, WSS Software automatically generates the missing ones the first time you boot using WSS Software Version 4.1 or later. You do not need to install certificates unless you want to replace the ones automatically generated by WSS Software. (For more information, see the “Certificates Automatically Generated by WSS Software” section in the “Managing Keys and Certificates” chapter of the *Nortel WLAN Security Switch 2300 Series Configuration Guide*.)



Note. Before installing a new certificate, verify with the **show timedate** and **show timezone** commands that the WSS is set to the correct date, time, and time zone. Otherwise, certificates might not be installed correctly.

This chapter presents cryptography commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Encryption Keys	crypto generate key on page 472 show crypto key domain on page 481 show crypto key ssh on page 481
PKCS #7 Certificates	crypto generate request on page 473 crypto ca-certificate on page 470 show crypto ca-certificate on page 479 crypto certificate on page 471 show crypto certificate on page 480
PKCS #12 Certificate	crypto otp on page 476 crypto pkcs12 on page 477
Self-Signed Certificate	crypto generate self-signed on page 475

crypto ca-certificate

Installs a certificate authority's own PKCS #7 certificate into the WSS certificate and key storage area.

Syntax `crypto ca-certificate {admin | eap | web} PEM-formatted-certificate`

admin	Stores the certificate authority's certificate that signed the administrative certificate for the WSS. The administrative certificate authenticates the WSS to WLAN Management Software or Web View.
eap	Stores the certificate authority's certificate that signed the Extensible Authentication Protocol (EAP) certificate for the WSS. The EAP certificate authenticates the WSS to 802.1X supplicants (clients).
web	Stores the certificate authority's certificate that signed the Web-based AAA certificate for the WSS. The Web certificate authenticates the WSS to clients who use Web-based AAA.
<i>PEM-formatted-certificate</i>	ASCII text representation of the certificate authority PKCS #7 certificate, consisting of up to 5120 characters that you have obtained from the certificate authority.

Defaults None.

Access Enabled.

History

Version 4.1 **webaaa** option renamed to **web**

Usage The Privacy-Enhanced Mail protocol (PEM) format is used for representing a PKCS #7 certificate in ASCII text. PEM uses base64 encoding to convert the certificate to ASCII text, then puts the encoded text between the following delimiters:

```
-----BEGIN CERTIFICATE-----  
-----END CERTIFICATE-----
```

To use this command, you must already have obtained a copy of the certificate authority's certificate as a PKCS #7 object file. Then do the following:

- 1 Open the PKCS #7 object file with an ASCII text editor such as Notepad or vi.
- 2 Enter the **crypto ca-certificate** command on the CLI command line.
- 3 When WSS Software prompts you for the PEM-formatted certificate, paste the PKCS #7 object file onto the command line.

Examples The following command adds the certificate authority's certificate to WSS certificate and key storage:

WSS# crypto ca-certificate admin

Enter PEM-encoded certificate

```
-----BEGIN CERTIFICATE-----
```

```
MIIDwDCCA2qgAwIBAgIQL2jvuu4PO5FAQCyewU3ojANBgkqhkiG9wOBAQUFADCB
```



```
mzerMClaweVQQTToewi\wpoer0QWNFNkj90044mbdrl1277SWQ8G7DiwYUtrqoQplKJvxz
.....
Lm8wmVYxP56M;CUAm908C2foYgOY40=
-----END CERTIFICATE-----
```

See Also **show crypto ca-certificate on page 479**

crypto certificate

Installs one of the WSS's PKCS #7 certificates into the certificate and key storage area on the WSS. The certificate, which is issued and signed by a certificate authority, authenticates the WSS either to WLAN Management Software or Web View, or to 802.1X supplicants (clients).

Syntax `crypto certificate { admin | eap | web } PEM-formatted certificate`

admin	Stores the certificate authority's administrative certificate, which authenticates the WSS to WLAN Management Software or Web View.
eap	Stores the certificate authority's Extensible Authentication Protocol (EAP) certificate, which authenticates the WSS to 802.1X supplicants (clients).
web	Stores the certificate authority's Web-based AAA certificate, which authenticates the WSS to clients who use Web-based AAA.
<i>PEM-formatted certificate</i>	ASCII text representation of the PKCS #7 certificate, consisting of up to 5120 characters, that you have obtained from the certificate authority.

Defaults None.

Access Enabled.

History

Version 4.1 **webaaa** option renamed to **web**

Usage To use this command, you must already have generated a certificate request with the **crypto generate request** command, sent the request to the certificate authority, and obtained a signed copy of the WSS certificate as a PKCS #7 object file. Then do the following:

- 1 Open the PKCS #7 object file with an ASCII text editor such as Notepad or vi.
- 2 Enter the **crypto certificate** command on the CLI command line.
- 3 When WSS Software prompts you for the PEM-formatted certificate, paste the PKCS #7 object file onto the command line.

The WSS verifies the validity of the public key associated with this certificate before installing it, to prevent a mismatch between the WSS's private key and the public key in the installed certificate.

Examples The following command installs a certificate:

```
WSS# crypto certificate admin
```

```
Enter PEM-encoded certificate
```

```
-----BEGIN CERTIFICATE-----
MIIBdTCP3wIBADA2MQswCQYDVQQGEwJVUzELMAkGA1UECBMCQOEwGjAYBgNVB
AMU
EXR1Y2hwdWJzQHRycHouY29tMIGfMAOGCSqGSIb3DQEBAQAA4GNADCBiQKBgQC4
.....
2L8Q9tk+G2As84QYLm8wmVY>xP56M;CUAm908C2foYgOY40=
-----END CERTIFICATE-----
```

See Also

- [crypto generate request on page 473](#)
- [crypto generate self-signed on page 475](#)

crypto generate key

Generates an RSA public-private encryption key pair that is required for a Certificate Signing Request (CSR) or a self-signed certificate. For SSH, generates an authentication key.

Syntax `crypto generate key { admin | domain | eap | ssh | web }`
`{ 128 | 512 | 1024 | 2048 }`

admin	Generates an administrative key pair for authenticating the WSS to WLAN Management Software or Web View.
domain	Generates a key pair for authenticating management traffic exchanged by WSSs within a Mobility Domain.
eap	Generates an EAP key pair for authenticating the WSS to 802.1X supplicants (clients).
ssh	Generates a key pair for authenticating the WSS to Secure Shell (SSH) clients.
web	Generates an administrative key pair for authenticating the WSS to Web-based AAA clients.
128 512 1024 2048	Length of the key pair in bits.

Note: The minimum key length for SSH is **1024**. The length **128** applies only to **domain** and is the only valid option for it.

Defaults None.

Access Enabled.

History

Version 4.1 **webaaa** option renamed to **web**

Version 5.0 **domain** option added

Usage You can overwrite a key by generating another key of the same type.

SSH requires an SSH authentication key, but you can allow WSS Software to generate it automatically. The first time an SSH client attempts to access the SSH server on a WSS, the switch automatically generates a 1024-byte SSH key. If you want to use a 2048-byte key instead, use the **crypto generate key ssh 2048** command to generate one.

Examples To generate an administrative key for use with WLAN Management Software, type the following command:

```
WSS# crypto generate key admin 1024
key pair generated
```

See Also [show crypto key ssh on page 481](#)

crypto generate request

Generates a Certificate Signing Request (CSR). This command outputs a PEM-formatted PKCS #10 text string that you can cut and paste to another location for delivery to a certificate authority.

This command generates either an administrative CSR for use with WLAN Management Software and Web View, or an EAP CSR for use with 802.1X clients.

Syntax `crypto generate request { admin | eap | web }`

admin	Generates a request for an administrative certificate to authenticate the WSS to WLAN Management Software or Web View.
eap	Generates a request for an EAP certificate to authenticate the WSS to 802.1X supplicants (clients).
web	Generates a request for a Web-based AAA certificate to authenticate the WSS to Web-based AAA clients.

After type the command, you are prompted for the following variables:

Country Name <i>string</i>	(Optional) Specify the abbreviation for the country in which the WSS is operating, in 2 alphanumeric characters with no spaces.
State Name <i>string</i>	(Optional) Specify the name of the state, in up to 64 alphanumeric characters. Spaces are allowed.
Locality Name <i>string</i>	(Optional) Specify the name of the locality, in up to 80 alphanumeric characters with no spaces.
Organizational Name <i>string</i>	(Optional) Specify the name of the organization, in up to 80 alphanumeric characters with no spaces.
Organizational Unit <i>string</i>	(Optional) Specify the name of the organizational unit, in up to 80 alphanumeric characters with no spaces.
Common Name <i>string</i>	Specify a unique name for the WSS, in up to 80 alphanumeric characters with no spaces. Use a fully qualified name if such names are supported on your network. This field is required.

Email Address <i>string</i>	(Optional) Specify your email address, in up to 80 alphanumeric characters with no spaces.
Unstructured Name <i>string</i>	(Optional) Specify any name, in up to 80 alphanumeric characters with no spaces.

Defaults None.

Access Enabled.

History

- Version 4.1
- **webaaa** option renamed to **web**
 - Maximum string length for State Name increased from two to 64 alphanumeric characters.

Usage To use this command, you must already have generated a public-private encryption key pair with the **crypto generate key** command.

Enter **crypto generate request admin**, **crypto generate request eap**, or **crypto generate request web** and press Enter. When you are prompted, type the identifying values in the fields, or press Enter if the field is optional. You must enter a common name for the WSS.

This command outputs a PKCS #10 text string in Privacy-Enhanced Mail protocol (PEM) format that you paste to another location for submission to the certificate authority. You then send the request to the certificate authority to obtain a signed copy of the WSS certificate as a PKCS #7 object file.

Examples To request an administrative certificate from a certificate authority, type the following command:

WSS# **crypto generate request admin**

Country Name: **US**

State Name: **CA**

Locality Name: **Santa Clara**

Organizational Name: **Nortel**

Organizational Unit: **ENG**

Common Name: **ENG**

Email Address: **admin@example.com**

Unstructured Name: **admin**

CSR for admin is

-----BEGIN CERTIFICATE REQUEST-----

```
MIIBuzCCASQCAQAwezELMAkGA1UEBhMCdXMxCzAJBgNVBAGTAmNhMQswCQYDVQ
QQH
```

```
EwJjYTELMAkGA1UEChMCY2ExCzAJBgNVBAsTAmNhMQswCQYDVQQDEwJjYTEYMB
YG
```

```
CSqGSIb3DQEJARYJY2FAY2EuY29tMREwDwYJKoZIhvcNAQkCEwJjYTCBnzANBgkq
hkiG9w0BAQEFAAOBjQAwgYkCgYEA1zatpYStOjHMa0QJmWHeZPPFGQ9kBEimJKPG
bznFjAC780GcZtnJPGqnMnOKj/4NdknonT6NdCd2fBdGbuEFGNMNgZMYKGcV2JJu
tr*P*z*exECScaNlicKMYa$SLQo621vh67RM1KTMECM6uCBB6XNypIHn1gtrrpL/
LhyGTWUCAwEAAaAAMA0GCSqGSIb3DQEBBAUAA4GBAHK5z2kfjBbV/F0b0MyC5S7K
htsw7T4SwmCij55qfUHxsRelggYcw6vJtr57jJ7wFfsMd8C50NcbJLF1nYC9OKkB
hW+5gDPAOZdOnnr591XKz3Zzyvyrktv00rcl8Fo2RfTQ3AOT9cUZqJVeI085GXJ
```

-----END CERTIFICATE REQUEST-----

See Also

- [crypto certificate on page 471](#)
- [crypto generate key on page 472](#)

crypto generate self-signed

Generates a self-signed certificate for either an administrative certificate for use with WLAN Management Software or an EAP certificate for use with 802.1X wireless users.

Syntax `crypto generate self-signed { admin | eap | web }`

admin	Generates an administrative certificate to authenticate the WSS to WLAN Management Software or Web View.
eap	Generates an EAP certificate to authenticate the WSS to 802.1X supplicants (clients).
web	Generates a Web-based AAA certificate to authenticate the WSS to Web-based AAA clients.

After type the command, you are prompted for the following variables:

Country Name <i>string</i>	(Optional) Specify the abbreviation for the country in which the WSS is operating, in 2 alphanumeric characters with no spaces.
State Name <i>string</i>	(Optional) Specify the abbreviation for the name of the state, in 2 alphanumeric characters with no spaces.
Locality Name <i>string</i>	(Optional) Specify the name of the locality, in up to 80 alphanumeric characters with no spaces.
Organizational Name <i>string</i>	(Optional) Specify the name of the organization, in up to 80 alphanumeric characters with no spaces.
Organizational Unit <i>string</i>	(Optional) Specify the name of the organizational unit, in up to 80 alphanumeric characters with no spaces.
Common Name <i>string</i>	Specify a unique name for the WSS, in up to 80 alphanumeric characters with no spaces. Use a fully qualified name if such names are supported on your network. This field is required. Note: If you are generating a Web-based AAA (web) certificate, use a common name that looks like a domain name (two or more strings connected by dots, with no spaces). For example, use <i>common.name</i> instead of <i>common name</i> . The string is not required to be an actual domain name. It simply needs to be formatted like one.
Email Address <i>string</i>	(Optional) Specify your email address, in up to 80 alphanumeric characters with no spaces.
Unstructured Name <i>string</i>	(Optional) Specify any name, in up to 80 alphanumeric characters with no spaces.

Defaults None.

Access Enabled.

History

Version 4.1 **webaaa** option renamed to **web**

Usage To use this command, you must already have generated a public-private encryption key pair with the **crypto generate key** command.

Examples To generate a self-signed administrative certificate, type the following command:

WSS# crypto generate self-signed admin

Country Name:

State Name:

Locality Name:

Organizational Name:

Organizational Unit:

Common Name: **wss1@example.com**

Email Address:

Unstructured Name:

success: self-signed cert for admin generated

See Also

- **crypto certificate on page 471**
- **crypto generate key on page 472**

crypto otp

Sets a one-time password (OTP) for use with the **crypto pkcs12** command.

Syntax **crypto otp** { **admin** | **eap** | **web** } *one-time-password*

admin	Creates a one-time password for installing a PKCS #12 object file for an administrative certificate and key pair—and optionally the certificate authority’s own certificate—to authenticate the WSS to WLAN Management Software or Web View.
eap	Creates a one-time password for installing a PKCS #12 object file for an EAP certificate and key pair—and optionally the certificate authority’s own certificate—to authenticate the WSS to 802.1X supplicants (clients).
web	Creates a one-time password for installing a PKCS #12 object file for a Web-based AAA certificate and key pair—and optionally the certificate authority’s own certificate—to authenticate the WSS to Web-based AAA clients.

one-time-password

Password of at least 1 alphanumeric character, with no spaces, for clients other than Microsoft Windows clients. The password must be the same as the password protecting the PKCS #12 object file.

Note: On a WSS that handles communications to and from Microsoft Windows clients, use a one-time password of 31 characters or fewer.

The following characters *cannot* be used as part of the one-time password of a PKCS #12 file:

- Quotation marks (“ ”)
- Question mark (?)
- Ampersand (&)

Defaults None.

Access Enabled.

History

Version 4.1

webaaa option renamed to **web**

Usage The password allows the public-private key pair and certificate to be installed together from the same PKCS #12 object file. WSS Software erases the one-time password after processing the **crypto pkcs12** command or when you reboot the WSS.

Nortel recommends that you create a password that is memorable to you but is not subject to easy guesses or a dictionary attack. For best results, create a password of alphanumeric uppercase and lowercase characters.

Examples The following command creates the one-time password *hap9iN#ss* for installing an EAP certificate and key pair:

```
WSS# crypto generate otp eap hap9iN#ss
OTP set
```

See Also [crypto pkcs12 on page 477](#)

crypto pkcs12

Unpacks a PKCS #12 object file into the certificate and key storage area on the WSS. This object file contains a public-private key pair, a WSS certificate signed by a certificate authority, and the certificate authority’s certificate.

Syntax `crypto pkcs12 {admin | eap | web} file-location-url`

admin

Unpacks a PKCS #12 object file for an administrative certificate and key pair—and optionally the certificate authority’s own certificate—for authenticating the WSS to WLAN Management Software or Web View.

eap

Unpacks a PKCS #12 object file for an EAP certificate and key pair—and optionally the certificate authority’s own certificate—for authenticating the WSS to 802.1X supplicants (clients).

web	Unpacks a PKCS #12 object file for a Web-based AAA certificate and key pair—and optionally the certificate authority's own certificate—for authenticating the WSS to Web-based AAA clients.
<i>file-location-url</i>	Location of the PKCS #12 object file to be installed. Specify a location of between 1 and 128 alphanumeric characters, with no spaces.

Defaults The password you enter with the **crypto otp** command must be the same as the one protecting the PKCS #12 file.

Access Enabled.

History

Version 4.1 **webaaa** option renamed to **web**

Usage To use this command, you must have already created a one-time password with the **crypto otp** command.

You must also have the PKCS #12 object file available. You can download a PKCS #12 object file via TFTP from a remote location to the local nonvolatile storage system on the WSS.

Examples The following commands copy a PKCS #12 object file for an EAP certificate and key pair—and optionally the certificate authority's own certificate—from a TFTP server to nonvolatile storage on the WSS, create the one-time password *hap9iN#ss*, and unpack the PKCS #12 file:

```
WSS# copy tftp://192.168.253.1/2048full.p12 2048full.p12
success: received 637 bytes in 0.253 seconds [ 2517 bytes/sec]
```

```
WSS# crypto otp eap hap9iN#ss
OTP set
```

```
WSS# crypto pkcs12 eap 2048full.p12
Unwrapped from PKCS12 file:
  keypair
  device certificate
  CA certificate
```

See Also **crypto otp** on page 476

show crypto ca-certificate

Displays information about the certificate authority's PEM-encoded PKCS #7 certificate.

Syntax `show crypto ca-certificate { admin | eap | web }`

- admin** Displays information about the certificate authority's certificate that signed the administrative certificate for the WSS.
The administrative certificate authenticates the WSS to WLAN Management Software or Web View.
- eap** Displays information about the certificate authority's certificate that signed the Extensible Authentication Protocol (EAP) certificate for the WSS.
The EAP certificate authenticates the **WSS** to 802.1X supplicants (clients).
- web** Displays information about the certificate authority's certificate that signed the Web-based AAA certificate for the WSS.
The Web-based AAA certificate authenticates the **WSS** to Web-based AAA clients.

Defaults None.

Access Enabled.

History

Version 4.1 **webaaa** option renamed to **web**

Examples To display information about the certificate of a certificate authority, type the following command:

WSS# show crypto ca-certificate

[Table 74](#) describes the fields in the display.

Table 1: show crypto ca-certificate Output

Fields	Description
Version	Version of the X.509 certificate.
Serial Number	A unique identifier for the certificate or signature.
Subject	Name of the certificate owner.
Signature Algorithm	Algorithm that created the signature, such as RSA MD5 or RSA SHA.
Issuer	Certificate authority that issued the certificate or signature.
Validity	Time period for which the certificate is valid.

See Also

- [crypto ca-certificate on page 470](#)

- [show crypto certificate on page 480](#)

show crypto certificate

Displays information about one of the cryptographic certificates installed on the WSS.

Syntax `show crypto certificate { admin | eap | web }`

admin	Displays information about the administrative certificate that authenticates the WSS to WLAN Management Software or Web View.
eap	Displays information about the EAP certificate that authenticates the WSS to 802.1X supplicants (clients).
web	Displays information about the Web-based AAA certificate that authenticates the WSS to Web-based AAA clients.

Defaults None.

Access Enabled.

History

Version 4.1 **webaaa** option renamed to **web**

Usage You must have generated a self-signed certificate or obtained a certificate from a certificate authority before displaying information about the certificate.

Examples To display information about a cryptographic certificate, type the following command:

WSS# show crypto certificate eap

[Table 75](#) describes the fields of the display.

Table 2: crypto certificate Output

Fields	Description
Version	Version of the X.509 certificate.
Serial Number	A unique identifier for the certificate or signature.
Subject	Name of the certificate owner.
Signature Algorithm	Algorithm that created the signature, such as RSA MD5 or RSA SHA.
Issuer	Certificate authority that issued the certificate or signature.
Validity	Time period for which the certificate is valid.

See Also

- **crypto generate self-signed on page 475**
- **show crypto ca-certificate on page 479**

show crypto key domain

Displays the checksum (also called a *fingerprint*) of the public key used to authenticate management traffic between WSSs.

Syntax `show crypto key domain`

Defaults None.

Access Enabled.

History Introduced in WSS Software 5.0.

Examples To display the fingerprint for WSS-WSS security, type the following command:

WSS# show crypto key domain

Domain public key:

e6:43:91:e2:b3:53:ed:46:76:5f:f0:96:3a:3b:86:d3

See Also **crypto generate key on page 472**

show crypto key ssh

Displays SSH authentication key information. This command displays the checksum (also called a *fingerprint*) of the public key. When you connect to the WSS with an SSH client, you can compare the SSH key checksum displayed by the WSS with the one displayed by the client to verify that you really are connected to the WSS and not another device.

Generally, SSH clients remember the encryption key after the first connection, so you need to check the key only once.

Syntax `show crypto key ssh`

Defaults None.

Access Enabled.

History Introduced in WSS Software 2.0.

Examples To display SSH key information, type the following command:

WSS# show crypto key ssh

ec:6f:56:7f:d1:fd:c0:28:93:ae:a4:f9:7c:f5:13:04

See Also **crypto generate key on page 472**

RADIUS and Server Groups Commands

Use RADIUS commands to set up communication between a WSS and groups of up to four RADIUS servers for remote authentication, authorization, and accounting (AAA) of administrators and network users. This chapter presents RADIUS commands alphabetically. Use the following table to locate commands in this chapter based on their uses.

RADIUS Client	set radius client system-ip on page 488
	clear radius client system-ip on page 484
RADIUS Servers	set radius on page 487
	set radius server on page 490
	clear radius on page 483
	clear radius server on page 486
Server Groups	set server group on page 492
	set server group load-balance on page 493
	clear server group on page 486
RADIUS Proxy	set radius proxy client on page 489
	set radius proxy port on page 489
	clear radius proxy client on page 485
	clear radius proxy port on page 485

(For information about RADIUS attributes, see the RADIUS appendix in the [Nortel WLAN 2300 System Software Configuration Guide](#).)

clear radius

Resets parameters that were globally configured for RADIUS servers to their default values.

Syntax `clear radius { deadtime | key | retransmit | timeout }`

deadtime	Number of minutes to wait after declaring an unresponsive RADIUS server unavailable before retrying the RADIUS server.
key	Password (shared secret key) used to authenticate to the RADIUS server.

retransmit	Number of transmission attempts made before declaring an unresponsive RADIUS server unavailable.
timeout	Number of seconds to wait for the RADIUS server to respond before retransmitting.

Defaults Global RADIUS parameters have the following default values:

- **deadtime**—0 (zero) minutes (The WSS does not designate unresponsive RADIUS servers as unavailable.)
- **key**—No key
- **retransmit**—3 (the total number of attempts, including the first attempt)
- **timeout**—5 seconds

Access Enabled.

History Introduced in WSS Software 1.0.

Usage To override the globally set values on a particular RADIUS server, use the **set radius server** command.

Examples To reset all global RADIUS parameters to their factory defaults, type the following commands:

WSS# clear radius deadtime

success: change accepted.

WSS# clear radius key

success: change accepted.

WSS# clear radius retransmit

success: change accepted.

WSS# clear radius timeout

success: change accepted.

See Also

- **set radius on page 487**
- **set radius server on page 490**
- **show aaa on page 210**

clear radius client system-ip

Removes the WSS's system IP address from use as the permanent source address in RADIUS client requests from the switch to its RADIUS server(s).

Syntax **clear radius client system-ip**

Defaults None.

Access Enabled.

History Introduced in WSS Software 1.0.

Usage The **clear radius client system-ip** command causes the WSS to use the IP address of the interface through which it sends a RADIUS client request as the source IP address. The WSS selects a source interface address based on information in its routing table as the source address for RADIUS packets leaving the switch.

Examples To clear the system IP address as the permanent source address for RADIUS client requests, type the following command:

WSS# clear radius client system-ip
success: change accepted.

See Also

- **set radius client system-ip on page 488**
- **show aaa on page 210**

clear radius proxy client

Removes RADIUS proxy client entries for third-party APs.

Syntax **clear radius proxy client all**

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.0.

Examples The following command clears all RADIUS proxy client entries from the switch:

WSS# clear radius proxy client all
success: change accepted.

See Also **set radius proxy client on page 489**

clear radius proxy port

Removes RADIUS proxy ports configured for third-party APs.

Syntax **clear radius proxy port all**

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.0.

Examples The following command clears all RADIUS proxy port entries from the switch:

WSS# clear radius proxy port all
success: change accepted.

See Also **set radius proxy port on page 489**

clear radius server

Removes the named RADIUS server from the WSS configuration.

Syntax `clear radius server server-name`

server-name Name of a RADIUS server configured to perform remote AAA services for the WSS.

Defaults None.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples The following command removes the RADIUS server *rs42* from a list of remote AAA servers:

WSS# clear radius server rs42
success: change accepted.

See Also

- [set radius server on page 490](#)
- [show aaa on page 210](#)

clear server group

Removes a RADIUS server group from the configuration, or disables load balancing for the group.

Syntax `clear server group group-name [load-balance]`

group-name Name of a RADIUS server group configured to perform remote AAA services for WSSs.

load-balance Ability of group members to share demand for services among servers.

Defaults None.

Access Enabled.

History Introduced in WSS Software 1.0.

Usage Deleting a server group removes the server group from the configuration. However, the members of the server group remain.

Examples To remove the server group *sg-77* type the following command:

WSS# clear server group sg-77
success: change accepted.

To disable load balancing in a server group *shorebirds*, type the following command:

WSS# set server group shorebirds load-balance disable
success: change accepted.

See Also [set server group on page 492](#)

set radius

Configures global defaults for RADIUS servers that do not explicitly set these values themselves. By default, the WSS automatically sets all these values except the password (key).

Syntax `set radius { deadtime minutes | encrypted-key string | key string | retransmit number | timeout seconds }`

deadtime <i>minutes</i>	Number of minutes the WSS waits after declaring an unresponsive RADIUS server unavailable before retrying the RADIUS server. You can specify from 0 to 1440 minutes.
encrypted-key <i>string</i>	<p>Password (shared secret key) used to authenticate to the RADIUS server, entered in its encrypted form. You must provide the same encrypted password that is defined on the RADIUS server. The password can be 1 to 64 characters long, with no spaces or tabs. WSS Software does not encrypt the string you enter, and instead displays the string in show config and show aaa output exactly as you entered it.</p> <p>Note: Use this option only if you are entering the key in its encrypted form. To enter the key in unencrypted form, use the key string option instead.</p>
key <i>string</i>	<p>Password (shared secret key) used to authenticate to the RADIUS server, entered in its unencrypted form. You must provide the same password that is defined on the RADIUS server. The password can be 1 to 64 characters long, with no spaces or tabs. WSS Software encrypts the displayed form of the string in show config and show aaa output.</p> <p>Note: Use this option only if you are entering the key in its unencrypted form. To enter the key in encrypted form, use the encrypted-key string option instead.</p>
retransmit <i>number</i>	Number of transmission attempts the WSS makes before declaring an unresponsive RADIUS server unavailable. You can specify from 1 to 100 retries.
timeout <i>seconds</i>	Number of seconds the WSS waits for the RADIUS server to respond before retransmitting. You can specify from 1 to 65,535.

Defaults Global RADIUS parameters have the following default values:

- **deadtime**—0 (zero) minutes (The WSS does not designate unresponsive RADIUS servers as unavailable.)
- **encrypted-key**—No key
- **key**—No key
- **retransmit**—3 (the total number of attempts, including the first attempt)
- **timeout**—5 seconds

Access Enabled.

History

Version 4.1 **encrypted-key** option added

Usage You can specify only one parameter per command line.

Examples The following commands sets the dead time to 5 minutes, the RADIUS key to *goody*, the number of retransmissions to 1, and the timeout to 21 seconds on all RADIUS servers connected to the WSS:

23x0# set radius deadtime 5

success: change accepted.

23x0# set radius key goody

success: change accepted.

23x0# set radius retransmit 1

success: change accepted.

23x0# set radius timeout 21

success: change accepted.

See Also

- **clear radius server on page 486**
- **set radius server on page 490**
- **show aaa on page 210**

set radius client system-ip

Causes all RADIUS requests to be sourced from the IP address specified by the **set system ip-address** command, providing a permanent source IP address for RADIUS packets sent from the WSS.

Syntax **set radius client system-ip**

Defaults None. If you do not use this command, RADIUS packets leaving the WSS have the source IP address of the outbound interface, which can change as routing conditions change.

Access Enabled.

History Introduced in WSS Software 1.0.

Usage The WSS system IP address must be set before you use this command.

Examples The following command sets the WSS system IP address as the address of the RADIUS client:

WSS# set radius client system-ip

success: change accepted.

See Also

- **clear radius client system-ip on page 484**
- **set system ip-address on page 65**

set radius proxy client

Adds a RADIUS proxy entry for a third-party AP. The proxy entry specifies the IP address of the AP and the UDP ports on which the WSS listens for RADIUS traffic from the AP.

Syntax `set radius proxy client address ip-address
[acct-port acct-udp-port-number] [port udp-port-number] key string`

address <i>ip-address</i>	IP address of the third-party AP. Enter the address in dotted decimal notation.
port <i>udp-port-number</i>	UDP port on which the WSS listens for RADIUS access-requests from the AP.
acct-port <i>acct-udp-port-number</i>	UDP port on which the WSS listens for RADIUS stop-accounting records from the AP.
key <i>string</i>	Password (shared secret key) the WSS uses to authenticate and encrypt RADIUS communication.

Defaults The default UDP port number for access-requests is 1812. The default UDP port number for stop-accounting records is 1813.

Access Enabled.

History Introduced in WSS Software 4.0.

Usage AAA for third-party AP users has additional configuration requirements. See the “Configuring AAA for Users of Third-Party APs” section in the “Configuring AAA for Network Users” chapter of the [Nortel WLAN 2300 System Software Configuration Guide](#).

Examples The following command configures a RADIUS proxy entry for a third-party AP RADIUS client at 10.20.20.9, sending RADIUS traffic to the default UDP ports 1812 and 1813 on the WSS:

```
WSS# set radius proxy client address 10.20.20.9 key radkey1
success: change accepted.
```

See Also

- [clear radius proxy client on page 485](#)
- [set authentication proxy on page 190](#)
- [set radius proxy port on page 489](#)

set radius proxy port

Configures the WSS port connected to a third-party AP as a RADIUS proxy for the SSID supported by the AP.

Syntax `set radius proxy port port-list [tag tag-value]
ssid ssid-name`

port <i>port-list</i>	WSS port(s) connected to the third-party AP.
------------------------------	--

tag *tag-value* 802.1Q tag value in packets sent by the third-party AP for the SSID.
ssid *ssid-name* SSID supported by the third-party AP.

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.0.

Usage AAA for third-party AP users has additional configuration requirements. See the “Configuring AAA for Users of Third-Party APs” section in the “Configuring AAA for Network Users” chapter of the [Nortel WLAN 2300 System Software Configuration Guide](#).

Enter a separate command for each SSID, and its tag value, you want the WSS to support.

Examples The following command maps SSID *mycorp* to packets received on port 3 or 4, using 802.1Q tag value 104:

```
WSS# set radius proxy port 3-4 tag 104 ssid mycorp
success: change accepted.
```

See Also

- [clear radius proxy port on page 485](#)
- [set authentication proxy on page 190](#)
- [set radius proxy client on page 489](#)

set radius server

Configures RADIUS servers and their parameters. By default, the WSS automatically sets all these values except the password (key).

Syntax `set radius server server-name [address ip-address] [auth-port port-number] [acct-port port-number] [timeout seconds] [retransmit number] [deadtime minutes] [[key string] | [encrypted-key string]] [author-password password]`

server-name	Unique name for this RADIUS server. Enter an alphanumeric string of up to 32 characters, with no blanks.
address ip-address	IP address of the RADIUS server. Enter the address in dotted decimal notation.
auth-port port-number	UDP port that the WSS uses for authentication and authorization.
acct-port port-number	UDP port that the WSS uses for accounting.
timeout seconds	Number of seconds the WSS waits for the RADIUS server to respond before retransmitting. You can specify from 1 to 65,535 seconds.
retransmit number	Number of transmission attempts made before declaring an unresponsive RADIUS server unavailable. You can specify from 1 to 100 retries.

deadtime <i>minutes</i>	Number of minutes the WSS waits after declaring an unresponsive RADIUS server unavailable before retrying that RADIUS server. Specify between 0 (zero) and 1440 minutes (24 hours). A zero value causes the switch to identify unresponsive servers as available.
key <i>string</i> encrypted-key <i>string</i>	<p>Password (shared secret key) the WSS uses to authenticate to RADIUS servers. You must provide the same password that is defined on the RADIUS server. The password can be 1 to 64 characters long, with no spaces or tabs.</p> <ul style="list-style-type: none"> • Use the key option to enter the string in its unencrypted form. WSS Software encrypts the displayed form of the string in show config and show aaa output. • To enter the string in its encrypted form instead, use the encrypted-key option. WSS Software does not encrypt the string you enter, and instead displays the string exactly as you enter it.
author-password <i>password</i>	Password used for authorization to a RADIUS server for MAC authentication. The client's MAC address is sent as the username and the author-password string is sent as the password. Specify a password of up to 64 alphanumeric characters with no spaces or tabs.

Defaults Default values are listed below:

- **auth-port**—UDP port 1812
- **acct-port**—UDP port 1813
- **timeout**—5 seconds
- **retransmit**—3 (the total number of attempts, including the first attempt)
- **deadtime**—0 (zero) minutes (The WSS does not designate unresponsive RADIUS servers as unavailable.)
- **key**—No key
- **encrypted-key**—No key
- **author-password**—nortel

Access Enabled.

History

Version 4.1 **encrypted-key** option added

Usage For a given RADIUS server, the first instance of this command must set both the server name and the IP address and can include any or all of the other optional parameters. Subsequent instances of this command can be used to set optional parameters for a given RADIUS server.

To configure the server as a remote authenticator for the WSS, you must add it to a server group with the **set server group** command.

Do not use the same name for a RADIUS server and a RADIUS server group.

Examples To set a RADIUS server named RS42 with IP address 198.162.1.1 to use the default accounting and authorization ports with a timeout interval of 30 seconds, two transmit attempts, 5 minutes of dead time, a key string of *keys4u*, and the default authorization password of *nortel*, type the following command:

```
23x0# set radius server RS42 address 198.162.1.1 timeout 30 retransmit 2 deadline 5 key
keys4U
```

See Also

- **set authentication admin** on page 182
- **set authentication console** on page 183
- **set authentication dot1x** on page 185
- **set authentication mac** on page 189
- **set authentication web** on page 191
- **set radius** on page 487
- **set server group** on page 492
- **show aaa** on page 210

set server group

Configures a group of one to four RADIUS servers.

Syntax `set server group group-name members server-name1 [server-name2] [server-name3] [server-name4]`

<i>group-name</i>	Server group name of up to 32 characters, with no spaces or tabs.
members <i>server-name1</i> <i>server-name2</i> <i>server-name3</i> <i>server-name4</i>	The names of one or more configured RADIUS servers. You can enter up to four server names.

Defaults None.

Access Enabled.

History Introduced in WSS Software 1.0.

Usage You must assign all group members simultaneously, as shown in the example. To enable load balancing, use **set server group load-balance enable**.

Do not use the same name for a RADIUS server and a RADIUS server group.

Examples To set server group *shorebirds* with members *heron*, *egret*, and *sandpiper*, type the following command:

```
23x0# set server group shorebirds members heron egret sandpiper
success: change accepted.
```

See Also

- **clear server group on page 486**
- **set server group load-balance on page 493**
- **show aaa on page 210**

set server group load-balance

Enables or disables load balancing among the RADIUS servers in a server group.

Syntax `set server group group-name load-balance { enable | disable }`

<i>group-name</i>	Server group name of up to 32 characters.
load-balance enable disable	Enables or disables load balancing of authentication requests among the servers in the group.

Defaults Load balancing is disabled by default.

Access Enabled.

History Introduced in WSS Software 1.0.

Usage You can optionally enable load balancing after assigning the server group members. If you configure load balancing, WSS Software sends each AAA request to a separate server, starting with the first one on the list and skipping unresponsive servers. If no server in the group responds, WSS Software moves to the next method configured with **set authentication** and **set accounting**.

In contrast, if load balancing is *not* configured, WSS Software always begins with the first server in the list and sends unfulfilled requests to each subsequent server in the group before moving on to the next configured AAA method.

Examples To enable load balancing between the members of server group *shorebirds*, type the following command:

```
23x0# set server group shorebirds load-balance enable
success: change accepted.
```

To disable load balancing between *shorebirds* server group members, type the following command:

```
23x0# set server group shorebirds load-balance disable
success: change accepted.
```

See Also

- **clear server group on page 486**
- **clear radius server on page 486**
- **set server group on page 492**
- **show aaa on page 210**

802.1X Management Commands

Use 802.1X management commands to modify the default settings for IEEE 802.1X sessions on a WSS. For best results, change the settings only if you are aware of a problem with the WSS's 802.1X performance.

This chapter presents 802.1X commands alphabetically. Use the following table to locate commands in this chapter based on their use. For information about configuring 802.1X commands for user authentication, see [Chapter , “AAA Commands,” on page 165](#).



Caution! 802.1X parameter settings are global for all SSIDs configured on the switch.

Wired Authentication Port Control	<ul style="list-style-type: none"> set dot1x port-control on page 502 clear dot1x port-control on page 497
Keys	<ul style="list-style-type: none"> set dot1x authcontrol on page 500 set dot1x key-tx on page 501 set dot1x tx-period on page 506 clear dot1x tx-period on page 499 set dot1x wep-rekey on page 506 set dot1x wep-rekey-period on page 507
Bonded Authentication	<ul style="list-style-type: none"> clear dot1x bonded-period on page 496 set dot1x bonded-period on page 500
Reauthentication	<ul style="list-style-type: none"> set dot1x reauth on page 503 set dot1x reauth-max on page 504 clear dot1x reauth-max on page 497 set dot1x reauth-period on page 504 clear dot1x reauth-period on page 498
Retransmission	<ul style="list-style-type: none"> set dot1x max-req on page 501 clear dot1x max-req on page 496
Quiet Period and Timeouts	<ul style="list-style-type: none"> set dot1x quiet-period on page 503 clear dot1x quiet-period on page 497 set dot1x timeout auth-server on page 505 clear dot1x timeout auth-server on page 498

set dot1x timeout supplicant on page 505

clear dot1x timeout supplicant on page 499

Settings, Active Clients, and Statistics **show dot1x on page 507**

clear dot1x bonded-period

Resets the Bonded Auth period to its default value.

Syntax `clear dot1x max-req`

Defaults The default bonded authentication period is 0 seconds.

Access Enabled.

History Introduced in WSS Software Version 2.1.

Usage

Examples To reset the Bonded period to its default, type the following command:

WSS# clear dot1x bonded-period

success: change accepted.

See Also

- **set dot1x bonded-period on page 500**
- **show dot1x on page 507**

clear dot1x max-req

Resets to the default setting the number of Extensible Authentication Protocol (EAP) requests that the WSS retransmits to a supplicant (client).

Syntax `clear dot1x max-req`

Defaults The default number is 20.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples To reset the number of 802.1X requests the WSS can send to the default setting, type the following command:

WSS# clear dot1x max-req

success: change accepted.

See Also

- **set dot1x max-req on page 501**
- **show dot1x on page 507**

clear dot1x port-control

Resets all wired authentication ports on the WSS to default 802.1X authentication.

Syntax `clear dot1x port-control`

Defaults By default, all wired authentication ports are set to **auto** and they process authentication requests as determined by the **set authentication dot1X** command.

Access Enabled.

History Introduced in WSS Software 1.0.

Usage This command is overridden by the **set dot1x authcontrol** command. The **clear dot1x port-control** command returns port control to the method configured. This command applies only to wired authentication ports.

Examples Type the following command to reset the wired authentication port control:

WSS# clear dot1x port-control

success: change accepted.

See Also

- [set dot1x port-control on page 502](#)
- [show dot1x on page 507](#)

clear dot1x quiet-period

Resets the quiet period after a failed authentication to the default setting.

Syntax `clear dot1x quiet-period`

Defaults The default is 60 seconds.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples Type the following command to reset the 802.1X quiet period to the default:

WSS# clear dot1x quiet-period

success: change accepted.

See Also

- [set dot1x quiet-period on page 503](#)
- [show dot1x on page 507](#)

clear dot1x reauth-max

Resets the maximum number of reauthorization attempts to the default setting.

Syntax `clear dot1x reauth-max`

Defaults The default is 2 attempts.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples Type the following command to reset the maximum number of reauthorization attempts to the default:

```
WSS# clear dot1x reauth-max
success: change accepted.
```

See Also

- [set dot1x reauth-max on page 504](#)
- [show dot1x on page 507](#)

clear dot1x reauth-period

Resets the time period that must elapse before a reauthentication attempt, to the default time period.

Syntax `clear dot1x reauth-period`

Defaults The default is 3600 seconds (1 hour).

Access Enabled.

History Introduced in WSS Software 1.0.

Examples Type the following command to reset the default reauthentication time period:

```
WSS# clear dot1x reauth-period
success: change accepted.
```

See Also

- [set dot1x reauth-period on page 504](#)
- [show dot1x on page 507](#)

clear dot1x timeout auth-server

Resets to the default setting the number of seconds that must elapse before the WSS times out a request to a RADIUS server.

Syntax `clear dot1x timeout auth-server`

Defaults The default is 30 seconds.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples To reset the default timeout for requests to an authentication server, type the following command:

```
WSS# clear dot1x timeout auth-server
success: change accepted.
```

See Also

- **set dot1x timeout auth-server on page 505**
- **show dot1x on page 507**

clear dot1x timeout supplicant

Resets to the default setting the number of seconds that must elapse before the WSS times out an authentication session with a supplicant (client).

Syntax `clear dot1x timeout supplicant`

Defaults The default for the authentication timeout sessions is 30 seconds.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples Type the following command to reset the timeout period for an authentication session:

WSS# clear dot1x timeout supplicant
success: change accepted.

See Also

- **set dot1x timeout supplicant on page 505**
- **show dot1x on page 507**

clear dot1x tx-period

Resets to the default setting the number of seconds that must elapse before the WSS retransmits an EAP over LAN (EAPoL) packet.

Syntax `clear dot1x tx-period`

Defaults The default is 5 seconds.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples Type the following command to reset the EAPoL retransmission time:

WSS# clear dot1x tx-period
success: change accepted.

See Also

- **set dot1x tx-period on page 506**
- **show dot1x on page 507**

set dot1x authcontrol

Provides a global override mechanism for 802.1X authentication configuration on wired authentication ports.

Syntax `set dot1x authcontrol {enable | disable}`

enable	Allows all wired authentication ports running 802.1X to use the authentication specified per port by the set dot1x port-control command.
disable	Forces all wired authentication ports running 802.1X to unconditionally accept all 802.1X authentication attempts with an EAP Success message (ForceAuth).

Defaults By default, authentication control for individual wired authentication is enabled.

Access Enabled.

History Introduced in WSS Software 1.0.

Usage This command applies only to wired authentication ports.

Examples To enable per-port 802.1X authentication on wired authentication ports, type the following command:

```
WSS# set dot1x authcontrol enable
success: dot1x authcontrol enabled.
```

See Also

- [set dot1x port-control on page 502](#)
- [show dot1x on page 507](#)

set dot1x bonded-period

Changes the Bonded Auth™ (bonded authentication) period. The *Bonded Auth period* is the number of seconds WSS Software allows a Bonded Auth user to reauthenticate.

Syntax `set dot1x bonded-period seconds`

<i>seconds</i>	Number of seconds WSS Software retains session information for an authenticated machine while waiting for a client to (re)authenticate on the same machine. You can change the bonded authentication period to a value from 1 to 300 seconds.
----------------	---

Defaults The default bonded period is 0 seconds, which disables the feature.

Access Enabled.

History Introduced in WSS Software 2.1.

Usage Normally, the Bonded Auth period needs to be set only if the network has Bonded Auth clients that use dynamic WEP, or use WEP-40 or WEP-104 encryption with WPA or RSN. These clients can be affected by the 802.1X reauthentication parameter or the RADIUS Session-Timeout parameter.

Nortel recommends that you try 60 seconds, and change the period to a longer value only if clients are unable to authenticate within 60 seconds.

The bonded authentication period applies only to 802.1X authentication rules that contain the **bonded** option.

Examples To set the bonded authentication period to 60 seconds, type the following command:

```
WSS# set dot1x bonded-period 60
success: change accepted.
```

See Also

- **clear dot1x bonded-period on page 496**
- **show dot1x on page 507**

set dot1x key-tx

Enables or disables the transmission of encryption key information to the supplicant (client) in EAP over LAN (EAPoL) key messages, after authentication is successful.

Syntax `set dot1x key-tx {enable | disable}`

enable	Enables transmission of encryption key information to clients.
disable	Disables transmission of encryption key information to clients.

Defaults Key transmission is enabled by default.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples Type the following command to enable key transmission:

```
WSS# set dot1x key-tx enable
success: dot1x key transmission enabled.
```

See Also **show dot1x on page 507**

set dot1x max-req

Sets the maximum number of times the WSS retransmits an EAP request to a supplicant (client) before ending the authentication session.

Syntax `set dot1x max-req number-of-retransmissions`

number-of-retransmissions Specify a value between 0 and 10.

Defaults The default number of EAP retransmissions is 2.

Access Enabled.

History Introduced in WSS Software 1.0.

Usage To support SSIDs that have both 802.1X and static WEP clients, WSS Software sends a maximum of two ID requests, even if this parameter is set to a higher value. Setting the parameter to a higher value does affect all other types of EAP messages.

Examples Type the following command to set the maximum number of EAP request retransmissions to three attempts:

```
WSS# set dot1x max-req 3
success: dot1x max request set to 3.
```

See Also

- [clear dot1x max-req on page 496](#)
- [show dot1x on page 507](#)

set dot1x port-control

Determines the 802.1X authentication behavior on individual wired authentication ports or groups of ports.

Syntax `set dot1x port-control { forceauth | forceunauth | auto } port-list`

forceauth	Forces the specified wired authentication port(s) to <i>unconditionally authorize</i> all 802.1X authentication attempts, with an EAP success message.
forceunauth	Forces the specified wired authentication port(s) to <i>unconditionally reject</i> all 802.1X authentication attempts with an EAP failure message.
auto	Allows the specified wired authentication ports to process 802.1X authentication normally as determined for the user by the set authentication dot1X command.
<i>port-list</i>	One or more wired authentication ports for which to set 802.1X port control.

Defaults By default, wired authentication ports are set to **auto**.

Access Enabled.

History Introduced in WSS Software 1.0.

Usage This command affects only wired authentication ports.

Examples The following command forces port 19 to unconditionally accept all 802.1X authentication attempts:

```
WSS# set dot1x port-control forceauth 19
success: authcontrol for 19 is set to FORCE-AUTH.
```

See Also

- [show port status on page 51](#)
- [show dot1x on page 507](#)

set dot1x quiet-period

Sets the number of seconds a WSS remains quiet and does not respond to a supplicant after a failed authentication.

Syntax `set dot1x quiet-period seconds`

seconds Specify a value between 0 and 65,535.

Defaults The default is 60 seconds.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples Type the following command to set the quiet period to 90 seconds:

WSS# set dot1x quiet-period 90
success: dot1x quiet period set to 90.

See Also

- `clear dot1x quiet-period` on page 497
- `show dot1x` on page 507

set dot1x reauth

Determines whether the WSS allows the reauthentication of supplicants (clients).

Syntax `set dot1x reauth {enable | disable}`

enable Permits reauthentication.

disable Denies reauthentication.

Defaults Reauthentication is enabled by default.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples Type the following command to enable reauthentication of supplicants (clients):

WSS# set dot1x reauth enable
success: dot1x reauthentication enabled.

See Also

- `set dot1x reauth-max` on page 504
- `set dot1x reauth-period` on page 504
- `show dot1x` on page 507

set dot1x reauth-max

Sets the number of reauthentication attempts that the WSS makes before the supplicant (client) becomes unauthorized.

Syntax `set dot1x reauth-max number-of-attempts`

number-of-attempts Specify a value between 1 and 10.

Defaults The default number of reauthentication attempts is 2.

Access Enabled.

History Introduced in WSS Software 1.0.

Usage If the number of reauthentications for a wired authentication client is greater than the maximum number of reauthentications allowed, WSS Software sends an EAP failure packet to the client and removes the client from the network. However, WSS Software does not remove a wireless client from the network under these circumstances.

Examples Type the following command to set the number of authentication attempts to 8:

WSS# set dot1x reauth-max 8

success: dot1x max reauth set to 8.

See Also

- [clear dot1x reauth-max on page 497](#)
- [show dot1x on page 507](#)

set dot1x reauth-period

Sets the number of seconds that must elapse before the WSS attempts reauthentication.

Syntax `set dot1x reauth-period seconds`

seconds Specify a value between 60 (1 minute) and 1,641,600 (19 days).

Defaults The default is 3600 seconds (1 hour).

Access Enabled.

Usage You also can use the RADIUS session-timeout attribute to set the reauthentication timeout for a specific client. In this case, WSS Software uses the timeout that has the lower value. If the session-timeout is set to fewer seconds than the global reauthentication timeout, WSS Software uses the session-timeout for the client. However, if the global reauthentication timeout is shorter than the session-timeout, WSS Software uses the global timeout instead.

Examples Type the following command to set the number of seconds to 100 before reauthentication is attempted:

WSS# set dot1x reauth-period 100

success: dot1x auth-server timeout set to 100.

See Also

- **clear dot1x reauth-period on page 498**
- **show dot1x on page 507**

set dot1x timeout auth-server

Sets the number of seconds that must elapse before the WSS times out a request to a RADIUS authentication server.

Syntax `set dot1x timeout auth-server seconds`

seconds Specify a value between 1 and 65,535.

Defaults The default is 30 seconds.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples Type the following command to set the authentication server timeout to 60 seconds:

```
WSS# set dot1x timeout auth-server 60
success: dot1x auth-server timeout set to 60.
```

See Also

- **clear dot1x timeout auth-server on page 498**
- **show dot1x on page 507**

set dot1x timeout supplicant

Sets the number of seconds that must elapse before the WSS times out an authentication session with a supplicant (client).

Syntax `set dot1x timeout supplicant seconds`

seconds Specify a value between 1 and 65,535.

Defaults The default is 30 seconds.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples Type the following command to set the number of seconds for authentication session timeout to 300:

```
WSS# set dot1x timeout supplicant 300
success: dot1x supplicant timeout set to 300.
```

See Also

- **clear dot1x timeout auth-server on page 498**
- **show dot1x on page 507**

set dot1x tx-period

Sets the number of seconds that must elapse before the WSS retransmits an EAPoL packet.

Syntax `set dot1x tx-period seconds`

seconds Specify a value between 1 and 65,535.

Defaults The default is 5 seconds.

Access Enabled.

History Introduced in WSS Software 1.0.

Examples Type the following command to set the number of seconds before the WSS retransmits an EAPoL packet to 300:

```
WSS# set dot1x tx-period 300
success: dot1x tx-period set to 300.
```

See Also

- **clear dot1x tx-period on page 499**
- **show dot1x on page 507**

set dot1x wep-rekey

Enables or disables Wired Equivalency Privacy (WEP) rekeying for broadcast and multicast encryption keys.

Syntax `set dot1x wep-rekey {enable | disable}`

enable Causes the broadcast and multicast keys for WEP to be rotated at an interval set by the **set dot1x wep-rekey-period** for each radio, associated VLAN, and encryption type. The WSS generates the new broadcast and multicast keys and pushes the keys to the clients via EAPoL key messages.

disable WEP broadcast and multicast keys are never rotated.

Defaults WEP key rotation is enabled, by default.

Access Enabled.

History Introduced in WSS Software 1.0.

Usage Reauthentication is *not* required for WEP key rotation to take place. Broadcast and multicast keys are always rotated at the same time, so all members of a given radio, VLAN, or encryption type receive the new keys at the same time.

Examples Type the following command to disable WEP key rotation:

```
WSS# set dot1x wep-rekey disable
success: wep rekeying disabled
```

See Also

- [set dot1x wep-rekey-period on page 507](#)
- [show dot1x on page 507](#)

set dot1x wep-rekey-period

Sets the interval for rotating the WEP broadcast and multicast keys.

Syntax `set dot1x wep-rekey-period seconds`

seconds Specify a value between 30 and 1,641,600 (19 days).

Defaults The default is 1800 seconds (30 minutes).

Access Enabled.

Examples Type the following command to set the WEP-rekey period to 300 seconds:

```
WSS# set dot1x wep-rekey-period 300
success: dot1x wep-rekey-period set to 300
```

See Also

- [set dot1x wep-rekey on page 506](#)
- [show dot1x on page 507](#)

show dot1x

Displays 802.1X client information for statistics and configuration settings.

Syntax `show dot1x {clients | stats | config}`

clients Displays information about active 802.1X clients, including client name, MAC address, and state.

stats Displays global 802.1X statistics associated with connecting and authenticating.

config Displays a summary of the current configuration.

Defaults None.

Access Enabled.

Examples Type the following command to display the 802.1X clients:

WSS# show dot1x clients

MAC Address	State	Vlan	Identity
00:20:a6:48:01:1f	Connecting	(unknown)	
00:05:3c:07:6d:7c	Authenticated	vlan-it	EXAMPLE\jose
00:05:5d:7e:94:83	Authenticated	vlan-eng	EXAMPLE\singh
00:02:2d:86:bd:38	Authenticated	vlan-eng	bard@xmples.com
00:05:5d:7e:97:b4	Authenticated	vlan-eng	EXAMPLE\havel
00:05:5d:7e:98:1a	Authenticated	vlan-eng	EXAMPLE\nash
00:0b:be:a9:dc:4e	Authenticated	vlan-pm	xalik@xmples.com
00:05:5d:7e:96:e3	Authenticated	vlan-eng	EXAMPLE\mishan
00:02:2d:6f:44:77	Authenticated	vlan-eng	EXAMPLE\ethan
00:05:5d:7e:94:89	Authenticated	vlan-eng	EXAMPLE\fmarsall
00:06:80:00:5c:02	Authenticated	vlan-eng	EXAMPLE\bmccarthy
00:02:2d:6a:de:f2	Authenticated	vlan-pm	neailey@xmples.com
00:02:2d:5e:5b:76	Authenticated	vlan-pm	EXAMPLE\tamara
00:02:2d:80:b6:e1	Authenticated	vlan-cs	dmc@xmples.com
00:30:65:16:8d:69	Authenticated	vlan-wep	MAC authenticated
00:02:2d:64:8e:1b	Authenticated	vlan-eng	EXAMPLE\wong

Type the following command to display the 802.1X configuration:

WSS# show dot1x config

802.1X user policy

'host/bob-laptop.mycorp.com' on ssid 'mycorp' doing PASSTHRU
'bob.mycorp.com' on ssid 'mycorp' doing PASSTHRU (bonded)

802.1X parameter	setting
-----	-----
supplicant timeout	30
auth-server timeout	30
quiet period	5
transmit period	5
reauthentication period	3600
maximum requests	2
key transmission	enabled
reauthentication	enabled
authentication control	enabled
WEP rekey period	1800
WEP rekey	enabled
Bonded period	60

port 5, authcontrol: auto, max-sessions: 16
port 6, authcontrol: auto, max-sessions: 1
port 7, authcontrol: auto, max-sessions: 1
port 8, authcontrol: auto, max-sessions: 1
port 9, authcontrol: auto, max-sessions: 1

```

port 10, authcontrol: auto, max-sessions: 1
port 11, authcontrol: auto, max-sessions: 1
port 12, authcontrol: auto, max-sessions: 1
port 13, authcontrol: auto, max-sessions: 1
port 14, authcontrol: auto, max-sessions: 1
port 15, authcontrol: auto, max-sessions: 1
port 16, authcontrol: auto, max-sessions: 1
port 22, authcontrol: auto, max-sessions: 16

```

Type the following command to display 802.1X statistics:

WSS# show dot1x stats

```

802.1X statistic          value
-----
Enters Connecting:        709
Logoffs While Connecting: 112
Enters Authenticating:    467
Success While Authenticating: 0
Timeouts While Authenticating: 52
Failures While Authenticating: 0
Reauths While Authenticating: 0
Starts While Authenticating: 31
Logoffs While Authenticating: 0
Starts While Authenticated: 85
Logoffs While Authenticated: 1
Bad Packets Received:     0

```

Table 76 explains the counters in the **show dot1x stats** output.

Table 1: show dot1x stats Output

Field	Description
Enters Connecting	Number of times that the WSS state transitions to the CONNECTING state from any other state.
Logoffs While Connecting	Number of times that the WSS state transitions from CONNECTING to DISCONNECTED as a result of receiving an EAPoL-Logoff message.
Enters Authenticating	Number of times that the state wildcard transitions.
Success While Authenticating	Number of times the WSS state transitions from AUTHENTICATING from AUTHENTICATED, as a result of an EAP-Response/Identity message being received from the supplicant (client).
Timeouts While Authenticating	Number of times that the WSS state wildcard transitions from AUTHENTICATING to ABORTING.
Failures While Authenticating	Number of times that the WSS state wildcard transitions from AUTHENTICATION to HELD.

Table 1: show dot1x stats Output (continued)

Field	Description
Reauths While Authenticating	Number of times that the WSS state wildcard transitions from AUTHENTICATING to ABORTING, as a result of a reauthentication request (reAuthenticate = TRUE).
Starts While Authenticating	Number of times that the WSS state wildcard transitions from AUTHENTICATING to ABORTING, as a result of an EAPoL-Start message being received from the Supplicant (client).
Logoffs While Authenticating	Number of times that the WSS state wildcard transitions from AUTHENTICATING to ABORTING, as a result of an EAPoL-logoff message being received from the Supplicant (client).
Bad Packets Received	Number of EAPoL packets received that have an invalid version or type.

RF Detection Commands

WSS Software automatically performs RF detection scans on enabled and disabled radios to detect rogue access points. A rogue access point is a BSSID (MAC address associated with an SSID) that does not belong to a Nortel device and is not a member of the ignore list configured on the seed switch of the Mobility Domain.

WSS Software can issue countermeasures against rogue devices to prevent clients from being able to use them.

You can configure RF detection parameters on individual WSSs.

This chapter presents RF detection commands alphabetically. Use the following table to locate the commands in this chapter based on their use.

Rogue Information	<ul style="list-style-type: none"> show rfdetect clients on page 520 show rfdetect mobility-domain on page 526 show rfdetect data on page 524 show rfdetect visible on page 531 show rfdetect counters on page 523
Countermeasures	<ul style="list-style-type: none"> show rfdetect countermeasures on page 522
Permitted Vendor List	<ul style="list-style-type: none"> set rfdetect vendor-list on page 518 show rfdetect vendor-list on page 531 clear rfdetect vendor-list on page 514
Permitted SSID List	<ul style="list-style-type: none"> set rfdetect ssid-list on page 517 show rfdetect ssid-list on page 530 clear rfdetect ssid-list on page 513
Client Black List	<ul style="list-style-type: none"> set rfdetect black-list on page 515 show rfdetect black-list on page 519 clear rfdetect black-list on page 512
Attack List	<ul style="list-style-type: none"> set rfdetect attack-list on page 514 show rfdetect attack-list on page 519 clear rfdetect attack-list on page 512
Ignore List	<ul style="list-style-type: none"> set rfdetect ignore on page 515 show rfdetect ignore on page 526 clear rfdetect ignore on page 513
AP Signatures	<ul style="list-style-type: none"> set rfdetect signature on page 517
Log Messages	<ul style="list-style-type: none"> set rfdetect log on page 516
WSS-to-Client RF Link	<ul style="list-style-type: none"> rfping on page 533

clear rfdetect attack-list

Removes a MAC address from the attack list.

Syntax `clear rfdetect attack-list mac-addr`

mac-addr MAC address you want to remove from the attack list.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command clears MAC address 11:22:33:44:55:66 from the attack list:

WSS# clear rfdetect attack-list 11:22:33:44:55:66
success: 11:22:33:44:55:66 is no longer in attacklist.

See Also

- [set rfdetect attack-list on page 514](#)
- [show rfdetect attack-list on page 519](#)

clear rfdetect black-list

Removes a MAC address from the client black list.

Syntax `clear rfdetect black-list mac-addr`

mac-addr MAC address you want to remove from the black list.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command removes MAC address 11:22:33:44:55:66 from the black list:

WSS# clear rfdetect black-list 11:22:33:44:55:66
success: 11:22:33:44:55:66 is no longer blacklisted.

See Also

- [set rfdetect black-list on page 515](#)
- [show rfdetect black-list on page 519](#)

clear rfdetect ignore

Removes a device from the ignore list for RF scans. WSS Software does not generate log messages or traps for the devices in the ignore list.

Syntax `clear rfdetect ignore mac-addr`

mac-addr Basic service set identifier (BSSID), which is a MAC address, of the device to remove from the ignore list.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Examples The following command removes BSSID *aa:bb:cc:11:22:33* from the ignore list for RF scans:

```
23x0# clear rfdetect ignore aa:bb:cc:11:22:33  
success: aa:bb:cc:11:22:33 is no longer ignored.
```

See Also

- [set rfdetect ignore on page 515](#)
- [show rfdetect ignore on page 526](#)

clear rfdetect ssid-list

Removes an SSID from the permitted SSID list.

Syntax `clear rfdetect ssid-list ssid-name`

ssid-name SSID name you want to remove from the permitted SSID list.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command clears SSID *mycorp* from the permitted SSID list:

```
WSS# clear rfdetect ssid-list mycorp  
success: mycorp is no longer in ssid-list.
```

See Also

- [set rfdetect ssid-list on page 517](#)
- [show rfdetect ssid-list on page 530](#)

clear rfdetect vendor-list

Removes an entry from the permitted vendor list.

Syntax `clear rfdetect vendor-list { client | ap } mac-addr | all`

client | ap Specifies whether the entry is for an AP brand or a client brand.

mac-addr | all Organizationally Unique Identifier (OUI) to remove.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command removes client OUI aa:bb:cc:00:00:00 from the permitted vendor list:

WSS# `clear rfdetect vendor-list client aa:bb:cc:00:00:00`
success: aa:bb:cc:00:00:00 is no longer in client vendor-list.

See Also

- [set rfdetect vendor-list on page 518](#)
- [show rfdetect vendor-list on page 531](#)

set rfdetect attack-list

Adds an entry to the attack list. The attack list specifies the MAC addresses of devices that WSS Software should issue countermeasures against whenever the devices are detected on the network. The attack list can contain the MAC addresses of APs and clients.

Syntax `set rfdetect attack-list mac-addr`

mac-addr MAC address you want to attack.

Defaults The attack list is empty by default.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage The attack list applies only to the WSS on which the list is configured. WSSs do not share attack lists.

When on-demand countermeasures are enabled (with the **set radio-profile countermeasures configured** command) only those devices configured in the attack list are subject to countermeasures. In this case, devices found to be rogues by other means, such as policy violations or by determining that the device is providing connectivity to the wired network, are not attacked.

Examples The following command adds MAC address aa:bb:cc:44:55:66 to the attack list:

```
WSS# set rfdetect attack-list 11:22:33:44:55:66
success: MAC 11:22:33:44:55:66 is now in attacklist.
```

See Also

- **clear rfdetect attack-list on page 512**
- **show rfdetect attack-list on page 519**
- **set radio-profile countermeasures on page 287**

set rfdetect black-list

Adds an entry to the client black list. The client black list specifies clients that are not allowed on the network. WSS Software drops all packets from the clients on the black list.

Syntax `set rfdetect black-list mac-addr`

mac-addr MAC address you want to place on the black list.

Defaults The client black list is empty by default.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage In addition to manually configured entries, the list can contain entries added by WSS Software. WSS Software can place a client in the black list due to an association, reassociation or disassociation flood from the client.

The client black list applies only to the WSS on which the list is configured. WSSs do not share client black lists.

Examples The following command adds client MAC address 11:22:33:44:55:66 to the black list:

```
WSS# set rfdetect black-list 11:22:33:44:55:66
success: MAC 11:22:33:44:55:66 is now blacklisted.
```

See Also

- **set rfdetect black-list on page 515**
- **show rfdetect black-list on page 519**

set rfdetect ignore

Configures a list of known devices to ignore during an RF scan. WSS Software does not generate log messages or traps for the devices in the ignore list.

Syntax `set rfdetect ignore mac-addr`

mac-addr BSSID (MAC address) of the device to ignore.

Defaults WSS Software reports all non-Nortel BSSIDs detected during an RF scan.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage Use this command to identify third-party APs and other devices you are already aware of and do not want WSS Software to report following RF scans.

If you try to initiate countermeasures against a device on the ignore list, the ignore list takes precedence and WSS Software does not issue the countermeasures. Countermeasures apply only to rogue devices.

If you add a device that WSS Software has classified as a rogue to the permitted vendor list or permitted SSID list, but not to the ignore list, WSS Software can still classify the device as a rogue. Adding an entry to the permitted vendor list or permitted SSID list merely indicates that the device is from an allowed manufacturer or is using an allowed SSID. However, to cause WSS Software to stop classifying the device as a rogue, you must add the device's MAC address to the ignore list.

Examples The following command configures WSS Software to ignore BSSID *aa:bb:cc:11:22:33* during RF scans:

```
23x0# set rfdetect ignore aa:bb:cc:11:22:33
```

success: MAC aa:bb:cc:11:22:33 is now ignored.

See Also

- **clear rfdetect ignore on page 513**
- **show rfdetect ignore on page 526**

set rfdetect log

Disables or reenables generation of log messages when rogues are detected or when they disappear.

Syntax `set rfdetect log {enable | disable}`

enable Enables logging of rogues.

disable Disables logging of rogues.

Defaults RF detection logging is enabled by default.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage The log messages for rogues are generated only on the seed and appear only in the seed's log message buffer. Use the **show log buffer** command to display the messages in the seed switch's log message buffer.

Examples The following command enables RF detection logging for the Mobility Domain managed by this seed switch:

```
23x0# set rfdetect log enable
```

success: rfdetect logging is enabled.

See Also [show log buffer on page 579](#)

set rfdetect signature

Enables AP signatures. An AP signature is a set of bits in a management frame sent by an AP that identifies that AP to WSS Software. If someone attempts to spoof management packets from a Nortel AP, WSS Software can detect the spoof attempt.

Syntax `set rfdetect signature {enable | disable}`

enable Enables AP signatures.

disable Disables AP signatures.

Defaults AP signatures are disabled by default.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage The command applies only to APs managed by the WSS on which you enter the command. To enable signatures on all APs in a Mobility Domain, enter the command on each WSS in the Mobility Domain.



Note. You must use the same AP signature setting (enabled or disabled) on all WSSs in a Mobility Domain.

Examples The following command enables AP signatures on a WSS:

```
23x0# set rfdetect signature enable
```

```
success: signature is now enabled.
```

set rfdetect ssid-list

Adds an SSID to the permitted SSID list. The permitted SSID list specifies the SSIDs that are allowed on the network. If WSS Software detects packets for an SSID that is not on the list, the AP that sent the packets is classified as a rogue. WSS Software issues countermeasures against the rogue if they are enabled.

Syntax `set rfdetect ssid-list ssid-name`

ssid-name SSID name you want to add to the permitted SSID list.

Defaults The permitted SSID list is empty by default and all SSIDs are allowed. However, after you add an entry to the list, WSS Software allows traffic only for the SSIDs that are on the list.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage The permitted SSID list applies only to the WSS on which the list is configured. WSSs do not share permitted SSID lists.

If you add a device that WSS Software has classified as a rogue to the permitted SSID list, but not to the ignore list, WSS Software can still classify the device as a rogue. Adding an entry to the permitted SSID list merely indicates that the device is using an allowed SSID. However, to cause WSS Software to stop classifying the device as a rogue, you must add the device's MAC address to the ignore list.

Examples The following command adds SSID *mycorp* to the list of permitted SSIDs:

```
WSS# set rfdetect ssid-list mycorp
success: ssid mycorp is now in ssid-list.
```

See Also

- **clear rfdetect ssid-list on page 513**
- **show rfdetect ssid-list on page 530**

set rfdetect vendor-list

Adds an entry to the permitted vendor list. The permitted vendor list specifies the third-party AP or client vendors that are allowed on the network. WSS Software does not list a device as a rogue or interfering device if the device's OUI is in the permitted vendor list.

Syntax `set rfdetect vendor-list {client | ap} mac-addr`

client | ap Specifies whether the entry is for an AP brand or a client brand.

mac-addr | all Organizationally Unique Identifier (OUI) to remove.

Defaults The permitted vendor list is empty by default and all vendors are allowed. However, after you add an entry to the list, WSS Software allows only the devices whose OUIs are on the list.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage The permitted vendor list applies only to the WSS on which the list is configured. WSSs do not share permitted vendor lists.

If you add a device that WSS Software has classified as a rogue to the permitted vendor list, but not to the ignore list, WSS Software can still classify the device as a rogue. Adding an entry to the permitted vendor list merely indicates that the device is from an allowed vendor. However, to cause WSS Software to stop classifying the device as a rogue, you must add the device's MAC address to the ignore list.

Examples The following command adds an entry for clients whose MAC addresses start with aa:bb:cc:

```
WSS# set rfdetect vendor-list client aa:bb:cc:00:00:00
success: MAC aa:bb:cc:00:00:00 is now in client vendor-list.
```

The trailing 00:00:00 value is required.

See Also

- **clear rfdetect vendor-list on page 514**
- **show rfdetect vendor-list on page 531**

show rfdetect attack-list

Displays information about the MAC addresses in the attack list.

Syntax `show rfdetect attack-list`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following example shows the attack list on a WSS:

WSS# show rfdetect attack-list

Total number of entries: 1

Attacklist MAC	Port/Radio/Chan	RSSI	SSID
11:22:33:44:55:66	ap 2/1/11	-53	rogue-ssid

See Also

- **clear rfdetect attack-list on page 512**
- **set rfdetect attack-list on page 514**

show rfdetect black-list

Displays information about the clients in the client black list.

Syntax `show rfdetect black-list`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following example shows the client black list on a WSS:

WSS# show rfdetect black-list

Total number of entries: 1

Blacklist MAC	Type	Port	TTL
11:22:33:44:55:66	configured	-	-
11:23:34:45:56:67	assoc req flood	3	25

See Also

- **clear rfdetect black-list on page 512**

- [set rfdetect black-list on page 515](#)

show rfdetect clients

Displays the wireless clients detected by a WSS.

Syntax `show rfdetect clients [mac mac-addr]`

mac mac-addr Displays detailed information for a specific client.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command shows information about all wireless clients detected by a WSS's APs:

WSS# show rfdetect clients

Total number of entries: 30

Client MAC	Client Vendor	AP MAC	AP Vendor	Port/Radio /Channel	NoL	Type	Last seen
00:03:7f:bf:16:70	Unknown	Unknown		ap 1/1/6	1	intfr	207
00:04:23:77:e6:e5	Intel	Unknown		ap 1/1/2	1	intfr	155
00:05:5d:79:ce:0f	D-Link	Unknown		ap 1/1/149	1	intfr	87
00:05:5d:7e:96:a7	D-Link	Unknown		ap 1/1/149	1	intfr	117
00:05:5d:7e:96:ce	D-Link	Unknown		ap 1/1/157	1	intfr	162
00:05:5d:84:d1:c5	D-Link	Unknown		ap 1/1/1	1	intfr	52

The following command displays more details about a specific client:

WSS# show rfdetect clients mac 00:0c:41:63:fd:6d

Client Mac Address: 00:0c:41:63:fd:6d, Vendor: Linksys

Port: ap 1, Radio: 1, Channel: 11, RSSI: -82, Rate: 2, Last Seen (secs ago): 84

Bssid: 00:0b:0e:01:02:00, Vendor: Nortel, Type: intfr, Dst: ff:ff:ff:ff:ff:ff

Last Rogue Status Check (secs ago): 3

The first line lists information for the client. The other lines list information about the most recent 802.11 packet detected from the client.

[Table 77](#) and [Table 78](#) describe the fields in these displays.

Table 1: show rfdetect clients Output

Field	Description
Client MAC	MAC address of the client.
Client Vendor	Company that manufactures or sells the client.
AP MAC	MAC address of the radio with which the rogue client is associated.

Table 1: show rfdetect clients Output (continued)

Field	Description
AP Vendor	Company that manufactures or sells the AP with which the rogue client is associated.
Port/Radio/Channel	Port number, radio number, and channel number of the radio that detected the rogue. For a AP, the connection number is labeled <i>ap</i> . (This stands for <i>ap</i> .)
NoL	Number of listeners. This is the number of AP radios that detected the rogue client.
Type	Classification of the rogue device: <ul style="list-style-type: none"> • rogue—Wireless device that is on the network but is not supposed to be on the network. • intfr—Wireless device that is not part of your network and is not a rogue, but might be causing RF interference with AP radios. • known—Device that is a legitimate member of the network.
Last seen	Number of seconds since an AP radio last detected 802.11 packets from the device.

Table 2: show rfdetect clients mac Output

Field	Description
RSSI	Received signal strength indication (RSSI)—the strength of the RF signal detected by the AP radio, in decibels referred to 1 milliwatt (dBm).
Rate	The data rate of the client.
Last Seen	Number of seconds since an AP radio last detected 802.11 packets from the device.
BSSID	MAC address of the SSID with which the rogue client is associated.
Vendor	Company that manufactures or sells the AP with which the rogue client is associated.

Table 2: show rfdetect clients mac Output (continued)

Field	Description
Typ	Classification of the rogue device: <ul style="list-style-type: none"> rogue—Wireless device that is on the network but is not supposed to be on the network. intfr—Wireless device that is not part of your network and is not a rogue, but might be causing RF interference with AP radios. known—Device that is a legitimate member of the network.
Dst	MAC addressed to which the last 802.11 packet detected from the client was addressed.
Last Rogue Status Check	Number of seconds since the WSS looked on the air for the AP with which the rogue client is associated. The switch looks for the client's AP by sending a packet from the wired side of the network addressed to the client, and watching the air for a wireless packet containing the client's MAC address.

show rfdetect countermeasures

Displays the current status of countermeasures against rogues in the Mobility Domain.

Syntax `show rfdetect countermeasures`

Defaults None.

Access Enabled.

History

Version 4.0 Output no longer lists rogues for which countermeasures have not been started.

Usage This command is valid only on the seed switch of the Mobility Domain.

Examples The following example displays countermeasures status for the Mobility Domain:

WSS# show rfdetect countermeasures

Total number of entries: 190

Rogue MAC	Type	Countermeasures Radio Mac	WSS-IPaddr	Port/Radio /Channel
00:0b:0e:00:71:c0	intfr	00:0b:0e:44:55:66	10.1.1.23	ap 4/1/6
00:0b:0e:03:00:80	rogue	00:0b:0e:11:22:33	10.1.1.23	ap 2/1/11

[Table 79](#) describes the fields in this display.

Table 3: show rfdetect countermeasures Output

Field	Description
Rogue MAC	BSSID of the rogue.
Type	Classification of the rogue device: <ul style="list-style-type: none"> • rogue—Wireless device that is on the network but is not supposed to be on the network. • intfr—Wireless device that is not part of your network and is not a rogue, but might be causing RF interference with AP radios. • known—Device that is a legitimate member of the network.
Countermeasures Radio MAC	MAC address of the Nortel radio sending countermeasures against the rogue.
WSS-IPaddr	System IP address of the WSS that is managing the AP that is sending or will send countermeasures.
Port/Radio/Channel	Port number, radio number, and channel number of the countermeasures radio. For a AP, the connection number is labeled <i>ap</i> . (This stands for <i>ap</i> .)

See Also [set radio-profile countermeasures on page 287](#)

show rfdetect counters

Displays statistics for rogue and Intrusion Detection System (IDS) activity detected by the APs managed by a WSS.

Syntax `show rfdetect counters`

Defaults None.

Access Enabled.

History Introduced in WSS Software 4.0.

Examples The following command shows counters for rogue activity detected by a WSS:

WSS# show rfdetect counters

Type	Current	Total
Rogue access points	0	0
Interfering access points	139	1116
Rogue 802.11 clients	0	0
Interfering 802.11 clients	4	347
802.11 adhoc clients	0	1
Unknown 802.11 clients	20	965
Interfering 802.11 clients seen on wired network	0	0

802.11 probe request flood	0	0
802.11 authentication flood	0	0
802.11 null data flood	0	0
802.11 mgmt type 6 flood	0	0
802.11 mgmt type 7 flood	0	0
802.11 mgmt type d flood	0	0
802.11 mgmt type e flood	0	0
802.11 mgmt type f flood	0	0
802.11 association flood	0	0
802.11 reassociation flood	0	0
802.11 disassociation flood	0	0
Weak wep initialization vectors	0	0
Spoofed access point mac-address attacks	0	0
Spoofed client mac-address attacks	0	0
Ssid masquerade attacks	1	12
Spoofed deauthentication attacks	0	0
Spoofed disassociation attacks	0	0
Null probe responses	626	11380
Broadcast deauthentications	0	0
FakeAP ssid attacks	0	0
FakeAP bssid attacks	0	0
Netstumbler clients	0	0
Wellenreiter clients	0	0
Active scans	1796	4383
Wireless bridge frames	196	196
Adhoc client frames	8	0
Access points present in attack-list	0	0
Access points not present in ssid-list	0	0
Access points not present in vendor-list	0	0
Clients not present in vendor-list	0	0
Clients added to automatic black-list	0	0

show rfdetect data

Displays information about the APs detected by a WSS.

Syntax `show rfdetect data`

Defaults None.

Access Enabled.

History

Version 4.0 Vendor, Type, and Flags fields added.

Usage You can enter this command on any WSS in the Mobility Domain. The output applies only to the switch on which you enter the command. To display all devices that a specific Nortel radio has detected, even if the radio is managed by another WSS, use the `show rfdetect visible` command.

To display rogue information for the entire Mobility Domain, use the `show rfdetect mobility-domain` command on the seed switch.

Only one MAC address is listed for each Nortel radio, even if the radio is beaconing multiple SSIDs.

Examples The following command shows the devices detected by this WSS during the most recent RF detection scan:

WSS# show rfdetect data

Total number of entries: 197

Flags: i = infrastructure, a = ad-hoc

c = CCMP, t = TKIP, 1 = 104-bit WEP, 4 = 40-bit WEP, w = WEP(non-WPA)

BSSID Vendor Type Port/Radio/Ch Flags RSSI Age SSID

```

-----
00:07:50:d5:cc:91 Cisco intf 3/1/6 i---w -61 6 r27-cisco1200-2
00:07:50:d5:dc:78 Cisco intf 3/1/6 i---w -82 6 r116-cisco1200-2
00:09:b7:7b:8a:54 Cisco intf 3/1/2 i----- -57 6
00:0a:5e:4b:4a:c0 3Com intf 3/1/11 i----- -57 6 public
00:0a:5e:4b:4a:c2 3Com intf 3/1/11 i-t1-- -86 6 nortelwlan
00:0a:5e:4b:4a:c4 3Com intf 3/1/11 ic---- -85 6 nrtl-ccmp
00:0a:5e:4b:4a:c6 3Com intf 3/1/11 i-t--- -85 6 nrtl-tkip
00:0a:5e:4b:4a:c8 3Com intf 3/1/11 i---w -83 6 nrtl-voip
00:0a:5e:4b:4a:ca 3Com intf 3/1/11 i----- -85 6 nrtl-webaaa
...

```

Table 80 describes the fields in this display.

Table 4: show rfdetect data Output

Field	Description
BSSID	MAC address of the SSID used by the detected device.
Vendor	Company that manufactures or sells the rogue device.
Type	Classification of the rogue device: <ul style="list-style-type: none"> rogue—Wireless device that is not supposed to be on the network. The device has an entry in a WSS's FDB and is therefore on the network. intfr—Wireless device that is not part of your network but is not a rogue. The device does not have an entry in a WSS's FDB and is not actually on the network, but might be causing RF interference with AP radios. known—Device that is a legitimate member of the network.
Port/Radio/Channel	Port number, radio number, and channel number of the radio that detected the rogue. For a AP, the connection number is labeled <i>ap</i> . (This stands for <i>ap</i> .)
Flags	Classification and encryption information for the rogue: <ul style="list-style-type: none"> The i, a, or u flag indicates the classification. The other flags indicate the encryption used by the rogue. For flag definitions, see the key in the command output.
RSSI	Received signal strength indication (RSSI)—the strength of the RF signal detected by the AP radio, in decibels referred to 1 milliwatt (dBm).
Age	Number of seconds since an AP radio last detected 802.11 packets from the device.

See Also

- **show rfdetect mobility-domain on page 526**
- **show rfdetect visible on page 531**

show rfdetect ignore

Displays the BSSIDs of third-party devices that WSS Software ignores during RF scans. WSS Software does not generate log messages or traps for the devices in the ignore list.

Syntax **show rfdetect ignore**

Defaults None.

Access Enabled.

Examples The following example displays the list of ignored devices:

```
WSS# show rfdetect ignore
```

```
Total number of entries: 2
```

```
Ignore MAC
```

```
-----
```

```
aa:bb:cc:11:22:33
```

```
aa:bb:cc:44:55:66
```

See Also

- **clear rfdetect ignore on page 513**
- **set rfdetect ignore on page 515**

show rfdetect mobility-domain

Displays the rogues detected by all WSSs in the Mobility Domain during RF detection scans.

Syntax **show rfdetect mobility-domain**

[**ssid** *ssid-name* | **bssid** *mac-addr*]

ssid *ssid-name* Displays rogues that are using the specified SSID.

bssid *mac-addr* Displays rogues that are using the specified BSSID.

Defaults None.

Access Enabled.

History

- | | |
|-------------|--|
| Version 3.0 | Command introduced. |
| Version 4.0 | <ul style="list-style-type: none"> • bssid and ssid options added. • Vendor, Type, and Flags fields added. |

Usage This command is valid only on the seed switch of the Mobility Domain. To display rogue information for an individual switch, use the **show rfdetect data** command on that switch.

Examples The following command displays summary information for all SSIDs and BSSIDs detected in the Mobility Domain:

WSS# show rfdetect mobility-domain

Total number of entries: 194

Flags: i = infrastructure, a = ad-hoc, u = unresolved

c = CCMP, t = TKIP, 1 = 104-bit WEP, 4 = 40-bit WEP, w = WEP(non-WPA)

BSSID	Vendor	Type	Flags	SSID

00:07:50:d5:cc:91	Cisco	intfr	i---w	r27-cisco1200-2
00:07:50:d5:dc:78	Cisco	intfr	i---w	r116-cisco1200-2
00:09:b7:7b:8a:54	Cisco	intfr	i----	
00:0a:5e:4b:4a:c0		3Com	intfr	i---- public
00:0a:5e:4b:4a:c2		3Com	intfr	i---w nrtlwlan
00:0a:5e:4b:4a:c4		3Com	intfr	ic--- nrtl-ccmp
00:0a:5e:4b:4a:c6		3Com	intfr	i---w nrtl-tkip
00:0a:5e:4b:4a:c8		3Com	intfr	i---w nrtl-voip
00:0a:5e:4b:4a:ca		3Com	intfr	i---- nrtl-webaaa
...				

The lines in this display are compiled from data from multiple listeners (AP radios). If an item has the value *unresolved*, not all listeners agree on the value for that item. Generally, an unresolved state occurs only when an AP or a Mobility Domain is still coming up, and lasts only briefly.

The following command displays detailed information for rogues using SSID *nrtl-webaaa*.

WSS# show rfdetect mobility-domain ssid nrtl-webaaa

BSSID: 00:0a:5e:4b:4a:ca Vendor: 3Com SSID: nrtl-webaaa

Type: intfr Adhoc: no Crypto-types: clear

WSS-IPaddress: 10.8.121.102 Port/Radio/Ch: 3/1/11 Mac: 00:0b:0e:00:0a:6a

Device-type: interfering Adhoc: no Crypto-types: clear

RSSI: -85 SSID: nrtl-webaaa

BSSID: 00:0b:0e:00:7a:8a Vendor: Nortel SSID: nrtl-webaaa

Type: intfr Adhoc: no Crypto-types: clear

WSS-IPaddress: 10.8.121.102 Port/Radio/Ch: 3/1/1 Mac: 00:0b:0e:00:0a:6a

Device-type: interfering Adhoc: no Crypto-types: clear

RSSI: -75 SSID: nrtl-webaaa

WSS-IPaddress: 10.3.8.103 Port/Radio/Ch: ap 1/1/1 Mac: 00:0b:0e:76:56:82

Device-type: interfering Adhoc: no Crypto-types: clear
 RSSI: -76 SSID: nrtl-webaaa

Two types of information are shown. The lines that are not indented show the BSSID, vendor, and information about the SSID. The indented lines that follow this information indicate the listeners (AP radios) that detected the SSID. Each set of indented lines is for a separate AP listener.

In this example, two BSSIDs are mapped to the SSID. Separate sets of information are shown for each of the BSSIDs, and information about the listeners for each BSSID is shown.

The following command displays detailed information for a BSSID.

WSS# show rfdetect mobility-domain bssid 00:0b:0e:00:04:d1

BSSID: 00:0b:0e:00:04:d1 Vendor: Cisco SSID: notmycorp

Type: rogue Adhoc: no Crypto-types: clear

WSS-IPaddress: 10.8.121.102 Port/Radio/Ch: 3/2/56 Mac: 00:0b:0e:00:0a:6b

Device-type: rogue Adhoc: no Crypto-types: clear

RSSI: -72 SSID: notmycorp

WSS-IPaddress: 10.3.8.103 Port/Radio/Ch: ap 1/1/157 Mac: 00:0b:0e:76:56:82

Device-type: rogue Adhoc: no Crypto-types: clear

RSSI: -72 SSID: notmycorp

Table 81 and Table 82 describe the fields in these displays.

Table 5: show rfdetect mobility-domain Output

Field	Description
BSSID	MAC address of the SSID used by the detected device.
Vendor	Company that manufactures or sells the rogue device.
Type	Classification of the rogue device: <ul style="list-style-type: none"> • rogue—Wireless device that is not supposed to be on the network. The device has an entry in a WSS's FDB and is therefore on the network. • infr—Wireless device that is not part of your network but is not a rogue. The device does not have an entry in a WSS's FDB and is not actually on the network, but might be causing RF interference with AP radios. • known—Device that is a legitimate member of the network.
Flags	Classification and encryption information for the rogue: <ul style="list-style-type: none"> • The i, a, or u flag indicates the classification. • The other flags indicate the encryption used by the rogue. For flag definitions, see the key in the command output.

Table 5: show rfdetect mobility-domain Output (continued)

Field	Description
BSSID	MAC address of the SSID used by the detected device.
Vendor	Company that manufactures or sells the rogue device.
Type	Classification of the rogue device: <ul style="list-style-type: none"> • rogue—Wireless device that is not supposed to be on the network. The device has an entry in a WSS's FDB and is therefore on the network. • intfr—Wireless device that is not part of your network but is not a rogue. The device does not have an entry in a WSS's FDB and is not actually on the network, but might be causing RF interference with AP radios. • known—Device that is a legitimate member of the network.
SSID	SSID used by the detected device.

Table 6: show rfdetect mobility-domain ssid or bssid Output

Field	Description
BSSID	MAC address of the SSID used by the detected device.
Vendor	Company that manufactures or sells the rogue device.
SSID	SSID used by the detected device.
Type	Classification of the rogue device: <ul style="list-style-type: none"> • rogue—Wireless device that is on the network but is not supposed to be on the network. • intfr—Wireless device that is not part of your network and is not a rogue, but might be causing RF interference with AP radios. • known—Device that is a legitimate member of the network.
Adhoc	Indicates whether the rogue is an infrastructure rogue (is using an AP) or is operating in ad-hoc mode.

Table 6: show rfdetect mobility-domain ssid or bssid Output (continued)

Field	Description
Crypto-Types	Encryption type: <ul style="list-style-type: none"> • clear (no encryption) • ccmp • tkip • wep104 (WPA 104-bit WEP) • wep40 (WPA 40-bit WEP) • wep (non-WPA WEP)
WSS-IPaddress	System IP address of the WSS that detected the rogue.
Port/Radio/Channel	Port number, radio number, and channel number of the radio that detected the rogue. For a AP, the connection number is labeled <i>ap</i> . (This stands for <i>ap</i> .)
Mac	MAC address of the radio that detected the rogue.
Device-type	Device type detected by the AP radio.
Adhoc	Ad-hoc status (yes or no) detected by the AP radio.
Crypto-Types	Encryption type detected by the AP radio.
RSSI	Received signal strength indication (RSSI)—the strength of the RF signal detected by the AP radio, in decibels referred to 1 milliwatt (dBm).
SSID	SSID mapped to the BSSID.

See Also

- **show rfdetect data** on page 524
- **show rfdetect visible** on page 531

show rfdetect ssid-list

Displays the entries in the permitted SSID list.

Syntax `show rfdetect ssid-list`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following example shows the permitted SSID list on a WSS:

WSS# show rfdetect ssid-list

Total number of entries: 3

SSID

mycorp
corporate
guest

See Also

- **clear rfdetect ssid-list on page 513**
- **set rfdetect ssid-list on page 517**

show rfdetect vendor-list

Displays the entries in the permitted vendor list.

Syntax `show rfdetect vendor-list`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following example shows the permitted vendor list on a WSS:

WSS# show rfdetect vendor-list

Total number of entries: 1

OUI	Type

aa:bb:cc:00:00:00	client
11:22:33:00:00:00	ap

See Also

- **clear rfdetect vendor-list on page 514**
- **set rfdetect vendor-list on page 518**

show rfdetect visible

Displays the BSSIDs discovered by a specific Nortel radio. The data includes BSSIDs transmitted by other Nortel radios as well as by third-party access points.

Syntax `show rfdetect visible mac-addr`

Syntax `show rfdetect visible ap ap-num [radio {1 | 2}]`

Syntax `show rfdetect visible ap ap-num [radio {1 | 2}]`

mac-addr Base MAC address of the Nortel radio.

Note: To display the base MAC address of a Nortel radio, use the `show ap status` command.

ap-num Port connected to the AP for which to display neighboring BSSIDs.

ap-num Number of a AP for which to display neighboring BSSIDs.

radio 1 Shows neighbor information for radio 1.

radio 2 Shows neighbor information for radio 2. (This option does not apply to single-radio models.)

Defaults None.

Access Enabled.

History

Version 4.0 Vendor, Type, and Flags fields added.

Usage If a Nortel radio is supporting more than one SSID, each of the corresponding BSSIDs is listed separately.

To display rogue information for the entire Mobility Domain, use the `show rfdetect mobility-domain` command on the seed switch.

Examples To following command displays information about the rogues detected by radio 1 on AP port 3:

WSS# show rfdetect visible ap 3 radio 1

Total number of entries: 104

Flags: i = infrastructure, a = ad-hoc

c = CCMP, t = TKIP, 1 = 104-bit WEP, 4 = 40-bit WEP, w = WEP(non-WPA)

Transmit MAC Vendor Type Ch RSSI Flags SSID

```
-----
00:07:50:d5:cc:91 Cisco intfr 6 -60 i---w r27-cisco1200-2
00:07:50:d5:dc:78 Cisco intfr 6 -82 i---w r116-cisco1200-2
00:09:b7:7b:8a:54 Cisco intfr 2 -54 i----
00:0a:5e:4b:4a:c0 3Com intfr 11 -57 i---- public
00:0a:5e:4b:4a:c2 3Com intfr 11 -86 i-t1-- Nortelwlan
00:0a:5e:4b:4a:c4 3Com intfr 11 -85 ic---- nrtl-ccmp
00:0a:5e:4b:4a:c6 3Com intfr 11 -85 i-t-- nrtl-tkip
00:0a:5e:4b:4a:c8 3Com intfr 11 -83 i---w nrtl-voip
00:0a:5e:4b:4a:ca 3Com intfr 11 -85 i---- nrtl-webaaa
...
```

Table 83 describes the fields in this display.

Table 7: show rfdetect visible Output

Field	Description
Transmit MAC	MAC address the rogue device that sent the 802.11 packet detected by the AP radio.
Vendor	Company that manufactures or sells the rogue device.
Type	Classification of the rogue device: <ul style="list-style-type: none"> • rogue—Wireless device that is on the network but is not supposed to be on the network. • intfr—Wireless device that is not part of your network and is not a rogue, but might be causing RF interference with AP radios. • known—Device that is a legitimate member of the network.
Ch	Channel number on which the radio detected the rogue.
RSSI	Received signal strength indication (RSSI)—the strength of the RF signal detected by the AP radio, in decibels referred to 1 milliwatt (dBm).
Flags	Classification and encryption information for the rogue: <ul style="list-style-type: none"> • The i, a, or u flag indicates the classification. • The other flags indicate the encryption used by the rogue. For flag definitions, see the key in the command output.
SSID	SSID used by the detected device.

See Also

- **show rfdetect data on page 524**
- **show rfdetect mobility-domain on page 526**

rfping

Provides information about the RF link between the WSS and the client based on sending test packets to the client.

Syntax `rfping {mac mac-addr | session-id session-id}`

mac-addr Tests the RF link between the WSS and the client with the specified MAC address.

session-id Tests the RF link between the WSS and the client with the specified local session ID.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 5.0.
Name of the command changed from test rflink to rfping in WSS Software Version 6.0.

Usage Use this command to send test packets to a specified client. The output of the command indicates the number of test packets received and acknowledged by the client, as well as the client's signal strength and signal-to-noise ratio.

Examples The following command tests the RF link between the WSS and the client with MAC address 00:0e:9b:bf:ad:13:

WSS# rfping mac 00:0e:9b:bf:ad:13

RF-Link Test to 00:0e:9b:bf:ad:13 :

Session-Id: 2

Packets Sent	Packets Rcvd	RSSI	SNR	RTT (micro-secs)
20	20	-68	26	976

Table 84 describes the fields in this display.

Table 8: rfping Output

Field	Description
Packets Sent	The number of test packets sent from the WSS to the client.
Packets Rcvd	The number of test packets acknowledged by the client.
RSSI	Received signal strength indication (RSSI)—the strength of the RF signal from the client, in decibels referred to 1 milliwatt (dBm).
SNR	Signal-to-noise ratio (SNR), in decibels (dB), of the data received from the client.
RTT (micro-secs)	The round-trip time, in microseconds, for the client response to the test packets.

See Also

- **show rfdetect data on page 524**
- **show rfdetect visible on page 531**

File Management Commands

Use file management commands to manage system files and to display software and boot information. This chapter presents file management commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Software Version	<ul style="list-style-type: none"> reset system on page 546 show version on page 554
Boot Settings	<ul style="list-style-type: none"> set boot partition on page 550 set boot configuration-file on page 550 set boot backup-configuration on page 549 show boot on page 551 clear boot config on page 537 clear boot backup-configuration on page 537
File Management	<ul style="list-style-type: none"> dir on page 540 copy on page 537 md5 on page 544 delete on page 539 mkdir on page 545 rmdir on page 548
Configuration File	<ul style="list-style-type: none"> save config on page 548 load config on page 543 show config on page 553
System Backup and Restore	<ul style="list-style-type: none"> backup on page 535 restore on page 547
Sygate On-Demand Agent (SODA) file installation and removal	<ul style="list-style-type: none"> install soda agent on page 542 uninstall soda agent on page 556

backup

Creates an archive of WSS system files and optionally, user file, in Unix *tape archive (tar)* format.

Syntax `backup system [tftp:ip-addr]/filename [all | critical]`

<code>[tftp:ip-addr]/filename</code>	Name of the archive file to create. You can store the file locally in the switch's nonvolatile storage or on a TFTP server.
all	Backs up system files and all the files in the user files area. The user files area contains the set of files listed in the <i>file</i> section of dir command output.
critical	Backs up system files only, including the configuration file used when booting, and certificate files. The size of an archive created by this option is generally 1MB or less.

Defaults The default is **all**.

Access Enabled.

Usage You can create an archive located on a TFTP server or in the switch's nonvolatile storage. If you specify a TFTP server as part of the filename, the archive is copied directly to the TFTP server and not stored locally on the switch.

Use the **critical** option if you want to back up or restore only the system-critical files required to operate and communicate with the switch. Use the **all** option if you also want to back up or restore Web-based AAA pages, backup configuration files, image files, and any other files stored in the user files area of nonvolatile storage.

The maximum supported file size is 32 MB. If the file size of the tarball is too large, delete unnecessary files (such as unneeded copies of system image files) and try again, or use the **critical** option instead of the **all** option.

Neither option archives image files or any other files listed in the *Boot* section of **dir** command output. The **all** option archives image files only if they are present in the user files area.

Archive files created by the **all** option are larger than files created by the **critical** option. The file size depends on the files in the user area, and the file can be quite large if the user area contains image files.

The **backup** command places the boot configuration file into the archive. (The boot configuration file is the *Configured boot configuration* in the **show boot** command's output.) If the running configuration contains changes that have not been saved, these changes are not in the boot configuration file and are not archived. To make sure the archive contains the configuration that is currently running on the switch, use the **save config** command to save the running configuration to the boot configuration file, before using the **backup** command.

Examples The following command creates an archive of the system-critical files and copies the archive directly to a TFTP server. The filename in this example includes a TFTP server IP address, so the archive is not stored locally on the switch.

```
WSS# backup system tftp://10.10.20.9/sysa_bak critical
```

```
success: sent 28263 bytes in 0.324 seconds [ 87231 bytes/sec]
```

See Also

- **dir** on page 540
- **restore** on page 547

clear boot backup-configuration

Clears the filename specified as the backup configuration file. In the event that WSS Software cannot read the configuration file at boot time, a backup configuration file is not used.

Syntax clear boot backup-configuration

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command clears the name specified as the backup configuration file from the configuration of the WSS:

WSS# clear boot backup-configuration

success: Backup boot config filename was cleared.

See Also

- [set boot backup-configuration on page 549](#)
- [show boot on page 551](#)

clear boot config

Resets to the factory default the configuration that WSS Software loads during a reboot.

Syntax clear boot config

Defaults None.

Access Enabled.

Examples The following commands back up the configuration file on a WSS, reset the switch to its factory default configuration, and reboot the switch:

WSS# copy configuration tftp://10.1.1.1/backupcfg

success: sent 365 bytes in 0.401 seconds [910 bytes/sec]

WSS# clear boot config

success: Reset boot config to factory defaults.

WSS# reset system force

..... rebooting

See Also

- [reset system on page 546](#)
- [show config on page 553](#)

copy

Performs the following copy operations:

- Copies a file from a TFTP server to nonvolatile storage.
- Copies a file from nonvolatile storage or temporary storage to a TFTP server.
- Copies a file from one area in nonvolatile storage to another.
- Copies a file to a new filename in nonvolatile storage.

Syntax `copy source-url destination-url`

source-url

Name and location of the file to copy. The uniform resource locator (URL) can be one of the following:

- `[subdirname/]filename`
- **file:**`[subdirname/]filename`
- **tftp://ip-addr**`[subdirname/]filename`
- **tmp:**`filename`

For the filename, specify between 1 and 128 alphanumeric characters, with no spaces. Enter the IP address in dotted decimal notation.

The *subdirname* option specifies a subdirectory.

destination-url

Name of the copy and the location where to place the copy. The URL can be one of the following:

- `[subdirname/]filename`
- **file:**`[subdirname/]filename`
- **tftp://ip-addr**`[subdirname/]filename`

If you are copying a system image file into nonvolatile storage, the filename must include the boot partition name. You can specify one of the following:

- **boot0:**`filename`
- **boot1:**`filename`

Defaults None.

Access Enabled.

Usage The *filename* and **file:filename** URLs are equivalent. You can use either URL to refer to a file in a WSS's nonvolatile memory. The **tftp://ip-addr/filename** URL refers to a file on a TFTP server. If DNS is configured on the WSS, you can specify a TFTP server's hostname as an alternative to specifying the IP address.

The **tmp:filename** URL specifies a file in temporary storage. You can copy a file out of temporary storage but you cannot copy a file into temporary storage. Temporary storage is reserved for use by WSS Software.

If you are copying a system image file into nonvolatile storage, the filename must be preceded by the boot partition name, which can be **boot0** or **boot1**. Enter the filename as **boot0:filename** or **boot1:filename**. You must specify the boot partition that *was not* used to load the currently running image.

The maximum supported file size for TFTP is 32 MB.

Examples The following command copies a file called *floorwss* from nonvolatile storage to a TFTP server:

```
WSS# copy floorwss tftp://10.1.1.1/floorwss
success: sent 365 bytes in 0.401 seconds [ 910 bytes/sec]
```

The following command copies a file called *closetwss* from a TFTP server to nonvolatile storage:

```
WSS# copy tftp://10.1.1.1/closetwss closetwss
success: received 637 bytes in 0.253 seconds [ 2517 bytes/sec]
```

The following command copies system image *WSS020101.020* from a TFTP server to boot partition 1 in nonvolatile storage:

```
WSS# copy tftp://10.1.1.107/WSS020101.020 boot1:WSS020101.020
.....success: received 9163214
bytes in 105.939 seconds [ 86495 bytes/sec]
```

The following commands rename *test-config* to *new-config* by copying it from one name to the other in the same location, then deleting *test-config*:

```
WSS# copy test-config new-config
WSS# delete test-config
success: file deleted.
```

The following command copies file *corpa-login.html* from a TFTP server into subdirectory *corpa* in a WSS's nonvolatile storage:

```
WSS# copy tftp://10.1.1.1/corpa-login.html corpa/corpa-login.html
success: received 637 bytes in 0.253 seconds [ 2517 bytes/sec]
```

See Also

- **delete** on page 539
- **dir** on page 540

delete

Deletes a file.



Caution! WSS Software does not prompt you to verify whether you want to delete a file. When you press Enter after typing a **delete** command, WSS Software immediately deletes the specified file.



Note. WSS Software does not allow you to delete the currently running software image file or the running configuration.

Syntax `delete url`

url Filename. Specify between 1 and 128 alphanumeric characters, with no spaces.
If the file is in a subdirectory, specify the subdirectory name, followed by a forward slash, in front of the filename. For example: **subdir_a/file_a**.

Defaults None.

Access Enabled.

Usage You might want to copy the file to a TFTP server as a backup before deleting the file.

Examples The following commands copy file *testconfig* to a TFTP server and delete the file from nonvolatile storage:

```
WSS# copy testconfig tftp://10.1.1.1/testconfig
success: sent 365 bytes in 0.401 seconds [ 910 bytes/sec]
```

```
WSS# delete testconfig
success: file deleted.
```

Examples The following command deletes file *dang_doc* from subdirectory *dang*:

```
WSS# delete dang/dang_doc
success: file deleted.
```

See Also

- [copy on page 537](#)
- [dir on page 540](#)

dir

Displays a list of the files in nonvolatile storage and temporary files.

Syntax `dir [subdirname] | [file:] | [core:] | [boot0:] | [boot1:]`

subdirname Subdirectory name. If you specify a subdirectory name, the command lists the files in that subdirectory. Otherwise, the command lists the files in the root directory and also lists the subdirectories.

file: Limits **dir** output to the contents of the user files area

core: Limits **dir** output to the contents of the */tmp/core* subdirectory

boot0: Limits **dir** output to the contents of the *boot0* partition

boot1: Limits **dir** output to the contents of the *boot1* partition

Defaults None.

Access Enabled.

History

Version 4.1 **core**, **file**, **boot0**, and **boot1**: options added, to limit the output to the specified category

Examples The following command displays the files in the root directory:

WSS# dir

```
=====
file:
Filename                Size      Created
file:configuration      48 KB    Jul 12 2005, 15:02:32
file:corp2:corp2cnfig   17 KB    Mar 14 2005, 22:20:04
corp_a/                  512 bytes May 21 2004, 19:15:48
file:dangcfg            14 KB    Mar 14 2005, 22:20:04
old/                     512 bytes May 16 2004, 17:23:44
file:pubsconfig-april062005 40 KB    May 09 2005, 21:08:30
file:sysa_bak            12 KB    Mar 15 2005, 19:18:44
file:testback           28 KB    Apr 19 2005, 16:37:18
Total:      159 Kbytes used, 207663 Kbytes free
=====
```

```
=====
Boot:
Filename                Size      Created
boot0:wss040100.020     9780 KB  Aug 23 2005, 15:54:08
*boot1:wss040100.020   9796 KB  Aug 28 2005, 21:09:56
Boot0: Total:          9780 Kbytes used, 2460 Kbytes free
Boot1: Total:          9796 Kbytes used, 2464 Kbytes free
=====
```

```
=====
temporary files:
Filename                Size      Created
core:command_audit.cur  37 bytes  Aug 28 2005, 21:11:41
Total:      37 bytes used, 91707 Kbytes free
=====
```

The following command displays the files in the *old* subdirectory:

WSS# dir old

```
=====
file:
Filename                Size      Created
file:configuration.txt  3541 bytes Sep 22 2003, 22:55:44
file:configuration.xml  24 KB    Sep 22 2003, 22:55:44
Total:      27 Kbytes used, 207824 Kbytes free
=====
```

The following command limits the output to the contents of the user files area:

WSS# dir file:

```
=====
file:
Filename                Size      Created
file:configuration      48 KB    Jul 12 2005, 15:02:32
file:corp2:corp2cnfig   17 KB    Mar 14 2005, 22:20:04
corp_a/                  512 bytes May 21 2004, 19:15:48
file:dangcfg            14 KB    Mar 14 2005, 22:20:04
dangdir/                 512 bytes May 16 2004, 17:23:44
file:pubsconfig-april062005 40 KB    May 09 2005, 21:08:30
file:sysa_bak            12 KB    Mar 15 2005, 19:18:44
file:testback           28 KB    Apr 19 2005, 16:37:18
Total:      159 Kbytes used, 207663 Kbytes free
=====
```

The following command limits the output to the contents of the */tmp/core* subdirectory:

WSS# dir core:

```
=====
file:
Filename                Size      Created
core:command_audit.cur  37 bytes  Aug 28 2005, 21:11:41
Total:    37 bytes used, 91707 Kbytes free
```

The following command limits the output to the contents of the *boot0* partition:

WSS# dir boot0:

```
=====
file:
Filename                Size      Created
boot0:wss040100.020    9780 KB   Aug 23 2005, 15:54:08
Total:    9780 Kbytes used, 207663 Kbytes free
```

[Table 85](#) describes the fields in the **dir** output.

Table 1: Output for dir

Field	Description
Filename	Filename or subdirectory name. For files, the directory name is shown in front of the filename (for example, file:configuration). The <i>file:</i> directory is the root directory. For subdirectories, a forward slash is shown at the end of the subdirectory name (for example, old/). In the boot partitions list (Boot:), an asterisk (*) indicates the boot partition from which the currently running image was loaded and the image filename.
Size	Size in Kbytes or bytes.
Created	System time and date when the file was created or copied onto the switch.
Total	Number of kilobytes in use to store files and the number that are still free.

See Also

- [copy on page 537](#)
- [delete on page 539](#)

install soda agent

Installs Sygate On-Demand (SODA) agent files in a directory on the WSS.

Syntax `install soda agent agent-file agent-directory directory`

agent-file Name of a .zip file on the WSS containing SODA agent files.

directory Directory on the WSS where SODA agent files are to be installed. The command automatically creates this directory.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage Use this command to install a .zip file containing SODA agent files into a directory on the WSS. Prior to installing the SODA agent files, you must have already copied the .zip file to the WSS. This command creates the specified directory, unzips the file and places the contents into the directory. If the specified directory has the same name as an SSID, then that SSID uses the SODA agent files in the directory if SODA functionality is enabled for the service profile that manages the SSID.

Examples The following command installs the contents of the file *soda.ZIP* into a directory called *sp1*.

WSS# install soda agent soda.ZIP agent-directory sp1

This command may take up to 20 seconds...

WSS#

See Also

- [uninstall soda agent on page 556](#)
- [set service-profile soda mode on page 329](#)

load config



Caution! This command completely removes the running configuration and replaces it with the configuration contained in the file. Nortel recommends that you save a copy of the current running configuration to a backup configuration file before loading a new configuration.

Loads configuration commands from a file and replaces the WSS's running configuration with the commands in the loaded file.

Syntax `load config [url]`

url Filename. Specify between 1 and 128 alphanumeric characters, with no spaces.

If the file is in a subdirectory, specify the subdirectory name, followed by a forward slash, in front of the filename. For example: **backup_configs/config_c**.

Defaults The default file location is nonvolatile storage.



Note. The current version supports loading a configuration file only from the switch's nonvolatile storage. You cannot load a configuration file directly from a TFTP server.

If you do not specify a filename, WSS Software uses the same configuration filename that was used for the previous configuration load. For example, if the WSS used *configuration* for the most recent configuration load, WSS Software uses *configuration* again unless you specify a different filename. To display the filename of the configuration file WSS Software loaded during the last reboot, use the **show boot** command.

Access Enabled.

Usage This command completely replaces the running configuration with the configuration in the file.

Examples The following command reloads the configuration from the most recently loaded configuration file:

WSS# load config

Reloading configuration may result in lost of connectivity, do you wish to continue? (y/n) [n]y
success: Configuration reloaded

The following command loads configuration file *testconfig1*:

WSS# load config testconfig1

Reloading configuration may result in lost of connectivity, do you wish to continue? (y/n) [n]y
success: Configuration reloaded

See Also

- **save config on page 548**
- **show boot on page 551**
- **show config on page 553**

md5

Calculates the MD5 checksum for a file in the switch's nonvolatile storage.

Syntax **md5** [**boot0:** | **boot1:**]*filename*

boot0: | **boot1:** Boot partition into which you copied the file.

filename Name of the file.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage You must include the boot partition name in front of the filename. If you specify only the filename, the CLI displays a message stating that the file does not exist.

Examples The following command calculates the checksum for image file WSS040003.020 in boot partition 0:

```
pubs# md5 boot0:WSS040003.020
```

```
MD5 (boot0:WSS040003.020) = b9cf7f527f74608e50c70e8fb896392a
```

See Also

- **copy on page 537**
- **dir on page 540**

mkdir

Creates a new subdirectory in nonvolatile storage.

Syntax `mkdir [subdirname]`

subdirname Subdirectory name. Specify between 1 and 32 alphanumeric characters, with no spaces.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Examples The following commands create a subdirectory called *corp2* and display the root directory to verify the result:

```
WSS# mkdir corp2
```

```
success: change accepted.
```

```
WSS# dir
```

```
=====
file:
Filename                Size                Created
file:configuration      17 KB              May 21 2004, 18:20:53
file:configuration.txt  379 bytes          May 09 2004, 18:55:17
corp2/                  512 bytes          May 21 2004, 19:22:09
corp_a/                 512 bytes          May 21 2004, 19:15:48
file:dangcfg            13 KB              May 16 2004, 18:30:44
dangdir/               512 bytes          May 16 2004, 17:23:44
old/                   512 bytes          Sep 23 2003, 21:58:48
Total:                  33 Kbytes used, 207822 Kbytes free
=====
Boot:
Filename                Size                Created
*boot0:bload            746 KB             May 09 2004, 19:02:16
*boot0:wss030000.020    8182 KB            May 09 2004, 18:58:16
boot1:wss030000.020     8197 KB            May 21 2004, 18:01:02
Boot0: Total:           8928 Kbytes used, 3312 Kbytes free
Boot1: Total:           8197 Kbytes used, 4060 Kbytes free
=====
```

temporary files:

Filename	Size	Created
Total:	0 bytes used, 93537 Kbytes free	

See Also

- **dir on page 540**
- **rmdir on page 548**

reset system

Restarts a WSS and reboots the software.

Syntax `reset system [force]`

force Immediately restarts the system and reboots, without comparing the running configuration to the configuration file.

Defaults None.

Access Enabled.

Usage If you do not use the **force** option, the command first compares the running configuration to the configuration file. If the running configuration and configuration file do not match, WSS Software does not restart the WSS but instead displays a message advising you to either save the configuration changes or use the **force** option.

Examples The following command restarts a WSS that does not have any unsaved configuration changes:

WSS# reset system

This will reset the entire system. Are you sure (y/n)y

The following commands attempt to restart a WSS with a running configuration that has unsaved changes, and then force the switch to restart:

WSS# reset system

error: Cannot reset, due to unsaved configuration changes. Use "reset system force" to override.

WSS# reset system force

..... rebooting

See Also

- **save config on page 548**
- **show boot on page 551**
- **show version on page 554**

restore

Unzips a system archive created by the **backup** command and copies the files from the archive onto the switch.

Syntax `restore system [tftp:/ip-addr/]filename [all | critical] [force]`

<code>[tftp:/ip-addr/]filename</code>	Name of the archive file to load. The archive can be located in the switch's nonvolatile storage or on a TFTP server.
all	Restores system files <i>and</i> the user files from the archive.
critical	Restores system files only, including the configuration file used when booting, and certificate files.
force	Replaces files on the switch with those in the archive, even if the switch is not the same as the one from which the archive was created. CAUTION! Do not use this option unless advised to do so by Nortel TAC. If you restore one switch's system files onto another switch, you must generate new key pairs and certificates on the switch.

Defaults The default is **critical**.

Access Enabled.

Usage If a file in the archive has a counterpart on the switch, the archive version of the file replaces the file on the switch. The **restore** command does not delete files that do not have counterparts in the archive. For example, the command does not completely replace the user files area. Instead, files in the archive are added to the user files area. A file in the user area is replaced only if the archive contains a file with the same name.



Note. If the archive's files cannot fit on the switch, the restore operation fails. Nortel recommends deleting unneeded image files before creating or restoring an archive.

The **backup** command stores the MAC address of the switch in the archive. By default, the **restore** command works only if the MAC address in the archive matches the MAC address of the switch where the **restore** command is entered. The **force** option overrides this restriction and allows you to unpack one switch's archive onto another switch.



Caution! Do not use the **force** option unless you are certain you want to replace the switch's files with files from another switch. If you restore one switch's system files onto another switch, you must generate new key pairs and certificates on the switch.

If the configuration running on the switch is different from the one in the archive or you renamed the configuration file, and you want to retain changes that were made after the archive was created, see the “Managing System Files” chapter of the *Nortel WLAN 2300 System Software Configuration Guide*.

Examples The following command restores system-critical files on a switch, from archive *sysa_bak*:

```
WSS# restore system tftp://10.10.20.9/sysa_bak
success: received 11908 bytes in 0.150 seconds [ 79386 bytes/sec]
```

success: restore complete.

See Also [backup on page 535](#)

rmdir

Removes a subdirectory from nonvolatile storage.

Syntax `rmdir [subdirname]`

subdirname Subdirectory name. Specify between 1 and 32 alphanumeric characters, with no spaces.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Usage WSS Software does not allow the subdirectory to be removed unless it is empty. Delete all files from the subdirectory before attempting to remove it.

Examples The following example removes subdirectory *corp2*:

```
WSS# rmdir corp2
success: change accepted.
```

See Also

- [dir on page 540](#)
- [mkdir on page 545](#)

save config

Saves the running configuration to a configuration file.

Syntax `save config [filename]`

filename Name of the configuration file. Specify between 1 and 128 alphanumeric characters, with no spaces.
To save the file in a subdirectory, specify the subdirectory name, followed by a forward slash, in front of the filename. For example:
backup_configs/config_c.

Defaults By default, WSS Software saves the running configuration as the configuration filename used during the last reboot.

Access Enabled.

Usage If you do not specify a filename, WSS Software replaces the configuration file loaded during the most recent reboot. To display the filename of the configuration file WSS Software loaded during the most recent reboot, use the **show boot** command.

The command completely replaces the specified configuration file with the running configuration.

Examples The following command saves the running configuration to the configuration file loaded during the most recent reboot. In this example, the filename used during the most recent reboot is *configuration*.

WSS# save config

Configuration saved to configuration.

The following command saves the running configuration to a file named *testconfig1*:

WSS# save config testconfig1

Configuration saved to testconfig1.

See Also

- **load config on page 543**
- **show boot on page 551**
- **show config on page 553**

set boot backup-configuration

Specifies the name of a backup configuration file to be used in the event that WSS Software cannot read the WSS's configuration file at boot time.

Syntax `set boot backup-configuration filename`

filename Name of the file to use as a backup configuration file if WSS Software cannot read the WSS's configuration file.

Defaults By default, there is no backup configuration file.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command specifies a file called `backup.cfg` as the backup configuration file on the WSS:

```
WSS# set boot backup-configuration backup.cfg
success: backup boot config filename set.
```

See Also

- [clear boot backup-configuration on page 537](#)
- [show boot on page 551](#)

set boot configuration-file

Changes the configuration file to load after rebooting.

Syntax `set boot configuration-file filename`

filename Filename. Specify between 1 and 128 alphanumeric characters, with no spaces.
To load the file from a subdirectory, specify the subdirectory name, followed by a forward slash, in front of the filename. For example:
backup_configs/config_c.

Defaults The default configuration filename is *configuration*.

Access Enabled.

Usage The file must be located in the switch's nonvolatile storage.

Examples The following command sets the boot configuration file to *testconfig1*:

```
WSS# set boot configuration-file testconfig1
success: boot config set.
```

set boot partition

Specifies the boot partition in which to look for the system image file following the next system reset, software reload, or power cycle.

Syntax `set boot partition {boot0 | boot1}`

boot0 Boot partition 0.

boot1 Boot partition 1.

Defaults By default, a WSS uses the same boot partition for the next software reload that was used to boot the currently running image.

Access Enabled.

History Introduced in WSS Software Version 1.1.

Usage To determine the boot partition that was used to load the currently running software image, use the **dir** command.

Examples The following command sets the boot partition for the next software reload to partition 1:

```
WSS# set boot partition boot1
```

success: Boot partition set to boot1.

See Also

- [copy on page 537](#)
- [dir on page 540](#)
- [reset system on page 546](#)

show boot

Displays the system image and configuration filenames used after the last reboot and configured for use after the next reboot.

Syntax **show boot**

Defaults None.

Access Access.

History

Version 4.1

- New fields, Configured boot version and Backup boot configuration, added

Examples The following command shows the boot information for a WSS:

```
WSS# show boot
```

```
Configured boot version:    5.0.7.0.20
Configured boot image:     boot1:N6050700.020
Configured boot configuration: file:configuration
Backup boot configuration:  NONE
Booted version:           5.0.7.0.20
Booted image:             boot1:N6050700.020
Booted configuration:     file:configuration
Product model:            2360
```

[Table 86](#) describes the fields in the **show boot** output.

Table 2: Output for show boot

Field	Description
Configured boot version	Software version the switch will run next time the software is rebooted.
Configured boot image	Boot partition and image filename WSS Software will use to boot next time the software is rebooted.
Configured boot configuration	Configuration filename WSS Software will use to boot next time the software is rebooted.
Backup boot configuration	The name of the configuration file to be used in the event that WSS Software cannot read the configured boot configuration file next time the software is rebooted.
Booted version	Software version the switch is running.
Booted image	Boot partition and image filename WSS Software used the last time the software was rebooted. WSS Software is running this software image.
Booted configuration	Configuration filename WSS Software used to load the configuration the last time the software was rebooted.

See Also

- **clear boot config on page 537**
- **reset system on page 546**
- **set boot configuration-file on page 550**
- **show version on page 554**

show config

Displays the configuration running on the WSS.

Syntax `show config [area area] [all]`

area *area*

Configuration area. You can specify one of the following:

- **aaa**
- **acls**
- **ap**
- **arp**
- **eapol**
- **httpd**
- **ip**
- **ip-config**
- **l2acl**
- **log**
- **mobility-domain**
- **network-domain**
- **ntp**
- **portconfig**
- **port-group**
- **qos**
- **radio-profile**
- **rfdetect**
- **service-profile**
- **sm**
- **snmp**
- **snoop**
- **spantree**
- **system**
- **trace**
- **vlan**
- **vlan-fdb**

area *area*,
cont.

If you do not specify a configuration area, nondefault information for all areas is displayed.

all

Includes configuration items that are set to their default values.

Defaults None.

Access Enabled.

History

- Version 4.0
- New options added for remote traffic monitoring:
snoop
 - **rfdevice** changed to **rfdetect**
- Version 4.1 New options added: **l2acl**, **network-domain**, and **qos**
- Version 5.0 Option **portgroup** renamed to **port-group** for consistency with **clear port-group**, **set port-group**, and **show port-group** commands.

Usage If you do not use one of the optional parameters, configuration commands that set nondefault values are displayed for all configuration areas. If you specify an area, commands are displayed for that area only. If you use the **all** option, the display also includes commands for configuration items that are set to their default values.

Examples The following command shows configuration information for VLANs:

WSS# show config area vlan

```
# Configuration nvgen'd at 2004-5-21 19:36:48
# Image 3.0.0
# Model WSS
# Last change occurred at 2004-5-21 18:20:50
set vlan 1 port 1
```

See Also

- **load config on page 543**
- **save config on page 548**

show version

Displays software and hardware version information for a WSS and, optionally, for any attached AP.

Syntax **show version [details]**

details Includes additional software build information and information about the APs configured on the WSS.

Defaults None

Access All.

Examples The following command displays version information for a WSS:

WSS# show version

```
WLAN Security Switch 2300 Series, Version: 5.0.0 QA 67
Copyright (c) 2002, 2003, 2004, 2005 Nortel. All rights reserved.
```

```

Build Information: (build#67) TOP 2005-09-21 04:41:00
Model:           WSS
Hardware
  Mainboard:     version 24 ; revision 3 ; FPGA version 24
  PoE board:     version 1 ; FPGA version 6
Serial number    0321300013
Flash:           5.0.0.14 - md0a
Kernel:          3.0.0#20: Fri Sep 22 17:43:51 PDT 2005
BootLoader:      5.00 / 5.0.0

```

The following command displays additional software build information and AP information:

```

WSS# show version details
WLAN Security Switch 2300 Series, Version: 5.0.0 QA 67
  Copyright (c) 2002, 2003, 2004, 2005 Nortel. All rights reserved.

```

```

Build Information: (build#67) TOP 2005-09-21 04:41:00
Label:           5.0.0.67_092205_WSS2380
Build Suffix:    -d-O1
Model:           WSS
Hardware
  Mainboard:     version 24 ; revision 3 ; FPGA version 24
  CPU Model:     750 (Revision 3.1)
  PoE board:     version 1 ; FPGA version 6
Serial number    0321300013
Flash:           5.0.0.14 - md0a
Kernel:          3.0.0#20: Fri Sep 22 17:43:51 PDT 2005
BootLoader:      5.00 / 5.0.0

```

Port/ap	AP Model	Serial #	Versions
11 /-	AP-2330	0424902948	H/W : A
			F/W1 : 5.6
			F/W2 : 5.6
			S/W : 5.0.0.67_072105_0432__AP
			BOOT S/W : 5.0.3.15_062705_0107__AP

Table 87 describes the fields in the **show version** output.

Table 3: Output for show version

Field	Description
Build Information	Factory timestamp of the image file.
Label	Software version and build date.
Build Suffix	Build suffix.
Model	Build model.
Hardware	Version information for the WSS's motherboard and Power over Ethernet (PoE) board.
Serial number	Serial number of the WSS.
Flash	Flash memory version.
Kernel	Kernel version.
BootLoader	Boot code version.
Port/ap	Port number connected to an AP.
AP Model	AP model number.
Serial #	AP serial number.
Versions	AP hardware, firmware, and software versions.

See Also **show boot** on page 551

uninstall soda agent

Removes the contents of a directory containing SODA agent files.

Syntax `uninstall soda agent agent-directory directory`

directory Directory on the WSS where SODA agent files are to be removed.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Usage Use this command to remove a SODA agent directory and all of its contents. All files in the specified directory are removed. The command removes the directory and its contents, regardless of whether it contains SODA agent files.

Examples The following command removes the directory *sp1* and all of its contents:

WSS# `uninstall soda agent agent-directory sp1`

This will delete all files in agent-directory, do you wish to continue? (y|n) [n]y

See Also

- **install soda agent on page 542**
- **set service-profile soda mode on page 329**

Trace Commands

Use trace commands to perform diagnostic routines. While WSS Software allows you to run many types of traces, this chapter describes commands for those traces you are most likely to use. For a complete listing of the types of traces WSS Software allows, type the **set trace ?** command.



Caution! Using the **set trace** command can have adverse effects on system performance. Nortel recommends that you use the lowest levels possible for initial trace commands, and slowly increase the levels to get the data you need.

This chapter presents trace commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Trace	set trace sm on page 563
	set trace dot1x on page 562
	set trace authentication on page 561
	set trace authorization on page 561
	show trace on page 564
	show trace on page 564
	save trace on page 560
	clear log trace on page 559

clear log trace

Deletes the log messages stored in the trace buffer.

Syntax **clear log trace**

Defaults None.

Access Enabled.

Examples To delete the trace log, type the following command:

WSS# clear log trace

See Also

- **set log on page 576**
- **show log buffer on page 579**

clear trace

Deletes running trace commands and ends trace processes.

Syntax `clear trace {trace-area | all}`

trace-area Ends a particular trace process. Specify one of the following keywords to end the traces documented in this chapter:

- **authorization**—Ends an authorization trace
- **dot1x**—Ends an 802.1X trace
- **authentication**—Ends an authentication trace
- **sm**—Ends a session manager trace

all Ends all trace processes.

Defaults None.

Access Enabled.

Examples To clear all trace processes, type the following command:

```
WSS# clear trace all
success: clear trace all
```

To clear the session manager trace, type the following command:

```
WSS# clear trace sm
success: clear trace sm
```

See Also

- [set trace authentication on page 561](#)
- [set trace authorization on page 561](#)
- [set trace dot1x on page 562](#)
- [set trace sm on page 563](#)
- [show trace on page 564](#)

save trace

Saves the accumulated trace data for enabled traces to a file in the WSS's nonvolatile storage.

Syntax `save trace filename`

filename Name for the trace file. To save the file in a subdirectory, specify the subdirectory name, then a slash. For example: **traces/trace1**

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 3.0.

Examples To save trace data into the file *trace1* in the subdirectory *traces*, type the following command:

```
WSS# save trace traces/trace1
```

set trace authentication

Traces authentication information.

Syntax `set trace authentication [mac-addr mac-address] [port port-num] [user username] [level level]`

mac-addr <i>mac-address</i>	Traces a MAC address. Specify a MAC address, using colons to separate the octets (for example, 00:11:22:aa:bb:cc).
port <i>port-num</i>	Traces a port number. Specify a WSS port number between 1 and 22.
user <i>username</i>	Traces a user. Specify a username of up to 32 alphanumeric characters with no spaces.
level <i>level</i>	Determines the quantity of information included in the output. You can set the level with an integer from 1 to 10, where level 10 provides the most information. Levels 1 through 5 provide user-readable information. If you do not specify a level, level 5 is the default.

Defaults The default trace level is 5.

Access Enabled.

Examples The following command starts a trace for information about user *jose*'s authentication:

```
WSS# set trace authentication user jose
success: change accepted.
```

See Also

- [clear trace on page 560](#)
- [show trace on page 564](#)

set trace authorization

Traces authorization information.

Syntax `set trace authorization [mac-addr mac-address] [port port-num] [user username] [level level]`

mac-addr <i>mac-address</i>	Traces a MAC address. Specify a MAC address, using colons to separate the octets (for example, 00:11:22:aa:bb:cc).
port <i>port-num</i>	Traces a port number. Specify a WSS port number between 1 and 22.
user <i>username</i>	Traces a user. Specify a username of up to 80 alphanumeric characters with no spaces.
level <i>level</i>	Determines the quantity of information included in the output. You can set the level with an integer from 1 to 10, where level 10 provides the most information. Levels 1 through 5 provide user-readable information. If you do not specify a level, level 5 is the default.

Defaults The default trace level is 5.

Access Enabled.

Examples The following command starts a trace for information for authorization for MAC address 00:01:02:03:04:05:

```
WSS# set trace authorization mac-addr 00:01:02:03:04:05  
success: change accepted.
```

See Also

- [clear trace on page 560](#)
- [show trace on page 564](#)

set trace dot1x

Traces 802.1X sessions.

Syntax `set trace dot1x [mac-addr mac-address] [port port-num] [user username] [level level]`

mac-addr <i>mac-address</i>	Traces a MAC address. Specify a MAC address, using colons to separate the octets (for example, 00:11:22:aa:bb:cc).
port <i>port-num</i>	Traces a port number. Specify a WSS port number between 1 and 22.
user <i>username</i>	Traces a user. Specify a username of up to 80 alphanumeric characters with no spaces.
level <i>level</i>	Determines the quantity of information included in the output. You can set the level with an integer from 1 to 10, where level 10 provides the most information. Levels 1 through 5 provide user-readable information. If you do not specify a level, level 5 is the default.

Defaults The default trace level is 5.

Access Enabled.

Examples The following command starts a trace for the 802.1X sessions for MAC address 00:01:02:03:04:05:

```
WSS# set trace dot1x mac-addr 00:01:02:03:04:05:
success: change accepted.
```

See Also

- **clear trace on page 560**
- **show trace on page 564**

set trace sm

Traces session manager activity.

Syntax `set trace sm [mac-addr mac-address] [port port-num] [user username] [level level]`

mac-addr <i>mac-address</i>	Traces a MAC address. Specify a MAC address, using colons to separate the octets (for example, 00:11:22:aa:bb:cc).
port <i>port-num</i>	Traces a port number. Specify a WSS port number between 1 and 22.
user <i>username</i>	Traces a user. Specify a username of up to 80 alphanumeric characters, with no spaces.
level <i>level</i>	Determines the quantity of information included in the output. You can set the level with an integer from 1 to 10, where level 10 provides the most information. Levels 1 through 5 provide user-readable information. If you do not specify a level, level 5 is the default.

Defaults The default trace level is 5.

Access Enabled.

Examples Type the following command to trace session manager activity for MAC address 00:01:02:03:04:05:

```
WSS# set trace sm mac-addr 00:01:02:03:04:05:
success: change accepted.
```

See Also

- **clear trace on page 560**
- **show trace on page 564**

show trace

Displays information about traces that are currently configured on the WSS, or all possible trace options.

Syntax `show trace [all]`

all Displays all possible trace options and their configuration.

Defaults None.

Access Enabled.

Examples To view the traces currently running, type the following command:

WSS# show trace

milliseconds spent printing traces: 1885.614

Trace Area	Level	Mac	User	Port Filter
-----	-----	-----	-----	-----
dot1x	5		0	
sm	5		0	

See Also

- [clear trace on page 560](#)
- [set trace authentication on page 561](#)
- [set trace authorization on page 561](#)
- [set trace dot1x on page 562](#)
- [set trace sm on page 563](#)

Snoop Commands

Use snoop commands to monitor wireless traffic, by using a AP as a sniffing device. The AP copies the sniffed 802.11 packets and sends the copies to an observer, which is typically a protocol analyzer such as Ethereal or Tethereal.

(For more information, including setup instructions for the monitoring station, see the “Remotely Monitoring Traffic” section in the “Troubleshooting a WSS” chapter of the *Nortel WLAN Security Switch 2300 Series Configuration Guide*.)

This chapter presents snoop commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Remote monitoring (snooping)

set snoop on page 567

show snoop info on page 571

clear snoop on page 565

set snoop map on page 568

show snoop map on page 571

show snoop on page 570

clear snoop map on page 566

set snoop mode on page 569

show snoop stats on page 572

clear snoop

Deletes a snoop filter.

Syntax `clear snoop filter-name`

filter-name Name of the snoop filter.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command deletes snoop filter *snoop1*:

WSS# clear snoop snoop1

See Also

- **set snoop on page 567**
- **show snoop info on page 571**

clear snoop map

Removes a snoop filter from an AP radio.

Examples `clear snoop map filter-name ap ap-num radio {1 | 2}`

<i>filter-name</i>	Name of the snoop filter.
ap <i>ap-num</i>	Number of a AP to which to snoop filter is mapped.
radio 1	Radio 1 of the AP.
radio 2	Radio 2 of the AP. (This option does not apply to single-radio models.)

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command removes snoop filter *snoop2* from radio 2 on AP 3:

WSS# clear snoop map snoop2 ap 3 radio 2

success: change accepted.

The following command removes all snoop filter mappings from all radios:

WSS# clear snoop map all

success: change accepted.

See Also

- **set snoop map on page 568**
- **show snoop on page 570**
- **show snoop map on page 571**

set snoop

Configures a snoop filter.

Syntax `set snoop filter-name [condition-list] [observer ip-addr] [snap-length num]`

<i>filter-name</i>	Name for the filter. The name can be up to 15 alphanumeric characters, with no spaces.
<i>condition-list</i>	<p>Match criteria for packets. Conditions in the list are ANDed. Therefore, to be copied and sent to an observer, a packet must match all criteria in the <i>condition-list</i>. You can specify up to eight of the following conditions in a filter, in any order or combination:</p> <ul style="list-style-type: none"> • frame-type {eq neq} {beacon control data management probe} • channel {eq neq} <i>channel</i> • bssid {eq neq} <i>bssid</i> • src-mac {eq neq lt gt} <i>mac-addr</i> • dest-mac {eq neq lt gt} <i>mac-addr</i> • host-mac {eq neq lt gt} <i>mac-addr</i> • mac-pair <i>mac-addr1 mac-addr2</i> <p>To match on packets to or from a specific MAC address, use the dest-mac or src-mac option. To match on both send and receive traffic for a host address, use the host-mac option. To match on a traffic flow (source and destination MAC addresses), use the mac-pair option. This option matches for either direction of a flow, and either MAC address can be the source or destination address.</p> <p>If you omit a condition, all packets match that condition. For example, if you omit frame-type, all frame types match the filter.</p> <p>For most conditions, you can use eq (equal) to match only on traffic that matches the condition value. Use neq (not equal) to match only on traffic that is not equal to the condition value.</p> <p>The src-mac, dest-mac, and host-mac conditions also support lt (less than) and gt (greater than).</p>
observer <i>ip-addr</i>	Specifies the IP address of the station where the protocol analyzer is located. If you do not specify an observer, the AP radio still counts the packets that match the filter.
snap-length <i>num</i>	Specifies the maximum number of bytes to capture. If you do not specify a length, the entire packet is copied and sent to the observer. Nortel recommends specifying a snap length of 100 bytes or less.

Defaults No snoop filters are configured by default.

Access Enabled.

History

Version 4.0	Command introduced
Version 5.0	New Boolean operators: lt (less than) and gt (greater than). The new options apply to src-mac , dest-mac , and host-mac .

Usage Traffic that matches a snoop filter is copied after it is decrypted. The decrypted (clear) version is sent to the observer.

For best results:

- Do not specify an observer that is associated with the AP where the snoop filter is running. This configuration causes an endless cycle of snoop traffic.
- If the snoop filter is running on a AP, and the AP used a DHCP server in its local subnet to configure its IP information, and the AP did not receive a default router (gateway) address as a result, the observer must also be in the same subnet. Without a default router, the AP cannot find the observer.
- The AP that is running a snoop filter forwards snooped packets directly to the observer. This is a one-way communication, from the AP to the observer. If the observer is not present, the AP still sends the snoop packets, which use bandwidth. If the observer is present but is not listening to TZSP traffic, the observer continuously sends ICMP error indications back to the AP. These ICMP messages can affect network and AP performance.

Examples The following command configures a snoop filter named *snoop1* that matches on all traffic, and copies the traffic to the device that has IP address 10.10.30.2:

```
WSS# set snoop snoop1 observer 10.10.30.2 snap-length 100
```

The following command configures a snoop filter named *snoop2* that matches on all data traffic between the device with MAC address aa:bb:cc:dd:ee:ff and the device with MAC address 11:22:33:44:55:66, and copies the traffic to the device that has IP address 10.10.30.3:

```
WSS# set snoop snoop2 frame-type eq data mac-pair aa:bb:cc:dd:ee:ff  
11:22:33:44:55:66 observer 10.10.30.3 snap-length 100
```

See Also

- **clear snoop** on page 565
- **set snoop map** on page 568
- **set snoop mode** on page 569
- **show snoop info** on page 571
- **show snoop stats** on page 572

set snoop map

Maps a snoop filter to a radio on a AP. A snoop filter does take effect until you map it to a radio and enable the filter.

Examples `set snoop map filter-name ap ap-num radio {1 | 2}`

<i>filter-name</i>	Name of the snoop filter.
ap <i>ap-num</i>	Number of a AP to which to map the snoop filter.
radio 1	Radio 1 of the AP.
radio 2	Radio 2 of the AP. (This option does not apply to single-radio models.)

Defaults Snoop filters are unmapped by default.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage You can map the same filter to more than one radio. You can map up to eight filters to the same radio. If more than one filter has the same observer, the AP sends only one copy of a packet that matches a filter to the observer. After the first match, the AP sends the packet and stops comparing the packet against other filters for the same observer.

If the filter does not have an observer, the AP still maintains a counter of the number of packets that match the filter. (See **show snoop stats on page 572**.)

Examples The following command maps snoop filter *snoop1* to radio 2 on AP 3:

```
WSS# set snoop map snoop1 ap 3 radio 2
success: change accepted.
```

See Also

- **clear snoop map on page 566**
- **set snoop on page 567**
- **set snoop mode on page 569**
- **show snoop map on page 571**
- **show snoop stats on page 572**

set snoop mode

Enables a snoop filter. A snoop filter does not take effect until you map it to an AP radio and enable the filter.

```
Examples set snoop {filter-name | all}
mode {enable [stop-after num-pkts] | disable}
```

<i>filter-name</i> all }	Name of the snoop filter. Specify all to enable all snoop filters.
enable [stop-after <i>num-pkts</i>]	Enables the snoop filter. The stop-after option disables the filter after the specified number of packets match the filter. Without the stop-after option, the filter operates until you disable it or until the AP is restarted.
disable	Disables the snoop filter.

Defaults Snoop filters are disabled by default.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage The filter mode is not retained if you change the filter configuration or disable and reenable the radio, or when the AP or the WSS is restarted. You must reenable the filter to place it back into effect.

Examples The following command enables snoop filter *snoop1*, and configures the filter to stop after 5000 packets match the filter:

```
WSS# set snoop snoop1 mode enable stop-after 5000  
success: filter 'snoop1' enabled
```

See Also

- **show snoop on page 570**
- **show snoop info on page 571**
- **show snoop map on page 571**
- **show snoop stats on page 572**

show snoop

Displays the AP radio mapping for all snoop filters.

Syntax `show snoop`

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage To display the mappings for a specific AP radio, use the **show snoop map** command.

Examples The following command shows the AP radio mappings for all snoop filters configured on a WSS:

```
WSS# show snoop  
ap: 3      Radio: 2  
    snoop1  
    snoop2  
ap: 2      Radio: 2  
    snoop2
```

See Also

- **clear snoop map on page 566**
- **set snoop map on page 568**
- **show snoop map on page 571**

show snoop info

Shows the configured snoop filters.

Syntax `show snoop filter-name`

filter-name Name of the snoop filter.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Examples The following command shows the snoop filters configured in the examples above:

WSS# show snoop info

```
snoop1:
  observer 10.10.30.2 snap-length 100
  all packets
snoop2:
  observer 10.10.30.3 snap-length 100
  frame-type eq data
  mac-pair (aa:bb:cc:dd:ee:ff, 11:22:33:44:55:66)
```

See Also

- [clear snoop on page 565](#)
- [set snoop on page 567](#)

show snoop map

Shows the AP radios that are mapped to a specific snoop filter.

Syntax `show snoop map filter-name`

filter-name Name of the snoop filter.

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage To display the mappings for all snoop filters, use the **show snoop** command.

Examples The following command shows the mapping for snoop filter *snoop1*:

```
WSS# show snoop map snoop1
filter 'snoop1' mapping
```

ap: 3 Radio: 2

See Also

- [clear snoop map on page 566](#)
- [set snoop map on page 568](#)
- [show snoop on page 570](#)

show snoop stats

Displays statistics for enabled snoop filters.

Examples `show snoop stats [filter-name [ap-num [radio {1 | 2}]]]`

<i>filter-name</i>	Name of the snoop filter.
ap <i>ap-num</i>	Number of a AP to which the snoop filter is mapped.
radio 1	Radio 1 of the AP.
radio 2	Radio 2 of the AP. (This option does not apply to single-radio models.)

Defaults None.

Access Enabled.

History Introduced in WSS Software Version 4.0.

Usage The AP retains statistics for a snoop filter until the filter is changed or disabled. The AP then clears the statistics.

Examples The following command shows statistics for snoop filter *snoop1*:

WSS# show snoop stats snoop1

Filter	ap	Radio	Rx Match	Tx Match	Dropped	Stop-After
snoop1	3	1	96	4	0	stopped

Table 88 describes the fields in this display.

Table 1: show snoop stats Output

Field	Description
Filter	Name of the snoop filter.
ap	AP containing the radio to which the filter is mapped.
Radio	Radio to which the filter is mapped.
Rx Match	Number of packets received by the radio that match the filter.
Tx Match	Number of packets sent by the radio that match the filter.
Dropped	Number of packets that matched the filter but that were not copied to the observer due to memory or network problems.
Stop-After	Filter state: <ul style="list-style-type: none">• running—enabled• stopped—disabled• <i>number-of-packets</i>—If the filter is running and the stop-after option was used to stop the filter, this field displays the number of packets that still need to match before the filter is stopped.

System Log Commands

Use the system log commands to record information for monitoring and troubleshooting. WSS Software system logs are based on RFC 3164, which defines the log protocol.

This chapter presents system log commands alphabetically. Use the following table to locate commands in this chapter based on their use.

System Logs	set log on page 576
	set log mark on page 578
	show log buffer on page 579
	show log config on page 581
	show log trace on page 581
	clear log on page 575

clear log

Clears the log messages stored in the log buffer, or removes the configuration for a syslog server and stops sending log messages to that server.

Syntax `clear log [buffer | server ip-addr]`

buffer	Deletes the log messages stored in nonvolatile storage.
server <i>ip-addr</i>	Deletes the configuration for and stops sending log messages to the syslog server at this IP address. Specify an address in dotted decimal notation.

Defaults None.

Access Enabled.

Examples To stop sending system logging messages to a server at 192.168.253.11, type the following command:

WSS# clear log server 192.168.253.11

success: change accepted.

Type the following command to clear all messages from the log buffer:

WSS# clear log buffer

success: change accepted.

See Also

- **clear log trace on page 559**

- [set log on page 576](#)

set log

Enables or disables logging of WSS and AP events to the WSS log buffer or other logging destination and sets the level of the events logged. For logging to a syslog server only, you can also set the facility logged.

Syntax `set log {buffer | console | current | sessions | trace} [severity severity-level] [enable | disable]`

`set log server ip-addr [port port-number] severity severity-level [local-facility facility-level]`

buffer	Sets log parameters for the log buffer in nonvolatile storage.
console	Sets log parameters for console sessions.
current	Sets log parameters for the current Telnet or console session. These settings are not stored in nonvolatile memory.
server <i>ip-addr</i>	Sets log parameters for a syslog server. Specify an address in dotted decimal notation.
sessions	Sets the default log values for Telnet sessions. You can set defaults for the following log parameters: <ul style="list-style-type: none">• Severity• Logging state (enabled or disabled) To override the session defaults for an individual session, type the set log command from within the session and use the current option.
trace	Sets log parameters for trace files.
port <i>port-number</i>	Sets the TCP port for sending messages to the syslog server. You can specify a number from 1 to 65535. The default syslog port is 514.

severity *severity-level* Logs events at a severity level greater than or equal to the level specified. Specify one of the following:

- **emergency**—The WSS is unusable.
- **alert**—Action must be taken immediately.
- **critical**—You must resolve the critical conditions. If the conditions are not resolved, the WSS can reboot or shut down.
- **error**—The WSS is missing data or is unable to form a connection.
- **warning**—A possible problem exists.
- **notice**—Events that potentially can cause system problems have occurred. These are logged for diagnostic purposes. No action is required.
- **info**—Informational messages only. No problem exists.
- **debug**—Output from debugging.

local-facility *facility-level*

For messages sent to a syslog server, maps all messages of the severity you specify to one of the standard local log facilities defined in RFC 3164. You can specify one of the following values:

- **0**—maps all messages to *local0*.
- **1**—maps all messages to *local1*.
- **2**—maps all messages to *local2*.
- **3**—maps all messages to *local3*.
- **4**—maps all messages to *local4*.
- **5**—maps all messages to *local5*.
- **6**—maps all messages to *local6*.
- **7**—maps all messages to *local7*.

If you do not specify a local facility, WSS Software sends the messages with their default WSS Software facilities. For example, AAA messages are sent with facility 4 and boot messages are sent with facility 20 by default.

enable Enables messages to the specified target.

disable Disables messages to the specified target.

Defaults

- Events at the error level and higher are logged to the WSS console.
- Events at the error level and higher are logged to the WSS system buffer.
- Trace logging is enabled, and debug-level output is stored in the WSS trace buffer.

Access Enabled.

History Option **port** added in Version 4.1

Usage Using the command with only **enable** or **disable** turns logging on or off for the target at all levels. For example, entering **set log buffer enable** with no other keywords turns on logging to the system buffer of all facilities at all levels. Entering **set log buffer disable** with no other keywords turns off all logging to the buffer.

Examples To log only emergency, alert, and critical system events to the console, type the following command:

```
WSS# set log console severity critical enable
success: change accepted.
```

See Also

- **show log config on page 581**
- **clear log on page 575**

set log mark

Configures WSS Software to generate mark messages at regular intervals. The mark messages indicate the current system time and date. Nortel can use the mark messages to determine the approximate time when a system restart or other event causing a system outage occurred.

Syntax **set log mark** [**enable** | **disable**] [**severity** *level*]
[**interval** *interval*]

enable	Enables the mark messages.
disable	Disables the mark messages.
severity <i>level</i>	Log severity at which the messages are logged: <ul style="list-style-type: none">• emergency• alert• critical• error• warning• notice• info• debug
interval <i>interval</i>	Interval at which WSS Software generates the mark messages. You can specify from 1 to 2147483647 seconds.

Defaults Mark messages are disabled by default. When they are enabled, WSS Software generates a message at the notice level once every 300 seconds by default.

Access Enabled.

History Introduced in WSS Software Version 4.1.

Examples The following command enables mark messages:

```
WSS# set log mark enable
success: change accepted.
```

See Also [show log config on page 581](#)

set log trace mbytes

This command is deprecated in WSS Software Version 4.0.

show log buffer

Displays system information stored in the nonvolatile log buffer or the trace buffer.

Syntax `show log buffer` [*{+|-}number-of-messages*] [**facility** *facility-name*] [**matching string**] [**severity** *severity-level*]

buffer	Displays the log messages in nonvolatile storage.
<i>+ -number-of-messages</i>	Displays the number of messages specified as follows: <ul style="list-style-type: none"> • A positive number (for example, +100), displays that number of log entries starting from the oldest in the log. • A negative number (for example, -100) displays that number of log entries starting from newest in the log.
facility <i>facility-name</i>	Area of WSS Software that is sending the log message. Type a space and a question mark (?) after show log buffer facility for a list of valid facilities.
matching string	Displays messages that match a string—for example, a username or IP address.

severity *severity-level* Displays messages at a severity level greater than or equal to the level specified. Specify one of the following:

- **emergency**—The WSS is unusable.
- **alert**—Action must be taken immediately.
- **critical**—You must resolve the critical conditions. If the conditions are not resolved, the WSS can reboot or shut down.
- **error**—The WSS is missing data or is unable to form a connection.
- **warning**—A possible problem exists.
- **notice**—Events that potentially can cause system problems have occurred. These are logged for diagnostic purposes. No action is required.
- **info**—Informational messages only. No problem exists.
- **debug**—Output from debugging.

Defaults None.

Access Enabled.

History

Version 5.0 Option **COPP** removed. The option is not applicable to WSS Software Version 5.0.

Usage The debug level produces a lot of messages, many of which can appear to be somewhat cryptic. Debug messages are used primarily by Nortel for troubleshooting and are not intended for administrator use.

Examples Type the following command to see the facilities for which you can view event messages archived in the buffer:

WSS# show log buffer facility ?

<facility name> Select one of: **KERNEL, AAA, SYSLOGD, ACL, AP, APM, ARP, ASO, BOOT, CLI, CLUSTER, CRYPTO, DOT1X, NET, ETHERNET, GATEWAY, HTTPD, IGMP, IP, MISC, NOSE, NP, RAND, RESOLV, RIB, ROAM, ROGUE, SM, SNMPD, SPAN, STORE, SYS, TAGMGR, TBRIDGE, TCPSSL, TELNET, TFTP, TLS, TUNNEL, VLAN, X509, XML, RAPDA, WEBVIEW, EAP, FP, STAT, SSHD, SUP, DNSD, CONFIG, BACKUP.**

The following command displays logged messages for the AAA facility:

WSS# show log buffer facility AAA

AAA Jun. 25 09:11:32.579848 ERROR AAA_NOTIFY_ERR: AAA got SM special event (98) on locality 3950 which is gone

See Also

- **clear log on page 575**
- **show log config on page 581**

show log config

Displays log configuration information.

Syntax `show log config`

Defaults None.

Access Enabled.

Examples To display how logging is configured, type the following command:

WSS# show log config

```
Logging console:           disabled
Logging console severity:  DEBUG
Logging sessions:         disabled
Logging sessions severity: INFO
Logging buffer:           enabled
Logging buffer severity:   WARNING
Logging trace:            enabled
Logging trace severity:   DEBUG
Logging buffer size:      10485760 bytes
Log marking:              disabled
Log marking severity:     NOTICE
Log marking interval:     300 seconds

Logging server:           172.21.12.19 port 514 severity EMERGENCY

Current session:          disabled
Current session severity: INFO
```

See Also

- **set log on page 576**
- **clear log on page 575**

show log trace

Displays system information stored in the nonvolatile log buffer or the trace buffer.

Syntax `show log trace` [{+|-|/}*number-of-messages*] [**facility** *facility-name*] [**matching string**]
[**severity** *severity-level*]

trace	Displays the log messages in the trace buffer.
+ - / <i>number-of-messages</i>	Displays the number of messages specified as follows: <ul style="list-style-type: none">• A positive number (for example, +100), displays that number of log entries starting from the oldest in the log.• A negative number (for example, -100) displays that number of log entries starting from newest in the log.• A number preceded by a slash (for example, /100) displays that number of the most recent log entries in the log, starting with the least recent.
facility <i>facility-name</i>	Area of WSS Software that is sending the log message. Type a space and a question mark (?) after show log trace facility for a list of valid facilities.
matching string	Displays messages that match a string—for example, a username or IP address.
severity <i>severity-level</i>	Displays messages at a severity level greater than or equal to the level specified. Specify one of the following: <ul style="list-style-type: none">• emergency—The WSS is unusable.• alert—Action must be taken immediately.• critical—You must resolve the critical conditions. If the conditions are not resolved, the WSS can reboot or shut down.• error—The WSS is missing data or is unable to form a connection.• warning—A possible problem exists.• notice—Events that potentially can cause system problems have occurred. These are logged for diagnostic purposes. No action is required.• info—Informational messages only. No problem exists.• debug—Output from debugging.

Defaults None.

Access Enabled.

History

Version 5.0 Option **COPP** removed. The option is not applicable to WSS Software Version 5.0.

Examples Type the following command to see the facilities for which you can view event messages archived in the buffer:

WSS# show log trace facility ?

<facility name> Select one of: KERNEL, AAA, SYSLOGD, ACL, APM, ARP, ASO, BOOT, CLI, CLUSTER, CRYPTO, DOT1X, ENCAP, ETHERNET, GATEWAY, HTTPD, IGMP, IP, MISC, NOSE, NP, RAND, RESOLV, RIB, ROAM, ROGUE, SM, SNMPD, SPAN, STORE, SYS, TAGMGR, TBRIDGE, TCPSSL, TELNET, TFTP, TLS, TUNNEL, VLAN, X509, XML, **AP**, RAPDA, WEBVIEW, EAP, PORTCONFIG, FP.

The following command displays the newest five trace log entries for the ROGUE facility:

WSS# show log trace +5 facility ROGUE

```
ROGUE Oct 28 16:30:19.695141 ERROR ROGUE_AP_ALERT: Xmtr Mac 01:0b:0e:ff:00:3b Po
rt 7 Radio 1 Chan 36 RSSI 18 Tech DOT_11A SSID nortel
      ROGUE Oct 28 16:30:19.7046
37 ERROR ROGUE_AP_ALERT: Xmtr Mac 01:0b:0e:00:09:5f Port 7 Radio 1 Chan 36 RSSI
15 Tech DOT_11A SSID examplewlan
      ROGUE Oct 28 16:30:19.711253 ERROR ROGUE_AP_ALER
T: Xmtr Mac 01:0b:0e:00:06:b7 Port 7 Radio 1 Chan 36 RSSI 36 Tech DOT_11A SSID wlan-7
      ROGUE Oct 28 16:30:19.717954 ERROR ROGUE_AP_ALERT: Xmtr Mac 00:0b:0e:00:0
6:8f Port 7 Radio 1 Chan 36 RSSI 13 Tech DOT_11A SSID nortel
      ROGUE Oct 28 16:30:
19.727069 ERROR ROGUE_AP_ALERT: Xmtr Mac 01:0b:0e:da:da:dd Port 7 Radio 1 Chan 3
6 RSSI 22 Tech DOT_11A SSID nortel
```

See Also

- **clear log on page 575**
- **show log config on page 581**

Boot Prompt Commands

Boot prompt commands enable you to perform basic tasks, including booting a system image file, from the boot prompt (boot>). A CLI session enters the boot prompt if WSS Software does not boot successfully or you intentionally interrupt the boot process. To interrupt the boot process, press **q** followed by **Enter** (return).



Caution! Generally, boot prompt commands are used only for troubleshooting. Nortel recommends that you use these commands only when working with Nortel to diagnose a system issue. In particular, commands that change boot parameters can interfere with an WSS's ability to boot successfully.

This chapter presents boot prompt commands alphabetically. Use the following table to locate commands in this chapter based on their use.

Command Information	ls on page 594 help on page 593
Booting	boot on page 587 reset on page 595 autoboot on page 586 dhcp on page 591
File Management	dir on page 592 fver on page 593 version on page 599
Boot Profile Management	show on page 596 create on page 590 next on page 595 change on page 588 delete on page 590
Diagnostics	diag on page 592 test on page 599

autoboot

Displays or changes the state of the autoboot option. The autoboot option controls whether a WSS automatically boots a system image after initializing the hardware, following a system reset or power cycle.

Syntax `autoboot [ON | on | OFF | off]`

ON	Enables the autoboot option.
on	Same effect as ON .
OFF	Disables the autoboot option.
off	Same effect as OFF .

Defaults The autoboot option is enabled by default.

Access Boot prompt.

Examples The following command displays the current setting of the autoboot option:

boot> autoboot

The autoboot flag is on.

See Also [boot on page 587](#)

boot

Loads and executes a system image file.

Syntax `boot [BT=type] [DEV=device] [FN=filename] [HA=ip-addr] [FL=num] [OPT=option] [OPT+=option]`

- | | |
|---------------------------|---|
| BT=<i>type</i> | <p>Boot type:</p> <ul style="list-style-type: none"> • c—Compact flash. Boots using nonvolatile storage or a flash card. • n—Network. Boots using a TFTP server. |
| DEV=<i>device</i> | <p>Location of the system image file:</p> <ul style="list-style-type: none"> • c:—Nonvolatile storage area containing boot partition 0 • d:—Nonvolatile storage area containing boot partition 1 • e:—Primary partition of the flash card in the flash card slot • f:—Secondary partition of the flash card in the flash card slot • boot0—boot partition 0 • boot1—boot partition 1 <p>When the boot type is n (network), the device can be one of the following:</p> <ul style="list-style-type: none"> • emac1—Port 1 on a 2350 • emac2—Port 2 on a 2350-2 • mgmt or tsec0—The 10/100 port labelled Mgmt on an 2382 |
| FN=<i>filename</i> | System image filename. |
| HA=<i>ip-addr</i> | Host address (IP address) of a TFTP server. This parameter applies only when the boot type is n (network). |
| FL=<i>num</i> | Number representing the bit settings of boot flags to pass to the booted system image. Use this parameter only if advised to do so by Nortel. |
| OPT=<i>option</i> | String up to 128 bytes of boot options to pass to the booted system image <i>instead of</i> the boot option(s) in the currently active boot profile. The options temporarily replace the options in the boot profile. Use this parameter only if advised to do so by Nortel. |
| OPT+=<i>option</i> | String up to 128 bytes of boot options to pass to the booted system image <i>in addition to</i> the boot option(s) in the currently active boot profile. The options are appended to the options already in the boot profile. Use this parameter only if advised to do so by Nortel. |

Defaults The boot settings in the currently active boot profile are used by default.

Access Boot prompt.

Usage If you use an optional parameter, the parameter setting overrides the setting of the same parameter in the currently active boot profile. However, the boot profile itself is not changed. To display the currently active boot profile, use the **show** command. To change the currently active boot profile, use the **change** command.

Examples The following command loads system image file WSS010101.020 from boot partition 1:

```
boot> boot FN=WSS010101.020 DEV=boot1
```

```
Compact Flash load from boot1:testcfg matches WSS010101.020.
```

```
unzip: Inflating ramdisk_1.1.1.. OK
```

```
unzip file len 36085486 OK
```

Copyright (c) 1996, 1997, 1998, 1999, 2000, 2001, 2002, 2003

The NetBSD Foundation, Inc. All rights reserved.

Copyright (c) 1982, 1986, 1989, 1991, 1993

The Regents of the University of California. All rights reserved.

Power Cycle Reboot

Detecting hardware...done.

readclock: 2003-10-8 2:9:50.67 UTC=>1065578990.670000 (1064992894)

init: Creating mfs /dev

erase ^H, werase ^W, kill ^U, intr ^C, status ^T

Doing Nortel mounts and links

Starting nos_mon...

nos_mon:ps: not found

SYSLOGD Oct 08 02:10:05.477814 CRITICAL SYSTEM_READY: The system has finished booting.

Copyright (c) 2002, 2003

Nortel, Inc.

Username:

Password:

See Also

- **change** on page 588
- **show** on page 596

change

Changes parameters in the currently active boot profile. (For information about boot profiles, see **show** on page 596.)

Syntax **change**

Defaults The default boot type is **c** (compact flash). The default filename is *default*. The default flags setting is 0x00000000 (all flags disabled) and the default options list is `run=nos;boot=0`. The default device setting is the boot partition specified by the most recent **set boot partition** command typed at the Enabled level of the CLI, or boot 0 if the command has never been typed.

Access Boot prompt.

Usage After you type the **change** command, the system interactively displays the current setting of each parameter and prompts you for the new setting. When prompted, type the new setting, press Enter to accept the current setting, or type . (period) to change the setting to its default value. To back up to the previous parameter, type - (hyphen).

For information about each of the boot parameters you can set, see **show on page 596**.

Examples The following command enters the configuration mode for the currently active boot profile, changes the device to **boot1**, and leaves the other parameters with their current settings:

```
boot> change
Changing the default configuration is not recommended.
Are you sure that you want to proceed? (y/n)y
```

```
BOOT TYPE: [c]
DEVICE: [boot0:]boot1
FILENAME: [default]
FLAGS: [0x00000000]
OPTIONS: [run=nos;boot=0]
```

The following command enters the configuration mode for the currently active boot profile and configures the WSS (in this example, a 2350) to boot using a TFTP server:

```
boot> change
Changing the default configuration is not recommended.
Are you sure that you want to proceed? (y/n)y
```

```
BOOT TYPE: [c]> n
DEVICE: [boot0:]> emac1
FILENAME: [default]> bootfile
HOST IP: [0.0.0.0]> 172.16.0.1
LOCAL IP: [0.0.0.0]> 172.16.0.21
GATEWAY IP: [0.0.0.0]> 172.16.0.20
IP MASK: [0.0.0.0]> 255.255.255.0
FLAGS: [0x00000000]>
OPTIONS: [run=nos;boot=0]>
```

See Also

- **boot on page 587**
- **create on page 590**
- **delete on page 590**
- **dhcp on page 591**
- **next on page 595**
- **show on page 596**

create

Creates a new boot profile. (For information about boot profiles, see **show on page 596**.)

Syntax **create**

Defaults The new boot profile has the same settings as the currently active boot profile by default.

Access Boot prompt.

Usage A WSS can have up to four boot profiles. The boot profiles are stored in slots, numbered 0 through 3. When you create a new profile, the system uses the next available slot for the profile. If all four slots already contain profiles and you try to create a fifth profile, the switch displays a message advising you to change one of the existing profiles instead.

To make a new boot profile the currently active boot profile, use the **next** command. To change boot parameter settings, use the **change** command.

Examples The following command creates a new boot profile in slot 1 on a WSS that currently has only one boot profile, in slot 0:

boot> create

```
BOOT Index: 1
BOOT TYPE:  c
DEVICE:    boot1:
FILENAME:  default
FLAGS:    00000000
OPTIONS:   run=nos;boot=0
```

See Also

- **change on page 588**
- **delete on page 590**
- **next on page 595**
- **show on page 596**

delete

Removes the currently active boot profile. (For information about boot profiles, see **show on page 596**.)

Syntax **delete**

Defaults None.

Access Boot prompt.

Usage When you type the **delete** command, the next-lower numbered boot profile becomes the active profile. For example, if the currently active profile is number 3, profile number 2 becomes active after you type **delete** to delete profile 3. You cannot delete boot profile 0.

Examples To remove the currently active boot profile, type the following command:

boot> delete

```
BOOT Index: 1
BOOT TYPE:  c
DEVICE:    boot1:
FILENAME:  default
FLAGS:    00000000
OPTIONS:   run=nos;boot=0
```

See Also

- **change on page 588**
- **create on page 590**
- **next on page 595**
- **show on page 596**

dhcp

Displays or changes the state of the DHCP option. The DHCP option controls whether a WSS uses DHCP to obtain its IP address when it is booted using a TFTP server.

Syntax **dhcp [ON | on | OFF | off]**

ON	Enables the DHCP option.
on	Same effect as ON .
OFF	Disables the DHCP option.
off	Same effect as OFF .

Defaults The DHCP option is disabled by default.

Access Boot prompt.

Examples The following command displays the current setting of the DHCP option:

boot> dhcp

DHCP is currently enabled.

The following command disables the DHCP option:

boot> dhcp

DHCP is currently disabled.

See Also **boot on page 587**

diag

Accesses the diagnostic mode.

Syntax `diag`

Defaults The diagnostic mode is disabled by default.

Access Boot prompt.

Usage Access to the diagnostic mode requires a password, which is not user configurable. Use this mode only if advised to do so by Nortel.

dir

Displays the boot code and system image files on a WSS.

Syntax `dir [c: | d: | e: | f: | boot0 | boot1]`

c:	Nonvolatile storage area containing boot partition 0 (primary).
d:	Nonvolatile storage area containing boot partition 1 (secondary).
e:	Primary partition of the flash card in the flash card slot.
f:	Secondary partition of the flash card in the flash card slot.
boot0	Boot partition 0.
boot1	Boot partition 1.

Defaults None.

Access Boot prompt.

Usage To display the system image software versions, use the **fver** command. This command does not list the boot code versions. To display the boot code versions, use the **version** command.

Examples The following command displays all the boot code and system image files on a WSS:

boot> dir

```
Internal Compact Flash Directory (Primary):
WSS010101.020      5523634 bytes
  BLOAD            696176 bytes
  BSTRAP           38056 bytes
```

```
Internal Compact Flash Directory (Secondary):
WSS010101.020      5524593 bytes
```

See Also

- **fver** on page 593
- **version** on page 599

fver

Displays the version of a system image file installed in a specific location on a WSS.

Syntax `fver {c: | d: | e: | f: | boot0: | boot1:} [filename]`

c:	Nonvolatile storage area containing boot partition 0 (primary).
d:	Nonvolatile storage area containing boot partition 1 (secondary).
e:	Primary partition of the flash card in the flash card slot.
f:	Secondary partition of the flash card in the flash card slot.
boot0:	Boot partition 0.
boot1:	Boot partition 1.
<i>[filename]</i>	System image filename.

Defaults None.

Access Boot prompt.

Usage To display the image filenames, use the **dir** command. This command does not list the boot code versions. To display the boot code versions, use the **version** command.

Examples The following command displays the system image version installed in boot partition 1:

```
boot> fver boot1
File boot1:default version is 1.1.0.98.
```

See Also

- [dir on page 592](#)
- [version on page 599](#)

help

Displays a list of all the boot prompt commands or detailed information for an individual command.

Syntax `help [command-name]`

command-name Boot prompt command.

Defaults None.

Access Boot prompt.

Usage If you specify a command name, detailed information is displayed for that command. If you do not specify a command name, all the boot prompt commands are listed.

Examples The following command displays detailed information for the **fver** command:

boot> help fver

fver Display the version of the specified device:filename.

USAGE: fver [c:file|d:file|e:file|f:file|boot0:file|boot1:file|boot2:file|boot3:file]

Command to display the version of the compressed image file associated with the given device:filename.

See Also **Is on page 594**

Is

Displays a list of the boot prompt commands.

Syntax **Is**

Defaults None.

Access Boot prompt.

Usage To display help for an individual command, type help followed by the command name (for example, **help boot**).

Examples To display a list of the commands available at the boot prompt, type the following command:

boot> **Is**

Is	Display a list of all commands and descriptions.
help	Display help information for each command.
autoboot	Display the state of, enable, or disable the autoboot option.
boot	Load and execute an image using the current boot configuration profile.
change	Change the current boot configuration profile.
create	Create a new boot configuration profile.
delete	Delete the current boot configuration profile.
next	Select the next boot configuration profile.
show	Display the current boot configuration profile.
dir	Display the contents of the specified boot partition.
fver	Display the version of the loadable image specified by device:filename.
version	Display HW and Bootstrap/Bootloader version information.
reset	Reset the system.
test	Display the state of, enable, or disable the tests option.
diag	Access the diagnostic command CLI.

See Also [help on page 593](#)

next

Activates and displays the boot profile in the next boot profile slot. (For information about boot profiles, see [show on page 596](#).)

Syntax `next`

Defaults None.

Access Boot prompt.

Usage A WSS contains 4 boot profile slots, numbered 0 through 3. This command activates the boot profile in the next slot, in ascending numerical order. If the currently active slot is 3, the command activates the boot profile in slot 0.

Examples To activate the boot profile in the next slot and display the profile, type the following command:

boot> next

```
BOOT Index: 0
BOOT TYPE:  c
DEVICE:    boot1:
FILENAME:  testcfg
FLAGS:     00000000
OPTIONS:   run=nos;boot=0
```

See Also

- [change on page 588](#)
- [create on page 590](#)
- [delete on page 590](#)
- [show on page 596](#)

reset

Resets a WSS's hardware.

Syntax `reset`

Defaults None.

Access Boot prompt.

Usage After resetting the hardware, the reset command attempts to load a system image file only if other boot settings are configured to do so.

Examples To immediately reset the system, type the following command at the boot prompt:

boot> reset

```
Nortel WSS Bootstrap 1.17 Release
Testing Low Memory 1 .....
Testing Low Memory 2 .....
CISTPL_VERS_1: 4.1 <SanDisk> <SDP> <5/3 0.6>
Reset Cause (0x02) is COLD
```

Nortel WSS Bootstrap/Bootloader

```
Version 1.6.5 Release
Bootstrap 0 version: 1.17 Active
Bootloader 0 version: 1.6.5 Active
Bootstrap 1 version: 1.17
Bootloader 1 version: 1.6.3
```

```
WSS Board Revision: 3.
WSS Controller Revision: 24.
POE Board Revision: 1
POE Controller Revision: 6
```

```
BOOT Index: 0
BOOT TYPE: c
DEVICE: boot1:
FILENAME: default
FLAGS: 00000000
OPTIONS: run=nos;boot=0
```

See Also [boot on page 587](#)

show

Displays the currently active boot profile. A boot profile is a set of parameters that a WSS uses to control the boot process. Each boot profile contains the following parameters:

- **Boot type**—Either compact flash (local device on the WSS) or network (TFTP)
- **Boot device**—Location of the system image file
- **Filename**—System image file
- **Flags**—Number representing the bit settings of boot flags to pass to the booted system image.
- **Options**—String up to 128 bytes of boot options to pass to the booted system image

A WSS can have up to four boot profiles, numbered 0 through 3. Only one boot profile can be active at a time. You can create, change, and delete boot profiles. You also can activate another boot profile in place of the currently active one.

Syntax **show**

Defaults None.

Access Boot prompt.

Examples To display the currently active boot profile, type the following command at the boot prompt:

boot> show

```

BOOT Index: 0
BOOT TYPE:  c
DEVICE:    boot1:
FILENAME:  default
FLAGS:    00000000
OPTIONS:   run=nos;boot=0
    
```

The following is an example of a boot profile from a 2350 that is booted with a software image downloaded from a TFTP server. In the example, when the 2350 boots, it downloads a system image file called *bootfile* located on a TFTP server with address 172.16.0.1.

boot> show

```

BOOT Index: 0
BOOT TYPE:  n
DEVICE:    emac1
FILENAME:  bootfile
HOST IP:   172.16.0.1
LOCAL IP:  172.16.0.21
GATEWAY IP: 172.16.0.20
IP MASK:   255.255.255.0
FLAGS:    00000000
OPTIONS:   run=nos
    
```

Table 89 describes the fields in the display.

Table 1: Output for show

Field	Description
BOOT Index	Boot profile slot, which can be a number from 0 to 3.
BOOT TYPE	Boot type: <ul style="list-style-type: none"> • c—Compact flash. Boots using nonvolatile storage or a flash card. • n—Network. Boots using a TFTP server.

Table 1: Output for show (continued)

Field	Description
DEVICE	<p>Location of the system image file:</p> <ul style="list-style-type: none">• c:—Nonvolatile storage area containing boot partition 0• d:—Nonvolatile storage area containing boot partition 1• e:—Primary partition of the flash card in the flash card slot• f:—Secondary partition of the flash card in the flash card slot• boot0—boot partition 0• boot1—boot partition 1 <p>When the boot type is Network, the device can be one of the following:</p> <ul style="list-style-type: none">• emac1—Port 1 on a 2350• emac2—Port 2 on a 2350• mgmt or tsec0—The 10/100 port labelled Mgmt on an 2382
HOST IP	For network booting, the IP address of the host where the system image resides
LOCAL IP	For network booting, the IP address of the WSS. If the DHCP option is enabled, this does not need to be specified.
GATEWAY IP	For network booting, the default router (gateway) used by the WSS. If the DHCP option is enabled, this does not need to be specified.
IP MASK	For network booting, the subnet mask. If the DHCP option is enabled, this does not need to be specified.
FILENAME	System image file name.
FLAGS	Number representing the bit settings of boot flags to pass to the booted system image.
OPTIONS	String up to 128 bytes of boot options to pass to the booted system image.

See Also

- **change on page 588**
- **create on page 590**
- **delete on page 590**
- **dhcp on page 591**

- next on page 595

test

Displays or changes the state of the poweron test flag. The poweron test flag controls whether a WSS performs a set of self tests prior to the boot process.

Syntax test [ON | on | OFF | off]

ON	Enables the poweron test flag.
on	Same effect as ON .
OFF	Disables the poweron test flag.
off	Same effect as OFF .

Defaults The poweron test flag is disabled by default.

Access Boot prompt.

Examples The following command displays the current setting of the poweron test flag:

```
boot> test
```

The diagnostic execution flag is not set.

See Also boot on page 587

version

Displays version information for a WSS's hardware and boot code.

Syntax version

Defaults None.

Access Boot prompt.

Usage This command does not list the system image file versions installed in the boot partitions. To display system image file versions, use the **dir** or **fver** command.

Examples To display hardware and boot code version information, type the following command at the boot prompt:

```
boot> version
```

```
Nortel WSS Bootstrap/Bootloader
```

```
Version 1.6.5 Release
```

```
Bootstrap 0 version: 1.17 Active
```

```
Bootloader 0 version: 1.6.5 Active
```

```
Bootstrap 1 version: 1.17
```

Bootloader 1 version: 1.6.3

WSS Board Revision: 3.

WSS Controller Revision: 24.

POE Board Revision: 1

POE Controller Revision: 6

See Also

- **dir** on page 592
- **fver** on page 593

Command Index

Numerics

84100

CommandName
clear ap radio 237

A

access levels, command line 17
administrative access mode 9
advisory notices, explanations of 7
all access 17
asterisks (*)
 in MAC addresses 12
 in user globs 12
asterisks. See double asterisks (**); single asterisks (*)
auth 279
auth-psk 279
autoboot 586

B

backup 535
boot 587

C

change 588
CIDR format for subnet masks in command entries 12
classless interdomain routing (CIDR) format 12
clear ap boot-configuration 241
clear ap image 237
clear ap local-switching vlan-profile 238
clear ap radio 239
clear ap radio load-balancing group 241
clear banner motd 54

clear boot backup-configuration 537
clear boot config 537
clear dap 24
clear domain security 217
clear dot1x max-req 496
clear dot1x port-control 497
clear dot1x quiet-period 497
clear dot1x reauth-max 497
clear dot1x reauth-period 498
clear dot1x timeout auth-server 498
clear dot1x timeout supplicant 499
clear dot1x tx-period 499
clear fdb 74
clear history 54
clear igmp statistics 415
clear interface 99
clear ip alias 100
clear ip dns domain 100
clear ip dns server 101
clear ip route 101
clear ip telnet 102
clear log 575
clear log buffer 575
clear log server 575
clear mobility-domain 218
clear mobility-domain member 218
clear network-domain 225
clear network-domain mode 226
clear network-domain peer 226
clear network-domain seed-ip 227
clear ntp server 102
clear ntp update-interval 103
clear port counters 24
clear port media-type 25
clear port mirror 26
clear port name 26

- clear port type 27
- clear port-group 25
- clear prompt 55
- clear radio-profile 242
- clear radius 483
- clear radius client system-ip 484
- clear radius proxy client 485
- clear radius proxy port 485
- clear radius server 486
- clear rfdetect attack-list 512
- clear rfdetect black-list 512
- clear rfdetect ignore 513
- clear rfdetect ssid-list 513
- clear rfdetect vendor-list 514
- clear security l2-restrict 75
- clear security l2-restrict counters 75
- clear server group 486
- clear server group load-balance 486
- clear service-profile 243
- clear sessions 435
- clear sessions network 436
- clear snmp notify profile 104
- clear snmp notify target 104
- clear snmp usm 105
- clear spantree portcost 390
- clear spantree portpri 390
- clear spantree portvlancost 391
- clear spantree portvlanpri 391
- clear spantree statistics 392
- clear summertime 105
- clear system 55
- clear system countrycode 55
- clear system ip-address 55, 106
- clear system location 56
- clear system name 55
- clear timezone 106
- clear vlan 76
- CLI (command-line interface)
 - command description format 17
 - command prompts 10
 - conventions 9
 - help 16
 - history buffer command reuse 15
 - keyboard shortcuts 15
 - list formats 14
 - MAC address globs 12
 - overview 9
 - port list conventions 14
 - subnet mask notation 12
 - syntax notation 11
 - tabs for command completion 16
 - text entry conventions 11
 - user globs 12
 - VLAN identification 14
 - wildcard mask notation 12
- command description format 17
- command history description
 - history, command 17
- Command Index 601
- command prompts 10
- command-line interface. See CLI (command-line interface)
- connection modes, CLI 9
- conventions, CLI 9
- copy 537
- create 590
- crypto ca-certificate 470
- crypto ca-certificate admin 470
- crypto ca-certificate eap 470
- crypto certificate 471
- crypto certificate admin 471
- crypto certificate eap 471
- crypto generate key 472
- crypto generate request 473
- crypto generate request admin 473
- crypto generate request eap 473
- crypto generate self-signed 475
- crypto generate self-signed admin 475
- crypto generate self-signed eap 475
- crypto otp 476
- crypto otp admin 476
- crypto otp eap 476
- crypto pkcs12 477
- crypto pkcs12 admin 477
- crypto pkcs12 eap 477

D

delete 539, 590
delimiter characters, for user globs 12
dhcp 591
diag 592
dir 540, 592
disable 19
documentation, product 6
dotted decimal notation, in IP addresses 12
double asterisks (**)
 in user globs 12
 in VLAN globs 14
wildcard 16

E

enable 19
enabled access 17
Ethernet ports
 port list conventions 14

F

fver 593

G

globs, VLAN
 defined 13
globs. See MAC address globs; user globs; VLAN globs

H

help 56, 593
help, command-line 16
history 57
history buffer, reusing commands in 15

I

install soda agent 542
IP addresses
 conventions for entry and display 12

K

keyboard shortcuts for command entry 15

L

last-resort username
 passwords are invalid 206
list formats for command entry 14
load config 543
ls 594

M

MAC address 445
MAC address globs
 conventions for 13
 matching order 14
 single asterisks (*) in 13
 wildcards in 13
MAC addresses
 asterisks (*) in 12
 leading zeros in
 12
 wildcards in 12
manuals, product 6
md5 544
mkdir 545
mobility domain member 218
Mobility System Software CLI. See CLI (command-line interface) 9
monitor port counters 28
MSS CLI. See CLI (command-line interface)
Multicast packets 446

N

names
 globbing in 12
network access mode 9
next 595

O

online help, command line 16

P

password
 invalid for last-resort users 206
ping 107
port lists
 conventions for 14
product documentation 6

Q

quickstart 57
quit 20

R

reset 595
reset ap 245
reset port 32
reset system 546
restore 547
rmdir 548

S

safety notices, explanations of 7
save config 548
set {ap | dap} radio mode 270
set accounting system 181
set ap auto 245
set ap auto mode 247
set ap auto persistent 247
set ap auto radiotype 248
set ap bias 249
set ap blink 250
set ap boot-configuration 370
set ap boot-configuration ip 251
set ap boot-configuration mesh mode 252
set ap boot-configuration mesh psk-phrase 252
set ap boot-configuration mesh psk-raw 253
set ap boot-configuration switch 255
set ap boot-configuration vlan 256
set ap fingerprint 257
set ap force-image-download 257
set ap group 258
set ap image 259

set ap local-switching mode 260
set ap local-switching vlan-profile 260
set ap name 261
set ap radio antenna-location 262
set ap radio antennatype 263
set ap radio auto-tune max-power 265
set ap radio auto-tune max-retransmissions 266
set ap radio channel 267
set ap radio link-calibration 268
set ap radio load-balancing 268
set ap radio load-balancing group 269
set ap radio min-client-rate 266
set ap radio min-tx-datarate 268
set ap radio radio-profile 271
set ap radio tx-power 272
set ap security 274
set ap sticky-bit 275
set ap upgrade-firmware 275
set arp 108
set arp agingtime 109
set auto-config 57
set band-preference 275
set banner motd 59
set boot backup-configuration 549
set boot configuration-file 550
set confirm 60
set dap 33
set domain security 218
set dot1x authcontrol 500
set dot1x key-tx 501
set dot1x max-req 501
set dot1x port-control 502
set dot1x quiet-period 503
set dot1x reauth 503
set dot1x reauth-max 504
set dot1x reauth-period 504
set dot1x timeout auth-server 505
set dot1x timeout supplicant 505
set dot1x tx-period 506
set dot1x wep-rekey 506
set dot1x wep-rekey-period 507
set enablepass 20
set fdb 77
set fdb agingtime 78

-
- set igmp 416
 - set igmp lmqi 416
 - set igmp mrouter 417
 - set igmp mrsol 417
 - set igmp mrsol mrsi 418
 - set igmp oqi 418
 - set igmp proxy-report 419
 - set igmp qi 420
 - set igmp qri 420
 - set igmp querier 421
 - set igmp receiver 422
 - set igmp rv 422
 - set interface 109
 - set interface dhcp-client 110
 - set interface dhcp-server 111
 - set interface status 112
 - set ip alias 113
 - set ip dns 113
 - set ip dns domain 114
 - set ip dns server 115
 - set ip https server 116
 - set ip route 116
 - set ip snmp server 118
 - set ip ssh 118
 - set ip ssh server 119
 - set ip telnet 120
 - set ip telnet server 120
 - set length 60
 - set license 61
 - set load-balancing mode 276
 - set load-balancing strictness 277
 - set log 576
 - set log buffer 576
 - set log console 576
 - set log current 576
 - set log mark 578
 - set log server 576
 - set log sessions 576
 - set log trace 576
 - set log trace mbytes 579
 - set mobility-domain member 219
 - set mobility-domain mode member seed-ip 220
 - set mobility-domain mode seed domain-name 221
 - set network-domain mode member seed-ip 227
 - set network-domain mode seed domain-name 229
 - set network-domain peer 228
 - set ntp 121
 - set ntp server 122
 - set ntp update-interval 122
 - set port 35
 - set port media-type 36
 - set port mirror 37
 - set port name 38
 - set port negotiation 39
 - set port poe 39
 - set port speed 40
 - set port trap 41
 - set port type ap 41
 - set port type wired-auth 44
 - set port-group 35
 - set prompt 62
 - set radio-profile active-scan 278
 - set radio-profile auth-dot1x 279
 - set radio-profile auth-psk 279
 - set radio-profile auto-tune channel-config 279
 - set radio-profile auto-tune channel-holddown 280
 - set radio-profile auto-tune channel-interval 281
 - set radio-profile auto-tune channel-lockdown 282
 - set radio-profile auto-tune power-backoff-timer 282
 - set radio-profile auto-tune power-config 282
 - set radio-profile auto-tune power-interval 283
 - set radio-profile auto-tune power-lockdown 284
 - set radio-profile auto-tune power-ramp-interval 285
 - set radio-profile beacons-ssid 286
 - set radio-profile beacon-interval 278, 285
 - set radio-profile cipher-ccmp 286
 - set radio-profile cipher-tkip 286
 - set radio-profile cipher-wep104 286
 - set radio-profile cipher-wep40 286
 - set radio-profile clear-ssid 286
 - set radio-profile countermeasures 287
 - set radio-profile crypto-ssid 288
 - set radio-profile dtim-interval 288
 - set radio-profile frag-threshold 289
 - set radio-profile long-retry 290
 - set radio-profile max-rx-lifetime 290
-

- set radio-profile max-tx-lifetime 290
- set radio-profile mode 291
- set radio-profile preamble-length 294
- set radio-profile psk-phrase 294
- set radio-profile psk-raw 294
- set radio-profile rts-threshold 297
- set radio-profile service-profile 298
- set radio-profile shared-key-auth 304
- set radio-profile short-retry 304
- set radio-profile tkip-mc-time 304
- set radio-profile wep active-multicast-index 304
- set radio-profile wep active-unicast-index 304
- set radio-profile wep key-index 304
- set radio-profile wmm 304
- set radio-profile wmm-powersave 305
- set radio-profile wpa-ie 305
- set radius 487
- set radius client system-ip 488
- set radius deadtime 487
- set radius key 487
- set radius proxy client 489
- set radius proxy port 489
- set radius retransmit 487
- set radius server 490
- set radius timeout 487
- set rfdetect attack-list 514
- set rfdetect black-list 515
- set rfdetect ignore 515
- set rfdetect log 516
- set rfdetect signature 517
- set rfdetect ssid-list 517
- set rfdetect vendor-list 518
- set security 12-restrict 78
- set server group 492
- set server group load-balance 493
- set service-profile auth-dot1x 307
- set service-profile auth-fallthru 308
- set service-profile auth-psk 309
- set service-profile beacon 310
- set service-profile cac-mode 311
- set service-profile cac-session 312
- set service-profile cipher-ccmp 312
- set service-profile cipher-tkip 313
- set service-profile cipher-wep104 314
- set service-profile cipher-wep40 315
- set service-profile cos 315
- set service-profile dhcp-restrict 316
- set service-profile idle-client-probing 317
- set service-profile keep-initial-vlan 317
- set service-profile load-balancing-exempt 318
- set service-profile long-retry-count 319
- set service-profile no-broadcast 320
- set service-profile proxy-arp 321
- set service-profile psk-phrase 322
- set service-profile psk-raw 323
- set service-profile rsn-ie 323
- set service-profile shared-key-auth 324
- set service-profile short-retry-count 325
- set service-profile soda agent-directory 326
- set service-profile soda enforce-checks 326
- set service-profile soda failure-page 327
- set service-profile soda logout-page 328
- set service-profile soda mode 329
- set service-profile soda remediation-acl 330
- set service-profile soda success-page 330
- set service-profile ssid-name 331
- set service-profile ssid-type 332
- set service-profile static-cos 332
- set service-profile tkip-mc-time 333
- set service-profile user-idle-timeout 336
- set service-profile web-portal-acl 336
- set service-profile web-portal-form 337
- set service-profile web-portal-session-timeout 339, 340
- set service-profile wep active-multicast-index 340
- set service-profile wep active-unicast-index 341
- set service-profile wep key-index 342
- set service-profile wpa-ie 342
- set snmp community 123
- set snmp notify profile 125
- set snmp notify target 131
- set snmp protocol 135
- set snmp security 136
- set snmp usm 136
- set spantree 393
- set spantree backbonefast 393
- set spantree fwdelay 394
- set spantree hello 394

set spantree maxage 395
set spantree portcost 395
set spantree portfast 396
set spantree portpri 397
set spantree portvlancost 397
set spantree portvlanpri 398
set spantree priority 399
set spantree uplinkfast 399
set summertime 140
set system contact 62
set system countrycode 63
set system idle-timeout 64
set system ip-address 65, 141
set system location 65
set system name 66
set timedate 142
set timezone 143
set vlan name 79
set vlan port 80
set vlan tunnel-affinity 81
show 596
show {ap | dap} config 344
show ap arp 343
show ap connection 371
show ap counters 348
show ap dual-home 352
show ap etherstats 355
show ap fdb 353
show ap global 373
show ap group 357
show ap qos-stats 354
show ap status 358
show ap unconfigured 374
show ap vlan 365
show arp 144
show auto-tune attributes 367
show auto-tune neighbors 368
show banner motd 67
show boot 551
show config 553
show crypto ca-certificate 479
show crypto ca-certificate admin 479
show crypto ca-certificate eap 479
show crypto certificate 480
show crypto certificate admin 480
show crypto certificate eap 480
show crypto key domain 481
show crypto key ssh 481
show dhcp-client 145
show dhcp-server 147
show dot1x 507
show fdb 81
show fdb agingtime 83
show fdb count 84
show igmp 423
show igmp mrouter 426
show igmp querier 427
show igmp receiver-table 429
show igmp statistics 431
show interface 149
show ip alias 150
show ip dns 151
show ip https 152
show ip route 153
show ip telnet 155
show licenses 67
show load 67
show load-balancing group 375
show log buffer 579
show log config 581
show log trace 581
show mobility-domain config 222
show mobility-domain status 222
show network-domain 229
show ntp 156
show ntp on page 163 103
show port counters 46
show port media-type 48
show port mirror 49
show port poe 49
show port status 51
show port-group 47
show qos default 95
show radio-profile 376
show rfdetect attack-list 519
show rfdetect black-list 519
show rfdetect clients 520
show rfdetect countermeasures 522

- show rfdetect counters 523
- show rfdetect data 524
- show rfdetect ignore 526
- show rfdetect mobility-domain 526
- show rfdetect ssid-list 530
- show rfdetect vendor-list 531
- show rfdetect visible 531
- show roaming station 84
- show roaming vlan 85
- show security l2-restrict 87
- show service-profile 380
- show sessions 437
- show sessions network 439
- show snmp community 158
- show snmp counters 158
- show snmp notify profile 158
- show snmp notify target 159
- show snmp status 159
- show snmp usm 160
- show spantree 400
- show spantree backbonefast 403
- show spantree blockedports 404
- show spantree portfast 405
- show spantree portvlancost 406
- show spantree statistics 407
- show spantree uplinkfast 412
- show summertime 160
- show system 68
- show tech-support 70
- show timedate 161
- show timezone 161
- show tunnel 88
- show version 554
- show vlan config 89
- single asterisks (*)
 - in MAC address globs 13
 - in VLAN globs 14
 - wildcard 16
- subnet masks
 - notation conventions 12
- syntax notation 11

T

- tabs, for command completion 16
- telnet 162
- test 599
- test rflink 533
- traceroute 163
- Trapeze Networks Mobility System 5

U

- unicast 446
- Unicast bytes in 446
- Unicast packets in 446
- Unicast packets out 446
- uninstall soda agent 556
- user globs
 - asterisks (*) in 12
 - conventions for 12
 - delimiter characters 12
 - double asterisks (**) in 12
 - matching order 14
 - wildcards in 12

V

- version 599
- virtual LANs. See VLANs (virtual LANs)
- VLAN globs
 - conventions for 13
 - double asterisks (**) in 14
 - matching order 14
 - single asterisks (*) in 14
 - wildcards in 14
- VLAN ID or name 14
- VLANs (virtual LANs)
 - VLAN name or number 14
 - VLAN names 14
 - VLAN numbers 14

W

- wildcard masks
 - notation conventions 12
- wildcards
 - in MAC address globs 13

in MAC addresses 12
in user globs 12
in VLAN globs 14

Nortel WLAN—Security Switch 2300 Series Command Line Reference

Nortel WLAN—Security Switch 2300 Series Release 6.0.7

Document Number: **NN47250-100**

Document Status: **Standard**

Document Version: **02.51**

Release Date: **June 2008**

Copyright © Nortel Networks Limited 2007-2008 All Rights Reserved

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

*Nortel, Nortel Networks, the Nortel logo, and the Globemark are trademarks of Nortel Networks.

*Microsoft, MS, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

All other trademarks and registered trademarks are the property of their respective owners.

To provide feedback, or to report a problem in this document, go to www.nortel.com/documentfeedback.

