



WESTELL

4-PORT ROUTER (MODEL 2400)

USER GUIDE



CONTENTS

1. Product Description	1
2. Safety Instructions.....	1
3. Regulatory Information	2
4. Networking and Installation Requirements	4
5. Begin the Hardware Installation.....	8
6. Install the USB Drivers	12
7. Set Up an Account Profile.....	25
8. Set Up Macintosh OS X	35
9. Advanced Configuration	39
10. Technical Support Information.....	109
11. Warranty and Repairs.....	109
12. Product Specifications.....	110
13. Software License Agreement	109
14. Publication Information.....	112

1. PRODUCT DESCRIPTION

Westell's Router adds reliable, high-speed, Internet and LAN access to your existing home or office phone line. Your ADSL connection is "always-on" ending the hassles of dial-up modems and busy signals. Installation is easy ... no tools ... no headaches. Simply plug the Router into the 10/100 Base-T or USB port of your PC, apply power, perform the simple software configuration, and connect your ADSL equipped phone line to the Router.

This Router is capable of data rates up to 100 times faster than a traditional analog modem. However, unlike analog modems, Westell's Router allows you to use the same phone line for simultaneous voice/fax communications and high-speed Internet access, eliminating the need for dedicated phone lines for voice and data. The Plug and Play feature enables ease of configuration.

NOTE: Hereafter the Westell 4-Port Router will be referred to as the "Router."

2. SAFETY INSTRUCTIONS

Never install any telephone wiring during a lightning storm.

Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.

Never touch non-insulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.

Use caution when installing or modifying telephone lines.



Risk of electric shock. Voltages up to 140 Vdc (with reference to ground) may be present on telephone lines.

3. REGULATORY INFORMATION

3.1 FCC Compliance Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Federal Communication Commission (FCC) Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to a different circuit from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

PART 68 - COMPLIANCE REGISTRATION

This equipment (Router) complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. A label on the bottom of this equipment contains, among other information, the Federal Communication Commission (FCC) registration number, the Ringer Equivalence Number (REN), and the product identifier. For products approved after July 23, 2001 the product identifier is in the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g. 03 is a REN of 0.3). The REN is used to determine the number of devices that may be connected to a telephone line. For earlier products, the REN is separately shown on the label. If requested, this number must be provided to the telephone company.

Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most, but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company.

This equipment is designated to connect to the telephone network or premises wiring using a compatible modular jack that is Part 68 compliant. An FCC compliant telephone cord and modular plug is provided with the equipment. See the Installation Information section of this User Guide for details.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to connect to a compatible modular jack that is also compliant. See installation instruction for details.

If this terminal equipment (Router) causes harm to the telephone network, the telephone company may request you to disconnect the equipment until the problem is resolved. The telephone company will notify you in advance if temporary discontinuance of service is required. If advance notification is not practical, the telephone company will notify you as soon as possible. You will be advised of your right to file a complaint with the FCC if you believe such action is necessary.

If you experience trouble with this equipment (Router), do not try to repair the equipment yourself. The equipment cannot be repaired in the field and must be returned to Westell, Inc. Contact Westell Technical Support at telephone no. (630) 375-4500 for instructions on product return.

The telephone company may make changes to their facilities, equipment, operations, or procedures that could affect the operation of this equipment. If this happens, the telephone company will provide advance notice in order for you to make the modifications necessary to maintain uninterrupted service.

If your home has specially wired alarm equipment connected to the telephone line, ensure that the installation of this equipment (Router) does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

This equipment cannot be used on public coin phone service provided by the telephone company. Connection of this equipment to party line service is subject to state tariffs.

3.2 Canada Certification Notice

The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operations and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The department does not guarantee the equipment will operate to the user's satisfaction.

This equipment meets the applicable Industry Canada Terminal Equipment Technical Specification. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specification were met. It does not imply that Industry Canada approved the equipment. The Ringer Equivalence Number (REN) is 0.0. The Ringer Equivalence Number that is assigned to each piece of terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed five.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local Telecommunication Company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations. Connection to a party line service is subject to state tariffs. Contact the state public utility commission, public service commission, or corporation commission for information.

If your home has specially wired alarm equipment connected to the telephone line, ensure that the installation of this equipment (Router) does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

If you experience trouble with this equipment (Router), do not try to repair the equipment yourself. The equipment cannot be repaired in the field and must be returned to the manufacturer. Repairs to certified equipment should be coordinated by a representative, and designated by the supplier. Contact Westell Technical Support at telephone no. (630) 375-4500 for instructions on product return.

The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed five.

Users should ensure, for their own protection, that the electrical ground connections of the power utility, telephone lines, and internal, metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.



Users should not attempt to make such connections themselves, but should contact the appropriate electrical inspection authority, or electrician, as appropriate.

4. NETWORKING AND INSTALLATION REQUIREMENTS

4.1 Networking Requirements

CONNECTION TYPE	MINIMUM SYSTEM REQUIREMENTS	NETWORKING SCHEME
ETHERNET	<ul style="list-style-type: none"> • Pentium® or equivalent and above class machines • Microsoft® Windows® (95, 98, NT 4.0, 2000, or XP) or Macintosh® OS 9.X or OS X installed • Computer Operating System CD-ROM on hand • Internet Explorer 4.x or Netscape Navigator 4.x or higher • 32 MB RAM • 10 MB of free hard drive space • TCP/IP Protocol stack installed • 10/100 Base-T Network Interface Card (NIC) 	<p>Networking via 10/100 Base-T Ethernet requires an available Ethernet port with a 10/100 Base-T Network Interface Card (NIC) installed on your PC.</p>
USB	<ul style="list-style-type: none"> • Pentium® or equivalent and above class machines • Microsoft® Windows® 98, ME, 2000, or XP installed • Computer Operating System CD-ROM on hand • Internet Explorer 4.x or Netscape Navigator 4.x or higher • 32 MB RAM • 10 MB of free hard drive space • USB Version 1.0 or 1.1 compliant bus • An available USB Port 	<p>Networking via USB requires Windows 98, ME, 2000 or XP and an available USB port.</p>



4.2 Installation Requirements

To install the Router, you will need the following:

- A Network Interface Card (NIC) installed in your PC or
- An available USB port

NOTE: Please wait until you have received notification from your service provider that your DSL line has been activated before installing the Router and software.

4.3 Before you begin:

Make sure that your kit contains the following items:

- Westell 4-Port Router (Model 2400)
- Power Supply
- RJ-45 Ethernet cable
- USB cable
- RJ-11 Phone cable
- Westell CD-ROM containing USB software drivers and User Guide in PDF format
- Quick Start Guide

Microfilters

ADSL signals must be blocked from reaching each telephone, answering machine, fax machine, computer modem or any similar conventional device. Failure to do so may degrade telephone voice quality and ADSL performance. Install a microfilter if you desire to use the DSL-equipped line jack for telephone, answering machine, fax machine or other telephone device connections. Microfilter installation requires no tools or telephone rewiring. Just unplug the telephone device from the baseboard or wall mount and snap in a microfilter, next snap in the telephone device. If your kit did not include microfilters, please contact your ISP or Westell to obtain a microfilter kit, which contains multiple microfilters for your installation.

4.4 LED Indicators

The LED indicators are located on the front panel of the Router and are used to verify the unit's operation and status. LED states are described in Table 1.

Table 1. LED States and Descriptions

LED	State	Description
SYNC	Slow Flashing Green	Power ON and waiting for carrier detect signal (1 flash/sec)
	Moderate Flashing Green	Power ON and attempting synchronization (2 flashes/sec)
	Solid Green	Power ON and synchronized with ADSL line card
	Steady Red (less than 20 sec.)	Hardware power-up in process
	Flashing Yellow	Modem failed self-diagnostics
	Solid Yellow	Modem is in safe boot mode
	No Light	No Power
USB	Solid Green	USB link established
	Flashing Green	Transmit or Receive Activity
	No Light	No USB link established
Ethernet Ports 1,2,3,4	Solid Green	Ethernet link established
	Flashing Green	Transmit or Receive Activity
	No Light	No Ethernet link established

4.5 Cable Connectors and Switch Locations

The following items are located on the rear panel of the Router. See Table 1. Tables 2 through 5 list the connector types and pinout designations.

- DSL Connector (RJ-11)
- Reset Button
- ON/OFF Switch
- Power Connector
- USB Connector
- Ethernet Connectors (RJ-45)




Figure 1. Rear Panel

Table 2. Connector Descriptions





CONNECTOR	NAME	TYPE	FUNCTION
	DSL	6-pin RJ-11 modular jack	Connects to an ADSL-equipped telephone jack or DSL connection of a POTS splitter.
	Power	Barrel connector	Power source.
	USB	4-pin USB Series B connector	Connects the USB device to the PC.
	Ethernet	8-pin (RJ-45) modular jacks	Connects four PCs or peripherals together.

Table 3. DSL Pinouts

Pinout	Description
1, 2, 5, 6	Not Used
3	DSL Tip
4	DSL Ring

Table 4. USB Series B Connector Pinouts

Pin	Name	Description	Cable Color
1	VBUS/Vcc	5 Vdc	Red
2	D –	Data –	White
3	D +	Data +	Green
4	GND	Ground	Black

Table 5. Ethernet Pinouts

Pinout	Description
1	Rx+
2	Rx-
3	Tx+
4,5,7,8	Not Used
6	Tx-

5. BEGIN THE HARDWARE INSTALLATION

This section explains the procedures for installing the Westell Router. You may choose to install the Router in one of three ways: Ethernet only, USB only, or Ethernet and USB. To install the Router via 10/100 Base-T Ethernet only, refer to section 5.1. To install the Router via USB only, refer to section 5.2. If you want to use both USB and 10/100 Base-T Ethernet interfaces simultaneously, please follow the procedures outlined in section 5.3.



Please wait until you have received notification from your Service Provider that your DSL line has been activated before installing your 4-Port Router.



NOTE: If you are using a Westell Router in conjunction with an Ethernet Hub or Switch, refer to the manufacturer's instructions for proper installation and configuration. Westell recommends the use of a surge protector to protect equipment attached to the AC power supply.

5.1 Router Installation via 10/100 Base-T Ethernet

You can choose to connect your primary computer via Ethernet or USB installation. Westell recommends that you connect your Router using an Ethernet connection.




NOTE: Before you connect the Router via 10/100 Base-T, you must have an available Ethernet card installed in your computer. If your Ethernet card does not auto-negotiate, you must set it to half duplex. Refer to the Ethernet card manufacturer's instructions for installing and configuring your Ethernet card. If you do not have an Ethernet card installed in your computer but do have an available USB Port, go to the **Router Installation via USB** section of this User Guide.

1. Connect the power supply cord to the power connector  marked **12V** on the rear panel of the Router. Plug the other end of the power supply cord into a surge-protected AC wall socket.
2. Connect the DSL phone cable from the DSL jack  on the rear panel of the Router to the DSL-equipped telephone jack on the wall.



WARNING: The connection to the Router's DSL jack must come from a non-filtered connection to the telephone jack on the wall. If you are using a microfilter, then be certain that the DSL phone cable is connected to the "DSL/HPN" non-filtered jack. You must use the phone cord that was provided with the Router kit.

3. Connect the Ethernet cable from the Ethernet jack  on the rear panel of the Router to the Ethernet port on your computer. **Repeat this step to connect up to 3 additional PCs to the Router.**

NOTE: You may connect to any of the four Ethernet jacks on the rear panel of the Router as they serve as an Ethernet hub.

Congratulations! You have completed the Ethernet hardware installation for your Router. No USB driver software installation is required when using an Ethernet connection. Refer to your Internet Service Provider's instructions for installing subscriber software and connecting to the Internet.






Figure 2. Router Connection via 10/100 Base-T Ethernet

5.2 Router Installation via USB



NOTE: The USB installation will not function for Macintosh computers. Macintosh computers must install the Router via Ethernet connections.

The Router allows you to network your primary computer via Ethernet or USB installation. Westell recommends that you connect your Router using an Ethernet installation

1. Connect the power supply cord to the power connector  marked **12V** on the rear panel of the Router. Plug the other end of the power supply cord into a surge-protected AC wall socket.
2. Connect the DSL phone cable from the connector  on the rear panel of the Router marked to the DSL-equipped telephone line jack on the wall.



WARNING: The connection to the Router's DSL jack must come from a non-filtered connection to the telephone jack on the wall. If you are using a microfilter, then be certain that the DSL phone cable is connected to the "DSL/HPN" non-filtered jack. You must use the phone cord that was provided with the Router kit.

3. Connect the USB cable from the USB connector  on the rear panel of the Router to the USB port on the PC.

Congratulations! You have completed the USB hardware installation for your Router. You must now go to step 6 (INSTALL THE USB DRIVERS) to begin the USB drivers software installation.






Figure 3. Router Connection via USB


5.3 Router Installation via 10/100Base-T Ethernet and USB (Simultaneous Hardware Installation)


The 4-Port Router supports simultaneous use of 10/100 Base-T Ethernet and USB ports. Refer to the instructions below for instructions on how to install your Router using both Ethernet and USB ports.

1. Connect the power supply cord to the power connector  marked **12V** on the rear panel of the Router. Plug the other end of the power supply cord into a surge-protected AC wall socket.
2. Connect the DSL phone cable from the DSL jack  on the rear panel of the Router to the DSL-equipped telephone jack on the wall.



WARNING: The connection to the Router's DSL jack must come from a non-filtered connection to the telephone jack on the wall. If you are using a microfilter, then be certain that the DSL phone cable is connected to the "DSL/HPN" non-filtered jack. You must use the phone cord that was provided with the Router kit.

3. Connect the USB cable from the USB connector  on the rear panel of the Router to the USB port on the PC.

4. Connect the Ethernet cable from the Ethernet jack  on the rear panel of the Router to the Ethernet port on your computer. **Repeat this step to connect up to 3 additional PCs to the Router.**

NOTE: You may connect to any of the four Ethernet jacks on the rear panel of the Router as they serve as an Ethernet hub.

Congratulations! You have completed the simultaneous hardware (Ethernet and USB) installation for your Router. You must now go to Section 6 (INSTALL THE USB DRIVERS) to begin the USB drivers software installation. No software installation is required when using only an Ethernet connection. Refer to your Internet Service Provider's instructions for installing subscriber software and connecting to the Internet.




Figure 4. Simultaneous Connection via 10/100Base-T Ethernet and USB

6. INSTALL THE USB DRIVERS

This section explains how to install the USB modem drivers for the 4-Port Router. If you are using only Ethernet ports, USB driver installation is not necessary. The Microsoft® Plug and Play auto-detect feature recognizes when new hardware has been installed. After you connect the Router to the PC, the Router will automatically be detected.

Before you begin the USB driver installation, you must determine which operating system is installed on your PC. To view information about your operating system, go to the 'My Computer' icon located on your desktop and then right click. Next, select 'Properties' from the options displayed, the 'System Properties' box will appear. At the 'System Properties' box, click on the 'General' tab. This will display the 'System Properties' for your PC, including the operating system installed on your PC (e.g. Microsoft Windows 98).

6.1 Westell CD-ROM Installation:

1. Place the Westell CD-ROM that you received in the Router kit into the CD-ROM drive of the PC that is connected to the USB port.
2. Go to the USB driver installation section that matches your operating system and follow the procedures outlined in that section.
3. Verify the connection to the computer by observing the state of the USB LED. Once the USB drivers have been installed, the USB LED should be solid green. Solid green indicates a USB connection has been established. Refer to Table 1 (LED States and Descriptions) in section 4.4 of this User Guide.

6.2 Installing the USB Drivers for Windows 98



IMPORTANT: Confirm that the Westell USB Driver CD-ROM is inserted in the appropriate drive before continuing this installation.

1. After you have connected the Router to your PC, the **New Hardware Found** window appears See Figure 5. In a few moments, the Add **New Hardware Wizard** window will open. See Figure 6. Click **Next**.




Figure 5. Windows 98




Figure 6. Add New Hardware

2. **Windows 98:** Click the option button for **Search for the best driver for your device. (Recommended)**. See Figure 7. Click **Next**.




Figure 7. Windows 98

3. **Windows 98:** Select **CD-ROM drive** option. See Figure 8. Click **Next**. Windows will search for the driver.




Figure 8. Windows 98

4. **Windows 98:** Select the option button **The updated driver (Recommended) Westell 4 Port Router**. See Figure 9. Click **Next**.



NOTE: If Figure 8 does not appear at this step, and Figure 9 appears with the text 'USB Composite device', 'C:\Windows\Inf\USB.Inf', do not continue. Go back to step 3 and specify the location of the Westell CD-ROM.




Figure 9. Location of Hardware Device Driver

5. **Windows 98:** Windows will display the location of the driver. (The drive “letter” may vary.) See Figure 10. Click Next.




Figure 10. Loading Device Driver

6. **Windows 98:** Remove the Westell CD from the CD-ROM Drive. Next, insert the Windows operating system CD into the CD-ROM Drive. See Figure 11. Click **OK**.




Figure 11. Insert Windows Operating System CD

7. **Windows 98:** The system will begin copying files (Figure 12).




Figure 12. Copying Files

8. **Windows 98:** Figure 13 may pop up, depending on how Windows 98 was installed on the computer. The installation of the Westell modem requires files that are supplied by Microsoft for Windows 98. If Figure 13 pops up, insert the Windows 98 Operating System CD into the computers CD-ROM drive, wait a moment for the CD to be recognized by the system, and then click on **OK**. The system should find the required files on the Windows 98 CD and automatically complete the installation.




Figure 13. Windows 98

If the Operating System CD is not available, or if Figure 13 pops up again, you will have to manually specify the location of the files. The required files may be stored on your hard drive. A common location for these files is "C:\Windows\Options\Cabs." Try specifying this path or the path to your CD-ROM drive (usually "D:\") by clicking the **Browse...** button in the **Insert Disk** screen. When you have specified the correct path, click on **OK**. The system will begin copying the files. See Figure 14.

NOTE: It is very important that the Windows 98 files be installed. Do not click on **Cancel** or **Skip File** in the dialogs, doing so will result in an improper installation and the modem will not function correctly.




Figure 14. Windows 98

9. **Windows 98:** The window below confirms that the PC has finished loading the drivers. See Figure 15. Click **Finish**.




Figure 15. Windows 98

10. **Windows 98:** Click **Yes** to restart your computer. See Figure 16.




Figure 16. Restart the Computer

Congratulations! You have completed the software installation for the USB drivers. After the computer has restarted, the Router is ready for use. Refer to the Internet Service Provider (ISP) installation manual to install the software required for your Internet connection.

6.3 Installing the USB Drivers for Windows ME

1. **Windows ME:** After you have connected the Router to your PC, the **New Hardware Found** window appears. See Figure 17. In a few moments, the **Add New Hardware Wizard** window appears. See Figure 18. Click the option button for **Automatic search for a better driver (Recommended)**. Click **Next**.




Figure 17. Windows ME




Figure 18. Windows ME

2. **Windows ME:** Windows will display the location of the driver. See Figure 19.



Figure 19. Location of Hardware Device Driver

3. **Windows ME:** The window below confirms that the PC has finished loading the drivers. See Figure 20. Click **Finish**.



Figure 20. Windows ME

4. **Windows ME:** When the **System Settings Change** screen appears, the USB drivers are installed properly. See Figure 21. Click **Yes**.




Figure 21. Restart the Computer

Congratulations! You have completed the software installation for the USB drivers. After the computer has restarted, the Router will be ready for use. Refer to the Internet Service Provider (ISP) installation manual to install the software required for your Internet connection.

6.4 Installing the USB Driver for Windows 2000

1. After you have connected the Router to your PC, the **New Hardware Found** window will appear. See Figure 22. In a few moments, the **Found New Hardware Wizard** window will appear. See Figure 23. Click **Next**.




Figure 22. Found New Hardware



Figure 23. Welcome to Install Device Driver

2. **Windows 2000: The Install Hardware Device Drivers window appears. Select Search for a suitable driver for my device (recommended).** See Figure 24. Click Next.




Figure 24. Search for Device Driver

3. **Windows 2000: The Driver Files Search Results window appears. Select the CD-ROM drives option.** See Figure 25. Click Next.




Figure 25. Locate Driver Files

4. **Windows 2000:** The **Driver Files Search Results** window appears. (The drive “letter” may vary.) See Figure 26. Click **Next**.




Figure 26. Driver Files Search Results

5. **Windows 2000:** The window below confirms that the PC has finished loading the drivers See Figure 27. Click **Finish**.



Figure 27. Drivers Loaded

6. **Windows 2000:** When the **System Settings Change** screen appears, the USB drivers are installed properly. See Figure 28. Click **Yes**.




Figure 28. Restart Your Computer

Congratulations! You have completed the software installation for the USB drivers. After your computer has restarted, the Router is ready for use. Refer to the Internet Service Provider (ISP) installation manual to install the software required for your Internet connection.

6.5 Installing the USB Driver for Windows XP

After you have connected the Westell Router to your PC, the Found New Hardware Wizard window will open. See Figure 29. Select option button **Install the software automatically (Recommended)**. Click Next.




Figure 29. Windows XP

1. **Windows XP:** The window below confirms that the PC has finished loading the drivers. See Figure 30. Click **Finish**.




Figure 30. Windows XP


Congratulations! You have completed the software installation for the USB drivers. The Router is now ready for use. Refer to the Internet Service Provider (ISP) installation manual to install the software required for your Internet connection.

7. SET UP AN ACCOUNT PROFILE

This section explains how to set up your account profile and establish a connection to your ISP.

NOTE: Before you set up your account, you must obtain your **Account ID** and **Account Password** from your Internet Service Provider. You will use this information when you set up your account parameters. If you are at a screen and need help, click on the **Help** button to learn more about the screen.

After connecting the Router, bring up your Web browser and type **http://dslrouter** or **http://192.168.1.1** in the browser's address window. Press **Enter** on your keyboard. The **Getting Started** screen will appear. Click on **next**.



Type in your account parameters. (Account parameters are required before connecting to the Internet.)
Account Parameters include:

- **Connection Name**-the Connection Name is a word or phrase that you use to identify your account. (You may enter up 64 characters in this field.)
- **Account ID**-the Account ID is provided by your Internet Service Provider. (You may enter up 255 characters in this field.)
- **Account Password**-the Account Password is provided by your Internet Service Provider. (You may enter up 255 characters in this field.)




When you enter your account parameters into the **User Name** screen, they will be displayed (as shown in the screen below). Click **next** if you want your account parameters to take affect. Click on **reset** if you do not want the account parameters that you entered to take affect, or if you want to re-enter the parameters.



Enter the VPI and VCI values that you obtained from your Internet Service Provider. Click on **next**.

NOTE: Depending on your Internet Service Provider, the **VPI/VCI** screen may come pre-configured and it will be displayed here. In this case, you will not be able to change any values in this screen. Click on **next** to go to the **PROTOCOL** screen.




Select the Protocol type that you obtained from your Internet Service Provider. Click on **next**.

NOTE: Depending on your Internet Service Provider, the **PROTOCOL** screen may come pre-configured and it will be displayed here. In this case, you will need to click on **next** to go to the **SET-UP COMPLETE** screen.




When the **SET-UP COMPLETE** screen appears, you have successfully completed your Account Profile setup. Click on **done**.



You must reset your Router in order to capture your new settings. (If you click on **Cancel**, your new settings will not take affect.) Click on **OK**, this will reset your Router and your new settings will take affect.




The screen below shows that the Router is being reset.




7.1 Establish a PPP Session

View the **Connection Rate** at the **Connection Overview** section in the following homepage. If this status reads **No DSL Connection**, check the DSL physical connection, which is explained in section 5 (BEGIN THE HARDWARE INSTALLATION).




The screen below shows the connection rate with values that indicate a successful SYNC has been established. The connection rate values represent the transmission speed of your DSL line. (The Router may take time to report the values.) Click on the **Connect** button to establish a PPP session.




The screen below will appear briefly. When the **PPP Status** displays **Connecting...**, this means that you are establishing a PPP session.

NOTE: The Router will handle transmission rates up to 8 Mbps. Your actual DSL rates may vary depending on your Internet Service Provider.



Once a PPP session has been successfully established, the **PPP Status** will display **UP**. Congratulations! You may now surf the Internet.




7.2 Disconnecting a PPP Session

If you are ready to disconnect from your Internet Service Provider, click the **Disconnect** button in the **Connection Overview** screen (shown above). The following pop-up screen will appear. Click **OK** to disconnect the PPP session.




The **PPP Status** in the **Connection Overview** screen, allows you to view the state of your ISP connection. If you click the **Disconnect** button in **Connection Overview** screen, the **PPP Status** should display **DOWN**. This indicates that you no longer have an ISP connection. In this event, your Router will maintain its DSL connection. If you would like to remove the DSL connection, set the Router's power switch to the OFF position.




7.3 Service Configuration

To use an application that utilizes the NAT (Network Address Translation) protocol, you will have to configure your Router's NAT settings. Select **Configuration Service** from the **Configuration** menu.

Westell has developed an extensive list of NAT services and you may select any service from this list. By selecting your specific NAT service and setting up a NAT profile, you will ensure that the appropriate ports on your Router are open and that the required application traffic can pass through your LAN. For a list of supported NAT services, go to section 9.8 (NAT Services).



This screen allows you to attach a predefined NAT service to your default profile. Once you have selected a NAT service, click on **enable**. This will display the **Load New NAT Configuration** screen.




Click on **OK** in the **Load new NAT Configuration?** screen. This will load the new NAT Configuration and the settings will be saved automatically.




NOTE: You can attach multiple NAT services to your profile. However, for each NAT service that you attach, you must first select the new NAT service. Next, you must load the new NAT Configuration, as explained in the previous instructions.

If you want to view the details of your profile, click on **details**. If you want to delete the NAT service that is attached to your profile, click on **delete**.



If you select **details**, the screen below will be displayed. It contains the service name, protocol, and port information for the NAT service you selected. Click on **close**.



8. SET UP MACINTOSH OS X


This section provides instructions on how to use Macintosh Operating System 10 with the Westell Router. Follow the instructions in this section to create a new network configuration for Macintosh OS X.



NOTE: The USB installation will not function for Macintosh Computers. Macintosh computers must use the Router's Ethernet installation. Refer to page 8 for installation instructions.


Open the System Preference Screen

After you have connected the Westell Router to the Ethernet port of your Macintosh, the screen below will appear. Click on the “**Apple**” icon in the upper right corner of the screen and select **System Preferences**.




Choose the Network Preferences

After selecting **System Preferences...**, from the previous screen, the **System Preferences** screen will be displayed. From the **System Preferences** screen, click on the **Network** icon.



Create a New Location

After selecting the **Network** icon at the **System Preferences** screen, the **Network** screen will be displayed. Select **New Location** from the **Location** field.



Name the New Location


After selecting **New Location** from the **Network** screen, the following screen will be displayed. In the field labeled **Name your new location:**, change the text from “Untitled” to “Westell.” Click on **OK**.



Select the Ethernet Configuration

After clicking on **OK** in the previous step, the **Network** screen will be displayed. The **Network** screen shows the settings for the newly created location. From the **Configure** field in the **Network** screen, select **Built-in Ethernet**. Click **Save**.

NOTE: Default settings for the Built-in Ethernet configuration are sufficient to operate the Router.




Check the IP Connection

To verify that the computer is communicating with the Router, follow the instructions below.


1. Go to the “**Apple**” icon in the upper right corner of the screen and select **System Preferences**.
2. From the **System Preferences** screen, click on the **Network** icon. The **Network** screen will be displayed.
3. From the **Configure** field in the **Network** screen, select **Built-in Ethernet**.
4. View the IP address field. An IP address that begins with **192.168.1** should be displayed.

NOTE: The DHCP server provides this IP address. If this IP address is not displayed, check the Router’s wiring connection to the PC. If necessary, refer to section 5 for installation instructions.




Create a User Account

In the address window of your Internet Explorer web browser, type **Http://dslrouter/**. Press enter on your keyboard.




The **Getting Started** screen will be displayed. You may now begin your Account Setup. Refer to section 7 of this User Guide to configure your Router.



9. ADVANCED CONFIGURATION


The Advanced Configuration section of your Westell Router allows you to make changes to features like your firewall settings. The following sections will explain each feature of your Router and explain how to make changes to your configuration.

NOTE: As you navigate through the various screens of your Westell Router, the active page that you have selected will appear in the lefthand window of the homepage screen shown below.




9.1 Home

The following settings will be displayed on your Home page. Click on **profile editor**.




Connection Overview	Displays your DSL connection rate.
Connection Name	This Connection Name is from the connection profile that you established in section 7.
PPP Status	UP = PPP session established DOWN = No PPP session established.
Connect/Disconnect	CONNECT = Establish a PPP session DISCONNECT = Disconnect a PPP session
Profile Editor	This allows you to make changes to the profile that you created in section 7.

If you select the **New Connection** function from your **Connection Overview** screen, the **New Connection** screen will appear. Follow steps in the **New Connection** screen to establish a new user profile, as defined in section 7. You can store up to eight unique user profiles in your Router.



If you select **Edit** from the **Connection Overview** screen at your home page, the **Edit “My Connection” Connection** screen will appear. Follow the steps in the **Edit “My Connection” Connection** screen to change your existing user profile, which you set up in section 7.




Connection Name	This field allows you to enter a new connection name of your choice (up to 64 characters).
Account ID	Use the same account ID that you used in section 7 if you are connecting to the same Service Provider. If you have multiple Service Providers, you can enter this information at this time.
Account Password	Use the same account password that you used in section 7 if you are connecting to the same Service Provider. If you have multiple Service Providers, you can enter this information at this time.
NAT Profile	Westell recommends that you use the Default parameter.
Manual	Selecting this feature allows you to manually establish your PPP session.
On Demand	Selecting this feature allows the Router to automatically re-establish your PPP session upon demand.
Always On	Selecting this feature allows the Router to establish an “always-on” PPP session if it goes down.
Time Out Enable	Selecting this feature allows you to enable the timeout parameter of your PPP session, which is set to a factory default of 20 minutes.
Save Password	Selecting this feature allows you to save the password for your new connection profile in your Router so that you will not have to re-enter it in case of a re-boot.
Minutes for Connection Time Out	This option allows you to specify the number of minutes that you want a PPP session to stay active before it is disconnected due to inactivity. (This feature works if you have selected the Time Out Enable feature explained above.)

9.2 Status

Connection Summary


The following settings will be displayed if you select **Connection Summary** from the **Status** menu.



DSL Connection Information	
Connection Rate	This field will let you know if you have a DSL Sync (UP/DOWN) and the DSL rate at which you are connected.
Connection Status	This field will display how much information was received (IN) or sent (OUT) in packets.
IP Network Address	PPP = An IP address identifies your device on the Internet Primary DNS = Provided by your Service Provider Secondary DNS = Provided by your Service Provider
Ethernet Status	This field will display your Ethernet information that was received (IN) or sent (OUT) in packets on your Ethernet port.
ATM Network Address	This field will display your VPI & VCI values, which are provided by your Internet Service Provider.
Firewall Status	This field will display your firewall traffic in packets. Passed: Monitors information traffic that was successfully received (IN) or transmitted (OUT) in packets. Dropped: Monitors information traffic that was not successfully received (IN) or transmitted (OUT) due to your firewall settings.
PPP Connection Information	
Connection Name	This is from the connection profile that you established in section 7.
Connection Duration	This field will display how long your PPP session has been connected.
Status	This field will display the status of your PPP session. UP=Connected DOWN=Disconnected
Number of Reconnects	This field will display the number of attempts that were made to establish a PPP session.

About

The following settings will be displayed if you select **About** from the **Status** menu.




Model Number	Router manufacturer's model number.
Serial Number	Router manufacturer's serial number.
MAC Address	MAC address of this device.
Software Version	Version of Application Software.
Software Model	Router application type.
Description	Product description.
Boot Loader	Version of boot loader software

9.3 Configuration

VC Configuration

The following settings will be displayed if you select **VC Configuration** from the **Configuration** menu.



NOTE: Westell strongly recommends that you do not change any values in this section. If you experience any problems, please re-set your Router via the external hardware re-set button or via the procedure defined under the **Maintenance** menu.


Status	Allows you to enable or disable your VC (Virtual Connection)
VPI	Displays the VPI (Virtual Path Indicator) value for a particular VC, which is defined by your Service Provider.
VCI	Displays the VCI (Virtual Channel Indicator) value for a particular VC, which is defined by your Service Provider.
Protocol	Displays the Protocol for each VC, which is specified by your Service Provider.



<p>NOTE: The configuration specified by your Service Provider will determine which Protocols are available to you.</p>	<p>PPPoA = Point to Point Protocol over ATM (Asynchronous Transfer Mode) PPPoE = Point to Point Protocol over Ethernet Bridge = Bridge Protocol Classical IPoA = Internet Protocol over ATM (Asynchronous Transfer Mode). This is an ATM encapsulation of the IP protocol.</p>
<p>Bridge Broadcast</p>	<p>Factory Default = CHECKED</p> <p>When this setting is CHECKED, the Router will allow Broadcast IP packets to/from the WAN. When this setting is NOT CHECKED, the router will block Broadcast IP packets to/from the WAN. This setting is only valid if one of the Virtual Channels is configured for Bridge mode.</p>
<p>Bridge Multicast</p>	<p>Factory Default = CHECKED</p> <p>When this setting is CHECKED, the Router will allow Multicast IP packets to/from the WAN. When this setting is NOT CHECKED, the Router will block Multicast IP packets to/from the WAN. This setting is only valid if one of the Virtual Channels is configured for Bridge mode.</p>
<p>Spanning Tree Protocol</p>	<p>Factory Default = DISABLED</p> <p>Spanning Tree Protocol is a link management protocol that provides path redundancy while preventing undesirable loops in the network. For Ethernet network to function properly, only one active path can exist between two stations.</p> <p>When ENABLED, two bridges are used to interconnect the same two computer network segments. Spanning Tree Protocol will allow the bridges to exchange information so that only one of them will handle a given message that is being sent between two computers within the network.</p>

The following settings will be displayed if you select **edit** from your **VC Configuration** menu on any of your existing VC (Virtual Connections) settings. If you change any of your existing VC settings, click on **Set VC**.

NOTE: Westell strongly recommends that you do not change any values in this section. If you experience any problems, please re-set your Router via the external hardware re-set button or via the procedure defined under the **Maintenance** menu.



VC 1 Configuration	
VPI	This setting allows you to change your VPI (Virtual Path Indicator) value for a particular VC, which is defined by your Service Provider.
VCI	This setting allows you to change your VCI (Virtual Channel Indicator) value for a particular VC, which is defined by your Service Provider.
PCR	<p>Factory Default = 100%</p> <p>Peak Cell Rate (PCR)-The maximum rate at which cells can be transmitted across a virtual circuit, specified in cells per second and defined by the interval between the transmission of the last bit of one cell and the first bit of the next.</p> <p>This value is a percentage of the current data rate. 100 allows this VC to use 100% of the available bandwidth. 80 allows this VC to use 80% of the available bandwidth.</p>
QoS	<p>Quality of Service, which is determined by your Service Provider.</p> <p>CBR = Constant Bit Rate UBR = Unspecified Bit Rate VBR = Variable Bit Rate</p>
Protocol	<p>The Protocol for each VC, which is specified by your Service Provider.</p> <p>PPPoA = Point to Point Protocol over ATM (Asynchronous Transfer Mode) PPPoE = Point to Point Protocol over Ethernet Bridge = Bridge Protocol Classical IPoA = Internet Protocol over ATM (Asynchronous Transfer Mode). This is an ATM encapsulation of the IP protocol.</p>
Status	The protocol status.

VC x PPPoE Settings	
IP Address	Displays the IP network address that your modem is on.
Gateway	Displays the router IP Gateway address
DNS Primary	Provided by your Service Provider
DNS Secondary	Provided by your Service Provider
MRU Negotiation	Factory Default = DISABLED If ENABLED, the Maximum Received Unit (MRU) would enforce MRU negotiations. (NOTE: enable this option only at your Internet Service Provider's request.)
Tunneling	Factory Default = ENABLE If ENABLED, this option allows PPP traffic to be bridged to the WAN. This feature allows you to use a PPPoE shim on the host computer to connect to the Internet Service Provider, by bypassing the Router's capability to do this.


NOTE: The values for IP Address, Gateway, DNS Primary, and DNS Secondary are all "Override of the value obtained from the PPP connection," They default to "0.0.0.0," in which case the override is ignored. Westell recommends that you do not change these values unless you are instructed by the Internet Service Provider.

If you have made any changes to your VC settings, you need to save them. To save the new VC settings, click on **OK** when asked **Set this PPPoE VC configuration?** If you click on **cancel**, the new VC settings will not be saved.




DNS Configuration

The following settings will be displayed if you select **DNS Configuration** from the **Configuration** menu.




DNS Server	
Enable	Factory Default = CHECKED Displays the status of the DNS Server. If you disable this feature, the router will not automatically resolve the host name.
User Assigned DNS	
Domain Name	This field allows you to enter a Domain Name for your Router. NOTE: Some ISP's may require the name for identification purposes.
	To add a Domain Name, in the field under User Assigned DNS, type in your new domain name and click Set .
Static Host Assignment	
Host Name	This field allows you to enter a HOST name for your Router. To add a new Host name, in the field under Static Host Assignment, type in the Host Name and the IP address and click Set .
IP Address	Displays the IP address that is assigned to the Host Name.
Discover Local Devices	
This field displays a list of the computers on the LAN that were assigned a DHCP Address. The computer name, MAC address, and IP address of each discovered device is displayed.	

The screens below show that a new Host name was added.



DHCP Configuration


The following settings will be displayed if you select **DHCP Configuration** from the **Configuration** menu.




DHCP Server	<p>This setting allows the ADSL router to automatically assign IP addresses to local devices connected on the LAN. Westell advises setting this to enabled for the private LAN.</p> <p>Off = DHCP Server is disabled Private LAN = DHCP addresses will be saved into the Private LAN configuration. Public LAN = DHCP addresses will be saved into the Public LAN configuration. This option is only available if the Public LAN DHCP server is enabled.</p> <p>NOTE: These addresses will be overwritten if the Internet Service Provider supports dynamic setting of these values.</p>
DHCP Start Address	<p>Factory Default = 192.168.1.15</p> <p>This field displays the first IP address that the DHCP server will provide. The DHCP Start Address must be within the IP address and lower than the DHCP End Address. You may use any number from 0 to 254 in this address.</p>
DHCP End Address	<p>Factory Default = 192.168.1.47</p> <p>This field displays the last IP address that the DHCP server will provide. The DHCP End Address must be within the IP address and higher than the DHCP Start Address. You may use any number from 0 to 254 in this address.</p>
DHCP Lease Time	<p>Factory Default = 01:00:00:00</p> <p>Displays the amount of time the provided addresses will be valid, after which the DHCP client will usually re-submit a request.</p> <p>NOTE: DHCP Lease Time is displayed in the format (dd:hh:mm:ss)*. This value must be greater than 10 seconds. Seconds must be between 0 and 59, minutes must be between 0 and 59, and hours must be between 0 and 23.</p> <p>*(dd = days, hh = hours, mm = minutes, ss = seconds)</p>

If you click on the pull-down arrow at **DHCP Server:**, a list of options will be displayed. Select **Off**, **Private LAN**, or **Public LAN**.


NOTE: Public LAN option will appear only if the Public LAN feature is enabled. Private LAN is the default DHCP Server option.




If you selected **Off** at **DHCP Server:**, the following screen will be displayed. Click on **save** to save the **DHCP Server** setting.




If you selected Private LAN at DHCP Server:, the following screen will be displayed. Click on save to save your DHCP Server setting. If you click on reset, your DHCP Server setting will be reset to factory default. (Private LAN is the factory default for DHCP Server.)




If you clicked on **save**, the following pop-up screen will appear. Click on **OK**.



If you selected **Public LAN** at **DHCP Server**:, the following screen will be displayed. Click on **save** to save your **DHCP Server** setting. If you click on **reset**, your **DHCP Server** setting will be reset to factory default. (**Private LAN** is the factory default for **DHCP Server**.)




If you clicked on **save**, the following pop-up screen will appear. Click on **OK**.



Private LAN Configuration


The following settings will be displayed if you select **Private LAN** from the **Configuration** screen. Private LAN allows you to set up a network behind your Router.

NOTE: Both Private LAN and Public LAN cannot be disabled.



Private LAN DHCP Server Enable	Default = CHECKED If this box is CHECKED, it enables DHCP addresses to be served from the Private LAN pool.
Private LAN Enable	Default = CHECKED If this box is CHECKED, it enables the addresses from the Private LAN to use the NAT interface.
Modem IP Address	Displays the Router's IP address
Subnet Mask	Displays the Subnet Mask, which determines what portion of an IP address is controlled by the network, and which portion is controlled by the host.

If you clicked on the **Private LAN DHCP Server Enable** box, the following screen will be displayed. If you change the settings in this screen, click on **save**. If you click on **reset**, the changes will not take affect.



If you clicked on **save**, the following pop-up screen will be displayed. Click on **OK**. This will save you **Private LAN Configuration** settings. If you click **Cancel**, your new settings will not take affect.



NOTE: DHCP Lease Time is displayed in the following format: (dd:hh:mm:ss)* This value must be greater than 10 seconds. The default = 01:00:00:00. Seconds must be between 0 and 59, minutes must be between 0 and 59, and hours must be between 0 and 23.
 *(dd = days, hh = hours, mm = minutes, ss = seconds).


If the settings you have entered in the **Private LAN Configuration** screen are incorrect, the following warnings messages may be displayed via pop-up screens. If this occurs, check the settings in the **Private LAN Configuration** screen.

Warning Message	Check Private LAN DHCP Settings
Start Address is not part of the Subnet	Check the value in the DHCP Start Address field
End Address is not part of the Subnet	Check the value in the DHCP End Address field
End Address is below the Start Address	Check the value in the DHCP End Address field
Lease time must be greater than 10 seconds	Check the values in the DHCP Lease Time fields
Seconds must be between 0 and 53	Check the Seconds value in the DHCP Lease Time field
Minutes must be between 0 and 59	Check the Minutes value in the DHCP Lease Time field
Hours must be between 0 and 23	Check the Hours value in the DHCP Lease Time field

Public LAN Configuration


The following screen will be displayed if you select **Public LAN** from the **Configuration** menu. The Public LAN feature, if available from your service provider, allows the Router to use LAN IP addresses that are accessible from the WAN. Public LAN allows your computer to have global addressability.

NOTE: Both Private LAN and Public LAN cannot be disabled.




Public LAN DHCP Server Enable	Default = NOT CHECKED If this box is CHECKED, it enables DHCP addresses to be served from the Public LAN pool
Public LAN Enable	Default = NOT CHECKED If this box is CHECKED, it enables the addresses from the Public LAN to bypass the NAT interface.
Public LAN IP Address	Provides a Public IP Address if the service provider does not automatically provide one.
Public LAN Subnet Mask	Provides a Public Subnet Mask if the service provider does not automatically provide one.

If you clicked on the **Public LAN DHCP Server Enable** box, the following screen will be displayed. Click on the **Public LAN Enable** box to enable Public LAN.



If you clicked on the **Public LAN Enable** box, the following screen will be displayed. Click on **save**.



If you click on **Save** in the **Public LAN Configuration** screen, the following pop-up screen will be displayed. Click **OK**. This will save you **Public LAN Configuration** settings. If you click on **Cancel**, your new settings will not take affect.




NOTE: DHCP Lease Time is displayed in the following format: (dd:hh:mm:ss)*. This value must be greater than 10 seconds. The default = 01:00:00:00. Seconds must be between 0 and 59, minutes must be between 0 and 59, and hours must be between 0 and 23.
 *(dd = days, hh = hours, mm = minutes, ss = seconds).


If the settings you have entered in the **Public LAN Configuration** screen are incorrect, the following warnings messages may be displayed via pop-up screens. If this occurs, check settings in the **Public LAN Configuration** screen.

Warning Message	Check Public LAN DHCP Settings
Start Address is not part of the Subnet	Check the value in the DHCP Start Address field
End Address is not part of the Subnet	Check the value in the DHCP End Address field
End Address is below the Start Address	Check the value in the DHCP End Address field
Lease time must be greater than 10 seconds	Check the values in the DHCP Lease Time fields
Seconds must be between 0 and 53	Check the Seconds field at DHCP Lease Time
Minutes must be between 0 and 59	Check the Minutes field at DHCP Lease Time
Hours must be between 0 and 23	Check the Hours field at DHCP Lease Time

If you clicked on **OK**, the following pop-up screen will be displayed. Click on **OK**. This will allow the modem to be reset and the new configuration will take affect.




If you clicked on **OK**, the following screen will be displayed. This screen shows that the Router is being reset.



Single Static IP Configuration

The following settings will be displayed if you select **Single Static IP Configuration** from the **Configuration** menu. The Single Static IP Configuration screen allows you to select the device on your LAN that will share your Single Static IP.


To enable Single Static IP, select either **User Configured PC** or **iad_hcrtl_0004** from the window in the **Single Static IP** screen. Click on **enable**.




If you clicked on **enable**, the following pop-up screen will appear. Click on **OK** to enable this device for Single Static IP, Click on **Cancel** to abort.



If you clicked on **OK** in the pop-up screen, the following pop-up screen will appear. The Router must be reset in order for the new configuration to take affect. Click on **OK**.




The following screen displays the IP address for the device you selected as your Single Static IP device. Click on **disable** if you want to disable the Single Static IP for this device.



Service Configuration

The following settings will be displayed if you select **Service Configuration** from the **Configuration** menu.

Westell has developed an extensive list of NAT services and you may select any service from this list. By selecting your specific NAT service and setting up a NAT profile, you will ensure that the appropriate ports on your Router are open and that the required application traffic can pass through your LAN. For a list of supported services, please go to section 9.8 (NAT Services).




Current Profile	Displays the NAT (Network Address Translation) services that you have selected.
Service Name	Drop down selection menu of NAT (Network Address Translation) service you can select to configure you Router.


If you select **new** from the **Service Configuration** screen, the **Create new NAT Profile?** pop-up screen will be displayed. Click on **OK** to begin creating your new NAT profile. Click **Cancel** if you do not want to create a new NAT profile.




This screen below shows that you have chosen to create a new NAT profile. After you create the new NAT profile, click on **enable**. You may create up to four NAT profiles and attach an unlimited number of services to each profile.



If you select **edit** from the **Service Configuration** screen, the following screen will be displayed. By selecting the **edit** feature, you can make changes to your NAT profile by adding or deleting NAT applications that will work with your Router. Type your new NAT profile name into the field labeled **Profile Name**.



The following screen shows that a new profile name called '**My NAT Profile**' was entered into the **Profile Name** field. If you want save the new NAT profile, click on **save**. If you do not want to save the new NAT profile, click on **close**.




If you clicked on **save** in the **Edit NAT Profile** screen, the following pop-up screen will be displayed. Click **OK** to save your new profile settings. If you click on **Cancel**, your new profile settings will not be saved.



The following screens show you how to add NAT services if you select **enable** from the **Service Configuration** screen.

Westell has developed an extensive list of NAT services and you may select any service from this list. By selecting your specific NAT service and setting up a NAT profile, you will ensure that the appropriate ports on your Router are open and that the required application traffic can pass through your LAN. For a list of supported services, please go to section 9.8 (NAT Services).

From the selection provided, click on the service name of your choice. Next, click on **enable** in the **Service Configuration** screen.




Click on **OK** in the **Load new NAT Configuration?** screen. This will load the new NAT Configuration and the settings will automatically be saved.




NOTE: You can attach multiple NAT services to your profile. However, for each NAT service that you attach to your profile, you must first select the new NAT service. Next, load the new NAT Configuration, as explained above.

Once you have selected a NAT service and you have saved it to your NAT profile, the screen below will be displayed. It shows which NAT service is active for the selected profile.




If you select **details** under **Services**, the screen below displays the details of the selected NAT service. If you select **delete**, you will remove that NAT service profile from your Router.



NOTE: If you would like to set up additional Advanced Service Configuration options, please refer to section 9.4 (Advanced Service Configuration).


Firewall Configuration

The following settings will be displayed if you select **Firewall Configuration** from the **Configuration menu**.



High	High security level only allows basic Internet functionality. Only Mail, News, Web, FTP, and IPSEC are allowed. All other traffic is prohibited.
Medium	Factory Default = Medium Like High security, Medium security only allows basic Internet functionality by default. However, Medium security allows customization through NAT configuration so that you can enable the traffic that you want to pass.
Low	The Low security setting will allow all traffic except for known attacks. With Low security, your Router is visible to other computers on the Internet.
Custom	Custom is an advanced configuration option that allows you to edit the firewall configuration directly. NOTE: only the most advanced users should try this.


If you select **Edit** from the **Security Level** screen, the **User Defined Firewall Rules** screen will be displayed. This screen allows you to change the security parameters on your Inbound and Outbound Firewall rules. To apply the new settings, click **Apply** in the screen labeled **User Defined Firewall Rules**.



If you clicked **Apply** in the **User Define Firewall Rules** screen, the following pop-up screen will be displayed. Click on **OK** if you want your new firewall setting to take affect. If you click **Cancel**, your new firewall settings will not take affect.




If you want to save your new firewall settings, click on **Save** in the screen labeled **User Define Firewall Rules**.



If you clicked **Save** in the **User Define Firewall Rules** screen, the following pop-up screen will be displayed. Click **OK** when asked **Do you wish to save these Rules to Flash and switch you Security Level to "User"?** This will save your new firewall settings. If you click **Cancel**, your new firewall settings will not be saved.




If you select **Help** in the screen labeled **User Defined Firewall Rules**, the following screen will be displayed. This screen give a detailed explanation of the Firewall Rules.



ATM Loopback Configuration

If you select **ATM Loopback** from the **Configuration** menu, the following settings will be displayed.





<p>Enable ATM 0/21 Loopback:</p>	<p>Factory Default = ENABLED</p> <p>This option enables the 0/21 loopback , which is used by your ISP. NOTE: Westell does not recommend that you change this setting.</p>
----------------------------------	---

9.4 Advanced Service Configuration

To setup additional Service Configuration options go to **Configuration** at the homepage menu and select **Service Configuration**. Click on **Advanced Configuration** at the **Service Configuration** screen.

When you click on **Advanced Configuration**, a Wizard will appear. The Wizard will guide you through the steps of creating an advanced NAT service entry. You can setup port forwarding and trigger port options as well as enable Static NAT through the advanced configuration wizard.

NOTE: Westell strongly recommends that you do not change any values in this section. If you experience any problems, please re-set your Router via the external hardware re-set switch or the procedure defined under the Maintenance menu.




Well Known Service	This option allows you to Configure Port Forwarding parameters based on well-known services.
Custom Service	This option allows you to customize your Port Forwarding based on your specific port requirements.
Static NAT	This option allows you to set up a Static NAT IP Address.


Well Known Service

If you select **Well Known Service** from the **Advanced NAT Configuration** screen, the following steps will walk you through the process of configuring your Router to work with the selected NAT service.


Select a service from the pull down menu. Click on **next**.




The selected service will appear in the **Well Know Service** field and in the **Service Name** field.




When the selected NAT service has been added, you will be notified. Click on **done**.



The screen below displays the added service.



If you clicked on **details** in the **Service Configuration** screen, the following settings will be displayed.




Service Name	The NAT service you selected.
Protocol	The type of Protocol used to run this NAT service
Local Port	The port that is running this NAT service.
Global Port	The port on the WAN that is used to run this NAT service.
Local IP Address	If a static IP address has been assigned, it will be displayed here.

If you clicked on here in the **Port Forwarding Details** screen, the following pop-up screen will be displayed.




Custom Service

If you select **Custom Service** from the **Advanced NAT Configuration** screen, the following steps will walk you through the process of configuring your Router to work with the special NAT services. Click on **next** to continue.




Port Forwarding with Translation

If you select **Port Forwarding with Translation**, the follow settings will be displayed. Click on **next** to continue.




This screen displays the NAT service that you are adding.




Service Name	The NAT service you selected.
Local IP Address	If a static IP address has been assigned, it will be displayed here.
Local Port	The port that is running this NAT service.
Global Port	The port on the WAN that is used to run this NAT service.
Protocol	The type of Protocol that is used to run this NAT service

The screen below displays a message that the NAT service has been added. Click on **done**.




Port Forwarding Ranges of Ports

If you select **Port Forwarding Ranges of Ports** from the **Custom Service** screen, the following settings from the **Port Range** screen will be displayed. Click on **next** to continue.




Service Name	The NAT service you selected.
Local IP Address	If a static IP address has been assigned, it will be displayed here.
Global Port Range	The port range that is provided by the service that you are customizing.
Protocol	The type of Protocol that is used to run this NAT service.

The screen below displays a message that the NAT service has been added. Click on **done**.




Port Forwarding Trigger Ports

If you select **Trigger Ports** from the **Custom Service** screen, the following settings will be displayed.




Service Name	The NAT service you selected.
Local Trigger Port	The local LAN side TCP/UDP port.
Global Port Range	The WAN side TCP/UDP port range.

The screen below displays a message that the NAT service has been added. The setup is complete. Click on **done**.




Static NAT


If you select **Static NAT** from the **Advanced NAT Configuration** screen, the following steps will walk you through the process of configuring your Router to work with the special NAT services.




Enter your Static NAT IP address. Click on **next**.



The screen below displays a message that the NAT service has been added. The setup is complete. Click on **done**.




The screen below displays the Static NAT address.



9.5 Maintenance

Backup/Store

The following settings will be displayed if you select **Backup/Restore** from the **Maintenance** menu.




Current configuration becomes Backup Configuration	Select this button if you want to store all of the current configuration data such that it can be recalled later.
Backed up configuration becomes Current configuration	Select this button if you want to retrieve the last back up copy of all configuration parameters and make these values current.
Factory default becomes Current configuration	Select this button if you want set all user configurable parameters back to the factory default.

Firewall Log


The following settings will be displayed if you select **Firewall Log** from the **Maintenance** menu.

This screen is an advanced diagnostics screen. It alerts you of noteworthy information sent to your Router from the Internet. The screen can contain 1000 entries, but a maximum of 50 entries are displayed at a time. Once 1000 entries have been logged, the oldest entry is removed to make space for the new entries as they occur. The following settings are displayed.



Packet	The packet number.
Time	The time that the packet was sent.
Interface	The type of protocol interface.
Direction	The direction of transmission.
Rule	The internal rule that caused the logged event. The internal rule is setup under Firewall rules.
Alert	A description of the logged event.

To view the details of a packet, click **Details** in the **Firewall Log** screen. This will bring up the **Packet Details** screen, which displays information about the specific log entry.



Source IP	Source IP of the packet that was logged
Destination IP	Destination IP of the packet that was logged.
Protocol	Type of Protocol used: TCP - Transmission Control Protocol UDP - User Datagram Protocol IP - Internet Protocol ICMP - Internet Control Message Protocol IGMP - Internet Group Management Protocol
Source Port (for	Source Port of the packet that was logged.

TCP/UDP* only)	The following identifiers may be displayed in this field: ICMP Type-Messages that are identified by a type field. ICMP Code-ICMP messages that have a code assigned to them. IGMP Type: Messages that are identified by a type field. IGMP Code: IGMP messages that have a code assigned to them.
Destination Port (for TCP/UDP* only)	Destination Port of the packet that was logged. The following identifiers may be displayed in this field: ICMP Type-Messages that are identified by a type field. ICMP Code-ICMP messages that have a code assigned to them. IGMP Type: Messages that are identified by a type field. IGMP Code: IGMP messages that have a code assigned to them.
TCP Flags	Reported error flags for TCP
*NOTE: TCP and UDP protocols carry Data. ICMP protocols contain only control messages for the TCP/IP.	


To clear the Firewall log, click **Clear Log** in the **Firewall Log** screen. The following pop-up screen will be displayed. Click **OK** when asked “**Do you wish to clear the Firewall log file?**” If you click **Cancel**, the firewall log will not be cleared.



To obtain a printable format of the Firewall Log, at the **Firewall Log** screen, click **Printable/Savable Format**. This will allow you to send a copy of the Firewall log to your designated printer.

Change Password

The following settings will be displayed if you select **Change Password** from the **Maintenance** menu. After you enter your data into the appropriate settings, click on **change**.




Enter Administrative Name NOTE: This changes the Systems Administrator password not the PPP password.	Type the name of your network administrative.
Enter Administrative Password	Type your network administrator's password.
Verify Administrative Password	Re-type your network administrator's password.

Remote Access


The following screen will appear if you select Remote Access from the **Maintenance** menu. To enable Remote Access, type in a password and click the enable remote access button.

NOTE: The password should be at least 4 characters long and should not exceed 32 characters. Do not type a blank space or asterisks in the Password field. The password is also case sensitive.




User Name	Displays your current User Name (Static field)
Password	Field for entering your password
URL	Displays the IP address of the remote management gateway

The following screen displays a message that the remote access is currently enabled. After 20 minutes of inactivity, or on reboot, remote access will be automatically disabled. To disable remote access, click on the **disable remote access** button.



Update Device


The following screen will be displayed if you click on **Update Device** from the **Maintenance** menu. This screen is used to update the firmware that controls the operation of the DSL modem. The updated firmware may be loaded from either a file that is located on your PC's hard drive or from update files stored on an Internet server.




Click on the **check for web update** button in the **Update Device** screen to check the web for possible software updates. This screen will retrieve the software update file and display any available update information. You must be connected to the Internet to use this option.

Click on the **web update now** button in the **Update Device** screen to download the software update file and automatically update the modem firmware if an update is available and applicable. You must be connected to the Internet to use this option.


If you click on the **settings** button in the **Update Device** screen, the following screen will appear. This screen displays the location of the update software file.




Click on the **local update now** button in the **Update Device** screen to select the upgrade file from your PC's hard drive. This screen allows you to upgrade the software on your Router. Click **Browse...** and go to the location where the upgrade file is stored.




Select the appropriate upgrade file from your browser. The file name will appear in the field labeled **Upgrade File**. Click on **upload file**.




This screen shows that the file is being uploaded to your Router.



This screens below show that the file upload has completed and that the Programming Flash is being erased to prepare the Flash storage area for upload of the new file. (Programming Flash is a temporary storage area for uploaded files.)




The screen below shows that the upload was successful. The modem will now reboot.






The screen below shows that the Router is being reset.



9.6 Troubleshooting

System Self Tests

The following settings will be displayed if you select **System Self Tests** from the **Troubleshooting** menu. Click on **test** to run a diagnostic test on your Router's connection.




Connection/Status	
DSL	<p>The Router checks the status of the Router connection.</p> <p>Possible responses are: UP: The Router is operating correctly and has obtained synchronization with the opposing network device. DOWN: The Router is operating correctly, but has not synchronized with the opposing device.</p>
PPPoE	<p>Indicates that a PPPoE session is or is not established.</p> <p>Possible responses are: Session UP: A valid PPPoE session has been detected. No Session: Currently there is no active PPPoE session established. Initiating Session: A PPP session must be connected from the homepage screen.</p>
PPP	<p>Indicates that a PPPoE or PPPoA session must already be established.</p> <p>Possible responses are: Connection UP: The Router has established a connection No Connection: There is no PPP connection Initiating Connection: The PPP connection process has been initiated Connection Halted: A successful PPP connection was halted Cannot Connect: A PPP connection could not be made because of a PPPoE session failure. Authorization Failure: The user name or password is incorrect.</p>




	Link Control Protocol Failed: Re-establish the session (from the home page).
Test Description / Test Results	
Self Test	Performs an integrity check of certain internal components of the Router.
PING ISP's Router	<p>Performs an IP network check (i.e., an IP Ping) of the Service Provider's Router. This test verifies that the Router can exchange IP traffic with an entity on the other side of the DSL line.</p> <p>Possible responses are: Success: The Router has detected an IP Remote Router connection. No Response: The IP Remote Router does not answer the IP Ping. Could not test: The test could not be executed because of the Router status.</p>
DNS	<p>Performs a test to try to resolve the name of a particular host. The host name is entered in the input box.</p> <p>Possible responses are: Success: The Router has successfully obtained the resolved address. The IP address is shown below the host name input box. No Response: The Router has failed to successfully obtain the resolved address. Host not found: The DNS Server was unable to find an address for the given host name. No data, enter host name: No host name is specified. Could not test: The test could not be executed because of Router status.</p>
IP Address	IP Address of the Host Name.
PING	<p>Performs an IP continuity check to a remote computer either within or beyond the Service Provider's network.</p> <p>Possible responses are: Success: The Remote Host computer was detected. No Response: There was no response to the Ping from the remote computer. No name or address to PING: No host name or IP address was specified. Could not test: The test could not be executed because of the Router status.</p>

Diagnostic Logs


If you select **Diagnostic Log**, from the **System Self Test** menu, the following screen will be displayed.



To see a list of the log options, click on the arrow at the LOGS pull-down menu. Select an option from the list provided at the **Diagnostics Logs** screen.




If you clicked on **All**, the following screen will be displayed. This screen provides a detailed list of the Router's connection status, and system information. Click on **clear diagnostic log** to clear the diagnostic log information.



WAN VC Statistics


The following settings will be displayed if you select **WAN VC Stats** from the **Troubleshooting** menu.



VPI/VCI	Displays the VPI/VCI values obtained from your Internet Service Provider.
In Errors	The number of error packets received on the ATM port.
In Discard Packets	The number of discarded packets received.
In Non Unicast Packets	The number of non-Unicast packets received on the ATM port.
In Unicast Packets	The number of Unicast packets received on the ATM port.
In Octets	The number of bytes received on the ATM port.
Out Errors	The number of outbound packets that could not be transmitted due to errors.
Out Discard Packets	The number of outbound packets discarded.
Out Non Unicast Packets	The number of non-Unicast packets transmitted on the ATM port.
Out Unicast Packets	The number of Unicast packets transmitted on the ATM port.
Out Octets	The number of bytes transmitted on the ATM port.
MTU	Maximum Transmission Unit -The number of data bytes contained in the ATM frame.
Interface Type	A unique identifier that represents the interface type.
Interface Description	A description field that refers to the interface type.

Ethernet Port Statistics


The following settings will be displayed if you select **Ethernet Port Stats** from the **Troubleshooting** menu.



In Errors	The number of error packets received on the Ethernet interface.
In Discard Packets	The number of discarded packets received.
In Non Unicast Packets	The number of non-Unicast packets received on the Ethernet interface.
In Unicast Packets	The number of Unicast packets received on the Ethernet interface.
In Octets	The number of bytes received on the Ethernet interface.
Out Errors	The number of outbound packets that could not be transmitted due to errors.
Out Discard Packets	The number of outbound packets discarded.
Out Non Unicast Packets	The number of non-Unicast packets transmitted on the Ethernet interface.
Out Unicast Packets	The number of Unicast packets transmitted on the Ethernet interface.
Out Octets	The number of bytes transmitted on the Ethernet interface.
MTU	Maximum Transmission Unit- The number of data bytes contained in the Ethernet frame.
Interface Type	A unique identifier that represents the interface type.
Interface Description	A description field that refers to the interface type.

Transceiver Statistics


The following settings will be displayed if you select **Transceiver Stats** from the **Troubleshooting** menu.



Transceiver Revision	The transceiver software version number.
Vendor ID Code	The CPE Vendor's ID code for their chipset.
Line Mode	The operational mode. Modes supported are No Mode, Multi Mode, T.1413 Mode, G.DMT Mode, and G.LITE Mode.
Data Path	The data path used (either Fast or Interleaved).
Transceiver Information-Down Stream/Up Stream Path	
DSL Speed (Kbits/Sec)	The transmission rate that is provided by your Internet Service Provider (ISP).
SNR Margin (db)	The Signal-to-Noise Ratio (S/N) where 0 db = 1×10^{-7} , which inhibits your DSL speed.
Line Attenuation (dB)	The DSL line loss.
Transmit Power (db/Hz)	The transmitted signal strength.

USB Port Statistics

The following settings will be displayed if you select **USB Port Stats** from the **Troubleshooting** menu.



Number of Resets	The number of times the Host PC reset the USB interface.
Number of Isrs	The number of times the Host PC requested communication with the Router.
In Unicast Packets	The number of packets received that did not have a Multicast or Broadcast class destination IP address.
In Non Unicast Packets	The number of packets received that had a Multicast or Broadcast class destination IP address.
In Multicast Frames	The number of frames received that had a Multicast class destination IP address.
In Broadcast Frames	The number of frames received that had a Broadcast class destination IP address.
In Errors	The number of packets received with an invalid format
Out Good Frames	The number of frames sent to the Host PC.
Out Unicast Packets	The number of packets sent that did not have a Multicast or Broadcast class destination IP address
Out Non Unicast Packets	The number of packets sent that had a Multicast or Broadcast class destination IP address.
Out Multicast Frames	The number of frames sent that had a Multicast class destination IP address.
Out Broadcast Frames	The number of frames sent that had a Broadcast class destination IP address.
Out Errors	The number of packets received by the Router but not sent to PC due to an error condition.

9.7 Help

If you select **Help** from the menu bar, a message from the help screens will be displayed. The type of message displayed depends on the menu that you are viewing. If you are viewing a pop-up screen, click the **help** link in the pop-up screen to obtain help messages.

A

About

This screen provides information about the Router. The following settings are displayed.

About	
Model Number	Router manufacturer's model number.
Serial Number	Router manufacturer's serial number.
MAC Address	Ethernet MAC (i.e., hardware) Address of the Router.
Software Version	Router application software version number.
Software Model	Router application type.
Description	Description of the Router protocol processing application software.
Boot Loader	Router boot loader version number.

Advanced Home Page

The advanced home page offers the same functionality as the home page but adds the ability to change the connection profile settings defined in the Router.

About	
Edit	An "Edit" link is added for each connection profile. Selecting this link will pop-up a window that allows the connection profile settings to be changed.
New Connection	The "New Connection" link will pop-up a window to allow the creation of a new connection profile.

ATM Loopback

ATM Loopback	
ATM Loopback	This setting enables 0/21 loopback. Westell recommends that you <u>do not</u> change this setting.

B

Backup/Restore

This option allows the Router configuration to be backed up to or restored from a secure location in flash. The following options are displayed.

Backup/Restore	
Current becomes Back-up	Selecting this command button will backup the current active configuration to the secure flash location.
Back-up becomes Current	This command button will restore the previously stored configuration from the flash location.
Factory becomes Current	This option will restore the Router to the state that it arrived in from the factory.

C

Change Administration Password

The Router has an administrators password. This password protects the Router from any unauthorized modifications to the configuration setting in the Router. The following settings are displayed.

Change Administration Password	
Enter Administration Name	This field specifies the Administrator's name. Only one administrator can be defined.
Enter/Verify Administration Password	This field specifies the password required to enable administrator access. The password must be entered twice to ensure that the password has been entered correctly.

Connection Summary

Connection Summary	
Connection Summary	The connection profile screen displays summary information about the Router. The connection state is shown along with the amount of traffic has passed through the Router. Each connection profile is listed with its associated usage information.

D

Diagnostics Help

This screen provides tools for diagnosing PPP connection problems. Some tests depend on the Router status and the capabilities exercised by previous tests, which may prevent other types of testing.

Beginning of Diagnostics Help screens

DSL

The Router status checks the Router connection. The following is a list of the possible responses:

DSL	
Up	The Router is operating correctly and has obtained synchronization with the opposing modem.
Down	Explanation: The Router is operating correctly, but has not synchronized with the opposing DSLAM. Solution: First, check to be sure that the cable connecting your Router to the ADSL wall jack is properly connected at both ends. If the cable is properly connected and the Router does not synchronize, try another phone cable. Next, wait for the Router to train. It can sometimes take as long as two minutes for the Router to train. If it still has not come into synchronization, power cycle the Router. If you have tried the approach above and the Router still does not synchronize, contact your service provider.

PPPoE

The PPPoE status indicates if a PPPoE session is established (i.e., if the PPPoE Discovery procedure has completed). The following is a list of the possible responses:

PPPoE	
Session up	A valid PPPoE session has been detected.
no session	Currently there is no active PPPoE session. A PPP session must be connected from the homepage screen.
initiating session	The connection process for a PPPoE session has been initialized. It can sometimes take a few seconds for the PPPoE Discovery procedure to complete. Wait 10-15 seconds and try again. If the PPPoE Discovery still cannot complete, there may be a configuration issue with your service provider's equipment. Verify your VPI/VCI settings (on the LAN Advanced page) and contact your ISP provider.
Session halted	A successful PPPoE session was halted. A PPP session must be connected from the homepage screen.
passed	A valid PPPoE session was established.
Session failure	A PPPoE session could not be made. There may be a configuration issue with your service provider's equipment. Verify your VPI/VCI settings (on the LAN Advanced page) and contact your provider.

PPP

This field displays the PPP Connection status. A PPPoE or PPPoA session must already be established. The following is a list of the possible responses:

PPP	
Connection up	The Router has established a PPP connection.
no connection	There is no PPP connection. A PPP session must be connected from the homepage screen.
initiating connection	The PPP connection process has been initialized.
Connection halted	A successful PPP connection was halted. Solution: A PPP session must be connected from the homepage screen.
Cannot connect	Explanation: A PPP connection could not be made because of a PPPoE session failure.
Authorization failure	The username or password is incorrect. Verify that the username and password your Service Provider issued are entered correctly.
Link control protocol failed	Try re-establishing the session (from the home page). If this doesn't help, there may be a configuration issue or other failure with your provider's equipment. Contact your service provider.

Self Test

The Self Test performs an integrity check of certain internal components of the Router. The following is a list of the possible responses:

Self Test	
Success	The Router is operating correctly.
Flash Corrupt	Explanation: The self-test process has detected a problem with internal flash memory. Solution: Restart the Router. If the error persists, contact your service provider.

PING ISPs' Router

The IP remote router test performs an IP network check (i.e., an IP Ping) of the Service Provider's Router. This test verifies that the Router can exchange IP traffic with an entity on the other side of the DSL line. The following is a list of the possible responses:

PING ISP's Router	
Success	The Router has detected an IP remote router connection.
No Response	Explanation: This message will occur when an IP remote Router does not answer the IP Ping. Solution: This test fails when the provider's Router does not give its IP address to the Router during session establishment. Try Pinging another host, using the Ping test near the bottom of the Diagnostic screen. If you are able to Ping any host, or even if you are able to find an IP address for a given host name (try "www.yahoo.com"), then the failure of the "IP Remote Router" test is moot, because the success of the Ping demonstrates that you are getting IP traffic across the DSL line. If the separate Ping fails as well, contact your service provider.
could not test	Explanation: Test could not be executed because of Router status.

DNS

The DNS test issues a request to try to resolve the name of a particular host. The host name is entered in the input box. The following is a list of the possible responses:

DNS	
Success	The Router has successfully obtained the resolved address. The IP address is shown below the host name input box
No Response	Explanation: The Router has failed to successfully obtain the resolved address. Solution: Determine the IP addresses of your DNS servers (from the home page, click "Edit" and then "Advanced"), and then use the Ping test near the bottom of the Diagnostic screen to try to Ping those addresses. This may provide useful information when you contact your service provider and speak with Technical Support.
Host not found	Explanation: The DNS Server was unable to find an address for the given host name. Solution: That host may no longer be available on the Internet. Try entering a different host name.
No data, enter host name	Explanation: There must be a host name entered in the input box.
could not test	Explanation: Test could not be executed because of Router status.

PING

Select **PING** to check IP continuity to a remote computer either within or beyond the Service Providers network.

Enter either the IP address or the hostname of the remote host computer into the input box to the right of the Test button. If you Ping by name, DNS will be used to look up the appropriate IP address for that name.

The following is a list of the possible responses:

PING	
Success	The Remote Host Computer was detected.
No Response	Explanation: This message will occur when there was no response to the Ping from the remote computer. Solution: Bear in mind that many hosts on the Internet are configured for security reasons to not respond to IP Ping messages. If you get a success from the DNS test using the same host name, chances are good that your connection is fine, whether you can Ping the named host or not.
No name or address to PING	Explanation: There must be a host name or IP address entered in the input box in order for the Router to Ping.
could not test	Explanation: Test could not be executed because of Router status.

End of Diagnostic Help Screens

DHCP Configuration

This screen contains the settings which control how the ADSL router interacts with the local devices connected to the router. Westell does not recommend that you change these settings. The following settings are displayed.

DHCP	
DHCP Server	Dynamic Host Configuration Protocol (DHCP) is an Internet standard that allows the ADSL router to automatically assign IP addresses to devices connected on the LAN network. It is advised that this is enabled for Private LAN.
DHCP Start Address (If DHCP is enabled)	This setting specifies the start of the IP address pool that the modem uses to assign IP addresses to local devices.
DHCP End Address (If DHCP is enabled)	This setting specifies the end address of the IP address pool used for automatic configuration of local devices.
DHCP Lease (If DHCP is enabled)	This setting specifies the DHCP lease time.

DNS Configuration

The Router has a built-in DNS server. The Router has a feature called "Dynamic DNS." When an IP address is assigned, the Router will interrogate the new device for a machine name using several well-known networking protocols. Any names learned will dynamically be added to the DNS servers table of local hosts. A static host assignment is needed only if the new device does not support any of the well-known protocols. The following settings are displayed.

DNS Configuration Screen	
Domain Name	The name of your network. This uses the internet standard for delineating domain names.
Static Host Assignment	This table allows the creation and maintenance of manually configured DNS entries.
Dynamic Host Assignment	This table shows the current list of devices that have automatically provided information.

E

Edit Connection Profiles

This screen facilitates the changing of connection profile parameters. The following settings are displayed.

Edit Connection Profiles	
Connection Name	This field is a description of the default connection profile that the Router will use. Feel free to use whatever description you desire.
Account ID	Your account ID is supplied by your ISP. This text string uniquely identifies you with your ISP.
Account Password	The Account Password is a key phrase or text string that verifies your identity to the ISP.
Service Profile	The Router stores several service profiles. A service profile is a collection of settings for the built-in firewall and NAT. These settings control which applications are enabled to talk through the Router. This selection specifies which service profile is used when the Router is using this connection.
Manual/Auto/Always ON	These radio buttons specify how this connection profile is used. A manual

	setting requires that this connection must be manually established through the “homepage” connection button. When this is set to auto, the Router will monitor the network traffic and determine when a connection needs to be made. The connection process will happen automatically the “Always ON” selection causes the Router to aggressively establish a connection with your ISP. Whenever the Router detects that the connection to your ISP is down, it will try to re-establish that connection.
Time Out Enable/Connection Time Out	Selecting this option will enable the disconnect timeout. If this option is enabled the Router will monitor the ISP connection for activity. If there is no activity for the timeout period, the Router will disconnect from the ISP.
Edit VC Connection	This screen is an advanced screen. Modifying parameters identified on this screen can cause severe disruption of your service. VC stands for “Virtual Connection.” A VC identifies a connection through the service provider’s ATM network to your ISP. It is not recommended that you change anything on these pages unless explicitly instructed by your service provider.

F

Firewall Settings

This screen is an advanced configuration screen. It allows you to set the level of security you wish to have on your local network. All security levels except “None” protect against known Internet attacks and devices that attempt to gain remote access to your Router. The following settings are displayed.

Firewall Settings	
High	This security level only allows basic Internet functionality. Only Mail, News, Web, FTP, and IPSEC are allowed. No other traffic is allowed. Another restriction of high security is that it can’t be modified by NAT configuration options. With High security, you are guaranteed to only pass the previously mentioned traffic.
Medium	This security level only allows basic Internet functionality by default. Like High security, Medium security, allows customization through NAT configuration, so you can enable the traffic that you want to pass.
Low	The low security setting will allow all traffic except for known attacks. With low security, your Router is visible by other computers on the Internet.
Custom	Custom is a very advanced configuration option that allows you to edit the firewall configuration directly. Only the most expert users should try this.

H

Home Page

The home page gives you a quick summary of the Router’s state. The following settings are displayed.

Home Page	
Connection Overview	The Connection Overview section displays the status of the DSL connection. The DSL must show a state of “UP” in order for the Router to communicate with your service provider’s network.
Connection Name	The Connection Name section displays all of the connection profiles that are

	defined by the Router. A connection profile is information that the Router needs to establish a connection to your ISP. The “PPP Status” columns will show a status of “UP” if the Router is currently using that profile to communicate. The command button allows you to control the connection state.
Profile Editor	Selecting the “Profile Editor” link will allow you to define or change any of the connection profile settings.

L

LAN Configuration

This screen contains the setting that controls how the Router interacts with the local devices connected to the Router. Westell does not recommend that you change these settings. The following settings are displayed.

LAN Configuration	
Router IP Address	This controls the IP address that the Router uses for local communication.
Subnet Mask	This setting specifies the subnet mask to use to determine if an IP address belongs to your local network.
DHCP Start Address	This setting specifies the start of the IP address pool that the Router uses to assign IP addresses to local devices.
DHCP End Address	This setting specifies the end address of the IP address pool used for automatic configuration of local devices.
DNS Server Enable	DNS stands for Domain Name System. This is an Internet standard that facilitates communication among devices. This allows a name to be used when specifying a device instead of an IP address. Normally you want this enabled.
DHCP Server Enable	DHCP stands for Dynamic Host Configuration Protocol. This is an Internet standard that allows the Router to automatically assign IP addresses to devices connected on the LAN network. It is advised that this option is set to Enabled.

LAN Statistics

This page contains information regarding the configuration and status of your Local LAN. The following settings are displayed.

LAN Configuration	
Device IP Address	This displays the IP address that the ADSL router uses for local communication.
DHCP NetMask	This displays the subnet address that the ADSL router’s DHCP server issues in DHCP responses.
DHCP Start Address	This setting specifies the start of the IP address pool that the modem uses to assign IP addresses to local devices.
DHCP End Address	This setting specifies the end address of the IP address pool used for automatic configuration of local devices.
DHCP Server Status	Displays the status, “ON” or “OFF” of the DHCP Server
DHCP Server	Displays which network “Public” or “Private” the DHCP server is serving IP addresses for.
Devices on LAN	This page displays the current devices the modem has found on your LAN. The name of the device, the Ethernet MAC address, and the status, “Active” or “Inactive” is displayed in the table.

P

Private LAN

This page contains the settings that control how the ADSL router interacts with the local devices connected to the router. It is not recommended that these settings be changed. The following settings are displayed.

Private LAN	
Private LAN DHCP Server Enable	Dynamic Host Configuration Protocol (DHCP) is an Internet standard that allows the ADSL router to automatically assign IP addresses to devices connected on the LAN network. It is advised that this is enabled for Private LAN.
Private LAN Enable	This setting enables the Private NAT'ed interface. It is advised to leave this enabled.
Modem IP Address	This controls the IP address that the ADSL router uses for local communication.
Subnet Mask	This setting specifies the subnet mask to use to determine if an IP address belongs to your local network.
DHCP Start Address (If DHCP is enabled for Private LAN)	This setting specifies the start of the IP address pool that the modem uses to assign IP addresses to local devices.
DHCP End Address (If DHCP is enabled for Private LAN)	This setting specifies the end address of the IP address pool used for automatic configuration of local devices.
DHCP Lease (If DHCP is enabled for Private LAN)	This setting specifies the DHCP lease time.

Protocol

Protocol	
Protocol	This screen informs the Router which networking protocol to use when communicating with your ISP. This information is provided by your ISP.

Public LAN

This screen contains the settings that control how the ADSL router interacts with the local devices connected to the router. It is not recommended that these settings be changed. The following settings are displayed.

Public LAN	
Public LAN DHCP Server Enable	Dynamic Host Configuration Protocol (DHCP) is an Internet standard that allows the ADSL router to automatically assign IP addresses to devices connected on the LAN network. It is advised that this is enabled for Private LAN.
Public LAN Enable	This setting enables the Public interface. This feature allows a global subnet to exist behind your modem.
Modem IP Address	This controls the IP address that the ADSL router uses for local communication.
Subnet Mask	This setting specifies the subnet mask to use to determine if an IP address

	belongs to your local network.
DHCP Start Address (If DHCP is enabled for Public LAN)	This setting specifies the start of the IP address pool that the modem uses to assign IP addresses to local devices.
DHCP End Address (If DHCP is enabled for Public LAN)	This setting specifies the end address of the IP address pool used for automatic configuration of local devices.
DHCP Lease (If DHCP is enabled for Public LAN)	This setting specifies the DHCP lease time.

S

Software Upgrade

Software Upgrade	
Software Upgrade	This screen is used to upgrade the Router's application image. The application image is specified by entering in the filename or by use of the browse button.

Single Static IP

This page contains the settings that would allow the PPP address received from the network to be propagated to a single LAN device behind the modem.

Single Static IP	
WAN IP Address	This is the PPP IP address the ISP has assigned the modem.
Selection box	<p>This box contains the devices available to share the Single Static IP address the ISP has assigned the modem. The names listed in the select box will be populated by the modem's DHCP server based on DHCP requests. If a device's name cannot be determined, the current IP address of the device will be placed in the list.</p> <p>When the feature is enabled, the active machine will be highlighted in the select box and be displayed at the bottom of the page with the "disable" button.</p> <p>When the feature is disabled, no device in the select box will be highlighted and the "enable" button will be available.</p> <p>When the "User Configured PC" is selected, a local PC must be configured manually with the WAN IP address as its Ethernet adapter's address.</p>

U

User Name

This screen asks for information that will allow the Router to make a connection to the ISP on your behalf. The Router will need to know your Account ID and Account Password. This information is stored in the Router.

User Name	
Connection Name	This is a description of the default connection profile, which the Router will use. Feel free to use whatever description you desire.
Account ID	Your Account Id is supplied by your ISP and is a text string that uniquely identifies you with your ISP.
Account Password	The Account Password is a key phrase or text string that verifies your identity to the ISP.

V

VC Configuration

VC Configuration Screen	
VC Configuration	This screen is an advanced screen. Modifying parameters on this screen can cause severe disruption of your service. VC stands for "Virtual Connection." A VC identifies a connection through the service provider's ATM network to your ISP. It is not recommended that anything be changed on these pages unless explicitly instructed by your service provider.

VPI/VCI

VPI/VCI	
VPI/VCI	This screen asks for information that the Router needs to establish a communication channel to your ISP. The VPI and VCI values are supplied by your ISP.

9.8 NAT Services

For your convenience, the Westell Router supports protocols for Applications, Games, and VPN-specific programs. Table 6 provides protocol information for the services that are supported by your Router.

NOTE: To configure your Router for a service or application, follow the steps from the Advanced Service Configuration section. See section 9.4 of this User Guide.

Table 6. Applications/Games/VPN Support

Application/Game	Port/Protocol
Aliens vs. Predator	80 UDP, 2300 UDP, 8000-8999 UDP
America Online	5190 TCP/UDP
Anarchy Online	7013 TCP/UDP, 7500-7501 TCP/UDP
AOL Instant Messenger	4099 TCP, 5190 TCP
Asheron's Call	9000-9013 UDP
Battlecom	2300-2400 TCP/UDP, 47624 TCP/UDP
Black and White	2611-2612 TCP, 6667 TCP, 6500 UDP, 27900 UDP
Blizzard Battle.net (Diablo II)	4000 TCP, 6112 TCP/UDP
Buddy Phone	700, 701 UDP
Bungie.net, Myth, Myth II Server	3453 TCP
Calista IP Phone	3000 UDP, 5190 TCP
Citrix Metaframe	1494 TCP
Client POP/IMAP	110 TCP
Client SMTP	25 TCP
Counter Strike	27015 TCP/UDP, 27016 TCP/UDP
Dark Reign 2	26214 TCP/UDP
Delta Force (Client and Server)	3568 UDP, 3100-3999 TCP/UDP
Delta Force 2	3568-3569 UDP
DeltaForce: Land Warrior	UDP 53 TCP 21 TCP 7430 TCP 80 UDP 1029 UDP 1144 UDP 65436 UDP 17428
DNS	53 UDP
Elite Force	2600 UDP, 27500 UDP, 27910 UDP, 27960 UDP
Everquest	1024-7000 TCP/UDP
F-16, Mig 29	3863 UDP
F-22 Lightning 3	4660-4670 TCP/UDP, 3875 UDP, 4533-4534 UDP, 4660-4670 UDP
F-22 Raptor	3874-3875 UDP
Fighter Ace II	50000-50100 TCP/UDP
Fighter Ace II for DX play	50000-50100 TCP/UDP, 47624 TCP, 2300-2400 TCP/UDP
FTP	20 TCP, 21 TCP
GameSpy Online	UDP 3783 UDP 6515 TCP 6667 UDP 12203



Application/Game	Port/Protocol
	TCP/UDP 13139 UDP 27900 UDP 28900 UDP 29900 UDP 29901
Ghost Recon	TCP 80 UDP 1038 UDP 1032 UDP 53 UDP 2347 UDP 2346
GNUTella	6346 TCP/UDP, 1214 TCP
Half Life Server	27005 UDP(client only) 27015 UDP
Heretic II Server	28910 TCP
Hexen II	26900 (+1) each player needs their own port. Increment by one for each person
Hotline Server	5500, 5503 TCP 5499 UDP
HTTPS	443 TCP/UDP
ICMP Echo	4 ICMP
ICQ OLD	4000 UDP, 20000-20019 TCP
ICQ 2001b	4099 TCP, 5190 TCP
ICUII Client	2000-2038 TCP, 2050-2051 TCP, 2069 TCP, 2085 TCP, 3010-3030 TCP
ICUII Client Version 4.xx	1024-5000 TCP, 2050-2051 TCP, 2069 TCP, 2085 TCP, 3010-3030 TCP, 2000-2038 TCP, 6700-6702 TCP, 6880 TCP, 1200-16090 TCP
IMAP	119 TCP/UDP
IMAP v.3	220 TCP/UDP
Internet Phone	22555 UDP
IPSEC ESP	PROTOCOL 50
IPSEC IKE	500 UDP
Ivisit	9943 UDP, 56768 UDP
KALI, Doom & Doom II	2213 UDP, 6666 UDP (EACH PC USING KALI MUST USE A DIFFERENT PORT NUMBER STARTING WITH 2213 + 1
KaZaA	1214 TCP/UDP
Limewire	6346 TCP/UDP, 1214 TCP
Medal Of Honor: Allied Assault	TCP 80 UDP 53 UDP 2093 UDP 12201 TCP 12300 UDP 2135 UDP 2139 TCP/UDP 28900
mIRC Chat	6660-6669 TCP
Motorhead Server	16000 TCP/UDP, 16010-16030 TCP/UDP
MSN Game Zone	6667 TCP, 28800-29000 TCP
MSN Game Zone (DX 7 & 8 play)	6667 TCP, 6073 TCP, 28800-29000 TCP, 47624 TCP, 2300-2400 TCP/UDP



Application/Game	Port/Protocol
MSN Messenger	6891-6900 TCP, 1863 TCP/UDP, 5190 UDP, 6901 TCP/UDP
Napster	6699 TCP
Need for Speed 3, Hot Pursuit	1030 TCP
Need for Speed, Porsche	9442 UDP
Net2Phone	6801 UDP
NNTP	119 TCP/UDP
Operation FlashPoint	47624 UDP, 6073 UDP, 2300-2400 TCP/UDP, 2234 TCP
Outlaws	5310 TCP/UDP
Pal Talk	2090-2091 TCP/UDP, 2095 TCP, 5001 TCP, 8200-8700 TCP/UDP, 1025-2500 UDP
pcAnywhere host	5631 TCP, 5632 UDP, 22 UDP
Phone Free	1034-1035 TCP/UDP, 9900-9901 UDP, 2644 TCP, 8000 TCP
Quake 2	27910 UDP
Quake 3	27660 UDP Each computer playing QuakeIII must use a different port number, starting at 27660 and incrementing by 1. You'll also need to do the following: 1. Right click on the QIII icon 2. Choose "Properties" 3. In the Target field you'll see a line like "C:\Program Files\Quake III Arena\quake3.exe" 4. Add the Quake III net_port command to specify a unique communication port for each system. The complete field should look like this: "C:\Program Files\Quake III Arena\quake3.exe" +set net_port 27660 5. Click OK. 6. Repeat for each system behind the NAT, adding one to the net_port selected (27660,27661,27662)
Quicktime 4/Real Audio	6970-32000 UDP, 554 TCP/UDP
Rainbow Six & Rogue Spear	2346 TCP
Real Audio	6970-7170 UDP
Return To Castle Wolfenstein	27960 TCP/UDP
Roger Wilco	TCP/UDP 3782 UDP 3783 (BaseStation)
ShoutCast Server	8000-8005 TCP
SSH Secure Shell	22 TCP/UDP
Starcraft	2346 TCP
Starfleet Command	2300-2400 TCP/UDP, 47624 TCP/UDP
Telnet	23 TCP
Tiberian Sun & Dune 2000	1140-1234, 4000 TCP/UDP
Ultima Online	5001-5010 TCP, 7775-7777 TCP, 8800-8900 TCP, 9999 UDP, 7875 UDP
Unreal Tournament server	7777 (default gameplay port) 7778 (server query port) 7779,7779+ are allocated dynamically for each helper UdpLink objects, including UdpServerUplink objects. Try starting with 7779-7781 and add ports if needed 27900 server query, if master server uplink is enabled. Home master servers use other ports like 27500 Port 8080 is for UT Server Admin. In the [UWeb.WebServer] section of the server.ini file, set the ListenPort to 8080 and ServerName to the IP assigned to the Modem from your ISP.
USENET News Service	143 TCP



Application/Game	Port/Protocol
VNC, Virtual Network Computing	5500 TCP, 5800 TCP, 5900 TCP
Westwood Online, C&C	4000 TCP/UDP, 1140-1234 TCP/UDP
World Wide Web (HTTP)	80 TCP 443 TCP (SSL) 8008 OR 8080 TCP (PROXY)
Yahoo Messenger Chat	5000-5001 TCP
Yahoo Messenger Phone	5055 UDP
VPN Protocol	Comments
IPSec Encryption	IPSec using AH can not be supported through NAT. IPSec using ESP and L2TP can be supported via an ALG
L2TP	IPSec using ESP and L2TP can be supported via an ALG.
PPTP	Works through NAT.



10. TECHNICAL SUPPORT INFORMATION

Westell Technical Support

If technical assistance is required, contact Westell by using one of the following options:

Phone: 1-630-375-4500
email: global_support@westell.com

Visit Westell at www.westell.com to obtain additional information, view frequently asked questions, and enter on-line service requests.

11. WARRANTY AND REPAIRS

Warranty

Westell warrants this product free from defects at the time of shipment. Westell also warrants this product fully functional for the period specified by the terms of the warranty. Any attempt to repair or modify the equipment by anyone other than an authorized Westell representative will void the warranty.

Repairs

Westell will repair any defective Westell equipment without cost during the warranty period if the unit is defective for any reason other than abuse, improper use, or improper installation, or acts of nature. Before returning the defective equipment, request a **Return Material Authorization (RMA)** number from Westell. Once an RMA number is obtained, return the defective unit, freight prepaid, along with a brief description of the problem to:

Westell, Inc.
ATTN: R.G.M Department
750 N. Commons Drive
Aurora, IL 60504-7940

Westell will continue to repair faulty equipment beyond the warranty period for a nominal charge. Contact a Westell Technical Support Representative for details.

12. PRODUCT SPECIFICATIONS

ADSL

- DSL Line Code: Discrete Multi-Tone (DMT)
- DSL Rates: 32 kbps to 8 Mbps downstream and 32 kbps to 800 Kbps upstream
- Power spectral density: -40 dBm/Hz
- DSL Impedance: 100 Ohms
- DSL Performance: Performance: per G.992.1, ANSI T1.413.

Protocol Features

- Bridge Encapsulation per RFC2684 (Formerly RFC1483)
- Logical Link Control/Subnetwork Access Protocol (LLC/SNAP)
- Software Upgradeable
- PPPoE Support
- ATM SAR: Internal to Modem

12.1 System Requirements for USB

- Pentium Class PC or above
- Microsoft Windows 98, 2000, ME, or XP installed
- Operating system CD
- Internet Explorer 4.x or Netscape Navigator 4.x or higher
- 32 MB RAM
- 10 MB of free hard drive space
- USB Version 1.0 or 1.1 compliant bus

12.2 System Requirements for 10/100 Base-T/Ethernet

- Pentium Class PC or above
- Microsoft Windows 95, 98, 2000, ME, NT 4.0, or XP installed or
- Macintosh® OS 9.X or OS X installed
- Operating system CD
- 32 MB RAM
- Ethernet 10/100 Base-T interface
- 10 MB of free hard drive space
- TCP/IP Protocol installed

Dimensions

- Weight Height: 1.6 in. (4.1 cm)
- Width: 7.3 in. (18.5 cm)
- Depth: 6.1 in. (15.5 cm)

Weight

- Approx. 0.63 lbs. (0.29 kg)

Environmental

- Ambient Operating Temperature: +32 to +104°F (0 to +40°C)
- Relative Humidity: 5 to 95%, non-condensing

Power Supply

- 120 VAC to 12 VAC wall-mount power supply

Power Consumption

- Less than 8 watts typical, from 120 VAC

Connectors

- DSL/LINE: 6-pin modular jack
- Power connector
- PC: USB Series B connector
- Ethernet: 8-pin RJ-45 modular jack

EMC Compliance

- FCC, Part 15 Class B

Safety

- Conforms to UL Standard 60950, 3rd Edition
- Certified to CAN/CSA Standard C22.2 No. 60950

Regulatory Approval

- UL
- CSA
- FCC, Part 68
- Industry Canada CS03

13. SOFTWARE LICENSE AGREEMENT

READ THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT CAREFULLY. THIS SOFTWARE IS COPYRIGHTED AND LICENSED (NOT SOLD). BY INSTALLING AND OPERATING THIS PRODUCT, YOU ARE ACCEPTING AND AGREEING TO THE TERMS OF THIS LICENSE AGREEMENT. IF YOU ARE NOT WILLING TO BE BOUND BY THE TERMS OF THIS LICENSE AGREEMENT, YOU SHOULD PROMPTLY RETURN THE SOFTWARE AND HARDWARE TO WESTELL TECHNOLOGIES, INC. THIS LICENSE AGREEMENT REPRESENTS THE ENTIRE AGREEMENT CONCERNING THE SOFTWARE BETWEEN YOU AND WESTELL TECHNOLOGIES, INC. (REFERRED TO AS "LICENSOR"), AND IT SUPERSEDES ANY PRIOR PROPOSAL, REPRESENTATION, OR UNDERSTANDING BETWEEN THE PARTIES.

1. License Grant. Licensor hereby grants to you, and you accept, a nonexclusive license to use the SOFTWARE Diskettes and the computer programs contained therein in machine-readable, object code form only (collectively referred to as the "SOFTWARE"), and the accompanying User Documentation, only as authorized in this License Agreement. The SOFTWARE may be used only in connection with the number of systems for which you have paid license fees as dictated in your support agreement. You agree that you will not assign, sublicense, transfer, pledge, lease, rent, or share your rights under this License Agreement. You agree that you may not reverse assemble, reverse compile, or otherwise translate the SOFTWARE.

You may retain the SOFTWARE Diskettes for backup purposes only. In addition, you may make one copy of the SOFTWARE in any storage medium for backup purposes only. You may make one copy of the User's Manual for backup purposes only. Any such copies of the SOFTWARE or the User's Manual shall include Licensor's copyright and other proprietary notices. Except as authorized under this paragraph, no copies of the SOFTWARE or any portions thereof may be made by you or any person under your authority or control.

2. Licensor's Rights. You acknowledge and agree that the SOFTWARE and the User's Manual are proprietary products of Licensor protected under U.S. copyright law. You further acknowledge and agree that all right, title, and interest in and to the SOFTWARE, including associated intellectual property rights, are and shall remain with Licensor. This License Agreement does not convey to you an interest in or to the SOFTWARE, but only a limited right of use revocable in accordance with the terms of this License Agreement.

3. License Fees. The fees paid by you under the support agreement are paid in consideration of the licenses granted under this License Agreement.

4. Term. This License Agreement is effective upon your opening of this package and shall continue until terminated. You may terminate this License Agreement at any time by returning the SOFTWARE and all copies thereof and extracts therefrom to Licensor. Licensor may terminate this License Agreement upon the breach by you of any term hereof. Upon such termination by Licensor, you agree to return to Licensor the SOFTWARE and all copies and portions thereof.

5. Limited Warranty. Licensor warrants, for your benefit alone, for a period of 90 days from the date of commencement of this License Agreement (referred to as the "Warranty Period") that the SOFTWARE Diskettes in which the SOFTWARE is contained are free from defects in material and workmanship. Licensor further warrants, for your benefit alone, that during the Warranty Period the SOFTWARE shall operate substantially in accordance with the functional specifications in the User's Manual. If during the Warranty Period, a defect in the SOFTWARE appears, you may return the SOFTWARE to Licensor for replacement. You agree that the foregoing constitutes your sole and exclusive remedy for breach by Licensor of any warranties made under this Agreement.



EXCEPT FOR THE WARRANTIES SET FORTH ABOVE, THE SOFTWARE DISKETTES, AND THE SOFTWARE CONTAINED THEREIN, ARE LICENSED "AS IS," AND LICENSOR DISCLAIMS ANY AND ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

6. Limitation of Liability. Licensor's cumulative liability to you or any other party for any loss or damages resulting from any claims, demands, or actions arising out of or relating to this Agreement shall not exceed the license fee paid to Licensor for the use of the SOFTWARE. In no event shall Licensor be liable for any indirect, incidental, consequential, special, or exemplary damages or lost profits, even if Licensor has been advised of the possibility of such damages. **SOME STATES DO NOT ALLOW THE LIMITATION OR EXCLUSION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.**

7. Governing Law. This License Agreement shall be construed and governed in accordance with the laws of the State of Illinois. You submit to the jurisdiction of the state and federal courts of the state of Illinois and agree that venue is proper in those courts with regard to any litigation arising under this Agreement.

8. Costs of Litigation. If any action is brought by either party to this License Agreement against the other party regarding the subject matter hereof, the prevailing party shall be entitled to recover, in addition to any other relief granted, reasonable attorney fees and expenses of litigation.

9. Severability. Should any term of this License Agreement be declared void or unenforceable by any court of competent jurisdiction, such declaration shall have no effect on the remaining terms hereof.

10. No Waiver. The failure of either party to enforce any rights granted hereunder or to take action against the other party in the event of any breach hereunder shall not be deemed a waiver by that party as to subsequent enforcement of rights or subsequent actions in the event of future breaches.

14. PUBLICATION INFORMATION

Westell® 4-Port Router (Model 2400)
User Guide Part Number 030-300331 Rev. A
October 2002

©2002 Westell, Inc.
All rights reserved. Printed in the USA.

Westell, Inc.
750 North Commons Drive
Aurora, Illinois 60504 USA
(630)375-4500
www.westell.com

Trademarks

