

## **INSTALLATION INSTRUCTIONS KK-RLL ROOF MOUNTED LOAD LIGHT**

### **TOOLS REQUIRED:**

Power drill	Safety goggles
Caulk gun with silicone	Wrench set
3/8" drill bit	

### **HARDWARE SUPPLIED:**

1	Work Light with Double Lamp	HE-90600B
2	5/16 -18 x 1" Stainless Hex Head Bolt	GSM34010
2	5/16-18 Nylock Nut	GSM30017
2	5/16" x 1 1/2" Fender Washer	GSM31019
1	3/8" Plastic Grommet	GSM20003
1	Light mounting Bracket	PRM97310

### **INSTALLATION INSTRUCTIONS:**

*Note: Mounting and wiring must be done prior to prisoner compartment installation.*

1. Bolt light fixture to the mounting bracket. (End with 2" flange and one hole). Overall bracket size is 10 1/2" long by 2" wide.
2. Position load light bracket in desired location on roof: Recommended location is to center light above door opening on side or rear of van. If there is a third brake light, position the work light over the third brake light not on top of light.
3. Mark and drill three (3) 3/8" diameter holes. Bolt the bracket assembly on with two (2) stainless steel 5/16-18 x 1" bolts, nuts and fender washers.
4. The 3<sup>rd</sup> 3/8" diameter hole is for the wire. Wire goes through the roof and the bracket. Insert 3/8" plastic grommet in the hole from inside van going outside. Run wire through the bracket and grommet. Silicone the hole.
5. Follow the attached wiring diagram for the standard 3-way switching included in kit. This gives the option of turning light on from the cab of the vehicle or the rear or side doors.

*Note: See attached wiring diagram.*

*Note: If desired, light can be activated with a single pole single throw switch in the dash.*

**KWIK KIT OPTION  
ROOF MOUNTED LOAD LIGHT (KK-RLL)  
3-WAY SWITCHING WIRE DIAGRAM**

