





Alienware Hangar18 Quick Start Guide



HDTV must be HDCP compliant



Blu-ray Disc™ 1080p HD Connection



NOTE: The video outputs shaded above (HDMI, VGA and Component) will not be functional when using the HDMI 1080p graphics card.




You can playback your Blu-ray Disc™ DVD's from the Vista Media Center main menu.


OPTION 1 - Connect to your HDTV via 1080p HDMI cable



Alienware Hangar18 Quick Start Guide




OPTION 2 - Connect to your HDTV via 720p HDMI cable




2 OPTION 3 - Connect to your HDTV via Component cable




Alienware Hangar18 Quick Start Guide



720p HD Connection




OPTION 4 - Connect to your HDTV via VGA cable



SUBWOOFER Connection


FL FR RL RR C




Connect to 5.1 speakers 3



Alienware Hangar18 Quick Start Guide



Connect power cord and turn POWER switch to ON position



4 Connect USB receiver for TV remote