User Instructions





CAUTION! Read instructions before installing or plugging unit in.

SPECIFICATIONS: MODEL - Spirograph™

Weight: 8 lbs.

Size: 8.5" H x 8" W x 15" L Lamp: ZB-EXN 12V 50W

Fuse: 3A Voltage In: 120V

Working

Position: Any Safe position

Duty Cycle: None

HALOGEN LAMP WARNING!

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.

Thank you for purchasing the Spiral Graph™ by American DJ®. For your convenience the Spiral Graph™ has been lamped and is ready to be used, there is no assembly required. Please read the following instructions before installing or using your new Spiral Graph™.

Operating Instructions:

Unit is ready to be hung or set on flat surface. Unit will rotate wheel slowly making a unique, vibrant kaliedoscopic effect that produces a multi-colored and multi-textured effect. Motor rotation will start when unit is turned on/off. For best results, shine on a light colored wall or ceiling. we suggest using fog or special effects smoke when using this unit. This will enhance the effect allowing you to see the beams of light. Use an American DJ® high quality mobile pro fog machine.

Caution! Never open unit when in use. Always disconnect main power before serving or replacing lamp. Remember always replace same lamp and fuses.

Lamp replacement: Remove single knurled screws from top of unit, , and remove top panel and disconnect lamp from socket. Remove and replace lamp.