

0000:0000=Unknown USB Device  
0001=Fry's Electronics  
0001:142B=Arbiter Systems, Inc.  
0002=Ingram  
0003=Club Mac  
0004=Nebraska Furniture Mart  
0009:21E7=Sagemcom  
0017:04CA=Office Keyboard  
0053=Planex  
0053:5301=GW-US54ZGL 802.11bg (zd1211rw)  
0066=SCM Microsystems  
0066:1001=SCM Microsystems SCR300 USB Smart Card Reader  
0079=DragonRise  
0079:0006=Generic USB Joystick  
0079:0011=Gamepad  
0104:00BE=Socket USB Sync Card  
0105=Unknown  
0105:145F=802.11bg (zd1211rw)  
0123:0001=Touchkit USB Controller for TouchScreen  
0145=Unknown  
0145:0112=Card Reader  
0154=LW154 Wireless 150N Adapter  
0200:19FF=Rocketfish Bluetooth Adapter  
0204=Chipsbank Microelectronics  
0204:6025=CBM2080 Flash drive controller  
0204:6026=CBM1180 Flash drive controller  
0218=Hangzhou World  
0218:0301=MIDI Port  
02AD=HUMAX  
02AD:138C=PVR Mass Storage  
0300=MM300 eBook Reader  
0324=OCZ Technology  
0324:BC06=OCZ ATV USB 2.0 Flash Drive  
0324:BC08=OCZ Rally2/ATV USB 2.0 Flash Drive  
0325=OCZ Technology  
0325:AC02=ATV Turbo / Rally2 Dual Channel USB 2.0 Flash Drive  
0326:1028=ViPower USB 2.0 MobileRACK  
0326:6228=ViPower USB 2.0 Storage Adapter  
0326:8220=ViPower USB 2.0 SmartDUP  
0326:8258=ViPower USB 2.0 SmartDOCK  
0326:9208=ViPower USB 2.0 SmartCABLE  
0326:9258=ViPower USB 2.0 Storage Bridge  
0386=LTS  
0386:0001=PSX for USB Converter  
03DA=Bernd Walter Computer Technology  
03DA:0002=HD44780 LCD interface  
03E8=AOX  
03E8:0004=SE401 WebCam  
03E8:0006=DFR-200 USB Fingerprint Reader  
03E8:0008=Endpoints USB Ethernet Adapter  
03E8:0015=OnSpec EEPROM  
03E8:2123=SiPix StyleCam Deluxe  
03E8:8004=Aox 99001  
03E9=Thesys Microelectronics  
03EA=Data Broadcasting  
03EB=Atmel  
03EB:0002=TVTool USB-Sconi  
03EB:0902=USB 4-Port Hub  
03EB:2002=Mass Storage Device  
03EB:2015=at90usbkey sample firmware (HID keyboard)

03EB:2018=at90usbkey sample firmware (CDC ACM)  
03EB:2019=stk525 sample firmware (microphone)  
03EB:201C=at90usbkey sample firmware (HID mouse)  
03EB:201D=at90usbkey sample firmware (HID generic)  
03EB:2022=at90usbkey sample firmware (composite device)  
03EB:2040=LUFA Test PID  
03EB:2041=LUFA Mouse Demo Application  
03EB:2042=LUFA Keyboard Demo Application  
03EB:2043=LUFA Joystick Demo Application  
03EB:2044=LUFA CDC Demo Application  
03EB:2045=LUFA Mass Storage Demo Application  
03EB:2046=LUFA Audio Output Demo Application  
03EB:2047=LUFA Audio Input Demo Application  
03EB:2048=LUFA MIDI Demo Application  
03EB:2049=Stripe Snoop Magnetic Stripe Reader  
03EB:204A=LUFA CDC Class Bootloader  
03EB:204B=LUFA USB to Serial Adapter Project  
03EB:204C=LUFA RNDIS Demo Application  
03EB:204D=LUFA Combined Mouse and Keyboard Demo Application  
03EB:204E=LUFA Dual CDC Demo Application  
03EB:204F=LUFA Generic HID Demo Application  
03EB:2060=Benito Programmer Project  
03EB:2061=LUFA Combined Mas Storage and Keyboard Demo Application  
03EB:2062=LUFA Combined CDC and Mouse Demo Application  
03EB:2063=LUFA Datalogger Device  
03EB:2064=Interfaceless Control-Only LUFA Devices  
03EB:2065=LUFA Test and Measurement Demo Application  
03EB:2066=LUFA Multiple Report HID Demo  
03EB:2068=LUFA Virtual Serial/Mass Storage Demo  
03EB:2069=LUFA Webserver Project  
03EB:2103=JTAG ICE mkII  
03EB:2104=AVR ISP mkII  
03EB:2105=AVRONE!  
03EB:2106=STK600 development board  
03EB:2107=AVR Dragon  
03EB:210D=XPLAIN evaluation kit (CDC ACM)  
03EB:2122=XMEGA-A1 Explained evaluation kit  
03EB:21FE=USB to UART Protocol Converter  
03EB:21FE:0001=USB to UART Protocol Converter (AVR309)  
03EB:2310=EVK11xx evaluation board  
03EB:2FFB=at90usb AVR DFU bootloader  
03EB:2FFD=at89c5130/c5131 DFU bootloader  
03EB:2FFF=at89c5132/c51sndlc DFU bootloader  
03EB:3301=USB 4-Port Hub  
03EB:3301:0300=SIIG USB Switch 4-to-2  
03EB:3312=USB 4-Port Hub  
03EB:4102=AirVast W-Buddie WN210  
03EB:5601=NETGEAR ME102 Access Point  
03EB:5603=Cisco 7920 WiFi IP Phone  
03EB:6124=at91sam SAMBA bootloader  
03EB:7602=Red Inalambrica Local 802.11b WLAN USB Card  
03EB:7603=AT76c503a D-Link DWL-120 802.11b Adapter  
03EB:7604=FastVNET  
03EB:7605=AT76c503a 802.11b Adapter  
03EB:7606=AT76c505 802.11b dapter  
03EB:7611=NETGEAR ME102 Access Point  
03EB:7613=WL-1130 USB  
03EB:7614=AT76c505a Wireless Adapter  
03EB:7615=AT76C505AMX Wireless Adapter  
03EB:7617=SMC EZ Connect Wireless USB Adapter(SMC2662W)

03EB:7800=Mini Album  
03EB:FF07=Tux Droid fish dongle  
03EC=Iwatsu America  
03ED=Mitel  
03EE=Mitsumi  
03EE:0000=Mitsumi USB CD-R/RW Drive  
03EE:2501=eHome Infrared Receiver (USBCIR)  
03EE:2502=eHome Infrared Receiver (USBCIR)  
03EE:2600=Mitsumi Fingerprint Reader  
03EE:5609=Mitsumi Japanese USB Keyboard  
03EE:641F=WIF-0402C Bluetooth Adapter  
03EE:6438=Mitsumi Bluetooth Device  
03EE:6440=WML-C52APR Bluetooth Adapter  
03EE:6901=Mitsumi USB Floppy  
03EE:6902=Mitsumi USB Floppy Disk Drive  
03EE:7500=MITSUMI USB2.0 CD-R/RW  
03EE:FFFF=Bluetooth Devices  
03F0=Hewlett Packard  
03F0:0004=DeskJet 895c  
03F0:0011=OfficeJet G55  
03F0:0011:0100=HP OfficeJet G55 USB  
03F0:0012=DeskJet 1125C Printer Port  
03F0:0024=KU-0316 Keyboard  
03F0:002A=LaserJet P1102  
03F0:002A:01=P1100 USB EWS Device Driver  
03F0:0101=HP ScanJet 4100C  
03F0:0101:0100=Hewlett Packard ScanJet 4100C  
03F0:0102=PhotoSmart S20  
03F0:0104=DeskJet 880c/970c  
03F0:0105=ScanJet 4200c  
03F0:0107=HP USB CD-Writer Plus  
03F0:010C=Multimedia Keyboard USB Hub  
03F0:0111=G55xi Printer/Scanner/Copier  
03F0:0111:0100=HP OfficeJet G55xi USB  
03F0:0117=LaserJet 3200  
03F0:0117:0100=HP LaserJet 3200 USB  
03F0:011C=hn210w 802.11b Adapter  
03F0:011D=HP nc4200  
03F0:011D:0017=HP nc4200  
03F0:0121=HP49g+ Calculator  
03F0:0122=HP USB Internet Keyboard  
03F0:0125=HP USB Mass Storage Device  
03F0:012A:0100:03=HP LEDM Driver  
03F0:0201=HP ScanJet 6200C  
03F0:0201:0100=Hewlett Packard ScanJet 6200C  
03F0:0202=PhotoSmart S20  
03F0:0204=DeskJet 815c  
03F0:0205=ScanJet 3300c  
03F0:0207=CD-Writer Plus 8200e  
03F0:020C=Multimedia Keyboard  
03F0:0211=OfficeJet G85  
03F0:0211:0100=HP OfficeJet G85 USB  
03F0:0212=DeskJet 1220C  
03F0:0217=LaserJet 2200  
03F0:0217:0100=HP LaserJet 2200 USB  
03F0:0218=APOLLO P2500/2600  
03F0:0225=HP USB Mass Storage Device  
03F0:022A:0100:01=HP LEDM Driver  
03F0:0304=DeskJet 810c/812c  
03F0:0305=ScanJet 4300c

03F0:0307=CD-Writer+ CD-4e  
03F0:0311=OfficeJet G85xi  
03F0:0311:0100=HP OfficeJet G85xi USB  
03F0:0312=Color Inkjet CP1700  
03F0:0314=designjet 30/130 series  
03F0:0317=LaserJet 1200  
03F0:0317:0100=HP LaserJet 1200 USB  
03F0:0324=SK-2885 keyboard  
03F0:0325=HP USB Mass Storage Device  
03F0:032A:01=P1100 USB EWS Device Driver  
03F0:0401=HP ScanJet 5200C  
03F0:0401:0100=Hewlett Packard ScanJet 5200C  
03F0:0404=DeskJet 830c/832c  
03F0:0405=ScanJet 3400cse  
03F0:0411=OfficeJet G95  
03F0:0411:0100=HP OfficeJet G95 USB  
03F0:0412=Printing Support  
03F0:0417=LaserJet 1200 series  
03F0:0417:0100=HP LaserJet 1220 USB  
03F0:0423=HS-COMBO  
03F0:0425=HP USB Mass Storage Device  
03F0:042A:01=P1130 USB EWS Device Driver  
03F0:0504=DeskJet 885c  
03F0:0505=HP ScanJet 2100C  
03F0:0507=HP DVD+RW  
03F0:050C=5219 Wireless Keyboard  
03F0:0511=OfficeJet K60  
03F0:0511:0100=HP OfficeJet K60 USB  
03F0:0512=HP DeskJet 450 series  
03F0:0517=HP LaserJet 1000  
03F0:051D=HP integrated module with Bluetooth wireless technology.  
03F0:052A:01=P1210 USB EWS Device Driver  
03F0:0601=HP ScanJet 6300C  
03F0:0601:0100=Hewlett Packard ScanJet 6300C  
03F0:0604=DeskJet 840c Scanner  
03F0:0605=HP ScanJet 2200C  
03F0:0611=OfficeJet K60xi  
03F0:0611:0100=HP OfficeJet K60xi USB  
03F0:0612=business inkjet 3000  
03F0:0624=HP USB BT Transceiver [1.2]  
03F0:0701=ScanJet 5300c/5370c  
03F0:0704=DeskJet 825c  
03F0:0705=Scanjet 6100C Series  
03F0:0705:01=Hewlett Packard ScanJet 4400C  
03F0:070C=HP Personal Media Drive  
03F0:0711=OfficeJet K80  
03F0:0711:0100=HP OfficeJet K80 USB  
03F0:0712=DeskJet 1180c  
03F0:0714=Printing Support  
03F0:072A:0100:03=HP LEDM Driver  
03F0:0801=HP ScanJet 7400C  
03F0:0804=DeskJet 816c  
03F0:0805=Hewlett Packard ScanJet 4470C  
03F0:0805:01=Hewlett Packard ScanJet 4470C  
03F0:0811=OfficeJet K80xi  
03F0:0811:0100=HP OfficeJet K80xi USB  
03F0:0817=LaserJet 3300  
03F0:0817:0100=HP LaserJet 3300  
03F0:0824=HP USB Smart Card Reader  
03F0:0901=HP Scanjet 2300c

03F0:0904=DeskJet 845c  
03F0:0912=Printing Support  
03F0:0917=LaserJet 3330  
03F0:0917:0100=HP LaserJet 3330  
03F0:0924=HP Modular USB Smartcard Keyboard  
03F0:0924:01=HP Modular USB Smartcard Keyboard  
03F0:092A:01=P1560 USB EWS Device Driver  
03F0:0A01=HP Scanjet 2400  
03F0:0A0C=USB MouseMaestro Mouse Filter Driver (Windows 2000)  
03F0:0A17=HP Color LaserJet 3700  
03F0:0A2A:01=HP PNP EWS Null  
03F0:0A2A:0100:02=HP LEDM Driver  
03F0:0B01=HP ScanJet 8200 series  
03F0:0B0C=Wireless Keyboard and Optical Mouse  
03F0:0B17=hp LaserJet 2300  
03F0:0B2A:0001:01=HP LEDM Driver  
03F0:0C17=hp LaserJet 1010  
03F0:0C24=HP Bluetooth Dongle  
03F0:0D12=Officejet 9100 series  
03F0:0D14=Designjet T610 24in  
03F0:0D17=hp LaserJet 1012  
03F0:0E17=hp LaserJet 1015  
03F0:0F0C=Wireless Keyboard and Optical Mouse receiver  
03F0:0F11=OfficeJet V40  
03F0:0F11:0100=HP OfficeJet V40 USB  
03F0:0F12=Printing Support  
03F0:0F17=hp LaserJet 1150  
03F0:1001=HP Photo Scanner  
03F0:1002=photosmart 140 series  
03F0:1004=DeskJet 970c/970cse  
03F0:1005=Scanjet 5400C Series  
03F0:1011=OfficeJet V40xi  
03F0:1011:0100=HP OfficeJet V40xi USB  
03F0:1016=HP USB Sync  
03F0:1017=HP LaserJet 1300 series  
03F0:1024=HP USB Smart Card Keyboard  
03F0:1024:01=HP USB Smart Card Keyboard  
03F0:1027=Virtual Keyboard  
03F0:1027:01=Virtual Mouse  
03F0:104D=Bluetooth Devices  
03F0:1101=HP Photo Scanner 1200  
03F0:1102=photosmart 240 series  
03F0:1104=Deskjet 959C  
03F0:1105=ScanJet 5470c  
03F0:110C=HP Pocket Media Drive  
03F0:1111=officejet v60  
03F0:1116=Jornada 568 Pocket PC  
03F0:1117=hp LaserJet 1300n  
03F0:1151=750xi Printer/Scanner/Copier  
03F0:1202=Photosmart 320 Series  
03F0:1202:01=HP Photosmart 320 Series  
03F0:1204=DeskJet 930c  
03F0:1205=HP Scanjet 4500c/5550c  
03F0:1211=officejet v60xi  
03F0:1216=HP USB Sync 1612  
03F0:1217=hp LaserJet 2300L  
03F0:1302=Photosmart 370 Series  
03F0:1302:01=HP Photosmart 370 Series  
03F0:1305=HP Scanjet 4570c/5500c  
03F0:1311=OfficeJet V30

03F0:1311:0100=HP OfficeJet V30 USB  
03F0:1312=Deskjet 460  
03F0:1317=LaserJet 1005  
03F0:1405=HP Scanjet 3600 Series  
03F0:1411=PSC 750  
03F0:1411:0100=HP PSC 750 USB  
03F0:1424=f2105 Monitor USB Hub  
03F0:1502=HP Photosmart 420 Series  
03F0:1502:02=HP Photosmart 420 Series  
03F0:1504=Deskjet 920c  
03F0:150C=Mood Lighting (Microchip Technology Inc.)  
03F0:1511=PSC 750xi  
03F0:1511:0100=HP PSC 750xi USB  
03F0:1512=USB Printing Support  
03F0:1517=hp color LaserJet 3500  
03F0:1524=HP USB Smart Card Keyboard - KR  
03F0:1524:01=HP USB Smart Card Keyboard - KR  
03F0:1602=Photosmart 330 Series  
03F0:1602:01=HP Photosmart 330 Series  
03F0:1604=DeskJet 940c  
03F0:1605=HP ScanJet 5530  
03F0:1611=psc 780  
03F0:1617=hp LaserJet 3015  
03F0:1617:0100=HP LaserJet 3015  
03F0:161D=Wireless Rechargeable Optical Mouse (HID)  
03F0:1624=HP USB Smart Card Keyboard - JP  
03F0:1624:01=HP USB Smart Card Keyboard - JP  
03F0:1702=Photosmart 380 Series  
03F0:1702:01=HP Photosmart 380 Series  
03F0:1704=deskjet 948C  
03F0:1705=ScanJet 5590  
03F0:1711=psc 780xi  
03F0:1712=Printing Support  
03F0:1717=hp LaserJet 3020  
03F0:1717:0100=HP LaserJet 3020  
03F0:171D=HP Integrated Module with Bluetooth 2.0 Wireless Technology  
03F0:1801=Inkjet P-2000U  
03F0:1802=Photosmart 470 Series  
03F0:1802:01=HP Photosmart 470 Series  
03F0:1804=deskjet 916C  
03F0:1805=HP Scanjet 7600 series  
03F0:1811=PSC 720  
03F0:1811:0100=HP PSC 720 USB  
03F0:1812=USB Printing Support  
03F0:1817=hp LaserJet 3030  
03F0:1817:0100=HP LaserJet 3030  
03F0:181D=HP integrated module with Bluetooth 2.0 wireless technology.  
03F0:1902=HP Photosmart A430 Series  
03F0:1902:02=HP Photosmart A430 Series  
03F0:1904=DeskJet 3820  
03F0:1911=OfficeJet V45  
03F0:1911:0100=HP OfficeJet V45 USB  
03F0:1917=hp LaserJet 3380  
03F0:1917:0100=HP LaserJet 3380  
03F0:1A02=Photosmart A510 series  
03F0:1A02:01=HP Photosmart A510 Series  
03F0:1A11=officejet 5100 series  
03F0:1A11:0100=hp officejet 5100 series  
03F0:1A17=HP Color LaserJet 4650  
03F0:1B02=Photosmart A610 series

03F0:1B02:01=HP Photosmart A610 Series  
03F0:1B04=deskjet 3810  
03F0:1B05=ScanJet 4850C/4890C  
03F0:1B07=Premium Starter Webcam  
03F0:1C02=Photosmart A710 series  
03F0:1C02:01=HP Photosmart A710 Series  
03F0:1C17=hp color LaserJet 2550 series  
03F0:1D02=Photosmart A310 series  
03F0:1D02:01=HP Photosmart A310 Series  
03F0:1D17=hp LaserJet 1320 series  
03F0:1E02=HP Photosmart A320 Printer series  
03F0:1E02:01=HP Photosmart A320 Series  
03F0:1E04:01=HP Deskjet D2500 Series  
03F0:1E11=PSC-950  
03F0:1E11:0100=HP PSC 950 USB  
03F0:1E17=hp LaserJet 1160 series  
03F0:1F02=HP Photosmart A440 Printer series  
03F0:1F02:02=HP Photosmart A440 Series  
03F0:1F11=PSC 920  
03F0:1F11:0100=HP PSC 920 USB  
03F0:1F12=HP Officejet Pro K5300  
03F0:1F12:01=HP Officejet Pro K5300 Series  
03F0:1F17=HP Color LaserJet 5550 series  
03F0:1F1D=un2400 Gobi Wireless Modem  
03F0:2001=HP USB Floppy  
03F0:2002=USB Hub  
03F0:2002:0100=HP Photosmart 7345 series (Dot4USB)  
03F0:2004=DeskJet 640c  
03F0:2005=HP Scanjet 3500c Series  
03F0:2012=Officejet Pro K5400  
03F0:2012:01=HP Officejet Pro K5400 Series  
03F0:2016=HP USB Sync 1620  
03F0:201D=un2400 Gobi Wireless Modem (QDL mode)  
03F0:2102=photosmart 7345  
03F0:2104=DeskJet 630c  
03F0:2112=Officejet Pro L7500  
03F0:2112:02=Officejet Pro L7500  
03F0:2116=HP USB Sync 1621  
03F0:211D=Sierra MC5725 [ev2210]  
03F0:2202=photosmart 7600 series  
03F0:2205=HP Scanjet 3500c Series  
03F0:2212=Officejet Pro L7600  
03F0:2212:02=Officejet Pro L7600  
03F0:2216=HP USB Sync 1622  
03F0:2217=HP Color LaserJet 9500 MFP  
03F0:2302=photosmart 7600 series  
03F0:2304=DeskJet 656c  
03F0:2305=HP ScanJet 3970  
03F0:2311=officejet d series  
03F0:2311:0100=hp officejet d series  
03F0:2312=Officejet Pro L7700  
03F0:2312:02=Officejet Pro L7700  
03F0:2317=HP LaserJet 4350  
03F0:231D=HP Integrated Module with Bluetooth 2.1 Wireless Technology  
03F0:2402=photosmart 7700 series  
03F0:2404=HP Deskjet F2200  
03F0:2404:02=HP DeskJet F2200  
03F0:2405=ScanJet 4070 Photosmart  
03F0:2417=HP LaserJet 4250  
03F0:241D=Gobi 2000 Wireless Modem (QDL mode)

03F0:2424=LP1965 19" Monitor USB Hub  
03F0:2502=photosmart 7700 series  
03F0:2504=HP Deskjet F4200 series  
03F0:2504:02=HP DeskJet F4200  
03F0:2505=HP Scanjet 3770  
03F0:2512=HP Officejet Pro L7300  
03F0:2512:02=Officejet Pro L7300  
03F0:2517=HP LaserJet 2410  
03F0:251D=Gobi 2000 Wireless Modem  
03F0:2524=LP3065 30" Monitor USB Hub  
03F0:2602=Photosmart A520 series  
03F0:2602:01=HP Photosmart A520 series  
03F0:2605=HP Scanjet 3800  
03F0:2611=officejet 7100 series  
03F0:2611:0100=hp officejet 7100 series  
03F0:2612:01=HP Officejet K7100 Series  
03F0:2617=HP Color LaserJet 2820 Series  
03F0:2617:0100=HP Color LaserJet 2820  
03F0:2624=Pole Display (HP522 2 x 20 Line Display)  
03F0:2702=HP Photosmart A620 series  
03F0:2702:01=HP Photosmart A620 Series  
03F0:2704=HP 915  
03F0:2704:02=HP 915  
03F0:2712:01=HP Officejet Pro K8600 Series  
03F0:2717=HP Color LaserJet 2830 Series  
03F0:2717:0100=HP Color LaserJet 2830 Series  
03F0:2804=HP Deskjet D730  
03F0:2804:01=HP Deskjet D730 Series  
03F0:2811=hp psc 2100 series  
03F0:2811:02=HP PSC 2100 Series  
03F0:2812:01=HP Officejet H470 Series  
03F0:2817=HP Color LaserJet 2840 Series  
03F0:2817:0100=HP Color LaserJet 2840  
03F0:281D=HP Integrated Module with Bluetooth 2.1 Wireless Technology  
03F0:2902=HP Photosmart A820 series  
03F0:2902:01=HP Photosmart A820 Series  
03F0:2904=HP Deskjet F735  
03F0:2904:02=HP Deskjet F735  
03F0:2905=HP Scanjet 7800  
03F0:2911=hp psc 2200 series  
03F0:2911:02=HP PSC 2200 Series  
03F0:2917=HP LaserJet 2420  
03F0:2A11=hp psc 2150 series  
03F0:2A11:02=HP PSC 2150 Series  
03F0:2A12=HP Officejet J4500  
03F0:2A12:02=HP Officejet J4500  
03F0:2A17=HP LaserJet 2430  
03F0:2A1D=HP Integrated module with Bluetooth 2.1 wireless technology  
03F0:2B11=hp psc 2170 series  
03F0:2B11:02=HP PSC 2170 Series  
03F0:2B12=HP Officejet J4660  
03F0:2B12:02=HP Officejet J4660  
03F0:2B17=LaserJet 1020  
03F0:2C12=HP Officejet J4680  
03F0:2C12:02=HP Officejet J4680  
03F0:2C17=Printing Support  
03F0:2C24=Logitech M-UAL-96 Mouse  
03F0:2D11=HP Officejet 6100 series  
03F0:2D11:02=HP Officejet 6100 Series  
03F0:2D17=Printing Support



03F0:2E11=hp psc 1000 series  
03F0:2E12=Officejet 4500 G510n-z  
03F0:2E17=Printing Support  
03F0:2E24=LP2275w Monitor USB Hub  
03F0:2F11=hp psc 1200 series  
03F0:2F11:02=HP PSC 1200 Series  
03F0:2F17=EWS 2605dn  
03F0:2F17:0100:01=HP EWS UPD  
03F0:2F24=LP2475w Monitor Hub  
03F0:3002=photosmart P1000  
03F0:3004=deskjet 980c  
03F0:3005=HP ScanJet 4600 series  
03F0:3011=hp psc 1100 series  
03F0:3011:02=HP PSC 1100 Series  
03F0:3012=HP Officejet J5500  
03F0:3012:02=HP Officejet J5500  
03F0:3016=HP USB Sync 1630  
03F0:3017=Printing Support  
03F0:3102=photosmart P1100  
03F0:3104=DeskJet 960c  
03F0:3111=hp officejet 4100 series  
03F0:3111:02=HP Officejet 4100 Series  
03F0:3112=HP Officejet J3600  
03F0:3112:02=HP Officejet J3600  
03F0:3116=HP USB Sync 1631  
03F0:3117=EWS 2605dtn  
03F0:3117:0100:01=HP EWS UPD  
03F0:311D=Atheros AR9285 Malbec Bluetooth Adapter  
03F0:3202=photosmart 1215  
03F0:3207=4 GB flash drive  
03F0:3211=hp officejet 4105 series  
03F0:3211:02=HP Officejet 4105 Series  
03F0:3212=HP Officejet J3500  
03F0:3212:02=HP Officejet J3500  
03F0:3216=HP USB Sync 1632  
03F0:3217=HP LaserJet 3050  
03F0:3217:01=HP LaserJet 3050 EWS  
03F0:3302=photosmart 1218  
03F0:3304=DeskJet 990c  
03F0:3312=HP Officejet J6400  
03F0:3312:02=HP Officejet J6400  
03F0:3317=HP LaserJet 3052  
03F0:3317:01=HP LaserJet 3052 EWS  
03F0:3402=photosmart 1115  
03F0:3404=DeskJet 6122  
03F0:3412=Officejet Pro L7400  
03F0:3417=HP LaserJet 3055  
03F0:3502=photosmart 230  
03F0:3502:0100=HP Photosmart 230 series (Dot4USB)  
03F0:3504=DeskJet 6127c  
03F0:3511=hp psc 2300 series  
03F0:3511:02=HP PSC 2300 Series  
03F0:3517=HP LaserJet 3390  
03F0:3517:01=HP LaserJet 3392 EWS  
03F0:3602=photosmart 1315  
03F0:3611=hp psc 2400 series  
03F0:3611:02=HP PSC 2400 Series  
03F0:3612=Officejet Pro 8000 A809 Series  
03F0:3617=EWS 2605  
03F0:3617:0100:01=HP EWS UPD

03F0:3711=hp psc 2500 series  
03F0:3711:02=HP PSC 2500 Series  
03F0:3717=EWS UPD  
03F0:3717:0100:01=HP Color LaserJet CLJ2700 Series EWS  
03F0:3724=Webcam  
03F0:3802=photosmart 100  
03F0:3805=HP ScanJet 8300C  
03F0:3812=Officejet Pro 8500 A909a  
03F0:3817=LaserJet P2015 Series  
03F0:3817:0100:01=HP LaserJet P2015 Series EWS  
03F0:3902=photosmart 130  
03F0:3902:0100=HP Photosmart 130 series (Dot4USB)  
03F0:3905=HP ScanJet 8200C  
03F0:3912=Officejet Pro 8500 A909g  
03F0:3A02=photosmart 7150  
03F0:3A02:0100=HP Photosmart 7150 series (Dot4USB)  
03F0:3A11=hp officejet 5500 series  
03F0:3A11:02=HP Officejet 5500 Series  
03F0:3A17=Printing Support  
03F0:3B02=photosmart 7150~  
03F0:3B11=hp psc 1300 series  
03F0:3B11:02=HP PSC 1300 Series  
03F0:3B17=LaserJet M1005 MFP  
03F0:3C02=PhotoSmart 7350  
03F0:3C02:0100=HP Photosmart 7350 series (Dot4USB)  
03F0:3C11=hp psc 1358 series  
03F0:3C17=EWS UPD  
03F0:3C17:0100:01=HP Color LaserJet CLJ2700 Series EWS  
03F0:3D02=photosmart 7350~  
03F0:3D11=hp officejet 4200 series  
03F0:3D11:02=HP Officejet 4200 Series  
03F0:3D17=LaserJet P1005  
03F0:3E02=photosmart 7550  
03F0:3E02:0100=HP Photosmart 7550 series (Dot4USB)  
03F0:3E17=LaserJet P1006  
03F0:3F02=photosmart 7550~  
03F0:3F11=PSC-1315/PSC-1317  
03F0:3F11:02=HP PSC 1310 Series  
03F0:4002=Hewlett Packard Digital Camera  
03F0:4004=cp1160  
03F0:4012=Officejet Pro 8500 A909n  
03F0:4016=HP USB Sync 1640  
03F0:4102=HP 618/912 Digital Camera  
03F0:4102:0100=HP Digital Camera  
03F0:4102:0101=HP PhotoSmart C618 Camera  
03F0:4105=ScanJet 4370  
03F0:4111=HP Officejet 7200 series  
03F0:4111:02=HP Officejet 7200 Series  
03F0:4116=HP USB Sync 1641  
03F0:4117=Printing Support  
03F0:4202=HP 812 Digital Camera  
03F0:4205=Scanjet G3010  
03F0:4211=HP Officejet 7300 series  
03F0:4211:02=HP Officejet 7300 Series  
03F0:4212=Officejet 6000 E609a Series  
03F0:4216=HP USB Sync 1642  
03F0:4217=EWS CM1015  
03F0:4302=HP PhotoSmart 850  
03F0:4305=ScanJet G3110  
03F0:4311=HP Officejet 7400 series

03F0:4311:02=HP Officejet 7400 Series  
03F0:4312=Officejet 6000 E609n Series  
03F0:4317=Color LaserJet CM1017  
03F0:4402=HP PhotoSmart 935  
03F0:4412=Officejet 6500 E709a  
03F0:4417=EWS UPD  
03F0:4417:0100:01=HP EWS CP1510 Series  
03F0:4502=HP PhotoSmart 945  
03F0:4505=ScanJet G4010  
03F0:4511=HP Photosmart 2600 series  
03F0:4511:02=HP Photosmart 2600 Series  
03F0:4512=Officejet 6500 E709n  
03F0:4517=EWS UPD  
03F0:4517:0100:02=HP EWS M1522n  
03F0:4517:0100:03=HP LaserJet M1522n MFP Fax  
03F0:4605=ScanJet G4050  
03F0:4611=HP Photosmart 2700 series  
03F0:4611:02=HP Photosmart 2700 Series  
03F0:4717=Color LaserJet CP1215  
03F0:4811=HP PSC 1600 series  
03F0:4811:02=HP PSC 1600 Series  
03F0:4911=HP PSC 2350 series  
03F0:4911:02=HP PSC 2350 Series  
03F0:4B11=HP Officejet 6200 series  
03F0:4B11:02=HP Officejet 6200 Series  
03F0:4C11=HP PSC 1500 series  
03F0:4C11:02=HP PSC 1500 Series  
03F0:4C17=EWS UPD  
03F0:4C17:0100:02=HP EWS M1522nf  
03F0:4C17:0100:03=HP LaserJet M1522nf MFP Fax  
03F0:4D11=PSC 1400  
03F0:4D11:02=HP PSC 1400 Series  
03F0:4D17=EWS UPD  
03F0:4D17:0100:02=HP EWS UPD  
03F0:4E11=HP Photosmart 2570 series  
03F0:4E11:02=HP Photosmart 2570 Series  
03F0:4E17:0100:02=HP EWS UPD  
03F0:4F11=HP Officejet 5600 series  
03F0:4F11:02=HP Officejet 5600 Series  
03F0:4F17=Color LaserJet CM1312 MFP  
03F0:4F17:0100:02=HP EWS UPD  
03F0:5004=DeskJet 995C  
03F0:5011=HP Photosmart 3100 series  
03F0:5011:02=HP Photosmart 3100 Series  
03F0:5016=HP USB Sync 1650  
03F0:5017=EWS UPD  
03F0:5017:0100:01=HP EWS CP1510 Series  
03F0:5111=HP Photosmart 3200 series  
03F0:5111:01=HP Photosmart 3200 Printer  
03F0:5111:02=HP Photosmart 3200 Series  
03F0:5111:03=HP Photosmart 3200 Disks  
03F0:5116=HP USB Sync 1651  
03F0:5117:01=HP PNP EWS Null  
03F0:5117:0100:02=HP LEDM Driver  
03F0:5211=HP Photosmart 3300 series  
03F0:5211:02=HP Photosmart 3300 Series  
03F0:5216=HP USB Sync 1652  
03F0:5217:0100:01=HP Color LaserJet CP2020 Series EWS  
03F0:5311=HP Officejet 6300  
03F0:5312=Officejet Pro 8500A

03F0:5317:0100:01=HP Color LaserJet CP2020 Series EWS  
03F0:5411=HP Officejet 4300  
03F0:5411:02=HP Officejet 4300 Series  
03F0:5417:0100:01=HP Color LaserJet CP2020 Series EWS  
03F0:5511=HP Deskjet F300  
03F0:5511:02=HP Deskjet F300 Series  
03F0:5611=HP Photosmart C3100  
03F0:5611:02=HP Photosmart C3100  
03F0:5617=LaserJet M1120 MFP  
03F0:5711=HP Photosmart C4100  
03F0:5711:02=HP Photosmart C4100  
03F0:5717=LaserJet M1120n MFP  
03F0:5811=HP Photosmart C5100  
03F0:5811:02=HP Photosmart C5100  
03F0:5817=LaserJet M1319f MFP  
03F0:5911=HP Photosmart C6100  
03F0:5911:02=HP Photosmart C6100  
03F0:5917:0100:02=HP EWS UPD  
03F0:5A11=HP Photosmart C7100  
03F0:5A11:02=HP Photosmart C7100  
03F0:5A17:0100:02=HP EWS UPD  
03F0:5B11=Officejet J5700  
03F0:5B11:02=Officejet J5700  
03F0:5B17:0100:02=HP EWS UPD  
03F0:5C11=HP Photosmart C4200 Printer series  
03F0:5C11:02=HP Photosmart C4200  
03F0:5C17:0001:01=HP Color LaserJet P2050 Series EWS  
03F0:5C17:0100:01=HP EWS UPD  
03F0:5D11=HP Photosmart C5200 series  
03F0:5D11:02=HP Photosmart C5200  
03F0:5D17:0001:01=HP EWS UPD  
03F0:5D17:0100:01=HP EWS UPD  
03F0:5E11=HP Photosmart D7400 series  
03F0:5E11:01=HP Photosmart D7400 Series  
03F0:6004=DeskJet 5550  
03F0:6102=Hewlett Packard Digital Camera  
03F0:6104=DeskJet 5650c  
03F0:6117=color LaserJet 3550  
03F0:6202=HP 215 Digital Camera  
03F0:6204=DeskJet 5150c  
03F0:6217=Color LaserJet 4700  
03F0:6302=HP 318/612 Digital Camera  
03F0:6317=Color LaserJet 4730mfp  
03F0:6402=HP 715 Digital Camera  
03F0:6411=HP Photosmart C8100 series  
03F0:6411:02=HP Photosmart C8100  
03F0:6417=HP LaserJet 5200  
03F0:6502=HP 120 Series Digital Camera  
03F0:6511=HP Photosmart C7200 series  
03F0:6511:02=HP Photosmart C7200  
03F0:6602=HP PhotoSmart 320  
03F0:6611=HP Photosmart C4380 series  
03F0:6611:02=HP Photosmart C4380  
03F0:6617=HP LaserJet 5200L  
03F0:6702=HP PhotoSmart 720  
03F0:6711:02=HP Photosmart C4340  
03F0:6717=Color LaserJet 3000  
03F0:6802=HP PhotoSmart 620  
03F0:6811=Photosmart D5300 series  
03F0:6811:01=HP Photosmart D5300 series

03F0:6817=Color LaserJet 3800  
03F0:6911=Photosmart D7200 series  
03F0:6911:01=HP Photosmart D7200 series  
03F0:6917=Color LaserJet 3600  
03F0:6A02=HP PhotoSmart 735  
03F0:6A11=Photosmart C6200 series  
03F0:6A11:02=HP Photosmart C6200 series  
03F0:6A17=LaserJet 4240  
03F0:6B02=hp photosmart R707  
03F0:6B11=HP Photosmart C4500 series  
03F0:6B11:02=HP Photosmart C4500  
03F0:6C02=HP PhotoSmart 733  
03F0:6C11:02=HP Photosmart C4400  
03F0:6C17=Color LaserJet 4610  
03F0:6D02=HP Photosmart R607  
03F0:6D11=HP Photosmart D5400 series  
03F0:6D11:01=HP Deskjet D5400 Series  
03F0:6E02=HP Photosmart R507  
03F0:6F11=HP Photosmart D7500 series  
03F0:6F11:01=HP Photosmart D7500 Series  
03F0:6F17=HP Color LaserJet CP6005  
03F0:7004=DeskJet 3320  
03F0:7011=HP Photosmart C6300 series  
03F0:7011:02=HP Photosmart C6300  
03F0:7017=HP Color LaserJet CP9505  
03F0:7102=HP PhotoSmart 635  
03F0:7104=DeskJet 3420c  
03F0:7111=HP Photosmart C5300 series  
03F0:7111:02=HP Photosmart C5300  
03F0:7117=CM8060 Color MFP with Edgeline Technology  
03F0:7202=HP PhotoSmart 430 series  
03F0:7204=DeskJet 36xx  
03F0:7211=HP Photosmart C5500 series  
03F0:7211:02=HP Photosmart C5500  
03F0:7217=LaserJet M5035 MFP  
03F0:7302=HP Photosmart M305/M307  
03F0:7304=DeskJet 35xx  
03F0:7311=HP Photosmart C309a series  
03F0:7317=LaserJet P3005  
03F0:7402=HP Photosmart M407  
03F0:7404=Printing Support  
03F0:7411=HP Photosmart C4600 series  
03F0:7411:02=HP Photosmart C4600  
03F0:7417=LaserJet M4345 MFP  
03F0:7502=HP Photosmart M22  
03F0:7504=Printing Support  
03F0:7517=HP LaserJet M3035 MFP  
03F0:7602=HP Photosmart R717  
03F0:7604=USB Printing Support  
03F0:7611=DeskJet F2492 All-in-One  
03F0:7611:02=HP Deskjet F2400 series  
03F0:7617=LaserJet P3004  
03F0:7702=HP Photosmart R817  
03F0:7704=Deskjet D4100  
03F0:7711=HP Deskjet F4400 series  
03F0:7711:02=HP DeskJet F4400  
03F0:7717=CM8050 Color MFP with Edgeline Technology  
03F0:7802=HP Photosmart M417  
03F0:7804=Deskjet D1360  
03F0:7811:02=HP Deskjet Ink Advant K209a-z

03F0:7817=Color LaserJet CP3505  
03F0:7902=HP Photosmart M517  
03F0:7911=HP Photosmart C309b series  
03F0:7917=LaserJet M5025 MFP  
03F0:7A02=HP Photosmart M415  
03F0:7A04=DeskJet D2460  
03F0:7A17=HP LaserJet M3027 MFP  
03F0:7B02=HP Photosmart M23  
03F0:7B17=Color LaserJet CP4005  
03F0:7C02=HP Photosmart E217  
03F0:7C17=Color LaserJet CM6040 Series  
03F0:7D02=HP Photosmart E317  
03F0:7D04=HP Deskjet F2100 Printer series  
03F0:7D04:02=HP Deskjet F2100  
03F0:7D17=Color LaserJet CM4730 MFP  
03F0:7E02=HP Photosmart R818  
03F0:7E04=HP Deskjet F4100 Printer series  
03F0:7E04:02=HP Deskjet F4100  
03F0:7F11=HP Deskjet D1600 series  
03F0:8002=HP Photosmart M425  
03F0:8011=HP Deskjet D2600 series  
03F0:8011:01=HP Deskjet D2600 Series  
03F0:8017=LaserJet P4515  
03F0:8102=HP Photosmart M525  
03F0:8104=Printing Support  
03F0:8117=LaserJet P4015  
03F0:811C=Ethernet HN210E  
03F0:8202=HP Photosmart M527  
03F0:8204=Printing Support  
03F0:8207=FHA-3510 2.4GHz Wireless Optical Mobile Mouse  
03F0:8211:01=HP Deskjet D5500 series  
03F0:8217=LaserJet P4014  
03F0:8302=HP Photosmart M627  
03F0:8317=LaserJet M9050 MFP  
03F0:8402=HP Photosmart R725  
03F0:8404=HP Deskjet 6800 Series  
03F0:8404:01=HP Deskjet 6800 Series  
03F0:8417=LaserJet M9040 MFP  
03F0:8502=HP Photosmart R727  
03F0:8504=HP Deskjet 6600 Series  
03F0:8504:01=HP Deskjet 6600 Series  
03F0:8517=HP Color LaserJet CP3525  
03F0:8602=HP Photosmart R827  
03F0:8604=HP Deskjet 5400 Series  
03F0:8604:01=HP Deskjet 5400 Series  
03F0:8702=HP Photosmart R927  
03F0:8704=HP Deskjet 5900 Series  
03F0:8704:01=HP Deskjet 5900 Series  
03F0:8717=HP Color LaserJet CP4520 Series  
03F0:8802=HP Photosmart R960 Series  
03F0:8804=HP Deskjet 6980 Series  
03F0:8804:01=HP Deskjet 6980 Series  
03F0:8817=HP Color LaserJet CP4020 Series  
03F0:8904=HP Deskjet 6940 Series  
03F0:8904:01=HP Deskjet 6940 Series  
03F0:8A17=HP Color LaserJet CM3530 MFP  
03F0:8B02=HP Photosmart E327  
03F0:8C02=HP Photosmart E427  
03F0:8C07=Digital Stereo Headset  
03F0:8C11=HP Deskjet F4500 series

03F0:8C17=HP Color LaserJet CM6030 MFP  
03F0:8D17:0100=HP LaserJet P3010 Series  
03F0:9002=HP Photosmart M437  
03F0:9102=HP Photosmart M537  
03F0:9302=Photosmart R930 series  
03F0:9402=HP Photosmart R837  
03F0:9502=Photosmart R840 series  
03F0:9517:0100=HP Color LaserJet CM6049f MFP  
03F0:9602=Photosmart M730 series  
03F0:9617:0100=HP LaserJet M9059 MFP  
03F0:9702=Photosmart R740 series  
03F0:9717:0100=HP LaserJet M4349x MFP  
03F0:9802=Photosmart Mz60 series  
03F0:9902=Photosmart M630 series  
03F0:9A02=Photosmart E330 series  
03F0:9B02=Photosmart M540 series  
03F0:9C02=Photosmart M440 series  
03F0:A004=DeskJet 5850c  
03F0:A011=Deskjet 3050A  
03F0:B002=photosmart 7200 series  
03F0:B002:01=HP Photosmart 7200 Series  
03F0:B102=photosmart 7200 series  
03F0:B102:01=HP Photosmart 7200 Series  
03F0:B116=Webcam  
03F0:B202=photosmart 7600 series  
03F0:B302=photosmart 7600 series  
03F0:B402=photosmart 7700 series  
03F0:B502=photosmart 7700 series  
03F0:B602=photosmart 7900 series  
03F0:B702=photosmart 7900 series  
03F0:B802=Photosmart 7400 Series  
03F0:B802:01=HP Photosmart 7400 Series  
03F0:B902=Photosmart 7800 Series  
03F0:BA02=Photosmart 8100 Series  
03F0:BA02:01=HP Photosmart 8100 Series  
03F0:BB02=Photosmart 8400 Series  
03F0:BB02:01=HP Photosmart 8400 Series  
03F0:BC02=Photosmart 8700 Series  
03F0:BC02:01=HP Photosmart 8700 Series  
03F0:BD02=Photosmart Pro B9100 series  
03F0:BEF4=NEC Picty760  
03F0:C002=Photosmart 7800 Series  
03F0:C002:01=HP Photosmart 7800 Series  
03F0:C102=Photosmart 8000 Series  
03F0:C102:01=HP Photosmart 8000 Series  
03F0:C202=Photosmart 8200 Series  
03F0:C202:01=HP Photosmart 8200 Series  
03F0:C302=Deskjet D2300  
03F0:C402=Photosmart D5100 series  
03F0:C402:01=HP Photosmart D5100 Series  
03F0:C502=Photosmart D6100 series  
03F0:C502:01=HP Photosmart D6100 Series  
03F0:C602=Photosmart D7100 series  
03F0:C602:01=HP Photosmart D7100 Series  
03F0:C702=Photosmart D7300 series  
03F0:C702:01=HP Photosmart D7300 Series  
03F0:C802=HP Photosmart D5060 Printer  
03F0:C802:01=HP Photosmart D5060 Series  
03F0:CD02=Wireless Printer Adapter  
03F0:D102=HP Photosmart B8500 series

03F0:D102:01=HP Photosmart B8500 Series  
03F0:D104=HP Bluetooth Wireless Print and PC Adapter  
03F0:D404=HP Bluetooth Wireless Print and PC Adapter  
03F0:D604=Broadcom Bluetooth 2.1 + EDR USB Device  
03F0:EFBE=NEC Picty900  
03F0:F0BE=NEC Picty920  
03F0:F1BE=NEC Picty800  
03F1=Genoa Technology  
03F2=Oak Technology  
03F3=Adaptec  
03F3:0001=Çë°²×°³ŞÉİİá¹@µÄÇÝ¶¯³İĐò  
03F3:0020=AWN-8020 WLAN  
03F3:0080=AVC-1100 Audio Capture  
03F3:0083=AVC-2200 Device  
03F3:0087=AVC-2210 Loader  
03F3:0088=AVC-2210 Device  
03F3:008B=AVC-2310 Loader  
03F3:008C=AVC-2310 Device  
03F3:0094=eHome Infrared Receiver (USBCIR)  
03F3:009B=AVC-1410 GameBridge TV NTSC  
03F3:2000=Adaptec USBXchange Firmware Loader  
03F3:2001=Adaptec USBXchange Adapter  
03F3:2002=USB2-Xchange  
03F3:2003=USB2-Xchange Adapter  
03F3:ADCC=Adaptec USB Composite Device Support  
03F4=Diebold  
03F5=Siemens Electromechanical  
03F8=Epson Research Center  
03F9=KeyTronic  
03F9:0100=Key Tronic USB Keyboard  
03F9:0101=Key Tronic USB Keyboard  
03F9:0102=Key Tronic USB Keyboard Mouse  
03F9:0102:01=Key Tronic USB Keyboard Mouse  
03FB=OPTi  
03FC=Elitegroup Computer Systems  
03FD=Xilinx  
03FD:0003=Xilinx Platform Cable USB Firmware Loader  
03FD:0004=Xilinx Platform Cable USB  
03FD:0007=Xilinx Platform Cable USB Firmware Loader  
03FD:0008=Xilinx Platform Cable USB  
03FD:0009=Xilinx Embedded Platform USB Firmware Loader  
03FD:000B=Xilinx USB Xpress Platform Cable Firmware Loader  
03FD:000D=Xilinx Embedded Platform USB Firmware Loader  
03FD:000F=Xilinx Platform Cable USB Firmware Loader  
03FD:0098=Xilinx MultiLINUX Cable  
03FE=Farallon  
0400=National Semiconductor  
0400:05DC=Rigol Technologies DS1000USB Oscilloscope  
0400:0807=National Semiconductor Bluetooth Board  
0400:080A=Bluetooth Device  
0400:09C4=Rigol Technologies DG1022 Arbitrary Waveform Generator  
0400:1000=Mustek BearPaw 1200 Scanner  
0400:1001=Mustek BearPaw 2400 Scanner  
0400:1237=National Semiconductor USB Hub  
0400:A000=National Smart Display Reference Device  
0400:C359=Logitech Harmony (Boot loader mode)  
0400:C35B=Printing Support  
0400:C55D=Rigol Technologies DS5000USB Oscilloscope  
0401=National Registry  
0402=Acer Labs



0402:5462=M5462 IDE Controller  
0402:5602=Acer OrbiCam  
0402:5603=USB 2.0 Q-tec Webcam 300  
0402:5606=Acer Crystal Eye webcam  
0402:5608=Lenovo EasyCamera  
0402:5621=USB Mass Storage Device  
0402:5623=VistaScan Astra 3600(ENG)  
0402:5627=Welland ME-740PS USB2 3.5" Power Saving Enclosure  
0402:5632=USB Virtual Network Adapter  
0402:5634=USB Mass Storage Device  
0402:5635=USB Mass Storage Device  
0402:5636=USB 2.0 Storage Device  
0402:5637=USB Mass Storage Device  
0402:5642=Emprex MicroStorage  
0402:5642:0100=Emprex MicroStorage  
0402:5661=M5661 MP3 player  
0402:5667=Music player  
0402:9665=Gateway Webcam  
0403=Future Technology Devices  
0403:0000=H4SMK USB 7-Port Hub  
0403:0232=USB Serial Converter  
0403:1060=JTAG adapter  
0403:6001=8-bit FIFO  
0403:6007=USB Serial Converter  
0403:6008=USB Serial Converter  
0403:6009=USB Serial Converter  
0403:6010=USB High Speed Serial Converter  
0403:6010:01=USB High Speed Serial Converter  
0403:6011=USB Serial Converter A  
0403:6011:01=USB Serial Converter B  
0403:6011:02=USB Serial Converter C  
0403:6011:03=USB Serial Converter D  
0403:6014=FT232H Single HS USB-UART/FIFO IC  
0403:8040=USB 4-Port Hub  
0403:8070=USB 7-Port Hub  
0403:8370=USB 7-Port Hub  
0403:8371=PS/2 Keyboard And Mouse  
0403:8372=FT8U100AX Serial Port  
0403:BCD8=Stellaris Development Board  
0403:BCD9=Stellaris Evaluation Board  
0403:C630=lcd2usb interface  
0403:C631=i2c-tiny-usb interface  
0403:C632=xul541 c64 floppy drive interface  
0403:C633=TinyCrypt dongle  
0403:C634=glcd2usb interface  
0403:C7D0=RR-CirKits LocoBuffer-USB  
0403:C8B8=Alpermann+Velte MTD TCU  
0403:C8B9=Alpermann+Velte MTD TCU 1HE  
0403:C8BA=Alpermann+Velte Rubidium H1  
0403:C8BB=Alpermann+Velte Rubidium H3  
0403:C8BC=Alpermann+Velte Rubidium S1  
0403:C8BD=Alpermann+Velte Rubidium T1  
0403:C8BE=Alpermann+Velte Rubidium D1  
0403:CC48=product FTDI TACTRIX\_OPENPORT\_13M 0xcc48 OpenPort 1.3 Mitsubishi  
0403:CC49=product FTDI TACTRIX\_OPENPORT\_13S 0xcc49 OpenPort 1.3 Subaru  
0403:CC4A=product FTDI TACTRIX\_OPENPORT\_13U 0xcc4a OpenPort 1.3 Universal  
0403:D010=SCS PTC-IIusb  
0403:D011=SCS Position-Tracker/TNC  
0403:D012=SCS DRAGON 1  
0403:D013=SCS DRAGON 1

0403:D388=Xsens USB converter (1/2)  
0403:D388:01=Xsens USB converter (2/2)  
0403:D38B=Xsens USB-serial converter  
0403:D38C=Xsens Wireless Receiver  
0403:D6F8=UNI Black BOX  
0403:D9A9=Actisense USG-1 NMEA Serial Gateway  
0403:D9AA=Actisense NGT-1 NMEA2000 PC Interface  
0403:DB30=Cyan USB Debug Interface Channel A  
0403:DB30:01=Cyan USB Debug Interface Channel B  
0403:E0D0=Total Phase Aardvark I2C/SPI analyzer  
0403:E0E8=ELV FHZ 1300 PC  
0403:E0E9=ELV WS 500  
0403:E0EB=ELV USB Master-Slave Schaltsteckdose UMS 100  
0403:E0EC=ELV TFD 128  
0403:E0ED=ELV Messwertuebertragung FM3 RX  
0403:E0EE=Conrad WS 777  
0403:E0EF=ELV EM 1010 PC  
0403:E0F0=ELV CSI 8  
0403:E0F1=ELV EM 1000 DL  
0403:E0F2=ELV PCK 100  
0403:E0F3=ELV RFP 500  
0403:E0F4=ELV Signalgeber  
0403:E0F5=ELV UTP 8  
0403:E0F6=ELV WS 300 PC  
0403:E0F7=Conrad WS 444 PC  
0403:E521=EVER Sinline XL Series UPS  
0403:E6C8=PYRAMID Computer GmbH LCD  
0403:E700=Elster Unicom III Optical Probe  
0403:E888=Expert ISDN Control USB  
0403:E889=USB-RS232 OptoBridge  
0403:E88A=Expert mouseCLOCK USB II  
0403:E88B=Precision Clock MSF USB  
0403:E88C=Expert mouseCLOCK USB II HBG  
0403:EA90=Eclo 1-Wire Adapter  
0403:ED71=HAMEG HO870 Serial Port  
0403:ED72=Hameg HM1508-2 Oscilloscope  
0403:ED73=HAMEG HO730 Serial Port  
0403:ED74=HAMEG HO820 Serial Port  
0403:EF10=FT1245BL  
0403:F068=ELV USB-AD-Wandler  
0403:F069=ELV USB-DA-Wandler  
0403:F06A=ELV USB-Schrittmotoren-Interface  
0403:F06B=ELV Thermometer T1100  
0403:F06C=ELV PCD200  
0403:F06D=ELV USB-LCD-Ansteuerung  
0403:F06E=ALC 8xxx Expert  
0403:F06F=ELV FHZ 1000 PC  
0403:F070=Serial Converter 422/485 [Vardaan VEUSB422R3]  
0403:F1A0=Asix PRESTO Programmer  
0403:F208=Papenmeier Braille-Display  
0403:F3C0=4N-GALAXY Serial Converter  
0403:F680=Suunto Sports Instrument  
0403:F758=GW Instek GDS-8x0 Oscilloscope  
0403:F850=USB-UIRT (Universal Infrared Receiver+Transmitter)  
0403:F918=Ant8 Logic Probe  
0403:F9C8=CoachComm Remote  
0403:F9C9=CoachComm Remote  
0403:F9CA=CoachComm Remote  
0403:F9CB=CoachComm Remote  
0403:F9CC=CoachComm Remote

0403:F9CD=CoachComm Remote  
0403:F9CE=CoachComm Remote  
0403:F9CF=CoachComm Remote  
0403:FA00=Matrix Orbital USB Serial  
0403:FA01=Matrix Orbital MX2 or MX3  
0403:FA02=Matrix Orbital MX4 or MX5  
0403:FA03=Matrix Orbital VK/LK202 Family  
0403:FA04=Matrix Orbital VK/LK204 Family  
0403:FAC0=DS2200  
0403:FAC1=PS40M10 A  
0403:FAC1:01=PS40M10 B  
0403:FAC2=DS1M12 A  
0403:FAC2:01=DS1M12 B  
0403:FAC3=DS100M10 A  
0403:FAC3:01=DS100M10 B  
0403:FB59=ELV CLI7000  
0403:FB5C=ELV PPS7330  
0403:FB5D=ELV Temperatur-Feuchte-Messgeraet  
0403:FB5E=ELV USB DCF Funkuhr UDF 77  
0403:FB5F=ELV USB-I/O-Interface  
0403:FC08=Crystalfontz CFA-632 USB LCD  
0403:FC09=Crystalfontz CFA-634 USB LCD  
0403:FC0B=Crystalfontz CFA-633 USB LCD  
0403:FC0C=Crystalfontz CFA-631 USB LCD  
0403:FC0D=Crystalfontz CFA-635 USB LCD  
0403:FC82=SEMC DSS-20 SyncStation  
0403:FD48=ShipModul MiniPlex-4xUSB NMEA Multiplexer  
0403:FD49=ShipModul MiniPlex-4xUSB-AIS NMEA Multiplexer  
0403:FF08=ToolHouse LoopBack Adapter  
0403:FF18=Logbook Bus  
0403:FF19=Logbook Bus  
0403:FF1A=Logbook Bus  
0403:FF1B=Logbook Bus  
0403:FF1C=Logbook Bus  
0403:FF1D=Logbook Bus  
0403:FF1E=Logbook Bus  
0403:FF1F=Logbook Bus  
0404=NCR  
0404:0202=NCR 78XX Scanner  
0404:0203=NCR 78XX Scanner - Embedded System  
0404:0310=NCR K590 Self-Service Printer  
0404:0311=NCR 7167 Receipt/Slip Printer  
0404:0312=NCR 7197 Receipt Printer  
0404:0320=5932-USB Keyboard  
0404:0321=5953-USB Dynakey  
0404:0322=5932-USB Enhanced Keyboard  
0404:0323=5932-USB Enhanced Keyboard, Flash-Recovery/Download  
0404:0324=5953-USB Enhanced Dynakey  
0404:0325=5953-USB Enhanced Dynakey Flash-Recovery/Download  
0404:0328=K016: USB-MSR ISO 3-track MSR: POS Standard (See HID pages)  
0404:0329=K018: USB-MSR JIS 2-Track MSR: POS Standard  
0404:032A=K016: USB-MSR ISO 3-Track MSR: HID Keyboard Mode  
0404:032B=K016/K018: USB-MSR Flash-Recovery/Download  
0405=Sand  
0405:0000=Sand USB Hub  
0406=Fujitsu-ICL Computers  
0407=Fujitsu Personal Systems  
0408=Quanta Computer  
0408:0103=FV TouchCam N1 (Audio)  
0408:030C=HP Webcam

0408:0314=HP Webcam-101  
0408:03A0=USB Webcam  
0408:03B1=USB Webcam  
0408:03B2=HP Webcam  
0408:03BA=HP Webcam  
0408:03E0=USB Webcam  
0408:03E1=LG Webcam  
0408:03F0=HP Webcam  
0408:03F1=HP Webcam  
0408:03F2=USB Webcam  
0408:03F4=HP Webcam-101  
0408:03F5=Sony Visual Communication Camera  
0408:03FE=USB Webcam  
0408:03FF=HP Webcam-50  
0408:0F01=HP Webcam  
0408:0F03=HP Webcam-101  
0408:0F21=USB Webcam  
0408:0F22=USB Webcam  
0408:0F41=HP Webcam-101  
0408:0FF0=USB Webcam  
0408:0FF1=HP Webcam-50  
0408:0FF3=HP Webcam-50  
0408:1030=FV TouchCam N1 (Video)  
0408:10FA=USB Webcam  
0408:130A=USB Webcam  
0408:1311=USB Webcam  
0408:1312=Lenovo EasyCamrea  
0408:1321=LG Webcam  
0408:1322=USB Webcam  
0408:1323=USB Webcam  
0408:13BA=LG Webcam  
0408:13C0=USB Webcam  
0408:13E0=USB Webcam  
0408:13E1=USB Webcam  
0408:13E2=LG Webcam  
0408:13E3=USB Webcam  
0408:13E5=USB Webcam  
0408:13F1=USB Webcam  
0408:13F2=USB Webcam  
0408:13F3=USB Webcam  
0408:13F4=USB Webcam  
0408:13FC=USB Webcam  
0408:13FD=USB Webcam  
0408:1612=USB Webcam  
0408:16FA=USB Webcam  
0408:1AF1=HP Webcam  
0408:1F21=USB Webcam  
0408:1F22=USB Webcam  
0408:1F23=USB Webcam  
0408:1F24=USB Webcam  
0408:1F25=USB Webcam  
0408:1FA1=USB Webcam  
0408:1FC1=LG Webcam  
0408:1FC2=USB Webcam  
0408:1FC3=USB Webcam  
0408:1FD5=USB Webcam  
0408:20B2=USB Webcam  
0408:20BA=USB Webcam  
0408:20F5=Integrated Webcam  
0408:20F8=Integrated Webcam

0408:3000=Optical dual-touch panel  
0408:3001=Optical Touch Screen  
0408:F003=Windows Active Sync Device  
0409=NEC  
0409:0011=NEC PC98 Series Layout USB Keyboard Mouse  
0409:0011:01=NEC PC98 Series Layout USB Keyboard Mouse  
0409:0012=Aterm IT75DSU ISDN TA  
0409:0014=NEC PC98-NX 106/109 USB Keyboard Mouse  
0409:0014:01=NEC PC98-NX 106/109 USB Keyboard Mouse  
0409:0019=NEC 109 Japanese USB Keyboard with Bus-Powered Hub  
0409:001A=NEC PC98 Series USB Keyboard with Bus-Powered Hub  
0409:0024=NEC PC98 Series USB Keyboard with Bus-Powered Hub  
0409:0025=NEC USB Mini Keyboard with Bus-Powered Hub  
0409:0027=MultiSync Monitor  
0409:002C=NEC Klik!-USB Drive  
0409:0034=NEC 109 Japanese USB Keyboard with One-touch start buttons  
0409:003F=NEC Wireless USB Keyboard with One-touch start buttons  
0409:0040=NEC USB Floppy  
0409:004E=SuperScript 1400 Series  
0409:004F=NEC Wireless USB Keyboard with One-touch start buttons  
0409:0058=Belkin USB V2.0 4-Port Hub  
0409:0059=Belkin USB V2.0 4-Port Hub  
0409:005A=Belkin USB V2.0 4-Port Hub  
0409:0066=eHome Infrared Receiver (USBCIR)  
0409:006A=USB Storage Driver  
0409:006D=USB Storage Driver  
0409:0081=SuperScript 1400 Series  
0409:0082=SuperScript 1400 Series  
0409:0094=NEC Japanese USB Keyboard with One-touch start buttons  
0409:0095=NEC Japanese USB Keyboard  
0409:00A9=AtermIT21L 128K Support USB Standard  
0409:00AA=AtermITX72 128K Support USB Standard  
0409:00AB=AtermITX62 128K Support USB Standard  
0409:00AC=AtermIT42 128K Support USB Standard  
0409:00AE=INSMATEV70G-MAX USB Standard  
0409:00AF=AtermITX70 128K Support USB Standard  
0409:00B0=AtermITX80 128K Support USB Standard  
0409:00B2=AtermITX80D 128K Support USB Standard  
0409:00C0=Wireless Remocon  
0409:00D5=NEC USB Sync  
0409:00D6=NEC USB Sync  
0409:00D7=NEC Squale  
0409:00E1=NEC 606 USB Controller  
0409:00EE=NEC IR Remote Controller  
0409:00EE:01=NEC IR Remote Controller  
0409:00F7=NEC Smart Display PK-SD10  
0409:00F8=NEC 808 USB Controller  
0409:0108=USB2.0 IC Card R/W  
0409:010C=NEC 616 USB Controller  
0409:0116=NEC 313 USB Controller  
0409:011D=e228 Mobile Phone  
0409:0137=NEC 338 USB Controller  
0409:0148=NEC CK1506 Smart Card Reader  
0409:018B=NEC CK1506-02 Smart Card Reader  
0409:0203=NEC HID Audio Controls  
0409:0203:03=NEC HID Audio Controls  
0409:021D=Aterm WL54SU2 802.11g Wireless Adapter [Atheros AR5523]  
0409:022F:0100=FOMA N2502 HIGH-SPEED  
0409:022F:0100:02=FOMA N2502 HIGH-SPEED Command Port  
0409:0243=Broadcom Bluetooth 2.1 + EDR USB Device

0409:0248=Aterm PA-WL54GU  
0409:0249=Aterm WL300NU-G  
0409:02B4=Aterm WL300NU-AG  
0409:02B6=Realtek RTL8192SU Wireless LAN 802.11n USB 2.0 Network Adapter  
0409:55AA=NEC USB Hub  
0409:55AB=NEC USB Hub [iMac kbd]  
0409:8010=NEC Intellibase USB Hub  
0409:8011=NEC Intellibase USB Hub  
0409:8024=NEC USB Sync  
0409:8025=NEC USB Sync  
0409:EFBE=P!cty 900 [HP DJ]  
0409:F0BE=P!cty 920 [HP DJ 812c]  
040A=Kodak  
040A:0000=Kodak DVC needs update. Go to [www.kodak.com](http://www.kodak.com)  
040A:0001=DVC-323  
040A:0002=Kodak DVC 323 Digital Video Camera  
040A:0100=Kodak DC220 Digital Camera  
040A:0100:01=KODAK DIGITAL SCIENCE DC220  
040A:0100:0100=Kodak DC220 Digital Camera  
040A:0100:0101=KODAK Digital Science DC220  
040A:0110=Kodak DC260 Digital Camera  
040A:0110:01=KODAK DIGITAL SCIENCE DC260  
040A:0110:0100=Kodak DC260 Digital Camera  
040A:0110:0101=KODAK Digital Science DC260  
040A:0111=Kodak DC265 Digital Camera  
040A:0111:01=KODAK DIGITAL SCIENCE DC265  
040A:0111:0100=Kodak DC265 Digital Camera  
040A:0111:0101=KODAK Digital Science DC265  
040A:0112=Kodak DC290 Zoom Digital Camera  
040A:0112:0100=Kodak DC290 Digital Camera  
040A:0112:0101=KODAK Digital Science DC290  
040A:0120=Kodak DC240 Digital Camera  
040A:0120:0100=Kodak DC240 Digital Camera  
040A:0121=Kodak Digital Camera  
040A:0121:0100=Kodak PTP Prototype Digital Camera  
040A:0130=Kodak DC280 Digital Camera  
040A:0130:0100=Kodak DC280 Digital Camera  
040A:0131=Kodak DC5000 Zoom Digital Camera  
040A:0131:0100=Kodak DC5000 Zoom Digital Camera  
040A:0132=Kodak DC3400 Digital Camera  
040A:0132:0100=Kodak DC3400 Digital Camera  
040A:0140=Kodak DC4800 Zoom Digital Camera  
040A:0140:0100=Kodak DC4800 Zoom Digital Camera  
040A:0160=Kodak DC4800 Zoom Digital Camera  
040A:0170=KODAK DX3900 Zoom Digital Camera  
040A:0200=Kodak Digital Camera  
040A:0200:0100=Kodak Digital Camera  
040A:0300=EZ-200  
040A:0400=Kodak mc3 Camera  
040A:0402=KODAK Digital Camera  
040A:0403=KODAK Digital Camera  
040A:0500=KODAK DX3500 Digital Camera  
040A:0510=KODAK DX3600 Zoom Digital Camera  
040A:0525=KODAK DX3215 Zoom Digital Camera  
040A:0530=KODAK DX3700 Digital Camera  
040A:0535=KODAK DX4230 Digital Camera  
040A:0540=KODAK LS420 Digital Camera  
040A:0550=KODAK DX4900 Digital Camera  
040A:0555=KODAK DX4330 Digital Camera  
040A:0560=KODAK CX4210 Digital Camera

040A:0565=KODAK LS743 Zoom Digital Camera  
040A:0566=KODAK DX4300 Digital Camera  
040A:0567=KODAK LS753 Zoom Digital Camera  
040A:0568=KODAK LS443 Zoom Digital Camera  
040A:0569=KODAK LS633 Zoom Digital Camera  
040A:0570=KODAK DX6340 Zoom Digital Camera  
040A:0571=KODAK CX6330 Zoom Digital Camera  
040A:0572=KODAK DX6440 Zoom Digital Camera  
040A:0573=KODAK CX6230 Zoom Digital Camera  
040A:0574=KODAK CX6200 Digital Camera  
040A:0575=KODAK DX6490 Zoom Digital Camera  
040A:0576=KODAK DX4530 Zoom Digital Camera  
040A:0577=KODAK DX7630 Zoom Digital Camera  
040A:0578=KODAK CX7300 Zoom Digital Camera  
040A:0579=KODAK CX7220 Zoom Digital Camera  
040A:057A=KODAK Digital Camera  
040A:057B=KODAK CX7430 Zoom Digital Camera  
040A:057C=KODAK Digital Camera  
040A:057D=KODAK DX7440 Zoom Digital Camera  
040A:057E=KODAK C300 Digital Camera  
040A:057F=KODAK DX7590 Zoom Digital Camera  
040A:0580=KODAK Z730 Digital Camera  
040A:0581=KODAK Z760 Digital Camera  
040A:0582=KODAK EasyShare-One Digital Camera  
040A:0583=KODAK LS755 Digital Camera  
040A:0584=KODAK Digital Camera  
040A:0585=KODAK Digital Camera  
040A:0586=KODAK Digital Camera  
040A:0587=KODAK Z700 Digital Camera  
040A:0588=KODAK Z740 Digital Camera  
040A:0589=KODAK C360 Digital Camera  
040A:058A=KODAK C310 Digital Camera  
040A:058B=KODAK Digital Camera  
040A:058C=KODAK C330 Digital Camera  
040A:058D=KODAK C340 Digital Camera  
040A:058E=KODAK V530 Digital Camera  
040A:058F=KODAK V550 Digital Camera  
040A:0590=KODAK Digital Camera  
040A:0591=KODAK V570 Digital Camera  
040A:0592=KODAK P850 Zoom Digital Camera  
040A:0593=KODAK P880 Zoom Digital Camera  
040A:0594=KODAK Digital Camera  
040A:0595=KODAK Digital Camera  
040A:0596=KODAK Digital Camera  
040A:0597=KODAK Digital Camera  
040A:0598=KODAK Digital Camera  
040A:0599=KODAK Digital Camera  
040A:059A=KODAK Digital Camera  
040A:059B=KODAK Digital Camera  
040A:059C=KODAK Digital Camera  
040A:059D=KODAK Digital Camera  
040A:059E=KODAK Z650 Digital Camera  
040A:059F=KODAK Digital Camera  
040A:05A0=KODAK Digital Camera  
040A:05A1=KODAK Digital Camera  
040A:05A2=KODAK Digital Camera  
040A:05A3=KODAK Digital Camera  
040A:05A4=KODAK Digital Camera  
040A:05A5=KODAK Digital Camera  
040A:05A6=KODAK Digital Camera

040A:05A7=KODAK Digital Camera  
040A:05A8=KODAK Digital Camera  
040A:05A9=KODAK Digital Camera  
040A:05AA=KODAK Digital Camera  
040A:05AB=KODAK Digital Camera  
040A:05AC=KODAK Digital Camera  
040A:05AD=KODAK Digital Camera  
040A:05AE=KODAK Digital Camera  
040A:05AF=KODAK Digital Camera  
040A:05B0=KODAK Digital Camera  
040A:05B1=KODAK Digital Camera  
040A:05B2=KODAK Digital Camera  
040A:05B3=KODAK Digital Camera  
040A:05B4=KODAK Digital Camera  
040A:05B5=KODAK Digital Camera  
040A:05B6=KODAK Digital Camera  
040A:05B7=KODAK Digital Camera  
040A:05B8=KODAK Digital Camera  
040A:05B9=KODAK Digital Camera  
040A:05BA=KODAK Digital Camera  
040A:05BB=KODAK Digital Camera  
040A:05BC=KODAK Digital Camera  
040A:05BD=KODAK Digital Camera  
040A:05BE=KODAK Digital Camera  
040A:05BF=KODAK Digital Camera  
040A:05C0=KODAK Digital Camera  
040A:05C1=KODAK Digital Camera  
040A:05C2=KODAK Digital Camera  
040A:05C3=KODAK Digital Camera  
040A:05C4=KODAK Digital Camera  
040A:05C5=KODAK Digital Camera  
040A:05C8=EASYSHARE Z1485 IS Digital Camera  
040A:05D3=EasyShare M320 Camera  
040A:05D4=EasyShare C180 Digital Camera  
040A:1001=EasyShare SV811 Digital Picture Frame  
040A:4000=InkJet Color Printer  
040A:4109=EasyShare Printer Dock Series 3  
040A:410D=EasyShare G600 Printer Dock  
040A:5010=Wireless Adapter  
040A:5012=Kodak DBT-220 USB Bluetooth Adapter  
040A:6001=Kodak i30  
040A:6002=Kodak i40  
040A:6003=Kodak i40T  
040A:6004=Kodak i55  
040A:6005=Kodak i65  
040A:6006=Kodak i85  
040A:6013=Kodak i1220  
040B=Weltrend Semiconductor  
040B:6510=Weltrend Bar Code Reader  
040B:6520=XBOX Xploder  
040B:6533=Speed-Link Competition Pro  
040C=VTech Computers  
040D=VIA Technologies  
040D:3184=VNT VT6656 USB-802.11 Wireless LAN Adapter  
040D:6205=USB 2.0 Card Reader  
040E=MCCI  
040F=Echo Speech  
0411=Melco  
0411:0001=LUA-TX Ethernet [pegasus]  
0411:0005=LUA-TX Ethernet



0411:0006=BUFFALO WLI-USB-L11 Wireless LAN Adapter  
0411:0009=LUA2-TX Ethernet  
0411:000B=BUFFALO WLI-USB-L11G-WR Wireless LAN Adapter  
0411:000D=BUFFALO WLI-USB-L11G Wireless LAN Adapter  
0411:0012=LUA-KTX Ethernet  
0411:0013=MELCO USB2-IDE Adapter  
0411:0016=BUFFALO WLI-USB-S11 Wireless LAN Adapter  
0411:0018=MELCO USB2-IDE Adapter  
0411:001C=USB-IDE Bridge: DUB-PxxG  
0411:0027=BUFFALO WLI-USB-KS11G Wireless LAN Adapter  
0411:003D=LUA-U2-KTX Ethernet  
0411:0044=BUFFALO WLI-USB-KB11 Wireless LAN Adapter  
0411:004B=BUFFALO WLI-USB-G54 Wireless LAN Adapter  
0411:004D=WLI-USB-B11 Wireless LAN Adapter  
0411:0050=BUFFALO WLI2-USB2-G54 Wireless LAN Adapter  
0411:005E=BUFFALO WLI-U2-KG54-YB Wireless LAN Adapter  
0411:0065=Python2 WDM Encoder  
0411:0066=BUFFALO WLI-U2-KG54 Wireless LAN Adapter  
0411:0067=BUFFALO WLI-U2-KG54-AI Wireless LAN Adapter  
0411:0089=Buffalo RUF-C/U2 Flash Drive  
0411:008B=Nintendo Wi-Fi  
0411:0091=WLI-U2-KAMG54 Wireless LAN Adapter  
0411:0092=WLI-U2-KAMG54 Bootloader  
0411:0097=BUFFALO WLI-U2-KG54-BB Wireless LAN Adapter  
0411:00A9=WLI-U2-AMG54HP Wireless LAN Adapter  
0411:00AA=WLI-U2-AMG54HP Bootloader  
0411:00B3=PC-OP-RS1 RemoteStation  
0411:00BC=WLI-U2-KG125S 802.11g Adapter [Broadcom 4320 USB]  
0411:00C5=WDF Driver for Buffalo DH1U2  
0411:00CA=802.11n Network Adapter  
0411:00CB=WLI-U2-G300N 802.11n Adapter  
0411:00D8=BUFFALO WLI-U2-SG54HP Wireless LAN Adapter  
0411:00D9=BUFFALO WLI-U2-G54HP Wireless LAN Adapter  
0411:00DA=Wi-Fi Wireless LAN USB Adapter  
0411:00DF=WDF Driver for Buffalo DH1U2P  
0411:00E8=BUFFALO WLI-UC-G300N Wireless LAN Adapter  
0411:00FA=WDF Driver for Buffalo DH-KONE/U2  
0411:00FD=WDF Driver for Buffalo DH-KONE/U2S  
0411:0116=BUFFALO WLR-UC-G Wireless LAN Adapter  
0411:012E=BUFFALO WLI-UC-AG300N Wireless LAN Adapter  
0411:0137=BUFFALO WLI-UC-G Wireless LAN Adapter  
0411:0148=BUFFALO WLI-UC-G300HP Wireless LAN Adapter  
0411:0150=BUFFALO WLP-UC-AG300 Wireless LAN Adapter  
0411:0157=Buffalo External Hard Drive HD-PEU2  
0411:0158=Buffalo WLI-UC-GNHP Wireless LAN Adapter  
0411:015D=BUFFALO WLI-UC-GN Wireless LAN Adapter  
0411:016F=Buffalo WLI-UC-G301N Wireless LAN Adapter  
0411:017F=Sony UWA-BR100 802.11abgn Wireless Adapter [Atheros AR7010]  
0411:019E=Buffalo WLI-UC-GNP Wireless LAN Adapter  
0411:01A1=MiniStation Metro  
0411:01A2=Buffalo WLI-UC-GNM Wireless LAN Adapter  
0411:01EE=WLI-UC-GNM2 Wireless LAN Adapter [Ralink RT3070]  
0412=Award Software  
0413=Leadtek Research  
0413:1310=WinFast TV - NTSC + FM  
0413:1310:01=Leadtek WinFast TV USB Audio - PHP NTSC  
0413:1311=WinFast TV - NTSC + MTS + FM  
0413:1311:01=Leadtek WinFast TV USB Audio - PHP NTSC+MTS  
0413:1312=WinFast TV - PAL BG + FM  
0413:1312:01=Leadtek WinFast TV USB Audio - PHP PAL BG

0413:1313=WinFast TV - PAL BG+TXT + FM  
0413:1313:01=Leadtek WinFast TV USB Audio - PHP PAL BG+TXT  
0413:1314=WinFast TV Audio - PHP PAL I  
0413:1314:01=Leadtek WinFast TV USB Audio - PHP PAL I  
0413:1315=WinFast TV Audio - PHP PAL I+TXT  
0413:1315:01=Leadtek WinFast TV USB Audio - PHP PAL I+TXT  
0413:1316=WinFast TV Audio - PHP PAL DK  
0413:1316:01=Leadtek WinFast TV USB Audio - PHP PAL DK  
0413:1317=WinFast TV Audio - PHP PAL DK+TXT  
0413:1317:01=Leadtek WinFast TV USB Audio - PHP PAL DK+TXT  
0413:1318=WinFast TV - PAL I/DK + FM  
0413:1318:01=Leadtek WinFast TV USB Audio - PHP PAL I/DK  
0413:1319=WinFast TV - PAL N + FM  
0413:1319:01=Leadtek WinFast TV USB Audio - PHP PAL N  
0413:131A=WinFast TV Audio - PHP SECAM LL  
0413:131A:01=Leadtek WinFast TV USB Audio - PHP SECAM LL  
0413:131B=WinFast TV Audio - PHP SECAM LL+TXT  
0413:131B:01=Leadtek WinFast TV USB Audio - PHP SECAM LL+TXT  
0413:131C=WinFast TV Audio - PHP SECAM DK  
0413:131C:01=Leadtek WinFast TV USB Audio - PHP SECAM DK  
0413:131D=WinFast TV - SECAM DK + TXT + FM  
0413:131D:01=Leadtek WinFast TV USB Audio - PHP SECAM DK+TXT  
0413:131E=WinFast TV - NTSC Japan + FM  
0413:131E:01=Leadtek WinFast TV USB Audio - PHP NTSC Japan  
0413:1320=WinFast TV - NTSC  
0413:1320:01=Leadtek WinFast TV USB Audio - PHP NTSC  
0413:1321=WinFast TV - NTSC + MTS  
0413:1321:01=Leadtek WinFast TV USB Audio - PHP NTSC+MTS  
0413:1322=WinFast TV - PAL BG  
0413:1322:01=Leadtek WinFast TV USB Audio - PHP PAL BG  
0413:1323=WinFast TV - PAL BG+TXT  
0413:1323:01=Leadtek WinFast TV USB Audio - PHP PAL BG+TXT  
0413:1324=WinFast TV Audio - PHP PAL I  
0413:1324:01=Leadtek WinFast TV USB Audio - PHP PAL I  
0413:1325=WinFast TV Audio - PHP PAL I+TXT  
0413:1325:01=Leadtek WinFast TV USB Audio - PHP PAL I+TXT  
0413:1326=WinFast TV Audio - PHP PAL DK  
0413:1326:01=Leadtek WinFast TV USB Audio - PHP PAL DK  
0413:1327=WinFast TV Audio - PHP PAL DK+TXT  
0413:1327:01=Leadtek WinFast TV USB Audio - PHP PAL DK+TXT  
0413:1328=WinFast TV - PAL I/DK  
0413:1328:01=Leadtek WinFast TV USB Audio - PHP PAL I/DK  
0413:1329=WinFast TV - PAL N  
0413:1329:01=Leadtek WinFast TV USB Audio - PHP PAL N  
0413:132A=WinFast TV Audio - PHP SECAM LL  
0413:132A:01=Leadtek WinFast TV USB Audio - PHP SECAM LL  
0413:132B=WinFast TV Audio - PHP SECAM LL+TXT  
0413:132B:01=Leadtek WinFast TV USB Audio - PHP SECAM LL+TXT  
0413:132C=WinFast TV Audio - PHP SECAM DK  
0413:132C:01=Leadtek WinFast TV USB Audio - PHP SECAM DK  
0413:132D=WinFast TV - SECAM DK + TXT  
0413:132D:01=Leadtek WinFast TV USB Audio - PHP SECAM DK+TXT  
0413:132E=WinFast TV - NTSC Japan  
0413:132E:01=Leadtek WinFast TV USB Audio - PHP NTSC Japan  
0413:2101=Leadtek USB-to-Serial Port  
0413:6023=EMP Audio Device  
0413:6023:01=USB EMP Audio Device  
0413:6024=WinFast PalmTop/Novo TV Video  
0413:6025=WinFast TV Dongle (cold state)  
0413:6026=WinFast TV Dongle (warm state)

0413:6029=WinFast DTV Dongle Gold  
0413:602C=WinFast TV Dongle With Infrared Receiver  
0413:6125=WinFast TV Dongle  
0413:6126=WinFast TV Dongle BDA Driver  
0413:6644=WinFast TV Dongle With Infrared Receiver  
0413:6F00=WinFast TV Dongle With Infrared Receiver (STK7700P)  
0414=Giga-Byte Technology  
0416=Winbond Electronics  
0416:0035=W89C35 802.11bg WLAN Adapter  
0416:0101=Winbond USB Hub  
0416:0961=AVL Flash Card Reader  
0416:3810=Winbond USB Smart Card Controller  
0416:3811=Generic Controller - Single interface  
0416:3812=Smart Card Controller\_2Interface  
0416:3813=Panel Display  
0416:5518=USB 4-Port Hub  
0416:551A=PC Sync Keypad  
0416:551B=PC Async Keypad  
0416:551C=Sync Tenkey  
0416:551D=Async Tenkey  
0416:551E=Keyboard  
0416:551F=Keyboard w/ Sys and Media  
0416:5521=Keyboard  
0416:6481=16-bit Scanner  
0416:6851=USB Data Cable  
0416:7021=Winbond 702 USB Data Cable  
0416:7721=Winbond USB Memory Stick Reader/Writer  
0416:7721:01=Winbond USB SD Memory Card Reader/Writer  
0416:7722=Winbond USB Memory Stick Reader/Writer  
0416:7723=Winbond USB SD Memory Card Reader/Writer  
0417=Symbios Logic  
0418=AST Research  
0419=Samsung Info. Systems America  
0419:0001=IrDA Remote Controller  
0419:0600=Desktop Wireless 6000  
0419:3001=Xerox P1202 Laser Printer  
0419:3003=Olivetti PG L12L  
0419:3201=Docuprint P8ex  
0419:3404=SCX-5x12 Series  
0419:3406=MFP 830 Series  
0419:3407=ML-912  
0419:3601=InkJet Color Printer  
0419:3602=InkJet Color Printer  
0419:4602=SAMSUNG USB Remote NDIS Network Device  
0419:8001=Samsung USB Hub  
0419:8002=SyncMaster 757DFX HID Device  
0419:A001=TCC730 USB  
0419:A002=TeleChips USB Driver  
0419:AA03=SDAS-3 MP3 Player  
041A=Phoenix Technologies  
041B=d'TV  
041D=S3  
041E=Creative Labs  
041E:1002=Nomad II MP3 Player  
041E:1003=Blaster GamePad Cobra  
041E:1050=GamePad Cobra  
041E:1053=Mouse Gamer HD7600L  
041E:200C=MuvO V100  
041E:2020=Zen X-Fi 2  
041E:2029=ZiiO

041E:2801=Prodikeys PC-MIDI multifunction keyboard  
041E:3000=SoundBlaster Extigy  
041E:3002=SB External Composite Device  
041E:3010=SoundBlaster MP3+  
041E:3014=SB External Composite Device  
041E:3015=Creative SB Digital Music LX  
041E:3020=SoundBlaster Audigy 2 NX  
041E:3030=SB External Composite Device  
041E:3040=Sound Blaster Live! 24-bit External  
041E:3041=USB SB X-Fi XA Karaoke  
041E:3042=SB X-Fi Surround 5.1  
041E:3060=Sound Blaster Audigy 2 ZS External  
041E:3061=SoundBlaster Audigy 2 ZS Video Editor  
041E:3090=Sound Blaster Digital Music SX  
041E:30D2=SB X-Fi Notebook  
041E:30D3=SB Play!  
041E:30D5=Sound Blaster Wireless  
041E:30D8=SB Easy Record/SB Connect Hi-Fi  
041E:30E0=SB X-Fi Go!  
041E:3F00=E-Mu Xboard 25 MIDI Controller  
041E:3F02=E-Mu 0202  
041E:3F04=E-Mu 0404  
041E:3F07=E-Mu Xmidi 1x1  
041E:4003=VideoBlaster WebCam Go Plus [W9967CF]  
041E:4004=Nomad II MG MP3 Player  
041E:4005=WebCam Blaster Go ES  
041E:4005:01=Video Blaster WebCam Go ES (Still)  
041E:4007=Go Mini  
041E:400A=PC-Cam 300  
041E:400A:01=Creative PC-CAM 300 (Still Image)  
041E:400B=PC-Cam 600  
041E:400C=WebCam 5 [pwc]  
041E:400D=WebCam PD1001  
041E:400F=Creative PC-CAM 550 (Video)  
041E:400F:01=Creative PC-CAM 550 (Still)  
041E:4011=Creative WebCam Pro eX (Video)  
041E:4012=Creative PC-CAM 350 (Video)  
041E:4012:01=Creative PC-CAM 350 (Still Image)  
041E:4013=PC-Cam 750  
041E:4013:01=Creative PC-CAM 750 (Still Image)  
041E:4015=Creative CardCam Value (Video)  
041E:4015:01=Creative CardCam Value (Still Image)  
041E:4016=Creative CardCam  
041E:4017=Creative WebCam Mobile  
041E:4018=WebCam Vista  
041E:4019=Audio Device  
041E:401A=WebCam Vista [PD1100]  
041E:401C=Creative WebCam NX  
041E:401D=Creative WebCam NX Ultra  
041E:401E=Creative WebCam NX Pro  
041E:401F=Creative WebCam Notebook  
041E:4020=Creative WebCam NX  
041E:4021=Creative WebCam NX Ultra  
041E:4022=Creative WebCam NX Pro  
041E:4024=Creative PC-CAM 880 (Camera)  
041E:4026=Creative PC-CAM 880 (Camera)  
041E:4028=Creative WebCam Vista Plus  
041E:4029=Creative WebCam Vista Pro  
041E:402F=Creative DC-CAM 3000Z  
041E:4034=Creative WebCam Instant

041E:4035=Creative WebCam Instant  
041E:4036=Creative WebCam Live!  
041E:4037=Creative WebCam Live!  
041E:4038=Creative WebCam Live! Pro  
041E:4039=Creative WebCam Live! Effects  
041E:403A=Creative WebCam NX Pro  
041E:403B=Creative Webcam Vista [VF0010]  
041E:403C=Creative WebCam Live! Ultra  
041E:403D=Creative WebCam Notebook Ultra  
041E:403E=Creative WebCam Vista Plus  
041E:403F=Creative WebCam Vista Pro  
041E:4041=Creative WebCam Live! Motion  
041E:4043=Vibra Plus Webcam  
041E:4045=Live! Cam Voice  
041E:4049=Live! Cam Voice  
041E:4051=Live! Cam Notebook Pro [VF0250]  
041E:4052=Live! Cam Vista IM  
041E:4053=Live! Cam Video IM  
041E:4054=Live! Cam Video IM  
041E:4055=Live! Cam Video IM Pro  
041E:4056=Live! Cam Video IM Pro  
041E:4057=Live! Cam Optia  
041E:4058=Live! Cam Optia AF (VC0100)  
041E:4058:02=VC0100 Live! Cam Optia AF  
041E:405A=Divi CAM525D  
041E:405B=Live! Cam Notebook Ultra (VC0130)  
041E:405B:01=VC0130 Live! Cam Notebook Ultra  
041E:405F=WebCam Vista/Live! Cam Chat VF0330  
041E:4060=Live! Cam Video Chat (VF0350)  
041E:4060:01=VF0350 Live! Cam Video Chat/Video IM  
041E:4061=Live! Cam Notebook Pro (VF0400)  
041E:4061:01=VF0400 Live! Cam Notebook Pro  
041E:4063=Live! Cam Video IM Pro (VF0410)  
041E:4063:02=VF0410 Live! Cam Video IM Pro  
041E:4064=Live! Cam Vista IM (VF0420)  
041E:4067=Live! Cam Video IM (VF0350)  
041E:4067:01=VF0350 Live! Cam Video Chat/Video IM  
041E:4068=Live! Cam Notebook (VF0470)  
041E:4069=Live! Cam Video IM/Video Chat (VF0540)  
041E:4069:02=VF0540 Live! Cam Video IM/Video Chat  
041E:406A=Live! Cam Notebook Ultra (VF0490)  
041E:406A:02=VF0490 Live! Cam Notebook Ultra  
041E:406B=Live! Cam Chat IM (VF0530)  
041E:406C=Live! Cam Sync (VF0520)  
041E:406D=Live! Cam Optia AF (VF0560)  
041E:406D:02=VF0560 Live! Cam Optia AF  
041E:4071=Live! Cam Video IM Ultra (VF0415)  
041E:4071:02=VF0415 Live! Cam Video IM Ultra  
041E:4072=Live! Cam Notebook Ultra (VF0490)  
041E:4072:02=VF0490 Live! Cam Notebook Ultra  
041E:4080=Live! Cam Socialize HD (VF0610)  
041E:4080:02=VF0610 Live! Cam Socialize HD  
041E:4083=Live! Cam Socialize [VF0640]  
041E:4087=Live! Cam Socialize HD 1080 [VF0680]  
041E:4088=Live! Cam Chat HD (VF0700)  
041E:4088:02=VF0700 Live! Cam Chat HD  
041E:4100=Nomad Jukebox 2  
041E:4101=Nomad Jukebox 3  
041E:4102=NOMAD MuVo^2  
041E:4106=Nomad MuVo

041E:4107=NOMAD MuVo  
041E:4108=Nomad Jukebox Zen  
041E:4109=Nomad Jukebox Zen NX  
041E:410B=NOMAD Jukebox Zen (USB 2.0)  
041E:410C=Nomad MuVo NX  
041E:410F=NOMAD MuVo^2 (Flash)  
041E:4110=Nomad Jukebox Zen Xtra  
041E:4111=Dell Digital Jukebox  
041E:4116=MuVo^2  
041E:4117=Nomad MuVo TX  
041E:411B=Creative Zen Touch  
041E:411C=Nomad MuVo USB 2.0  
041E:411D=Zen  
041E:411E=Creative Zen Micro  
041E:4120=Nomad MuVo TX FM  
041E:4123=Appareil mobile MTP  
041E:4124=MuVo^2 FM (uHDD)  
041E:4126=Dell DJ (2nd gen)  
041E:4127=Dell DJ  
041E:4128=NOMAD Jukebox Zen Xtra (mtp)  
041E:412B=MuVo N200 with FM radio  
041E:412F=Dell Digital Jukebox 2.Gen  
041E:4130=Zen Micro (mtp)  
041E:4131=Zen Touch (mtp)  
041E:4133=Mass Storage Device  
041E:4134=Zen Neeon  
041E:4136=Zen Sleek  
041E:4137=Zen Sleek (mtp)  
041E:4139=Zen Nano Plus  
041E:413C=Zen MicroPhoto  
041E:4150=Zen V (MTP)  
041E:4151=Zen Vision:M (mtp)  
041E:4152=Zen V Plus  
041E:4153=Zen Vision W  
041E:4155=Zen Stone plus  
041E:4157=Zen (MTP)  
041E:500F=Broadband Blaster 8012U-V  
041E:5015=TECOM Bluetooth Device  
041E:FFFE=Creative Live! Camera  
041E:FFFF=Monitor Integrated Webcam  
041F=LCS Telegraphics  
0420=Chips and Technologies  
0420:1307=Celly SIM Card Reader  
0421=Nokia  
0421:0001=Nokia GSM Phone USB Phone Parent  
0421:0007=Nokia GSM Phone USB Phone Parent  
0421:000B=Nokia GSM Phone USB Phone Parent  
0421:000E=Nokia N77 USB Phone Parent  
0421:0012=Nokia GSM Phone USB Phone Parent  
0421:0015=Nokia GSM Phone USB Phone Parent  
0421:0018=Nokia 6288 USB Phone Parent  
0421:0019=6288 GSM Smartphone (imaging mode)  
0421:001A=6288 GSM Smartphone (file transfer mode)  
0421:001B=Nokia 6555b USB Phone Parent  
0421:001D=Nokia GSM Phone USB Phone Parent  
0421:001F=Nokia 3555b USB Phone Parent  
0421:0024=5610 XpressMusic (Storage mode)  
0421:0025=Nokia GSM Phone USB Phone Parent  
0421:0026=Nokia GSM Phone USB Phone Parent  
0421:0028=5610 XpressMusic (Imaging mode)

0421:002C=Nokia GSM Phone USB Phone Parent  
0421:002D=6120 Phone (Mass storage mode)  
0421:002E=6120 Phone (Media-Player mode)  
0421:002F=Nokia GSM Phone USB Phone Parent  
0421:0031=Nokia GSM Phone USB Phone Parent  
0421:003A=Nokia GSM Phone USB Phone Parent  
0421:003D=Nokia GSM Phone USB Phone Parent  
0421:0040=Nokia GSM Phone USB Phone Parent  
0421:0042=Nokia GSM Phone USB Phone Parent  
0421:0047=Nokia 6555 USB Phone Parent  
0421:004B=Nokia 6555c USB Phone Parent  
0421:004E=Nokia 3555 USB Phone Parent  
0421:0051=Nokia 3555c USB Phone Parent  
0421:0054=Nokia GSM Phone USB Phone Parent  
0421:0057=Nokia GSM Phone USB Phone Parent  
0421:005B=Nokia GSM Phone USB Phone Parent  
0421:005E=Nokia 3110 Classic USB Phone Parent  
0421:0061=Nokia GSM Phone USB Phone Parent  
0421:0064=Nokia GSM Phone USB Phone Parent  
0421:0066=Nokia Internet Modem  
0421:0068=Nokia GSM Phone USB Phone Parent  
0421:006B=Nokia GSM Phone USB Phone Parent  
0421:006C=5310 Xpress music (Storage mode)  
0421:006D=N95 (Storage mode)  
0421:006E=N95 (Multimedia mode)  
0421:006F=N95 (Printing mode)  
0421:0070=Nokia GSM Phone USB Phone Parent  
0421:0071=Nokia GSM Phone USB Phone Parent  
0421:0076=Nokia GSM Phone USB Phone Parent  
0421:007B=Nokia GSM Phone USB Phone Parent  
0421:007C=Nokia GSM Phone USB Phone Parent  
0421:007F=Nokia GSM Phone USB Phone Parent  
0421:0085=Nokia GSM Phone USB Phone Parent  
0421:0088=Nokia GSM Phone USB Phone Parent  
0421:008B=Nokia GSM Phone USB Phone Parent  
0421:008F=Nokia GSM Phone USB Phone Parent  
0421:0094=Nokia GSM Phone USB Phone Parent  
0421:0096=N810 Internet Tablet  
0421:0099=Nokia GSM Phone USB Phone Parent  
0421:009C=Nokia GSM Phone USB Phone Parent  
0421:00A0=Nokia GSM Phone USB Phone Parent  
0421:00A3=Nokia GSM Phone USB Phone Parent  
0421:00A7=Nokia GSM Phone USB Phone Parent  
0421:00AA=E71 (Mass storage mode)  
0421:00AB=Nokia GSM Phone USB Phone Parent  
0421:00AE=Nokia GSM Phone USB Phone Parent  
0421:00B0=Nokia GSM Phone USB Phone Parent  
0421:00B1=Nokia GSM Phone USB Phone Parent  
0421:00BD=Nokia GSM Phone USB Phone Parent  
0421:00BF=Nokia GSM Phone USB Phone Parent  
0421:00C3=Nokia GSM Phone USB Phone Parent  
0421:00C5=Nokia GSM Phone USB Phone Parent  
0421:00C8=Nokia GSM Phone USB Phone Parent  
0421:00CB=Nokia GSM Phone USB Phone Parent  
0421:00CE=Nokia GSM Phone USB Phone Parent  
0421:00D1=Nokia USB Phone Parent  
0421:00D4=Nokia GSM Phone USB Phone Parent  
0421:00D8=Nokia GSM Phone USB Phone Parent  
0421:00DC=Nokia GSM Phone USB Phone Parent  
0421:00DF=Nokia GSM Phone USB Phone Parent

0421:00E2=Nokia 6650 Fold USB Phone Parent  
0421:00E4=E71 (Media transfer mode)  
0421:00E8=Nokia GSM Phone USB Phone Parent  
0421:00E9=Nokia GSM Phone USB Phone Parent  
0421:00ED=Nokia GSM Phone USB Phone Parent  
0421:00F0=Nokia GSM Phone USB Phone Parent  
0421:00F3=Nokia GSM Phone USB Phone Parent  
0421:00F6=Nokia GSM Phone USB Phone Parent  
0421:00FC=Nokia GSM Phone USB Phone Parent  
0421:0103=ADL Flashing Engine AVALON Parent  
0421:0104=Nokia ADL USB Re-Flashing Engine Parent  
0421:0105=Nokia BB5 ADL Loader USB Phone Parent  
0421:0106=Nokia USB ROM Parent  
0421:0108=Nokia GSM Phone USB Phone Parent  
0421:010C=Nokia GSM Phone USB Phone Parent  
0421:010E=Nokia GSM Phone USB Phone Parent  
0421:0111=Nokia GSM Phone USB Phone Parent  
0421:0116=Nokia GSM Phone USB Phone Parent  
0421:011C=Nokia GSM Phone USB Phone Parent  
0421:011D=Nokia GSM Phone USB Phone Parent  
0421:0124=Nokia GSM Phone USB Phone Parent  
0421:0128=Nokia GSM Phone USB Phone Parent  
0421:012C=Nokia GSM Phone USB Phone Parent  
0421:0130=Nokia GSM Phone USB Phone Parent  
0421:0134=Nokia GSM Phone USB Phone Parent  
0421:0138=Nokia GSM Phone USB Phone Parent  
0421:0139=Nokia GSM Phone USB Phone Parent  
0421:013C=Nokia GSM Phone USB Phone Parent  
0421:013F=Nokia GSM Phone USB Phone Parent  
0421:0140=Nokia GSM Phone USB Phone Parent  
0421:0143=Nokia GSM Phone USB Phone Parent  
0421:014B=Nokia GSM Phone USB Phone Parent  
0421:014F=Nokia GSM Phone USB Phone Parent  
0421:0153=Nokia GSM Phone USB Phone Parent  
0421:0154=Nokia GSM Phone USB Phone Parent  
0421:0155=5800 XpressMusic (Multimedia mode)  
0421:0156=5800 XpressMusic (Storage mode)  
0421:0157=5800 XpressMusic (Imaging mode)  
0421:0158=Nokia GSM Phone USB Phone Parent  
0421:0165=Nokia 3610a USB Phone Parent  
0421:0168=Nokia GSM Phone USB Phone Parent  
0421:016D=Vertu Signature USB Phone Parent  
0421:0170=Vertu Ascent Ti USB Phone Parent  
0421:0173=Nokia 5208 USB Phone Parent  
0421:0178=Nokia GSM Phone USB Phone Parent  
0421:017A=Nokia GSM Phone USB Phone Parent  
0421:017D=Nokia GSM Phone USB Phone Parent  
0421:0182=Nokia 8800 SapphireArte USB Phone Parent  
0421:0187=Nokia GSM Phone USB Phone Parent  
0421:018A=Nokia GSM Phone USB Phone Parent  
0421:018D=Nokia 3611 USB Phone Parent  
0421:0194=Nokia GSM Phone USB Phone Parent  
0421:0199=6700 Classic (msc)  
0421:019A=Nokia USB Phone Parent  
0421:019B=6700 Classic (mtp)  
0421:019E=Nokia GSM Phone USB Phone Parent  
0421:01A2=Nokia GSM Phone USB Phone Parent  
0421:01A9=Nokia GSM Phone USB Phone Parent  
0421:01B0=Nokia GSM Phone USB Phone Parent  
0421:01B1=6303 classic Phone (Mass storage mode)



0421:01B2=Nokia GSM Phone USB Phone Parent  
0421:01B3=Nokia GSM Phone USB Phone Parent  
0421:01B6=Nokia GSM Phone USB Phone Parent  
0421:01BC=Nokia GSM Phone USB Phone Parent  
0421:01C7=N900 (Storage Mode)  
0421:01C8=Nokia GSM Phone USB Phone Parent  
0421:01CC=Nokia GSM Phone USB Phone Parent  
0421:01D0=Nokia GSM Phone USB Phone Parent  
0421:01D4=Nokia GSM Phone USB Phone Parent  
0421:01D6=Nokia 7212 classic USB Phone Parent  
0421:01D9=Nokia GSM Phone USB Phone Parent  
0421:01DC=Nokia USB Phone Parent  
0421:01E1=Nokia USB Phone Parent  
0421:01E3=Nokia USB Phone Parent  
0421:01E6=Nokia USB Phone Parent  
0421:01EA=Nokia USB Phone Parent  
0421:01EC=Nokia USB Phone Parent  
0421:01F5=Nokia USB Phone Parent  
0421:01F8=Nokia 7618s USB Phone Parent  
0421:01FB=Nokia USB Phone Parent  
0421:01FE=Nokia 6212 Classic USB Phone Parent  
0421:0201=Nokia USB Phone Parent  
0421:0204=Nokia USB Phone Parent  
0421:0208=Nokia 5130 XPressMusic USB Phone Parent  
0421:0209=Nokia GSM Phone USB Phone Parent  
0421:020B=Nokia 5130 XPressMusic USB Phone Parent  
0421:020F=Nokia USB Phone Parent  
0421:0212=Nokia USB Phone Parent  
0421:0216=Nokia USB Phone Parent  
0421:0219=Nokia USB Phone Parent  
0421:021E=Nokia USB Phone Parent  
0421:0223=Nokia USB Phone Parent  
0421:0226=Nokia USB Phone Parent  
0421:0228=5530 XpressMusic  
0421:022A=Nokia USB Phone Parent  
0421:0235=Nokia USB Phone Parent  
0421:023A=6730 Classic  
0421:023D=Nokia USB Phone Parent  
0421:0241=Nokia USB Phone Parent  
0421:0244=Nokia USB Phone Parent  
0421:0249=Nokia USB Phone Parent  
0421:024B=Nokia USB Phone Parent  
0421:0250=Nokia USB Phone Parent  
0421:0252=Nokia USB Phone Parent  
0421:0258=Nokia USB Phone Parent  
0421:025A=Nokia USB Phone Parent  
0421:0261=Nokia USB Phone Parent  
0421:0264=Nokia USB Phone Parent  
0421:026A=N97 (mass storage)  
0421:026B=N97 (Multimedia)  
0421:026C=Nokia USB Phone Parent  
0421:026D=N97 (Pictures)  
0421:0275=Nokia USB Phone Parent  
0421:0279=Nokia USB Phone Parent  
0421:027D=Nokia USB Phone Parent  
0421:0282=Nokia USB Phone Parent  
0421:0285=Nokia USB Phone Parent  
0421:0288=Nokia 6720 classic USB Phone Parent  
0421:028C=Nokia 6710 Navigator USB Phone Parent  
0421:028F=Nokia 2700 classic USB Phone Parent

0421:0292=Nokia 2700 classic USB Phone Parent  
0421:0294=Nokia 6650 fold USB Phone Parent  
0421:0295=660i/6600i Slide Phone (Mass Storage)  
0421:0296=Nokia USB Phone Parent  
0421:0297=660i/6600i Slide Phone (Still Image)  
0421:029A=Nokia 6710 Navigator USB Phone Parent  
0421:029F=Nokia USB Phone Parent  
0421:02A1=Nokia USB Phone Parent  
0421:02AA=Nokia USB Phone Parent  
0421:02AD=Nokia USB Phone Parent  
0421:02B1=Nokia USB Phone Parent  
0421:02BA=Nokia USB Phone Parent  
0421:02BD=Nokia USB Phone Parent  
0421:02C0=Nokia USB Phone Parent  
0421:02C3=Nokia USB Phone Parent  
0421:02C6=Nokia USB Phone Parent  
0421:02C9=Nokia USB Phone Parent  
0421:02CD=Nokia USB Phone Parent  
0421:02D1=Nokia USB Phone Parent  
0421:02D4=Nokia USB Phone Parent  
0421:02D9=Nokia USB Phone Parent  
0421:02DF=Nokia USB Phone Parent  
0421:02E1=5230 (Storage mode)  
0421:02E2=5230 (Multimedia mode)  
0421:02E3=Nokia USB Phone Parent  
0421:02E4=5230 (Imaging mode)  
0421:02E7=Nokia USB Phone Parent  
0421:02E9=Nokia 5802 XpressMusic USB Phone Parent  
0421:02ED=Nokia USB Phone Parent  
0421:02F2=Nokia USB Phone Parent  
0421:02F6=Nokia USB Phone Parent  
0421:02FB=Nokia USB Phone Parent  
0421:0302=Nokia USB Phone Parent  
0421:030F=Nokia USB Phone Parent  
0421:0312=Nokia USB Phone Parent  
0421:0315=Nokia USB Phone Parent  
0421:031D=Nokia USB Phone Parent  
0421:0325=Nokia USB Phone Parent  
0421:032B=Nokia USB Phone Parent  
0421:032F=Nokia USB Phone Parent  
0421:0335=Nokia USB Phone Parent  
0421:033C=Nokia USB Phone Parent  
0421:033E=Nokia USB Phone Parent  
0421:0342=Nokia USB Phone Parent  
0421:0348=Nokia USB Phone Parent  
0421:034C=Nokia 5230 USB Phone Parent  
0421:0352=Nokia USB Phone Parent  
0421:0355=Nokia USB Phone Parent  
0421:0359=Nokia USB Phone Parent  
0421:035B=Nokia USB Phone Parent  
0421:035F:01=Nokia USB Phone Parent  
0421:0360=Nokia USB Phone Parent  
0421:0363=Nokia USB Phone Parent  
0421:036C=Nokia USB Phone Parent  
0421:0370=Nokia USB Phone Parent  
0421:0374=Nokia USB Phone Parent  
0421:0378=Nokia USB Phone Parent  
0421:037C=Nokia USB Phone Parent  
0421:0380=Nokia USB Phone Parent  
0421:0384=Nokia USB Phone Parent

0421:0388=Nokia USB Phone Parent  
0421:038B=Nokia USB Phone Parent  
0421:038F=Nokia USB Phone Parent  
0421:0393=Nokia USB Phone Parent  
0421:0399=Nokia USB Phone Parent  
0421:039C=Nokia USB Phone Parent  
0421:03A2=Nokia USB Phone Parent  
0421:03A4=C5 (Storage mode)  
0421:03A7=Nokia USB Phone Parent  
0421:03A8=Nokia USB Phone Parent  
0421:03AD=Nokia USB Phone Parent  
0421:03B1=Nokia USB Phone Parent  
0421:03B4=Nokia USB Phone Parent  
0421:03B8=Nokia USB Phone Parent  
0421:03BE=Nokia USB Phone Parent  
0421:03C5=Nokia USB Phone Parent  
0421:03CD=Nokia USB Phone Parent  
0421:03CF=Nokia USB Phone Parent  
0421:03D2=Nokia USB Phone Parent  
0421:03D3=Nokia USB Phone Parent  
0421:03D9=Nokia USB Phone Parent  
0421:03DF=Nokia USB Phone Parent  
0421:03E2=Nokia USB Phone Parent  
0421:03E6=Nokia USB Phone Parent  
0421:03ED=Nokia USB Phone Parent  
0421:03F3=Nokia USB Phone Parent  
0421:03F5=Nokia USB Phone Parent  
0421:03FA=Nokia C2-00 USB Phone Parent  
0421:03FD=Nokia USB Phone Parent  
0421:0400=Nokia 7600 USB Phone Parent  
0421:0401=Nokia 6650 USB Phone Parent  
0421:0402=Nokia 6255 USB Phone Parent  
0421:0404=Nokia 5510  
0421:0405=Nokia 9500 USB Phone Parent  
0421:0407=Nokia Music Player HDR-1(tm)  
0421:040B=N-Gage GSM Phone  
0421:040D=Nokia 6620 USB Phone Parent  
0421:040E=Nokia 6651 USB Phone Parent  
0421:040F=Nokia 6230 USB Phone Parent  
0421:0410=Nokia 6630 USB Phone Parent  
0421:0411=Nokia 7610 USB Phone Parent  
0421:0412=Nokia 33 USB Phone Parent  
0421:0413=Nokia 6260 USB Phone Parent  
0421:0414=Nokia 7370 USB Phone Parent  
0421:0415=Nokia 9300 USB Phone Parent  
0421:0416=Nokia 6170 USB Phone Parent  
0421:0417=Nokia 7270 USB Phone Parent  
0421:0418=Nokia E70 USB Phone Parent  
0421:0419=Nokia E60 USB Phone Parent  
0421:041A=9500 GSM Communicator (RNDIS)  
0421:041B=9300 GSM Smartphone (RNDIS)  
0421:041C=Nokia 7710 USB Phone Parent  
0421:041D=Nokia 6670 USB Phone Parent  
0421:041E=Nokia 6680 USB Phone Parent  
0421:041F=Nokia 6235 USB Phone Parent  
0421:0420=Nokia GSM Phone USB Phone Parent  
0421:0421=Nokia 3230 USB Phone Parent  
0421:0422=Nokia 6681 USB Phone Parent  
0421:0423=Nokia 6682 USB Phone Parent  
0421:0425=Nokia N71 USB Phone Parent

0421:0428=Nokia 6230i USB Phone Parent  
0421:0429=6230i Camera Phone  
0421:042D=Nokia 3250 USB Phone Parent  
0421:042F=Nokia N91 USB Phone Parent  
0421:0430=Nokia USB Phone Parent  
0421:0431=770 Internet Tablet  
0421:0432=Nokia N90 USB Phone Parent  
0421:0435=E-70 (IP Passthrough/RNDIS mode)  
0421:0436=E-60 (IP Passthrough/RNDIS mode)  
0421:0437=Nokia 6265 USB Phone Parent  
0421:0439=Vertu Constellation USB Phone Parent  
0421:043A=Nokia N70 USB Phone Parent  
0421:043B=Nokia 3155 USB Phone Parent  
0421:043C=Nokia 6155 USB Phone Parent  
0421:043D=Nokia 6270 USB Phone Parent  
0421:043F=Nokia GSM Phone USB Phone Parent  
0421:0441=Nokia 6136 USB Phone Parent  
0421:0443=Nokia N70 USB Phone Parent  
0421:0444=N91  
0421:0445=Nokia N80 USB Phone Parent  
0421:044C=FOMA NM850iG USB Phone Parent  
0421:044D=Nokia E61 USB Phone Parent  
0421:044E=E-61 (Data Exchange mode)  
0421:044F=E-61 (IP Passthrough/RNDIS mode)  
0421:0453=Nokia 9300i USB Phone Parent  
0421:0456=Nokia 6111 USB Phone Parent  
0421:0457=6111 Phone (Printing mode)  
0421:0458=Nokia 6111 USB Phone Parent  
0421:045A=Nokia 6280 USB Phone Parent  
0421:045D=Nokia 6282 USB Phone Parent  
0421:0464=Nokia 6165 USB Phone Parent  
0421:0466=Nokia 6165i USB Phone Parent  
0421:0468=Nokia CDMA Phone USB Phone Parent  
0421:046A=Nokia CDMA Phone USB Phone Parent  
0421:046C=Nokia CDMA Phone USB Phone Parent  
0421:046E=Nokia GSM Phone USB Phone Parent  
0421:0471=6110 Navigator  
0421:0472=Nokia E70 USB Phone Parent  
0421:0475=Nokia N62 USB Phone Parent  
0421:047B=Nokia 6131 USB Phone Parent  
0421:0481=Nokia GSM Phone USB Phone Parent  
0421:0485=MTP Device  
0421:0486=Nokia GSM Phone USB Phone Parent  
0421:0489=Nokia GSM Phone USB Phone Parent  
0421:048C=Nokia 2855 USB Phone Parent  
0421:048E=Nokia N92 USB Phone Parent  
0421:0491=Nokia 6233 USB Phone Parent  
0421:0494=Nokia 6234 USB Phone Parent  
0421:0499=Nokia GSM Phone USB Phone Parent  
0421:049D=Nokia GSM Phone USB Phone Parent  
0421:04A1=Nokia GSM Phone USB Phone Parent  
0421:04A5=Nokia GSM Phone USB Phone Parent  
0421:04A9=Nokia 6125 USB Phone Parent  
0421:04AC=Nokia GSM Phone USB Phone Parent  
0421:04AF=Nokia GSM Phone USB Phone Parent  
0421:04B2=Nokia GSM Phone USB Phone Parent  
0421:04B5=Nokia GSM Phone USB Phone Parent  
0421:04B8=Nokia GSM Phone USB Phone Parent  
0421:04B9=5300  
0421:04BC=Nokia GSM Phone USB Phone Parent

0421:04C0=Nokia GSM Phone USB Phone Parent  
0421:04C1=Nokia GSM Phone USB Phone Parent  
0421:04C2=Nokia 770 USB Phone Parent  
0421:04C3=N800 Internet Tablet  
0421:04C4=Nokia N72 USB Phone Parent  
0421:04C6=Nokia CDMA Phone USB Phone Parent  
0421:04C9=Nokia GSM Phone USB Phone Parent  
0421:04CB=Nokia GSM Phone USB Phone Parent  
0421:04CE=Nokia GSM Phone USB Phone Parent  
0421:04CF=E90 Communicator (Storage mode)  
0421:04D2=Nokia GSM Phone USB Phone Parent  
0421:04D5=Nokia CDMA Phone USB Phone Parent  
0421:04D8=Nokia GSM Phone USB Phone Parent  
0421:04DC=Nokia CDMA Phone USB Phone Parent  
0421:04DF=Nokia N75 USB Phone Parent  
0421:04E6=Nokia GSM Phone USB Phone Parent  
0421:04E7=Nokia 6178i USB Phone Parent  
0421:04E9=Nokia GSM Phone USB Phone Parent  
0421:04F0=Nokia GSM Phone USB Phone Parent  
0421:04F2=Nokia 8600 Luna USB Phone Parent  
0421:04F6=Nokia GSM Phone USB Phone Parent  
0421:04F9=Nokia GSM 6300 Phone USB Phone Parent  
0421:0500=Nokia GSM Phone USB Phone Parent  
0421:0502=Nokia GSM Phone USB Phone Parent  
0421:0505=Nokia GSM Phone USB Phone Parent  
0421:0508=Nokia GSM Phone USB Phone Parent  
0421:0509=E65 (Storage mode)  
0421:050A=Nokia USB Phone Parent  
0421:050C=Nokia USB Phone Parent  
0421:050F=Nokia USB Phone Parent  
0421:0513=Nokia USB Phone Parent  
0421:051A=Nokia USB Phone Parent  
0421:051D=Nokia USB Phone Parent  
0421:0520=Nokia USB Phone Parent  
0421:0524=Nokia USB Phone Parent  
0421:0529=Nokia USB Phone Parent  
0421:052B=Nokia USB Phone Parent  
0421:0531=Nokia USB Phone Parent  
0421:0533=Nokia USB Phone Parent  
0421:053A=Nokia USB Phone Parent  
0421:0600=Digital Pen SU-1B  
0421:0606=Nokia PT-6 USB Phone Parent  
0421:0610=CS-15 (Internet Stick 3G modem)  
0421:0800=Nokia Connectivity Adapter Cable DKU-5  
0421:0801=Nokia Data Cable DKU-6  
0421:0802=Nokia CA-42 USB Phone Parent  
0421:08BB=Nokia USB Phone Parent  
0421:08BE=Nokia USB Phone Parent  
0422=ADI System  
0422:6130=ADI C350 USB PC Camera  
0422:7310=ADI C350 USB PC Camera  
0423=LeCroy  
0423:000A=NetMate Ethernet  
0423:000B=CATC FireInspector IEEE 1394 Bus Analyzer  
0423:000C=NetMate2 Ethernet  
0423:000D=USB Chief Bus & Protocol Analyzer  
0423:0010=Advisor USB 2.0 Analyzer  
0423:0011=Merlin Bluetooth Analyzer  
0423:0100=Generic Universal Protocol Analyzer  
0423:0101=UPA USBTracer

0423:0200=Generic 10K Universal Protocol Analyzer  
0423:0207=10K SASTracer  
0423:020A=PETracer ML  
0423:020B=PETrainer x4  
0423:0300=Generic Universal Protocol Analyzer  
0423:0301=2500H USB Tracer Trainer  
0423:030A=PETracer x1  
0423:0400=UPAS100K Protocol Board  
0423:040A=PETracer EML  
0423:040B=PETrainer EML  
0423:0500=UPAS100K Platform  
0423:0501=UPAS100K I/O Board  
0423:0800=Generic Dragon Protocol Analyzer Platform  
0423:080A=PETracer Edge  
0423:1237=USB Hub  
0424=Standard Microsystems  
0424:0001=Integrated USB Hub  
0424:0ACD=Sitecom Internal Multi Memory reader/writer MD-005  
0424:0FDC=SMSC USB Floppy  
0424:10CD=Sitecom Internal Multi Memory reader/writer MD-005  
0424:2020=USB Hub  
0424:20CD=Sitecom Internal Multi Memory reader/writer MD-005  
0424:20FC=6-in-1 Card Reader  
0424:2228=9-in-2 Card Reader  
0424:223A=USB Mass Storage Device Filter Driver (2K,XP)  
0424:2503=USB V2.0 4-Port Hub  
0424:2504=USB V2.0 4-Port Hub  
0424:2512=USB V2.0 4-Port Hub  
0424:2514=USB V2.0 4-Port Hub  
0424:2517=Hub  
0424:2524=USB MultiSwitch Hub  
0424:2602=USB V2.0 4-Port Hub  
0424:2640=USB 2.0 Hub  
0424:4060=Ultra Fast Media Reader  
0424:4064=Ultra Fast Media Reader  
0424:9500=LAN9500 USB 2.0 to Ethernet 10/100 Adapter  
0424:9505=LAN9505 USB 2.0 to Ethernet 10/100 Adapter  
0424:A700=USB V2.0 4-Port Hub  
0425=Motorola  
0425:0101=G-Tech Wireless Mouse & Keyboard  
0425:F102=G-Tech U+P Wireless Mouse  
0425:FF07=Freescale USB JW32 ICP Device  
0426=Integrated Device Technology  
0426:0426=WDM Driver  
0427=Motorola  
0428=Advanced Gravis Computer  
0428:4001=GamePad Pro  
0429=Cirrus Logic  
042A=Ericsson  
042B=Intel  
042B:9316=Intel 8x931Hx Customer Hub  
042C=Innovative Semiconductors  
042D=Micronics  
042E=Acer  
042E:0380=MP3 Player  
042F=Molex  
0430=Fujitsu  
0430:0002=Fujitsu 109 USB Keyboard  
0430:0002:01=Fujitsu USB Composite Keyboard Mouse  
0430:0005=Type 6 Keyboard

0430:000A=Fujitsu 109 Japanese USB Keyboard  
0430:000B=Fujitsu 109 Japanese USB Keyboard  
0430:0082=Fujitsu 109 Japanese USB Keyboard  
0430:0083=Fujitsu 109 Japanese USB Keyboard  
0430:00A2=Type 7 Keyboard  
0430:0100=3-button Mouse  
0430:0500=Fujitsu Touch Panel (USB)  
0430:0501=Fujitsu Touch Panel (USB)  
0430:0502=Fujitsu Touch Panel (USB)  
0430:0503=Fujitsu Touch Panel (USB)  
0430:0504=Fujitsu Touch Panel (USB)  
0430:0505=Fujitsu Touch Panel (USB)  
0430:0506=Fujitsu Touch Panel (USB)  
0430:0507=Fujitsu Touch Panel (USB)  
0430:0508=Fujitsu Touch Panel (USB)  
0430:100E=24.1" LCD Monitor v4  
0430:36BA=Fujitsu USB Bus Powered Hub  
0430:CDAB=Raritan KVM dongle  
0431=Itac Systems  
0431:0100=ITAC Evolution USB Mouse-Trak  
0431:0100:01=Evolution USB Mouse-Trak by ITAC  
0432=Unisys  
0433=Alps Electric  
0433:1101=IBM Game Controller  
0433:ABAB=ALPS USB Keyboard  
0434=Samsung Info. Systems America  
0435=Hyundai Electronics America  
0436=Taugagreining HF  
0436:0005=CameraMate (DPCM\_USB)  
0437=Framatome Connectors USA  
0438=Advanced Micro Devices  
0438:AC14=ATI Unified AVStream Driver  
0438:B003=ATI Unified AVStream Driver  
0439=Voice Technologies Group  
043D=Lexmark International  
043D:0001=Laser Printer  
043D:0002=Optra E310 Printer  
043D:0003=Laser Printer  
043D:0004=Laser Printer  
043D:0005=Laser Printer  
043D:0006=Laser Printer  
043D:0007=Laser Printer  
043D:0008=Inkjet Color Printer  
043D:0009=Optra S2450 Printer  
043D:000A=Laser Printer  
043D:000B=Inkjet Color Printer  
043D:000C=Optra E312 Printer  
043D:000D=Laser Printer  
043D:000E=Laser Printer  
043D:000F=Laser Printer  
043D:0010=Laser Printer  
043D:0011=Laser Printer  
043D:0012=Inkjet Color Printer  
043D:0013=Inkjet Color Printer  
043D:0014=InkJet Color Printer  
043D:0015=InkJet Color Printer  
043D:0016=Lexmark Z12 Color Jetprinter  
043D:0017=Z32 printer  
043D:0018=Z52 Printer  
043D:0019=Forms Printer

043D:001A=Z65 Printer  
043D:001B=InkJet Photo Printer  
043D:001C=Kodak Personal Picture Maker 200 Printer  
043D:001D=InkJet Color Printer  
043D:001E=InkJet Photo Printer  
043D:001F=Kodak Personal Picture Maker 200 Card Reader  
043D:0020=Z51 Printer  
043D:0021=Z33 Printer  
043D:0022=InkJet Color Printer  
043D:0023=Laser Printer  
043D:0024=Laser Printer  
043D:0025=InkJet Color Printer  
043D:0026=InkJet Color Printer  
043D:0027=InkJet Color Printer  
043D:0028=InkJet Color Printer  
043D:0029=Scan Print Copy  
043D:002A=Scan Print Copy  
043D:002B=Scan Print Copy  
043D:002C=Scan Print Copy  
043D:002D=Lexmark X73 MFP Scanner  
043D:002E=Scan Print Copy  
043D:002F=Scan Print Copy  
043D:0030=Scan Print Copy  
043D:0031=Scan Print Copy  
043D:0032=Scan Print Copy  
043D:0033=Scan Print Copy  
043D:0034=Scan Print Copy  
043D:0035=Scan Print Copy  
043D:0036=Scan Print Copy  
043D:0037=Scan Print Copy  
043D:0038=Scan Print Copy  
043D:0039=Scan Print Copy  
043D:003A=Scan Print Copy  
043D:003B=Scan Print Copy  
043D:003C=Scan Print Copy  
043D:003D=X83 Scan/Print/Copy  
043D:003E=Scan Print Copy  
043D:003F=Scan Print Copy  
043D:0040=Scan Print Copy  
043D:0041=Scan Print Copy  
043D:0042=Scan Print Copy  
043D:0043=Scan Print Copy  
043D:0044=Scan Print Copy  
043D:0045=Scan Print Copy  
043D:0046=Scan Print Copy  
043D:0047=Scan Print Copy  
043D:0048=Scan Print Copy  
043D:0049=Scan Print Copy  
043D:004A=Scan Print Copy  
043D:004B=Scan Print Copy  
043D:004C=Scan Print Copy  
043D:004D=Laser Printer  
043D:004E=Laser Printer  
043D:004F=InkJet Color Printer  
043D:0050=InkJet Color Printer  
043D:0051=Laser Printer  
043D:0052=Laser Printer  
043D:0053=InkJet Color Printer  
043D:0054=InkJet Color Printer  
043D:0057=Z35 Printer



043D:0058=Laser Printer  
043D:005A=X63  
043D:005C=InkJet Color Printer  
043D:0060=X74/X75 Scanner  
043D:0061=X74 USB Hub  
043D:0065=X5130  
043D:0069=X74/X75 Printer  
043D:006D=X125  
043D:006E=C510  
043D:0072=X6170 Printer  
043D:0073=InkJet Color Printer  
043D:0078=InkJet Color Printer  
043D:0079=InkJet Color Printer  
043D:007A=USB Hub  
043D:007B=InkJet Color Printer  
043D:007C=Lexmark X1110/X1130/X1140/X1150/X1170/X1180/X1185  
043D:007D=Photo 3150  
043D:008A=4200 Series  
043D:008B=InkJet Color Printer  
043D:008C=to CF/SM/SD/MS Card Reader  
043D:008E=InkJet Color Printer  
043D:008F=Lexmark X422  
043D:0093=X5250  
043D:0095=E220 Printer  
043D:0096=2200 Series  
043D:0097=P6250  
043D:0098=7100 Series  
043D:009E=P910 Series Human Interface Device  
043D:009F=InkJet Color Printer  
043D:00A9=IBM Infoprint 1410 MFP  
043D:00AB=InkJet Color Printer  
043D:00B2=3300 Series  
043D:00B8=7300 Series  
043D:00B9=8300 Series  
043D:00BA=InkJet Color Printer  
043D:00BB=2300 Series  
043D:00BD=Printing Support  
043D:00BE=Printing Support  
043D:00BF=Printing Support  
043D:00C0=6300 Series  
043D:00C1=4300 Series  
043D:00C7=Printing Support  
043D:00C8=Printing Support  
043D:00C9=Printing Support  
043D:00CB=Printing Support  
043D:00CC=E120 (n)  
043D:00D0=9300 Series  
043D:00D3=Lexmark X340 Scanner  
043D:00D4=Lexmark X342n Scanner  
043D:00D5=Printing Support  
043D:00D6=Lexmark X340 Scanner  
043D:00E8=Lexmark X642e  
043D:00E9=2400 Series  
043D:00F6=3400 Series  
043D:00F7=InkJet Color Printer  
043D:00FF=InkJet Color Printer  
043D:010B=2500 Series  
043D:010D=Lexmark 3500-4500 Series  
043D:010F=6500 Series  
043D:0114=Lexmark X940e/X945e

043D:0120=Lexmark X543/X544  
043D:0121=Lexmark X543/X544  
043D:012F=Lexmark X940e/X945e  
043D:0142=X3650 (Printer, Scanner, Copier)  
043D:014C=Lexmark X650 Series  
043D:014D=Lexmark X650 Series  
043D:014E=Lexmark X650 Series  
043D:019B=Lexmark X650 Series  
043D:019C=Lexmark X650 Series  
043D:4303=Xerox WorkCentre Pro 412  
043E=LG Electronics USA  
043E:3001=AN-WF100 802.11abgn Wireless Adapter [Broadcom BCM4323]  
043E:42BD=Flatron 795FT Plus Monitor  
043E:4A4D=Flatron 915FT Plus Monitor  
043E:7001=MF-PD100 Soul Digital MP3 Player  
043E:7013=MP3 Player  
043E:8484=LPC-U30 Webcam II  
043E:8585=LPC-UC35 Webcam  
043E:8888=Electronics VCS Camera II (LPC-U20)  
043E:9800=Remote Control Receiver\_iMON  
043E:9803=eHome Infrared Receiver (USBCIR)  
043E:9804=DMB Receiver Control  
043E:9C01=LGE Sync  
043E:9C03=LGE USB Sync  
043F=RadiSys  
0440=NANAO  
0441=Winbond Systems  
0441:1456=USB Hub  
0442=Ericsson  
0442:ABBA=ERICSSON Bluetooth Device  
0443=Gateway 2000  
0443:000E=Multimedia Keyboard  
0443:002E=Millennium Keyboard  
0445=Lucent Technologies  
0446=NMB Technologies  
0446:6781=NMB USB Keyboard with PS/2 Mouse Port  
0446:6781:01=NMB USB Keyboard Mouse  
0446:6782=NMB USB Keyboard  
0447=Momentum Microsystems  
044A=Shamrock Tech  
044B=WSI  
044C=CCL/ITRI  
044D=Siemens Nixdorf  
044E=Alps Electric  
044E:1104=ALPS Japanese USB Keyboard  
044E:2002=MD-5500 Printer  
044E:2014=Sony Bluetooth Device  
044E:3001=UGTZ4 Bluetooth  
044E:3002=Bluetooth Device  
044E:3003=Bluetooth Devices  
044E:3004=Bluetooth Adapter  
044E:3005=ALPS Integrated Bluetooth Device  
044E:3006=Bluetooth Adapter  
044E:3007=ALPS Bluetooth Device  
044E:300A=Sony Bluetooth USB Adapter  
044E:300C=Bluetooth USB Controller (ALPS/UGPZ6)  
044E:300D=Bluetooth USB Controller (ALPS/UGPZ6)  
044E:3010=ALPS-UGPZ9-BCM2046  
044E:3012=USB Human Interface Device  
044E:3013=USB Human Interface Device

044E:3014=Sony Alps Device in Firmware Upgrade  
044E:3017=ALPS-UGPZ9-BCM2046  
044E:301A=Bluetooth USB Controller (ALPS/UGPZ9)  
044E:301B=ALPS-UGPZ9-BCM2046  
044E:301D=Broadcom Bluetooth 2.1 + EDR USB Device  
044E:FFFF=Compaq Bluetooth Multiport Firmware Upgrade Module  
044F=ThrustMaster  
044F:0400=HOTAS Cougar  
044F:A003=ThrustMaster Rage 3D USB Game Pad  
044F:A01B=NEC PK-GP301 Driving Wheel  
044F:A0A0=Thrustmaster Top Gun USB Joystick  
044F:A0A1=ThrustMaster Top Gun USB Joystick (rev2)  
044F:A0A3=Fusion Digital GamePad  
044F:A201=NEC PK-GP201 PlayStick  
044F:B10A=T.16000M Joystick  
044F:B203=360 Modena Pro Wheel  
044F:B300=Firestorm Dual Power  
044F:B304=Firestorm Dual Power  
044F:B307=vibrating Upad  
044F:B30B=Wireless VibrationPad  
044F:B323=Dual Trigger 3-in-1 (PC Mode)  
044F:B324=Dual Trigger 3-in-1 (PS3 Mode)  
044F:B603=force feedback Wheel  
044F:B605=force feedback Racing Wheel  
044F:B651=Ferrari GT Rumble Force Wheel  
044F:B653=RGT Force Feedback Clutch Racing Wheel  
044F:B654=Ferrari GT Force Feedback Wheel  
044F:B700=Tacticalboard  
0450=DFI  
0451=Texas Instruments  
0451:1234=TI Mistral Bluetooth Device  
0451:1428=USB Hub  
0451:1446=General Purpose USB Hub  
0451:16A6=BM-USBD1 BlueRobin RF heart rate sensor receiver  
0451:2036=Dazzle Fusion USB Hub  
0451:2046=USB V1.0 4-Port Hub  
0451:2046:0125=USB V1.1 4-Port Hub  
0451:2077=TUSB2077 USB Hub  
0451:3410=TUSB3410 Microcontroller  
0451:341A=Nokia Connectivity Adapter Cable DKU-5  
0451:3F00=OMAP1610  
0451:3F02=SMC WSKP100 Wi-Fi Phone  
0451:5409=Frontier Labs NEX IA+ Digital Audio Player  
0451:6000=AU5 ADSL Modem (pre-reenum)  
0451:6001=AU5 ADSL Modem  
0451:6060=RNDIS/BeWAN ADSL2+  
0451:6070=RNDIS/BeWAN ADSL2+  
0451:625F=Trekstor USB-Stick 12 CS-D 12 GB  
0451:D000=OMAP2420 USB device  
0451:D003=OMAPV1030 USB device  
0451:D004=LOCOSTO USB device  
0451:D006=OMAP2430 USB device  
0451:D008=OMAPV1230 USB device  
0451:D009=OMAP3430 USB device  
0451:D00B=OMAPV1035 USB device  
0451:DBC0=TI Device Bay Controller  
0451:DBC0:0100=TI Device Bay Controller  
0451:E001=GraphLink  
0451:E003=TI-84 Plus Calculator  
0451:E004=TI-89 Titanium Calculator

0451:E008=TI-84 Plus Silver Calculator  
0451:E009=TI Educational Handheld Device  
0451:E00A=TI Educational Handheld Device  
0451:E00B=TI Educational Handheld Device  
0451:E00C=TI Educational Handheld Device  
0451:E00D=TI Educational Handheld Device  
0451:F430=MSP-FET430UIF JTAG Tool  
0451:F432=MSP-eZ430U USB Tool  
0451:FFFF=TI Mistral Bluetooth Device  
0452=Mitsubishi Electronics America  
0452:0021=Mitsubishi HID Monitor Controls  
0452:0021:02=Mitsubishi USB Monitor  
0452:0050=Diamond Pro 900u CRT Monitor  
0452:0051=Integrated USB Hub  
0453=CMD Technology  
0453:6781=NMB USB Keyboard  
0453:6783=Chicony USB Composite Keyboard  
0454=Vobis Microcomputer AG  
0455=Telematics International  
0456=Analog Devices  
0456:F000=FT2232 JTAG ICE [gnICE]  
0456:F001=FT2232H Hi-Speed JTAG ICE [gnICE+]  
0457=Silicon Integrated Systems  
0457:0150=Super Talent 1GB Flash Drive  
0457:0151=Super Flash 1GB Flash Drive  
0457:0162=802.11b USB Wireless LAN Adapter  
0457:0163=802.11b/g USB Wireless LAN Adapter  
0457:5401=Wireless USB Adapter RO80211GS-USB  
0458=Genius  
0458:0001=Genius USB Mouse  
0458:0001:01=Genius USB Mouse  
0458:0002=Genius USB Net Mouse Pro  
0458:0002:01=Genius USB Net Mouse Pro  
0458:0003=Genius USB Wheel Mouse  
0458:0003:01=Genius USB Wheel Mouse  
0458:0006=Easy Mouse+ USB(USB\Vid\_0458&Pid;\_0006) Mouse  
0458:0007=USB Scroll Mouse  
0458:0008=USB Scroll Mouse  
0458:000B=USB Scroll Mouse  
0458:000C=TACOMA Fingerprint V1.06.01  
0458:000E=NetScroll Optical Mouse  
0458:0013=TACOMA Fingerprint Mouse V1.06.01  
0458:0017=USB Scroll Mouse  
0458:0018=PowerScroll/WebScroll+ Series USB Mouse  
0458:0019=Genius EasyTrack Optical Mouse  
0458:001A=Genius WebScroll+  
0458:001B=NetScroll+ Eye Mouse  
0458:001C=NetScroll+ NB Mouser  
0458:001D=NetScroll+ NB Eye Mouse  
0458:001F=USB Scroll Mouse  
0458:0022=Genius Wireless Optical Mouse  
0458:0025=WebScroll+ NB Eye Mouse  
0458:0026=RF WebScroll+ NB Eye Mouse  
0458:0028=Genius PowerScroll NB Eye Mouse  
0458:0029=RF PowerScroll NB Eye Mouse  
0458:002B:01=Wireless TwinTouch+ Optical Value  
0458:002C:01=Wireless TwinTouch Optical Office  
0458:002E=NetScroll+ Traveler  
0458:0031=Genius NetScroll+ Optical Mouse  
0458:0033=Wireless Optical Pro

0458:0034=Wireless NetScroll+ Traveler  
0458:0035=NetScroll  
0458:0036=NetScroll+ Mini Traveler  
0458:0037=NetScroll Eye  
0458:0038=Wireless NetScroll+ Superior  
0458:0039=NetScroll+ Superior  
0458:003A=Scroll Mouse  
0458:003D:01=TwinTouch 16e  
0458:003E=Wireless Mini Navigator  
0458:003F=BT Dongle  
0458:0040:01=Wireless TwinTouch Optical Office KB-12e  
0458:0041:01=TwinTouch 19eNB  
0458:0042=Mini Navigator  
0458:0045=Wireless Navigator  
0458:0046=Wireless Scroll Mouse  
0458:0048:01=TwinTouch LuxeMate  
0458:0049:01=TwinTouch SE  
0458:004A=Navigator  
0458:004C=Slimstar Pro Keyboard  
0458:0056=Ergo 300 Mouse  
0458:0057=Enhanced Gaming Device  
0458:0059=Enhanced Laser Device  
0458:005A=Enhanced Device  
0458:005B=Enhanced Device  
0458:005C=Enhanced Laser Gaming Device  
0458:005D=Enhanced Device  
0458:0061=Broadcom Bluetooth 3.0 USB  
0458:0066=Genius Traveler 1000 Wireless Mouse  
0458:0072=Navigator 335  
0458:0083=Genius Bluetooth USB Dongle Firmware Upgrade  
0458:0087=Ergo 525V Laser Mouse  
0458:0100=EasyPen Tablet  
0458:0101=CueCat  
0458:011B=NetScroll T220  
0458:1001=Genius USB Joystick  
0458:1002=Genius USB Game Pad  
0458:1003=Genius VideoCam  
0458:1004=Flight2000 F-23 Joystick  
0458:1007=MaxFighter Force Feedback F-33D (USB)  
0458:1008=Speed Wheel Force Feedback (USB)  
0458:100A=Aashima Technology Trust Sight Fighter Vibration Feedback Joystick  
0458:2001=ColorPage-Vivid Pro Scanner  
0458:2004=ColorPage-HR6 V1 Scanner  
0458:2005=ColorPage-HR6/Vivid3  
0458:2007=ColorPage-HR6 V2 Scanner  
0458:2008=ColorPage-HR6 V2 Scanner  
0458:2009=ColorPage-HR6A Scanner  
0458:2011=ColorPage-Vivid3x Scanner  
0458:2012=Plustek Scanner  
0458:2013=ColorPage-HR7 Scanner  
0458:2014=ColorPage-Vivid4  
0458:2015=ColorPage-HR7LE Scanner  
0458:2016=ColorPage-HR6X Scanner  
0458:2017=ColorPage-Vivid3xe  
0458:2018=ColorPage-HR7X  
0458:2019=ColorPage-HR6X Slim  
0458:201A=ColorPage-Vivid4xe  
0458:201B=ColorPage-Vivid4x  
0458:201C=ColorPage-HR8  
0458:201D=ColorPage-Vivid 1200 X

0458:201E=ColorPage-Slim 1200  
0458:201F=ColorPage-Vivid 1200 XE  
0458:2020=ColorPage-Slim 1200 USB2  
0458:2021=ColorPage-SF600  
0458:3017=SPEED WHEEL 3 Vibration  
0458:3018=Wireless 2.4Ghz Game Pad  
0458:3019=10-Button USB Joystick with Vibration  
0458:301A=MaxFire G-12U Vibration  
0458:301D=Genius MaxFire MiniPad  
0458:400F=Genius TVGo DVB-T02Q MCE  
0458:4012=TVGo DVB-T03  
0458:5003=G-pen 560 Tablet  
0458:5004=G-pen Tablet  
0458:6001=GF3000F Ethernet Adapter  
0458:7004=VideoCAM Express  
0458:7006=Dsc 1.3 Smart Camera Device  
0458:7007=VideoCAM Web  
0458:7009=G-Shot G312 Still Camera Device  
0458:700C=VideoCAM Web V3  
0458:700D=G-Shot G511 Composite Device  
0458:700F=VideoCAM Web  
0458:7012=WebCAM USB2.0  
0458:7014=VideoCAM Live V3  
0458:701C=G-Shot G512 Still Camera  
0458:7020=Sim 321C  
0458:7025=Eye 311Q Camera Device  
0458:7029=Genius Look 320s (SN9C201 + HV7131R)  
0458:702F=Genius Slim 322  
0458:7035=i-Look 325T Camera  
0458:7045=Genius Look 1320 V2  
0458:704C=Genius i-Look 1321  
0458:704D=Slim 1322AF  
0458:7055=Slim 2020AF camera  
0458:705A=Asus USB2.0 Webcam  
0458:705C=Genius iSlim 1300AF  
0458:7079=FaceCam 2025R  
0459=Adobe Systems  
045A=Diamond Multimedia Systems  
045A:07DA=Diamond USB Modem  
045A:07DA:0100=Diamond SupraExpress 56k v.90  
045A:0B4A=Diamond SupraMax 56K USB modem  
045A:0B68=SupraMax 56K Modem  
045A:5001=Rio600 Digital Audio Player  
045A:5002=Rio800 Digital Audio Player  
045A:5003=nike psa[play digital audio player  
045A:5005=Rio S10 MP3 Player  
045A:5006=Rio S50 MP3 Player  
045A:5007=Rio S35 MP3 Player  
045A:5008=Rio 900 MP3 Player  
045A:5009=Rio S30 MP3 Player  
045A:500D=Fuse MP3 Player  
045A:500E=Chiba MP3 Player  
045A:500F=Cali MP3 Player  
045A:5010=Rio S11 MP3 Player  
045A:501C=Virgin MPF-1000  
045A:501D=Rio Fuse  
045A:501E=Rio Chiba  
045A:501F=Rio Cali  
045A:503F=Cali256 MP3 Player  
045A:5202=Rio Riot MP3 Player

045A:5210=Rio Karma Music Player  
045A:5220=Rio Nitrus MP3 Player  
045A:5221=Rio Eigen  
045B=Hitachi  
045D=Northern Telecom  
045E=Microsoft  
045E:0007=SideWinder Game Pad USB version 1.0  
045E:0008=Microsoft SideWinder Precision Pro (USB)  
045E:0009=Microsoft USB IntelliMouse (IntelliPoint)  
045E:000B=Microsoft USB Natural?Keyboard  
045E:000E=Microsoft SideWinder?Freestyle Pro (USB)  
045E:0014=Microsoft Digital Sound System 80  
045E:0014:02=Microsoft Digital Sound System 80 HID Audio Controls  
045E:001A=Microsoft SideWinder?Precision Racing Wheel  
045E:001B=Microsoft SideWinder?Force Feedback 2  
045E:001C=Microsoft Integrated USB Hub  
045E:001D=Microsoft Natural?Keyboard Pro  
045E:001D:01=Microsoft Natural?Keyboard Pro Hot Keys  
045E:001D:0111=Microsoft Natural?Keyboard Pro Model RT9401  
045E:001D:0111:01=Microsoft Natural?Keyboard Pro Model RT9401 Hot Keys  
045E:001E=Microsoft USB IntelliMouse Explorer (IntelliPoint)  
045E:0023=Microsoft USB Trackball Optical (IntelliPoint)  
045E:0024=Microsoft USB Trackball Explorer (IntelliPoint)  
045E:0025=Microsoft USB IntelliMouse with IntelliEye  
045E:0026=Microsoft SideWinder?Game Pad Pro  
045E:0027=Microsoft SideWinder?Plug and Play Game Pad  
045E:0028=Microsoft SideWinder?Dual Strike  
045E:0029=Microsoft SideWinder?Precision Racing Wheel  
045E:002B=Microsoft Internet Keyboard Pro  
045E:002B:01=Microsoft Internet Keyboard Pro Hot Keys  
045E:002D=Microsoft Internet Keyboard  
045E:002D:01=Microsoft Keyboard Hot Keys  
045E:002D:0100=Microsoft Internet Keyboard  
045E:002D:0100:01=Microsoft Internet Keyboard Hot Keys  
045E:002F=Microsoft Integrated USB Hub  
045E:0033=Microsoft SideWinder?Strategic Commander  
045E:0034=Microsoft SideWinder?Force Feedback Wheel (USB)  
045E:0038=Microsoft SideWinder?Precision 2  
045E:0039=Microsoft USB 5-Button Mouse with IntelliEye?  
045E:003B=SideWinder Game Voice  
045E:003C=SideWinder Joystick  
045E:0040=Microsoft USB 3-Button Mouse with IntelliEye?  
045E:0040:0300=Microsoft USB 3-Button Mouse with IntelliEye?V1.1A  
045E:0047=Microsoft USB 5-Button Mouse with IntelliEye?  
045E:0048=Microsoft Office Keyboard (USB)  
045E:0048:01=Microsoft Office Keyboard Hot Keys (USB)  
045E:0053=Microsoft USB Optical Mouse (IntelliPoint)  
045E:0059=Microsoft USB Wireless IntelliMouse Explorer (IntelliPoint)  
045E:005C=Microsoft USB Office Keyboard (106/109)  
045E:005C:01=Microsoft Office Keyboard Hot Keys (USB) (106/109)  
045E:005F=Microsoft Wireless MultiMedia Keyboard (USB)  
045E:005F:01=Microsoft USB Wireless Optical Mouse (IntelliPoint)  
045E:0061=Microsoft Wireless MultiMedia Keyboard (USB) (106/109)  
045E:0061:01=Microsoft USB Wireless Optical Mouse (IntelliPoint)  
045E:0063=Microsoft Wireless Natural MultiMedia Keyboard (USB)  
045E:0063:01=Microsoft USB Wireless Optical Mouse (IntelliPoint)  
045E:0065=Microsoft Wireless Natural MultiMedia Keyboard (USB) (106/109)  
045E:0065:01=Microsoft USB Wireless Optical Mouse (IntelliPoint)  
045E:006A=Microsoft USB Wireless Optical Mouse (IntelliPoint)  
045E:006A:0017=Microsoft Wireless IntelliPoint Optical Mouse 1.0A

045E:006D=Microsoft eHome MCIR 109 Keyboard  
045E:006E=MN510 802.11b Adapter  
045E:006F=Microsoft Smart Display Reference Device  
045E:0070=Microsoft Wireless MultiMedia Keyboard (USB)  
045E:0070:01=Microsoft USB Wireless IntelliMouse Explorer (IntelliPoint)  
045E:0071=Microsoft Wireless MultiMedia Keyboard (USB) (106/109)  
045E:0071:01=Microsoft USB Wireless IntelliMouse Explorer (IntelliPoint)  
045E:0072=Microsoft Wireless Natural MultiMedia Keyboard (USB)  
045E:0072:01=Microsoft USB Wireless IntelliMouse Explorer (IntelliPoint)  
045E:0073=Microsoft Wireless Natural MultiMedia Keyboard (USB) (106/109)  
045E:0073:01=Microsoft USB Wireless IntelliMouse Explorer (IntelliPoint)  
045E:0079=IXI Ogo CT-17 handheld device  
045E:007A=10/100 USB NIC  
045E:007D=Microsoft USB 3-Button Mouse with IntelliEye?  
045E:007E=Microsoft Wireless Transceiver for Bluetooth  
045E:0080=Digital Media Pro Keyboard  
045E:0083=Microsoft USB Basic Optical Mouse (IntelliPoint)  
045E:0084=Microsoft USB Basic Optical Mouse (IntelliPoint)  
045E:0089=Microsoft Basic Keyboard (106/109)  
045E:008A=Microsoft USB Dual Receiver Wireless Mouse (IntelliPoint)  
045E:008B=Microsoft USB Dual Receiver Wireless Keyboard (106/109)  
045E:008C=Microsoft USB Wireless Mouse (IntelliPoint)  
045E:0095=Microsoft USB IntelliMouse Explorer 4.0 (IntelliPoint)  
045E:009C=Bluetooth Wireless Radio (Broadcom)  
045E:009D=Microsoft USB Dual Receiver Wireless Mouse (IntelliPoint)  
045E:009D:01=HID Non-User Input Data Filter  
045E:009E=Microsoft USB Dual Receiver Wireless Keyboard (106/109)  
045E:009E:01=HID Non-User Input Data Filter  
045E:009F=Microsoft USB Wireless Mouse (IntelliPoint)  
045E:00A0=eHome Infrared Receiver (USBCIR)  
045E:00A4=Microsoft USB Compact Optical Mouse (IntelliPoint)  
045E:00AC=Microsoft USB MultiMedia Keyboard (IntelliType Pro)  
045E:00AD=Microsoft MultiMedia Keyboard (106/109)  
045E:00AF=Microsoft Natural MultiMedia Keyboard (106/109)  
045E:00B0=Microsoft USB Digital Media Pro Keyboard (IntelliType Pro)  
045E:00B1=Microsoft USB Digital Media Pro Keyboard (106/109) (IntelliType Pro)  
045E:00B4=Microsoft USB Digital Media Keyboard (IntelliType Pro)  
045E:00B5=Microsoft USB Digital Media Keyboard (106/109) (IntelliType Pro)  
045E:00B8=Microsoft USB Optical Mouse by Starck (IntelliPoint)  
045E:00B9=Microsoft USB Wireless Mouse (IntelliPoint)  
045E:00BB=Microsoft USB Keyboard with Fingerprint Reader (IntelliType Pro)  
045E:00BB:02=Microsoft Fingerprint Reader  
045E:00BC=Microsoft USB Keyboard with Fingerprint Reader (106/109) (IntelliType Pro)  
045E:00BC:02=Microsoft Fingerprint Reader  
045E:00BD=Fingerprint Reader  
045E:00C2=Wireless Adapter MN-710  
045E:00C9=Appareil mobile MTP  
045E:00CA=Fingerprint Reader  
045E:00CB=Basic Optical Mouse v2.0  
045E:00CE=Microsoft USB Sync  
045E:00D1=Microsoft USB Comfort Optical Mouse 3000 (IntelliPoint)  
045E:00D2=Microsoft USB Notebook Optical Mouse 3000 (IntelliPoint)  
045E:00DA=eHome Infrared Receiver (USBCIR)  
045E:00DB=Microsoft USB Natural Ergonomic Keyboard 4000 (IntelliType Pro)  
045E:00DC=Microsoft USB Natural Ergonomic Keyboard 4000 (106/109) (IntelliType Pro)  
045E:00DD=Microsoft USB Comfort Curve Keyboard 2000 (IntelliType Pro)  
045E:00DE=Microsoft USB Comfort Curve Keyboard 2000 (106/109) (IntelliType Pro)  
045E:00E0=Microsoft USB Comfort Curve Keyboard 2000 (106/109)



045E:00E1=Microsoft Wireless Optical Mouse V1.0  
045E:00E1:0007=Microsoft Wireless Optical Mouse 2000  
045E:00E3=Microsoft Mouse and Keyboard Detection Driver (USB)  
045E:00E3:01=HID Non-User Input Data Filter  
045E:00E4=Microsoft USB Dual Receiver Wireless Keyboard (106/109)  
045E:00E4:01=HID Non-User Input Data Filter  
045E:00E5=HID Non-User Input Data Filter  
045E:00F0=Microsoft USB Laser Mouse 6000 (IntelliPoint)  
045E:00F1=Microsoft Mouse and Keyboard Detection Driver (USB)  
045E:00F1:01=HID Non-User Input Data Filter  
045E:00F2=Microsoft USB Dual Receiver Wireless Keyboard (106/109)  
045E:00F2:01=HID Non-User Input Data Filter  
045E:00F4=LifeCam VX-6000 (SN9C20x + OV9650)  
045E:00F4:01=Microsoft LifeCam VX-6000.  
045E:00F5=LifeCam VX-3000  
045E:00F5:01=Microsoft LifeCam VX-3000.  
045E:00F6=Microsoft USB Comfort Optical Mouse 1000 (IntelliPoint)  
045E:00F7=LifeCam VX-1000  
045E:00F7:01=Microsoft LifeCam VX-1000.  
045E:00F8=LifeCam NX-6000  
045E:00F8:02=Microsoft LifeCam NX-6000.  
045E:00F9=Wireless Desktop Receiver  
045E:00F9:01=HID Non-User Input Data Filter  
045E:00FA=Microsoft USB Dual Receiver Wireless Keyboard (106/109)  
045E:00FA:01=HID Non-User Input Data Filter  
045E:00FD=Microsoft Reclusa (106/109)  
045E:0202=Xbox Controller  
045E:0280=XBox Device  
045E:0283=Xbox Communicator  
045E:0284=Xbox DVD Playback Kit  
045E:0285=Xbox Controller S  
045E:0288=Xbox Controller S USB Hub  
045E:0289=Xbox Controller S  
045E:028B=Xbox360 DVD Emulator  
045E:028D=Xbox360 Memory Unit 64MB  
045E:028E=XBOX 360 Controller For Windows  
045E:028F=Xbox360 Wireless Controller  
045E:0290=Xbox360 Performance Pipe (PIX)  
045E:0291=Xbox 360 Wireless Receiver for Windows  
045E:0292=Xbox360 Wireless Networking Adapter  
045E:029C=Xbox360 HD-DVD Drive  
045E:029D=Xbox360 HD-DVD Drive  
045E:029E=Xbox360 HD-DVD Memory Unit  
045E:02A0=Xbox360 Big Button IR  
045E:02A8=Xbox360 Wireless N Networking Adapter [Atheros AR7010]  
045E:02AD=Xbox NUI Audio  
045E:02AE=Xbox NUI Camera  
045E:02B0=Xbox NUI Motor  
045E:0400=Windows Powered Pocket PC 2002  
045E:0401=Windows Powered Pocket PC 2002  
045E:0402=Windows Powered Pocket PC 2002  
045E:0403=Windows Powered Pocket PC 2002  
045E:0404=Windows Powered Pocket PC 2002  
045E:0405=Windows Powered Pocket PC 2002  
045E:0406=Windows Powered Pocket PC 2002  
045E:0407=Windows Powered Pocket PC 2002  
045E:0408=Windows Powered Pocket PC 2002  
045E:0409=Windows Powered Pocket PC 2002  
045E:040A=Windows Powered Pocket PC 2002  
045E:040B=Windows Powered Pocket PC 2002



045E:0462=Windows Powered Pocket PC 2003  
045E:0463=Windows Powered Pocket PC 2003  
045E:0464=Windows Powered Pocket PC 2003  
045E:0465=Windows Powered Pocket PC 2003  
045E:0466=Windows Powered Pocket PC 2003  
045E:0467=Windows Powered Pocket PC 2003  
045E:0468=Windows Powered Pocket PC 2003  
045E:0469=Windows Powered Pocket PC 2003  
045E:046A=Windows Powered Pocket PC 2003  
045E:046B=Windows Powered Pocket PC 2003  
045E:046C=Windows Powered Pocket PC 2003  
045E:046D=Windows Powered Pocket PC 2003  
045E:046E=Windows Powered Pocket PC 2003  
045E:046F=Windows Powered Pocket PC 2003  
045E:0470=Windows Powered Pocket PC 2003  
045E:0471=Windows Powered Pocket PC 2003  
045E:0472=Windows Powered Pocket PC 2003  
045E:0473=Windows Powered Pocket PC 2003  
045E:0474=Windows Powered Pocket PC 2003  
045E:0475=Windows Powered Pocket PC 2003  
045E:0476=Windows Powered Pocket PC 2003  
045E:0477=Windows Powered Pocket PC 2003  
045E:0478=Windows Powered Pocket PC 2003  
045E:0479=Windows Powered Pocket PC 2003  
045E:047A=Windows Powered Pocket PC 2003  
045E:047B=Windows Powered Pocket PC 2003  
045E:04C8=Windows Powered Smartphone 2002  
045E:04C9=Windows Powered Smartphone 2002  
045E:04CA=Windows Powered Smartphone 2002  
045E:04CB=Windows Powered Smartphone 2002  
045E:04CC=Windows Powered Smartphone 2002  
045E:04CD=Windows Powered Smartphone 2002  
045E:04CE=Windows Powered Smartphone 2002  
045E:04D7=Windows Powered Smartphone 2003  
045E:04D8=Windows Powered Smartphone 2003  
045E:04D9=Windows Powered Smartphone 2003  
045E:04DA=Windows Powered Smartphone 2003  
045E:04DB=Windows Powered Smartphone 2003  
045E:04DC=Windows Powered Smartphone 2003  
045E:04DD=Windows Powered Smartphone 2003  
045E:04DE=Windows Powered Smartphone 2003  
045E:04DF=Windows Powered Smartphone 2003  
045E:04E0=Windows Powered Smartphone 2003  
045E:04E1=Windows Powered Smartphone 2003  
045E:04E2=Windows Powered Smartphone 2003  
045E:04E3=Windows Powered Smartphone 2003  
045E:04E4=Windows Powered Smartphone 2003  
045E:04E5=Windows Powered Smartphone 2003  
045E:04E6=Windows Powered Smartphone 2003  
045E:04E7=Windows Powered Smartphone 2003  
045E:04E8=Windows Powered Smartphone 2003  
045E:04E9=Windows Powered Smartphone 2003  
045E:04EA=Windows Powered Smartphone 2003  
045E:04EC=Windows Phone (Zune)  
045E:063E=Zune HD Media Player  
045E:0640=KIN Phone  
045E:0641=KIN Phone  
045E:0642=KIN Phone  
045E:0707=Wireless Laser Mouse 8000  
045E:0708=Microsoft Wireless Transceiver for Bluetooth v3.0

045E:070A=Microsoft Charon Bluetooth Dongle (DFU)  
045E:070D:03=Microsoft RoundTable Panoramic Video  
045E:070D:05=Microsoft RoundTable Active Speaker Video  
045E:0710=Zune Media Player  
045E:0713=Microsoft Wireless Notebook Presenter Mouse 8000 (IntelliPoint)  
045E:0714=Microsoft Wireless Laser Mouse 8000 (IntelliPoint)  
045E:0715=Microsoft Wireless Entertainment Keyboard 8000 (IntelliType Pro)  
045E:0716=Microsoft Wireless Entertainment Keyboard 8000 (106/109) (IntelliType Pro)  
045E:0717=Microsoft Wireless Entertainment Keyboard 7000 (IntelliType Pro)  
045E:0718=Microsoft Wireless Entertainment Keyboard 7000 (106/109) (IntelliType Pro)  
045E:0719=Xbox 360 Wireless Receiver for Windows  
045E:071D=Microsoft Mouse and Keyboard Detection Driver (USB)  
045E:071D:01=Microsoft USB Dual Receiver Wireless Mouse (IntelliPoint)  
045E:071E=Microsoft USB Dual Receiver Wireless Keyboard (106/109)  
045E:071E:01=Microsoft USB Dual Receiver Wireless Mouse (IntelliPoint)  
045E:071F=Microsoft USB Wireless Mouse (IntelliPoint)  
045E:0721=LifeCam NX-3000 (UVC-compliant)  
045E:0721:02=Microsoft LifeCam NX-3000.  
045E:0723=LifeCam VX-7000 (UVC-compliant)  
045E:0723:02=Microsoft LifeCam VX-7000.  
045E:0724=Microsoft SideWinder Mouse (IntelliPoint)  
045E:0727=Microsoft Mobile Memory Mouse 8000 (IntelliPoint)  
045E:0730=Microsoft Digital Media Keyboard 3000 (IntelliType Pro)  
045E:0731=Microsoft Digital Media Keyboard 3000 (106/109)  
045E:0732=Microsoft Digital Media Keyboard 3000 (IntelliType Pro)  
045E:0733=Microsoft Digital Media Keyboard 3000 (106/109)  
045E:0734=Wireless Optical Desktop 700  
045E:0735=Microsoft Wireless Keyboard 700 v2.0 (106/109)  
045E:0736=Microsoft SideWinder X5 Mouse (IntelliPoint)  
045E:0737=Microsoft Compact Optical Mouse 500 v2.0 (IntelliPoint)  
045E:0745=Microsoft USB Wireless Mouse (IntelliPoint)  
045E:0746=Microsoft USB Dual Receiver Wireless Keyboard (106/109)  
045E:0748=Microsoft USB Wireless Mouse (IntelliPoint)  
045E:074B=Microsoft SideWinder X6 Keyboard (IntelliType Pro)  
045E:074C=Microsoft SideWinder X6 Keyboard (106/109)  
045E:074F=Microsoft Arc Mouse (IntelliPoint)  
045E:0750=Microsoft Wired Keyboard 600 (IntelliType Pro)  
045E:0751=Microsoft Wired Keyboard 600 (106/109)  
045E:0752=Microsoft Wired Keyboard 400 (IntelliType Pro)  
045E:0753=Microsoft Wired Keyboard 400 (106/109)  
045E:075C=Microsoft SideWinder X3 Mouse (IntelliPoint)  
045E:075D=LifeCam Cinema  
045E:0768=Microsoft SideWinder X4 Keyboard (IntelliType Pro)  
045E:0769=Microsoft SideWinder X4 Keyboard (106/109) (IntelliType Pro)  
045E:076C=Microsoft Comfort Mouse 4500 (IntelliPoint)  
045E:076D=LifeCam HD-5000  
045E:0773=Microsoft Mouse and Keyboard Detection Driver (USB)  
045E:0774=Microsoft Mouse and Keyboard Detection Driver (USB)  
045E:3500=Bluetooth Wireless Radio USB HUB  
045E:930A=ISOUSB.SYS Intel 82930 USB Isochronous IO Test Board  
045E:FFF8=Microsoft USB Keyboard  
045E:FFFF=Bluetooth Devices  
0460=Ace Cad Enterprise  
0460:0004=Tablet (5x3.75)  
0460:0006=LCD Tablet (12x9)  
0460:0008=Tablet (3x2.25)  
0461=Primax Electronics  
0461:0300=G2-300 Scanner

0461:0301=G2E-300 Scanner  
0461:0302=G2-300 #2 Scanner  
0461:0303=G2E-300 #2 Scanner  
0461:0340=Colorado 9600 Scanner  
0461:0341=Colorado 600u Scanner  
0461:0345=Vioneer 6200 Scanner  
0461:0346=Memorex Maxx 6136u Scanner  
0461:0347=VistaScan Astra 3600 (ENG)  
0461:0360=Colorado USB 19200  
0461:0361=Colorado 1200u Scanner  
0461:0363=VistaScan Astra 3600 (ENG)  
0461:0364=LG Electronics Scanworks 600U Scanner  
0461:0365=VistaScan Astra 3600 (ENG)  
0461:0366=Vioneer 6400 USB  
0461:0367=VistaScan Astra 3600 (ENG)  
0461:0371=VistaScan Astra 3600 (ENG)  
0461:0374=VistaScan Astra 3600 (ENG)  
0461:0375=VistaScan Astra 3600 (ENG)  
0461:0377=VistaScan Astra 3600 (ENG)  
0461:0378=VistaScan Astra 3600 (ENG)  
0461:037B=VistaScan Astra 3600 (ENG)  
0461:037C=VistaScan Astra 3600 (ENG)  
0461:0380=G2-600 Scanner  
0461:0381=ReadyScan 636i Scanner  
0461:0382=G2-600 #2 Scanner  
0461:0383=G2E-600 Scanner  
0461:038A=VistaScan Astra 3600 (ENG)  
0461:038B=Xerox 2400 Onetouch  
0461:038C=UMAX Astra 4100  
0461:0392=Medion/Lifetec/Tevion/Cytron MD 6190  
0461:03A8=9420M  
0461:0813=IBM UltraPort Camera  
0461:0815=Micro Innovations WebCam  
0461:0819=Fujifilm IX-30 Camera [webcam mode]  
0461:081A=Fujifilm IX-30 Camera  
0461:081C=Elitegroup ECS-C11 Camera  
0461:081D=Elitegroup ECS-C11 Storage  
0461:0823=Digital Camera  
0461:0824=Digital Camera - MSD  
0461:0827=Digital Camera  
0461:0A00=Micro Innovations Web Cam 320  
0461:4D01=Aspire USB Mouse  
0461:4D02=Mouse-in-a-Box  
0461:4D03=Kensington Mouse-in-a-box  
0461:4D04=Mouse  
0461:4D04:01=Sony USB Mouse (HID)  
0461:4D06=Ballless Mouse (HID)  
0461:4D15=USB Mouse  
0461:4D17=Optical Mouse  
0461:4D20=HP Optical Mouse  
0461:4D2A=PoPo Elixir Mouse (HID)  
0461:4D2B=Wireless Laser Mini Mouse (HID)  
0461:4D2C=PoPo Mini Pointer Mouse (HID)  
0461:4D2E=Optical Mobile Mouse (HID)  
0461:4D51=DELL Laser Mouse  
0461:4D62=HP Laser Mobile Mouse (HID)  
0461:4D6A=Generic Bluetooth Adaptor  
0461:4D75=Rocketfish Bluetooth Adapter  
0461:4DE7=webcam  
0463=MGE Systems

0463:0001=MGE USB UPS  
0463:FFFF=MGE USB UPS  
0464=AMP  
0467=AT&T Paradyne  
0468=Wieson Electronic  
046A=CHERRY GmbH  
046A:0001=Cherry GmbH USB Keyboard  
046A:0003=Cherry GmbH USB Hub  
046A:0004=USB Cherry CyBo@rd Keyboard  
046A:0004:01=USB Cherry CyBo@rd Hot Keys  
046A:0005=XX33 SmartCard Reader Keyboard  
046A:0005:01=SmartBoardXX33  
046A:0008=Wireless Keyboard and Mouse  
046A:0010=SmartBoard XX44  
046A:0010:01=SmartBoard XX44  
046A:0011=G83 (RS 6000) Keyboard  
046A:0021=CyMotion Expert Combo  
046A:0023=Cymotion Master Linux Keyboard  
046A:0023:01=Cymotion Master Linux Hot-Keys  
046A:0027=CyMotion Master Solar Keyboard  
046A:0027:01=CyMotion Master Solar Hot-Keys  
046A:002A=Wireless Mouse & Keyboard  
046A:002D=SmartTerminal XX44  
046A:003E=SmartTerminal ST-2xxx  
046A:005A:01=SmartBoard XX33  
046A:0080=eHealth Terminal ST 1503  
046A:0081=eHealth Keyboard G87 1504  
046A:0106=R-300 Wireless Mouse Receiver  
046B=American Megatrends  
046B:0001=Cherry USB Keyboard  
046B:0101=PS/2 Keyboard, Mouse & Joystick Ports  
046B:0301=USB V1.0 Hub  
046B:0500=JDI Serial/Parallel Interface  
046B:0500:02=JDI USB Parallel Port  
046B:FF10=Virtual Keyboard  
046B:FF10:01=Virtual Mouse  
046C=Toshiba  
046D=Logitech  
046D:0082=Acer Aspire 5672 Webcam  
046D:0200=Logitech USB WingMan Extreme Joystick  
046D:0203=M2452 Keyboard  
046D:0301=M4848 Mouse  
046D:0401=HP Pavilion Personal Color Scanner  
046D:0402=NEC PageScan  
046D:040F=Storm Technology - Logitech PageScan USB  
046D:040F:01=Storm Technology - Logitech PageScan USB  
046D:0430=Logitech Mic (Cordless)  
046D:0801=Logitech QuickCam Web (0801)  
046D:0801:01=Logitech Microphone (Web)  
046D:0802=Logitech Mic (Webcam 200)  
046D:0804=Logitech Mic (Webcam 250)  
046D:0805=Logitech Mic (Webcam 300)  
046D:0807=Logitech Mic (Webcam 500)  
046D:0808=Logitech Mic (Webcam 600)  
046D:0809=Logitech Mic (Webcam Pro 9000)  
046D:080A=Logitech Mic (Webcam 905)  
046D:080F=Webcam C120  
046D:0810=QuickCam Pro  
046D:0817=Logitech USB Camera (Webcam 100)  
046D:0819=Webcam C210

046D:081A=Logitech USB Camera (Webcam C260)  
046D:081B=HD Webcam C310  
046D:081D=Logitech USB Camera (HD Webcam C510)  
046D:0820=QuickCam VC  
046D:0821=Logitech USB Camera (HD Pro Webcam C910)  
046D:0823=Logitech USB Camera (B910 HD Webcam)  
046D:0824=Logitech USB Camera (Webcam C160)  
046D:0825=HD Webcam C270  
046D:0826=Logitech USB Camera (HD Webcam C525)  
046D:0828=HD Webcam B990  
046D:0830=QuickClip  
046D:0840=Logitech QuickCam Express  
046D:0850=Logitech QuickCam Web  
046D:0850:01=Logitech Microphone (Web)  
046D:0870=Logitech QuickCam Express  
046D:0890=Logitech QuickCam Traveler (Still Camera)  
046D:0890:01=Logitech QuickCam Traveler (Still Camera)  
046D:0890:02=Logitech Microphone (Traveler)  
046D:0892=Acer OrbiCam  
046D:0894=CrystalCam  
046D:0895=QuickCam for Dell Notebooks  
046D:0896=Acer OrbiCam  
046D:0897=QuickCam for Dell Notebooks  
046D:0899=QuickCam for Dell Notebooks  
046D:089D=Logitech QuickCam E2500  
046D:089D:01=Logitech Mic (QuickCam E2500)  
046D:08A0=QuickCam IM  
046D:08A1=QuickCam IM  
046D:08A1:01=QuickCam Mic (IM)  
046D:08A2=Labtec Mic (WebCam Pro)  
046D:08A3=QuickCam Chat  
046D:08A3:01=QuickCam Chat  
046D:08A6=Logitech QuickCam IM  
046D:08A6:01=Logitech Mic (IM)  
046D:08A7=Logitech QuickCam Image  
046D:08A7:01=Logitech Mic (Image)  
046D:08A9=Logitech QuickCam for Notebooks Deluxe  
046D:08A9:01=Logitech Mic (Notebooks Deluxe)  
046D:08AA=Labtec Notebooks  
046D:08AC=Logitech QuickCam Easy/Cool  
046D:08AD=Logitech QuickCam Communicate STX  
046D:08AD:01=Logitech Mic (Communicate STX)  
046D:08AE=Logitech QuickCam for Notebooks  
046D:08AE:01=Logitech Mic (Notebooks)  
046D:08AF=Logitech QuickCam Easy/Cool  
046D:08B0=Logitech QuickCam Pro 3000 (08B0)  
046D:08B0:01=Logitech Microphone (Pro 3000)  
046D:08B1=Logitech QuickCam for Notebooks Pro  
046D:08B1:01=Logitech Mic (Notebooks Pro)  
046D:08B2=Logitech QuickCam Pro 4000  
046D:08B2:01=Logitech Microphone (Pro 4000)  
046D:08B3=Logitech QuickCam Zoom  
046D:08B3:01=Logitech QuickCam Zoom Control  
046D:08B3:02=Logitech QuickCam Zoom Microphone  
046D:08B4=Logitech QuickCam Zoom  
046D:08B4:01=Logitech Microphone (Zoom)  
046D:08B5=Logitech QuickCam Orbit/Sphere  
046D:08B5:01=Logitech Mic (Orbit/Sphere)  
046D:08B7=Logitech ViewPort AV100  
046D:08B7:01=Logitech Mic (ViewPort AV100)

046D:08B9=Logitech QuickCam IM  
046D:08BD=Logitech QuickCam Pro 4000  
046D:08BD:01=Logicool Microphone (Pro 4000)  
046D:08C0=Logitech QuickCam Pro 3000  
046D:08C0:01=Logitech Microphone (Pro 3000)  
046D:08C1=Logitech QuickCam Fusion  
046D:08C1:01=Logitech Microphone (Fusion)  
046D:08C1:02=Logicool Microphone (Fusion)  
046D:08C2=QuickCam Orbit/Sphere MP  
046D:08C2:01=Logitech Mic (Orbit/Sphere MP)  
046D:08C2:02=Logicool Mic (Orbit/Sphere MP)  
046D:08C3=QuickCam for Notebooks Pro  
046D:08C3:01=Logitech Mic (Notebooks Pro)  
046D:08C3:02=Logicool Mic (Notebooks Pro)  
046D:08C5=Logitech QuickCam Pro 5000  
046D:08C5:01=Logitech Microphone (Pro 5000)  
046D:08C5:02=Logicool Microphone (Pro 5000)  
046D:08C6=QuickCam for Dell Notebooks Mic  
046D:08C6:01=QuickCam for Dell Notebooks Mic  
046D:08C6:02=QuickCam for Dell Notebooks Mic  
046D:08C7=QuickCam OEM Cisco VT Camera II  
046D:08C9=Logitech QuickCam Ultra Vision  
046D:08C9:01=Logitech Mic (Ultra Vision)  
046D:08C9:02=Logicool Mic (Ultra Vision)  
046D:08CA=Logitech QuickCam Fusion  
046D:08CA:01=Logitech Mic (Fusion)  
046D:08CA:02=Logicool Mic (Fusion)  
046D:08CB=Logitech Mic (Notebooks Pro)  
046D:08CB:01=Logitech Mic (Notebooks Pro)  
046D:08CB:02=Logicool Mic (Notebooks Pro)  
046D:08CC=Logitech Mic (Orbit/Sphere MP)  
046D:08CC:01=Logitech Mic (Orbit/Sphere MP)  
046D:08CC:02=Logicool Mic (Orbit/Sphere MP)  
046D:08CE=Logitech QuickCam Pro 5000  
046D:08CE:01=Logitech Mic (Pro 5000)  
046D:08CE:02=Logicool Mic (Pro 5000)  
046D:08CF=Logitech QuickCam UpdateMe  
046D:08D0=Logitech QuickCam Express  
046D:08D4=Logitech Headset (ViewPort AV100)  
046D:08D4:03=HID-Compliant Logitech Camera (ViewPort AV100)  
046D:08D7=Logitech QuickCam Communicate STX  
046D:08D7:01=Logitech Mic (Communicate STX)  
046D:08D8=Logitech Mic (Notebooks Deluxe)  
046D:08D8:01=Logitech Mic (Notebooks Deluxe)  
046D:08D9=Logitech QuickCam IM/Connect  
046D:08D9:01=Logitech Mic (IM/Connect)  
046D:08DA=Logitech QuickCam Messenger  
046D:08DA:01=Logitech Microphone (QuickCam)  
046D:08DD=Logitech QuickCam for Notebooks  
046D:08DD:01=Logitech Mic (Notebooks)  
046D:08E0=Logitech QuickCam Express  
046D:08E1=Labtec WebCam  
046D:08E4=Logitech QuickCam Express  
046D:08F0=Logitech QuickCam Messenger  
046D:08F0:01=Logitech Microphone (Messenger)  
046D:08F1=Logitech QuickCam Express  
046D:08F2=Logitech QuickCam Messenger  
046D:08F3=Logitech QuickCam Express  
046D:08F4=Labtec Webcam  
046D:08F5=Logitech QuickCam Communicate



046D:08F5:01=Logitech Mic (Communicate)  
046D:08F6=Logitech QuickCam Messenger  
046D:0900=Logitech ClickSmart 310 (Digital Camera)  
046D:0900:01=Logitech ClickSmart 310 (Digital Camera)  
046D:0901=Logitech ClickSmart 510 (Digital Camera)  
046D:0901:01=Logitech ClickSmart 510 (Digital Camera)  
046D:0901:02=Logitech Mic (ClickSmart 510)  
046D:0903=Logitech ClickSmart 820 Video (FW Upgrade Mode)  
046D:0903:01=Logitech ClickSmart 820 (FW Upgrade)  
046D:0904=Logitech ClickSmart 820 (Digital Camera)  
046D:0905=Logitech ClickSmart 820  
046D:0905:02=Logitech Mic (ClickSmart 820)  
046D:0910=Logitech QuickCam Cordless  
046D:0910:01=Logitech Microphone (Cordless)  
046D:0920=Logitech QuickCam Express  
046D:0921=Labtec WebCam  
046D:0922=Logitech QuickCam Live  
046D:0928=Logitech QuickCam Express  
046D:0929=Labtec WebCam Pro  
046D:092A=Logitech QuickCam for Notebooks  
046D:092B=Labtec WebCam Plus  
046D:092C=Logitech QuickCam Chat  
046D:092D=Logitech QuickCam Express/Go  
046D:092E=Logitech QuickCam Chat  
046D:092F=Logitech QuickCam Express/Go  
046D:0950=Logitech Pocket Digital  
046D:0950:01=Logitech Pocket Digital  
046D:0951=Logitech Pocket Digital 130  
046D:0960=Logitech ClickSmart 420 (Digital Camera)  
046D:0960:01=Logitech ClickSmart 420 (Digital Camera)  
046D:0960:02=Logitech Mic (ClickSmart 420)  
046D:0970=Logitech Pocket Video 750 (Digital Camera)  
046D:0971=Logitech Pocket Video 550 (Digital Camera)  
046D:0990=Logitech QuickCam Pro 9000  
046D:0990:01=Logitech Mic (Pro 9000)  
046D:0990:02=Logicool Mic (Pro 9000)  
046D:0991=Logitech Mic-Pro for Notebooks  
046D:0991:01=Logitech Mic-Pro for Notebooks  
046D:0991:02=Logicool Mic-Pro for Notebooks  
046D:0992=QuickCam Communicate Deluxe Mic  
046D:0992:01=QuickCam Communicate Deluxe Mic  
046D:0992:02=QCam Communicate Deluxe Mic  
046D:0994=Logitech Mic (Orbit/Sphere AF)  
046D:0994:01=Logitech Mic (Orbit/Sphere AF)  
046D:0994:02=Logicool Mic (Orbit/Sphere AF)  
046D:09A1=Logitech QuickCam S5500  
046D:09A1:01=Logitech Mic (QuickCam S5500)  
046D:09A1:02=Logicool Mic (Qcam S5500)  
046D:09A2=Logitech QuickCam S7500  
046D:09A2:01=Logitech Mic (QuickCam S7500)  
046D:09A2:02=Logicool Mic (Qcam S7500)  
046D:09A4=Logitech QuickCam E3500  
046D:09A4:01=Logitech Mic (QuickCam E3500)  
046D:09A4:02=Logicool Mic (Qcam E3500)  
046D:09A5=Logitech Mic (QuickCam 3000)  
046D:09A6=QuickCam Vision Pro  
046D:09B0=Acer OrbiCam  
046D:09B2=Fujitsu Webcam  
046D:09C0=QuickCam for Dell Notebooks  
046D:09C0:01=QuickCam for Dell Notebooks Mic

046D:09C0:02=QuickCam for Dell Notebooks Mic  
046D:09C1=Logitech Mic (Notebooks Deluxe)  
046D:09C1:01=Logitech Mic (Notebooks Deluxe)  
046D:09C1:02=Logicool Mic (Notebooks Deluxe)  
046D:09C2=Logitech QuickCam Communicate STX  
046D:09C2:01=Logitech Mic (Communicate STX)  
046D:09C2:02=Logicool Mic (Communicate STX)  
046D:0A01=Logitech Stereo Headset  
046D:0A01:01=Logitech Stereo Headset Headphones  
046D:0A01:02=Logitech Stereo Headset Microphone  
046D:0A01:03=Logitech Stereo Headset Controls  
046D:0A01:0113=Logitech Premium Stereo Headset 30  
046D:0A02=Premium Stereo USB Headset 350  
046D:0A03=Logitech USB Microphone  
046D:0A04=Logitech USB Speaker  
046D:0A07=Z-10 Speakers  
046D:0A0B=ClearChat Pro USB  
046D:0A0C=Clear Chat Comfort USB Headset  
046D:0A13=Z-5 Speakers  
046D:0A17=G330 Headset  
046D:0B02=BT Mini-Receiver (HID proxy mode)  
046D:0B06=MotioninJoy Virtual Xinput device for Windows  
046D:8801=Logitech USB Video Camera  
046D:8801:01=Logitech USB Microphone  
046D:8970=Logitech Pocket Video 750 (DFU)  
046D:8971=Logitech Pocket Video 550 (DFU)  
046D:9970=Logitech Pocket Video 750 (Test)  
046D:9971=Logitech Pocket Video 550 (Test)  
046D:B004=Dell HID-compliant Bluetooth Mouse  
046D:B006=HID-compliant Bluetooth Mouse  
046D:B007=Logitech MX Revolution Bluetooth Mouse  
046D:B008=HID-compliant Bluetooth Mouse  
046D:B009=Bluetooth Laser Mouse  
046D:B301=Logitech HID-Compliant Keyboard (106 keys)  
046D:B303=Logitech HID-Compliant Keyboard (106 keys)  
046D:B305=Logitech HID-Compliant Keyboard (106 keys)  
046D:B307=Logitech HID-Compliant Keyboard (106 keys)  
046D:B308=Logitech HID-Compliant Keyboard (106 keys)  
046D:B309=Logitech HID-compliant Bluetooth Touchpad  
046D:B30B=Logitech HID-Compliant Keyboard  
046D:B30C=Logitech HID-Compliant Keyboard  
046D:B3E1=Logitech HID-Compliant Keyboard (106 keys)  
046D:B3E3=Logitech HID-Compliant Keyboard (106 keys)  
046D:BFE4=Premium Optical Wheel Mouse  
046D:C000=Logitech USB First/Pilot Mouse+  
046D:C001=Logitech USB First/Pilot Mouse+  
046D:C002=Logitech USB MouseMan Wheel  
046D:C003=Logitech USB MouseMan  
046D:C004=Logitech USB WingMan Gaming Mouse  
046D:C005=Logitech USB WingMan Gaming Wheel Mouse  
046D:C00B=Logitech USB MouseMan Wheel+  
046D:C00C=Logitech USB WheelMouse  
046D:C00D=Logitech USB MouseMan Wheel+  
046D:C00D:01=USB Optical MouseMan Wheel  
046D:C00E=Logitech Wheel Mouse  
046D:C00E:01=USB Optical WheelMouse  
046D:C00F=USB MouseMan Traveler/Mobile  
046D:C00F:01=USB MouseMan Traveler/Mobile  
046D:C011=USB Optical MouseMan  
046D:C011:01=USB Optical MouseMan

046D:C012=Optical Mouse  
046D:C012:01=USB MouseMan Dual Optical  
046D:C014=Logitech HID-compliant Optical Mouse  
046D:C015=Logitech HID-compliant Optical Mouse  
046D:C016=Logitech Corded Optical Wheel Mouse  
046D:C016:01=USB Optical WheelMouse  
046D:C018=Logitech USB Optical Wheel Mouse  
046D:C019=Logitech Optical Tilt Wheel Mouse  
046D:C01A=Logitech USB UltraX Optical Mouse  
046D:C01B=Logitech USB MX310 Optical Mouse  
046D:C01C=USB Optical Mouse  
046D:C01D=Logitech USB MX510 Optical Mouse  
046D:C01E=MX518 Optical Mouse  
046D:C01F=Logitech HID-compliant G1 Optical Mouse  
046D:C024=Logitech USB MX300 Optical Mouse  
046D:C024:01=Logitech USB MX300 Optical Mouse  
046D:C025=MX500 Optical Mouse  
046D:C025:01=Logitech USB MX500 Optical Mouse  
046D:C030=Logitech USB iFeel Mouse  
046D:C031=Logitech USB iFeel Mouse+  
046D:C031:01=USB iFeel Mouse  
046D:C032=Logitech USB iFeel MouseMan  
046D:C033=Logitech USB iFeel MouseMan+  
046D:C033:01=USB iFeel MouseMan  
046D:C034=USB MouseMan Optical  
046D:C034:01=USB MouseMan Optical  
046D:C035=USB Mouse  
046D:C036=USB Mouse  
046D:C037=USB Mouse  
046D:C038=USB Mouse  
046D:C03D=Logitech HID-compliant Optical Wheel Mouse  
046D:C03E=HID-compliant Wheel Mouse  
046D:C03F=Logitech HID-compliant UltraX Optical Mouse  
046D:C040=Logitech Corded USB Wheel Mouse  
046D:C041=Logitech HID-compliant G5 Laser Mouse  
046D:C042=Logitech HID-compliant G3 Laser Mouse  
046D:C043=Logitech USB MX400 Performance Laser Mouse  
046D:C044=Logitech USB LX3 Optical Mouse  
046D:C045=Logitech USB Optical Tilt Wheel Mouse  
046D:C046=Logitech USB RX1000 Laser Mouse  
046D:C047=Logitech USB Laser Tilt Wheel Mouse  
046D:C048=Logitech HID-compliant G9 Laser Mouse  
046D:C049=Logitech HID-compliant G5 Laser Mouse  
046D:C050=RX 250 Optical Mouse  
046D:C051=Logitech USB G3 (MX518) Optical Mouse  
046D:C053=Logitech USB Laser Mouse  
046D:C058=M115 Mouse  
046D:C05A=USB Optical Mouse  
046D:C05B=USB Optical TiltWheel Mouse  
046D:C05D=Optical Mouse  
046D:C061=Logitech USB RX1500 Mouse  
046D:C062=Logitech USB LS1 Laser Mouse  
046D:C063=USB Laser Mouse  
046D:C064=USB Optical TiltWheel Mouse  
046D:C065=USB Optical Laser Mouse  
046D:C066=Logitech HID-compliant G9x Laser Mouse  
046D:C068=Logitech HID-compliant G Laser Mouse  
046D:C069=Logitech USB M500 Laser Mouse  
046D:C06B=Logitech HID-compliant G700 Gaming Mouse  
046D:C06C=Optical Mouse

046D:C070=Logitech HID-compliant Mouse  
046D:C071=Logitech HID-compliant Mouse  
046D:C071:01=Logitech HID-Compliant Keyboard  
046D:C072=Logitech HID-compliant Mouse  
046D:C072:01=Logitech HID Keyboard Consumer Controls  
046D:C073=Logitech HID-compliant Mouse  
046D:C073:01=Logitech HID-Compliant Keyboard  
046D:C074=Logitech HID-compliant Mouse  
046D:C074:01=Logitech HID-Compliant Keyboard  
046D:C075=HID-compliant Optical Mouse  
046D:C076=HID-compliant Optical Mouse  
046D:C077=HID-compliant Optical Wheel Mouse  
046D:C078=USB Optical Tilt Wheel Mouse  
046D:C079=HID-compliant Optical Wheel Mouse  
046D:C07A=USB Optical Tilt Wheel Mouse  
046D:C07B=HID-compliant Optical Wheel Mouse  
046D:C0FF=Logitech HID-compliant Mouse  
046D:C101=UltraX Media Remote  
046D:C110=Harmony Remote 885  
046D:C111=Harmony 525 Remote  
046D:C11F=Harmony 900 Remote  
046D:C122=Harmony 700 Remote  
046D:C201=Logitech USB WingMan Extreme Joystick with Throttle  
046D:C202=Logitech WingMan Formula (Yellow) (USB)  
046D:C207=Logitech WingMan Extreme Digital 3D (USB)  
046D:C208=Logitech WingMan Gamepad Extreme (USB)  
046D:C209=Logitech WingMan Gamepad Black (USB)  
046D:C20A=WingMan RumblePad  
046D:C20B=Logitech WingMan Action Pad (HID)  
046D:C20C=WingMan Precision  
046D:C20D=Logitech WingMan Attack 2 (HID)  
046D:C20E=Logitech WingMan Formula GP (HID)  
046D:C211=WingMan Cordless Gamepad  
046D:C212=WingMan Extreme Digital 3D  
046D:C213=Logitech Freedom 2.4 (HID)  
046D:C214=Logitech Attack 3 (HID)  
046D:C215=Logitech Extreme 3D Pro (HID)  
046D:C216=Logitech Dual Action (HID)  
046D:C218=Logitech RumblePad 2 HID  
046D:C219=Logitech Cordless RumblePad 2 HID  
046D:C21A=Logitech Precision Gamepad (HID)  
046D:C21C=G13 Advanced Gameboard  
046D:C21D=F310 Gamepad [XInput Mode]  
046D:C21E=F510 Gamepad [XInput Mode]  
046D:C21F=F710 Wireless Gamepad [XInput Mode]  
046D:C221=G15 Keyboard / Keyboard  
046D:C222=G15 Keyboard / LCD  
046D:C223=G15 Keyboard / USB Hub  
046D:C225=G11/G15 Keyboard / G keys  
046D:C226=G15 Refresh Keyboard  
046D:C227=G15 Refresh Keyboard  
046D:C228=G19 Gaming Keyboard  
046D:C228:01=G19 Gaming Interface  
046D:C229=G19 Gaming LCD Display  
046D:C229:01=G19 Gaming Macro  
046D:C22D=G510 Gaming Keyboard  
046D:C22E=G510 Gaming Keyboard onboard audio  
046D:C247=Logitech USB Gaming Mouse G100  
046D:C249=Logitech HID-compliant G9x Laser Mouse Call of Duty: MW3  
046D:C250=Cartman Prototype

046D:C281=Logitech WingMan Force USB  
046D:C281:01=Logitech WingMan Force USB  
046D:C281:0100=Logitech WingMan Force USB  
046D:C283=WingMan Force 3D  
046D:C285=WingMan Strike Force 3D  
046D:C286=Logitech Force 3D Pro USB (HID)  
046D:C287=Logitech Flight System G940  
046D:C291=Logitech WingMan Formula Force USB  
046D:C291:01=Logitech WingMan Formula Force USB  
046D:C291:0100=Logitech WingMan Formula Force USB  
046D:C293=Logitech WingMan Formula Force GP USB (HID)  
046D:C294=Logitech Driving Force USB (HID)  
046D:C294:2000=Logitech Driving Force EX USB (HID)  
046D:C294:2100=Logitech Formula Force RX USB  
046D:C294:2200=Logitech Driving Force RX USB (HID)  
046D:C295=Momo Force Steering Wheel  
046D:C298=Logitech Driving Force Pro USB (HID)  
046D:C299=G25 Racing Wheel  
046D:C29A=Logitech Driving Force GT USB  
046D:C29B=G27 Racing Wheel  
046D:C29C=Speed Force Wireless Wheel for Wii  
046D:C2A0=Wingman Force Feedback Mouse  
046D:C2A1=WingMan Force Feedback Mouse  
046D:C2A8=Logitech G940 Joystick (HID)  
046D:C2A9=Logitech G940 Throttle (HID)  
046D:C2AA=Logitech G940 Pedals (HID)  
046D:C301=iTouch Keyboard  
046D:C301:01=iTouch Keys  
046D:C302=iTouch Pro Keyboard  
046D:C302:01=iTouch Pro Keys  
046D:C303=iTouch Keyboard  
046D:C303:01=iTouch Keys  
046D:C304=Logitech HID-Compliant Keyboard  
046D:C304:01=Logitech HID-Compliant Keyboard  
046D:C305=Internet Keyboard  
046D:C305:01=Internet Keys  
046D:C306=Logitech HID-Compliant Keyboard  
046D:C306:01=Logitech HID-Compliant Keyboard  
046D:C307=Internet Keyboard USB  
046D:C307:01=Internet Keys USB  
046D:C308=Internet Navigator Keyboard  
046D:C308:01=Internet Keys USB  
046D:C309=Logitech USB iTouch Keyboard  
046D:C309:01=Internet Keys USB  
046D:C30A=iTouch Composite  
046D:C30A:01=Internet Keys USB  
046D:C30B=NetPlay Keyboard  
046D:C30C=Internet Keys (X)  
046D:C30C:01=Internet Keys USB (X)  
046D:C30D=Internet Keys  
046D:C30D:01=Internet Keys USB  
046D:C30E=UltraX Keyboard (Y-BL49)  
046D:C30E:01=UltraX Keys (X)  
046D:C30F=Logitech HID-Compliant Keyboard  
046D:C30F:01=Logitech HID-Compliant Keyboard  
046D:C311=Y-UF49 [Internet Pro Keyboard]  
046D:C312=DeLuxe 250 Keyboard  
046D:C313=USB Multimedia Keyboard  
046D:C313:01=USB Multimedia Hot-Keys  
046D:C315=Classic New Touch Keyboard

046D:C316=Logitech HID-Compliant Keyboard  
046D:C316:01=Logitech HID-Compliant Keyboard  
046D:C317=Logitech HID-Compliant Keyboard (106 keys)  
046D:C317:01=Logitech HID Keyboard Power Key  
046D:C318=Logitech HID-Compliant Keyboard  
046D:C31A=Comfort Wave 450  
046D:C31B=Logitech HID-Compliant Keyboard  
046D:C31B:01=Logitech HID Keyboard Power Key  
046D:C31C=Keyboard K120 for Business  
046D:C320=Logitech HID-Compliant Keyboard  
046D:C321=Logitech HID-Compliant Keyboard  
046D:C321:01=Logitech HID-compliant Pointing Device  
046D:C322=Logitech HID-Compliant Keyboard  
046D:C322:01=Logitech HID Keyboard Consumer Controls  
046D:C323=Logitech HID-Compliant Keyboard  
046D:C323:01=Logitech HID Keyboard Consumer Controls  
046D:C324=Logitech HID-Compliant Keyboard  
046D:C324:01=Logitech HID Keyboard Power Key  
046D:C325=Logitech HID-Compliant Keyboard  
046D:C325:01=Logitech HID Keyboard Power Key  
046D:C326=Logitech HID-Compliant Keyboard  
046D:C401=Logitech USB TrackMan Marble Wheel  
046D:C402=Logitech USB Marble Mouse  
046D:C403=Logitech USB Turbo TrackMan Marble FX  
046D:C404=Logitech USB TrackMan Wheel  
046D:C408=USB Marble Mouse  
046D:C408:01=USB Marble Mouse  
046D:C501=Logitech USB Cordless Mouse  
046D:C501:01=Logitech Cordless USB Mouse  
046D:C502=Logitech USB Cordless Mouse & iTouch Keys  
046D:C502:01=Logitech Cordless Dual USB Mouse & iTouch Keys  
046D:C503=Logitech USB Cordless iTouch Keys  
046D:C503:01=Logitech Cordless USB iTouch Keys  
046D:C504=Logitech Cordless Dual USB Mouse & iTouch Keys  
046D:C504:01=Logitech Cordless Dual USB Mouse & iTouch Keys  
046D:C505=Logitech Cordless Dual USB Mouse & iTouch Keys  
046D:C505:01=Logitech Cordless Dual USB Mouse & iTouch Keys  
046D:C506=Logitech Cordless USB Mouse  
046D:C506:01=Logitech Cordless USB Mouse  
046D:C508=Logitech Cordless USB Trackball  
046D:C508:01=Logitech Cordless USB Trackball  
046D:C509=Logitech Cordless USB Keyboard  
046D:C509:01=Logitech Cordless Dual USB Mouse & iTouch Keys  
046D:C50A=Logitech Cordless USB Mouse  
046D:C50B=Logitech Cordless Dual USB Mouse & iTouch Key  
046D:C50B:01=Logitech Cordless Dual USB Mouse & iTouch Keys  
046D:C50C=Logitech HID-Compliant Keyboard  
046D:C50C:01=Logitech HID-compliant Cordless Mouse  
046D:C50D=Logitech Cordless USB Mouse  
046D:C50E=MX-1000 Cordless Mouse Receiver  
046D:C510=Logitech Cordless USB Mouse  
046D:C512=Logitech Cordless USB Keyboard  
046D:C512:01=Logitech Cordless USB Mouse & Enhanced Keys  
046D:C513=Logitech HID-Compliant Keyboard  
046D:C513:01=Logitech HID-compliant Cordless Mouse  
046D:C514=Cordless Mouse  
046D:C515=Cordless 2.4 GHz Presenter Presentation remote control  
046D:C516=Logitech HID-Compliant Keyboard  
046D:C516:01=Logitech HID-compliant Cordless Mouse  
046D:C517=Logitech HID-Compliant Keyboard

046D:C517:01=Logitech HID-compliant Cordless Mouse  
046D:C518=Logitech HID-compliant Cordless Mouse  
046D:C51A=Logitech HID-compliant Cordless Mouse  
046D:C51B=Logitech HID-compliant Cordless Mouse  
046D:C51C=Logitech HID-Compliant Keyboard  
046D:C51C:01=Logitech HID-compliant Cordless Mouse  
046D:C521=Logitech HID-compliant Cordless Mouse  
046D:C525=Logitech HID-compliant Cordless Mouse  
046D:C526=Logitech HID-compliant Cordless Mouse  
046D:C529=Logitech HID-Compliant Keyboard  
046D:C529:01=Logitech HID-compliant Cordless Mouse  
046D:C52B=Unifying Receiver  
046D:C52B:02=Logitech Unifying USB receiver  
046D:C52E=Logitech HID-Compliant Keyboard  
046D:C52E:01=Logitech HID Keyboard Power Key  
046D:C52F=Logitech HID-compliant Cordless Mouse  
046D:C531=Logitech HID-compliant Cordless Mouse  
046D:C623=3Dconnexion Space Traveller 3D Mouse  
046D:C625=3Dconnexion Space Pilot 3D Mouse  
046D:C626=3Dconnexion Space Navigator 3D Mouse  
046D:C627=3Dconnexion Space Explorer 3D Mouse  
046D:C629=3Dconnexion SpacePilot Pro  
046D:C702=Logitech Cordless Presenter  
046D:C702:01=Logitech Cordless Presenter  
046D:C703=Logitech HID-Compliant Keyboard  
046D:C703:01=Logitech HID-compliant Bluetooth Mouse  
046D:C704=Logitech HID-Compliant Keyboard  
046D:C704:01=Logitech HID-compliant Bluetooth Mouse  
046D:C705=Logitech HID-compliant Bluetooth Mouse  
046D:C705:01=HID-compliant Device  
046D:C707=Bluetooth Wireless Hub  
046D:C708=Bluetooth Wireless Hub  
046D:C708:01=HID-compliant Device  
046D:C709=Bluetooth Wireless Hub  
046D:C70A=Logitech HID-compliant Bluetooth Mouse  
046D:C70B=Logitech HID-Compliant Keyboard  
046D:C70C=Logitech HID-compliant Bluetooth Mouse  
046D:C70D=Bluetooth Wireless Hub  
046D:C70E=Logitech HID-Compliant Keyboard  
046D:C70F=Bluetooth Wireless Hub (firmware upgrade)  
046D:C712=Bluetooth Wireless Hub (firmware upgrade)  
046D:C713=Logitech HID-Compliant Keyboard  
046D:C714=Logitech HID-compliant Touch Pad Mouse  
046D:C715=Bluetooth Wireless Hub (firmware upgrade)  
046D:C719=HID-compliant Device  
046D:C71A=Bluetooth Wireless Hub (firmware upgrade)  
046D:C71B=Logitech HID-Compliant Keyboard  
046D:C71C=HID-compliant Bluetooth Mouse  
046D:C71D=Bluetooth Wireless Hub (firmware upgrade)  
046D:C71E=Logitech HID-Compliant Keyboard  
046D:C71F=Logitech HID-compliant Touch Pad Mouse  
046D:C720=Bluetooth Wireless Hub (firmware upgrade)  
046D:CA03=Logitech MOMO Racing (HID)  
046D:CA04=Logitech Racing Wheel HID  
046D:CAB1=Cordless Keyboard for Wii HID Receiver  
046D:D001=Logitech QuickCam Pro USB  
046E=BTC  
046E:0100=BTC USB Keyboard  
046E:3001=Mass Storage Device  
046E:3002=Mass Storage Device

046E:3003=Mass Storage Device  
046E:3005=Mass Storage Device  
046E:3008=Mass Storage Device  
046E:5120=Office Keyboard  
046E:5250=KeyMaestro Multimedia Keyboard  
046E:5250:01=USB KeyMaestro Multimedia Keyboard  
046E:5251=USB KeyMaestro Multimedia Keyboard(Windows 2000)  
046E:5273=USB KeyMaestro KeyMaestro Multimedia Keyboard(Windows XP)  
046E:5273:01=USB KeyMaestro Multimedia Keyboard  
046E:5280=USB KeyMaestro Multimedia Keyboard(Windows XP)  
046E:52A2=USB KeyMaestro Multimedia Keyboard(Windows XP)  
046E:52A4=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:52B0=Office Keyboard  
046E:52D4=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:52D8=USB MouseMaestro Mouse Filter Driver (Windows 2000)  
046E:52D9=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:52DA=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:52DB=USB MouseMaestro Mouse Filter Driver (Windows 2000)  
046E:52DC=USB MouseMaestro Mouse Filter Driver (Windows 2000)  
046E:52E6=Cordless Mouse  
046E:52E7=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:52F0=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:5308=KeyMaestro USB Keyboard  
046E:5308:01=KeyMaestro Multimedia Keyboard  
046E:5408=KeyMaestro USB Multimedia Keyboard/Hub  
046E:5500=USB Multimedia Keyboard  
046E:5500:01=USB Multimedia Hot Heys  
046E:5500:0110=USB Multimedia Keyboard 6100C  
046E:5530=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:5540=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:5550=USB MouseMaestro Mouse Filter Driver (Windows XP)  
046E:5551=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:5554=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:5555=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:5556=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:5557=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:5558=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:5559=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:555A=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:555B=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:555C=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:556A=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:556C=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:556D=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:556E=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:556F=USB MouseMaestro Mouse Filter Driver (Windows Vista x64)  
046E:5570=USB KeyMaestro Multimedia Keyboard(Windows XP)  
046E:5720=Smart Card Reader  
046E:6782=CMD USB Keyboard  
046E:6782:01=BTC USB Keyboard Mouse  
046F=Crystal Semiconductor  
0471=Philips  
0471:0101=Philips DSS 350/370 Speakers  
0471:0101:02=Philips HID Audio Controls  
0471:0104=Philips DSS 330 Speakers  
0471:0105=UDA1321  
0471:0110=Philips Composite USB-Hifi Device  
0471:0111:0402=Philips Composite USB-Hifi Device  
0471:014F=GoGear SA9200  
0471:0151=USB Audio System



0471:0151:01=USB Audio System Stream  
0471:0151:02=USB Audio System Stream  
0471:0151:03=USB Audio System Control  
0471:0160=MP3 Player  
0471:0161=MP3 Player  
0471:0163=GoGear SA1100  
0471:0164=GoGear SA1110/02  
0471:0165=GoGear SA1330  
0471:0201=Philips USB Hub  
0471:0222=Creative Nomad Jukebox  
0471:0302=Philips 645 USB Camera Microphone  
0471:0302:01=Philips 645 USB Camera Mic  
0471:0303=Philips 646 USB Camera Microphone  
0471:0303:01=Philips 646 USB Camera Mic  
0471:0304=Askey VC010 WebCam [pwc]  
0471:0307=Philips 675 USB Camera Microphone  
0471:0307:01=Philips 675 USB Camera Mic  
0471:0308=Philips 680 USB Camera Microphone  
0471:0308:01=Philips 680 USB Camera Mic  
0471:030B=PC VGA Camera (Vesta Fun)  
0471:030C=Philips 690 USB Camera Microphone  
0471:030C:01=Philips 680/690 USB Camera Mic  
0471:0310=Philips ToUcam Fun Camera; Audio (Microphone)  
0471:0310:01=Philips ToUcam Fun Camera; Audio (Microphone)  
0471:0311=Philips ToUcam Pro Camera; Audio (Microphone)  
0471:0311:01=Philips ToUcam Pro Camera; Audio (Microphone)  
0471:0312=Philips PCVC750K Camera; Audio (Microphone)  
0471:0312:01=Philips PCVC750K Camera; Audio (Microphone)  
0471:0313=PCVC720K/40 Philips ToUcam Fun Camera; Audio (Microphone)  
0471:0314=DMVC 1000K  
0471:0316=DMVC 2000K Video Capture  
0471:0321=FunCam  
0471:0322=DMVC1300K PC Camera  
0471:0325=SPC 200NC PC Camera  
0471:0326=SPC 300NC PC Camera  
0471:0327=WEBc am SPC 6000 NC (WebCam w/ mic)  
0471:0328=SPC 700NC PC Camera  
0471:0329=Philips SPC 900NC PC Camera  
0471:0329:01=Philips SPC 900NC PC Camera; Audio (Microphone)  
0471:032A=USB Video Capture  
0471:032D=SPC 210NC PC Camera  
0471:032E=SPC 315NC PC Camera  
0471:0330=SPC 710NC PC Camera  
0471:0331=SPC 1300NC PC Camera  
0471:0332=SPC 1000NC PC Camera  
0471:0333=SPC 620NC PC Camera  
0471:0334=SPC 520/525NC PC Camera  
0471:0401=Philips Semiconductors CICT USB Keyboard  
0471:0402=PS/2 Mouse on Philips Semiconductors CICT USB Keyboard  
0471:0402:01=PS/2 Mouse on Philips Semiconductors CICT USB Keyboard  
0471:0406=Philips 15 inch Detachable Monitor  
0471:0407=Philips 10 inch Mobile Monitor  
0471:0408=SG3WA1/74 802.11b WLAN Adapter [Atmel AT76C503A]  
0471:0471=Digital Speaker System  
0471:0601=Philips USB Wireless Keyboard Mouse  
0471:0601:01=Philips USB Wireless Keyboard Mouse  
0471:0602=ATI Remote Wonder II Input Device  
0471:0603=ATI Remote Wonder II Controller  
0471:0608=eHome Infrared Receiver (USBCIR)  
0471:060A=TSU9600 Remote Control

0471:060C=eHome Infrared Receiver (USBCIR)  
0471:060D=eHome Infrared Receiver (USBCIR)  
0471:060E=RF Dongle  
0471:060F=eHome Infrared Receiver (USBCIR)  
0471:0613=Infrared Transceiver  
0471:0617=IEEE802.15.4 RF Dongle  
0471:0619=TSU9400 Remote Control  
0471:0666=Hantek DDS-3005 Arbitrary Waveform Generator  
0471:0700=Philips Semiconductors CICT USB Hub  
0471:0701=150P1 TFT Display  
0471:0809=Philips BluePearl Bluetooth USB Device  
0471:080E=USB CD R/W Writer  
0471:0811=JR24 CDRW  
0471:0814=DCCX38/P data cable  
0471:0815=eHome Infrared Receiver (USBCIR)  
0471:081E=Philips Phones USB  
0471:0826=USB PC Sync Device  
0471:0830=Phone for Windows Live Messenger  
0471:0844=SA2111/02 1GB Flash Audio Player  
0471:084A=GoGear SA3125  
0471:084E=GoGear SA60xx (mtp)  
0471:0888=Hantek DDS-3005 Arbitrary Waveform Generator  
0471:1103=Digital Speaker System  
0471:1120=Creative Rhomba MP3 player  
0471:1125=Nike psa[128max Player  
0471:1137=HDD065 MP3 player  
0471:1201=Arima Bluetooth Device  
0471:1230=Wireless Adapter 11g  
0471:1232=SNU6500 Wireless Adapter  
0471:1233=Wireless Adapter Bootloader Download  
0471:1234=Philips Semiconductors Modem USB  
0471:1236=Philips SNU5600 Wireless USB Adapter 11b/g  
0471:1237=TalkTalk SNU5630NS/05 Wireless USB Adapter  
0471:1552=ISP 1581 Hi-Speed USB MPEG2 Encoder Reference Kit  
0471:1801=Diva MP3 player  
0471:200A=Wireless Network Adapter  
0471:200F=Philips 802.11n Wireless USB Adapter  
0471:2021=SDE3273FC/97 2.5" SATA HDD Enclosure [INIC-1608L]  
0471:2022=GoGear SA52XX  
0471:2034=Webcam SPC530NC  
0471:2036=Webcam SPC1030NC  
0471:203F=TSU9200 Remote Control  
0471:2046=TSU9800 Remote Control  
0471:204E=GoGear RaGa (SA1942/02)  
0471:205E=TSU9300 Remote Control  
0471:206C=MCE IR Receiver - Spinel plus for ASUS  
0471:2070=GoGear Mix  
0471:2076=GoGear Aria  
0471:2079=GoGear Opus  
0471:2088=MCE IR Receiver with ALS- Spinel plus for ASUS  
0471:20B6=GoGear Vibe  
0471:20E3=GoGear Raga  
0471:262C=SPC230NC WebCam  
0471:485D=Senselock SenseIV v2.x  
0471:DF55=LPCXpresso LPC-Link  
0472=Sun Microsystems  
0472:0065=PFU-65 Keyboard  
0472:B086=Asus USB2.0 Webcam  
0472:B091=Webcam  
0473=Sanyo Information Business

0474=Sanyo Electric  
0474:0110=Digital Voice Recorder R200  
0474:0217=Xacti J2  
0474:022F=C5 Digital Media Camera (mass storage mode)  
0474:0230=C5 Digital Media Camera (PictBridge mode)  
0474:0231=C5 Digital Media Camera (PC control mode)  
0474:0401=SANYO USB Optical Drive  
0474:0701=SCP-4900 Cellphone  
0474:071F=Usb Com Port Enumerator  
0474:0722=W33SA Camera  
0475=Relisys/TECO Information System  
0475:0100=NEC Petiscan  
0475:0103=Eclipse 1200U/Episode  
0475:0210=Scorpio Ultra 3  
0476=AESP  
0477=Seagate Technology  
0478=Connectix  
0478:0001=QuickCam  
0478:0002=QuickClip  
0478:0003=QuickCam Pro  
0479=Advanced Peripheral Laboratories  
047A=USAR Systems  
047A:0004=ScreenCoder UR7HCTS2-USB  
047A:1000=Semtech Touch Sensor  
047A:1000:0060=Semtech Single Axis Touch Sensor (SH1475)  
047B=Silitek  
047B:0001=Silitek USB Keyboard  
047B:0002=Silitek USB Keyboard Mouse  
047B:0002:01=Silitek USB Keyboard Mouse  
047B:0011=SK-1688U Keyboard  
047B:00F9=Silitek SK-1789u Keyboard  
047B:0101=BlueTooth Keyboard and Mouse  
047B:020B=SK-3105 SmartCard Reader  
047B:020B:01=CCID USB Smart Card Reader  
047B:050E=USB Internet Compact Keyboard  
047B:1000=Trust Office Scan USB 19200  
047B:1002=HP ScanJet 4300c Parallel Port  
047C=Dell Computer  
047D=Kensington  
047D:1001=Kensington Wheel Mouse  
047D:1002=Kensington USB/PS2 Expert Mouse Pro  
047D:1003=Orbit TrackBall  
047D:1004=Kensington USB/PS2 MouseWorks  
047D:1005=TurboBall  
047D:1006=Kensington USB/PS2 TurboRing  
047D:1009=Kensington USB Orbit  
047D:1012=Kensington USB Wheel Mouse  
047D:1013=Kensington USB/PS2 Optical Elite  
047D:1014=Kensington USB/PS2 Expert Mouse Pro Wireless  
047D:1015=Kensington USB/PS2 Expert Mouse  
047D:1016=Kensington ADB/USB Orbit  
047D:1018=Kensington USB StudioMouse  
047D:101D=Kensington USB/PS2 Mouse\*in\*a\*Box Optical Pro  
047D:101E=Kensington USB StudioMouse Wireless  
047D:101F=Kensington USB PocketMouse Pro  
047D:1020=Kensington USB Expert Mouse  
047D:1021=Kensington USB Expert Mouse Wireless  
047D:1022=Kensington USB/PS2 Orbit Optical  
047D:1023=Kensington USB Pocket Mouse Pro Wireless  
047D:1024=Kensington USB PocketMouse

047D:1025=Kensington USB Mouse\*in\*a\*Box Optical Elite Wireless  
047D:1026=Kensington USB Pocket Mouse Pro  
047D:1027=Kensington USB StudioMouse  
047D:1028=Kensington USB StudioMouse Wireless  
047D:1029=Kensington USB Mouse\*in\*a\*Box Optical Elite  
047D:102A=Kensington USB Mouse\*in\*a\*Box Optical  
047D:102B=Kensington USB PocketMouse  
047D:102C=Kensington USB Iridio  
047D:102D=Kensington USB Pilot Optical  
047D:102E=Kensington USB Pilot Optical Pro  
047D:102F=Kensington USB Pilot Optical Pro Wireless  
047D:1030=Kensington Input Device  
047D:1031=Kensington Input Device  
047D:1032=Kensington Input Device  
047D:1033=Kensington Input Device  
047D:1034=Kensington Input Device  
047D:1035=Kensington Input Device  
047D:1036=Kensington Input Device  
047D:1037=Kensington Input Device  
047D:1038=Kensington Input Device  
047D:1039=Kensington Input Device  
047D:1043=Ci65m Wireless Notebook Optical Mouse  
047D:104A=PilotMouse Mini Retractable  
047D:105D=Kensington PocketMouse Bluetooth  
047D:105E=Kensington Bluetooth EDR Dongle  
047D:1061=PocketMouse Grip  
047D:1062=PocketMouse Max  
047D:1063=PocketMouse Max Wireless  
047D:1064=PocketMouse 2.0 Wireless  
047D:1065=PocketMouse 2.0  
047D:1066=PocketMouse Max Glow  
047D:1067=ValueMouse  
047D:1068=ValueOpt White  
047D:1069=ValueOpt Black  
047D:106A=PilotMouse Laser Wireless Mini  
047D:106B=PilotMouse Laser - 3 Button  
047D:106C=PilotMouse Laser - Gaming  
047D:106D=PilotMouse Laser - Wired  
047D:106E=PilotMouse Micro Laser  
047D:1070=ValueOpt Travel  
047D:1071=ValueOpt RF TX  
047D:1072=PocketMouse Colour  
047D:1073=PilotMouse Laser - 6 Button  
047D:1074=PilotMouse Laser Wireless Mini  
047D:1075=SlimBlade Presenter Media Mouse  
047D:1076=SlimBlade Media Mouse  
047D:1077=SlimBlade Presenter Mouse  
047D:1152=Kensington Bluetooth EDR Dongle Firmware Upgrade  
047D:1154=Kensington Bluetooth EDR Dongle  
047D:2002=Optical Elite Wireless  
047D:2002:01=Kensington USB Optical Elite Wireless  
047D:2010=Wireless Presentation Remote  
047D:2012=Wireless Presenter with Laser Pointer  
047D:2021=PilotBoard Wireless  
047D:2030=PilotBoard Wireless  
047D:2034=SlimBlade Media Notebook Set  
047D:2041=SlimBlade Trackball  
047D:4003=Gravis Xterminator Digital Gamepad  
047D:4005=Gravis Eliminator GamePad Pro  
047D:4006=Gravis Eliminator AfterShock

047D:4007=Gravis Xterminator Force  
047D:4008=Gravis Destroyer TiltPad  
047D:5001=Cabo I Camera  
047D:5002=VideoCam CABO II  
047D:5003=VideoCam  
047E=Lucent Microelectronics Technologies  
047E:0300=ORiNOCO USB Card  
047E:1001=USS720 Parallel Port  
047E:2892=Agere Systems USB 2.0 Soft Modem  
047E:BAD1=Lucent 56k Modem USB  
047E:F101=Lucent V.90 56K USB Modem  
047F=Plantronics  
047F:0101=Bulk Driver  
047F:0101:0101:04=Plantronics USB Bulk Driver  
047F:0301=Plantronics Headset  
047F:0CA1=Plantronics USB Audio Adapter  
047F:0CA1:01=Plantronics USB Audio Adapter Microphone  
047F:0CA1:02=Plantronics USB Audio Adapter Microphone  
047F:0CA1:03=Plantronics USB Audio Adapter Controls  
047F:0CA1:0004=Plantronics DSP-100 Audio Headset  
047F:4254=BUA-100 Bluetooth Adapter  
047F:AD01=GameCom 777 5.1 Headset  
0480=Toshiba America Info. Systems  
0480:0001=Toshiba InTouch Module  
0480:0004=Toshiba InTouch Module  
0480:0011=Toshiba InTouch Module  
0480:0014=Toshiba InTouch Module  
0481=Zenith Data Systems  
0482=Kyocera  
0482:0002=KM-WDK USB  
0482:0003=KM-WDK USB  
0482:0004=KM-WDK USB  
0482:0005=KM-WDK USB  
0482:0006=KM-WDK USB  
0482:000D=KM-WDK USB  
0482:000E=FS-1020D Printer  
0482:000F=KM-WDK USB  
0482:0100=Finecam S3x  
0482:0101=Finecam S4  
0482:0103=Finecam S5  
0482:0105=Finecam L3  
0482:0106=Kyocera Finecam  
0482:0106:0105=Kyocera Finecam S5R  
0482:0107=Digital Camera USB Device  
0482:0108=Digital Camera USB Device  
0482:0203=AH-K3001V  
0482:0204=iBurst Terminal  
0482:032A:02=Kyocera KM-1820 WIA Driver  
0482:032B:02=Kyocera FS-1118MFP WIA Driver  
0482:032C:02=Kyocera CS-1820 WIA Driver  
0483=SGS Thomson  
0483:0137=BeWAN ADSL USB ST (blue or green)  
0483:0138=Unicorn II (ST70138B + MTC-20174TQ chipset)  
0483:1302=Lexar Disk  
0483:1302:0142=Lexar Microsoft Driver DevCon 2005  
0483:1307=Cytronix 6in1 card reader  
0483:163D=Cool Icam Digi-MP3  
0483:2015=TouchChip?USB Fingerprint Reader  
0483:2016=TouchChip Fingerprint Coprocessor  
0483:2017=Biometric Smart Card Reader

0483:2017:01=Smart Card Reader Interface  
0483:2018=TouchChip Sensor Interface  
0483:2018:01=Smart Card Reader Interface  
0483:2302=Portable Flash Device (PFD)  
0483:3744=STLINK Pseudo disk  
0483:3748=ST-LINK/V2  
0483:4810=ISDN adapter  
0483:481D=BT Digital Access adapter  
0483:5000=STMicroelectronics USB Bluetooth Device  
0483:5001=ST Micro Bluetooth Device  
0483:5710=Joystick in FS Mode  
0483:5721=Hantek DDS-3X25 Arbitrary Waveform Generator  
0483:7270=ST Micro Serial Bridge  
0483:7554=56k SoftModem  
0483:DF11=STM Device in DFU Mode  
0483:FF10=Swann ST56 USB Modem  
0484=Specialix  
0485=Nokia Monitors  
0486=ASUS Computers  
0486:0185=EeePC T91MT HID Touch Panel  
0487=Stewart Connector  
0488=Cirque  
0489=Foxconn / Hon Hai  
0489:0000=Bluetooth Foxconn-CPBT20CU-CSRBC4  
0489:0001=Bluetooth Foxconn-CPBT22AU-CSRBC4  
0489:0005=Bluetooth Foxconn-CPWB102P-CSRBC4  
0489:0502=SmartMedia Card Reader Firmware Loader  
0489:0503=SmartMedia Card Reader  
0489:D00C=Rollei Compactline (Storage Mode)  
0489:D00E=Rollei Compactline (Video Mode)  
0489:E000=T-Com TC 300  
0489:E003=Pirelli DP-L10  
0489:E00B=Broadcom Bluetooth 2.1 + EDR USB Device  
0489:E00D=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0489:E00E=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0489:E00F=FOXCONN-T77H114-BCM2070  
0489:E010=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0489:E011=Broadcom 2046 Bluetooth 2.1+EDR USB Device  
0489:E012=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0489:E013=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0489:E014=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0489:E016=Foxconn / Hon Hai  
0489:E02C=Atheros AR5BBU12 Bluetooth Device  
0489:E02D=Broadcom BCM2070 Bluetooth Device  
0489:E02F=Broadcom Bluetooth 3.0 USB  
0489:E030=Broadcom Bluetooth 3.0 USB  
0489:E031=Broadcom BCM20702 Bluetooth USB Device  
0489:E032=Broadcom Bluetooth 3.0 USB  
0489:E039=Broadcom Bluetooth 3.0 USB  
048A=S-MOS Systems  
048C=Alps Electric  
048D=Integrated Technology Express  
048D:9009=Zolid HD DVD Maker  
048D:9135=Zolid Mini DVB-T Stick  
048F=Eicon Tech.  
0490=United Microelectronic  
0491=Capetronic  
0491:0003=Taxan Monitor Control  
0492=Samsung Semiconductor  
0492:0140=MP3 player

0492:0141=MP3 Player  
0493=MAG Technology  
0495=ESS Technology  
0496=Micron Electronics  
0497=Smile International  
0497:C001=Camera Device  
0498=Capetronic/Kaohsiung  
0499=Yamaha  
0499:1000=UX256 MIDI I/F  
0499:1001=Yamaha USB Audio  
0499:1002=MU2000  
0499:1003=MU500  
0499:1004=UW500  
0499:1005=MOTIF6  
0499:1006=MOTIF7  
0499:1007=MOTIF8  
0499:1008=UX96 MIDI I/F  
0499:1009=UX16 MIDI I/F  
0499:100A=EOS BX  
0499:100C=UC-MX  
0499:100D=UC-KX  
0499:100E=S08  
0499:100F=CLP-150  
0499:1010=CLP-170  
0499:1011=P-250  
0499:1012=TYROS  
0499:1013=PF-500  
0499:1014=S90  
0499:1015=MOTIF-R  
0499:1016=MDP-5  
0499:1017=CVP-204  
0499:1018=CVP-206  
0499:1019=CVP-208  
0499:101A=CVP-210  
0499:101B=PSR-1100  
0499:101C=PSR-2100  
0499:101D=CLP-175  
0499:101E=PSR-K1  
0499:101F=EZ-J24  
0499:1020=EZ-250i  
0499:1021=MOTIF ES 6  
0499:1022=MOTIF ES 7  
0499:1023=MOTIF ES 8  
0499:1024=CVP-301  
0499:1025=CVP-303  
0499:1026=CVP-305  
0499:1027=CVP-307  
0499:1028=CVP-309  
0499:1029=CVP-309GP  
0499:102A=PSR-1500  
0499:102B=PSR-3000  
0499:102E=ELS-01/01C  
0499:1030=PSR-295/293  
0499:1031=DGX-205/203  
0499:1032=DGX-305  
0499:1033=DGX-505  
0499:1037=PSR-E403  
0499:103C=MOTIF-RACK ES  
0499:1054=S90XS Keyboard/Music Synthesizer  
0499:1FFF=Yamaha USB MIDI

0499:2000=DGP-7  
0499:2001=DGP-5  
0499:3001=Yamaha HID Audio Controls  
0499:3001:02=Yamaha HID Audio Controls  
0499:3003=YST-M45D USB Speaker  
0499:3101=Yamaha USB Audio  
0499:4000=NetVolante RTA54i Broadband&ISDN Router  
0499:4001=NetVolante RTW65b Broadband Wireless Router  
0499:4002=NetVolante RTW65i Broadband&ISDN Wireless Router  
0499:4004=NetVolante RTA55i Broadband VoIP Router  
0499:5000=CS1D  
0499:5001=DSP1D  
0499:5002=DME32  
0499:5003=DM2000  
0499:5004=02R96  
0499:5005=ACU16-C  
0499:5006=NHB32-C  
0499:5007=DM1000  
0499:5008=01V96  
0499:5009=SPX2000  
0499:500A=PM5D  
0499:500B=DME64N  
0499:500C=DME24N  
0499:6001=CRW2200UX Lightspeed 2 External CD-RW Drive  
0499:7000=DTX  
0499:7010=UB99  
049A=Gandalf Technologies  
049B=System Connection  
049C=Acer Advanced Labs  
049C:0002=Keyboard (???)  
049D=VLSI Technology  
049F=Compaq  
049F:0002=InkJet Color Printer  
049F:0003=Compaq iPAQ USB Sync  
049F:000E=Compaq Internet Keyboard  
049F:000E:01=Compaq Internet Keyboard Hot Keys  
049F:0012=InkJet Color Printer  
049F:0018=Compaq Personal Audio Player PA-1  
049F:0019=InkJet Color Printer  
049F:001A=COMPAQ S4-100  
049F:001E=IJ650 Inkjet Printer  
049F:001F=WL215 Adapter  
049F:0021=S200 Scanner  
049F:0027=Bluetooth Multiport Module by Compaq  
049F:002A=1400P Inkjet Printer  
049F:002B=A3000  
049F:002C=Lexmark X125  
049F:0032=Compaq iPAQ USB Sync  
049F:0033=801.11b Adapter [orinoco]  
049F:0036=Compaq Bluetooth Multiport Firmware Upgrade Module  
049F:0051=KU-0133 Easy Access Internet Keyboard  
049F:0054=EKE USB Floppy  
049F:0076=Wireless LAN MultiPort W200  
049F:0080=Compaq GPRS Multiport  
049F:0086=HP nx7000  
049F:0086:1393=HP nx7000  
049F:504A=Personal Jukebox PJB100  
049F:505A=SA-11x0 based Linux Device, or Itsy (experimental)  
049F:8511=iPAQ Networking 10/100 Ethernet [pegasus2]  
049F:F511=USB 5-Port Hub



04A0=Digital Equipment  
04A1=SystemSoft  
04A1:FFF0=Telex Composite USB Device  
04A2=FirePower Systems  
04A3=Trident Microsystems  
04A4=Hitachi  
04A4:0004=DVD-CAM DZ-MV100A Camcorder  
04A4:0014=Hitachi USB Sync  
04A4:001E=DVDCAM USB HS Interface  
04A5=BenQ  
04A5:0001=API Generic USB K/B  
04A5:0002=API Ergo USB K/B  
04A5:0003=API Generic USB K/B Mouse  
04A5:0003:01=API Generic USB K/B Mouse  
04A5:1025=BenQ SDVD TW400S USB Device  
04A5:12A6=Scan C310U  
04A5:1A20=Color Flatbed Scanner 340U  
04A5:1A2A=Color Flatbed Scanner 640U  
04A5:2022=Color Flatbed Scanner 340U  
04A5:2040=Color Flatbed Scanner 640U+  
04A5:205E=ScanPrisa 640BU  
04A5:2060=Color Flatbed Scanner 640U  
04A5:207E=Acer/BenQ 640BU  
04A5:209E=ScanPrisa 640BT  
04A5:20AE=S2W 3000U  
04A5:20B0=S2W 4300U/3300U Scanner  
04A5:20BE=Acer/BenQ 640BT  
04A5:20C0=1240UT/5100U Scanner  
04A5:20DE=S2W 4300U/3300U Scanner  
04A5:20F8=Acer/BenQ 5000  
04A5:20FC=Acer/BenQ 5000  
04A5:20FE=Acer/BenQ 5300  
04A5:211F=Acer/BenQ ScanWit 2750  
04A5:2137=Acer/BenQ 5150/5250  
04A5:2202=7400UT  
04A5:2311=5560  
04A5:3002=DC2110 Driver  
04A5:3003=WebCam  
04A5:3003:01=DC 1300 WDM DSC Bulk Driver  
04A5:3004=Digital Still Camera 4500 Dirver  
04A5:3008=1500  
04A5:300A=3410  
04A5:300A:01=DC3410 Still Camera Device  
04A5:300C=1016  
04A5:300C:01=DC1016 series Still Camera Device  
04A5:300D=DC1016 USB Mass Storage Device  
04A5:300E=Digital Camera Driver  
04A5:300F=Digital Camera Driver  
04A5:3013=USB Device  
04A5:3015=USB Mass Storage Device  
04A5:3016=Composite USB Device  
04A5:3019=DC C40  
04A5:3023=USB Device  
04A5:3028=Digital Camera  
04A5:3038=USB Mass Storage Device  
04A5:3039=DSC-E Video Camera Device  
04A5:3039:01=DSC-E Still Camera Device  
04A5:303F=DC C500  
04A5:4000=P30 Composite Device  
04A5:4010=Mobile Phone

04A5:4010:01=Diagnostic Interface  
04A5:4010:02=NMEA Device  
04A5:4013=Mobile Phone  
04A5:4013:01=Diagnostic Interface  
04A5:4013:02=NMEA Device  
04A5:4044=BenQ-Siemens SF71  
04A5:4045=BenQ-Siemens E81  
04A5:4048=BenQ M7  
04A5:6001=USB Mass Storage Device  
04A5:6002=USB Mass Storage Device  
04A5:6003=USB Mass Storage Device  
04A5:6004=USB Mass Storage Device  
04A5:6005=USB Mass Storage Device  
04A5:6006=USB Mass Storage Device  
04A5:6007=USB Mass Storage Device  
04A5:6008=USB Mass Storage Device  
04A5:6009=USB Mass Storage Device  
04A5:600A=USB Mass Storage Device  
04A5:600B=USB Mass Storage Device  
04A5:600C=USB Mass Storage Device  
04A5:600D=USB Mass Storage Device  
04A5:600E=USB Mass Storage Device  
04A5:600F=USB Mass Storage Device  
04A5:6010=USB Mass Storage Device  
04A5:6011=USB Mass Storage Device  
04A5:6012=USB Mass Storage Device  
04A5:6013=USB Mass Storage Device  
04A5:6014=USB Mass Storage Device  
04A5:6015=USB Mass Storage Device  
04A5:6103=DP200 98 USB Mass Drive  
04A5:6125=MP3 Player  
04A5:6180=MP3 Player  
04A5:6200=JoyBee 120 MP3 Player  
04A5:6200:0001=JoyBee 120 MP3 Player  
04A5:6200:0001:01=JoyBee 120 MP3 Player  
04A5:620A=USB Driver  
04A5:6210=JoyBee 120 MP3 Player  
04A5:6210:0001=JoyBee 120 MP3 Player  
04A5:6510=Joybee 150 Win98 USB MASS Storage Driver  
04A5:7008=Acer 6511-UV USB Keyboard  
04A5:7500=Hi-Speed Mass Storage Device  
04A5:9000=AWL300 Wireless Adapter  
04A5:9001=AWL400 Wireless Adapter  
04A5:9213=Kbd Hub  
04A6=Nokia Display Products  
04A6:00B9=Nokia USB Audio  
04A6:0180=Nokia USB Hub Type P  
04A6:0181=Nokia HID Monitor Controls  
04A6:0181:02=Nokia USB Monitor Control  
04A7=Visioneer  
04A7:0100=Visioneer Strobe Pro USB Scanner  
04A7:0101=Visioneer Strobe Pro USB Scanner  
04A7:0102=StrobePro Scanner  
04A7:0201=Visioneer 3100 USB Scanner  
04A7:0211=Visioneer OneTouch 7600  
04A7:0221=Visioneer OneTouch 5300  
04A7:0223=OneTouch 8200  
04A7:0224=VistaScan Astra 3600 (ENG)  
04A7:0225=VistaScan Astra 3600 (ENG)  
04A7:0226=VistaScan Astra 3600 (ENG)

04A7:0229=VistaScan Astra 3600 (ENG)  
04A7:022A=VistaScan Astra 3600 (ENG)  
04A7:022C=VistaScan Astra 3600 (ENG)  
04A7:0231=Visioneer 6100 USB  
04A7:0311=6200 EPP/USB Scanner  
04A7:0321=Visioneer OneTouch 8100 USB  
04A7:0331=Visioneer 8650  
04A7:0341=Visioneer 6400 USB  
04A7:0361=VistaScan Astra 3600 (ENG)  
04A7:0362=OneTouch 9320  
04A7:0371=OneTouch 8700/8920  
04A7:0380=OneTouch 7700  
04A7:0382=Photo Port 7700  
04A7:0390=Visioneer 9650  
04A7:03A0=Xerox 4800 One Touch  
04A7:0410=OneTouch Pro 8800/8820  
04A7:0420=Visioneer 9320  
04A7:0421=Visioneer 9450  
04A7:0422=Visioneer 9550  
04A7:0423=Visioneer 9750 USB Scanner  
04A7:0424=Visioneer XP450  
04A7:0425=Strobe XP 100  
04A7:0426=Strobe XP 200  
04A7:0427=Strobe XP 100  
04A7:0444=OneTouch 7300  
04A7:0445=CardReader 100  
04A7:0446=Xerox DocuMate510  
04A7:0447=Xerox DocuMate520  
04A7:0448=Xerox DocuMate250  
04A7:0449=Xerox DocuMate252  
04A7:044A=Xerox 6400  
04A7:044C=Xerox DocuMate262  
04A7:0474=Strobe XP 300  
04A7:0475=Xerox DocuMate272  
04A7:0476=Xerox DocuMate632  
04A7:0477=Xerox DocuMate152  
04A7:0478=Xerox DocuMate752  
04A7:0479=Visioneer XP470  
04A7:047A=Visioneer 9450R  
04A7:047B=Visioneer 9650R  
04A7:047C=Xerox DocuMate510R  
04A7:047D=9420  
04A7:0480=9520  
04A7:048C=Xerox DocuMate252R  
04A7:048D=Xerox DocuMate262R  
04A7:048E=Xerox DocuMate272R  
04A7:048F=Visioneer XP470R  
04A7:0490=Xerox DocuMate250R  
04A7:0491=Visioneer XP450R  
04A7:0492=Xerox DocuMate520R  
04A7:0493=Visioneer 9750R  
04A7:0494=Strobe XP 120  
04A7:0495=Xerox DocuMate512  
04A7:0497=Visioneer 430  
04A7:0498=Xerox DocuMate632R  
04A7:0499=Visioneer 780  
04A7:049A=Xerox DocuMate752R  
04A7:049B=Strobe XP 100  
04A7:049C=Xerox DocuMate150  
04A7:049D=Xerox DocuMate162

04A7:04A0=7400  
04A7:04A7=Xerox DocuMate262i  
04A7:04AC=Xerox Travel Scanner 100  
04A8=Multivideo Labs  
04A8:0101=MultiVideo Labs USB Hub  
04A8:0303=Belkin USB Peripheral Switch  
04A8:0404=Belkin USB Peripheral Switch  
04A9=Canon  
04A9:1005=BJ Printer Hub  
04A9:1035=PD Printer Storage  
04A9:1050=BJC-8200  
04A9:1051=BJC-3000 Color Printer  
04A9:1052=BJC-6100  
04A9:1053=BJC-6200  
04A9:1054=BJC-6500  
04A9:1055=BJC-85  
04A9:1056=BJC-2100/2110 Color Printer  
04A9:1057=LR1  
04A9:105A=BJC-55  
04A9:105B=S600 Printer  
04A9:105C=S400  
04A9:105D=S450 Printer  
04A9:105E=S800  
04A9:1062=S500 Printer  
04A9:1063=S4500  
04A9:1064=S300 Printer  
04A9:1065=S100  
04A9:1066=S630  
04A9:1067=S900  
04A9:1068=S9000  
04A9:1069=S820  
04A9:106A=Canon S200SP  
04A9:106B=S520 Printer  
04A9:106D=S750 Printer  
04A9:106E=S820D  
04A9:1070=S530D  
04A9:1072=I850 Printer  
04A9:1073=I550 Printer  
04A9:1074=S330 Printer  
04A9:1076=i70  
04A9:1077=i950  
04A9:107A=S830D  
04A9:107B=i320  
04A9:107C=i470D  
04A9:107D=i9100  
04A9:107E=i450  
04A9:107F=i860  
04A9:1082=i350  
04A9:1084=i250  
04A9:1085=i255  
04A9:1086=i560  
04A9:1088=i965  
04A9:108A=i455  
04A9:108B=i900D  
04A9:108C=i475D  
04A9:108D=PIXMA iP2000  
04A9:108F=i80  
04A9:1090=i9900 Photo Printer  
04A9:1091=Canon PIXMA iP1500  
04A9:1093=PIXMA iP4000

04A9:1094=PIXMA iP3000x Printer  
04A9:1095=PIXMA iP6000D  
04A9:1097=PIXMA iP5000  
04A9:1098=PIXMA iP1000  
04A9:1099=PIXMA iP8500  
04A9:109C=PIXMA iP4000R  
04A9:109D=iP90  
04A9:10A0=PIXMA iP1600 Printer  
04A9:10A2=iP4200  
04A9:10A4=iP5200R  
04A9:10A5=iP5200  
04A9:10A7=iP6210D  
04A9:10A8=iP6220D  
04A9:10A9=iP6600D  
04A9:10B6=PIXMA iP4300 Printer  
04A9:10C2=PIXMA iP1800 Printer  
04A9:10C4=Pixma iP4500 Printer  
04A9:1404=W6400PG  
04A9:1405=W8400PG  
04A9:150F=BIJ2350 PCL  
04A9:1510=BIJ1350 PCL  
04A9:1512=BIJ1350D PCL  
04A9:1601=DR-2080C Scanner  
04A9:1607=DR-6080 Scanner  
04A9:1608=CANON DR-2580C USB  
04A9:1700=PIXMA MP110 Scanner  
04A9:1701=PIXMA MP130 Scanner  
04A9:1702=MP410 Composite  
04A9:1703=MP430 Composite  
04A9:1704=MP330 Composite  
04A9:1705=Canon Inkjet MP900  
04A9:1706=PIXMA MP750 Scanner  
04A9:1707=PIXMA MP780 Scanner  
04A9:1708=Canon Inkjet MP760/770  
04A9:1709=PIXMA MP150 Scanner  
04A9:170A=PIXMA MP170 Scanner  
04A9:170B=PIXMA MP450 Scanner  
04A9:170C=PIXMA MP500 Scanner  
04A9:170D=PIXMA MP800 Scanner  
04A9:170E=Canon MP800R  
04A9:1710=Canon MP950  
04A9:1712=Canon MP530  
04A9:1713=PIXMA MP830 Scanner  
04A9:1714=Canon MP160  
04A9:1715=Canon MP180  
04A9:1716=Canon MP460  
04A9:1717=Canon MP510  
04A9:1718=Canon MP600  
04A9:1719=Canon MP600R  
04A9:171A=Canon MP810  
04A9:171A:01=Canon MP810 Printer  
04A9:171A:02=Canon MP810 Disk Drive  
04A9:171B=Canon MP960  
04A9:171C=Canon MX7600 ser  
04A9:1721=Canon MP210 ser  
04A9:1722=Canon MP220 ser  
04A9:1723=Canon MP470 ser  
04A9:1724=Canon MP520 ser  
04A9:1725=Canon MP610 ser  
04A9:1726=Canon MP970 ser

04A9:1727=Canon MX300 ser  
04A9:1728=Canon MX310 ser  
04A9:1729=Canon MX700 ser  
04A9:172B=Canon MP140 ser  
04A9:172C=Canon MX850 ser  
04A9:172D=Canon MP980 ser  
04A9:172E=Canon MP630 ser  
04A9:172F=Canon MP620 ser  
04A9:1730=Canon MP540 ser  
04A9:1731=Canon MP480 ser  
04A9:1732=Canon MP240 ser  
04A9:1733=Canon MP260 ser  
04A9:1734=Canon MP190 ser  
04A9:1736=Canon MX320 ser  
04A9:173E=MP560  
04A9:173F=Pixma MP640 Multifunction device  
04A9:1748=Pixma MG5150  
04A9:1900=CanoScan LiDE 90  
04A9:1901=CanoScan 8800F  
04A9:1904=CanoScan LiDE 100  
04A9:1905=CanoScan LiDE 200  
04A9:1906=CanoScan 5600F  
04A9:1907=CanoScan LiDE 700F  
04A9:1909=CanoScan LiDE 110  
04A9:190A=CanoScan LiDE 210  
04A9:2200=CanoScan LiDE 25  
04A9:2201=CanoScan FB320U  
04A9:2202=CanoScan FB620U  
04A9:2204=CanoScan FB630U/FB636U  
04A9:2205=CanoScan FB1210U  
04A9:2206=CanoScan N650U/N656U  
04A9:2207=CanoScan 1220U  
04A9:2208=CanoScan D660U  
04A9:220A=CanoScan D2400UF  
04A9:220B=CanoScan D646U  
04A9:220C=CanoScan D1250U2  
04A9:220D=CanoScan LiDE 20/N670U/N676U  
04A9:220E=CanoScan LiDE 30/N1240U  
04A9:220F=CanoScan 8000F  
04A9:2210=CanoScan 9900F  
04A9:2212=CanoScan 5000F  
04A9:2213=LiDE 50  
04A9:2214=CanoScan LiDE 80  
04A9:2215=CanoScan 3000/3000F/3000ex  
04A9:2216=CanoScan 3200F  
04A9:2217=CanoScan 5400F/5200F  
04A9:2219=CanoScan 9950F  
04A9:221B=CanoScan 4200F  
04A9:221C=CanoScan LiDE 60  
04A9:221E=CanoScan 8400F  
04A9:221F=CanoScan LiDE 500F  
04A9:2220=CanoScan LiDE 25  
04A9:2224=CanoScan LiDE 600F  
04A9:2225=CanoScan LiDE 70  
04A9:2228=CanoScan 4400F  
04A9:2229=CanoScan 8600F  
04A9:2602=MultiPASS C555  
04A9:2603=MultiPASS C755  
04A9:260A=Canon CAPT USB Printer  
04A9:260E=LBP-2000

04A9:2610=MPC600F  
04A9:2611=SmartBase MPC400  
04A9:2612=MultiPASS C855  
04A9:2617=CAPT Printer  
04A9:261A=iR1600  
04A9:261B=iR1610  
04A9:261C=iC2300  
04A9:261F=Canon MPC200 Printer  
04A9:2621=iR2000  
04A9:2622=iR2010  
04A9:2623=FAX-B180C  
04A9:2629=FAXPHONE L75  
04A9:262B=Canon CAPT USB Printer  
04A9:262D=iR C3200  
04A9:262F=Canon Inkjet MP730 FAX  
04A9:262F:01=Canon Inkjet MP730  
04A9:2630=MultiPASS MP700  
04A9:2630:01=Canon Inkjet MP700  
04A9:2631=LASER CLASS 700  
04A9:2632=FAX-L2000  
04A9:2635=MPC190  
04A9:2637=iR C6800  
04A9:2638=iR C3100  
04A9:263C=Smartbase MP360  
04A9:263C:01=Canon Inkjet MP360  
04A9:263D=MP370  
04A9:263D:01=Canon Inkjet MP370  
04A9:263E=Canon Inkjet MP390 FAX  
04A9:263E:01=Canon Inkjet MP390  
04A9:263F=MP375  
04A9:263F:01=Canon Inkjet MP375  
04A9:2646=MF5530 Scanner Device V1.9.1  
04A9:2647=MF5550 Composite  
04A9:264C=Canon Inkjet MP740 FAX  
04A9:264C:01=Canon Inkjet MP740  
04A9:264D=PIXMA MP710  
04A9:264D:01=Canon Inkjet MP710  
04A9:264E=MF5630  
04A9:264F=MF5650 (FAX)  
04A9:2650=iR 6800C EUR  
04A9:2651=iR 3100C EUR  
04A9:2655=FP-L170/MF350/L380/L398  
04A9:2659=MF8100  
04A9:265B=CAPT Printer  
04A9:265C=iR C3220  
04A9:265D=MF5730  
04A9:265E=MF5750  
04A9:265F=MF5770  
04A9:2660=MF3110  
04A9:2663=iR3570/iR4570  
04A9:2664=iR2270/iR2870  
04A9:2665=iR C2620  
04A9:2666=iR C5800  
04A9:2667=iR85PLUS  
04A9:2669=iR105PLUS  
04A9:266A=CAPT Device  
04A9:266B=iR8070  
04A9:266C=iR9070  
04A9:266D=iR 5800C EUR  
04A9:266E=CAPT Device

04A9:266F=iR2230  
04A9:2670=iR3530  
04A9:2671=iR5570/iR6570  
04A9:2672=iR C3170  
04A9:2673=iR 3170C EUR  
04A9:2674=L120  
04A9:2675=iR2830  
04A9:2676=CAPT Device  
04A9:2677=iR C2570  
04A9:2678=iR 2570C EUR  
04A9:2679=CAPT Device  
04A9:267A=iR2016  
04A9:267B=iR2020  
04A9:267D=MF7100 Series  
04A9:2684=MF3200 Series  
04A9:2686=MF6500 Series  
04A9:2687=iR4530  
04A9:2688=LBP3460  
04A9:268C=iR C6870  
04A9:268D=iR 6870C EUR  
04A9:268E=iR C5870  
04A9:268F=iR 5870C EUR  
04A9:2691=iR7105  
04A9:26A3=MF4100 Series  
04A9:26B0=MF4600 Series  
04A9:26B4=MF4010 Series  
04A9:26B5=MF4200 Series  
04A9:3041=PowerShot S10  
04A9:3042=CanoScan FS4000US Film Scanner  
04A9:3043=PowerShot S20  
04A9:3044=EOS D30  
04A9:3045=PowerShot S100  
04A9:3046=IXY Digital  
04A9:3047=Digital IXUS  
04A9:3048=Canon PowerShot G1  
04A9:3049=PowerShot Pro90 IS  
04A9:304A=CP-10  
04A9:304B=IXY Digital 300  
04A9:304C=PowerShot S300  
04A9:304D=DIGITAL IXUS 300  
04A9:304E=PowerShot A20  
04A9:304F=PowerShot A10  
04A9:3050=IXY DIGITAL 200  
04A9:3051=PowerShot S110  
04A9:3052=DIGITAL IXUS v  
04A9:3053=Canon FS2720U  
04A9:3055=PowerShot G2  
04A9:3056=PowerShot S40  
04A9:3057=PowerShot S30  
04A9:3058=PowerShot A40  
04A9:3059=PowerShot A30  
04A9:305B=ZR45MC Digital Camcorder  
04A9:305C=PowerShot unknown 2  
04A9:3060=EOS D60  
04A9:3061=PowerShot A100  
04A9:3062=PowerShot A200  
04A9:3063=CP-100  
04A9:3065=PowerShot S200  
04A9:3066=Digital IXUS 330  
04A9:3067=MV550i Digital Video Camara



04A9:3069=PowerShot G3  
04A9:306A=Digital unknown 3  
04A9:306B=MVX2i Digital Video Camera  
04A9:306C=PowerShot S45  
04A9:306D=PowerShot S45 PtP Mode  
04A9:306E=PowerShot G3 (normal mode)  
04A9:306F=PowerShot G3 (ptp)  
04A9:3070=IXY 320, PS S230, IXUS v3  
04A9:3071=PowerShot S230 (ptp)  
04A9:3072=Canon Camera  
04A9:3073=Canon Camera  
04A9:3074=Canon Camera  
04A9:3075=Canon Camera  
04A9:3076=Canon Camera  
04A9:3077=Canon Camera  
04A9:3078=ZR70MC Digital Camcorder  
04A9:307A=MV650i (normal mode)  
04A9:307B=MV630i Digital Video Camera  
04A9:307C=MV630i (normal mode)  
04A9:307D=CP-300  
04A9:307F=Optura 20  
04A9:3080=MVX150i (normal mode) / Optura 20 (normal mode)  
04A9:3081=Optura 10  
04A9:3082=MVX100i / Optura 10  
04A9:3083=EOS 10D  
04A9:3084=EOS 300D / EOS Digital Rebel  
04A9:3085=PowerShot G5  
04A9:3087=Elura 50 (PTP mode)  
04A9:3088=Elura 50 (normal mode)  
04A9:308D=MVX3i  
04A9:308E=FV M1 (normal mode) / MVX 3i (normal mode) / Optura Xi (normal mode)  
04A9:3093=Optura 300  
04A9:3096=IXY DV M2 (normal mode) / MVX 10i (normal mode)  
04A9:3099=EOS 300D (ptp)  
04A9:309A=PowerShot A80  
04A9:309B=Digital IXUS (ptp)  
04A9:309C=PowerShot S1 IS  
04A9:309D=Camera  
04A9:309F=Canon Camera  
04A9:30A0=Canon Camera  
04A9:30A1=Canon Camera  
04A9:30A2=Canon Camera  
04A9:30A8=Elura 60E/Optura 40 (ptp)  
04A9:30A9=MVX25i (normal mode) / Optura 40 (normal mode)  
04A9:30B1=Canon Camera  
04A9:30B2=PowerShot S60 (normal mode) / PowerShot S60 (PTP mode)  
04A9:30B3=Canon Camera  
04A9:30B4=PowerShot S500  
04A9:30B5=PowerShot A75  
04A9:30B6=Digital IXUS II2 / Digital IXUS II2 (PTP mode) / PowerShot SD110 (PTP mode) / PowerShot SD110 Digital ELPH  
04A9:30B7=PowerShot A400 / PowerShot A400 (PTP mode)  
04A9:30B8=PowerShot A310 / PowerShot A310 (PTP mode)  
04A9:30B9=PowerShot A85  
04A9:30BA=PowerShot S410 Digital Elph  
04A9:30BB=PowerShot A95  
04A9:30BD=CP-220  
04A9:30BE=CP-330  
04A9:30BF=Canon Camera  
04A9:30C0=Canon Camera

04A9:30C1=Canon Camera  
04A9:30C2=Canon Camera  
04A9:30C4=Canon Camera  
04A9:30EA=EOS 1D Mark II (PTP mode)  
04A9:30EB=EOS 20D  
04A9:30EC=EOS 20D (ptp)  
04A9:30EE=EOS Kiss\_N REBEL\_XT 350D  
04A9:30EF=EOS 350D (ptp)  
04A9:30F0=Canon Camera  
04A9:30F1=Canon Camera  
04A9:30F2=Digital IXUS 700 (normal mode) / Digital IXUS 700 (PTP mode) / IXY Digital 600 (normal mode) / PowerShot SD500 (normal mode) /  
04A9:30F4=Canon Camera  
04A9:30F6=SELPHY CP400  
04A9:30F8=Canon Camera  
04A9:30F9=Canon Camera  
04A9:30FA=Canon Camera  
04A9:30FC=Canon Camera  
04A9:30FD=Canon Camera  
04A9:30FE=Digital IXUS 65 (PTP mode)/PowerShot SD630 (PTP mode)  
04A9:30FF=Canon Camera  
04A9:3101=EOS 5D  
04A9:310B=SELPHY CP600  
04A9:310E=Digital IXUS 50 (PTP mode)  
04A9:310F=Canon Camera  
04A9:3110=EOS Digital Rebel XTi  
04A9:3116=Canon Camera  
04A9:3117=PowerShot A700  
04A9:312D=Elura 100  
04A9:3138=PowerShot A710 IS  
04A9:3147=EOS 1Ds Mark III  
04A9:314F=PowerShot SD1000  
04A9:3155=PowerShot A450  
04A9:315A=PowerShot G9  
04A9:315D=PowerShot A720  
04A9:3160=Digital IXUS 860 IS  
04A9:3175=IXY Digital 25 IS  
04A9:3176=PowerShot A590  
04A9:317A=PowerShot A470  
04A9:3184=Digital IXUS 80 IS (PTP mode)  
04A9:3192=PowerShot SX110 IS  
04A9:319A=EOS 7D  
04A9:31BC=PowerShot D10  
04A9:31BF=PowerShot A480  
04A9:31C0=PowerShot SX200 IS  
04A9:31E5=Digital IXUS 200 IS  
04A9:31EE=SELPHY ES40  
04A9:31EF=PowerShot A495  
04A9:31F3=PowerShot Digital ELPH SD1400 IS  
04A9:31FF=Digital IXUS 55  
04A9:3210=PowerShot SX30 IS  
04A9:3214=SELPHY CP800  
04A9:3229=IXUS 220 HS  
04AA=DaeWoo Telecom  
04AB=Chromatic Research  
04AC=Micro Audiometrics  
04AD=DooIn Electronics  
04AD:0301=USB Sync 0301  
04AD:0302=USB Sync 0302  
04AD:0303=USB Sync 0303

04AD:2501=Panasonic Bluetooth Device  
04AF=Winnov L.P.  
04B0=Nikon  
04B0:0102=Nikon Coolpix 990  
04B0:0103=Nikon Coolpix 880  
04B0:0104=Coolpix 995  
04B0:0106=Coolpix 775  
04B0:0107=Coolpix 5000  
04B0:0108=Coolpix 2500  
04B0:0109=Nikon COOLPIX2500  
04B0:010A=Nikon Digital Camera E4500  
04B0:010B=Coolpix 4500 (ptp)  
04B0:010D=Coolpix 5700 (ptp)  
04B0:010E=Coolpix 4300 (storage)  
04B0:010F=Nikon COOLPIX4300  
04B0:0110=Coolpix 3500 (Sierra Mode)  
04B0:0111=Nikon COOLPIX3500  
04B0:0112=Nikon COOLPIX885  
04B0:0113=Coolpix 5000 (ptp)  
04B0:0114=Coolpix 3100 (storage)  
04B0:0115=Coolpix 3100 (ptp)  
04B0:0117=Coolpix 2100 (ptp)  
04B0:0119=Coolpix 5400 (ptp)  
04B0:011D=Coolpix 3700 (ptp)  
04B0:0121=Coolpix 3200 (ptp)  
04B0:0122=Coolpix 2200 (ptp)  
04B0:0124=Coolpix 8400 (mass storage mode)  
04B0:0125=Coolpix 8400 (ptp)  
04B0:0126=Coolpix 8800  
04B0:0129=Coolpix 4800 (ptp)  
04B0:012C=Coolpix 4100 (storage)  
04B0:012D=Coolpix 4100 (ptp)  
04B0:012E=Coolpix 5600 (ptp)  
04B0:0130=Coolpix 4600 (ptp)  
04B0:0135=Coolpix 5900 (ptp)  
04B0:0136=Coolpix 7900 (storage)  
04B0:0137=Coolpix 7900 (ptp)  
04B0:013A=Coolpix 100 (storage)  
04B0:013B=Coolpix 100 (ptp)  
04B0:0141=Coolpix P2 (storage)  
04B0:0142=Coolpix P2 (ptp)  
04B0:0163=Coolpix P5100 (ptp)  
04B0:0169=Coolpix P50 (ptp)  
04B0:0202=Coolpix SQ (ptp)  
04B0:0203=Coolpix 4200 (mass storage mode)  
04B0:0204=Coolpix 4200 (ptp)  
04B0:0205=Coolpix 5200 (storage)  
04B0:0206=Coolpix 5200 (ptp)  
04B0:0301=Coolpix 2000 (storage)  
04B0:0302=Nikon COOLPIX2000  
04B0:0317=Coolpix L20 (ptp)  
04B0:0402=DSC D100 (ptp)  
04B0:0403=D2H (mass storage mode)  
04B0:0404=D2H SLR (ptp)  
04B0:0405=D70 (mass storage mode)  
04B0:0406=DSC D70 (ptp)  
04B0:0408=D2X SLR (ptp)  
04B0:0409=D50 digital camera  
04B0:040A=D50 (ptp)  
04B0:040C=D2Hs

04B0:040E=DSC D70s (ptp)  
04B0:040F=D200 (mass storage mode)  
04B0:0410=D200 (ptp)  
04B0:0413=D40 (mass storage mode)  
04B0:0422=D700 (ptp)  
04B0:0425=D300S  
04B0:0F03=PD-10 Wireless Printer Adapter  
04B0:4000=Nikon LS-40  
04B0:4001=Nikon LS-50  
04B0:4002=Nikon LS-5000  
04B1=Pan International  
04B3=IBM  
04B3:3003=IBM Rapid Access III Keyboard  
04B3:3004=Media Access Pro Keyboard  
04B3:300A=IBM Rapid Access IIIe Keyboard  
04B3:3016=UltraNav Keyboard Hub  
04B3:3018=UltraNav Keyboard  
04B3:301A=SK-8815 USB Multimedia Keyboard  
04B3:301B=SK-8815 Keyboard  
04B3:301B:01=USB Enhanced Performance Keyboard  
04B3:301C=Enhanced Performance Keyboard  
04B3:301C:01=USB Enhanced Performance Keyboard  
04B3:3020=USB Enhanced Performance Keyboard  
04B3:3020:01=Lenovo Wireless USB 3-Button Wheel Mouse  
04B3:3025=USB NetVista Keyboard  
04B3:3100=IBM USB Mouse  
04B3:3100:0441=USB Mouse Model MO09KZ  
04B3:3103=ScrollPoint Pro Mouse  
04B3:3104=ScrollPoint Wireless Mouse  
04B3:3105=Lenovo ScrollPoint Optical (HID)  
04B3:3107=ThinkPad 800dpi Optical Travel Mouse  
04B3:3108=800dpi Optical Mouse w/ Scroll Point  
04B3:3109=Optical ScrollPoint Pro Mouse  
04B3:310B=Red Wheel Mouse  
04B3:310C=Lenovo USB Optical Wheel Mouse (HID)  
04B3:310D=USB Optical Wheel Mouse  
04B3:4010=IBM USB Remote NDIS Network Device  
04B3:4427=IBM USB CD-ROM Drive  
04B3:4482=IBM USB Serial Converter  
04B3:4485=Serial Converter  
04B3:4525=Double sided CRT  
04B3:4550=NVRAM (128 KB)  
04B3:4554=Cash Drawer  
04B3:4580=Hub w/ NVRAM  
04B3:4581=4800-2xx Hub w/ Cash Drawer  
04B3:4604=Keyboard w/ Card Reader  
04B3:4671=4820 LCD w/ MSR/KB  
04B3:7512=FlatBed Scanner(Italian)  
04B4=Cypress  
04B4:0000=Dacal DC-101 CD Library  
04B4:0001=Cypress USB Mouse  
04B4:0002=CY7C63x0x Thermometer  
04B4:0033=Mouse  
04B4:00FF=Cypress USB to PS2 Keyboard  
04B4:00FF:01=Cypress USB to PS2 Mouse  
04B4:0100=Cino FuzzyScan F760-B  
04B4:0101=Keyboard/Hub  
04B4:0102=Cypress USB Keyboard with APM  
04B4:0130=MyIRC Remote Receiver  
04B4:0306=Telephone Receiver

04B4:0407=Optical Skype Mouse  
04B4:0BAD=MetaGeek Wi-Spy  
04B4:1002=CY7C63001 R100 FM Radio  
04B4:1006=Synaptics DisplayPad  
04B4:1111=Dynamite PLUS USB  
04B4:1112=Dynamite PLUS v.2.0 USB  
04B4:1224=Naos 5000 Mouse  
04B4:2050=USB Hub  
04B4:2222=CAS Interface 3 USB  
04B4:2223=CAS2 PLUS USB  
04B4:2225=CAS2 PLUS v.2.0 USB  
04B4:2830=Operal DVB-S (cold state)  
04B4:3232=CAS Interface 3 USB  
04B4:4381=SCAPS USC-1 Scanner Controller  
04B4:4611=USB Storage Adapter FX2 (TPP)  
04B4:4616=USB Flash Disk (TPP)  
04B4:4C67=eHome Infrared Receiver (USBCIR)  
04B4:5201=Combi Keyboard-Hub (Hub)  
04B4:5202=Combi Keyboard-Hub (Keyboard)  
04B4:5500=HID->COM RS232 Adapter  
04B4:6370=ViewMate Desktop Mouse CC2201  
04B4:6473=CAS Interface 3 USB  
04B4:6560=Hi-Speed 4-Port USB 2.0 Hub  
04B4:6830=USB Storage Adapter AT2 (TPP)  
04B4:6831=USB Storage Adapter ISD-300LP (CY)  
04B4:7417=Wireless PC Lock  
04B4:8329=USB Keyboard  
04B4:8329:01=USB Mouse  
04B4:8613=CY7C68013 EZ-USB FX2 USB 2.0 Development Kit  
04B4:8614=DTV-DVB UDST7020BDA DVB-S Box(DVBS for MCE2005)  
04B4:861F=Anysee E30 USB 2.0 DVB-T Receiver  
04B4:BCA1=Barcode Reader  
04B4:CC04=Centor USB RACIA-ALVAR USB PORT  
04B4:CC06=Centor-P RACIA-ALVAR USB PORT  
04B4:D5D5=CY7C63x0x Zoltrix Z-Boxer GamePad  
04B4:DE61=Barcode Reader  
04B4:DE64=Barcode Reader  
04B4:F000=CY30700 Licorice evaluation board  
04B4:F111=CY8CKIT-002 PSoC MiniProg3 Rev A Program and debug kit  
04B4:F115=PSoC FirstTouch Programmer  
04B5=ROHM  
04B5:3064=Hantek DSO-3064  
04B6=Hint  
04B7=Compal Electronics  
04B8=Seiko Epson  
04B8:0001=Epson Stylus 740 USB Printer  
04B8:0002=ISD Smart Cable for Mac  
04B8:0003=ISD Smart Cable  
04B8:0004=Printer  
04B8:0005=Stylus C61/C44UX Printer  
04B8:0005:0100=Stylus C62 Printer  
04B8:0006=Printer  
04B8:0007=Printer  
04B8:0101=Epson Perfection 636U/GT-7000U  
04B8:0102=Epson GT-2200  
04B8:0103=Epson Perfection 610/GT-6600  
04B8:0104=Epson Perfection 1200U/GT-7600U  
04B8:0105=Epson StylusScan 2000  
04B8:0105:0100=EPSON StylusScan 2000  
04B8:0106=Epson StylusScan 2500

04B8:0106:0100=EPSON StylusScan 2500  
04B8:0107=Epson Expression 1600/ES-2000  
04B8:0108=Epson CC-700/ES-8000  
04B8:0109=Epson Expression 1640XL/ES-8500  
04B8:010A=Epson Perfection 1640SU/GT-8700F  
04B8:010B=Epson Perfection 1240/GT-7700U  
04B8:010C=Epson Perfection 640U Scanner  
04B8:010E=Epson Expression 1680/ES-2200  
04B8:010F=Epson Perfection 1250  
04B8:0110=Epson Perfection 1650/GT-8200U  
04B8:0111=Epson Perfection 2450/GT-9700  
04B8:0112=Epson Perfection 2450/GT-9700  
04B8:0114=Epson Perfection 660  
04B8:0116=Epson Perfection 3170/GT-9400  
04B8:0118=Epson Perfection 4180/GT-F600  
04B8:0119=Perfection 4490 Photo  
04B8:011A=Epson 1000 ICS  
04B8:011B=Epson Perfection 2400/GT-9300UF  
04B8:011C=Epson Perfection 3200/GT-9800F  
04B8:011D=Epson Perfection 1260  
04B8:011E=Epson Perfection 1660/GT-8300U  
04B8:011F=Epson Perfection 1670/GT-8400UF  
04B8:0120=Epson Perfection 1270/GT-7400U  
04B8:0121=Epson Perfection 2480/2580/GT-F500/GT-F550  
04B8:0122=Epson Perfection 3490/3590/GT-F520/GT-F570  
04B8:0126=Epson GT-15000/ES-7000H  
04B8:0128=Epson Perfection 4870/GT-X700  
04B8:0129=Epson Expression 10000XL/ES-10000G  
04B8:012A=Epson Perfection 4990/GT-X800  
04B8:012B=Epson GT-2500  
04B8:012C=Epson Perfection V700/GT-X900  
04B8:012D=Epson Perfection V100/GT-S600  
04B8:012F=Epson Perfection V350/GT-F700  
04B8:0130=Perfection V500 (GT-X770)  
04B8:0131=Perfection V300  
04B8:0136=GT-S80 (ES-D400)  
04B8:0137=GT-S50 (ES-D200)  
04B8:0138=Epson GT-20000/ES-H7200  
04B8:0202=Receipt Printer M129C  
04B8:0401=Epson CP 800 Digital Camera  
04B8:0402=Epson PhotoPC 850Z Digital Camera  
04B8:0403=Epson PhotoPC 3000Z Digital Camera  
04B8:0509=JVC PIX-MC10  
04B8:0601=Stylus Photo 875DC Card Reader  
04B8:0602=Stylus Photo 895 Card Reader  
04B8:0801=Epson Stylus CX5200/CX5100  
04B8:0802=Epson Stylus CX3200/CX3100  
04B8:0802:01=Epson USB Printer (Composite Device)  
04B8:0803=Printer (Composite Device)  
04B8:0804=Storage Device  
04B8:0805=Epson Stylus CX6400/CX6300  
04B8:0806=Epson Stylus Photo RX600  
04B8:0807=Epson Stylus Photo RX500/RX510  
04B8:0808=Epson Stylus CX5400/CX5300  
04B8:0809=Storage Device  
04B8:080A=Epson F-3200  
04B8:080C=ME100  
04B8:080D=Epson Stylus CX4600/CX4500  
04B8:080E=Epson Stylus CX3600/CX3500  
04B8:080F=Epson Stylus Photo RX420/RX430

04B8:0810=Epson RX700/PM-A900  
04B8:0811=Epson Stylus Photo RX620/RX630  
04B8:0812=MFP Composite Device  
04B8:0813=Epson Stylus CX6600/CX6500  
04B8:0814=(PM-A700)  
04B8:0815=Epson AL-CX11/LP-A500  
04B8:0816=Printer (Composite Device)  
04B8:0817=Epson LP-M5500  
04B8:0818=Epson CX3700/3800/DX3800  
04B8:0819=Epson CX4700/4800/DX4800/PX-A650  
04B8:081A=Epson RX520/530/PM-A750  
04B8:081B=MFP Composite Device  
04B8:081C=Epson RX640/650/PM-A890  
04B8:081D=Epson PM-A950  
04B8:081E=MFP Composite Device  
04B8:081F=Epson CX7700/7800  
04B8:0820=Epson CX4100/4200/DX4200  
04B8:0821=Epson CX5700F/CX5800F  
04B8:0822=Storage Device  
04B8:0823=MFP Composite Device  
04B8:0824=Storage Device  
04B8:0825=MFP Composite Device  
04B8:0826=Storage Device  
04B8:0827=Epson RX560/580/590/PM-A820  
04B8:0828=Epson PM-A970  
04B8:0829=Epson PM-T990  
04B8:082A=Epson PM-A920  
04B8:082B=Epson CX4900/5000/DX5000  
04B8:082C=Storage Device  
04B8:082D=Storage Device  
04B8:082E=Epson CX5900/6000/DX6000/PX-A720  
04B8:082F=Epson CX3900/4000/DX4000/PX-A620  
04B8:0830=Epson CX2800/2900/4080/ME200  
04B8:0831=Epson CX6900F/CX7000F/DX7000F  
04B8:0832=MFP Composite Device  
04B8:0833=Epson LP-M5600  
04B8:0834=Epson LP-M6000  
04B8:0835=Epson AL-CX21  
04B8:0836=Epson PM-T960  
04B8:0837=Epson RX680/685/690/PM-A940  
04B8:0838=Epson CX7300/7400/DX7400/PX-A640  
04B8:0839=Epson CX8300/8400/DX8400/PX-A740  
04B8:083A=Epson CX9300F/9400Fax/DX9400F/PX-FA700  
04B8:083B=MFP Composite Device  
04B8:083C=Epson RX585/595/610/PM-A840/A840S  
04B8:083D=MFP Composite Device  
04B8:083E=MFP Composite Device  
04B8:083F=Epson CX4300/CX4400/CX5500/CX5600/DX4400  
04B8:0841=Epson NX100/TX100/SX100/ME 300/PX-401A  
04B8:0843=Epson LP-M5000  
04B8:0844=Epson Artisan800/PX800/TX800/EP-901A/901F  
04B8:0846=Epson Artisan700/PX700/TX700/EP-801A  
04B8:0847=Epson BX600/SX600/TX600FW/WorkForce 600/ME 700/PX-601F  
04B8:0848=Epson BX300F/NX300/TX300F/ME 600F  
04B8:0849=Epson NX200/SX200/TX200  
04B8:084A=Epson NX400/SX400/TX400/PX-501A  
04B8:084C=Epson WorkForce 500  
04B8:084D=Stylus SX115  
04B8:0851=Stylus SX410  
04B8:0856=Stylus SX515W

04B8:085C=Stylus SX125  
04B9=Rainbow Technologies  
04B9:0300=SafeNet USB SuperPro/UltraPro  
04B9:0300:01=Rainbow USB SuperPro  
04B9:0301=SafeNet USB Security Security Token  
04B9:0302=SafeNet USB Security Security Token  
04B9:0303=SafeNet USB Security Security Token  
04B9:0304=SafeNet USB Security Security Token  
04B9:1000=iKey 1000 Token  
04B9:1001=iKey 1200 Token  
04B9:1002=iKey Token  
04B9:1003=iKey Token  
04B9:1004=iKey Token  
04B9:1005=iKey Token  
04B9:1006=iKey Token  
04B9:1200=iKey 2000 Token  
04B9:1201=iKey Token  
04B9:1202=iKey 2032 Token  
04B9:1203=iKey Token  
04B9:1204=iKey Token  
04B9:1205=iKey Token  
04B9:1206=iKey Token  
04B9:1300=iKey 3000 Token  
04B9:1301=iKey 3000  
04B9:1302=iKey Token  
04B9:1303=iKey Token  
04B9:1304=iKey Token  
04B9:1305=iKey Token  
04B9:1306=iKey Token  
04B9:8000=SafeNet Sentinel Hardware Key  
04B9:8001=SafeNet Sentinel Hardware Key/T  
04B9:8002=SafeNet Sentinel Hardware Key/M  
04B9:8003=SafeNet Sentinel Hardware Key/MT  
04B9:8004=SafeNet Sentinel Dual Hardware Key  
04B9:8005=SafeNet Sentinel Dual Hardware Key/T  
04BA=Toucan Systems  
04BB=I-O Data Device  
04BB:0101=I-O DATA USB2-IDE/ATAPI Bridge Adapter  
04BB:0201=I-O DATA USB2-IDE/ATAPI Bridge Adapter  
04BB:0204=DVD Multi-plus unit iU-CD2  
04BB:0206=DVD Multi-plus unit DVR-UEH8  
04BB:0301=USB Storage Device  
04BB:0314=USB-SSMRW SD-card  
04BB:0319=I-O DATA USB2-IDE/ATAPI Bridge Adapter  
04BB:031A=I-O DATA USB2-IDE/ATAPI Bridge Adapter  
04BB:031B=I-O DATA USB2-IDE/ATAPI Bridge Adapter  
04BB:031E=USB-SDRW SD-card  
04BB:0502=Nogatech Live! (BT)  
04BB:0528=GV-USB Video Capture  
04BB:0901=USB ETT  
04BB:0904=ET/TX Ethernet [pegasus]  
04BB:0913=I-O Data USB-ET/TX-S USB Ethernet Adapter  
04BB:0919=USB WN-B11  
04BB:0922=IOData AirPort WN-B11/USBS 802.11b  
04BB:0930=ETG-US2  
04BB:0937=I-O DATA WN-WAG/USL Wireless LAN Adapter  
04BB:0938=I-O DATA WN-G54/USL Wireless LAN Adapter  
04BB:093B=WN-GDN/USB  
04BB:093D=I-O DATA WN-G54/USB Wireless LAN Adapter  
04BB:093F=WNGDNUS2 802.11n (ar9170)



04BB:0944=I-O DATA WHG-AGDN/US Wireless LAN Adapter  
04BB:0945=I-O DATA WN-GDN/US3 Wireless LAN Adapter  
04BB:0947=I-O DATA WN-G150U Wireless LAN Adapter  
04BB:0948=I-O DATA WN-G300U Wireless LAN Adapter  
04BB:094B=I-O DATA WN-AG300U Wireless LAN Adapter  
04BB:0A03=Serial USB-RSAQ1  
04BB:0A07=I-O DATA USB2-iCN Adapter  
04BB:0A08=I-O DATA USB2-iCN Adapter  
04BB:0C01=FM-10 Pro Disk  
04BB:0F10=AVMC321 Digital Video  
04BD=Toshiba Electronics Taiwan  
04BE=Telia Research AB  
04BF=TDK  
04BF:0100=MediaReader CF  
04BF:0115=USB-PDC Adapter UPA9664  
04BF:0116=USB-cdmaOne Adapter UCA1464  
04BF:0117=USB-PHS Adapter UHA6400  
04BF:0118=USB-PHS Adapter UPA6400  
04BF:0135=TDK MediaReader Dual  
04BF:0202=73S1121F USB Smart Card Reader-  
04BF:0309=Bluetooth Adapter  
04BF:030A=IBM USB Bluetooth Ultraport Module  
04BF:030B=TDK Bluetooth Firmware Upgrade Device  
04BF:030C=Bluetooth Ultraport Firmware Upgrade Device  
04BF:0310=IBM Integrated Bluetooth  
04BF:0311=IBM Integrated Bluetooth Firmware Upgrade Device  
04BF:0317=Bluetooth Ultraport Module from IBM  
04BF:0318=IBM Integrated Bluetooth  
04BF:0319=TDK Bluetooth USB Adapter  
04BF:0320=TDK Bluetooth USB Adapter  
04BF:0321=TDK Bluetooth USB Firmware Upgrade Device  
04BF:0A28=INDI AV-IN Device  
04C1=U.S. Robotics  
04C1:0020=56K Voice Pro  
04C1:0022=56K Voice Pro  
04C1:007E=3Com U.S. Robotics USB ISDN TA  
04C1:0082=ISDN TA Pro  
04C1:008F=56k Voice Faxmodem  
04C1:0097=OfficeConnect Analog  
04C1:0097:02=3Com-USR USB Modem  
04C1:009D=HomeConnect WebCam [vicam]  
04C1:00A9=U.S. Robotics ISDN Pro TA-U USB  
04C1:00B9=3Com HomeConnect IDSL Modem  
04C1:3021=3Com-USR 56K Voice Pro  
04C1:F000=3COM OfficeConnect Cable Modem  
04C2=Method Electronics Far East  
04C3=Maxi Switch  
04C3:1101=Maxi Switch, Inc. #1101  
04C3:1102=Maxi Switch, Inc. #1102 Mouse  
04C3:1102:01=Maxi Switch, Inc. #1102 Mouse  
04C3:2101=Maxi Switch, Inc. #2101  
04C3:2102=Maxi Switch, Inc. #2102 Mouse  
04C3:2102:01=Maxi Switch, Inc. #2102 Mouse  
04C4=Lockheed Martin Energy Research  
04C5=Fujitsu  
04C5:1014=FUJITSU USB Data Cable  
04C5:1018=Fujitsu 109 Japanese USB Keyboard  
04C5:1020=Fujitsu USB Hot Buttons  
04C5:1020:01=Fujitsu USB Hot Buttons  
04C5:1022=Fujitsu 109 Japanese USB Keyboard

04C5:1029=fi-4010c Scanner  
04C5:102A=Smartaccess Smart Card Reader  
04C5:102C=USB Storage Adapter V3 (TPP)  
04C5:1033=fi-4110CUd  
04C5:1039=USB Storage Adapter V3 (TPP)  
04C5:1041=Fujitsu fi-4120Cdj Scanner  
04C5:1042=fi-4120c Scanner  
04C5:1058=FUJITSU USB Sync  
04C5:105B=AH-F401U Air H device  
04C5:1065=Fujitsu AAVID USB Function  
04C5:106D=Fujitsu AAVID USB Function  
04C5:1072=Fujitsu Smart Display  
04C5:1079=FUJITSU USB Sync  
04C5:1096=fi-5110EOX  
04C5:1097=fi-5110C  
04C5:10AE=fi-4120C2  
04C5:10AF=fi-4220C2  
04C5:10E0=fi-5120c Scanner  
04C5:10E1=fi-5220C  
04C5:10E7=fi-5900C  
04C5:10FE=S500  
04C5:1150=fi-6230  
04C5:12AE=HID-Compliant Keyboard  
04C5:12AE:01=HID Keyboard Power Key  
04C5:201D=USB 2.0 Mass Storage Device [MB86C30A-REB]  
04C6=Toshiba America Electronic  
04C7=Micro Macro Technologies  
04C8=Konica  
04C8:0720=USB Video Camera for Intel Proshare technology  
04C8:0720:0100=USB Video Camera for Intel Proshare technology  
04C8:0721=e-miniD Camera  
04C8:0722=e-mini  
04C8:0723=KD-200Z Camera  
04C8:0726=KD-310Z Camera  
04C8:0728=Revio C2 Mass Storage Device  
04C8:0729=Revio C2 Digital Camera  
04C8:072C=Revio KD20M  
04C8:072D=Revio KD410Z  
04C9:F101=Lucent USB Modem  
04CA=Lite-On Technology  
04CA:11AD=Broadcom Bluetooth 2.1 + EDR USB Device  
04CA:1766=Lite On HID Monitor Controls  
04CA:1766:02=Lite On USB Monitor  
04CA:2000=Broadcom Bluetooth 2.1 + EDR USB Device  
04CA:2001=Broadcom Bluetooth 2.1 + EDR USB Device  
04CA:9304=Lite On USB Hub  
04CA:F004=TV tuner device  
04CA:F006=TV tuner device  
04CA:F014=TV tuner device  
04CA:F016=TV tuner device  
04CB=Fuji Photo Film  
04CB:0100=FujiFilm FinePix Digital Camera  
04CB:0103=FinePix NX-700 printer  
04CB:0104=USB PC Camera  
04CB:0108=FinePix F601 Zoom (Disk mode)  
04CB:0109=FinePix F601 Zoom (PC-Cam mode)  
04CB:010A=FinePix S602 Zoom (Disk mode)  
04CB:010B=FinePix S602 Zoom (PC-Cam mode)  
04CB:010D=FinePix Digital Camera 020530/020531  
04CB:010E=FinePix Digital Camera 020906

04CB:010F=FinePix Digital Camera 020906  
04CB:0110=FinePix Digital Camera 020823  
04CB:0110:1000=Fujifilm DSC  
04CB:0111=FinePix Digital Camera 020823  
04CB:0112=FinePix Digital Camera 020715  
04CB:0113=FinePix Digital Camera 020715  
04CB:0114=FinePix F401 Zoom (Disk mode)  
04CB:0115=FinePix F401 Zoom (PC-Cam mode)  
04CB:0116=FinePix Digital Camera 020716  
04CB:0117=FinePix Digital Camera 020716  
04CB:0118=FinePix Digital Camera 020815  
04CB:0119=FinePix Digital Camera 020815  
04CB:011A=FinePix Digital Camera 020724  
04CB:011B=FinePix Digital Camera 020724  
04CB:011C=FinePix Digital Camera 020717  
04CB:011D=FinePix Digital Camera 020717  
04CB:011E=FinePix Digital Camera 021008  
04CB:011F=FinePix Digital Camera 021008  
04CB:0120=FinePix Digital Camera 030127  
04CB:0121=FinePix Digital Camera 030127  
04CB:0122=FinePix Digital Camera 030207  
04CB:0123=FinePix Digital Camera 030207  
04CB:0124=FinePix Digital Camera 030305  
04CB:0125=FinePix Digital Camera 030305  
04CB:0126=FinePix Digital Camera 030425  
04CB:0127=FinePix Digital Camera 030425  
04CB:0128=FinePix Digital Camera 030602  
04CB:0129=FinePix Digital Camera 030602  
04CB:012A=FinePix Digital Camera 030513  
04CB:012B=FinePix Digital Camera 030513  
04CB:012C=FinePix Digital Camera 030616  
04CB:012D=FinePix Digital Camera 030616  
04CB:012E=FinePix Digital Camera 030731  
04CB:012F=FinePix Digital Camera 030731  
04CB:0130=FinePix Digital Camera 030617  
04CB:0131=FinePix Digital Camera 030617  
04CB:0132=FinePix Digital Camera 030131  
04CB:013A=FinePix Digital Camera 030722  
04CB:013B=FinePix Digital Camera 030722  
04CB:013C=FinePix Digital Camera 030822  
04CB:013D=FinePix Digital Camera 030822  
04CB:013E=FinePix Digital Camera 030818  
04CB:013F=FinePix Digital Camera 030818  
04CB:0142=FinePix S7000 Zoom (PTP mode)/(PictBridge mode) / FinePix A330 (PictBridge mode)  
04CB:0145=FinePix Digital Camera 040001  
04CB:0148=FinePix Digital Camera 040002  
04CB:0149=FinePix A330 Zoom (UVC)  
04CB:014A=FinePix A330 Zoom (PTP)  
04CB:014B=FinePix Digital Camera 040003  
04CB:014C=FinePix A340 Zoom (UVC)  
04CB:0150=FinePix Digital Camera 040004  
04CB:0153=FinePix Digital Camera 040005  
04CB:0156=FinePix Digital Camera 040006  
04CB:0159=FinePix Digital Camera 040007  
04CB:015C=FinePix Digital Camera 040008  
04CB:015F=FinePix Digital Camera 040009  
04CB:0162=FinePix Digital Camera 040010  
04CB:0165=FinePix Digital Camera 040011  
04CB:0168=FinePix Digital Camera 040012

04CB:0169=FinePix E500 Zoom (UVC)  
04CB:016B=FinePix Digital Camera 040013  
04CB:016C=FinePix E510 Zoom (PC CAM)  
04CB:016E=FinePix Digital Camera 040014  
04CB:016F=FinePix S5500 Zoom (UVC)  
04CB:0171=FinePix Digital Camera 040015  
04CB:0172=FinePix E550 Zoom (PTP)  
04CB:0174=FinePix Digital Camera 040016  
04CB:0177=FinePix Digital Camera 040017  
04CB:0179=Finepix F10 Camera (PTP mode)  
04CB:017A=FinePix Digital Camera 040018  
04CB:017D=FinePix Digital Camera 040019  
04CB:0180=FinePix Digital Camera 040020  
04CB:0183=FinePix Digital Camera 040021  
04CB:0186=FinePix Digital Camera 040022  
04CB:0188=FinePix S5200/S5600 Zoom (PTP)  
04CB:0189=FinePix Digital Camera 040023  
04CB:018E=FinePix S9500 Zoom (DSC)  
04CB:018F=FinePix S9500 Zoom (PTP)  
04CB:0192=FinePix E900  
04CB:0193=FinePix E900 Zoom (PTP)  
04CB:019B=FinePix F30 Zoom (PTP)  
04CB:01AF=FinePix A700 (PTP)  
04CB:01BF=FinePix F6000fd/S6500fd Zoom (PTP)  
04CB:01C0=FinePix F20 Zoom (PTP)  
04CB:01C1=FinePix F31fd Zoom (PTP)  
04CB:01C4=FinePix S5700 Zoom (PTP)  
04CB:01C5=FinePix F40fd Zoom (PTP)  
04CB:01C6=FinePix A820  
04CB:01D2=FinePix A800 Zoom (PTP)  
04CB:01D3=FinePix A920 (PTP)  
04CB:01D4=FinePix F50fd (PTP)  
04CB:01D5=FinePix F47 Zoom (PTP)  
04CB:01F7=FinePix J250 (PTP)  
04CB:01FD=A160  
04CB:023E=FinePix AX300  
04CB:0240=FinePix S2950 Digital Camera  
04CC=Philips  
04CC:1122=Hub  
04CC:1520=USB 2.0 Hub (Avocent KVM)  
04CC:1521=7-Port USB 2.0 Hub  
04CC:1521:0200=Chronos 7-Port USB 2.0 Hub  
04CC:1A62=GW Instek GSP-830 Spectrum Analyzer (HID)  
04CC:226F=KANDY MOBILE OBEX  
04CC:2323=Ux500 serial debug port  
04CC:2533=NXP Reader  
04CC:8116=Logitech QuickCam Pro 3000  
04CC:8116:01=Logitech Microphone (Pro 3000)  
04CD=Tatung America  
04CE=ScanLogic  
04CE:0002=USB Storage Adapter SL11R (TPP)  
04CE:0100=USB2PRN Printer Class  
04CE:0300=Phantom 336CX - C3 scanner  
04CE:04CE=SL11DEMO, VID: 0x4ce, PID: 0x4ce  
04CE:07D1=SL11R, VID: 0x4ce, PID: 0x07D1  
04CF=Myson-Century  
04CF:0022=OCZ Alchemy Series Elixir II Keyboard  
04CF:0800=Myson-Century MTP800 USB Mass Storage Device  
04CF:0809=Myson-Century MTP809 USB Mass Storage Device  
04CF:0810=Myson-Century MTP809 USB Mass Storage Device

04CF:8810=Myson-Century CS8810 USB Mass Storage Device  
04CF:8811=Myson-Century CS8811 USB Mass Storage Device  
04CF:8813=Myson-Century CS8813 USB Mass Storage Device  
04CF:8817=Myson-Century CS8817 USB Mass Storage Device  
04CF:8818=Fast 3.5" External Storage  
04CF:8819=Myson-Century CS8819 USB Mass Storage Device  
04CF:9920=Myson-Century CS8819 USB Mass Storage Device  
04D0=Digi International  
04D1=ITT Canon  
04D2=Altec Lansing Technologies  
04D2:0070=Altec Lansing HID Audio Controls  
04D2:0070:02=Altec Lansing HID Audio Controls  
04D2:0305=Non-Compliant Audio Device  
04D2:0311=ADA-310 Speakers  
04D2:2060=Claritel-i750 - vp  
04D2:FF05=Non-Compliant USB Audio Device  
04D2:FF47=Altec Lansing HID Audio Controls  
04D2:FF47:02=Altec Lansing HID Audio Controls  
04D2:FF49=Altec Lansing HID Audio Controls  
04D2:FF49:02=Altec Lansing HID Audio Controls  
04D3=VidUS  
04D4=LSI Logic  
04D5=Forte Technologies  
04D6=CAE Technology  
04D7=Oki Semiconductor  
04D7:1BE4=OKI Bluetooth Device  
04D8=Micro Chip Technology  
04D8:0002=USB-LCD 2x20  
04D8:0003=PICKit 2 Microcontroller Programmer  
04D8:000A=CDC RS-232 Emulation Demo  
04D8:000B=PIC18F2550 (32K Flashable 10 Channel, 10 Bit A/D USB Microcontroller)  
04D8:0032=PICKit1  
04D8:0033=PICKit2  
04D8:0036=PICKit Serial Analyzer  
04D8:00E0=PIC32 Starter Board  
04D8:0A04=AGP LIN Serial Analyzer  
04D8:8000=Microchip MPLAB ICD 2 Firmware Loader  
04D8:8001=Microchip MPLAB ICD 2 Firmware Client  
04D8:8101=PIC24F Starter Kit  
04D8:900A=PICKit3  
04D8:C001=PicoLCD 20x4  
04D8:FBBA=DiscFerret Magnetic Disc Analyser (bootloader mode)  
04D8:FBBB=DiscFerret Magnetic Disc Analyser (active mode)  
04D8:FC92=Open Bench Logic Sniffer  
04D8:FFA2=GTP-USB-PLUS  
04D8:FFEF=PICoPLC [APStech]  
04D9=Holtek Microelectronics  
04D9:0022=Portable Keyboard  
04D9:0451=USB Browser Mouse  
04D9:0452=USB Browser Mouse  
04D9:048E=USB Browser Mouse  
04D9:0499=USB Browser Mouse  
04D9:1111=USB Browser Mouse  
04D9:1122=USB Browser Mouse  
04D9:1166=USB Browser Mouse  
04D9:1203=MC Industries Keyboard  
04D9:1400=PS/2 keyboard + mouse controller  
04D9:1503=Shortboard Lefty  
04D9:1603=Keyboard  
04D9:2013=Keyboard [Das Keyboard]

04D9:2221=Keyboard  
04DA=Panasonic  
04DA:0901=LS-120 Camera  
04DA:0912=SDR-S10  
04DA:0B01=Panasonic USB CD-R/RW Drive  
04DA:0B03=Panasonic USB SuperDisk 240MB  
04DA:0D01=CD-R Drive KXL-840AN  
04DA:0D09=CRRW09 USB CD-R/RW drive  
04DA:0D0A=CD-R Drive KXL-CB20AN  
04DA:0D0C=Panasonic USB Mass Storage Device  
04DA:0D0D=CDRCB03  
04DA:0D0E=DVD-ROM & CD-R/RW  
04DA:0F40=Panasonic Printer  
04DA:117A=PanaSCR7A Smart  
04DA:1500=MFSUSB Driver  
04DA:1800=DY-WL10 802.11abgn Adapter [Broadcom BCM4323]  
04DA:1B00=USB Reader Writer for SD Memory Card  
04DA:2121=EB-VS6  
04DA:2316=DVC Mass Storage Device  
04DA:2317=DVC USB-SERIAL Driver for WinXP  
04DA:2318=NV-GS11/230/250 (webcam mode)  
04DA:2319=NV-GS15 (webcam mode)  
04DA:231A=NV-GS11/230/250 (DV mode)  
04DA:231D=DVC Web Camera Device  
04DA:231E=DVC DV Stream Device  
04DA:2372=Lumix DMC-FZ10 Camera  
04DA:2374=DMC-FZ20  
04DA:2451=HDC-SD9  
04DA:2497=HDC-TM700  
04DA:2500=Panasonic USB Sync  
04DA:250C=Gobi Wireless Modem (QDL mode)  
04DA:250D=Gobi Wireless Modem  
04DA:2B00=Panasonic USB Mass Storage Device  
04DA:3904=N5HBZ0000055 802.11abgn Wireless Adapter [Atheros AR7010]  
04DA:3C04=JT-P100MR-20 [ePassport Reader]  
04DB=Hypertec  
04DC=Huan Hsin  
04DD=Sharp  
04DD:13A6=MFC2000  
04DD:6006=AL-1216  
04DD:6007=AL-1045  
04DD:6008=AL-1255  
04DD:6009=AL-1530CS  
04DD:600A=AL-1540CS  
04DD:600B=AL-1456  
04DD:600C=AL-1555  
04DD:600D=AL-1225  
04DD:600E=AL-1551CS  
04DD:600F=AR-122E  
04DD:6010=AR-152E  
04DD:6011=AR-157E  
04DD:6012=SN-1045  
04DD:6013=SN-1255  
04DD:6014=SN-1456  
04DD:6015=SN-1555  
04DD:6016=AR-153E  
04DD:6017=AR-122E N  
04DD:6018=AR-153E N  
04DD:6019=AR-152E N  
04DD:601A=AR-157E N

04DD:601B=AL-1217  
04DD:601C=AL-1226  
04DD:601D=AR-123E  
04DD:6021=IS01  
04DD:7002=DVC Ver.1.0  
04DD:7004=VE-CG40U Digital Still Camera  
04DD:7005=VE-CG30 Digital Still Camera  
04DD:7007=VL-Z7S Digital Camcorder  
04DD:8004=Zaurus SL-5000D/SL-5500 PDA  
04DD:8005=Zaurus A-300  
04DD:8006=Zaurus SL-B500/SL-5600/SL-C700 PDA  
04DD:8007=Zaurus C-700 PDA  
04DD:9014=IM-DR80 Portable NetMD Player  
04DD:9031=Zaurus C-750/C-760 PDA  
04DD:9032=Zaurus SL-6000  
04DD:903A=GSM GPRS  
04DD:9050=Zaurus C-860 PDA  
04DD:9056=Viewcam Z  
04DD:9073=AM-900  
04DD:9074=GSM GPRS  
04DD:90A9=Sharp Composite  
04DD:90D0=USB-to-Serial Comm. Port  
04DD:90F2=Sharp 3G GSM USB Control  
04DD:9120=Sharp WS004SH  
04DD:9122=Sharp WS007SH  
04DD:9123=W-ZERO3 ES Smartphone  
04DD:9193=GlobeTrotter Module 3G+ Diagnostics Interface  
04DD:91A3=922SH Internet Machine  
04DD:939A=IS03  
04DE=MindShare  
04DF=Interlink Electronics  
04E1=Iiyama  
04E1:0201=Iiyama USB Hub  
04E2=Exar  
04E3=Zilog  
04E4=ACC Microelectronics  
04E5=Promise Technology  
04E6=SCM Microsystems  
04E6:0001=USB ATAPI Storage Device  
04E6:0002=USB SCSI Storage Device  
04E6:0003=ZiO SmartMedia Adapter  
04E6:0005=eUSB SmartMedia/CompactFlash Card Reader  
04E6:0006=eUSB SmartMedia Card Reader  
04E6:0007=Hifd  
04E6:0009=eUSB ATA/ATAPI Adapter  
04E6:000A=USB CompactFlash Reader  
04E6:000B=eUSCSI Bridge  
04E6:000C=eUSCSI Bridge  
04E6:000D=Dazzle MS  
04E6:0012=Dazzle SD/MMC  
04E6:0101=USB ATAPI Storage Device  
04E6:0311=Dazzle DM-CF  
04E6:0312=Dazzle DM-SD/MMC  
04E6:0313=Dazzle SM  
04E6:0314=Dazzle MS  
04E6:0322=e-Film Reader-5  
04E6:0325=eUSB ORCA Quad Reader  
04E6:0327=Digital Media Reader  
04E6:0327:01=Digital Media Reader  
04E6:03FD=SCM Microsystems PCDxMOD Monitor

04E6:03FE=DMHS2 DFU Adapter  
04E6:0406=eUSB SmartDM Reader  
04E6:0408=SCM Microsystems PCDxMOD PCCard Module  
04E6:0409=SCM Microsystems PCDxMOD CompactFlash Module  
04E6:040A=SCM Microsystems PCDxMOD SD-MMC Module  
04E6:040B=SCM Microsystems PCDxMOD miniSD Module  
04E6:040C=SCM Microsystems PCDxMOD SmartMedia Module  
04E6:040D=SCM Microsystems PCDxMOD xD Module  
04E6:040E=SCM Microsystems PCDxMOD MemoryStick Module  
04E6:040F=SCM Microsystems PCDxMOD MemoryStickDUO Module  
04E6:04E6=eUSB DFU Adapter  
04E6:04E7=STCII DFU Adapter  
04E6:04E8=eUSBDM DFU Adapter  
04E6:04E9=DM-E DFU Adapter  
04E6:0500=Veridicom 5thSense Fingerprint Sensor and eUSB SmartCard  
04E6:0701=DCS200 Loader Device  
04E6:0702=DVD Creation Station 200  
04E6:0703=DVC100 Loader Device  
04E6:0704=Digital Video Creator 100  
04E6:1001=ActivCard SCR301 USB Smart Card Reader  
04E6:1010=USBAT-2 CompactFlash Card Reader  
04E6:1014=e-Film Reader-3  
04E6:1020=USBAT ATA/ATAPI Adapter  
04E6:2004=Reflex USB Smart card reader  
04E6:2007=RSA SecurID ComboReader  
04E6:2009=Citibank USB Smart Card Reader  
04E6:200A=Reflex USB v.2 Smart card reader  
04E6:200D=STR391 Reader  
04E6:5111=SCR331-DI SmartCard Reader  
04E6:5113=SCR333 Internal Smart Card Reader  
04E6:5114=SCR331-DI SmartCard Reader  
04E6:5115=SCR33x USB Smart Card Reader  
04E6:5116=SCR3310 USB Smart Card Reader  
04E6:5117=SCR3320 - Smart Card Reader  
04E6:5118=Expresscard USB SIM Card Reader  
04E6:5119=SCR3340 - ExpressCard54 Smart Card Reader  
04E6:511B=USB SmartCard Reader  
04E6:511C=Reflex USB V3  
04E6:511D=SCR3311 USB Smart Card Reader  
04E6:5120=SCR331-DI SmartCard Reader  
04E6:5121=SDI010 Smart Card Reader  
04E6:5123=USB SmartCard Reader  
04E6:5124=USB SmartCard Reader  
04E6:5125=ePassport Smart Card Reader  
04E6:5126=USB SmartCard Reader  
04E6:5127=D SCAN AUTHENTICATOR CF Smart Card Reader  
04E6:5128=USB SmartCard Reader  
04E6:512A=SDI010 Smart Card Reader  
04E6:512C=SDI011 Generic USB Smart Card Reader  
04E6:512D=SDI010 Smart Card Reader  
04E6:5137=SPR337 USB Smart Card Reader  
04E6:5151=SCR338 Keyboard Smart Card Reader  
04E6:5151:01=SCR338 USB Keyboard Smart Card Reader  
04E6:5200=STC3 DFU Adapter  
04E6:5292=SCL011 RFID reader  
04E6:5410=SCR35xx USB Smart Card Reader  
04E6:5413=USB Smart Card Reader  
04E6:5591=SCL3711 reader & NFC device  
04E6:E000=SCRx31 USB Reader  
04E6:E001=SCR33X USB Smart Card Reader



04E6:E003=SPRx32 USB Smart Card Reader  
04E7=Elo TouchSystems  
04E7:0001=Elo TouchSystems USB Touchmonitor Interface 2600 Rev 1  
04E7:0002=EloHID\_PID\_0002  
04E7:0004=EloHID\_PID\_0004  
04E7:0007=EloHID\_PID\_0007  
04E7:0008=EloHID\_PID\_0008  
04E7:0009=EloHID\_PID\_0009  
04E7:0020=EloHID\_PID\_0020  
04E7:0021=Elo TouchSystems USB Touchmonitor Interface  
04E7:0030=EloHID\_PID\_0030  
04E7:0032=Elo TouchSystems USB Touchmonitor Interface  
04E7:0033=Elo TouchSystems USB Touchmonitor Interface  
04E7:0041=Elo TouchSystems 5010 Surface Capacitive USB Touchmonitor Interface  
04E7:0042=Elo TouchSystems 5020 Surface Capacitive USB Touchmonitor Interface  
04E7:0050=EloHID\_PID\_0050  
04E7:0071=Elo TouchSystems USB Touchmonitor Interface  
04E7:0072=Elo TouchSystems USB Touchmonitor Interface  
04E7:0081=Elo TouchSystems USB Touchmonitor Interface  
04E7:0082=Elo TouchSystems USB Touchmonitor Interface  
04E7:00FF=Elo TouchSystems USB Touchmonitor Interface  
04E8=Samsung Electronics  
04E8:0100=Kingston Flash Drive (128MB)  
04E8:0110=Connect3D Flash Drive  
04E8:0111=Connect3D Flash Drive  
04E8:0120=Samsung InfoRanger SCM-120U  
04E8:0140=Samsung InfoRanger SCM-140  
04E8:1003=MP3 Player and Recorder  
04E8:1006=SAMSUNG SDC-200Z  
04E8:1600=Pen Drive USB2 32MB  
04E8:1F06=HX-MU064DA portable harddisk  
04E8:2018=WIS09ABGN LinkStick Wireless LAN Adapter  
04E8:2035=Digital Photo Frame Mass Storage  
04E8:2036=Digital Photo Frame Mini Monitor  
04E8:3004=ML-4600  
04E8:3005=Docuprint P1210  
04E8:3008=ML-6060 laser printer  
04E8:300C=ML-1210 Printer  
04E8:300E=Laser Printer  
04E8:3104=ML-3550N  
04E8:3210=ML-5200A Laser Printer  
04E8:3226=Laser Printer  
04E8:3228=Laser Printer  
04E8:322A=Laser Printer  
04E8:322C=Laser Printer  
04E8:3230=ML-1440  
04E8:3232=Laser Printer  
04E8:3236=ML-1450  
04E8:3238=ML-1430  
04E8:323A=ML-1710 Printer  
04E8:323B=Phaser 3130  
04E8:323C=Laser Printer  
04E8:323D=Phaser 3120  
04E8:323E=Laser Printer  
04E8:3240=Laser Printer  
04E8:3242=Laser Printer  
04E8:3248=Color Laser Printer  
04E8:324A=Laser Printer  
04E8:324C=ML-1740 Printer  
04E8:324D=Phaser 3121

04E8:3256=ML-1520 Laser Printer  
04E8:325B=Xerox Phaser 3117 Laser Printer  
04E8:325F=Phaser 3425 Laser Printer  
04E8:3260=CLP-510 Color Laser Printer  
04E8:3268=ML-1610 Mono Laser Printer  
04E8:326C=Samsung ML-2010 Series  
04E8:3276=ML-3050/ML-3051 Laser Printer  
04E8:328E=CLP-310 Color Laser Printer  
04E8:3292=ML-1640 Series Laser Printer  
04E8:3296=ML-2580N Mono Laser Printer  
04E8:3297=ML-191x/ML-252x Laser Printer  
04E8:3409=SCX-4216F Scanner  
04E8:340C=SCX-5x15 Series  
04E8:340D=SCX-6x20 Series  
04E8:340E=MFP 560 Series  
04E8:340F=Printing Support  
04E8:3412=SCX-4x20 Series  
04E8:3413=SCX-4100 Scanner  
04E8:3415=Composite Device  
04E8:3419=Samsung SCX-4x21 Series  
04E8:341A=Printing Support  
04E8:341B=SCX-4200 Series  
04E8:341C=Composite Device  
04E8:341D=Composite Device  
04E8:341F=Composite Device  
04E8:3420=Composite Device  
04E8:3421=Samsung CLX-8380 Series  
04E8:3425=Samsung CLX-216x Series  
04E8:3426=Samsung SCX-4500 Series  
04E8:3427=Samsung CLX-6200 Series  
04E8:3428=Samsung CLX-6240 Series  
04E8:3429=Samsung SCX-6x55 Series  
04E8:342A=Samsung CLX-3170 Series  
04E8:342B=Samsung SCX-4500W Series  
04E8:342C=Samsung SCX-4x24 Series  
04E8:342D=Samsung SCX-4x28 Series  
04E8:342E=Samsung SCX-4300 Series  
04E8:342F=Samsung SCX-5835\_5935 Series  
04E8:3430=Samsung SCX-5635 Series  
04E8:3432=Samsung SCX-4x26 Series  
04E8:3605=InkJet Color Printer  
04E8:3606=InkJet Color Printer  
04E8:3609=InkJet Color Printer  
04E8:3902=InkJet Color Printer  
04E8:3903=Xerox WorkCentre XK50cx  
04E8:390F=InkJet Color Printer  
04E8:3911=SCX-1020 Series  
04E8:392C=Samsung SCX-1430\_1450Series  
04E8:3931=Samsung SCX-1460\_1470 Series  
04E8:3932=Samsung SCX-1630\_1650 Series  
04E8:3937=Samsung SCX-1455 Series  
04E8:4005=GT-S8000 Jet (msc)  
04E8:4471=Samsung WLAN USB Stick  
04E8:4F1F=GT-S8000 Jet (mtp)  
04E8:5000=SAMSUNG YP-MF Series  
04E8:5001=SAMSUNG YP-100  
04E8:5002=Samsung SEW-2001u Card  
04E8:5002:0100=SAMSUNG YP-30  
04E8:5003=SAMSUNG YP-700  
04E8:5004=SAMSUNG YP-30

04E8:5005=SAMSUNG YP-300  
04E8:5006=SAMSUNG YP-750  
04E8:5008=Samsung YP-N30 Audio Player  
04E8:5008:0083=Samsung YP-N30 Audio Player  
04E8:500D=MP3 Player  
04E8:5010=MP3 Player  
04E8:5011=YP-780  
04E8:5013=YP-60  
04E8:5015=yepp upgrade  
04E8:5016=Samsung / Napster YP-910  
04E8:501B=MP3 Player  
04E8:501D=Samsung / Napster YH - 920 Mass Storage Device  
04E8:5021=Yepp YP-ST5  
04E8:5026=YP-MT6V  
04E8:5027=YP-T7  
04E8:502B=YP-F1  
04E8:5032=YP-J70  
04E8:503B=YP-U1 MP3 Player  
04E8:503D=YP-T7F  
04E8:5041=YP-Z5  
04E8:5050=YP-U2 MP3 Player  
04E8:5051=YP-F2R  
04E8:5055=YP-T9  
04E8:507D=YP-U3 MP3 Player  
04E8:507F=YP-T9J  
04E8:5080=Yepp YP-K3  
04E8:5081=Yepp YP-K3 (mtp)  
04E8:5082=YP-P2 (msc)  
04E8:5083=YP-P2  
04E8:508A=YP-T10  
04E8:508B=YP-S5 MP3 Player  
04E8:508C=YP-S5  
04E8:5090=YP-S3 (msc)  
04E8:5091=YP-S3 (mtp)  
04E8:5092=YP-U4  
04E8:5093=YP-U4 (mtp)  
04E8:5095=YP-S2  
04E8:510F=YP-R1  
04E8:5119=Yepp YP-P3  
04E8:511C=YP-Q2  
04E8:5121=YP-U5  
04E8:5123=Yepp YP-M1  
04E8:5A00=SAMSUNG YP-NEU  
04E8:5A01=SAMSUNG YP-NDU  
04E8:5A03=SAMSUNG YP-20  
04E8:5A04=SAMSUNG YP-800  
04E8:5A08=SAMSUNG YP-90  
04E8:5A0F=Appareil mobile MTP  
04E8:5B01=USB Memory Stick Reader/Writer  
04E8:5B02=USB Memory Stick Reader/Writer  
04E8:5B03=USB Memory Stick Reader/Writer  
04E8:5B04=USB Memory Stick Reader/Writer  
04E8:5B05=USB Memory Stick Reader/Writer  
04E8:5B11=Samsung SEW-2001u Card  
04E8:5F00=NEXiO Sync  
04E8:5F01=NEXiO Sync  
04E8:5F02=NEXiO Sync  
04E8:5F03=NEXiO Sync  
04E8:5F04=NEXiO Sync  
04E8:6032=G2 Portable hard drive

04E8:6601=SAMSUNG CDMA Modem  
04E8:6601:02=SAMSUNG CDMA Modem Diagnostic Serial Port (WDM)  
04E8:6602=Galaxy  
04E8:6603=Galaxy  
04E8:6611=MITs Sync  
04E8:6613=MITs Sync  
04E8:6615=MITs Sync  
04E8:6617=MITs Sync  
04E8:6619=MITs Sync  
04E8:661B=MITs Sync  
04E8:661E=Handheld  
04E8:6620=Handheld  
04E8:6622=Handheld  
04E8:6624=Handheld  
04E8:662E=MITs Sync  
04E8:6630=MITs Sync  
04E8:6632=MITs Sync  
04E8:663E=SAMSUNG Mobile USB Modem 1.0  
04E8:663F=Samsung Mobile USB Port II 1.0  
04E8:6640=SAMSUNG CDMA Modem  
04E8:6640:02=SAMSUNG CDMA Modem Diagnostic Serial Port (WDM)  
04E8:6651=Samsung Symbian S60 Phone USB Phone Parent  
04E8:6671=SAMSUNG AT command Port  
04E8:6702=X830  
04E8:6708=U600 Phone  
04E8:6709=U600  
04E8:6711=Samsung Symbian S60 Phone USB Phone Parent  
04E8:6721=Samsung Symbian S60 Phone USB Phone Parent  
04E8:6734=Juke  
04E8:6759=D900e Media Player  
04E8:675A=D900e Mass Storage  
04E8:675B=D900e Camera  
04E8:6765=SAMSUNG SYMBIAN USB Downloader Driver  
04E8:6771=SAMSUNG Mobile Modem  
04E8:6771:02=SAMSUNG Mobile Modem Diagnostic Serial Port (WDM)  
04E8:6772=Standalone LTE device (Trial)  
04E8:6795=S5230  
04E8:6795:02=SAMSUNG USB Mobile Logging  
04E8:6802=Standalone HSPA device  
04E8:6806=Composite LTE device (Trial)  
04E8:6807=Composite HSPA device  
04E8:6810=SAMSUNG Mobile Modem V2  
04E8:6810:02=SAMSUNG Mobile Modem Diagnostic Serial Port V2 (WDM)  
04E8:6811=SAMSUNG Mobile Modem V2  
04E8:6811:02=SAMSUNG Mobile Modem Diagnostic Serial Port V2 (WDM)  
04E8:6812=SAMSUNG Mobile Modem V2  
04E8:6812:02=SAMSUNG Mobile Modem Diagnostic Serial Port V2 (WDM)  
04E8:6813=SAMSUNG Mobile Modem V2  
04E8:6813:02=SAMSUNG Mobile Modem Diagnostic Serial Port V2 (WDM)  
04E8:6814=SAMSUNG Mobile Modem V2  
04E8:6814:02=SAMSUNG Mobile Modem Diagnostic Serial Port V2 (WDM)  
04E8:681C=Galaxy Portal/Spica Android Phone  
04E8:681C:03=SAMSUNG Android Composite ADB Interface  
04E8:681D=Galaxy Portal/Spica Android Phone  
04E8:6843=SAMSUNG Mobile USB Modem  
04E8:6844=SAMSUNG Mobile USB Modem  
04E8:6845=SAMSUNG Mobile USB Device  
04E8:6846=SAMSUNG Mobile USB Device  
04E8:6849=SAMSUNG USB Mobile Modem  
04E8:6849:03=SAMSUNG USB Mobile Logging

04E8:684A=SAMSUNG USB Mobile Modem  
04E8:684A:03=SAMSUNG USB Mobile Logging  
04E8:684B=SAMSUNG Mobile Modem  
04E8:684B:03=SAMSUNG Mobile Modem Diagnostic Serial Port (WDM)  
04E8:684C=SAMSUNG Mobile Modem  
04E8:684C:03=SAMSUNG Mobile Modem Diagnostic Serial Port (WDM)  
04E8:684D=SAMSUNG Mobile Modem V2  
04E8:684D:03=SAMSUNG Mobile Modem Diagnostic Serial Port V2 (WDM)  
04E8:684E=Wave (GT-S8500)  
04E8:684E:03=SAMSUNG Mobile Modem Diagnostic Serial Port V2 (WDM)  
04E8:685B=GT-I9100 Phone [Galaxy S II] (mass storage mode)  
04E8:685E=GT-I9100 Phone [Galaxy S II] (USB Debugging mode)  
04E8:6860=GT-I9100 Phone [Galaxy S II]  
04E8:6875=GT-B3710 Standalone LTE device (Commercial)  
04E8:6876=GT-B3710 LTE Modem  
04E8:6877=Galaxy S  
04E8:6877:03=SAMSUNG Android Composite ADB Interface  
04E8:6880=SAMSUNG Android USB Modem  
04E8:6880:02=SAMSUNG Android Composite ADB Interface  
04E8:6881=SAMSUNG Android USB Remote NDIS Network Device  
04E8:6888=GT-B3730 Composite LTE device (Commercial)  
04E8:6889=GT-B3730 Composite LTE device (Commercial)  
04E8:689A=LTE Storage Driver [CMC2xx]  
04E8:689C=SAMSUNG Android Composite ADB Interface  
04E8:689E=SAMSUNG Android USB Modem  
04E8:689E:02=SAMSUNG Android USB Diagnostic Serial Port (WDM)  
04E8:689E:04=SAMSUNG Android Composite ADB Interface  
04E8:68AA=Reality  
04E8:7011=Samsung SEW-2003U Card  
04E8:7021=Samsung Bluetooth Device  
04E8:7061=eHome Infrared Receiver (USBCIR)  
04E8:7080=SAMSUNG HSP Plus Modem Driver  
04E8:7081=Human Interface Device  
04E8:7081:03=USB Human Interface Device  
04E8:8001=Handheld  
04E8:9407=Samsung High Speed USB Driver  
04E8:E020=SERI E02 SCOM 6200 UMTS Phone  
04E8:E020:0010=SERI E02 SCOM 6200ES UMTS Phone  
04E8:E020:0020=SERI E02 SCOM 6200CS UMTS Phone  
04E8:E021=SERI E02 SCOM 6200 Virtual UARTs  
04E8:E021:0010=SERI E02 SCOM 6200ES Virtual UARTs  
04E8:E021:0020=SERI E02 SCOM 6200CS Virtual UARTs  
04E8:E022=SERI E02 SCOM 6200 Flash Load Disk  
04E8:E022:0010=SERI E02 SCOM 6200ES Flash Load Disk  
04E8:E022:0020=SERI E02 SCOM 6200CS Flash Load Disk  
04E8:FF30=SG\_iMON  
04E9=PC-Tel  
04EA=Sipex  
04EB=Northstar Systems  
04EB:E002=eHome Infrared Receiver (USBCIR)  
04EB:E004=eHome Infrared Receiver (USBCIR)  
04EC=Tokyo Electron  
04ED=Annabooks  
04EF=Pacific Electronic International  
04F0=Daewoo Electronics  
04F1=Victor Company of Japan  
04F1:0001=GC-QX3 Digital Still Camera  
04F1:0004=GR-DVL815U Digital Video Camera  
04F1:0006=JVC DV Camera Storage  
04F1:0008=GZ-MG30AA/MC500E Digital Video Camera

04F1:0009=GR-DX25EK Digital Video Camera  
04F1:000A=GR-D72 Digital Video Camera  
04F1:1001=GC-A50 Camera Device  
04F1:3008=USB 2.0 10/100Base Ethernet Adapter  
04F1:3009=MP-XP7250 WLAN Adapter  
04F1:3011=JVC USB Sync  
04F1:3012=JVC USB Sync  
04F2=Chicony Electronics  
04F2:0001=Chicony USB Keyboard Mouse  
04F2:0001:01=Chicony USB Keyboard Mouse  
04F2:0002=Chicony USB Keyboard  
04F2:0110=KU-2971 Keyboard  
04F2:0111=USB Keyboard  
04F2:0112=KU-8933 Keyboard with PS/2 Mouse port  
04F2:0116=KU-2971 German Keyboard  
04F2:0220=Wireless HID Receiver  
04F2:0402=Genius LuxeMate i200 Keyboard  
04F2:0403=KU-0420 keyboard  
04F2:0418=KU-0418 Tactical Pad  
04F2:0760=Acer KU-0760 Keyboard  
04F2:0860=2.4G Multimedia Wireless Kit  
04F2:A001=E-Video DC-100 Camera  
04F2:A120=ORITE CCD Webcam(PC370R)  
04F2:A121=ORITE CCD Webcam(PC370R)  
04F2:A122=ORITE CCD Webcam(PC370R)  
04F2:A123=ORITE CCD Webcam(PC370R)  
04F2:A124=ORITE CCD Webcam(PC370R)  
04F2:A128=PC Camera (SN9C202 + OV7663 + EEPROM)  
04F2:A133=Gateway Webcam  
04F2:A136=LabTec Webcam 5500  
04F2:A204=Digital Camera WIA Device (2230)  
04F2:A205=Digital Camera Mass Storage (2230)  
04F2:A208=Creative PC-CAM 880 (Camera)  
04F2:A209=Digital Camera Mass Storage (2320)  
04F2:A20A=Digital Camera III  
04F2:A20C=DSC WIA Device (3320)  
04F2:A210=Audio Device  
04F2:A212=Digital Camera V  
04F2:A214=Digital Video Device  
04F2:A216=Digital Video Device  
04F2:A218=Digital Video Device  
04F2:A21A=DV-310 Digital Camera  
04F2:A21C=DV-320 Digital Camera  
04F2:A21E=DV-330 Digital Camera  
04F2:A220=DDV-660 Digital Camera  
04F2:A222=DDV-S670 Digital Camera  
04F2:A224=DDC-600 Digital Camera  
04F2:A226=Digital Video VI-A  
04F2:A228=Digital Video VI-C  
04F2:A22A=Digital Video VII-A  
04F2:A22C=Digital Video VII-C  
04F2:A22E=Digital Video VI-B  
04F2:A230=Digital Video VII-B  
04F2:A232=Digital Video VIII  
04F2:A234=Digital Video IX  
04F2:A236=Digital Video X  
04F2:A238=Digital Video XI  
04F2:AFF0=CSR Bluetooth Device  
04F2:AFF2=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
04F2:AFF5=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter

04F2:AFF6=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
04F2:AFF7=Realtek RTL8188CUS Wireless LAN 802.11n USB Slim Solo  
04F2:AFF8=Realtek RTL8188CUS Wireless LAN 802.11n USB Slim Combo  
04F2:AFF9=Realtek RTL8188CUS Wireless LAN 802.11n USB Slim Solo  
04F2:AFFA=Realtek RTL8188CUS Wireless LAN 802.11n USB Slim Solo  
04F2:AFFB=Realtek RTL8188CUS Wireless LAN 802.11n USB Slim Combo  
04F2:AFFC=Realtek RTL8188CUS Wireless LAN 802.11n USB Slim Combo  
04F2:B008=Chicony USB 2.0 Camera  
04F2:B009=Integrated Camera  
04F2:B010=Integrated Camera  
04F2:B011=USB2.0 PC Camera (SN9C202)  
04F2:B012=1.3 MPixel UVC webcam  
04F2:B013=USB 2.0 Camera  
04F2:B015=VGA 24fps UVC Webcam  
04F2:B016=VGA 30fps UVC Webcam  
04F2:B018=2M UVC Webcam  
04F2:B021=ViewSonic 1.3M, USB2.0 Webcam  
04F2:B022=Gateway USB 2.0 Webcam  
04F2:B023=Gateway USB 2.0 Webcam  
04F2:B024=USB 2.0 Webcam  
04F2:B025=Camera  
04F2:B026=Acer Crystal Eye webcam  
04F2:B027=Gateway USB 2.0 Webcam  
04F2:B028=VGA UVC Webcam  
04F2:B029=USB 2.0 1.3M UVC Webcam  
04F2:B033=USB2.0 1.3M UVC WebCam  
04F2:B034=USB 2.0 2.0M UVC WebCam  
04F2:B036=Asus Integrated 0.3M UVC Webcam  
04F2:B044=Acer CrystalEye Webcam  
04F2:B053=HP Webcam [2 MP]  
04F2:B057=integrated USB webcam  
04F2:B059=HP Webcam [VGA]  
04F2:B066=USB 2.0 VGA UVC WebCam  
04F2:B071=2.0M UVC Webcam / CNF7129  
04F2:B076=Integrated Camera  
04F2:B077=Integrated Camera  
04F2:B082=HP Webcam [2 MP]  
04F2:B083=HP Webcam [VGA]  
04F2:B084=WebCam  
04F2:B091=Webcam  
04F2:B093=HP Webcam [2 MP]  
04F2:B104=CNF7069 Webcam  
04F2:B106=USB 2.0 2.0M UVC WebCam  
04F2:B107=CNF7070 Webcam  
04F2:B10B=USB 2.0 2.0M UVC WebCam  
04F2:B10C=USB 2.0 VGA UVC WebCam  
04F2:B10D=USB 2.0 2.0M UVC WebCam  
04F2:B10E=USB 2.0 VGA UVC WebCam  
04F2:B10F=USB 2.0 VGA UVC WebCam  
04F2:B110=HD Video WebCam  
04F2:B12E=HP Webcam [VGA]  
04F2:B13A=USB 2.0 1.3M UVC WebCam  
04F2:B140=USB 2.0 1.3M UVC WebCam  
04F2:B141=USB 2.0 1.3M UVC WebCam  
04F2:B14C=CNF8050 Webcam  
04F2:B155=WebCam  
04F2:B159=HP Webcam [2 MP Fixed]  
04F2:B15E=HP Webcam [2 MP Macro]  
04F2:B160=HD Video WebCam  
04F2:B163=HP Webcam [2 MP Macro]

04F2:B16B=USB 2.0 1.3M UVC WebCam  
04F2:B16E=USB 2.0 1.3M UVC WebCam  
04F2:B175=WebCam  
04F2:B183=HP Webcam [2 MP Macro]  
04F2:B189=USB 2.0 VGA UVC WebCam  
04F2:B1AA=Webcam-101  
04F2:B1AF=Integrated Camera  
04F2:B1B4=Lenovo Integrated Camera  
04F2:B1B9=USB 2.0 VGA UVC WebCam  
04F2:B1BE=USB 2.0 VGA UVC WebCam  
04F2:B1CF=Lenovo Integrated Camera  
04F2:B1E5=USB 2.0 VGA UVC WebCam  
04F2:B221=integrated camera  
04F2:B230=Integrated HP HD Webcam  
04F2:B272=Lenovo EasyCamera  
04F3=ELAN Microelectronics  
04F3:01A4=Wireless Keyboard  
04F3:0210=AM-400 Hama Optical Mouse  
04F3:0210:2290=USB Human Interface Device  
04F3:0212=Laser Mouse  
04F3:0214=Lynx M9 Optical Mouse  
04F3:0216:6600=USB Human Interface Device  
04F3:0221:6610=USB Human Interface Device  
04F3:0230=3D Optical Mouse  
04F3:0230:2458=USB Human Interface Device  
04F3:02F4=2.4G Cordless Mouse  
04F3:0611:01=USB Human Interface Device  
04F4=Harting Elektronik  
04F5=Fujitsu-ICL Systems  
04F6=Norand  
04F7=Newnex Technology  
04F8=FuturePlus Systems  
04F9=Brother International  
04F9:0002=HL-1050 Laser Printer  
04F9:0005=Printer  
04F9:0006=HL-1240 Laser Printer  
04F9:0007=HL-1250 Laser Printer  
04F9:0008=HL-1270 Laser Printer  
04F9:0009=Printer  
04F9:000A=Brother P2500 Series  
04F9:000A:01=Brother P2500 Series  
04F9:000B=Printer  
04F9:000C=Printer  
04F9:000D=HL-1440 Laser Printer  
04F9:000E=HL-1450 series  
04F9:000F=HL-1470N series  
04F9:0010=Printer  
04F9:0011=Printer  
04F9:0012=Printer  
04F9:0013=Printer  
04F9:0014=Printer  
04F9:0015=Printer  
04F9:0016=Printer  
04F9:0017=Printer  
04F9:0018=Printer  
04F9:001A=HL-1430 Laser Printer  
04F9:001C=Printer  
04F9:001E=Printer  
04F9:0020=HL-5130 series  
04F9:0021=HL-5140 series



04F9:0022=HL-5150D series  
04F9:0023=HL-5170DN series  
04F9:0024=Printer  
04F9:0025=Printer  
04F9:0027=HL-2030 Laser Printer  
04F9:0028=Printer  
04F9:0029=Printer  
04F9:002A=Printer  
04F9:002B=Printer  
04F9:002C=Printer  
04F9:002D=Printer  
04F9:0039=HL-5340 series  
04F9:0100=Brother MFC8600/9650 Series  
04F9:0100:01=Brother MFC8600/9650 Series  
04F9:0100:02=Brother MFC8600/9650 Series  
04F9:0101=Brother MFC9600/9870 Series  
04F9:0101:01=Brother MFC9600/9870 Series  
04F9:0101:02=Brother MFC9600/9870 Series  
04F9:0102=Brother MFC9750/1200 Series  
04F9:0102:01=Brother MFC9750/1200 Series  
04F9:0104=Brother MFC-8300J  
04F9:0104:01=Brother MFC-8300J  
04F9:0104:02=Brother MFC-8300J  
04F9:0105=Brother MFC-9600J  
04F9:0105:01=Brother MFC-9600J  
04F9:0105:02=Brother MFC-9600J  
04F9:0106=Brother MFC-7300C  
04F9:0106:01=Brother MFC-7300C  
04F9:0106:02=Brother MFC-7300C  
04F9:0107=Brother MFC-7400C  
04F9:0107:01=Brother MFC-7400C  
04F9:0107:02=Brother MFC-7400C  
04F9:0107:03=Brother MFC-7400C  
04F9:0108=Brother MFC-9200C  
04F9:0108:01=Brother MFC-9200C  
04F9:0108:02=Brother MFC-9200C  
04F9:0108:03=Brother MFC-9200C  
04F9:0109=Brother MFC-830  
04F9:0109:01=Brother MFC-830  
04F9:0109:02=Brother MFC-830  
04F9:010A=Brother MFC-840  
04F9:010A:01=Brother MFC-840  
04F9:010A:02=Brother MFC-840  
04F9:010A:03=Brother MFC-840  
04F9:010B=Brother MFC-860  
04F9:010B:01=Brother MFC-860  
04F9:010B:02=Brother MFC-860  
04F9:010B:03=Brother MFC-860  
04F9:010C=Brother MFC-7400J  
04F9:010C:01=Brother MFC-7400J  
04F9:010C:02=Brother MFC-7400J  
04F9:010C:03=Brother MFC-7400J  
04F9:010D=Brother MFC-9200J  
04F9:010D:01=Brother MFC-9200J  
04F9:010D:02=Brother MFC-9200J  
04F9:010D:03=Brother MFC-9200J  
04F9:010E=MFC3100C Scanner  
04F9:010E:01=Brother MFC-3100C  
04F9:010E:02=Brother MFC-3100C Remote Setup Port  
04F9:010F=MFC 5100C

04F9:010F:01=Brother MFC-5100C  
04F9:010F:02=Brother MFC-5100C Remote Setup Port  
04F9:0110=MFC4800 Scanner  
04F9:0110:01=Brother MFC-4800  
04F9:0110:02=Brother MFC-4800 Remote Setup Port  
04F9:0111=MFC 6800  
04F9:0111:01=Brother MFC-6800 USB  
04F9:0111:02=Brother MFC6800 USB Port (FaxModem)  
04F9:0112=DCP1000 Port (FaxModem)  
04F9:0112:01=Brother DCP-1000  
04F9:0113=MFC-8500  
04F9:0113:01=Brother MFC-8500 USB  
04F9:0113:02=Brother MFC-8500 Fax Only  
04F9:0114=MFC9700 Port (FaxModem)  
04F9:0114:01=Brother MFC-9700  
04F9:0114:02=Brother MFC-9700 Fax Only  
04F9:0115=MFC9800 Scanner  
04F9:0115:01=Brother MFC-9760  
04F9:0116=DCP1400 Scanner  
04F9:0116:01=Brother DCP1400 USB Scanner  
04F9:0119=MFC-9660  
04F9:0119:01=Brother MFC-9660 USB  
04F9:0119:02=Brother MFC-9660 Fax Only  
04F9:011A:01=Brother MFC-9800  
04F9:011A:02=Brother MFC-9800 Fax Only  
04F9:011B=MFC-9880  
04F9:011B:01=Brother MFC-9880  
04F9:011B:02=Brother MFC-9880 Fax Only  
04F9:011C=MFC-9760  
04F9:011C:01=Brother MFC9760 USB Scanner  
04F9:011D=MFC-9070  
04F9:011D:01=Brother MFC-9070  
04F9:011D:02=Brother MFC-9070 Remote Setup Port  
04F9:011E=MFC-9180  
04F9:011E:01=Brother MFC-9180 USB  
04F9:011E:02=Brother MFC9180 USB Port (FaxModem)  
04F9:011F=MFC-9160  
04F9:011F:01=Brother MFC-9160  
04F9:0120=MFC580 Port (FaxModem)  
04F9:0120:01=Brother MFC-580  
04F9:0120:02=Brother MFC-580 Remote Setup Port  
04F9:0121=MFC-590  
04F9:0121:01=Brother MFC-590  
04F9:0121:02=Brother MFC-590 Remote Setup Port  
04F9:0122=MFC-5100J  
04F9:0122:01=Brother MFC-5100J  
04F9:0122:02=Brother MFC-5100J Remote Setup Port  
04F9:0125:01=Brother MFC-6800J  
04F9:0125:02=Brother MFC-6800J Remote Setup Port  
04F9:0127:01=Brother MFC-9800J  
04F9:0127:02=Brother MFC-9800J Fax Only  
04F9:0128:01=Brother MFC-8500J  
04F9:0128:02=Brother MFC-8500J Fax Only  
04F9:0129=Imagistics 2500 (MFC-8640D clone)  
04F9:012B:01=Brother MFC-9030  
04F9:012B:02=Brother MFC-9030 Remote Setup Port  
04F9:012F=FAX-4750e  
04F9:012F:01=Brother FAX-4750e  
04F9:012F:02=Brother FAX-4750e Remote Setup Port  
04F9:0130:01=Brother FAX-5750e

04F9:0130:02=Brother FAX-5750e Remote Setup Port  
04F9:0132=MFC-5200C RemovableDisk  
04F9:0132:01=Brother MFC-5200C  
04F9:0132:02=Brother MFC-5200C Fax Only  
04F9:0135=MFC-100 Scanner  
04F9:0135:01=Brother MFC-100  
04F9:0135:02=Brother MFC-100 Remote Setup Port  
04F9:0136=MFC-150CL Scanner  
04F9:0136:01=Brother MFC-150CL  
04F9:0136:02=Brother MFC-150CL Remote Setup Port  
04F9:013A:01=Brother MFC-3200C  
04F9:013A:02=Brother MFC-3200C Remote Setup Port  
04F9:013C=MFC-890 Port  
04F9:013C:01=Brother MFC-890  
04F9:013C:02=Brother MFC-890 Fax Only  
04F9:013D=MFC-5200J Printer  
04F9:013D:01=Brother MFC-5200J  
04F9:013D:02=Brother MFC-5200J Fax Only  
04F9:013E=MFC-4420C RemovableDisk  
04F9:013E:01=Brother MFC-4420C  
04F9:013E:02=Brother MFC-4420C Remote Setup Port  
04F9:013F=MFC-4820C RemovableDisk  
04F9:013F:01=Brother MFC-4820C  
04F9:013F:02=Brother MFC-4820C Remote Setup Port  
04F9:0140=DCP-8020  
04F9:0140:01=Brother DCP-8020  
04F9:0141=DCP-8025D  
04F9:0141:01=Brother DCP-8025D  
04F9:0142=MFC-8420  
04F9:0142:01=Brother MFC-8420  
04F9:0142:02=Brother MFC-8420 Fax Only  
04F9:0143=MFC-8820D  
04F9:0143:01=Brother MFC-8820D  
04F9:0143:02=Brother MFC-8820D Fax Only  
04F9:0144=DCP-4020C RemovableDisk  
04F9:0144:01=Brother DCP-4020C  
04F9:0146=MFC-3220C  
04F9:0146:01=Brother MFC-3220C  
04F9:0146:02=Brother MFC-3220C Remote Setup Port  
04F9:0147=FAX-1820C Printer  
04F9:0148=MFC-3320CN Printer  
04F9:0148:01=Brother MFC-3320CN  
04F9:0148:02=Brother MFC-3320CN Fax Only  
04F9:0149=FAX-1920CN Printer  
04F9:014A=MFC-3420C  
04F9:014A:01=Brother MFC-3420C  
04F9:014A:02=Brother MFC-3420C Remote Setup Port  
04F9:014B=MFC-3820CN  
04F9:014B:01=Brother MFC-3820CN  
04F9:014B:02=Brother MFC-3820CN Fax Only  
04F9:014D=FAX-1815C Printer  
04F9:014E=MFC-8820J  
04F9:014E:01=Brother MFC-8820J  
04F9:014E:02=Brother MFC-8820J Fax Only  
04F9:014F:01=Brother DCP-8025J  
04F9:0150=MFC-8220 Port (FaxModem)  
04F9:0150:01=Brother MFC-8220  
04F9:0150:02=Brother MFC-8220 Fax Only  
04F9:0151=MFC-8210J  
04F9:0151:01=Brother MFC-8210J

04F9:0151:02=Brother MFC-8210J Fax Only  
04F9:0153:01=Brother DCP-1000J  
04F9:0157=MFC-3420J Printer  
04F9:0157:01=Brother MFC-3420J  
04F9:0157:02=Brother MFC-3420J Remote Setup Port  
04F9:0158=MFC-3820JN Port (FaxModem)  
04F9:0158:01=Brother MFC-3820JN  
04F9:0158:02=Brother MFC-3820JN Fax Only  
04F9:015B:01=Lenovo M7210 USB  
04F9:015B:02=Lenovo M7210 USB Port (FaxModem)  
04F9:015C:01=Lenovo M7110 USB  
04F9:015C:02=Lenovo M7110 USB Port (FaxModem)  
04F9:015D=MFC Composite Device  
04F9:015D:01=Brother DCP-8040  
04F9:015E=DCP-8045D  
04F9:015E:01=Brother DCP-8045D  
04F9:015F=MFC-8440  
04F9:015F:01=Brother MFC-8440  
04F9:015F:02=Brother MFC-8440 Fax Only  
04F9:0160=MFC-8840D  
04F9:0160:01=Brother MFC-8840D  
04F9:0160:02=Brother MFC-8840D Fax Only  
04F9:0161=MFC-210C  
04F9:0161:01=Brother MFC-210C  
04F9:0162=MFC-420CN Remote Setup Port  
04F9:0162:01=Brother MFC-420CN  
04F9:0162:02=Brother MFC-420CN Fax Only  
04F9:0163=MFC-410CN RemovableDisk  
04F9:0163:01=Brother MFC-410CN  
04F9:0163:02=Brother MFC-410CN Fax Only  
04F9:0165=MFC-620CN  
04F9:0165:01=Brother MFC-620CN  
04F9:0165:02=Brother MFC-620CN Fax Only  
04F9:0166=MFC-610CLN RemovableDisk  
04F9:0166:01=Brother MFC-610CLN  
04F9:0166:02=Brother MFC-610CLN Fax Only  
04F9:0168=MFC-620CLN  
04F9:0168:01=Brother MFC-620CLN  
04F9:0168:02=Brother MFC-620CLN Fax Only  
04F9:0169=DCP-110C RemovableDisk  
04F9:0169:01=Brother DCP-110C  
04F9:016B=DCP-310CN RemovableDisk  
04F9:016B:01=Brother DCP-310CN  
04F9:016C=FAX-2440C Printer  
04F9:016C:02=Brother FAX-2440C Fax Only  
04F9:016D=MFC-5440CN  
04F9:016D:01=Brother MFC-5440CN  
04F9:016D:02=Brother MFC-5440CN Fax Only  
04F9:016E=MFC-5840CN Remote Setup Port  
04F9:016E:01=Brother MFC-5840CN  
04F9:016E:02=Brother MFC-5840CN Fax Only  
04F9:0170=FAX-1840C Printer  
04F9:0171=FAX-1835C Printer  
04F9:0172=FAX-1940CN Printer  
04F9:0173=MFC-3240C Remote Setup Port  
04F9:0173:01=Brother MFC-3240C  
04F9:0173:02=Brother MFC-3240C Remote Setup Port  
04F9:0174=MFC-3340CN RemovableDisk  
04F9:0174:01=Brother MFC-3340CN  
04F9:0174:02=Brother MFC-3340CN Fax Only

04F9:017B=Imagistics sx2100  
04F9:0180=MFC-7420  
04F9:0180:01=Brother MFC-7420  
04F9:0180:02=Brother MFC-7420 Fax Only  
04F9:0181=MFC-7820N Port (FaxModem)  
04F9:0181:01=Brother MFC-7820N  
04F9:0181:02=Brother MFC-7820N Fax Only  
04F9:0182=Composite Device  
04F9:0182:01=Brother DCP-7010  
04F9:0183=DCP-7020  
04F9:0183:01=Brother DCP-7020  
04F9:0184=DCP-7025 Printer  
04F9:0184:01=Brother DCP-7025  
04F9:0185=MFC-7220 Printer  
04F9:0185:01=Brother MFC-7220  
04F9:0185:02=Brother MFC-7220 Fax Only  
04F9:0186=Composite Device  
04F9:0186:01=Brother MFC-7225N  
04F9:0186:02=Brother MFC-7225N Fax Only  
04F9:0187=FAX-2820 Printer  
04F9:0188=FAX-2920 Printer  
04F9:018A=MFC-9420CN  
04F9:018A:01=Brother MFC-9420CN  
04F9:018A:02=Brother MFC-9420CN Fax Only  
04F9:018B:02=Brother FAX-2810 Fax Only  
04F9:018C=DCP-115C  
04F9:018C:01=Brother DCP-115C  
04F9:018D=DCP-116C  
04F9:018D:01=Brother DCP-116C  
04F9:018E=DCP-117C  
04F9:018E:01=Brother DCP-117C  
04F9:018F=DCP-118C  
04F9:0190=DCP-120C  
04F9:0190:01=Brother DCP-120C  
04F9:0191=DCP-315CN  
04F9:0191:01=Brother DCP-315CN  
04F9:0192=DCP-340CW  
04F9:0192:01=Brother DCP-340CW  
04F9:0193=MFC-215C  
04F9:0193:01=Brother MFC-215C  
04F9:0194=MFC-425CN  
04F9:0194:01=Brother MFC-425CN  
04F9:0194:02=Brother MFC-425CN Fax Only  
04F9:0195=MFC-820CW Remote Setup Port  
04F9:0195:01=Brother MFC-820CW  
04F9:0195:02=Brother MFC-820CW Fax Only  
04F9:0196=MFC-820CN Remote Setup Port  
04F9:0196:01=Brother MFC-820CN  
04F9:0196:02=Brother MFC-820CN Fax Only  
04F9:0197=MFC-640CW  
04F9:0197:01=Brother MFC-640CW  
04F9:0197:02=Brother MFC-640CW Fax Only  
04F9:0198:01=Brother MFC-615CL  
04F9:0198:02=Brother MFC-615CL Fax Only  
04F9:0199:01=Brother MFC-830CLN  
04F9:0199:02=Brother MFC-830CLN Fax Only  
04F9:019A=MFC-840CLN Remote Setup Port  
04F9:019A:01=Brother MFC-840CLN  
04F9:019A:02=Brother MFC-840CLN Fax Only  
04F9:01A2=MFC-8640D

04F9:01A2:01=Brother MFC-8640D  
04F9:01A2:02=Brother MFC-8640D Fax Only  
04F9:01A3=Composite Device  
04F9:01A3:01=Brother DCP-8060  
04F9:01A4=DCP-8065DN Printer  
04F9:01A4:01=Brother DCP-8065DN  
04F9:01A5=MFC-8460N Port (FaxModem)  
04F9:01A5:01=Brother MFC-8460N  
04F9:01A5:02=Brother MFC-8460N Fax Only  
04F9:01A6=MFC-8860DN Port (FaxModem)  
04F9:01A6:01=Brother MFC-8860DN  
04F9:01A6:02=Brother MFC-8860DN Fax Only  
04F9:01A7=MFC-8870DW Printer  
04F9:01A7:01=Brother MFC-8870DW  
04F9:01A7:02=Brother MFC-8870DW Fax Only  
04F9:01A8=DCP-130C  
04F9:01A8:01=Brother DCP-130C  
04F9:01A9=DCP-330C  
04F9:01A9:01=Brother DCP-330C  
04F9:01AA=DCP-540CN  
04F9:01AA:01=Brother DCP-540CN  
04F9:01AB=MFC-240C  
04F9:01AB:01=Brother MFC-240C  
04F9:01AE=DCP-750CW RemovableDisk  
04F9:01AE:01=Brother DCP-750CW  
04F9:01AF=MFC-440CN  
04F9:01AF:01=Brother MFC-440CN USB  
04F9:01AF:02=Brother MFC-440CN Fax Only  
04F9:01B0=MFC-660CN  
04F9:01B0:01=Brother MFC-660CN  
04F9:01B0:02=Brother MFC-660CN Fax Only  
04F9:01B1=MFC-665CW Remote Setup Port  
04F9:01B1:01=Brother MFC-665CW  
04F9:01B1:02=Brother MFC-665CW Fax Only  
04F9:01B2=MFC-845CW Remote Setup Port  
04F9:01B2:01=Brother MFC-845CW  
04F9:01B2:02=Brother MFC-845CW Fax Only  
04F9:01B4=MFC-460CN Remote Setup Port  
04F9:01B4:01=Brother MFC-460CN  
04F9:01B4:02=Brother MFC-460CN Fax Only  
04F9:01B5=MFC-630CD  
04F9:01B5:01=Brother MFC-630CD USB  
04F9:01B5:02=Brother MFC-630CD Fax Only  
04F9:01B6=MFC-850CDN  
04F9:01B6:01=Brother MFC-850CDN USB  
04F9:01B6:02=Brother MFC-850CDN Fax Only  
04F9:01B7=MFC-5460CN Remote Setup Port  
04F9:01B7:01=Brother MFC-5460CN USB  
04F9:01B7:02=Brother MFC-5460CN Fax Only  
04F9:01B8=MFC-5860CN  
04F9:01B8:01=Brother MFC-5860CN USB  
04F9:01B8:02=Brother MFC-5860CN Fax Only  
04F9:01BA=MFC-3360C  
04F9:01BA:01=Brother MFC-3360C  
04F9:01BA:02=Brother MFC-3360C Fax Only  
04F9:01BD=MFC-8660DN  
04F9:01BD:01=Brother MFC-8660DN  
04F9:01BD:02=Brother MFC-8860DN Fax Only  
04F9:01BE=DCP-750CN RemovableDisk  
04F9:01BE:01=Brother DCP-750CN

04F9:01BF=MFC-860CDN Remote Setup Port  
04F9:01BF:01=Brother MFC-860CCN  
04F9:01BF:02=Brother MFC-860CCN Fax Only  
04F9:01C0=DCP-128C  
04F9:01C0:01=Brother DCP-128C  
04F9:01C1=DCP-129C  
04F9:01C1:01=Brother DCP-129C  
04F9:01C2=DCP-131C  
04F9:01C2:01=Brother DCP-131C  
04F9:01C3=DCP-329C  
04F9:01C3:01=Brother DCP-329C  
04F9:01C4=DCP-331C  
04F9:01C4:01=Brother DCP-331C  
04F9:01C5=MFC-239C  
04F9:01C5:01=Brother MFC-239C  
04F9:01C9:01=Brother DCP-9040CN  
04F9:01CA=MFC-9440CN Remote Setup Port  
04F9:01CA:01=Brother MFC-9440CN  
04F9:01CA:02=Brother MFC-9440CN Fax Only  
04F9:01CB:01=Brother DCP-9045CDN  
04F9:01CC:01=Brother MFC-9840CDW  
04F9:01CC:02=Brother MFC-9840CDW Fax Only  
04F9:01CE=DCP-135C  
04F9:01CE:01=Brother DCP-135C  
04F9:01CF=DCP-150C  
04F9:01CF:01=Brother DCP-150C  
04F9:01D0=DCP-350C  
04F9:01D0:01=Brother DCP-350C  
04F9:01D1=DCP-560CN  
04F9:01D1:01=Brother DCP-560CN  
04F9:01D2:01=Brother DCP-770CW  
04F9:01D3:01=Brother DCP-770CN  
04F9:01D4=MFC-230C  
04F9:01D4:01=Brother MFC-230C  
04F9:01D5=MFC-235C  
04F9:01D5:01=Brother MFC-235C  
04F9:01D6=MFC-260C  
04F9:01D6:01=Brother MFC-260C  
04F9:01D7:01=Brother MFC-465CN  
04F9:01D7:02=Brother MFC-465CN Fax Only  
04F9:01D8:01=Brother MFC-680CN  
04F9:01D8:02=Brother MFC-680CN Fax Only  
04F9:01D9:01=Brother MFC-685CW  
04F9:01D9:02=Brother MFC-685CW Fax Only  
04F9:01DA:01=Brother MFC-885CW  
04F9:01DA:02=Brother MFC-885CW Fax Only  
04F9:01DB:01=Brother MFC-480CN  
04F9:01DB:02=Brother MFC-480CN Fax Only  
04F9:01DC:01=Brother MFC-650CD  
04F9:01DC:02=Brother MFC-650CD Fax Only  
04F9:01DD:01=Brother MFC-870CDN  
04F9:01DD:02=Brother MFC-870CDN Fax Only  
04F9:01DE:01=Brother MFC-880CDN  
04F9:01DE:02=Brother MFC-880CDN Fax Only  
04F9:01DF=DCP-155C  
04F9:01DF:01=Brother DCP-155C  
04F9:01E0=MFC-265C  
04F9:01E0:01=Brother MFC-265C  
04F9:01E1=DCP-153C  
04F9:01E1:01=Brother DCP-153C

04F9:01E2=DCP-157C  
04F9:01E2:01=Brother DCP-157C  
04F9:01E3=DCP-353C  
04F9:01E3:01=Brother DCP-353C  
04F9:01E4=DCP-357C  
04F9:01E4:01=Brother DCP-357C  
04F9:01E5:01=Brother MFC-7840W  
04F9:01E5:02=Brother MFC-7840W Fax Only  
04F9:01E6:01=Brother MFC-7440N  
04F9:01E6:02=Brother MFC-7440N Fax Only  
04F9:01E7=MFC-7340  
04F9:01E7:01=Brother MFC-7340  
04F9:01E7:02=Brother MFC-7340 Fax Only  
04F9:01E8:01=Brother DCP-7045N  
04F9:01E9=DCP-7040  
04F9:01E9:01=Brother DCP-7040  
04F9:01EA=DCP-7030  
04F9:01EA:01=Brother DCP-7030  
04F9:01EB=MFC-7320  
04F9:01EB:01=Brother MFC-7320  
04F9:01EB:02=Brother MFC-7320 Fax Only  
04F9:01EC:01=Brother MFC-9640CW  
04F9:01EC:02=Brother MFC-9640CW Fax Only  
04F9:01ED:01=Brother MFC-7840N  
04F9:01ED:02=Brother MFC-7840N Fax Only  
04F9:01EE:01=Brother MFC-7450  
04F9:01EE:02=Brother MFC-7450 Fax Only  
04F9:01F1:01=Brother DCP-6690CW  
04F9:01F2:01=Brother MFC-6490CN  
04F9:01F2:02=Brother MFC-6490CN Fax Only  
04F9:01F3:01=Brother MFC-6490CW  
04F9:01F3:02=Brother MFC-6490CW Fax Only  
04F9:01F4=MFC-5890CN  
04F9:01F4:01=Brother MFC-5890CN  
04F9:01F4:02=Brother MFC-5890CN Fax Only  
04F9:01F5:01=Brother MFC-5490CN  
04F9:01F5:02=Brother MFC-5490CN Fax Only  
04F9:01F6:01=Brother MFC-930CDN  
04F9:01F6:02=Brother MFC-930CDN Fax Only  
04F9:01F7:01=Brother MFC-670CD  
04F9:01F7:02=Brother MFC-670CD Fax Only  
04F9:01F8:01=Brother MFC-990CW  
04F9:01F8:02=Brother MFC-990CW Fax Only  
04F9:01F9:01=Brother MFC-790CW  
04F9:01F9:02=Brother MFC-790CW Fax Only  
04F9:01FA:01=Brother MFC-490CN  
04F9:01FA:02=Brother MFC-490CN Fax Only  
04F9:01FB:01=Brother MFC-490CW  
04F9:01FB:02=Brother MFC-490CW Fax Only  
04F9:01FC:01=Brother MFC-297C  
04F9:01FD:01=Brother MFC-290C  
04F9:01FE:01=Brother MFC-250C  
04F9:01FF:01=Brother DCP-535CN  
04F9:0200:01=Brother DCP-585CW  
04F9:0201:01=Brother DCP-385C  
04F9:0202:01=Brother DCP-387C  
04F9:0203:01=Brother DCP-383C  
04F9:0204:01=Brother DCP-165C  
04F9:0205:01=Brother DCP-185C  
04F9:0206:01=Brother DCP-145C



04F9:0207:01=Brother DCP-163C  
04F9:0208:01=Brother DCP-167C  
04F9:020A:01=Brother MFC-8670DN  
04F9:020A:02=Brother MFC-8670DN Fax only  
04F9:020C:01=Brother DCP-9042CDN  
04F9:020D:01=Brother MFC-9450CDN  
04F9:020D:02=Brother MFC-9450CDN Fax Only  
04F9:0214:01=Brother MFC-7345N  
04F9:0214:02=Brother MFC-7345N Fax Only  
04F9:1000=Printer  
04F9:1002=Printer  
04F9:2002=PTUSB Printing  
04F9:2004=PT-2300/2310 p-Touch Labor Printer  
04F9:2015=QL-500 P-touch label printer  
04F9:2016=QL-550 P-touch label printer  
04F9:201A=PT-18R P-touch label printer  
04F9:201B=QL-650TD P-Touch Label Printer  
04F9:2027=QL-560 P-Touch Label Printer  
04F9:2100=Card Reader Writer  
04FA=Dallas Semiconductor  
04FA:2490=DS1490F 2-in-1 Fob, 1-Wire adapter  
04FA:4201=Generic USB Audio Device  
04FB=Biostar Microtech  
04FC=SunPlus  
04FC:0003=CM1092 Optical Scroller Mouse  
04FC:0005=USB Browser Mouse  
04FC:0013=ViewMate Desktop Mouse CC2201  
04FC:0015=ViewMate Desktop Mouse CC2201  
04FC:00D3=00052486 / Laser Mouse M1052 [hama]  
04FC:0171=SPCA1527A/SPCA1528 SD card camera (Mass Storage mode)  
04FC:0232=Fingerprint  
04FC:0538=Wireless Optical Mouse 2.4G [Bright]  
04FC:0561=Flexcam 100  
04FC:05D8=Wireless keyboard/mouse  
04FC:0C15=SPIF215A SATA bridge  
04FC:0C25=SPIF225A USB to SATA Bridge  
04FC:1528=SPCA1527A/SPCA1528 SD card camera (webcam mode)  
04FC:1533=Mass Storage  
04FC:2080=ASUS Webcam  
04FC:500C=CA500C Digital Camera  
04FC:504A=SPCA504a Digital Camera  
04FC:504A:01=Mega Camera, WDM DSC I/O Driver  
04FC:504B=Aiptek, 1.3 mega PockerCam  
04FC:5330=Digitrex 2110  
04FC:5330:01=Icatch(IV) Still Camera Device  
04FC:5331=Vivitar Vivicam 10  
04FC:5360=Sunplus Generic Digital Camera  
04FC:5720=Card Reader Driver  
04FC:7333=Finet Technology Palmpix DC-85  
04FC:755A=Sunplus MultiMedia Disk  
04FC:757A=Sunplus MultiMedia Disk  
04FC:8591=Sunplus MultiMedia Disk  
04FC:FFFF=PureDigital Ritz Disposable  
04FD=Soliton Systems  
04FD:0003=Soliton Smart Card Reader II  
04FE=PFU  
04FF=E-CMOS  
0500=SUH  
0500:0001=SUH DART USB Keyboard Mouse  
0500:0001:01=SUH DART USB Keyboard Mouse

0500:0002=SUH DART-2 USB Keyboard  
0501=DDK Electronics  
0502=Acer  
0502:0001=Acer Handheld  
0502:0736=Acer Handheld  
0502:15B1=PDA n311  
0502:1631=c10 Series  
0502:1632=c20 Series  
0502:16E1=Acer N10 USB Function  
0502:16E2=Acer n20 Pocket PC USB Sync  
0502:16E3=n30 Handheld Sync  
0502:3202=Liquid  
0502:3203=Liquid (Debug mode)  
0502:3325=Iconia tablet A500  
0502:3341=Iconia tablet A500  
0502:D001=Divio NW801/DVC-V6+ Digital Camera  
0503=Hitachi America  
0504=Hayes Microcomputer Products  
0506=3Com  
0506:009D=HomeConnect Camera  
0506:00A0=3CREB96 Bluetooth Adapter  
0506:00A1=3Com Bluetooth USB Device  
0506:00A2=3Com Bluetooth USB Device  
0506:00DF=3Com Home Connect  
0506:0100=HomeConnect ADSL Modem Driver  
0506:03E8=3C19250 Ethernet [klsi]  
0506:0A01=3CRSHEW696 Wireless Adapter  
0506:0A01:0100=3Com 3CRSHEW696 Wireless LAN USB Adapter  
0506:0A11=3CRWE254G72 802.11g Adapter  
0506:11F8=3Com HomeConnect Ethernet USB Adapter (3C460)  
0506:2922=3Com HomeConnect Cable Modem External with USB  
0506:3021=U.S.Robotics 56000 Voice FaxModem Pro  
0506:4601=3Com 3C460B 10/100 Mbps USB Ethernet Network Adapter  
0506:F002=3CP4218 ADSL Modem (pre-init)  
0506:F003=3CP4218 ADSL Modem  
0506:F100=3CP4218 ADSL Modem (pre-init)  
0507=Hosiden  
0507:0011=Konami ParaParaParadise Controller  
0508=Clarion  
0509=Aztech Systems  
0509:0801=ADSL Modem  
0509:0802=ADSL Modem (RFC1483)  
0509:0806=DSL Modem  
0509:080F=Binatone ADSL500 Modem Network Interface  
0509:0812=Pirelli ADSL Modem Network Interface  
050A=Cinch Connectors  
050B=Cable System International  
050C=InnoMedia  
050D=Belkin  
050D:0004=Direct Connect  
050D:0012=Belkin Bluetooth 2.0 USB Adapter filter  
050D:0013=Belkin Bluetooth 2.0 USB Adapter filter  
050D:0017=BCM2046 B1 BLUETOOTH USB + EDR ADAPTER CLASS 1 v2.1 UHE  
050D:0019=LOW-PROF BLUETOOTH ADPTR CLASS 2 10M  
050D:003A=Universal Media Reader  
050D:0050=F5D6050 802.11b Wireless Adapter  
050D:0081=Belkin Bluetooth Adapter  
050D:0083=Belkin Bluetooth Device  
050D:0084=Belkin Bluetooth Adapter  
050D:0102=Flip KVM

050D:0103=Belkin F5U103 USB-RS232 Adapter  
050D:0106=Belkin USB VideoBus II Adapter, Video  
050D:0106:01=Belkin USB VideoBus II Adapter, Audio  
050D:0108=F1DE108B KVM  
050D:0109=F5U109 PDA Adapter  
050D:0115=SCSI Adapter  
050D:0119=F5U119 USB to PS/2 Adapter  
050D:0119:01=F5U119 USB to PS/2 Mouse  
050D:0119:0120=F5U119 USB to PS/2 Keyboard  
050D:0121=F5D5050 100Mbps Ethernet  
050D:0122=Belkin USB Ethernet Adapter  
050D:0131=Belkin Bluetooth Device  
050D:016A=BCM2046 B1 BLUETOOTH USB + EDR ADAPTER CLASS 2 v2.1 UHE  
050D:0201=Belkin USB Peripheral Switch  
050D:0201:0100=Belkin F1U401 4x1 USB Switch Control  
050D:0208=Belkin USB VideoBus II, Video  
050D:0208:01=Belkin USB VideoBus II, Audio  
050D:0210=F5U228 Hi-Speed USB 2.0 DVD Creator  
050D:0211=F5U211 USB 2.0 15-in-1 Media Reader & Writer  
050D:0217=Belkin Components Hi-Speed 4-port USB 2.0 Hub  
050D:0217:0100=Belkin Components Hi-Speed 4-port USB 2.0 Hub (F5U217)  
050D:0224=Belkin Components Hi-Speed 4-port USB 2.0 Hub  
050D:0231=Belkin F5U231 Hi-Speed USB 2.0 TetraHub  
050D:0234=F5U234 USB V2.0 4-Port Hub  
050D:0237=Belkin Components Hi-Speed 7-Port USB 2.0 Hub  
050D:0240=F5U240 USB 2.0 CF Card Reader  
050D:0249=USB 2 Flash Media Device  
050D:0257=F5U257 Serial  
050D:0304=FSU304 USB 2.0 - 4 Ports Hub  
050D:0307=Belkin Components Hi-Speed 7-Port USB 2.0 Hub  
050D:0409=F5U409 Serial  
050D:0551=F6C550-AVR UPS  
050D:0706=2-N-1 USB 2.0 7-Port Hub (Lower half)  
050D:0802=Nostromo n40 USB Gamepad  
050D:0803=Nostromo n45 USB Dual Analog Gamepad  
050D:0805=Nostromo N50 GamePad  
050D:0815=Nostromo n52 HID SpeedPad 2.0  
050D:0815:01=Nostromo n52 HID SpeedPad 2.0 Mouse Wheel  
050D:0826=ErgoFit Wireless Optical Mouse (HID)  
050D:0834=Belkin MediaPilot Wireless Keyboard  
050D:0980=HID UPS Battery  
050D:1003=N450 USB adapter  
050D:1102=Realtek RTL8188CE-VAU 1T1R 802.11n WLAN Adapter  
050D:1202=F5U120-PC Parallel Printer Port  
050D:1203=Belkin F5U120 USB-RS232 Adapter  
050D:2102=Belkin Surf & Share Wireless USB Adapter  
050D:2103=N300 USB Network Adapter  
050D:258A=Belkin USB Easy Transfer Cable  
050D:258B=Belkin USB Easy Transfer Cable  
050D:258C=Belkin USB Easy Transfer Cable  
050D:258D=Belkin USB Easy Transfer Cable  
050D:302A=Belkin Wireless USB HWA  
050D:302B=Belkin Host Wire Adapter  
050D:302C=Belkin Cable Association Device  
050D:302D=Belkin Wireless USB Hub  
050D:302E=Belkin Cable Association Interface  
050D:3101=F1DF102U/F1DG102U Flip Hub  
050D:3201=F1DF102U/F1DG102U Flip KVM  
050D:4050=Verizon Wireless G USB Network Adapter  
050D:5055=F5D5055

050D:6051=11Mbps Wireless Network Adapter  
050D:615A=F7D4101 / F9L1101 802.11abgn Wireless Adapter [Broadcom BCM4323]  
050D:7050=F5D7050 ver 1000 WiFi  
050D:7051=F5D7051 54g USB Network Adapter  
050D:705A=Belkin Wireless G USB Adapter  
050D:705B=Belkin Wireless G USB Adapter  
050D:705C=Belkin Wireless G USB Network Adapter  
050D:705E=Realtek RTL8187B [F5D7050 Wireless G Adapter v5000]  
050D:706A=2-N-1 USB 2.0 7-Port Hub (Lower half)  
050D:8053=Belkin F5D8053 N Wireless USB Adapter  
050D:805C=F5D8053 N Wireless Adapter v3000 [Ralink RT2870]  
050D:805E=Belkin F5D8053 N Wireless USB Adapter  
050D:815C=Belkin F5D8053 N Wireless USB Adapter  
050D:815F=Belkin N Wireless USB Adapter  
050D:825A=Ralink RT2870 [F5D8055 N+ Wireless Adapter v1000]  
050D:825B=Ralink RT3070 [F5D8055 N+ Wireless Adapter v2000]  
050D:845A=Belkin Connect Wireless USB Adapter  
050D:8B5A=Ativa Wireless N USB Adapter  
050D:905B=Belkin Wireless G Plus MIMO USB Network Adapter  
050D:905C=Belkin Wireless G Plus MIMO USB Network Adapter  
050D:935A=F6D4050 N150 Enhanced Wireless Network Adapter v1000 [Ralink RT2870]  
050D:935B=F6D4050 N150 Enhanced Wireless Network Adapter v2000 [Ralink RT3070]  
050D:945A=Belkin Basic Wireless USB Adapter  
050E=Neon Technology  
050F=Kawatsu Semiconductor  
050F:0001=KC Technology USB Hub  
050F:0003=KC82C160S Hub  
050F:0180=KC-180 IrDA Dongle  
050F:0190=KC2190 USB Host-to-Host cable  
0510=Sejin  
0510:0001=Sejin USB Keyboard  
0510:1000=Sejin USB Keyboard with PS/2 Mouse Port  
0510:1000:01=Sejin USB Keyboard Mouse  
0510:E001=Sejin USB Mouse  
0510:E001:01=Sejin USB Mouse  
0511=N'ABLE Technologies  
0512=Hualon Microelectronics  
0513=digital-X  
0514=Berg Electronics  
0515=ACTC  
0516=Longwell Electronics  
0517=Butterfly Communications  
0518=EzKEY  
0518:0001=EzKEY USB to PS2 Keyboard  
0518:0001:01=EzKEY USB to PS2 Mouse  
0518:0001:0001=EzKEY USB to PS2 Keyboard - EZ-PU21  
0518:0001:0001:01=EzKEY USB to PS2 Mouse - EZ-PU21  
0518:0002=Office Keyboard  
0518:0002:01=Office Keyboard  
0518:0005=Office Keyboard  
0518:0008=Office Keyboard  
0519=Star Micronics  
0519:0003=TSP100ECO/TSP100II  
0519:C002=Xlive Bluetooth XBM-100S MP3 Player  
051A=WYSE Technology  
051A:A005=Smart Display Version 9973  
051B=Silicon Graphics  
051C=Holco Enterprise  
051C:0005=VFD Module  
051C:C001=eHome Infrared Receiver (USBCIR)

051C:C002=eHome Infrared Receiver (USBCIR)  
051D=American Power Conversion  
051D:0000=American Power Conversion USB UPS  
051D:0001=American Power Conversion USB UPS  
051D:0002=American Power Conversion USB UPS (Apcupsd)  
051D:0003=American Power Conversion USB UPS  
051D:0004=APC UPS  
051D:0005=APC UPS  
051D:0006=APC UPS  
051D:0007=APC UPS  
051D:0008=APC UPS  
051D:0009=APC UPS  
051D:0010=APC UPS  
051D:0011=APC UPS  
051D:0012=APC UPS  
051E=Scientific Atlanta  
051F=Elite Electronics  
0520=Taiwan Semiconductor Manufacturing  
0521=Airborn Connectors  
0522=Advanced Connectek  
0523=ATEN GMBH  
0524=Micro Devices Technology  
0525=Net Chip Technology  
0525:100D=RFMD Bluetooth Device  
0525:1080=NET1080 USB-USB Bridge  
0525:1265=File-backed Storage Gadget  
0525:127A=USB 2.0 Debug Connection Device  
0525:A140=IOmega (OME) USB PocketZip 40 Driver  
0525:A141=IOmega (OME) USB PocketZip 40 MP3 Player Driver  
0525:A220=GVC Bluetooth Wireless Adapter  
0525:A4A0=Linux-USB "Gadget Zero"  
0525:A4A1=Linux-USB Ethernet Gadget  
0525:A4A2=Linux-USB Ethernet/RNDIS Gadget  
0525:A4A3=Linux-USB user-mode isochronous source/sink  
0525:A4A4=Linux-USB user-mode source/sink  
0525:A4A5=Linux-USB File Storage Gadget  
0525:A4A6=Linux-USB Serial Gadget  
0525:A4A7=Linux-USB Serial Gadget (CDC ACM mode)  
0525:A4A8=Linux-USB Printer Gadget  
0525:A4A9=Linux-USB OBEX Gadget  
0525:A4AA=Linux-USB CDC Composite Gadge (Ethernet and ACM)  
0526=Temic Matra  
0527=ALTRA  
0528=ATI Technologies  
0528:7561=TV Wonder  
0528:7561:01=ATI TV Wonder, USB Edition (NTSC+)  
0528:7562=TV Wonder, Edition (FN5)  
0528:7562:01=ATI TV Wonder, USB Edition (FN5)  
0528:7563=TV Wonder, Edition (FI)  
0528:7563:01=ATI TV Wonder, USB Edition (FI)  
0528:7564=TV Wonder, Edition (FQ)  
0528:7564:01=ATI TV Wonder, USB Edition (FQ)  
0528:7565=TV Wonder, Edition (NTSC+)  
0528:7565:01=ATI TV Wonder, USB Edition (NTSC+)  
0528:7566=TV Wonder, Edition (FN5)  
0528:7566:01=ATI TV Wonder, USB Edition (FN5)  
0528:7567=TV Wonder, Edition (FI)  
0528:7567:01=ATI TV Wonder, USB Edition (FI)  
0528:7568=TV Wonder, Edition (FQ)  
0528:7568:01=ATI TV Wonder, USB Edition (FQ)

0528:7569=Live! Pro (A)  
0528:7569:01=ATI USB Live! Pro Audio (A)  
0528:756A=Live! Pro Audio (O)  
0528:756A:01=ATI USB Live! Pro Audio (O)  
0529=Fast Security AG  
0529:0001=Aladdin USB Key  
0529:0001:01=Aladdin Key - eToken  
0529:030B=eToken R1 v3.1.3.x  
0529:0313=eToken R1 v3.2.3.x  
0529:031B=eToken R1 v3.3.3.x  
0529:0323=eToken R1 v3.4.3.x  
0529:0412=eToken R2 v2.2.4.x  
0529:041A=eToken R2 v2.2.4.x  
0529:0422=eToken R2 v2.4.4.x  
0529:042A=eToken R2 v2.5.4.x  
0529:050B=USB Token  
0529:050C=eToken Pro v4.1.5.x  
0529:0513=USB Token  
0529:0514=eToken Pro v4.2.5.4  
0529:0600=eToken Pro 64k (4.2)  
0529:0602=USB Token  
0529:0603=USB Token  
0529:0604=USB Token  
0529:0605=USB Token  
0529:0606=USB Token  
0529:0607=USB Token  
0529:0608=USB Token  
0529:0609=USB Token  
0529:060A=USB Token  
0529:0620=USB Token  
0529:0621=USB Token  
0529:0700=USB Token  
0529:0702=USB Token  
0529:0703=USB Token  
0529:0704=USB Token  
0529:0705=USB Token  
0529:0706=USB Token  
0529:0707=USB Token  
0529:0708=USB Token  
0529:0709=USB Token  
0529:070A=USB Token  
0529:0720=USB Token  
0529:0721=USB Token  
052A=Crescent Heart Software  
052B=Tekom Development  
052B:0102=Ca508A HP1020 Camera v.1.3.1.6  
052B:0801=Yakumo MegaImage 37  
052B:1512=Yakumo MegaImage IV  
052B:1513=Aosta CX100 WebCam  
052B:1514=Aosta CX100 WebCam Storage  
052B:1905=Yakumo MegaImage 47  
052B:1911=Yakumo MegaImage 47 SL  
052B:2202=WDM Still Image Capture  
052B:2203=Sound Vision Stream Driver  
052B:3A06=DigiLife DDV-5120A  
052B:D001=P35U Camera Capture  
052C=Canon Information System  
052D=Avid Electronics  
052E=Standard Microsystems  
052F=Unicore Software

0530=American Microsystems  
0531=Wacom Technology  
0532=Systemtech  
0533=Alcatel Mobile Phones  
0534=Motorola  
0535=LIH TZU Electric  
0536=Honeywell formerly Welch Allyn Hand Held Products  
0536:018A=IT5800 Linear Imager  
0536:01A0=Portable Data Terminal  
0536:01CA=IT4800 Area Imager  
0536:020A=IT4600 Area Imager  
0536:026A=IT2020 Cordless Base  
0536:028A=IT4200 Area Imager  
0536:02CA=QC890 Verifier  
0536:02EA=3800G Linear Imager  
0536:030A=5180 Area Imager  
0536:032A=5110 Area Imager  
0536:04CA=4600r 2D Imager  
0536:04EA=4800dr Document Reader  
0536:052A=4800P 2D Imager  
0537=Inventec  
0538=Santa Cruz Operation  
0539=Shyh Shiun Terminals  
053A=Preh Werke  
053A:0B00=Hub  
053B=Global Village Communication  
053C=Institut of Microelectronic & Mechatronic Systems  
053D=Silicon Architect  
053E=Electronic Accessory Specialists  
053F=Synopsys  
0540=Universal Access  
0540:0101=Panache Surf ISDN TA  
0541=Sirf Technology  
0543=View Sonic  
0543:00FE=G773 Monitor Hub  
0543:00FF=P815 Monitor Hub  
0543:0BF2=ViewSonic airpanel V150 Wireless Smart Display  
0543:0BF3=ViewSonic airpanel V110 Wireless Smart Display  
0543:0ED9=ViewSonic Color Pocket PC V35  
0543:0F01=airsync Wi-Fi Wireless Adapter  
0543:1527=ViewSonic Color Pocket PC V36  
0543:1529=ViewSonic Color Pocket PC V37  
0543:152B=ViewSonic Color Pocket PC V38  
0543:152E=ViewSonic Pocket PC  
0543:1921=ViewSonic Communicator Pocket PC  
0543:1922=ViewSonic Smartphone  
0543:1923=ViewSonic Pocket PC V30  
0543:1A11=Wireless 802.11g Adapter  
0543:1E60=TA310 - ATSC/NTSC/PAL Driver(PCM4)  
0543:4153=ViewSonic G773 Control (?)  
0544=Cristie Electronics  
0545=Xirlink  
0545:7333=Trution Web Camera  
0545:8002=IBM NetCamera  
0545:8009=Veo PC Camera  
0545:800C=Veo StingRay  
0545:800D=Veo PC Camera  
0545:8080=IBM C-It WebCam  
0545:808A=Veo PC Camera  
0545:808B=Veo PC Camera

0545:808D=Veo PC Camera  
0545:810A=Veo Advanced Connect WebCam  
0545:810B=Veo PC Camera  
0545:810C=Veo PC Camera  
0545:8135=Veo Mobile/Advanced Web Camera  
0545:813A=Veo PC Camera  
0545:813B=Veo PC Camera  
0545:813C=Veo Mobile/Advanced Web Camera  
0545:8333=Veo Stingray/Connect Web Camera  
0545:888C=eVision 123 digital camera  
0545:888D=eVision 123 digital camera  
0546=Polaroid  
0546:0DAF=PDC 2300Z  
0546:1BED=PDC 1320 Camera  
0546:20D1=Polaroid SprintScan 4000+  
0546:3097=PDC 310  
0546:3155=PDC 3070 Camera  
0546:3187=Digital Camera  
0546:3191=Ion 80 Camera  
0546:3273=PDC 2030 Camera  
0546:3304=a500 Digital Camera  
0546:DCCF=Sound Vision Stream Driver  
0547=Anchor Chips  
0547:0001=ICSI Bluetooth Device  
0547:1002=Python2 WDM Encoder  
0547:1004=CAS Interface 2 USB  
0547:1005=CAS Interface 2 USB  
0547:1006=Hantek DSO-2100 UF  
0547:1010=Dynamite  
0547:2131=AN2131 EZUSB Microcontroller  
0547:2235=AN2235 EZUSB-FX Microcontroller  
0547:2710=EZ-Link Loader (EZLNKCLR.SYS)  
0547:2720=AN2720 USB-USB Bridge  
0547:2727=Xircom PGUNET USB-USB Bridge  
0547:2750=EZ-Link (EZLNKUSB.SYS)  
0547:2810=USB Storage Adapter FX (TPP)  
0547:3121=CAS Interface 2 USB  
0547:7777=TAIYO YUDEN Bluetooth Device  
0547:9999=AN2131 uninitialized (?)  
0548=Tyan Computer  
0548:1005=EZ Cart II GameBoy Flash Programmer  
0549=Pixera  
054A=Fujitsu Microelectronics  
054B=New Media  
054C=Sony  
054C:0001=Sony USB HUB  
054C:0002=Standard USB HUB  
054C:0010=Sony Digital Camera  
054C:0010:0328=Sony DSC  
054C:0012=Çë°²×°³ŞÈÌá¹@µÄÇý¶¯³ÌÐò  
054C:0014=Nogatech USBVision (SY)  
054C:0022=USB Storage Adapter V2 (TPP)  
054C:0023=Sony USB CD-R/RW Drive  
054C:0024=Sony Mavica Digital Still Camera  
054C:0025=Sony USB Memory Stick Walkman  
054C:002B=USB Storage Adapter V2 (TPP)  
054C:002C=Sony USB Floppy  
054C:002D=Sony Memory Stick Reader/Writer  
054C:002E=Sony Camcorder  
054C:002E:0200=Sony Camcorder



054C:0030=USB Storage Adapter V2 (TPP)  
054C:0032=Sony Memory Stick Reader/Writer  
054C:0035=Sony Network Walkman (E)  
054C:0036=Net MD  
054C:0037=Sony MG Memory Stick Reader/Writer  
054C:0038=Clie PEG-S300/D PalmOS PDA  
054C:0039=Network Walkman (MS)  
054C:003C=VAIO-MX LCD Control  
054C:0045=Sony Digital Imaging Video  
054C:0045:01=Sony Digital Imaging Audio  
054C:0046=Sony USB Network Walkman  
054C:004A=Sony USB Memory Stick Hi-Fi System  
054C:004B=Memory Stick Reader/Writer  
054C:004E=DSC-xxx (ptp)  
054C:0055=Sony USB Mass Storage Driver for Projector  
054C:0056=Sony MG Memory Stick Reader/Writer  
054C:0058=Sony MG Memory Stick CLIE  
054C:0066=Clie PEG-N7x0C PalmOS PDA Serial  
054C:0067=CMR-PC3 Webcam  
054C:0069=Sony Memory Stick Reader/Writer  
054C:006C=FeliCa S310 [PaSoRi]  
054C:006D=Clie PEG-T425 PDA Mass Storage  
054C:006F=Sony Network Walkman (EV)  
054C:0073=USB Storage CRX1750U  
054C:0075=Net MD  
054C:0076=USB Storage Adapter ACR-U20  
054C:007C=Net MD  
054C:007F=Sony IC Recorder (MS)  
054C:0080=Net MD  
054C:0081=Net MD  
054C:0084=Net MD  
054C:0085=Net MD  
054C:0086=Net MD  
054C:008B=Micro Vault 64M Mass Storage  
054C:0095=Sony Handheld  
054C:0099=Clie NR70 PDA Mass Storage  
054C:009A=Clie NR70 PDA Serial  
054C:00AA=Sony Projector (Memory Stick)  
054C:00AB=Sony Visual Communication Camera (PCGA-UVC10)  
054C:00AB:01=Sony USB Microphone (PCGA-UVC10)  
054C:00AF=DPP-EX Series Digital Photo Printer  
054C:00BF=IC Recorder (S)  
054C:00C0=Sony Digital Imaging Video  
054C:00C0:01=Sony Digital Imaging Audio  
054C:00C6=Net MD  
054C:00C7=Net MD  
054C:00C8=MZ-N710 Minidisc Walkman  
054C:00C9=Net MD  
054C:00CA=MZ-DN430 Minidisc Walkman  
054C:00CB=MSAC-US20 Memory Stick Reader  
054C:00DA=Sony Clie nx60  
054C:00E8=Sony Network Walkman (MS)  
054C:00E9=Handheld  
054C:00EB=Net MD  
054C:0101=Net MD  
054C:0103=IC Recorder (ST)  
054C:0105=Micro Vault Hub  
054C:0107=VCC-U01 Visual Communication Camera  
054C:0110=Sony Digital Imaging Video  
054C:0110:01=Sony Digital Imaging Audio

054C:0113=Net MD  
054C:0116=IC Recorder (P)  
054C:0144=Clie PEG-TH55 PDA  
054C:0147=Sony Visual Communication Camera (PCGA-UVC11)  
054C:0147:01=Sony USB Microphone (PCGA-UVC11)  
054C:014C=Aiwa AM-NX9 Net MD Music Recorder MDLP  
054C:014D=Memory Stick Reader/Writer  
054C:0154=Eyetoy Audio Device  
054C:015F=IC Recorder (BM)  
054C:0169=Clie PEG-TJ35 PDA Serial  
054C:016A=Clie PEG-TJ35 PDA Mass Storage  
054C:016B=Mobile HDD  
054C:016D=IC Recorder (SX)  
054C:016E=DPP-EX50 Digital Photo Printer  
054C:0171=SONY Fingerprint Sensor 3500  
054C:0174=Sony Memory Card Reader/Writer  
054C:017E=Net MD  
054C:017F=Hi-MD WALKMAN  
054C:0180=Net MD  
054C:0181=Hi-MD WALKMAN  
054C:0182=Net MD  
054C:0183=Hi-MD WALKMAN  
054C:0184=Net MD  
054C:0185=Hi-MD WALKMAN  
054C:0186=Net MD  
054C:0187=Hi-MD WALKMAN  
054C:0188=Net MD  
054C:018A=Net MD  
054C:018B=Hi-MD SOUND GATE  
054C:0198=Sony Memory Card Reader/Writer  
054C:019E=Micro Vault 1.0G Mass Storage  
054C:01AA=Sony MPEG RR-Engine  
054C:01AB=Sony MPEG RR-Engine  
054C:01AD=ATRAC HDD PA  
054C:01B4=Sony Memory Card Reader/Writer  
054C:01BB=802.11g  
054C:01BD=Sony Card Reader(01BD)  
054C:01C3=Sony Network Walkman  
054C:01C6=SONY MEMORY P-AUDIO  
054C:01C7=Printing Support  
054C:01C8=PSP Type A  
054C:01C9=PSP Type B  
054C:01D0=DVD+RW External Drive DRU-700A  
054C:01D5=IC RECORDER  
054C:01DE=VRD-VC10 [Video Capture]  
054C:01E9=Net MD  
054C:01EA=Hi-MD WALKMAN  
054C:01EE=IC RECORDER  
054C:01F6=Sony DRX-710UL  
054C:01FA=Sony IC Recorder (P)  
054C:01FB=NW-E405 Network Walkman  
054C:020E=Sony MPEG RR-Engine  
054C:020F=Device  
054C:0210=ATRAC HDD PA  
054C:0219=Net MD  
054C:021A=Hi-MD WALKMAN  
054C:021B=Net MD  
054C:021C=Hi-MD WALKMAN  
054C:021D=Net MD  
054C:0227=Printing Support

054C:022C=Net MD  
054C:022D=Hi-MD AUDIO  
054C:0233=ATRAC HDD PA  
054C:0236=Mobile HDD  
054C:023B=DVD+RW External Drive DRU-800UL  
054C:023C=Net MD  
054C:023D=Hi-MD WALKMAN  
054C:0243=MicroVault Flash Drive  
054C:024B=Vaio VGX Mouse  
054C:0257=Sony Interface Unit IFU-WLM2  
054C:0258=IFU-WLM2 USB Wireless LAN Module (Memory Mode)  
054C:0259=IC RECORDER  
054C:025F=Sony Memory Stick USB Reader/Writer (MSAC-US40)  
054C:0267=Tachikoma Device  
054C:0268=Batoh Device  
054C:0269=HDD WALKMAN  
054C:026A=HDD WALKMAN  
054C:0271=IC Recorder (P)  
054C:027C=NETWORK WALKMAN  
054C:027E=SONY Communicator  
054C:027F=IC RECORDER  
054C:0286=Net MD  
054C:0287=Hi-MD WALKMAN  
054C:0290=VGP-UVC100 Visual Communication Camera  
054C:029B=PRS-500 eBook reader  
054C:02A5=MicroVault Flash Drive  
054C:02AE=PlayStation 3 Memory Card Adaptor  
054C:02AF=Handycam DCR-DVD306E  
054C:02C4=Device  
054C:02D1=DVD RW  
054C:02D2=PSP  
054C:02E1=FeliCa S330 [PaSoRi]  
054C:02EA=PlayStation 3 Memory Card Adaptor  
054C:02F9=DSC-H9  
054C:0317=WALKMAN  
054C:031A=Walkman NWD-B103F  
054C:031E=PRS-505 reader  
054C:033E=DSC-W120  
054C:0346=Handycam DCR-SR55E  
054C:0348=HandyCam HDR-TG3E  
054C:034C=Realtek USB 2.0 Card Reader  
054C:035C=NWZ-A726/A728/A729  
054C:0382=Sony Card Reader(0382)  
054C:03A0=MotioninJoy Virtual Xinput device for Windows  
054C:03B4=MotioninJoy Virtual Xinput device for Windows  
054C:03BC=Webbie HD - MHS-CM1  
054C:03CC=Sony USB Multi-Card Reader - MRW68ED1  
054C:03D3=DR-BT100CX  
054C:03D5=PlayStation Move motion controller  
054C:03FC=WALKMAN [NWZ-E345]  
054C:03FD=WALKMAN  
054C:042F=MotioninJoy Virtual Xinput device for Windows  
054C:0440=DSC-H55  
054C:0485=MHS-PM5 HD camcorder  
054C:04CB=WALKMAN NWZ-E354  
054C:1000=Wireless Buzz! Receiver  
054D=Try  
054E=Proside  
054F=WYSE Technology Taiwan  
0550=Fuji Xerox

0550:0002=InkJet Color Printer  
0550:0004=InkJet Color Printer  
0550:0005=InkJet Color Printer  
0551=CompuTrend Systems  
0552=Philips Monitors  
0553=VLSI Vision  
0553:0001=TerraCAM USB  
0553:0002=CPiA WebCam  
0553:0100=STV0672 Camera  
0553:0140=Video Camera  
0553:0150=CDE CAM 100  
0553:0151=Digital Blue QX5 Microscope  
0553:0200=Dual-mode Camera0  
0553:0201=Dual-mode Camera1  
0553:0202=STMicroelectronics Imaging Division (VLSI Vision) Aiptek PenCam 1  
0553:0674=Multi-mode Camera  
0553:0679=NMS Video Camera (Webcam)  
0553:1002=Che-ez! Splash  
0554=Dictaphone  
0555=ANAM S&T  
0556=Asahi Kasei Microsystems  
0556:0001=AK5370 I/F A/D Converter  
0557=ATEN International  
0557:2001=UC-1284 Printer Port  
0557:2002=ATEN USB-Ethernet Adapter  
0557:2004=UC-100KM PS/2 Mouse and Keyboard adapter  
0557:2006=ATEN UC-1284B  
0557:2007=USB TO FAST ETHERNET  
0557:2008=ATEN UC-2000 Serial  
0557:2008:0001=ATEN UC-232A Serial  
0557:2009=UC-210T Ethernet  
0557:2011=UC-2324 4xSerial Ports [mos7840]  
0557:2202=CS124U Miniview II KVM Switch  
0557:2213=CS682 2-Port USB 2.0 DVI KVM Switch  
0557:2221=USB Keyboard  
0557:2221:01=USB Mouse  
0557:2404=4-port switch  
0557:2600=ATEN USB to IDE Adapter  
0557:2701=CE700A KVM Extender  
0557:4000=DSB-650 10Mbps Ethernet [klsi]  
0557:7000=Hub  
0557:7820=UC-2322 2xSerial Ports [mos7820]  
0558=Truevision  
0558:1009=GW Instek GDS-1000 Oscilloscope  
0558:100A=GW Instek GDS-1000A Oscilloscope  
0558:2009=GW Instek GDS-2000 Oscilloscope  
0559=Cadence Design Systems  
055A=Kenwood USA  
055B=KnowledgeTek  
055C=Proton Electronic  
055D=Samsung  
055D:0001=Samsung USB Keyboard  
055D:0BB1=SAMSUNG Bluetooth Device  
055D:1030=Samsung USB Optical Wheel Mouse (OMS3CB/OMGB30)  
055D:1031=Samsung USB Optical Wheel Mouse (OMA3CB/OMGI30)  
055D:1040=Optical Wheel Mouse USB Device for WindowXP  
055D:1050=Samsung USB E-Mail Optical Wheel Mouse (OMS3CE)  
055D:1080=Samsung USB Optical Wheel Mouse (OMS3CH)  
055D:2020=Samsung USB Floppy Disk Drive  
055D:3021=FMD9410NDL1 Multi-Card USB 2.0 Card Reader

055D:6780=Samsung USB Keyboard V1  
055D:6781=Samsung USB Keyboard Mouse  
055D:6781:01=Samsung USB Keyboard Mouse  
055D:8001=Samsung E.M. USB Hub  
055D:9000=AnyCam [pwc]  
055D:9001=MPC-C30 AnyCam Premium for Notebooks [pwc]  
055D:A000=SWL-2100U  
055D:A010=SAMSUNG WLAN USB Adapter(SWL-2300)  
055D:A011=SAMSUNG USB Boot Device  
055D:A012=SAMSUNG WLAN USB Adapter(SWL-2300)  
055D:A013=SAMSUNG WLAN USB Adapter(SWL-2350)  
055D:A230=USB Boot Device  
055D:B000=SAMSUNG 11Mbps WLAN Mini USB Adapter  
055D:B230=Netopia 802.11b WLAN USB Adapter  
055D:B231=LG Wireless LAN 11b USB Adapter  
055E=CTX  
055F=Mustek Systems  
055F:0001=ScanExpress 1200 CU  
055F:0002=ScanExpress 600 CU  
055F:0003=ScanExpress 1200 USB  
055F:0006=ScanExpress 1200 UB  
055F:0007=ScanExpress 1200 USB Plus  
055F:0008=ScanExpress 1200 CU Plus  
055F:0010=BearPaw 1200F  
055F:0210=ScanExpress A3 USB  
055F:0218=BearPaw 2400 TA  
055F:0219=BearPaw 2400 TA Plus  
055F:021A=BearPaw 2448 TA Plus  
055F:021B=BearPaw 1200 CU Plus  
055F:021C=BearPaw 1200CU Plus WIA Scanner  
055F:021D=BearPaw 2400CU Plus WIA Scanner  
055F:021E=BearPaw 1200 TA/CS  
055F:021F=MUSTEK 1248UB WIA Scanner  
055F:0400=BearPaw 2400 TA Pro  
055F:0401=P 3600 A3 Pro  
055F:0408=BearPaw 2448CU Pro WIA Scanner  
055F:0409=BearPaw 2448 TA Pro  
055F:040B=ScanExpress A3 USB 1200 PRO  
055F:0873=ScanExpress 600 USB  
055F:1000=BearPaw 4800 TA Pro  
055F:A350=gSmart 350  
055F:A800=MDC 800 Camera  
055F:B500=MDC 3000 Camera  
055F:C005=PC CAM 300A  
055F:C200=gSmart 300  
055F:C211=Kowa Bs888e Microcamera  
055F:C220=gSmart mini  
055F:C230=Digicam 330K  
055F:C232=MDC3500 Camera  
055F:C360=Mustek DV 4000  
055F:C420=GSmart Mini 2 WDM Video Capture  
055F:C420:01=GSmart Mini 2 WDM DSC I/O Driver  
055F:C430=gSmart LCD 2 Camera  
055F:C440=Mustek DV 3000  
055F:C520=gSmart mini 3  
055F:C530=Mustek Gsmart LCD 2  
055F:C540=gSmart D30 Camera  
055F:C630=MDC 4000 Camera  
055F:C631=MDC-4000  
055F:C640=5.0M SD DSC Video Capture

055F:C640:01=5.0M SD DSC WDM Bulk Driver  
055F:C650=Mustek MDC5500Z  
055F:D001=WCam 300  
055F:D003=WCam 300A  
055F:D004=WCam 300AN  
0560=Interface  
0561=Oasis Design  
0562=Telex Communications  
0562:0000=Telex USB Microphone  
0562:0001=Telex USB Microphone  
0562:0002=Telex USB Microphone  
0563=Immersion  
0564=Chinon Industries  
0565=Peracom Networks  
0565:0001=Serial Port [etek]  
0565:0002=Enet Ethernet [klsi]  
0565:0003=@Home Networks Ethernet [klsi]  
0565:0005=Enet2 Ethernet [klsi]  
0565:0041=Peracom USB Remote NDIS Ethernet Adapter  
0566=MIC  
0566:0110=ViewMate Desktop Mouse CC2201  
0566:1001=ViewMate Desktop Mouse CC2201  
0566:1002=ViewMate Desktop Mouse CC2201  
0566:1003=ViewMate Desktop Mouse CC2201  
0566:1004=ViewMate Desktop Mouse CC2201  
0566:1005=ViewMate Desktop Mouse CC2201  
0566:1006=ViewMate Desktop Mouse CC2201  
0566:1007=ViewMate Desktop Mouse CC2201  
0566:2800=MIC USB K/B  
0566:2801=MIC USB K/B Mouse  
0566:2801:01=MIC USB K/B Mouse  
0566:2802=Kbd Hub  
0566:2802:01=ViewMate Desktop Keyboard CC2201  
0566:2803:01=ViewMate Desktop Keyboard CC2201  
0566:2805:01=ViewMate Desktop Keyboard CC2201  
0566:2900:01=ViewMate Desktop Keyboard CC2201  
0566:3001:01=ViewMate Desktop Keyboard CC2201  
0566:3002:01=ViewMate Desktop Keyboard CC2201  
0566:3003:01=ViewMate Desktop Keyboard CC2201  
0566:3004=Genius KB-29E  
0566:3004:01=ViewMate Desktop Keyboard CC2201  
0566:3005:01=ViewMate Desktop Keyboard CC2201  
0566:3006:01=ViewMate Desktop Keyboard CC2201  
0566:3007:01=ViewMate Desktop Keyboard CC2201  
0566:3008:01=ViewMate Desktop Keyboard CC2201  
0566:3009:01=ViewMate Desktop Keyboard CC2201  
0566:3010:01=ViewMate Desktop Keyboard CC2201  
0566:3011:01=ViewMate Desktop Keyboard CC2201  
0566:3012:01=ViewMate Desktop Keyboard CC2201  
0566:3013:01=ViewMate Desktop Keyboard CC2201  
0566:3014:01=ViewMate Desktop Keyboard CC2201  
0566:3107:01=ViewMate Desktop Keyboard CC2201  
0566:3108:01=ViewMate Desktop Keyboard CC2201  
0566:3109:01=ViewMate Desktop Keyboard CC2201  
0566:3201:01=ViewMate Desktop Keyboard CC2201  
0566:3202:01=ViewMate Desktop Keyboard CC2201  
0566:3203:01=ViewMate Desktop Keyboard CC2201  
0567=Xyratex  
0568=Quartz Ingenierie  
0569=SegaSoft

056A=WACOM  
056A:0000=Wacom PenPartner  
056A:0001=PenPartner 4x5  
056A:0002=PenPartner 6x8  
056A:0003=Wacom CintiqPartner  
056A:0010=Graphire  
056A:0011=Graphire 2  
056A:0012=Graphire 2 5x7  
056A:0013=Graphire 3 4x5  
056A:0014=Graphire 3 6x8  
056A:0015=Graphire 4 4x5  
056A:0016=Graphire 4 6x8  
056A:0017=Bamboo Fun  
056A:0018=Bamboo Fun 6x8  
056A:0019=Bamboo One Medium  
056A:0020=Intuos 4x5  
056A:0021=Intuos 6x8  
056A:0022=Intuos 9x12  
056A:0023=Intuos 12x12  
056A:0024=Intuos 12x18  
056A:0030=PL400  
056A:0031=PL500  
056A:0032=PL600  
056A:0033=PL600SX  
056A:0034=PL550  
056A:0035=PL800  
056A:0037=PL700  
056A:0038=PL510  
056A:0039=DTU-710  
056A:003A=Wacom Mouse Monitor  
056A:003F=Cintiq 21UX  
056A:0041=Intuos2 4x5  
056A:0042=Intuos 2 6x8  
056A:0043=Intuos 2  
056A:0044=Intuos2 12x12  
056A:0045=Intuos2 12x18  
056A:0047=Intuos2 6x8  
056A:0060=Volito  
056A:0061=PenStation2  
056A:0062=Volito2 4x5  
056A:0063=Volito2 2x3  
056A:0064=PenPartner2  
056A:0065=Bamboo  
056A:0069=Bamboo One  
056A:006A=Wacom Mouse Monitor  
056A:006B=Wacom Mouse Monitor  
056A:0081=Graphire Wireless 6x8  
056A:0090=TPC90  
056A:0093=TPC93  
056A:0093:01=Wacom USB Touch  
056A:0095=Wacom USB ISD  
056A:0097=Wacom USB ISD  
056A:009A=TPC9A  
056A:009A:01=Wacom Capacitive Touch  
056A:00B0=Intuos3 4x5  
056A:00B1=Intuos3 6x18  
056A:00B2=Intuos3 9x12  
056A:00B3=Intuos3 12x12  
056A:00B4=Intuos3 12x19  
056A:00B5=Intuos3 6x11 (PTZ-631W)

056A:00B7=Intuos3 4x6  
056A:00B8=Intuos4 4x6  
056A:00B9=Intuos4 6x9  
056A:00BA=Intuos4 8x13  
056A:00BB=Intuos4 12x19  
056A:00BC=Wacom Mouse Monitor  
056A:00BD=Wacom Mouse Monitor  
056A:00C0=DTF-521  
056A:00C2=Wacom Mouse Monitor  
056A:00C4=DTF-720  
056A:00C5=Cintiq 20WSX  
056A:00C6=Cintiq 12WX  
056A:00C7=DTU-1931  
056A:00CC=Wacom Mouse Monitor  
056A:00CE=Wacom Mouse Monitor  
056A:00D0=Wacom Mouse Monitor  
056A:00D1=Bamboo Pen & Touch (CTH-460-DE)  
056A:00D2=Wacom Mouse Monitor  
056A:00D3=Bamboo Fun (CTH-661)  
056A:00D4=Wacom Mouse Monitor  
056A:00D5=Wacom Mouse Monitor  
056A:00D6=Wacom Mouse Monitor  
056A:00D7=Wacom Mouse Monitor  
056A:00D8=Wacom Mouse Monitor  
056A:00D9=Wacom Mouse Monitor  
056A:00DA=Wacom Mouse Monitor  
056A:00DB=Bamboo Fun (CTH-661SE-NL)  
056A:00F0=Wacom Mouse Monitor  
056A:00F0:01=Wacom Mouse Monitor  
056A:0400=PenPartner 4x5  
056A:4850=PenPartner 6x8  
056B=Decicon  
056C=e-TEK Labs  
056C:0006=KwikLink Host-Host Connector  
056C:8007=Kwik232 Serial Port  
056C:8100=KwikLink Host-Host Connector  
056C:8101=KwikLink USB-USB Bridge  
056D=EIZO  
056D:0000=EIZO USB Hub  
056D:0001=Monitor  
056D:0002=EIZO HID Monitor Controls  
056D:0002:02=EIZO USB HID Monitor  
056D:0003=EIZO Device Bay Controller  
056D:0003:0100=EIZO Device Bay Controller  
056E=Elecom  
056E:0002=29UO Mouse  
056E:200C=LD-USB/TX  
056E:4002=Laneed 100Mbps Ethernet LD-USB/TX [pegasus]  
056E:4005=LD-USB/TX  
056E:400B=LD-USB/TX  
056E:4010=LD-USB20  
056E:5003=UC-SGT  
056E:5004=UC-SGT  
056E:6008=Flash Disk  
056E:ABC1=LD-USB/TX  
056F=Korea Data Systems  
056F:CD00=CDM-751 CD organizer  
0570=Epson America  
0571=Interex  
0571:0002=echoFX InterView Lite



0572=Rockwell Semiconductor Systems  
0572:0001=Ezcam II WebCam  
0572:0002=Ezcam II WebCam  
0572:0040=Wondereye CP-115 WebCam  
0572:0041=Creative WebCam Notebook  
0572:0042=Creative WebCam Notebook  
0572:1232=V.90 modem  
0572:1234=Typhoon Redfun Modem V90 56k  
0572:1252=HCF V90 Data Fax Voice Modem  
0572:1253=Zoom V.92 Faxmodem  
0572:1300=D-Link DU-562M External Modem  
0572:1301=Modem Enumerator  
0572:1320=Conexant USB CX93010 ACF Modem  
0572:1321=Conexant USB CX93010 ACF Modem  
0572:1322=Conexant USB CX93010 ACF Modem  
0572:1323=Conexant USB CX93010 ACF Modem  
0572:1324=Conexant USB D400 V.92 Modem  
0572:1325=Conexant USB CX93010 ACF Modem  
0572:1328=Conexant USB CX93010 ACF Modem  
0572:1329=Conexant USB CX93010 ACF Modem  
0572:1330=Conexant USB CX93010 ACF Modem  
0572:1331=Conexant USB CX93010 ACF Modem  
0572:1332=Conexant USB CX93010 ACF Modem  
0572:1335=Conexant USB CX93010 ACF Modem  
0572:1340=Conexant USB CX93010 ACF Modem  
0572:1341=Conexant USB CX93010 ACF Modem  
0572:1342=Conexant USB CX93010 ACF Modem  
0572:1348=Conexant USB CX93010 ACF Modem  
0572:1349=Conexant USB CX93010 ACF Modem  
0572:2000=SoftGate 802.11 Adapter  
0572:2002=SoftGate 802.11 Adapter  
0572:8390=WinFast PalmTop/Novo TV Video  
0572:8392=WinFast PalmTop/Novo TV Video  
0572:CAFE=AccessRunner ADSL Modem  
0572:CB00=ZyXEL OMNI ADSL USB Device  
0572:CB01=Conexant USB Network Interface  
0572:CB06=StarModem Network Interface  
0572:CB07=ZTE ZXDSL852 Device  
0573=Nogatech  
0573:0003=Belkin VideoBus  
0573:0400=D-Link V100  
0573:0600=Dazzle USBVision (1006)  
0573:1300=leadtek USBVision (1006)  
0573:2000=X10 va10a Wireless Camera  
0573:2001=Dazzle EmMe (2001)  
0573:2101=leadtek USB Live! Pro  
0573:2101:01=Zoran USB Live! Pro Audio (2)  
0573:2D00=Osprey 50  
0573:2D01=Hauppauge WinTV USB Live Pro  
0573:3000=Dazzle MicroCam (NTSC)  
0573:3001=Dazzle MicroCam (PAL)  
0573:4000=Nogatech TV! (NTSC)  
0573:4001=Nogatech TV! (PAL)  
0573:4002=Nogatech TV! (PAL-I-)  
0573:4003=Nogatech TV! (MF-)  
0573:4008=Nogatech TV! (NTSC) (T)  
0573:4009=Nogatech TV! (PAL) (T)  
0573:4010=Nogatech TV! (NTSC) (A)  
0573:4100=USB-TV FM (NTSC)  
0573:4110=PNY USB-TV (NTSC) FM

0573:4400=Nogatech TV! Pro (NTSC)  
0573:4401=Nogatech TV! Pro (PAL)  
0573:4450=PixelView PlayTv-USB PRO (PAL) FM  
0573:4451=Nogatech TV! Pro (PAL+)  
0573:4452=Nogatech TV! Pro (PAL-I+)  
0573:4500=Nogatech TV! Pro (NTSC)  
0573:4501=Nogatech TV! Pro (PAL)  
0573:4550=ZTV ZT-721 2.4GHz USB A/V Receiver  
0573:4551=Dazzle TV! Pro Audio (P+)  
0573:4D00=Hauppauge WinTV USB (NTSC)  
0573:4D01=Hauppauge WinTV USB (PAL B/G)  
0573:4D02=Hauppauge WinTV USB (PAL I)  
0573:4D03=Hauppauge WinTV USB (PAL/SECAM)  
0573:4D04=Hauppauge WinTV (PAL D/K)  
0573:4D10=Hauppauge WinTV USB (NTSC FM)  
0573:4D11=Hauppauge WinTV USB (PAL B/G FM)  
0573:4D12=Hauppauge WinTV USB (PAL I FM)  
0573:4D14=Hauppauge WinTV (PAL D/K FM)  
0573:4D20=Hauppauge WinTV USB Pro (NTSC)  
0573:4D21=Hauppauge WinTV USB Pro (PAL B/G)  
0573:4D22=Hauppauge WinTV USB Pro (PAL I)  
0573:4D23=Hauppauge WinTV USB Pro (PAL/SECAM)  
0573:4D24=Hauppauge WinTV Pro (PAL D/K)  
0573:4D25=Hauppauge WinTV USB Pro (PAL/SECAM)  
0573:4D26=Hauppauge WinTV USB Pro (PAL/SECAM)  
0573:4D27=Hauppauge WinTV USB Pro (PAL B/G)  
0573:4D28=Hauppauge WinTV USB Pro (PAL B/G,D/K)  
0573:4D29=Hauppauge WinTV USB Pro (PAL I,D/K)  
0573:4D2A=Hauppauge WinTV USB Pro (NTSC)  
0573:4D2B=Hauppauge WinTV USB Pro (NTSC)  
0573:4D2C=Hauppauge WinTV Pro (PAL/SECAM)  
0573:4D30=Hauppauge WinTV USB Pro (NTSC FM)  
0573:4D31=Hauppauge WinTV USB Pro (PAL B/G FM)  
0573:4D32=Hauppauge WinTV USB Pro (PAL I FM)  
0573:4D34=Hauppauge WinTV Pro (PAL D/K FM)  
0573:4D35=Hauppauge WinTV USB Pro (PAL/SECAM FM)  
0573:4D36=Hauppauge WinTV Pro (PAL B/G FM)  
0573:4D37=Hauppauge WinTV USB Pro (PAL/SECAM FM)  
0573:4D38=Hauppauge WinTV Pro (NTSC FM)  
0574=City University of Hong Kong  
0575=Swets & Zeitlinger BV  
0576=BAFO/Quality Computer Accessories  
0576:1254=USB Easy Transfer Cable  
0576:2795=USB Easy Transfer Cable  
0576:9828=USB Easy Transfer Cable  
0577=ELSA  
0578=Intrinsix  
0579=GVC  
057A=Samsung Electronics America  
057B=Y-E Data  
057B:0000=Y-E Data USB Floppy  
057B:0001=Y-E Data USB Floppy  
057B:0006=Tri-Media Reader Card Reader  
057B:0010=Y-E Data USB Memory Stick Reader  
057B:0020=HEXA Media Drive 6-in-1 Card Reader Writer  
057B:0030=Memory Card Viewer (TV)  
057B:FFFF=USB FDD  
057C=AVM GmbH  
057C:0B00=AVM ISDN-Controller B1 Family  
057C:0C00=AVM ISDN-Controller FRITZ!Card USB

057C:1000=AVM ISDN-Controller FRITZ!Card USB v2.0  
057C:1000:0002=AVM ISDN-Controller FRITZ!Card Express  
057C:1900=AVM ISDN-Controller FRITZ!Card USB v2.1  
057C:2000=AVM FRITZ!X USB  
057C:2000:0100=AVM FRITZ!X USB  
057C:2000:0301=AVM FRITZ!X ISDN  
057C:2000:0302=AVM FRITZ!X USB  
057C:2200=BlueFRITZ! USB (WinXP/2000)  
057C:2300=Teledat X130 DSL  
057C:2800=ISDN-Connector TA  
057C:3200=Teledat X130 DSL  
057C:3300=BlueFRITZ! AP-DSL (WinXP/2000)  
057C:3500=FRITZ!Card DSL SL  
057C:3701=FRITZ!Box SL  
057C:3702=FRITZ!Box  
057C:3800=BlueFRITZ! USB (WinXP/2000)  
057C:3A00=FRITZ!Box Fon  
057C:3C00=FRITZ!Box WLAN  
057C:3D00=Fritz!Box  
057C:3E01=FRITZ!Box (Annex A)  
057C:4001=FRITZ!Box Fon (Annex A)  
057C:4101=FRITZ!Box WLAN (Annex A)  
057C:4201=FRITZ!Box Fon WLAN (Annex A)  
057C:4501=Eumex C 200 (WinXP/2000)  
057C:4601=Eumex 5520PC (WinXP/2000)  
057C:4602=Eumex 400 (WinXP/2000)  
057C:4701=AVM FRITZ!Box Fon ata  
057C:5401=Eumex 300 IP  
057C:5601=AVM FRITZ!WLAN Stick  
057C:6201=WLAN USB v1.1  
057C:62FF=WLAN USB v1.1 [no firmware]  
057C:8401=FRITZ!WLAN Stick N  
057C:8402=AVM Fritz!WLAN USB N 2.4  
057C:8403=Fritz!WLAN N v2 [Atheros AR7010]  
057C:84FF=AVM Fritz!WLAN USB N (in CD-ROM-mode)  
057D=Shark Multimedia  
057E=Nintendo  
057E:0305=Broadcom BCM2045A Bluetooth Radio [Nintendo Wii]  
057E:0306=Wii Remote Controller RVL-003  
057F=Quickshot Technology  
057F:6238=USB StrikePad  
0580=Denron  
0581=Racal Data Group  
0582=Roland  
0582:0000=UA-100  
0582:0002=Roland USB MIDI  
0582:0003=Sound Canvas SC-8850  
0582:0004=U-8  
0582:0005=Edirol UM-2 MIDI Adapter  
0582:0007=SoundCanvas SC-8820  
0582:0008=PC-300  
0582:0009=Edirol UM-1SX MIDI Adapter  
0582:000B=SK-500  
0582:000C=SC-D70  
0582:0010=EDIROL UA-5  
0582:0011=Edirol UA-5 Sound Capture  
0582:0012=XV-5050  
0582:0013=XV-5050  
0582:0014=EDIROL UM-880 MIDI I/F (native)  
0582:0015=EDIROL UM-880 MIDI I/F (generic)

0582:0016=EDIROL SD-90  
0582:0017=EDIROL SD-90  
0582:0018=UA-1A  
0582:001B=MMP-2  
0582:001C=MMP-2  
0582:001D=V-SYNTH  
0582:001E=V-SYNTH  
0582:0023=EDIROL UM-550  
0582:0024=EDIROL UM-550  
0582:0025=EDIROL UA-20  
0582:0026=EDIROL UA-20  
0582:0027=EDIROL SD-20  
0582:0028=EDIROL SD-20  
0582:0029=EDIROL SD-80  
0582:002A=EDIROL SD-80  
0582:002B=EDIROL UA-700  
0582:002C=EDIROL UA-700  
0582:002D=VX-2020 Synthesizer  
0582:002E=XV-2020 Synthesizer  
0582:002F=VariOS  
0582:0030=VariOS  
0582:0033=EDIROL PCR  
0582:0034=EDIROL PCR  
0582:0037=Digital Piano  
0582:0038=Digital Piano  
0582:003B=BOSS GS-10  
0582:003C=BOSS GS-10  
0582:0040=GI-20  
0582:0041=GI-20  
0582:0042=RS-70  
0582:0043=RS-70  
0582:0044=EDIROL UA-1000  
0582:0047=EDIROL UR-80 WAVE  
0582:0048=EDIROL UR-80 MIDI  
0582:0049=EDIROL UR-80 WAVE  
0582:004A=EDIROL UR-80 MIDI  
0582:004B=EDIROL M-100FX  
0582:004C=EDIROL PCR-A WAVE  
0582:004D=EDIROL PCR-A MIDI  
0582:004E=EDIROL PCR-A WAVE  
0582:004F=EDIROL PCR-A MIDI  
0582:0050=EDIROL UA-3FX  
0582:0052=EDIROL UM-1SX  
0582:0054=Digital Piano  
0582:0060=EXR Series  
0582:0064=EDIROL PCR-1 WAVE  
0582:0065=EDIROL PCR-1 MIDI  
0582:0066=EDIROL PCR-1 WAVE  
0582:0067=EDIROL PCR-1 MIDI  
0582:006A=SP-606  
0582:006B=SP-606  
0582:006D=FANTOM-X  
0582:006E=FANTOM-X  
0582:0073=EDIROL UA-25  
0582:0074=EDIROL UA-25  
0582:0075=BOSS DR-880  
0582:0076=BOSS DR-880  
0582:007A=RD  
0582:007B=RD  
0582:007D=EDIROL UA-101

0582:0080=G-70  
0582:0081=G-70  
0582:008B=EDIROL PC-50  
0582:008C=EDIROL PC-50  
0582:008D=EDIROL UA-101 USB1  
0582:0092=EDIROL PC-80 WAVE  
0582:0093=EDIROL PC-80 MIDI  
0582:0096=EDIROL UA-1EX  
0582:009A=EDIROL UM-3EX  
0582:009D=EDIROL UM-1  
0582:00A2=Digital Piano  
0582:00A3=EDIROL UA-4FX  
0582:00A6=Juno-G  
0582:00AD=SH-201  
0582:00C4=EDIROL M-16DX  
0582:00DB=BOSS GT-10 Guitar Effects Processor  
0582:00DE=Fantom-G7  
0582:00E6=EDIROL UA-25EX (Advanced mode)  
0582:00E7=EDIROL UA-25EX  
0582:010F=A-PRO  
0582:0110=A-PRO  
0583=Padix  
0583:0001=4 Axis 12 button +POV  
0583:0002=4 Axis 12 button +POV  
0583:2030=RM-203 USB Nest [mode 1]  
0583:2031=RM-203 USB Nest [mode 2]  
0583:2032=RM-203 USB Nest [mode 3]  
0583:2033=RM-203 USB Nest [mode 4]  
0583:2050=PX-205 PSX Bridge  
0583:205F=PSX/USB converter  
0583:206F=USB, 2-axis 8-button gamepad  
0583:3050=QF-305u Gamepad  
0583:3379=Rockfire X-Force  
0583:337F=Rockfire USB RacingStar Vibra  
0583:509F=USB, 4-Axis, 12-Button with POV  
0583:5259=Rockfire USB SkyShuttle Vibra  
0583:525F=USB Vibration Pad  
0583:5308=USB Wireless VibrationPad  
0583:5359=Rockfire USB SkyShuttle Pro  
0583:535F=USB, real VibrationPad  
0583:5659=Rockfire USB SkyShuttle Vibra  
0583:565F=USB VibrationPad  
0583:6009=Revenger  
0583:600F=USB, GameBoard II  
0583:6258=USB, 4-axis, 6-button joystick w/view finder  
0583:6889=Windstorm Pro  
0583:688F=QF-688uv Windstorm Pro Joystick  
0583:7070=QF-707u Bazooka Joystick  
0583:A000=MaxFire G-08XU Gamepad  
0583:A015=4-Axis, 16-Button with POV  
0583:A019=USB, Vibration, 4-axis, 8-button joystick w/view finder  
0583:A020=USB, 4-Axis, 10-Button with POV  
0583:A021=USB, 4-Axis, 12-Button with POV  
0583:A022=USB, 4-Axis, 14-Button with POV  
0583:A023=USB, 4-Axis, 16-Button with POV  
0583:A024=4axis, 12button vibration audio gamepad  
0583:A025=4axis, 12button vibration audio gamepad  
0583:A130=USB Wireless 2.4GHz Gamepad  
0583:A131=USB Wireless 2.4GHz Joystick  
0583:A132=USB Wireless 2.4GHz Wheelpad

0583:A133=USB Wireless 2.4GHz Wheel&Gamepad  
0583:A202=ForceFeedbackWheel  
0583:A209=MetalStrike FF  
0583:B000=USB,4-Axis,12-Button with POV  
0583:B001=USB,4-Axis,12-Button with POV  
0583:B002=Vibration,12-Button USB Wheel  
0583:B005=USB,12-Button Wheel  
0583:B008=USB Wireless 2.4GHz Wheel  
0583:B009=USB,12-Button Wheel  
0583:B00A=PSX/USB converter  
0583:B00B=PSX/USB converter  
0583:B00C=PSX/USB converter  
0583:B00D=PSX/USB converter  
0583:B00E=4-Axis,12-Button with POV  
0583:B00F=USB,5-Axis,10-Button with POV  
0583:B010=MetalStrike Pro  
0583:B012=Wireless MetalStrike  
0583:B013=USB,Wiress 2.4GHZ Joystick  
0583:B016=USB,5-Axis,10-Button with POV  
0583:B018=TW6 Wheel  
0583:FF60=USB Wireless VibrationPad  
0584=RATOC System  
0584:0008=Fujifilm MemoryCard ReaderWriter  
0584:0220=U2SCX SCSI Converter  
0584:B000=REX-USB60  
0585=FlashPoint Technology  
0585:0001=USB Digital Camera  
0585:0001:01=Digital camera  
0585:0001:0100=USB Digital Camera  
0585:0002=USB Digital Camera  
0585:0002:01=Digital camera  
0585:0002:0100=USB Digital Camera  
0585:0003=USB Digital Camera  
0585:0003:01=Digital camera  
0585:0003:0100=USB Digital Camera  
0585:0004=USB Digital Camera  
0585:0004:01=Digital camera  
0585:0004:0100=USB Digital Camera  
0585:0005=USB Digital Camera  
0585:0005:01=Digital camera  
0585:0005:0100=USB Digital Camera  
0585:0006=USB Digital Camera  
0585:0006:01=Digital camera  
0585:0006:0100=USB Digital Camera  
0585:0007=USB Digital Camera  
0585:0007:01=Digital camera  
0585:0007:0100=USB Digital Camera  
0585:0008=USB Digital Camera  
0585:0008:01=Digital camera  
0585:0008:0100=USB Digital Camera  
0585:0009=USB Digital Camera  
0585:0009:01=Digital camera  
0585:0009:0100=USB Digital Camera  
0585:000A=USB Digital Camera  
0585:000A:01=Digital camera  
0585:000A:0100=USB Digital Camera  
0585:000B=USB Digital Camera  
0585:000B:01=Digital camera  
0585:000B:0100=USB Digital Camera  
0585:000C=USB Digital Camera

0585:000C:01=Digital camera  
0585:000C:0100=USB Digital Camera  
0585:000D=USB Digital Camera  
0585:000D:01=Digital camera  
0585:000D:0100=USB Digital Camera  
0585:000E=USB Digital Camera  
0585:000E:01=Digital camera  
0585:000E:0100=USB Digital Camera  
0585:000F=USB Digital Camera  
0585:000F:01=Digital camera  
0585:000F:0100=USB Digital Camera  
0586=ZyXEL Communications  
0586:0025=802.11b/g/n USB Wireless Network Adapter  
0586:0102=omni.net II ISDN TA  
0586:1000=ZyXEL USB omni.net LCD Plus  
0586:1500=ZyXEL USB Omni56K Plus  
0586:1512=ZyXEL Omni56K DUO  
0586:2011=Scorpion-980N keyboard  
0586:3304=LAN Modem  
0586:3309=ADSL Modem Prestige 600 series  
0586:330A=ADSL Modem Interface  
0586:330E=USB Broadband ADSL Modem Rev 1.10  
0586:3400=ZyAIR B-220 IEEE 802.11b USB Adapter  
0586:3401=ZyAIR G-220  
0586:3402=ZyXEL G-220F 802.11g Wireless USB Adapter  
0586:3407=ZyXEL G-200v2 802.11b/g Wireless USB Adapter  
0586:3409=ZyXEL AG-225H 802.11a/g Wi-Fi Finder & USB Adapter  
0586:340A=ZyXEL M-202 802.11g Wireless USB Adapter  
0586:340C=ZyXEL G-270S 802.11g Wireless USB Adapter  
0586:340E=G-200 v3 802.11g Wireless USB Adapter  
0586:340F=Wi-Fi Wireless LAN USB Adapter  
0586:3410=Wi-Fi Wireless LAN USB Adapter  
0586:3411=M-220 802.11g Wireless USB Adapter  
0586:3412=Wi-Fi Wireless LAN USB Adapter  
0586:3413=AG-225H v2 802.11a/g Wi-Fi Finder & USB Adapter  
0586:3415=G-210H 802.11g Wireless USB Adapter  
0586:3416=NWD-210N 802.11b/g/n-draft wireless adapter  
0586:3417=NWD271N 802.11n Wireless Adapter [Atheros AR9001U-(2)NG]  
0586:3418=NWD211AN 802.11abgn Wireless Adapter [Ralink RT2870]  
0586:341A=Wireless N-lite USB Adapter  
0586:341E=Wireless N-lite USB Adapter  
0586:341F=Realtek RTL8192CU Wireless LAN 802.11n USB 2.0 Network Adapter  
0586:343E=Wireless N-lite USB Adapter  
0586:401A=Prestige USB Adapter  
0587=America Kotobuki Electronics  
0588=Sapien Design  
0589=Victron  
058A=Nohau  
058B=Siemens Semiconductor  
058C=In Focus Systems  
058C:0007=InFocus Flash  
058C:0008=InFocus LP130  
058C:000A=InFocus LP530  
058C:0010=InFocus Projector  
058C:0011=InFocus Projector  
058C:0012=InFocus Projector  
058C:0013=InFocus Projector  
058C:0014=InFocus Projector  
058C:0015=InFocus Projector  
058C:0016=InFocus Projector

058C:0017=InFocus Projector  
058C:0018=InFocus Projector  
058C:0019=InFocus Projector  
058C:001A=InFocus Projector  
058C:001B=InFocus Projector  
058C:001C=InFocus Projector  
058C:001D=InFocus Projector  
058C:001E=InFocus Projector  
058C:001F=InFocus Projector  
058D=Micrel Semiconductor  
058E=Tripath Technology  
058F=Alcor Micro  
058F:1234=Flash Drive  
058F:2412=SCard R/W CSR-145  
058F:2802=Monterey Keyboard  
058F:3820=UVC Video Camera  
058F:5492=Hub  
058F:6232=Hi-Speed 16-in-1 Flash Card Reader/Writer  
058F:6254=USB Hub  
058F:6331=USB Reader Drive  
058F:6332=USB Reader Drive  
058F:6335=SD/MMC Card Reader  
058F:6360=Multimedia Card Reader  
058F:6361=Multimedia Card Reader  
058F:6362=Hi-Speed 21-in-1 Flash Card Reader/Writer (Internal/External)  
058F:6363=USB Reader Drive  
058F:6364=Hi-Speed 7-in-1 Flash Card Reader/Writer [Sabrent]  
058F:6366=Multi Flash Reader  
058F:6368=USB Reader Drive  
058F:6369=USB Reader Drive  
058F:6373=USB Reader Drive  
058F:6377=Multimedia Card Reader  
058F:6386=Memory Card  
058F:6387=JetFlash USB Disk  
058F:6390=USB 2.0-IDE bridge  
058F:9213=MacAlly Kbd Hub  
058F:9215=AU9814 Hub  
058F:9254=USB V1.1 4-Port Hub  
058F:9310=Mass Storage (UID4/5A & UID7A)  
058F:9320=Micro Storage Driver for Win98  
058F:9321=Micro Storage Driver for Win98  
058F:9330=SD Reader  
058F:9331=Micro Storage Driver for Win98  
058F:9340=Delkin eFilm Reader-32  
058F:9350=Delkin eFilm Reader-32  
058F:9360=USB Multimedia Card Reader  
058F:9361=Multimedia Card Reader  
058F:9362=USB Multimedia Card Reader  
058F:9368=Multimedia Card Reader  
058F:9369=USB Reader Drive  
058F:9380=USB Flash Drive  
058F:9382=USB Flash Drive  
058F:9384=qdi U2Disk T209M  
058F:9410=Keyboard  
058F:9472=Keyboard Hub  
058F:9510=Alcor PC/SC USB Smart Card Reader  
058F:9520=Generic Usb Smart Card Reader  
058F:9720=USB-Serial Adapter  
0590=OMRON  
0590:0004=Cable Modem



0590:000B=MR56SVS  
0590:0028=HJ-720IT Pedometer  
0591=Questra Consulting  
0592=Exide Electronics  
0592:0002=UPS (X-Slot)  
0593=Incite  
0594=Princeton Graphic Systems  
0595=Zoran Microelectronics  
0595:1001=FUJIFILM EX-10/EX-20 DSC V1.00  
0595:2002=DIGITAL STILL CAMERA 6M 4X  
0595:4343=FUJIFILM EX-10/EX-20 PC V1.00  
0595:4545=FUJIFILM EX-10/EX-20 PC V1.00  
0596=Microtouch Systems  
0596:0001=Touchscreen  
0596:0002=MicroTouch USB Touch Screen Controller  
0596:0500=PCT Multitouch HID Controller  
0597=Trisignal Communications  
0598=Nigata Canotec  
0599=Brilliance Semiconductor  
059A=Spectrum Signal Processing  
059B=Iomega  
059B:0001=Iomega USB Zip 100  
059B:000B=Zip 100 (Type 2)  
059B:0020=IOmega  
059B:0021=IOmega  
059B:0022=IOmega  
059B:0023=IOmega  
059B:0024=IOmega  
059B:0025=IOmega  
059B:0026=IOmega  
059B:0027=IOmega  
059B:0028=IOmega  
059B:0029=IOmega  
059B:002A=IOmega  
059B:002B=IOmega  
059B:002C=IOmega  
059B:002D=IOmega  
059B:002E=IOmega  
059B:002F=IOmega  
059B:0030=Iomega USB Zip 250  
059B:0031=Iomega USB Zip 100  
059B:0032=Iomega Zip 250 USB Driver  
059B:0033=Iomega Zip 100 USB Driver  
059B:0034=Iomega Zip 100 USB Driver  
059B:0035=Iomega Zip 750 USB Driver  
059B:0037=Zip 750 MB  
059B:0040=SCSI Bridge  
059B:0042=Rev 70 GB  
059B:0050=Zip CD 650 Writer  
059B:0053=CDRW55292EXT CD-RW External Drive  
059B:0057=USB Mass Storage Device  
059B:005D=Mass Storage Device  
059B:005F=Mass Storage Device  
059B:0060=Iomega USB PCMCIA PocketZip Dock  
059B:0061=Varo USB PocketZip 40 MP3 Player  
059B:006D=HipZip MP3 Player  
059B:0070=Iomega Peerless USB Driver  
059B:007C=Ultra Max USB/1394  
059B:007D=HTC42606 0G9AT00 [Iomega HDD]  
059B:007E=Mini 256MB/512MB Flash Drive [IOM2D5]

059B:00DB=Iomega FotoShow Zip 250 Driver  
059B:0150=Mass Storage Device  
059B:015D=Super DVD Writer  
059B:0173=Hi-Speed USB-to-IDE Bridge Controller  
059B:0174=Hi-Speed USB-to-IDE Bridge Controller  
059B:0176=Hi-Speed USB-to-IDE Bridge Controller  
059B:0177=Hi-Speed USB-to-IDE Bridge Controller  
059B:0178=Hi-Speed USB-to-IDE Bridge Controller  
059B:0179=Hi-Speed USB-to-IDE Bridge Controller  
059B:017A=HDD  
059B:017B=HDD/1394A  
059B:017C=HDD/1394B  
059B:0251=Optical  
059B:0252=Optical  
059B:027A=LPHD250-U [Portable Hard Drive Silver Series 250 Go]  
059B:0470=Prestige Portable Hard Drive  
059B:047A=Select Portable Hard Drive  
059B:0579=eGo Portable Hard Drive  
059B:1052=DVD+RW External Drive  
059C=A-Trend Technology  
059D=Advanced Input Devices  
059E=Intelligent Instrumentation  
059F=Electronique D2  
059F:0201=LaCie StudioDrive USB2  
059F:0202=LaCie StudioDrive USB2  
059F:0203=LaCie StudioDrive USB2  
059F:0211=LaCie PocketDrive USB2  
059F:0212=LaCie PocketDrive USB2  
059F:0213=LaCie PocketDrive USB2  
059F:0323=LaCie d2 Drive USB2  
059F:0421=LaCie USB V2.0 Big Disk  
059F:0641=Mobile Hard drive  
059F:1010=Desktop Hard Drive  
059F:1019=Desktop Hard Drive  
059F:1021=Little Disk  
059F:1027=iamaKey V2  
059F:102A=Rikiki Hard Drive  
059F:1049=rikiki Harddrive  
059F:A601=LaCie USB Hard Drive  
059F:A602=LaCie USB CD-R/RW Drive  
05A0=Vetronix  
05A1=USC  
05A2=Fuji Film Microdevices  
05A3=VAutomation  
05A3:8388=Marvell 88W8388 802.11a/b/g WLAN  
05A4=Ortek Technology  
05A4:2000=WKB-2000 Wireless Keyboard with Touchpad  
05A4:9720=Ortek USB Keyboard Mouse  
05A4:9720:01=Ortek USB Keyboard Mouse  
05A4:9722=ORTEK Keyboard  
05A4:9731=MCK-600W Keyboard  
05A4:9731:01=USB Scroll Mouse  
05A4:9732:01=USB Scroll Mouse  
05A4:9756=Office Keyboard  
05A4:9783=Wireless Keypad  
05A5=Sampo Technology  
05A6=Cisco Systems  
05A6:0001=CVA124 Cable Voice Adapter (WDM)  
05A6:0002=CVA122 Cable Voice Adapter (WDM)  
05A6:0003=CVA124E Cable Voice Adapter (WDM)

05A6:0004=CVA122E Cable Voice Adapter (WDM)  
05A6:0101=Ralink RT3572 802.11a/b/g/n Wireless Lan USB Device  
05A7=Bose  
05A8=Spacetec IMC  
05A9=OmniVision Technologies  
05A9:0511=OV511 WebCam  
05A9:0518=Creative WebCam  
05A9:0518:0101=Philips ToUcam XS  
05A9:0519=OV519 Microphone  
05A9:1550=VEHO FilmScanner  
05A9:2640=Laptop Integrated Webcam  
05A9:2641=Monitor Integrated Webcam  
05A9:2643=Monitor Webcam (SP2208WFP)  
05A9:2645=Monitor Webcam C22W  
05A9:2649=Monitor Webcam  
05A9:264A=Monitor Webcam  
05A9:264B=Monitor Webcam  
05A9:264C=Monitor Webcam  
05A9:2800=SuperCAM  
05A9:4519=Webcam Classic  
05A9:7670=OV7670 Webcam  
05A9:8519=VGA USB Camera  
05A9:A511=Creative WebCam Pro  
05A9:A518=OmniVision Camera Mic  
05A9:A518:0100=EZPhone Camera Mic  
05A9:A518:0100:01=EZPhone Camera Mic  
05A9:A518:0110=OmniVision Camera Mic  
05A9:A518:0110:01=OmniVision Camera Mic  
05AA=Utilux South China  
05AB=In-System Design  
05AB:0002=Parallel Port  
05AB:0030=USB Storage Adapter V2 (TPP)  
05AB:0031=ATA Bridge  
05AB:0060=USB Storage Adapter V3 (TPP)  
05AB:0061=USB Storage Adapter V3 (TPP-I)  
05AB:0101=USB Storage Adapter (TPP)  
05AB:0130=USB Compact Flash and Microdrive Reader (TPP)  
05AB:0200=USS725 ATA Bridge  
05AB:0201=USB Storage Adapter (TPP)  
05AB:0202=ATA Bridge  
05AB:0300=Portable USB Hard Drive (TPP)  
05AB:0301=USB Storage Adapter V2 (TPP)  
05AB:0350=Portable USB Hard Drive (TPP)  
05AB:0351=USB Storage Adapter V2 (TPP)  
05AB:081A=ATA Bridge  
05AB:0CDA=USB Storage Adapter for CD-R/RW (TPP)  
05AB:1001=BAYI Printer Class Support  
05AB:5700=USB Storage Adapter V2 (TPP)  
05AB:5701=USB Storage Adapter V2 (TPP)  
05AB:5901=USB Smart Board (TPP)  
05AB:5A01=ATI USB Storage Adapter (TPP)  
05AB:5D01=DataBook USB Adapter (TPP)  
05AC=Apple  
05AC:0201=iMac Keyboard [ALPS M2452]  
05AC:0202=Apple Keyboard [ALPS]  
05AC:0205=Apple Extended Keyboard [Mitsumi]  
05AC:0206=Apple Extended Keyboard [Mitsumi]  
05AC:020B=Apple Pro Keyboard [Mitsumi, A1048/US layout]  
05AC:020C=Apple Extended Keyboard [Mitsumi]  
05AC:020D=Apple Pro Keyboard [Mitsumi, A1048/JIS layout]

05AC:020E=Apple Internal Keyboard/Trackpad  
05AC:020F=Apple Internal Keyboard/Trackpad  
05AC:0214=Internal Keyboard/Trackpad (ANSI)  
05AC:0215=Internal Keyboard/Trackpad (ISO)  
05AC:0216=Internal Keyboard/Trackpad (JIS)  
05AC:0217=Internal Keyboard/Trackpad (ANSI)  
05AC:0218=Internal Keyboard/Trackpad (ISO)  
05AC:0219=Internal Keyboard/Trackpad (JIS)  
05AC:021A=Internal Keyboard/Trackpad (ANSI)  
05AC:021B=Apple Internal Keyboard/Trackpad  
05AC:021C=Internal Keyboard/Trackpad (JIS)  
05AC:021D=Aluminum Mini Keyboard (ANSI)  
05AC:021E=Aluminum Mini Keyboard (ISO)  
05AC:021F=Aluminum Mini Keyboard (JIS)  
05AC:0220=Apple Aluminum Keyboard  
05AC:0221=Keyboard (Aluminium) (ISO)  
05AC:0222=Aluminum Keyboard (JIS)  
05AC:0223=Internal Keyboard/Trackpad (ANSI)  
05AC:0224=Internal Keyboard/Trackpad (ISO)  
05AC:0225=Internal Keyboard/Trackpad (JIS)  
05AC:0229=Internal Keyboard/Trackpad (MacBook Pro) (ANSI)  
05AC:022A=Internal Keyboard/Trackpad (MacBook Pro) (ISO)  
05AC:022B=Internal Keyboard/Trackpad (MacBook Pro) (JIS)  
05AC:0230=Internal Keyboard/Trackpad (MacBook Pro 4,1)  
05AC:0231=Internal Keyboard/Trackpad (MacBook Pro 4,1) (ISO)  
05AC:0232=Internal Keyboard/Trackpad (MacBook Pro 4,1) (JIS)  
05AC:0236=Internal Keyboard/Trackpad (ANSI)  
05AC:0237=Internal Keyboard/Trackpad (ISO)  
05AC:0238=Internal Keyboard/Trackpad (JIS)  
05AC:023F=Internal Keyboard/Trackpad (ANSI)  
05AC:0240=Internal Keyboard/Trackpad (ISO)  
05AC:0241=Internal Keyboard/Trackpad (JIS)  
05AC:0242=Internal Keyboard/Trackpad (ANSI)  
05AC:0243=Internal Keyboard/Trackpad (ISO)  
05AC:0244=Internal Keyboard/Trackpad (JIS)  
05AC:0245=Internal Keyboard/Trackpad (ANSI)  
05AC:0246=Internal Keyboard/Trackpad (ISO)  
05AC:0247=Internal Keyboard/Trackpad (JIS)  
05AC:0252=Internal Keyboard/Trackpad (ANSI)  
05AC:0253=Internal Keyboard/Trackpad (ISO)  
05AC:0254=Internal Keyboard/Trackpad (JIS)  
05AC:0301=iMac Mouse [Mitsumi/Logitech]  
05AC:0302=Apple Optical Mouse [Fujitsu]  
05AC:0304=Apple Mighty Mouse  
05AC:0306=Apple Optical USB Mouse [Fujitsu]  
05AC:030A=Internal Trackpad  
05AC:030B=Internal Trackpad  
05AC:030E=Wireless Trackpad [Magic Trackpad]  
05AC:1000=Bluetooth HCI MacBookPro (HID mode)  
05AC:1001=Apple Keyboard Hub [ALPS]  
05AC:1002=Apple Extended Keyboard Hub [Mitsumi]  
05AC:1003=Hub in Apple Pro Keyboard [Mitsumi, A1048]  
05AC:1006=Hub in Apple Aluminum Keyboard  
05AC:1101=Speakers  
05AC:1201=Apple iPod  
05AC:1202=iPod 2G  
05AC:1203=Apple iPod 4.Gen Grayscale 40G  
05AC:1204=iPod [Photo]  
05AC:1205=iPod Mini 1.Gen/2.Gen  
05AC:1206=iPod '06'

05AC:1207=iPod '07'  
05AC:1208=iPod '08'  
05AC:1209=iPod  
05AC:120A=iPod Nano  
05AC:1220=Apple Recovery (DFU) USB Driver  
05AC:1221=Apple Recovery (DFU) USB Driver  
05AC:1222=Apple Recovery (DFU) USB Driver  
05AC:1223=Apple Recovery (DFU) USB Driver  
05AC:1224=Apple Recovery (DFU) USB Driver  
05AC:1225=Apple Recovery (DFU) USB Driver  
05AC:1226=Apple Recovery (DFU) USB Driver  
05AC:1227=Apple Recovery (DFU) USB Driver  
05AC:1228=Apple Recovery (DFU) USB Driver  
05AC:1229=Apple Recovery (DFU) USB Driver  
05AC:1230=Apple Recovery (DFU) USB Driver  
05AC:1231=Apple Recovery (DFU) USB Driver  
05AC:1232=Apple Recovery (DFU) USB Driver  
05AC:1233=Apple Recovery (DFU) USB Driver  
05AC:1240=Apple Recovery (DFU) USB Driver  
05AC:1241=Apple Recovery (DFU) USB Driver  
05AC:1242=Apple Recovery (DFU) USB Driver  
05AC:1243=Apple Recovery (DFU) USB Driver  
05AC:1245=Apple Recovery (DFU) USB Driver  
05AC:1246=Apple Recovery (DFU) USB Driver  
05AC:1247=Apple Recovery (DFU) USB Driver  
05AC:1248=Apple Recovery (DFU) USB Driver  
05AC:1255=iPod Nano 4.Gen (DFU mode)  
05AC:1260=iPod Nano 2.Gen  
05AC:1261=iPod Classic  
05AC:1262=Apple iPod USB Driver  
05AC:1263=Apple iPod USB Driver  
05AC:1265=Apple iPod USB Driver  
05AC:1266=Apple iPod USB Driver  
05AC:1280=Apple Recovery (iBoot) USB Driver  
05AC:1281=Apple Recovery (iBoot) USB Driver  
05AC:1282=Apple Recovery (iBoot) USB Driver  
05AC:1283=Apple Recovery (iBoot) USB Driver  
05AC:1290=Apple Mobile Device USB Driver  
05AC:1290:02=Apple Mobile Device Ethernet  
05AC:1291=Apple Mobile Device USB Driver  
05AC:1292=Apple Mobile Device USB Driver  
05AC:1292:02=Apple Mobile Device Ethernet  
05AC:1293=Apple Mobile Device USB Driver  
05AC:1294=Apple Mobile Device USB Driver  
05AC:1294:02=Apple Mobile Device Ethernet  
05AC:1296=iPod Touch 3.Gen (8GB)  
05AC:1297=Apple Mobile Device USB Driver  
05AC:1297:02=Apple Mobile Device Ethernet  
05AC:1299=Apple iPod USB Driver  
05AC:129A=Apple Mobile Device USB Driver  
05AC:129A:02=Apple Mobile Device Ethernet  
05AC:129C=Apple Mobile Device USB Driver  
05AC:129C:02=Apple Mobile Device Ethernet  
05AC:129D=Apple Mobile Device USB Driver  
05AC:129E=Apple Mobile Device USB Driver  
05AC:129F=iPad 2  
05AC:129F:02=Apple Mobile Device Ethernet  
05AC:12A0=Apple Mobile Device USB Driver  
05AC:12A0:02=Apple Mobile Device Ethernet  
05AC:12A1=Apple Mobile Device USB Driver

05AC:12A1:02=Apple Mobile Device Ethernet  
05AC:12A2=Apple Mobile Device USB Driver  
05AC:12A2:02=Apple Mobile Device Ethernet  
05AC:12A3=Apple Mobile Device USB Driver  
05AC:12A3:02=Apple Mobile Device Ethernet  
05AC:12A4=Apple Mobile Device USB Driver  
05AC:12A4:02=Apple Mobile Device Ethernet  
05AC:12A5=Apple Mobile Device USB Driver  
05AC:12A5:02=Apple Mobile Device Ethernet  
05AC:1300=iPod Shuffle  
05AC:1301=2G iPod Shuffle  
05AC:1302=Apple iPod USB Driver  
05AC:1303=Apple iPod USB Driver  
05AC:1401=Modem  
05AC:1700=Apple Recovery (DFU) USB Driver  
05AC:1701=Apple Recovery (DFU) USB Driver  
05AC:8202=HCF V.90 Data/Fax Modem  
05AC:8203=Bluetooth HCI  
05AC:8204=Bluetooth HCI [Bluetooth 2.0 + EDR, build-in]  
05AC:8205=Bluetooth HCI MacBookPro  
05AC:8206=Bluetooth USB Host Controller  
05AC:820F=Bluetooth HCI  
05AC:8210=Broadcom Bluetooth 2.1 module  
05AC:8213=Broadcom Bluetooth 2.1 module  
05AC:8215=Broadcom Bluetooth 3.0 USB  
05AC:8216=Broadcom Bluetooth 3.0 USB  
05AC:8217=Broadcom Bluetooth 3.0 USB  
05AC:8218=Broadcom Bluetooth 2.1 module  
05AC:821A=Bluetooth Host Controller  
05AC:821B=MotioninJoy Virtual Xinput device for Windows  
05AC:8240=IR Receiver [build-in]  
05AC:8241=IR Receiver [built-in]  
05AC:8242=IR Receiver [built-in]  
05AC:8300=Built-in iSight (no firmware loaded)  
05AC:8403=Internal Memory Card Reader  
05AC:8501=Built-in iSight [Micron]  
05AC:8502=Built-in iSight  
05AC:8505=Built-in iSight  
05AC:8507=Built-in iSight  
05AC:8509=FaceTime HD Camera  
05AC:911C=Hub in A1082 [Cinema HD Display 23"]  
05AC:912F=Hub in Apple 30" Cinema Display  
05AC:921C=A1082 [Cinema HD Display 23"]  
05AC:9221=Apple 30" Cinema Display  
05AC:FFFF=Bluetooth in DFU mode - Driver  
05AD=Y.C.Cable U.S.A.  
05AE=Synopsys  
05AF=Jing-Mold Enterprise  
05AF:0809=Wireless Keyboard and Mouse  
05AF:0821=USB2.0 IDE to USB  
05AF:3062=Cordless Keyboard  
05AF:9167=KB 9151B - 678  
05AF:9267=KB 9251B - 678 Mouse  
05AF:9267:01=KB 9251B - 678 Mouse  
05B0=Fountain Technologies  
05B1=First International Computer  
05B1:1389=FIC Bluetooth Wireless Adapter  
05B2=Focus  
05B2:6200=Focus USB Keyboard  
05B2:7200=Focus USB Keyboard Mouse

05B2:7200:01=Focus USB Keyboard Mouse  
05B4=eXputer  
05B4:4857=Duo Digital Media Player(011221)  
05B4:6001=eXputer XMC6000 USB Zippy Drive  
05B4:6002=Duo Digital Media Player(011220)  
05B5=Dialogic  
05B6=Proxima  
05B7=Medianix Semiconductor  
05B8=Agiler  
05B8:3002=Scroll Mouse  
05B9=Philips Research Laboratories  
05BA=Digital Persona  
05BA:0007=Fingerprint Reader  
05BA:0008=Fingerprint Reader  
05BA:0008:02=U.are.U?4000B Fingerprint Reader  
05BA:0009=U.are.U?4000B Fingerprint Reader  
05BA:0009:02=U.are.U?4000B Fingerprint Reader  
05BA:000A=Fingerprint Reader  
05BA:000A:0100=U.are.U?4000B Fingerprint Reader  
05BA:000A:0101=U.are.U?4000B Fingerprint Reader  
05BA:000A:0102=U.are.U?4500 Fingerprint Reader  
05BA:0010=U.are.U?2500 Fingerprint Reader  
05BB=Grey Cell Systems  
05BC=Forward  
05BC:0001=Forward USB K/B with PS/2 Mouse  
05BC:0001:01=Forward USB K/B Mouse  
05BC:0002=Forward USB K/B  
05BC:0004=Trackball  
05BC:0102=3M Ergonomic Mouse  
05BC:0102:0200=3M Ergonomic Mouse EM500GPL  
05BD=RAFI  
05BE=Raychem  
05BF=S & S Research  
05C0=Keil Software  
05C1=Kawasaki Steel  
05C2=Mediaphonics S.A.  
05C5=Central Data  
05C5:0002=AccelePort USB 2  
05C5:0004=AccelePort USB 4  
05C5:0008=AccelePort USB 8  
05C6=Qualcomm  
05C6:0114=Select RW-200 CDMA Wireless Modem  
05C6:1000=Mass Storage Device  
05C6:3100=CDMA Wireless Modem/Phone  
05C6:3196=CDMA Wireless Modem  
05C6:3197=CDMA Wireless Modem/Phone  
05C6:3197:01=ZTE Diagnostics Interface 3197  
05C6:6000=Siemens Mobile Phone  
05C6:6000:01=ZTE Diagnostics Interface 6000  
05C6:6000:02=ZTE NMEA Device  
05C6:6503=AnyData APE-540H  
05C6:6613=Onda H600/N501HS ZTE MF330  
05C6:7000:01=ZTE Diagnostics Interface 7000  
05C6:7000:02=ZTE NMEA Device  
05C6:9000=SIMCom SIM5218 modem  
05C6:9001=Gobi Wireless Modem  
05C6:9002=Gobi Wireless Modem  
05C6:9008=Gobi Wireless Modem (QDL mode)  
05C6:9201=Gobi Wireless Modem (QDL mode)  
05C6:9202=Gobi Wireless Modem

05C6:9203=Gobi Wireless Modem  
05C6:9211=Acer Gobi Wireless Modem (QDL mode)  
05C6:9212=Acer Gobi Wireless Modem  
05C6:9214=Acer Gobi 2000 Wireless Modem (QDL mode)  
05C6:9215=Acer Gobi 2000 Wireless Modem  
05C6:9221=Gobi Wireless Modem (QDL mode)  
05C6:9222=Gobi Wireless Modem  
05C6:9224=Sony Gobi 2000 Wireless Modem (QDL mode)  
05C6:9225=Sony Gobi 2000 Wireless Modem  
05C6:9231=Gobi Wireless Modem (QDL mode)  
05C6:9234=Top Global Gobi 2000 Wireless Modem (QDL mode)  
05C6:9235=Top Global Gobi 2000 Wireless Modem  
05C6:9244=Samsung Gobi 2000 Wireless Modem (QDL mode)  
05C6:9245=Samsung Gobi 2000 Wireless Modem  
05C6:9264=Asus Gobi 2000 Wireless Modem (QDL mode)  
05C6:9265=Asus Gobi 2000 Wireless Modem  
05C6:9274=iRex Technologies Gobi 2000 Wireless Modem (QDL mode)  
05C6:9275=iRex Technologies Gobi 2000 Wireless Modem  
05C7=Qtronix  
05C7:0113=PC Line USB Mouse  
05C7:0113:0001=PC Line 3S-SUP USB Mouse  
05C7:1001=Qtronix USB Mouse  
05C7:1001:01=Qtronix USB Mouse  
05C7:2001=Qtronix USB Keyboard  
05C7:2011=Belkin USB Keyboard Mouse  
05C7:2011:01=Belkin USB Mouse  
05C7:6001=Qtronix USB Ten-Keypad  
05C8=Cheng Uei Precision Industry  
05C8:0103=FO13FF-65 PC-CAM  
05C8:020D=Realtek USB2.0 PC Camera  
05C8:020E=Realtek USB2.0 PC Camera  
05C8:030D=Realtek USB2.0 PC Camera  
05C8:0403=Webcam  
05C8:0404=Realtek USB2.0 PC Camera  
05C8:0405=Realtek USB2.0 PC Camera  
05C8:0406=Realtek USB2.0 PC Camera  
05C8:0407=Realtek USB2.0 PC Camera  
05C9=Semtech  
05CA=Ricoh Company  
05CA:0101=RDC-5300 Digital Camera  
05CA:0325=Caplio GX (ptp)  
05CA:032D=Caplio GX 8 (ptp)  
05CA:032F=Caplio R3 (ptp)  
05CA:03A1=IS200e  
05CA:0403=Printing Support  
05CA:0405=Type 101  
05CA:0406=Type 102  
05CA:040D=Scanner Driver Type 103  
05CA:1803=V5 camera [R5U870]  
05CA:1810=Pavilion Webcam [R5U870]  
05CA:1812=Pavilion Webcam  
05CA:1814=HD Webcam  
05CA:1830=Visual Communication Camera VGP-VCC2  
05CA:1832=Visual Communication Camera VGP-VCC3 [R5U870]  
05CA:1833=Visual Communication Camera VGP-VCC2 [R5U870]  
05CA:1834=Visual Communication Camera VGP-VCC2 [R5U870]  
05CA:1835=Sony Visual Communication Camera VGP-VCC5  
05CA:1836=Sony Visual Communication Camera VGP-VCC4  
05CA:1837=Visual Communication Camera VGP-VCC4 [R5U870]  
05CA:1839=Visual Communication Camera VGP-VCC6 [R5U870]



05CA:183A=Visual Communication Camera VGP-VCC7 [R5U870]  
05CA:183B=Visual Communication Camera VGP-VCC8 [R5U870]  
05CA:183D=Sony Vaio Integrated Webcam  
05CA:183E=Visual Communication Camera VGP-VCC9 [R5U870]  
05CA:1841=RY5U870 VGA-CAM F01\_UVC  
05CA:1870=HP Webcam 1000  
05CA:18A0=Integrated Webcam  
05CA:18A1=Integrated Webcam  
05CA:18A2=Integrated Webcam  
05CA:18A3=Integrated Webcam  
05CA:18A4=Integrated Webcam  
05CA:18A5=Integrated Webcam  
05CA:18A6=Integrated Webcam  
05CA:18A7=Integrated Webcam  
05CA:18A8=Integrated Webcam  
05CA:18A9=Integrated Webcam  
05CA:18AA=Integrated Webcam  
05CA:18AB=Integrated Webcam  
05CA:18AC=Integrated Webcam  
05CA:18AD=Integrated Webcam  
05CA:18AE=Integrated Webcam  
05CA:18AF=Integrated Webcam  
05CA:18B0=Sony Vaio Integrated Webcam  
05CA:18B1=Sony Vaio Integrated Webcam  
05CA:18B3=Sony Vaio Integrated Webcam  
05CA:2201=RDC-7 Digital Camera  
05CA:2202=Caplio RR30  
05CA:2203=Caplio 300G  
05CA:2204=Caplio G3  
05CA:2205=Caplio RR30 / Medion MD 6126 Camera  
05CA:2206=Konica DG-3Z  
05CA:2207=Caplio Pro G3  
05CA:2208=Caplio G4  
05CA:2209=Caplio 400G wide  
05CA:220A=KONICA MINOLTA DG-4Wide  
05CA:220B=Caplio RX  
05CA:220C=Caplio GX  
05CA:220D=Caplio R1/RZ1  
05CA:220E=Sea & Sea 5000G  
05CA:220F=Rollei dr5 / Rollei dr5 (PTP mode)  
05CA:2211=Caplio R1S  
05CA:2212=Caplio R1V  
05CA:2213=Caplio R2  
05CA:2214=Caplio GX8  
05CA:2215=DSC 725  
05CA:2216=Caplio R3  
05CA:2218=GR DIGITAL  
05CA:2222=RDC-i500  
05CB=Powerchip Semiconductor  
05CB:1483=Trust CombiScan 19200  
05CC=ELSA Gmbh  
05CC:2100=MicroLink ISDN Office  
05CC:2219=MicroLink ISDN  
05CC:2265=Elsa Microlink 56K USB Modem  
05CC:2265:0100=Elsa Microlink 56K USB Modem  
05CC:2267=MicroLink 56k (V.250)  
05CC:2280=MicroLink 56k Fun  
05CC:2500=Bluetooth Devices  
05CC:3000=Micolink USB2Ethernet [pegasus]  
05CC:3100=ELSA AirLancer USB-11

05CC:3363=MicroLink ADSL Fun  
05CD=Silicom  
05CE=SICAN Gmbh  
05CF=Sung Forn  
05D0=Lunar  
05D1=Brainboxes  
05D1:0003=Bluetooth Adapter BL-554  
05D2=Wave Systems  
05D3=Tohoku Ricoh  
05D5=SuperGate  
05D5:6782=SUPERGATE USB Keyboard with PS/2 Mouse Port  
05D5:6782:01=SUPERGATE USB Keyboard Mouse  
05D6=Philips Semiconductors  
05D7=Thomas & Betts  
05D7:0099=10Mbps Ethernet [klsi]  
05D8=Ultima Electronics  
05D8:4001=Artec Ultima 2000  
05D8:4002=Artec Ultima 2000 (GT6801 based)/Lifetec LT9385 Scanner  
05D8:4003=Artec E+ 48U  
05D8:4004=Artec E+ Pro  
05D8:4005=MEM48U  
05D8:4006=TRUST EASY WEBSCAN 19200  
05D8:4007=TRUST 240H EASY WEBSCAN GOLD  
05D8:4008=Trust Easy Webscan 19200  
05D8:4009=Umax Astraslim  
05D8:4013=IT Scan 1200  
05D8:8105=Artec T1 USB TVBOX (cold)  
05D8:8106=Artec T1 USB TVBOX (warm)  
05D8:8107=Artec T1 USB TVBOX with AN2235 (cold)  
05D8:8108=Artec T1 USB TVBOX with AN2235 (warm)  
05D8:8109=Artec T1 USB2.0 TVBOX (cold)  
05D8:810C=Digital TV stick USB 2.0 BDA  
05D8:810F=Infrared Receiver  
05D9=Axiohm Transaction Solutions  
05D9:A225=Axiohm A225 Printer  
05D9:A758=Axiohm A758 Printer  
05D9:A794=Axiohm A794 Printer  
05DA=Microtek International  
05DA:0091=ScanMaker X6u  
05DA:0093=ScanMaker V6USL  
05DA:0094=Microtek SlimScan C3U  
05DA:0099=Microtek ScanMaker X6U  
05DA:009A=Microtek SlimScan C6u  
05DA:00A0=Microtek SlimScan C3u  
05DA:00A3=Microtek ScanMaker V6USL  
05DA:00AC=Microtek ScanMaker V6UL  
05DA:00B6=Microtek ScanMaker V6UPL  
05DA:00EF=Microtek ScanMaker V6UPL  
05DA:1006=Jenoptik JD350 entrance  
05DA:1011=NHJ Che-ez! Kiss Digital Camera  
05DA:1018=Digital Dream Enigma 1.3  
05DA:1020=Digital Dream l'espion xtra  
05DA:1025=Take-it Still Camera Device  
05DA:1026=Take-it  
05DA:1043=Take-It 1300 DSC Bulk Driver  
05DA:1045=Take-it D1  
05DA:1047=Take-it Camera Composite Device  
05DA:1048=Take-it Q3  
05DA:1049=3M Still Camera Device  
05DA:1051=USB Camcorder Series

05DA:1051:01=USB Camcorder DSC Series  
05DA:1052=Mass Storage Device  
05DA:1053=Take-it DV Series  
05DA:1053:01=Take-it DSC Series  
05DA:1054=Mass Storage Device  
05DA:1055=Digital Camera Composite USB Device(536)  
05DA:1055:01=Digital Camera Series(536)  
05DA:1056=Mass Storage Device  
05DA:1057=Take-it Video Camera Device(536)  
05DA:1057:01=Take-it DSC Camera Device(536)  
05DA:1058=Mass Storage Device  
05DA:1059=Camcorder DSC Series  
05DA:1060=Microtek Take-it MV500  
05DA:2007=Microtek ArtixScan DI 1210  
05DA:200C=1394\_USB2 Scanner (USB)  
05DA:200E=ArtixScan DI 810  
05DA:2017=Microtek Sagitta (USB)  
05DA:201A=Microtek FileScan 3000  
05DA:201C=4800 Scanner  
05DA:201D=Microtek ArtixScan DI 1610  
05DA:201E=ScanMaker 1000XL (USB)  
05DA:201F=4800 Scanner-ICE (USB)  
05DA:202E=DI 2020 Scanner  
05DA:2032=ADF 2010+ Scanner  
05DA:2033=ADF 2020S Scanner  
05DA:2034=ADF DI Scanner-40  
05DA:2035=4800 AF Scanner  
05DA:208A=Microtek ScanMaker 9600XL  
05DA:208B=Microtek ScanMaker 6800 (USB)  
05DA:208F=ArtixScan DI 2010  
05DA:2091=Microtek ScanMaker X6  
05DA:2095=Microtek ArtixScan 1010  
05DA:209E=Microtek ScanMaker 4700LP  
05DA:20A7=Microtek ScanMaker 5600  
05DA:20B0=Microtek ScanMaker X12USL  
05DA:20B1=Microtek ScanMaker 8700 (USB)  
05DA:20B4=Microtek ScanMaker 4700  
05DA:20BD=Microtek ScanMaker 5700 (USB)  
05DA:20C9=Microtek ScanMaker 6700 (USB)  
05DA:20D2=Microtek ArtixScan 1800f (USB)  
05DA:20D6=PS4000 (USB)  
05DA:20DE=Microtek ScanMaker 9800XL (USB)  
05DA:20E0=Microtek ScanMaker 9700XL  
05DA:20ED=ScanMaker 4700  
05DA:20EE=Microtek ScanMaker X12USL  
05DA:3008=USB2.0 Scanner  
05DA:300A=4800 ICE Scanner  
05DA:300B=4800 Scanner  
05DA:300F=MiniScan C5  
05DA:3020=4800dpi Scanner  
05DA:3021=1200dpi Scanner  
05DA:3022=Scanner 4800dpi  
05DA:3023=USB1200II Scanner  
05DA:3024=4800 LL Scanner  
05DA:3025=Scanner 4800H48U  
05DA:30C1=USB600 Scanner  
05DA:30CE=Microtek ScanMaker 3800  
05DA:30CF=Microtek ScanMaker 4800  
05DA:30D4=USB1200 Scanner  
05DA:30D8=USB2.0 Scanner

05DA:30D9=USB2400 Scanner  
05DA:30E4=Microtek ScanMaker 4100  
05DA:30E5=USB3200 Scanner  
05DA:30E6=USB ICE Scanner  
05DA:40B3=Microtek ScanMaker 3600  
05DA:40B8=Microtek ScanMaker 3700  
05DA:40C7=Microtek ScanMaker 4600  
05DA:40CA=Microtek ScanMaker 3600  
05DA:40CB=Microtek ScanMaker 3700  
05DA:40DD=Microtek ScanMaker 3750i  
05DA:40FF=ScanMaker 3600  
05DA:5003=Microtek Goya  
05DA:5013=3200 Scanner  
05DA:80A3=ScanMaker V6USL  
05DA:80AC=ScanMaker V6UL/SpicyU  
05DB=Sun  
05DB:0003=SUNTAC U-Cable type D2  
05DB:0005=SUNTAC U-Cable type P1  
05DB:0009=SUNTAC Slipper U  
05DB:000A=SUNTAC Ir-Trinity  
05DB:000B=SUNTAC U-Cable type A3  
05DB:0011=SUNTAC U-Cable type A4  
05DC=Lexar Media  
05DC:0001=JumpShot  
05DC:0002=JumpShot  
05DC:0003=JumpShot  
05DC:0080=JumpDrive?  
05DC:0080:0001:01=JumpDrive?(2MB)  
05DC:0080:0001:02=JumpDrive?(4MB)  
05DC:0080:0001:03=JumpDrive?(8MB)  
05DC:0080:0001:04=JumpDrive?(16MB)  
05DC:0080:0001:05=JumpDrive?(32MB)  
05DC:0080:0001:06=JumpDrive?(64MB)  
05DC:0080:0001:07=JumpDrive?(128MB)  
05DC:0080:0001:08=JumpDrive?(256MB)  
05DC:0080:0001:09=JumpDrive?(512MB)  
05DC:0080:0001:0A=JumpDrive?(1GB)  
05DC:0081=Lexar USB RBC Compact Flash Drive  
05DC:00A7=JumpDrive Impact  
05DC:0100=JumpDrive?PRO  
05DC:0200=JumpDrive?2.0 Pro 40-500  
05DC:0200:01=JumpDrive?2.0 Pro 40-500 (2MB)  
05DC:0200:02=JumpDrive?2.0 Pro 40-500 (4MB)  
05DC:0200:03=JumpDrive?2.0 Pro 40-500 (8MB)  
05DC:0200:04=JumpDrive?2.0 Pro 40-500 (16MB)  
05DC:0200:05=JumpDrive?2.0 Pro 40-500 (32MB)  
05DC:0200:06=JumpDrive?2.0 Pro 40-500 (64MB)  
05DC:0200:07=JumpDrive?2.0 Pro 40-500 (128MB)  
05DC:0200:08=JumpDrive?2.0 Pro 40-500 (256MB)  
05DC:0200:09=JumpDrive?2.0 Pro 40-500 (512MB)  
05DC:0200:0A=JumpDrive?2.0 Pro 40-500 (1GB)  
05DC:0300=JumpDrive?  
05DC:0301=JumpDrive?Classic  
05DC:0302=JD Micro  
05DC:0303=JD Micro Pro  
05DC:0304=JD Secure II  
05DC:0310=JumpDrive?  
05DC:0311=JumpDrive?Classic  
05DC:0312=JD Micro  
05DC:0313=JD Micro Pro

05DC:0320=JumpDrive  
05DC:0321=JD Micro  
05DC:0322=JD Micro Pro  
05DC:0323=Lexar UFC  
05DC:0330=JumpDrive?Expression  
05DC:0340=JumpDrive?TAD  
05DC:0350=Express Card  
05DC:0400=Lexar UFDC  
05DC:0401=Lexar UFDC  
05DC:0403=Locked B Device  
05DC:0405=Locked C Device  
05DC:0407=Locked D Device  
05DC:0409=Locked E Device  
05DC:040B=Locked F Device  
05DC:040D=Locked G Device  
05DC:040F=Locked H Device  
05DC:0410=JumpDrive?  
05DC:0411=JumpDrive?  
05DC:0413=Locked J Device  
05DC:0415=Locked K Device  
05DC:0417=Locked L Device  
05DC:0419=Locked M Device  
05DC:041B=Locked N Device  
05DC:041D=Locked O Device  
05DC:041F=Locked P Device  
05DC:0420=JumpDrive?  
05DC:0421=JumpDrive?  
05DC:0423=Locked R Device  
05DC:0425=Locked S Device  
05DC:0427=Locked T Device  
05DC:0429=Locked U Device  
05DC:042B=Locked V Device  
05DC:042D=Locked W Device  
05DC:042F=Locked X Device  
05DC:0431=Locked Y Device  
05DC:0433=Locked Z Device  
05DC:4D02=MP3 Player  
05DC:4D12=MP3 Player  
05DC:4D30=MP3 Player  
05DC:A300=JumpDrive2  
05DC:A310=JumpDrive?  
05DC:A320=JumpDrive?PRO  
05DC:A330=JumpDrive?SECURE  
05DC:A350=JumpDrive?I.D.  
05DC:A400=Lexar Media JumpDrive?  
05DC:A400:0100=JumpDrive?2.0 Pro 40-501  
05DC:A400:0100:01=JumpDrive?2.0 Pro 40-501 (2MB)  
05DC:A400:0100:02=JumpDrive?2.0 Pro 40-501 (4MB)  
05DC:A400:0100:03=JumpDrive?2.0 Pro 40-501 (8MB)  
05DC:A400:0100:04=JumpDrive?2.0 Pro 40-501 (16MB)  
05DC:A400:0100:05=JumpDrive?2.0 Pro 40-501 (32MB)  
05DC:A400:0100:06=JumpDrive?2.0 Pro 40-501 (64MB)  
05DC:A400:0100:07=JumpDrive?2.0 Pro 40-501 (128MB)  
05DC:A400:0100:08=JumpDrive?2.0 Pro 40-501 (256MB)  
05DC:A400:0100:09=JumpDrive?2.0 Pro 40-501 (512MB)  
05DC:A400:0100:0A=JumpDrive?2.0 Pro 40-501 (1GB)  
05DC:A400:0100:0B=JumpDrive?2.0 Pro 40-501 (2GB)  
05DC:A400:0100:0C=JumpDrive?2.0 Pro 40-501 (4GB)  
05DC:A400:2000=Lexar Media JumpDrive?Elite  
05DC:A400:2000:06=JumpDrive?Elite (64MB)

05DC:A400:2000:07=JumpDrive?Elite (128MB)  
05DC:A400:2000:08=JumpDrive?Elite (256MB)  
05DC:A400:2000:09=JumpDrive?Elite (512MB)  
05DC:A400:2000:0A=JumpDrive?Elite (1GB)  
05DC:A410=JumpDrive?  
05DC:A411=JumpDrive?Traveler  
05DC:A420=JumpDrive?2.0 Pro 40-501  
05DC:A420:3000=JumpDrive?2.0 Pro 40-501 Rev C  
05DC:A420:3000:01=JumpDrive?2.0 Pro 40-501 (2MB)  
05DC:A420:3000:02=JumpDrive?2.0 Pro 40-501 (4MB)  
05DC:A420:3000:03=JumpDrive?2.0 Pro 40-501 (8MB)  
05DC:A420:3000:04=JumpDrive?2.0 Pro 40-501 (16MB)  
05DC:A420:3000:05=JumpDrive?2.0 Pro 40-501 (32MB)  
05DC:A420:3000:06=JumpDrive?2.0 Pro 40-501 (64MB)  
05DC:A420:3000:07=JumpDrive?2.0 Pro 40-501 (128MB)  
05DC:A420:3000:08=JumpDrive?2.0 Pro 40-501 (256MB)  
05DC:A420:3000:09=JumpDrive?2.0 Pro 40-501 (512MB)  
05DC:A420:3000:0A=JumpDrive?2.0 Pro 40-501 (1GB)  
05DC:A420:3000:0B=JumpDrive?2.0 Pro 40-501 (2GB)  
05DC:A420:3000:0C=JumpDrive?2.0 Pro 40-501 (4GB)  
05DC:A420:3000:0D=JumpDrive?2.0 Pro 40-501 (8GB)  
05DC:A421=JumpDrive?Pro II  
05DC:A422=JumpDrive?Micro Pro  
05DC:A430=JumpDrive?SECURE  
05DC:A431=JumpDrive?Secure II  
05DC:A432=JumpDrive?Classic  
05DC:A440=JumpDrive?LIGHTNING  
05DC:A450=JumpDrive?TouchGuard  
05DC:A460=JD Mercury  
05DC:A501=JumpDrive?Classic  
05DC:A510=JumpDrive?Sport  
05DC:A530=JumpDrive?Expression  
05DC:A531=JumpDrive?Secure II  
05DC:A560=JumpDrive?FireFly  
05DC:A560:3000=JumpDrive?FireFly 00-5004  
05DC:A560:3000:01=JumpDrive?FireFly 00-5004 (2MB)  
05DC:A560:3000:02=JumpDrive?FireFly 00-5004 (4MB)  
05DC:A560:3000:03=JumpDrive?FireFly 00-5004 (8MB)  
05DC:A560:3000:04=JumpDrive?FireFly 00-5004 (16MB)  
05DC:A560:3000:05=JumpDrive?FireFly 00-5004 (32MB)  
05DC:A560:3000:06=JumpDrive?FireFly 00-5004 (64MB)  
05DC:A560:3000:07=JumpDrive?FireFly 00-5004 (128MB)  
05DC:A560:3000:08=JumpDrive?FireFly 00-5004 (256MB)  
05DC:A560:3000:09=JumpDrive?FireFly 00-5004 (512MB)  
05DC:A560:3000:0A=JumpDrive?FireFly 00-5004 (1GB)  
05DC:A560:3000:0B=JumpDrive?FireFly 00-5004 (2GB)  
05DC:A560:3000:0C=JumpDrive?FireFly 00-5004 (4GB)  
05DC:A560:3000:0D=JumpDrive?FireFly 00-5004 (8GB)  
05DC:A575=JumpDrive?FireFly  
05DC:A575:1100=JumpDrive?FireFly 00-5003  
05DC:A575:1100:01=JumpDrive?FireFly 00-5003 (2MB)  
05DC:A575:1100:02=JumpDrive?FireFly 00-5003 (4MB)  
05DC:A575:1100:03=JumpDrive?FireFly 00-5003 (8MB)  
05DC:A575:1100:04=JumpDrive?FireFly 00-5003 (16MB)  
05DC:A575:1100:05=JumpDrive?FireFly 00-5003 (32MB)  
05DC:A575:1100:06=JumpDrive?FireFly 00-5003 (64MB)  
05DC:A575:1100:07=JumpDrive?FireFly 00-5003 (128MB)  
05DC:A575:1100:08=JumpDrive?FireFly 00-5003 (256MB)  
05DC:A575:1100:09=JumpDrive?FireFly 00-5003 (512MB)  
05DC:A575:1100:0A=JumpDrive?FireFly 00-5003 (1GB)

05DC:A575:1100:0B=JumpDrive?FireFly 00-5003 (2GB)  
05DC:A575:1100:0C=JumpDrive?FireFly 00-5003 (4GB)  
05DC:A575:1100:0D=JumpDrive?FireFly 00-5003 (8GB)  
05DC:A701=JumpDrive?FireFly  
05DC:A701:1100=JumpDrive?FireFly 00-5005  
05DC:A701:1100:01=JumpDrive?FireFly 00-5005 (2MB)  
05DC:A701:1100:02=JumpDrive?FireFly 00-5005 (4MB)  
05DC:A701:1100:03=JumpDrive?FireFly 00-5005 (8MB)  
05DC:A701:1100:04=JumpDrive?FireFly 00-5005 (16MB)  
05DC:A701:1100:05=JumpDrive?FireFly 00-5005 (32MB)  
05DC:A701:1100:06=JumpDrive?FireFly 00-5005 (64MB)  
05DC:A701:1100:07=JumpDrive?FireFly 00-5005 (128MB)  
05DC:A701:1100:08=JumpDrive?FireFly 00-5005 (256MB)  
05DC:A701:1100:09=JumpDrive?FireFly 00-5005 (512MB)  
05DC:A701:1100:0A=JumpDrive?FireFly 00-5005 (1GB)  
05DC:A701:1100:0B=JumpDrive?FireFly 00-5005 (2GB)  
05DC:A701:1100:0C=JumpDrive?FireFly 00-5005 (4GB)  
05DC:A701:1100:0D=JumpDrive?FireFly 00-5005 (8GB)  
05DC:A731=JumpDrive?FireFly  
05DC:A731:1100=JumpDrive?FireFly 00-5010  
05DC:A731:1100:01=JumpDrive?FireFly 00-5010 (2MB)  
05DC:A731:1100:02=JumpDrive?FireFly 00-5010 (4MB)  
05DC:A731:1100:03=JumpDrive?FireFly 00-5010 (8MB)  
05DC:A731:1100:04=JumpDrive?FireFly 00-5010 (16MB)  
05DC:A731:1100:05=JumpDrive?FireFly 00-5010 (32MB)  
05DC:A731:1100:06=JumpDrive?FireFly 00-5010 (64MB)  
05DC:A731:1100:07=JumpDrive?FireFly 00-5010 (128MB)  
05DC:A731:1100:08=JumpDrive?FireFly 00-5010 (256MB)  
05DC:A731:1100:09=JumpDrive?FireFly 00-5010 (512MB)  
05DC:A731:1100:0A=JumpDrive?FireFly 00-5010 (1GB)  
05DC:A731:1100:0B=JumpDrive?FireFly 00-5010 (2GB)  
05DC:A731:1100:0C=JumpDrive?FireFly 00-5010 (4GB)  
05DC:A731:1100:0D=JumpDrive?FireFly 00-5010 (8GB)  
05DC:A731:1100:0E=JumpDrive?FireFly 00-5010 (16GB)  
05DC:A731:1100:0F=JumpDrive?FireFly 00-5010 (32GB)  
05DC:A731:1100:10=JumpDrive?FireFly 00-5010 (64GB)  
05DC:A790=JumpDrive 2GB  
05DC:A811=16GB Gizmo!  
05DC:B002=USB CF Reader  
05DC:B018=Lexar RW018 USB 2.0 Multi Card Reader  
05DC:B018:0128=Lexar RW018 USB 2.0 Multi Card Reader Rev C  
05DC:B047=SDHC Reader [RW047-7000]  
05DD=Delta Electronics  
05DD:FF31=AWU-120  
05DD:FF32=FriendlyNET AeroLAN AL2011  
05DD:FF35=PCW 100 - Wireless 802.11b Adapter  
05DD:FF91=2Wire PC Port Phoneline 10Mbps Adapter  
05DF=Silicon Vision  
05E0=Symbol Technologies  
05E0:0600=Symbol USB COM Port Emulation  
05E0:0700=Symbol Bar Code Scanner (CS1504)  
05E0:0800=Symbol Spectrum24 Wireless LAN USB Adapter  
05E0:1200=DS6608 Bar Code Scanner  
05E0:1200:0201=LS2208 Bar Code Scanner  
05E0:1900=SNAPI Imaging Device  
05E0:2000=MC3090 Rugged Mobile Computer  
05E0:2001=Symbol USB Sync 0x2001  
05E0:2002=Symbol USB Sync 0x2002  
05E0:2003=Symbol USB Sync 0x2003  
05E0:2004=Symbol USB Sync 0x2004

05E0:2005=Symbol USB Sync 0x2005  
05E0:2006=Symbol USB Sync 0x2006  
05E0:2007=Symbol USB Sync 0x2007  
05E0:2008=Symbol USB Sync 0x2008  
05E0:2009=Symbol USB Sync 0x2009  
05E0:200A=Symbol USB Sync 0x200A  
05E0:200D=MC70 Rugged Mobile Computer  
05E1=Syntek Semiconductor  
05E1:0100=802.11g + Bluetooth Wireless Adapter  
05E1:0408=STK1160 Video Capture Device  
05E1:0500=DC-112X  
05E1:0501=WebCam, Chipset DC-1125 similar to 174f:a311 - Asus F2F, F2J, F3J, F3T  
, G1, Z53JA  
05E1:0501:01=USB2.0 Video Enhancement Device  
05E1:0890=STK011 Camera  
05E1:0892=STK013 Camera  
05E1:0895=STK016 Camera  
05E1:0896=STK017 Camera  
05E2=ElecVision  
05E3=Genesys Logic  
05E3:000A=Keyboard with PS/2 Port  
05E3:000B=Mouse  
05E3:0100=Genesys Logic Scanner Controller NT5.0  
05E3:0120=Pacific Image Electronics PrimeFilm 1800u slide/negative scanner  
05E3:0131=CF/SM Reader/Writer  
05E3:0142=Multiple Slides Scanner-3600  
05E3:0143=Multiple Frames Film Scanner-36series  
05E3:0180=Plustek Scanner  
05E3:0182=Wize Media 1000  
05E3:0189=HP ScanJet 4600 series  
05E3:018A=Xerox 6400  
05E3:0300=GLUSB98PT Parallel Port  
05E3:0301=USB2LPT Cable Release2  
05E3:0406=Hub  
05E3:0501=GL620USB Host-Host interface  
05E3:0502=GL620USB GeneLink USB-USB Bridge  
05E3:0503=Genesys Logic USB2.0 PC Camera  
05E3:0504=HID Keyboard Filter  
05E3:0505=Genesys Logic USB2.0 PC Camera  
05E3:0507=Genesys Logic USB2.0 PC Camera  
05E3:0604=USB V2.0 4-Port Hub  
05E3:0605=USB V2.0 4-Port Hub [ednet]  
05E3:0606=USB V2.0 4-Port Hub [D-Link DUB-H4]  
05E3:0607=Logitech G110 Hub  
05E3:0608=Genesys Logic USB V2.0 4-Port Hub  
05E3:0610=4-port hub  
05E3:0660=USB V2.0 4-Port Hub  
05E3:0700=SIIG US2256 CompactFlash Card Reader  
05E3:0701=USB Optical Device  
05E3:0702=USB 2.0 IDE Adapter  
05E3:0703=USB Card Reader  
05E3:0704=USB Card Reader  
05E3:0705=USB Card Reader  
05E3:0706=USB Card Reader  
05E3:0707=USB Card Reader  
05E3:0708=USB Card Reader  
05E3:0709=USB Card Reader  
05E3:070A=USB Pen Flash  
05E3:070B=USB Pen Flash  
05E3:070E=X-PRO CR20xA USB 2.0 Internal Card Reader



05E3:070F=Pen Flash  
05E3:0710=USB Card Reader  
05E3:0711=USB Card Reader  
05E3:0712=Delkin Mass Storage Device  
05E3:0715=USB 2.0 microSD Reader  
05E3:0716=USB 2.0 Multislot Card Reader/Writer  
05E3:0717=All-in-1 Card Reader  
05E3:0718=IDE/SATA Adapter  
05E3:0723=USB 2.0 SD/MMC/MS Flash Card Reader  
05E3:0727=microSD Reader/Writer  
05E3:0731=GL3310 USB to SATA Bridge  
05E3:0760=Genesys Logic, Inc. Card Reader  
05E3:0761=USB Card Reader  
05E3:0780=USBFS DFU Adapter  
05E3:07A0=USB Pen Flash  
05E3:0880=Wasp (SL-6612)  
05E3:0927=USB Card Reader  
05E3:1205=Afilias Optical Mouse H3003  
05E3:A700=USB Pen Flash  
05E3:F102=VX7012 TV Box  
05E3:F103=VX7012 TV Box  
05E3:F104=VX7012 TV Box  
05E3:F191=Genesys Logic USB2.0 PC Camera  
05E3:F192=Genesys Logic USB2.0 PC Camera  
05E3:FD21=3M TL20 Temperature Logger  
05E3:FE00=Razer Mouse  
05E4=Red Wing  
05E5=Fuji Electric  
05E6=Keithley Instruments  
05E8=ICC  
05E9=Kawasaki LSI  
05E9:0008=KLSI USB Ethernet Adapter  
05E9:0009=KLSI USB Ethernet Adapter  
05E9:000C=USB-to-RS-232  
05E9:000D=USB-to-RS-232  
05E9:0014=RS-232 J104  
05E9:0040=KLSI USB Ethernet Adapter  
05E9:2008=Ethernet Adapter  
05EB=FFC  
05EC=COM21  
05EE=Cytechinfo  
05EF=AVB  
05EF:020A=Top Shot Pegasus Joystick  
05EF:8884=Mag Turbo Force Wheel  
05EF:8888=Top Shot Force Feedback Racing Wheel  
05F0=Canopus  
05F0:0101=Canopus DA-Port USB  
05F1=Compass Communications  
05F2=Dexin  
05F2:0010=Dexin USB AQ Mouse  
05F2:0010:01=Dexin USB AQ Mouse  
05F3=PI Engineering  
05F3:0007=Kinesis Advantage PRO MPC/USB Keyboard  
05F3:0081=Kinesis Integrated Hub  
05F3:00FF=VEC Footpedal  
05F3:020B=PS2 Adapter  
05F3:0232=X-Keys Switch Interface, Programming Mode  
05F3:0261=X-Keys Switch Interface, SPLAT Mode  
05F3:0264=X-Keys Switch Interface, Composite Mode  
05F5=Unixtar Technology

05F6=AOC International  
05F7=RFC Distribution  
05F9=PSC Scanning  
05F9:2206=Gryphon Barcode Scanner  
05F9:2602=Datalogic Magellan 1100i Barcode Scanner  
05FA=STSL  
05FA:3301=STSL USB Keyboard with PS/2 Mouse Port  
05FA:3301:01=STSL USB Keyboard Mouse  
05FA:3302=STSL USB Keyboard  
05FA:3303=STSL USB Keyboard with PS/2 Mouse Port  
05FA:3303:01=STSL USB Keyboard Mouse  
05FC=Harman Multimedia  
05FC:1001=Office Keyboard  
05FC:7849=Harman/Kardon SoundSticks  
05FD=InterAct  
05FD:0239=InterAct SV-239 HammerHead Digital (USB)  
05FD:0251=Raider Pro  
05FD:0253=ProPad 8 Digital  
05FD:0286=InterAct SV-286 Cyclone Digital (USB)  
05FD:107A=PowerPad Pro X-Box pad  
05FD:262A=3dfx HammerHead FX  
05FD:262F=HammerHead Fx  
05FD:DAAE=Game Shark  
05FD:DBAE=ActionReplay XBox  
05FE=Chic Technilogy  
05FE:0001=Belkin USB Mouse  
05FE:0001:01=Belkin USB Mouse  
05FE:0003=Cypress USB Mouse  
05FE:0005=Viewmaster 4D Browser Mouse  
05FE:0007=Twinhead Mouse  
05FE:0009=Inland Pro 4500/5000 Mouse  
05FE:0010=USB Browser Mouse  
05FE:0011=Cypress Ultra Mouse  
05FE:0011:0001=Cypress Ultra Mouse Model C-3UP  
05FE:0012=USB Browser Mouse  
05FE:0014=Gamepad  
05FE:1002=HP USB Multimedia Keyboard With LCD  
05FE:1010=USB Browser Mouse  
05FE:1010:01=Laser Mouse  
05FE:2022=MI-2900Z Optical USB Mouse  
05FF=LeCroy  
0600=Barco Display Systems  
0601=Jazz Hipster  
0601:0003=Internet Security Co., Ltd. SecureKey  
0602=Vista Imaging  
0602:1001=ViCam WebCam  
0603=Novatek Microelectronics  
0603:00F1=Keyboard  
0603:00F2=USB Keyboard  
0603:6871=Mouse  
0603:B5D3=MP3 Player and Radio  
0604=Jean  
0605=Anchor  
0605:0001=Anchor USB Mouse  
0605:0001:01=Anchor USB Mouse  
0606=Royal Information Electronics  
0607=Bridge Information  
0608=Genrad Ads  
0609=SMK Manufacturing  
0609:0303=USB Touch Panel

0609:0314=USB Touch Panel  
0609:031D=eHome Infrared Receiver (USBCIR)  
0609:0322=SMK eHome Infrared Transceiver  
0609:0334=eHome Infrared Receiver (USBCIR)  
0609:0338=eHome Infrared Receiver (USBCIR)  
0609:FF12=SMK Bluetooth Device  
060A=Worthington Data Solutions  
060B=Solid Year  
060B:0001=MacAlly Keyboard  
060B:0230=KSK-8003 UX Keyboard  
060B:1006=Japanese USB Keyboard - 260U  
060B:2101=Solid Year USB Keyboard with PS/2 Mouse Port  
060B:2101:01=Solid Year USB Keyboard Mouse  
060B:2231=KSK-6001 UELX Keyboard  
060B:5811=ACK-571U Wireless Keyboard  
060B:5903=Japanese USB Keyboard - 595U  
060B:6001=SolidTek USB 2p HUB  
060B:6002=SolidTek USB Keyboard  
060B:6003=Japanese USB Keyboard - 600HM  
060B:A001=Maxwell Compact Pc PM3  
060C=EEH Datalink GmbH  
060D=Auctor  
060E=Transmonde Technologies  
060F=Joinsoon Electronics  
0610=Costar Electronics  
0611=Totoku Electric  
0613=TransAct Technologies  
0614=Bio-Rad Laboratories  
0615=Quabbin Wire & Cable  
0616=Future Techno Designs  
0617=Swiss Federal Insitute of Technology  
0618=MacAlly  
0618:0101=Mouse  
0619=Seiko Instruments  
0619:0101=SLP-100 Driver  
0619:0102=SLP-200 Driver  
0619:0103=SLP-100N Driver  
0619:0104=SLP-200N Driver  
0619:0105=SLP-240 Driver  
0619:0501=SLP-440 Driver  
0619:0502=SLP-450 Driver  
061A=Veridicom International  
061A:0110=5thSense Fingerprint Sensor  
061A:0200=FPS200 Fingerprint Sensor  
061A:8200=VKI-A Fingerprint Sensor/Flash Storage (dumb)  
061A:9200=VKI-B Fingerprint Sensor/Flash Storage (smart)  
061B=Promptus Communications  
061C=Act Labs  
061D=Quatech  
061E=Nissei Electric  
061E:0001=nissei 128DE-USB - USB  
061E:0010=nissei 128DE-PNA - USB  
0620=Alaris  
0620:0004=QuickVideo weeCam  
0620:0007=QuickVideo weeCam  
0620:000A=QuickVideo weeCam  
0620:000B=QuickVideo weeCam  
0621=ODU-Steckverbindungssysteme  
0622=Iotech  
0623=Littelfuse

0624=Apex  
0624:0248=Avocent DVC Keyboard  
0624:0248:01=Avocent DVC Mouse  
0624:0248:02=Avocent DVC Control  
0624:0248:03=Avocent DVC Storage  
0624:0248:04=Avocent DVC Bulk SFF  
0624:0294=Dell 03R874 KVM dongle  
0625=TiMedia Technology  
0626=Nippon Systems Development  
0627=Adomax Technology  
0628=Tasking Software  
0629=Zida Technologies  
062A=MosArt Semiconductor  
062A:0000=Optical mouse  
062A:0001=Notebook Optical Mouse  
062A:0102=Wireless Keyboard/Mouse Combo [MK1152WC]  
062A:0201=Defender Office Keyboard (K7310) S Zodiac KM-9010  
062A:0252=USB Human Interface Device  
062A:3286=Nano Receiver [Sandstrom Laser Mouse SMWLL11]  
062A:6301:0100=USB Human Interface Device  
062A:9003=VoIP Conference Hub (A16GH)  
062A:9004=USR9602 USB Internet Mini Phone  
062B=Greatlink Electronics Taiwan  
062C=Institute for Information Industry  
062D=Taiwan Tai-Hao Enterprises  
062E=Mainsuper Enterprises  
062F=Sin Sheng Terminal & Machine  
0631=JUJO Electronics  
0633=Cyrrix  
0634=Micron Technology  
0634:0655=Embedded Mass Storage Drive [RealSSD]  
0635=Method Electronics  
0636=Sierra Imaging  
0636:0003=Vivicam 35Xx  
0637:0003=GUNZE USB Touch Panel  
0638=Avision  
0638:0268=iVina 1200U Scanner  
0638:026A=Minolta Scan Dual II  
0638:0A10=UMAX Astra 4500 Scanner  
0638:0A13=Avision AV600U  
0638:0A15=Minolta SC-110  
0638:0A16=Minolta SC-215  
0638:0A17=Avision AV8000S  
0638:0A18=Avision AV610  
0638:0A19=Avision AV610  
0638:0A1D=Avision AV600U Plus  
0638:0A1E=Avision AV500U  
0638:0A22=Avision AVA6  
0638:0A23=Avision AV220  
0638:0A24=Avision AV210  
0638:0A25=Avision AV210  
0638:0A27=Avision AV120  
0638:0A2A=Avision AV220C2  
0638:0A2B=Avision AV220D2  
0638:0A2C=Avision AV220+  
0638:0A2D=Avision AV220C2-G  
0638:0A2E=Avision AV220C2-B  
0638:0A2F=Avision AV210C2-G  
0638:0A30=UMAX Astra 6700 Scanner  
0638:0A33=Avision AV122

0638:0A37=Avision AVA6  
0638:0A3A=Avision AV210C2  
0638:0A3C=Avision AV121  
0638:0A3D=Avision AV160  
0638:0A3E=Avision AV160  
0638:0A3F=Avision AV180  
0638:0A40=Avision AV8300  
0638:0A41=Avision MF3000  
0638:0A45=Avision @V5100  
0638:0A4A=Avision AV180  
0638:0A4D=Avision AV8050U  
0638:0A4E=Avision AV3200SU  
0638:0A4F=Avision AV3730SU  
0638:0A52=Avision AM6220  
0638:0A57=Avision AV6200  
0638:0A5C=Avision AV320  
0638:0A5E=Avision AV610C2  
0638:0A61=Avision IT8300  
0638:0A65=Avision AV3750SU  
0638:0A66=Avision AV3850SU  
0638:0A68=Avision AV8350  
0638:0A6A=Avision AM6120  
0638:0A6B=Avision AM6124  
0638:0A82=Avision FB6080E  
0638:0A84=Avision FB2080E  
0638:0A88=Avision AV600G  
0638:0A93=Avision AV122C2  
0638:0A94=Avision AV220-B  
0638:0A96=Avision AV320+  
0638:0AA0=Avision AM3000  
0638:0AA1=Avision @V2500  
0638:0AB8=Avision AV220C2+  
0638:0F01=Fujitsu fi-4010CU  
0638:0F03=Avision DS-320F  
0638:1A1A=Nexx NX2200  
0638:1A1B=Nexx NX2400  
0638:4004=Minolta Dimage Scan Elite II  
0639=Chrontel  
063A=Techwin  
063B=Taugagreining HF  
063C=Yamaichi Electronics  
063D=Fong Kai Industrial  
063E=RealMedia Technology  
063F=New Technology Cable  
0640=Hitex Development Tools  
0640:0026=LPC-Stick  
0641=Woods Industries  
0642=VIA Medical  
0644=TEAC  
0644:0000=TEAC USB Floppy  
0644:0200=CA-200 USB Card Reader  
0644:0300=USB Mass Storage Device  
0644:1000=TEAC USB CD-ROM Drive  
0644:800D=TASCAM Portastudio DP-01FX  
0644:800E=TASCAM US-122L  
0644:8021=TASCAM US-122mkII  
0644:D001=TEAC USB CD-R/RW Unit  
0644:D002=TEAC USB CD-R/RW Unit  
0644:D010=TEAC USB CD-RW/DVD Unit  
0645=Who? Vision Systems

0646=UMAX  
0647=Acton Research  
0647:0100=ARC SpectraPro UV/VIS/IR Monochromator/Spectrograph  
0647:0101=ARC AM-VM Mono Airpath/Vacuum Monochromator/Spectrograph  
0647:0102=ARC Inspectrum Mono  
0647:0103=ARC Filterwheel  
0647:03E9=Inspectrum 128x1024 F VIS Spectrograph  
0647:03EA=Inspectrum 256x1024 F VIS Spectrograph  
0647:03EB=Inspectrum 128x1024 B VIS Spectrograph  
0647:03EC=Inspectrum 256x1024 B VIS Spectrograph  
0648=Inside Out Networks  
0649=Weli Science  
064B=White Mountain DSP  
064B:0165=Blackfin 535 [ADZS HPUSB ICE]  
064C=Ji-Haw Industrial  
064D=TriTech Microelectronics  
064E=Suyin  
064E:8101=Integrated Webcam  
064E:A100=Acer Crystal Eye webcam  
064E:A101=Acer Crystal Eye webcam  
064E:A102=Integrated Webcam  
064E:A103=Acer Crystal Eye webcam  
064E:A108=USB 2.0 UVC 2.0M WebCam  
064E:A110=Acer Crystal Eye webcam  
064E:A111=Acer Crystal Eye webcam  
064E:A112=Acer Crystal Eye webcam  
064E:A113=USB 2.0 UVC 2.0M WebCam  
064E:A114=USB 2.0 UVC 0.35M WebCam  
064E:A115=USB 2.0 UVC 2.0M WebCam  
064E:A116=USB 2.0 UVC 1.3M WebCam  
064E:A117=WebCam  
064E:A118=Integrated Webcam  
064E:A120=Acer Crystal Eye webcam  
064E:A122=USB 2.0 UVC 2.0M WebCam  
064E:A124=USB 2.0 UVC 0.3M WebCam  
064E:A125=HP Webcam-101  
064E:A127=Lenovo EasyCamera  
064E:A130=USB 2.0 UVC 1.3M WebCam  
064E:A131=USB 2.0 UVC 2.0M WebCam  
064E:A133=USB 2.0 UVC HD WebCam  
064E:A134=USB 2.0 UVC 0.3M WebCam  
064E:A136=Asus Integrated Webcam [CN031B]  
064E:A138=USB 2.0 UVC 0.3M WebCam  
064E:A219=1.3M WebCam (notebook emachines E730, Acer sub-brand)  
064E:C107=HP webcam [dv6-1190en]  
064E:D100=Acer Crystal Eye webcam  
064E:D101=Acer CrystalEye Webcam  
064E:E201=Lenovo Integrated Webcam  
064E:E203=Lenovo Integrated Webcam  
064E:E20A=USB 2.0 Camera  
064E:E210=USB 2.0 Camera  
064E:E211=USB 2.0 Camera  
064E:E212=USB 2.0 Camera  
064E:E213=USB 2.0 Camera  
064E:E214=USB 2.0 Camera  
064E:E215=USB 2.0 Camera  
064E:E216=USB 2.0 Camera  
064E:E217=USB 2.0 Camera  
064E:E218=USB 2.0 Camera  
064E:E219=USB 2.0 Camera

064E:E21A=USB 2.0 Camera  
064E:E21B=USB 2.0 Camera  
064E:E21C=USB 2.0 Camera  
064E:E21D=USB 2.0 Camera  
064E:E21E=USB 2.0 Camera  
064E:E21F=USB 2.0 Camera  
064E:E220=USB 2.0 UVC 0.3M Webcam  
064E:E221=USB 2.0 UVC 0.3M Webcam  
064E:E222=USB 2.0 UVC 0.3M Webcam  
064E:E223=USB 2.0 UVC 0.3M Webcam  
064E:E224=USB 2.0 UVC 0.3M Webcam  
064E:E225=USB 2.0 UVC 0.3M Webcam  
064E:E226=USB 2.0 UVC 0.3M Webcam  
064E:E227=USB 2.0 UVC 0.3M Webcam  
064E:E228=USB 2.0 UVC 0.3M Webcam  
064E:E229=USB 2.0 UVC 0.3M Webcam  
064E:E22A=USB 2.0 UVC 0.3M Webcam  
064E:E22B=USB 2.0 UVC 0.3M Webcam  
064E:E22C=USB 2.0 UVC 0.3M Webcam  
064E:E22D=USB 2.0 UVC 0.3M Webcam  
064E:E22E=USB 2.0 UVC 0.3M Webcam  
064E:E22F=USB 2.0 UVC 0.3M Webcam  
064E:E230=USB 2.0 UVC 1.3M Webcam  
064E:E231=USB 2.0 UVC 1.3M Webcam  
064E:E232=USB 2.0 UVC 1.3M Webcam  
064E:E233=USB 2.0 UVC 1.3M Webcam  
064E:E234=USB 2.0 UVC 1.3M Webcam  
064E:E235=USB 2.0 UVC 1.3M Webcam  
064E:E236=USB 2.0 UVC 1.3M Webcam  
064E:E237=USB 2.0 UVC 1.3M Webcam  
064E:E238=USB 2.0 UVC 1.3M Webcam  
064E:E239=USB 2.0 UVC 1.3M Webcam  
064E:E23A=USB 2.0 UVC 1.3M Webcam  
064E:E23B=USB 2.0 UVC 1.3M Webcam  
064E:E23C=USB 2.0 UVC 1.3M Webcam  
064E:E23D=USB 2.0 UVC 1.3M Webcam  
064E:E23E=USB 2.0 UVC 1.3M Webcam  
064E:E23F=USB 2.0 UVC 1.3M Webcam  
064E:E240=USB 2.0 UVC 2M Webcam  
064E:E241=USB 2.0 UVC 2M Webcam  
064E:E242=USB 2.0 UVC 2M Webcam  
064E:E243=USB 2.0 UVC 2M Webcam  
064E:E244=USB 2.0 UVC 2M Webcam  
064E:E245=USB 2.0 UVC 2M Webcam  
064E:E246=USB 2.0 UVC 2M Webcam  
064E:E247=USB 2.0 UVC 2M Webcam  
064E:E248=USB 2.0 UVC 2M Webcam  
064E:E249=USB 2.0 UVC 2M Webcam  
064E:E24A=USB 2.0 UVC 2M Webcam  
064E:E24B=USB 2.0 UVC 2M Webcam  
064E:E24C=USB 2.0 UVC 2M Webcam  
064E:E24D=USB 2.0 UVC 2M Webcam  
064E:E24E=USB 2.0 UVC 2M Webcam  
064E:E24F=USB 2.0 UVC 2M Webcam  
064E:F100=HP Webcam-50  
064E:F101=HP Webcam-101  
064E:F102=Lenovo Integrated Webcam [R5U877]  
064E:F103=Lenovo Integrated Webcam [R5U877]  
064E:F111=USB 2.0 UVC 1.3M WebCam  
064E:F113=USB 2.0 UVC 2.0M WebCam

064E:F115=USB 2.0 UVC 2.0M WebCam  
064E:F116=USB 2.0 UVC 1.3M WebCam  
064E:F117=USB 2.0 UVC HD WebCam  
064E:F118=USB 2.0 UVC 1.3M WebCam  
064E:F205=Integrated Camera  
064E:F206=Integrated Camera  
064E:F207=Lenovo EasyCamera  
064E:F208=Lenovo EasyCamera  
064E:F210=Lenovo EasyCamera  
064E:F211=Lenovo EasyCamera  
064E:F216=Lenovo EasyCamera  
064E:F217=Lenovo EasyCamera  
064E:F219=Lenovo EasyCamera  
064E:F220=Lenovo EasyCamera  
064E:F221=Lenovo EasyCamera  
064E:F222=Lenovo EasyCamera  
064E:F223=Lenovo EasyCamera  
064E:F224=Lenovo EasyCamera  
064E:F225=Lenovo EasyCamera  
064E:F226=Lenovo EasyCamera  
064E:F227=Lenovo EasyCamera  
064E:F228=Lenovo EasyCamera  
064E:F229=Lenovo EasyCamera  
064E:F22A=Lenovo EasyCamera  
064E:F22B=Lenovo EasyCamera  
064E:F22C=Lenovo EasyCamera  
064E:F22D=Lenovo EasyCamera  
064E:F22E=Lenovo EasyCamera  
064E:F22F=Lenovo EasyCamera  
064E:F240=USB 2.0 Camera  
064E:F241=USB 2.0 Camera  
064E:F242=USB 2.0 Camera  
064E:F243=USB 2.0 Camera  
064E:F244=USB 2.0 Camera  
064E:F245=USB 2.0 Camera  
064E:F246=USB 2.0 Camera  
064E:F247=USB 2.0 Camera  
064E:F248=USB 2.0 Camera  
064E:F249=USB 2.0 Camera  
064E:F24A=USB 2.0 Camera  
064E:F24B=USB 2.0 Camera  
064E:F24C=USB 2.0 Camera  
064E:F24D=USB 2.0 Camera  
064E:F24E=USB 2.0 Camera  
064E:F24F=USB 2.0 Camera  
064F=WIBU-Systems AG  
064F:03E9=Propellerhead Record Ignition Key  
064F:03F2=CmStick/M (article no. 1010)  
064F:03F3=CmStick/M (article no. 1011)  
064F:0BD7=WIBU-BOX/U  
064F:0BD8=WIBU-BOX/RU  
0650=Dynapro Systems  
0651=Likom Technology Sdn. Bhd.  
0652=Stargate Solutions  
0653=CNF  
0654=Granite Microsystems  
0654:0005=Granite Microsystems Device Bay Controller  
0654:0005:0100=Granite Microsystems Device Bay Controller  
0654:0006=Granite Microsystems USB Hub  
0654:0007=Granite Microsystems Device Bay Controller



0654:0007:0100=Granite Microsystems Device Bay Controller  
0654:0016=Granite Microsystems USB Hub  
0655=Space Shuttle Hi-Tech  
0656=Glory Mark Electronic  
0657=Tekcon Electronics  
0658=Sigma Designs  
0659=Aethra  
065A=Optoelectronics  
065A:0001=Barcode scanner  
065B=Tracewell Systems  
065E=Silicon Graphics  
065F=Good Way Technology  
0660=TSAY-E (BVI) International  
0661=Hamamatsu Photonics K.K.  
0662=Kansai Electric  
0663=Topmax Electronic  
0663:0103=CobraPad  
0664=Groovy Technology  
0664:0301=GTouch Touch Screen  
0664:0302=GTouch Touch Screen  
0664:0303=GTouch Touch Screen  
0664:0304=GTouch Touch Screen  
0664:0305=GTouch Touch Screen  
0664:0306=GTouch Touch Screen  
0664:0307=GTouch Touch Screen  
0664:0309=GTouch Touch Screen  
0665=Cypress Semiconductor  
0665:0301=DM2 USB Controller Driver  
0665:5161=USB to Serial  
0667=Aiwa  
0667:0FA1=TD-U8000 Tape Drive  
0668=WordWand  
0669=Oce' Printing Systems GmbH  
066A=Total Technologies  
066B=Linksys  
066B:0105=SCM eUSB SmartMedia Card Reader  
066B:010A=Melco MCR-U2 SmartMedia / CompactFlash Reader  
066B:200C=USB10TX  
066B:2202=Linksys USB 10Base-T Ethernet Adapter  
066B:2203=Linksys Etherfast USB 10/100 Ethernet Adapter  
066B:2204=USB100TX HomePNA Ethernet [pegasus]  
066B:2206=USB Ethernet [pegasus]  
066B:2207=Linksys HomeLink Phoneline 10M USB Network Adapter  
066B:2211=WUSB11 802.11b Adapter  
066B:2212=WUSB11v2.5 802.11b Adapter  
066B:2213=WUSB12v1.1 802.11b Adapter  
066B:2219=Instant Wireless Network Adapter  
066B:400B=USB10TX  
066D=Entrega  
066E=Acer Semiconductor America  
066F=SigmaTel  
066F:003B=MP3 Player  
066F:003E=MP3 Player  
066F:003F=MP3 Player  
066F:0040=MP3 Player  
066F:0041=MP3 Player  
066F:0042=MP3 Player  
066F:0043=MP3 Player  
066F:004B=A-Max PA11 MP3 Player  
066F:3400=Player Recovery Device

066F:3410=Philips GoGear Audio Recovery  
066F:3410:0083=Philips GoGear Audio Recovery  
066F:3500=Philips GoGear Audio Recovery  
066F:3600=Philips GoGear Audio Recovery  
066F:3780=STMP3780/i.MX23 SystemOnChip in RecoveryMode  
066F:4200=SigmaTel USB-IrDA Adapter  
066F:4200:0100=SigmaTel USB-IrDA Dongle  
066F:4210=STIr4210 IrDA Bridge  
066F:8000=MP3 Player  
066F:8000:0001=SigmaTel MSCN Audio Player  
066F:8000:0001:01=SigmaTel MSCN Audio Player  
066F:8001=SigmaTel MSCN Audio Player  
066F:8001:0001:01=SigmaTel MSCN Audio Player  
066F:8004=MP3 Player  
066F:8008=i-Bead 100 MP3 Player  
066F:8020=MP3 Player  
066F:8034=MP3 Player  
066F:8036=MP3 Player  
066F:8038=MP3 Player  
066F:8056=MP3 Player  
066F:8060=MP3 Player  
066F:8066=MP3 Player  
066F:807E=MP3 Player  
066F:8092=MP3 Player  
066F:8096=MP3 Player  
066F:809A=MP3 Player  
066F:80AA=MP3 Player  
066F:80AC=MP3 Player  
066F:80B8=MP3 Player  
066F:80BA=MP3 Player  
066F:80BC=MP3 Player  
066F:80BF=MP3 Player  
066F:80C5=MP3 Player  
066F:80C8=MP3 Player  
066F:80CA=MP3 Player  
066F:80CC=MP3 Player  
066F:8104=MP3 Player  
066F:8106=MP3 Player  
066F:8108=MP3 Player  
066F:810A=MP3 Player  
066F:810C=MP3 Player  
066F:8122=MP3 Player  
066F:8124=MP3 Player  
066F:8126=MP3 Player  
066F:8128=MP3 Player  
066F:8134=MP3 Player  
066F:8136=MP3 Player  
066F:8138=MP3 Player  
066F:813A=MP3 Player  
066F:813E=MP3 Player  
066F:8140=MP3 Player  
066F:8142=MP3 Player  
066F:8144=MP3 Player  
066F:8146=MP3 Player  
066F:8148=MP3 Player  
066F:814C=MP3 Player  
066F:8201=MP3 Player  
066F:8202=MP3 Player  
066F:8203=MP3 Player  
066F:8204=MP3 Player

066F:8205=MP3 Player  
066F:8206=MP3 Player  
066F:8207=MP3 Player  
066F:8208=MP3 Player  
066F:8209=MP3 Player  
066F:820A=MP3 Player  
066F:820B=MP3 Player  
066F:820C=MP3 Player  
066F:820D=MP3 Player  
066F:820E=MP3 Player  
066F:820F=MP3 Player  
066F:8210=MP3 Player  
066F:8211=MP3 Player  
066F:8212=MP3 Player  
066F:8213=MP3 Player  
066F:8214=MP3 Player  
066F:8215=MP3 Player  
066F:8216=MP3 Player  
066F:8217=MP3 Player  
066F:8218=MP3 Player  
066F:8219=MP3 Player  
066F:821A=MP3 Player  
066F:821B=MP3 Player  
066F:821C=MP3 Player  
066F:821D=MP3 Player  
066F:821E=MP3 Player  
066F:821F=MP3 Player  
066F:8220=MP3 Player  
066F:8221=MP3 Player  
066F:8222=MP3 Player  
066F:8223=MP3 Player  
066F:8224=MP3 Player  
066F:8225=MP3 Player  
066F:8226=MP3 Player  
066F:8227=MP3 Player  
066F:8228=MP3 Player  
066F:8229=MP3 Player  
066F:8230=MP3 Player  
066F:829C=MP3 Player  
066F:82E0=MP3 Player  
066F:835D=MP3 Player  
066F:9000=MP3 Player  
066F:9001=MP3 Player  
066F:9002=MP3 Player  
0670=Sequel Imaging  
0670:0001=Calibrator  
0670:0005=Enable Cable  
0672=Labtec  
0672:1041=Labtec HID Audio Controls  
0672:1041:02=Labtec HID Audio Controls  
0672:5000=SpaceBall 4000 FLX  
0673=HCL  
0673:5000=Keyboard  
0674=Key Mouse Electronic  
0674:0001=Office Keyboard  
0675=Draytech  
0675:0110=Vigor 128 ISDN TA  
0675:0530=Vigor530 IEEE 802.11G Adapter (ISL3880+NET2280)  
0675:0550=Vigor550  
0675:1688=miniVigor 128 ISDN TA

0675:6694=USB ISDN TA  
0676=Teles AG  
0676:0001=TELES.S0/USB-Box  
0676:0002=TELES.S0/2AB/USB-Box  
0676:0004=TELES.S0/2AB/USB/LCR-Box  
0677=Aiwa  
0677:07D5=TM-ED1285 (USB)  
0677:07D5:0100=TM-ED1285 (USB)  
0677:0FA1=TD-U8000 Tape Drive  
0678=ACARD Technology  
067B=Prolific Technology  
067B:0000=Hi-Speed USB Bridge Cable  
067B:0001=USB-USB Network Bridge Driver  
067B:0307=Motorola Serial Adapter  
067B:04BB=PL2303 Serial (IODATA USB-RSAQ2)  
067B:0610=Onext EG210U MODEM  
067B:0611=Aldiga AL-11U Quad-band GSM/GPRS/EDGE modem  
067B:2303=Prolific USB-to-Serial Comm Port  
067B:2303:0001=Prolific USB-to-Serial Comm Port  
067B:2303:0002=MAT USB-to-Serial Bridge  
067B:2303:0202=Prolific PL-2303 USB-to-Serial  
067B:2303:0300=Prolific PL-2303X USB-to-Serial  
067B:2305=PL2305 Parallel Port  
067B:2306=Raylink Bridge Controller  
067B:2307=PL2307 USB-ATAPI4 Bridge  
067B:2313=FITEL PHS U Cable Adaptor  
067B:2315=Flash Disk Embedded Hub  
067B:2316=Flash Disk Security Device  
067B:2317=Prolific USB Flash Storage Device 1.1  
067B:2501=Hi-Speed USB Bridge Cable  
067B:2507=USB2 to SATA Disk Drive  
067B:2515=Flash Disk Embedded Hub  
067B:2517=Prolific USB Flash Storage Device 2.0  
067B:25A1=USB Easy Transfer Cable  
067B:25A2=USB Easy Transfer Cable  
067B:25B1=USB Easy Transfer Cable  
067B:25B2=USB Easy Transfer Cable  
067B:25C1=USB Easy Transfer Cable  
067B:25C2=USB Easy Transfer Cable  
067B:25D1=USB Easy Transfer Cable  
067B:25D2=USB Easy Transfer Cable  
067B:25E1=USB Easy Transfer Cable  
067B:25E2=USB Easy Transfer Cable  
067B:25F1=USB Easy Transfer Cable  
067B:25F2=USB Easy Transfer Cable  
067B:3400=Hi-Speed USB Flash Disk with AuthenTec TruePrint AES3400  
067B:3500=Hi-Speed USB Flash Disk with AuthenTec TruePrint AES3500  
067B:3507=PL3507 ATAPI6 Bridge  
067B:AAA0=Microsoft USB GPS Port  
067B:AAA2=PL2303 Serial Adapter (IODATA USB-RSAQ3)  
067C=Efficient Networks  
067C:1001=Siemens SpeedStream 100Mbps Ethernet  
067C:1022=Siemens SpeedStream 1022 802.11b Adapter  
067C:1023=SpeedStream Wireless  
067C:4020=SpeedStream 4020 ATM/ADSL Installer  
067C:4031=Efficient ADSL Modem  
067C:4032=SpeedStream 4031 ATM/ADSL Installer  
067C:4033=SpeedStream 4031 ATM/ADSL Installer  
067C:4060=Alcatel Speedstream 4060 ADSL Modem  
067C:4062=Efficient Networks 4060 Loader

067C:5667=Efficient Networks Virtual Bus for ADSL Modem  
067C:C031=SpeedStream 4031 ATM/ADSL Installer  
067C:C032=SpeedStream 4031 ATM/ADSL Installer  
067C:C033=SpeedStream 4031 ATM/ADSL Installer  
067C:C060=SpeedStream 4060 Miniport ATM/ADSL Adapter  
067C:D667=Efficient Networks Virtual Bus for ADSL Modem  
067C:E240=Speedstream Ethernet Adapter E240  
067C:E540=Speedstream Ethernet Adapter E240  
067D=Hohner  
067E=Intermec  
067E:0801=SR30 Barcode Scanner  
067E:0803=VCP, Barcode scanner  
067E:0805=VCP + UVC, Barcode scanner  
067E:1001=Intermec 700 Color Mobile Computer  
067F=Virata  
067F:4552=9Telecom USB Modem  
067F:6542=DSL Modem  
067F:6549=DSL Modem  
067F:7541=DSL Modem  
0680=Realtek Semiconductor  
0680:0002=Arowana Optical Wheel Mouse MSOP-01  
0681=Siemens Information and Communication Products  
0681:0001=Dect Base  
0681:0002=Gigaset 3075 Passive ISDN  
0681:0005=Mouse with Fingerprint Reader  
0681:0009=DECT USB serial Interface  
0681:0009:01=DFU firmware in app-mode  
0681:0012=I-Gate 802.11b Adapter  
0681:001B=WLL013  
0681:001D=Hipath 1000  
0681:0021=Dect Base  
0681:0022=Dect Base  
0681:0026=DECT Data - Gigaset M34  
0681:002B=A-100-I ADSL Modem  
0681:002E=ADSL Router\_S-141  
0681:0034=GSM module MC35/ES75 USB Modem  
0681:3C06=Siemens 802.11g USB Wireless Network Adapter  
0681:8009=DFU firmware in dfu-mode  
0682=Victor Company of Japan  
0684=Actiontec Electronics  
0686=Minolta  
0686:2001=PagePro 4110W  
0686:2004=PagePro 1200W  
0686:2005=Magicolor 2300 DL  
0686:3001=PagePro 4100  
0686:3005=PagePro 1250E  
0686:3006=MINOLTA-QMS PagePro 1250W  
0686:3009=Magicolor 2300W  
0686:300B=PagePro 1350W  
0686:300C=PagePro 1300W  
0686:302E=Develop D 1650iD PCL  
0686:3034=Develop D 2050iD PCL  
0686:4001=Dimage 2300  
0686:4003=Dimage 2330 Zoom  
0686:4004=Minolta Scan Elite II  
0686:4005=Minolta DiMAGE E201 Mass Storage Device  
0686:4006=Dimage 7 digital still camera  
0686:4007=Dimage S304 digital still camera  
0686:4008=Dimage 5 Camera  
0686:4009=Dimage X digital still camera

0686:400A=Dimage S404 digital still camera  
0686:400B=Dimage 7i digital still camera  
0686:400C=Dimage F100 Camera  
0686:400D=Minolta Di1610  
0686:400E=Minolta Scan Elite 5400  
0686:400F=Dimage 7Hi Camera  
0686:4010=Dimage Xi Camera  
0686:4011=Dimage F300 Camera  
0686:4012=Dimage F200 Camera  
0686:4014=Dimage S414 digital still camera  
0686:4015=Dimage XT Camera [storage]  
0686:4016=KONICA\_MINOLTA DiMAGE Xt  
0686:4017=Dimage E223  
0686:4018=Dimage Z1 Camera  
0686:4019=Dimage A1 Camera [remote mode]  
0686:401A=Dimage A1 Camera  
0686:401B=KONICA\_MINOLTA DiMAGE X20  
0686:401C=Dimage X20 Camera  
0686:401E=Dimage E323 Camera  
068A=Pertech  
068B=Potrans International  
068E=CH Products  
068E:00D3=OEM 3 axis 5 button joystick  
068E:00E2=HFX OEM Joystick  
068E:00F1=Pro Throttle  
068E:00F2=Flight Sim Pedals  
068E:00F3=Fighterstick  
068E:00F4=Combatstick  
068E:00FA=Flight Sim Pedals  
068E:00FF=Flight Sim Yoke  
068E:0500=GameStick 3D  
068E:0501=CH Pro Pedals  
068E:0504=F-16 Combat Stick  
068F:8001=MP3 Player  
068F:8003=MP3 Player  
068F:8005=MP3 Player  
068F:8007=MP3 Player  
068F:8019=MP3 Player  
068F:8021=MP3 Player  
068F:8023=MP3 Player  
068F:8028=MP3 Player  
068F:8029=MP3 Player  
0690=Golden Bridge Electech  
0693=Hagiwara Sys-Com  
0693:0002=USB SmartMedia Reader/Writer  
0693:0003=USB CompactFlash Reader/Writer  
0693:0005=USB Dual Slot Reader/Writer  
0693:0006=USB SM PCCard R/W and SPD  
0693:0007=FlashGate ME (Authenticated)  
0693:000A=USB SDCard/MMC Reader/Writer  
0694=Lego Group  
0694:0001=Mindstorms Tower  
0694:0002=Mindstorms NXT  
0698=Chuntex (CTX)  
0698:1786=CTX HID Monitor Controls  
0698:1786:02=CTX USB Monitor  
0698:2003=CTX M730V built in Camera  
0698:9999=CTX USB Hub  
0699=Tektronix  
069A=Askey Computer

069A:0001=VC010 WebCam [pwc]  
069A:0303=Cable Modem  
069A:0311=ADSL Router Remote NDIS Device  
069A:0318=Remote NDIS Device  
069A:0319=220V Remote NDIS Device  
069A:0320=IEEE 802.11b Wireless LAN Card  
069A:0321=Dynalink WLL013 / Compex WLU11A 802.11b Adapter  
069A:0402=Scientific Atlanta WebSTAR 100 & 200 series Cable Modem  
069A:0811=BT Virtual Bus for Helium  
069A:0821=BT Voyager 1010 802.11b Adapter  
069A:4402=Scientific Atlanta WebSTAR 2000 series Cable Modem  
069A:4403=Scientific Atlanta WebSTAR 300 series Cable Modem  
069A:4501=Scientific-Atlanta WebSTAR 2000 series Cable Modem  
069B=Thomson  
069B:0704=DCM245 Cable Modem  
069B:0705=THG540K Cable Modem  
069B:070C=MP3 Player  
069B:070D=MP3 Player  
069B:070E=MP3 Player  
069B:070F=MP3 Player  
069B:0731=Lyra M200E256  
069B:0761=RCA H100A  
069B:0778=PEARL USB Device  
069B:2220=RCA Kazoo RD1000 MP3 Player  
069B:300A=RCA Lyra MP3 Player  
069B:3012=MP3 Player  
069B:3013=MP3 Player  
069B:5557=RCA CDS6300  
069D=Hughes Network Systems (HNS)  
069D:0001=Satellite Receiver Device  
069D:0002=Satellite Device  
069E=Marx  
069E:0005=CryptoBox v1.2  
069F=Allied Data Technologies BV  
069F:0010=Tornado Speakerphone FaxModem 56.0  
069F:0011=Tornado Speakerphone FaxModem 56.0  
069F:1000=ADT VvBus for CopperJet  
069F:1004=CopperJet 821 RouterPlus  
06A2=Topro Technology  
06A2:0033=USB Mouse  
06A3=Saitek PLC  
06A3:0006=Cyborg Gold Joystick  
06A3:0109=Saitek P880 Pad USB  
06A3:0160=ST290 Pro  
06A3:0200=Xbox Adrenalin Hub  
06A3:0241=Xbox Adrenalin Gamepad  
06A3:0255=X52 Flight Controller  
06A3:040B=P990 Dual Analog Pad  
06A3:040C=P2900 Wireless Pad  
06A3:0422=ST90 Joystick  
06A3:0460=ST290 Pro Flight Stick  
06A3:0461=Saitek AV8R Joystick Aviator  
06A3:0463=ST290  
06A3:0464=Saitek Cyborg Evo Joystick  
06A3:0471=Cyborg Graphite Stick  
06A3:0501=Saitek R100 Sports Wheel USB  
06A3:0502=ST200 Stick  
06A3:0506=Saitek PW6 Wheel HID  
06A3:0509=Saitek R4 Racing Wheel II (HID-Device)  
06A3:051E=Saitek Cyborg 3D Digital Stick II USB

06A3:052D=P750 Gamepad  
06A3:052F=Saitek P1500 Rumble Pad HID  
06A3:053C=Saitek X45 Flight Controller USB  
06A3:053F=X36F Flightstick  
06A3:056C=Saitek P2000 Tilt Pad HID  
06A3:056F=Saitek P2000 Tilt Pad HID  
06A3:05D2=Saitek PC Dash 2 USB  
06A3:075C=X52 Flight Controller  
06A3:0762=Saitek X52 Pro Flight Control System  
06A3:0763=Saitek Pro Flight Rudder Pedals  
06A3:0805=R440 Force Wheel  
06A3:0BAC=Saitec Pro Flight Yoke  
06A3:1003=Saitek GM2 Action Pad USB  
06A3:1003:01=Saitek GM2 Mouse USB  
06A3:1009=Saitek Action Pad USB  
06A3:100A=SP550 Pad and Joystick Combo  
06A3:100B=SP550 Pad  
06A3:1509=Saitek P3000 Wireless Pad USB  
06A3:1589=Saitek P3000 Wireless Pad USB  
06A3:2541=X45 Flight Controller  
06A3:3509=P3000 RF GamePad  
06A3:353E=Cyborg Evo Wireless  
06A3:3589=P3000 Wireless Pad  
06A3:35BE=Cyborg Evo  
06A3:5509=P3000 Wireless Pad  
06A3:8000=Gamers' Keyboard  
06A3:8000:02=Saitek Gamers' Keyboard  
06A3:8009=Saitek R4 Racing Wheel II (HID-Device)  
06A3:801E=Saitek Cyborg 3D Digital Stick II HID  
06A3:8020=Eclipse Keyboard  
06A3:8021=Eclipse II Keyboard  
06A3:802D=Saitek P750 Pad USB  
06A3:803F=Saitek X36 Flight Controller HID  
06A3:806F=Saitek P2000 Tilt Pad USB  
06A3:80C0=Pro Gamer Command Unit  
06A3:80C1=Cyborg Command Pad Unit  
06A3:A502=Gaming Mouse  
06A3:F518=P3200 Rumble Force Game Pad  
06A3:FF04=Saitek R440 Force Wheel (USB)  
06A3:FF0C=Cyborg Force Rumble Pad  
06A3:FF0D=P2600 Rumble Force Pad  
06A3:FF12=Saitek Cyborg 3D Force Stick (USB)  
06A3:FF17=ST330 Rumble Force Stick (USB)  
06A3:FF52=Cyborg 3D Rumble Force Joystick  
06A3:FFB5=Cyborg Evo Force Joystick  
06A4=Xiamen Doowell Electron  
06A5=Divio  
06A5:0000=Typhoon Webcam 100k [nw8000]  
06A5:D001=ProLink DS3303u WebCam  
06A5:D800=Chicony TwinkleCam  
06A5:D820=Wize Media 1000  
06A7=MicroStore  
06A8=Topaz Systems  
06A8:0042=SignatureGem 1X5 Pad  
06A8:0043=SignatureGem 1X5-HID Pad  
06A9=Westell  
06A9:0005=WireSpeed Dual Connect Modem  
06A9:0006=WireSpeed Dual Connect Modem  
06A9:000A=WireSpeed Dual Connect Modem  
06A9:000B=WireSpeed Dual Connect Modem



06A9:000E=802.11g Adapter  
06AA=Sysgration  
06AC=Fujitsu Laboratories of America  
06AD=Greatland Electronics Taiwan  
06AE=Professional Multimedia Testing Centre  
06AF=Harting  
06B8=Pixela  
06B9=Alcatel Telecom  
06B9:0120=SpeedTouch 120g Wireless USB Adapter  
06B9:0121=SpeedTouch 121g Wireless Dongle  
06B9:2001=SPEED TOUCH Card  
06B9:4061=SpeedTouch ADSL Modem  
06B9:4061:0001=SpeedTouch ADSL Modem  
06B9:4061:0200=SpeedTouch 330 ADSL Modem  
06B9:4061:0300=SpeedTouch 500 Series  
06B9:4061:0400=SpeedTouch 330 ADSL Modem  
06B9:4062=Thomson ST Remote NDIS Device  
06B9:A5A5=DynaMiTe Modem  
06BA=Smooth Cord & Connector  
06BB=EDA  
06BC=Oki Data  
06BC:000B=Okipage 14ex Printer  
06BC:00A9=OKI ES1624MFP  
06BC:00AA=OKI C5510MFP  
06BC:00C3=OKI C5540MFP  
06BC:00C4=OKI ES1624MFP  
06BC:00C5=OKI C5540MFP  
06BC:00C7=OKI C5540MFP  
06BC:00D3=OKI C5510MFP  
06BC:011C=OKI C5550MFP  
06BC:011D=OKI C5550MFP  
06BC:011E=OKI C5550MFP  
06BC:011F=OKI ES2032MFP  
06BC:0120=OKI CX2032MFP  
06BC:0200=OKI MC560  
06BC:0201=OKI MC560  
06BC:0202=OKI CX2033MFP  
06BC:0203=OKI ES5460MFP  
06BC:0A91=B2500MFP (printer+scanner)  
06BC:3801=B6100 Laser Printer  
06BD=AGFA-Gevaert NV  
06BD:0001=Agfa SnapScan 1212U  
06BD:0002=Agfa SnapScan 1236U  
06BD:0100=SnapScan Touch  
06BD:0101=SNAPSCAN ELITE  
06BD:0200=ScanMaker 8700  
06BD:02BF=Agfa DuoScan f40  
06BD:0400=CL30  
06BD:0401=Iomega USB Mass Storage Class Driver  
06BD:0403=ePhoto CL18 Camera  
06BD:0404=ePhoto CL20 Camera  
06BD:2061=Agfa SnapScan 1212U  
06BD:208D=Agfa SnapScan e40  
06BD:208F=Agfa SnapScan e50  
06BD:2091=Agfa SnapScan e20  
06BD:2093=Agfa SnapScan e10  
06BD:2095=Agfa SnapScan e25  
06BD:2097=Agfa SnapScan e26  
06BD:20FD=Agfa SnapScan e52  
06BD:20FF=Agfa SnapScan e42

06BE=AME Optimedia Technology  
06BE:0800=Optimedia Camera  
06BE:1005=Dazzle DPVM! (1005)  
06BE:D001=P35U Camera Capture  
06BF=Leoco  
06C2=Phidgets  
06C2:0030=PhidgetRFID  
06C2:0038=4-Motor PhidgetServo v3.0  
06C2:0039=1-Motor PhidgetServo v3.0  
06C2:003A=8-Motor PhidgetAdvancedServo  
06C2:0040=PhidgetInterface Kit 0-0-4  
06C2:0044=PhidgetInterface Kit 0-16-16  
06C2:0045=PhidgetInterface Kit 8-8-8  
06C2:0048=PhidgetStepper (Under Development)  
06C2:0049=PhidgetTextLED Ver 1.0  
06C2:004A=PhidgetLED Ver 1.0  
06C2:004B=PhidgetEncoder Ver 1.0  
06C2:0051=PhidgetInterface Kit 0-5-7 (Custom)  
06C2:0052=PhidgetTextLCD  
06C2:0053=PhidgetInterfaceKit 0-8-8  
06C2:0058=PhidgetMotorControl Ver 1.0  
06C2:0070=PhidgetTemperatureSensor Ver 1.0  
06C2:0071=PhidgetAccelerometer Ver 1.0  
06C2:0072=PhidgetWeightSensor Ver 1.0  
06C2:0073=PhidgetHumiditySensor  
06C2:0074=PhidgetPHSensor  
06C2:0075=PhidgetGyroscope  
06C4=Bizlink International  
06C5=Hagenuk, GmbH  
06C6=Infowave Software  
06C8=SIIG  
06C9=Taxan (Europe)  
06C9:0005=Monitor Control  
06C9:0007=Monitor Control  
06C9:0009=Monitor Control  
06CA=Newer Technology  
06CB=Synaptics  
06CB:0001=Synaptics USB TouchPad  
06CB:0002=Synaptics Integrated USB TouchPad  
06CB:0003=Synaptics cPad  
06CB:0005=Synaptics Touchpad/FPS  
06CB:0006=Synaptics TouchScreen  
06CB:0007=Synaptics USB Styk  
06CB:0008=Synaptics USB WheelPad  
06CB:0009=Synaptics Composite USB TouchPad  
06CB:0009:01=Synaptics Composite USB TouchStyk  
06CB:000E=Synaptics USB HID Device  
06CB:0010=Synaptics Composite USB Human Interface Device  
06CB:0010:01=Synaptics Wireless TouchPad  
06CB:0013=Synaptics DisplayPad  
06CC=Terayon Communication Systems  
06CC:0101=Cable Modem  
06CC:0102=Cable Modem  
06CC:0103=Cable Modem  
06CC:0104=Cable Modem  
06CC:0304=Cable Modem  
06CD=Keyspan  
06CD:0101=USA-28 PDA [preenum]  
06CD:0102=USA-28X PDA [preenum]  
06CD:0103=USA-19 PDA [preenum]

06CD:0104=PDA [prerenum]  
06CD:0105=USA-18X PDA [preenum]  
06CD:0106=USA-19W PDA [preenum]  
06CD:0107=Keyspan PDA Adaptor (USA19)  
06CD:0108=USA-19W PDA  
06CD:0109=Keyspan USB Preloader (USA49W)  
06CD:010A=Keyspan USB 4-Port Serial Adapter (USA49W)  
06CD:010B=USA-19Q PDA  
06CD:010C=Keyspan PDA Adaptor (USA19QI)  
06CD:010D=Keyspan USB Preloader (USA19Q)  
06CD:010E=Keyspan PDA Adaptor (USA19Q)  
06CD:010F=USA-28 PDA  
06CD:0110=USA-28X PDA  
06CD:0111=USA-18 serial Adapter  
06CD:0112=USA-18X PDA  
06CD:0113=USA-28Xb PDA [no firmware]  
06CD:0114=USA-28X PDA  
06CD:0115=USA-28Xa PDA  
06CD:0116=USA-18XA serial Adapter (no firmware)  
06CD:0117=USA-18XA serial Adapter  
06CD:0118=USA-19QW PDA  
06CD:0119=USA-19QW PDA  
06CD:011A=Keyspan USB Preloader (USA49WLC)  
06CD:011B=Keyspan MPR Serial Preloader (MPRQI)  
06CD:011C=Keyspan MPR Serial (MPRQI)  
06CD:011D=Keyspan MPR Serial Preloader (MPRQ)  
06CD:011E=Keyspan MPR Serial (MPRQ)  
06CD:0121=USA-19hs serial adapter  
06CD:012A=USA-49Wlc serial adapter  
06CD:0201=Digital Media Remote  
06CD:0202=UIA-11 remote control  
06CF=SpheronVR AG  
06CF:1010=PanoCam 10  
06CF:1012=PanoCam 12/12X  
06D0=LapLink  
06D0:0622=LapLink Gold USB-USB Bridge [net1080]  
06D1=Daewoo Electronics  
06D3=Mitsubishi Electric  
06D3:0380=CP8000D Port  
06D3:0381=CP770D Port  
06D3:0385=CP900D Port  
06D3:0387=CP980D Port  
06D3:038B=CP3020D Port  
06D3:038C=CP900DW(ID) Port  
06D3:0393=CP9500D/DW Port  
06D3:0394=CP9000D/DW Port  
06D3:03A1=CP9550D/DW Port  
06D4=Cisco Systems  
06D5=Toshiba  
06D5:4000=Toshiba USB 109 Japanese Keyboard  
06D6=Aashima Technology B.V.  
06D6:0025=Gamepad  
06D6:0026=Predator TH 400 Gamepad  
06D6:002D=Trust PowerC@m 350FT  
06D6:002E=Trust PowerC@m 350FS  
06D6:0030=Trust 710 LCD POWERC@m ZOOM - MSD  
06D6:0031=Trust 610/710 LCD POWERC@m ZOOM  
06D6:003A=Trust PowerC@m 770Z  
06D6:003B=Trust PowerC@m 770Z (webcam mode)  
06D6:003C=Trust 910z PowerC@m

06D6:003F=Trust 735S POWERC@M ZOOM, WDM Video Capture  
06D6:003F:01=Trust 735S POWERC@M ZOOM, WDM DSC Bulk Driver  
06D6:0050=Trust 738AV LCD PV Digital Camera  
06D6:0062=TRUST 782AV LCD P. V. Video Capture  
06D6:0066=TRUST Digital PCTV and Movie Editor  
06D6:0067=Trust 350FS POWERC@M FLASH  
06D6:006B=TRUST AUDIO VIDEO EDITOR  
06D7=Network Computing Devices (NCD)  
06D8=Technical Marketing Research  
06DA=Phoenixtec Power  
06DA:0002=UPS  
06DA:0003=1300VA UPS  
06DB=Paradyne  
06DC=Foxlink Image Technology  
06DC:0012=Scan 1200c Scanner  
06DC:0014=Prolink Winscan Pro 2448U  
06DE=Heisei Electronics  
06E0=Multi-Tech Systems  
06E0:F101=MT5634ZBA MultiModem 56k Intl.  
06E0:F103=MT5634MU MultiMobileUSB  
06E0:F104=MultiTech MT5634ZBA-USB 56K Modem  
06E0:F107=MT5634ZBA-USB-V92 MultiModemUSB  
06E1=ADS Technologies  
06E1:0008=ADS USB-Ethernet Adapter  
06E1:0009=ADS USB-Ethernet Adapter  
06E1:0833=Mass Storage Device  
06E1:A155=FM Radio Receiver/Instant FM Music (RDX-155-EF)  
06E1:A160=Instant Video-To-Go RDX-160 (no firmware)  
06E1:A161=Instant Video-To-Go RDX-160  
06E1:A190=Instand VCD Usb Capture  
06E1:A191=Instant VideoXpress  
06E1:A333=DVB-T USB2.0 adapter firmware loader  
06E1:A334=DVB-T USB adapter  
06E1:A334:01=Infrared Receiver  
06E1:A337=Mini DigitalTV  
06E1:A701=ADS DVD Xpress  
06E1:B337=Mini DigitalTV  
06E1:B701=ADS DVD Xpress B  
06E4=Alcatel Microelectronics  
06E6=Tiger Jet Network  
06E6:0200=Internet Phone  
06E6:0201=Internet Phone  
06E6:0202=Composite Device  
06E6:0203=Internet Phone  
06E6:0210=Composite Device  
06E6:0211=Internet Phone  
06E6:0212=Internet Phone  
06E6:031C=Internet Phone  
06E6:031D=Internet Phone  
06E6:031E=Internet Phone  
06E6:3200=Composite Device  
06E6:3201=Internet Phone  
06E6:3202=Composite Device  
06E6:3203=Composite Device  
06E6:7200=Composite Device  
06E6:7210=Composite Device  
06E6:7250=Composite Device  
06E6:825C=Internet Phone  
06E6:831C=Internet Phone  
06E6:831D=Composite Device

06E6:831E=Composite Device  
06E6:B200=Composite Device  
06E6:B201=Composite Device  
06E6:B202=Internet Phone  
06E6:B210=Internet Phone  
06E6:B211=Composite Device  
06E6:B212=Composite Device  
06E6:B250=Composite Device  
06E6:B251=Internet Phone  
06E6:B252=Internet Phone  
06E6:C200=Internet Phone  
06E6:C201=Internet Phone  
06E6:C202=Composite Device  
06E6:C203=Internet Phone  
06E6:C210=Personal PhoneGateway  
06E6:C211=Personal PhoneGateway  
06E6:C212=Personal PhoneGateway  
06E6:C213=PPG Device  
06E6:C25C=Composite Device  
06E6:C290=PPG Device  
06E6:C291=PPG Device  
06E6:C292=PPG Device  
06E6:C293=Personal PhoneGateway  
06E6:C31C=Composite Device  
06E6:C39C=Personal PhoneGateway  
06E6:C39D=PPG Device  
06E6:C39E=PPG Device  
06E6:C39F=PPG Device  
06E6:C700=Internet Phone  
06E6:C701=Internet Phone  
06E6:C702=Composite Device  
06E6:C703=Internet Phone  
06E6:C710=VoIP Combo Device  
06E6:C711=VoIP Combo  
06E6:C712=VoIP Combo Device  
06E6:C713=VoIP Combo Device  
06E6:CF00=Composite Device  
06E6:CF01=Internet Phone  
06E6:CF02=Internet Phone  
06E6:CF03=Composite Device  
06E6:D210=Personal PhoneGateway  
06E6:D211=PPG Device  
06E6:D212=PPG Device  
06E6:D213=Personal PhoneGateway  
06E6:D700=Composite Device  
06E6:D701=Composite Device  
06E6:D702=Internet Phone  
06E6:D703=Composite Device  
06E6:D710=VoIP Combo  
06E6:D711=VoIP Combo Device  
06E6:D712=VoIP Combo  
06E6:D713=VoIP Combo  
06E6:DF00=Composite Device  
06E6:DF01=Composite Device  
06E6:DF02=Internet Phone  
06E6:DF03=Internet Phone  
06E6:F200=Internet Phone  
06E6:F201=Internet Phone  
06E6:F202=Composite Device  
06E6:F203=Composite Device

06E6:F210=Internet Phone  
06E6:F250=Composite Device  
06E6:F252=Internet Phone  
06E6:F310=Internet Phone  
06E6:F350=Composite Device  
06EA=Sirius Technologies  
06EA:0001=NetCom Roadster II 56k  
06EA:0002=Roadster II 56k  
06EB=PC Expert Tech.  
06EF=I.A.C. Geometrische Ingenieurs B.V.  
06F0=T.N.C Industrial  
06F0:DE01=DualCam Video Camera  
06F0:DE02=DualCam Still Camera  
06F1=Opcode Systems  
06F1:A011=Opcode SonicPort  
06F1:A021=Opcode SonicPort Optical  
06F2=Emine Technology Company  
06F2:0011=USB KVM Switch Keyboard  
06F2:0011:01=USB KVM Switch Mouse  
06F6=Wintrend Technology  
06F7=Wailly Technology  
06F7:0003=USB->Din 4 Adaptor  
06F8=Guillemot  
06F8:0002=Guillemot Jet Leader USB Joystick  
06F8:1000=C-Media USB Sound Device  
06F8:1000:03=USB Human Interface Device  
06F8:3002=Hercules Blog Webcam  
06F8:3004=Hercules Classic Silver  
06F8:3005=Hercules Dualpix Exchange  
06F8:3007=Hercules Dualpix Chat and Show  
06F8:A300=Dual Analog Leader GamePad  
06F8:B000=Hercules DJ Console  
06F8:C000=Hercules Muse Pocket  
06F8:D002=Hercules DJ Console  
06F8:E000=HWGUSB2-54 WLAN  
06F8:E010=HWGUSB2-54-LB  
06F8:E020=HWGUSB2-54V2-AP  
06F8:E031=Hercules Wireless N Mini USB Key  
06F8:E032=HWGUm-54 [Hercules Wireless G Ultra Mini Key]  
06F8:E033=Hercules Wireless N Pico USB  
06F8:E034=Wireless N LB USB  
06F9=ASYST electronic d.o.o.  
06FA=HSD S.r.L  
06FC=Motorola Semiconductor Products Sector  
06FC:0000=DFR-400 USB Fingerprint Reader  
06FD=Boston Acoustics  
06FD:0101=Boston USB Audio Device  
06FD:0102=Boston USB Audio Device  
06FD:0201=Boston 2-piece USB Audio Device  
06FE=Gallant Computer  
0701=Supercomal Wire & Cable SDN. BHD.  
0703=Bvtech Industry  
0705=NKK  
0706=Ariel  
0707=SMC  
0707:0100=2202 Ethernet [klsi]  
0707:0200=EZ Connect USB to Ethernet Converter  
0707:0201=EZ Connect USB to Dual Speed Ethernet Converter  
0707:0201:0101=EZ Connect USB to Dual Speed Ethernet SMC2206USB/ETH  
0707:EE04=SMCWUSB32 802.11b Wireless LAN USB Card

0707:EE06=EZ-Connect 802.11g Adapter  
0707:EE13=EZ-Connect 802.11g Adapter  
0708=Putercom  
0708:047E=USB-1284 BRIDGE  
0709=Silicon Systems  
070A=Oki Electric Industry  
070A:4002=OKI Bluetooth Device  
070A:4003=OKI Bluetooth Device  
070D=Comoss Electronic  
070E=Excel Cell Electronic  
0710=Connect Tech  
0710:0001=WhiteHEAT USB (Boot Loader)  
0710:0001:0041=WhiteHEAT USB Rev A (Boot Loader)  
0710:0001:0042=WhiteHEAT USB Rev B (Boot Loader)  
0710:0001:0043=WhiteHEAT USB Rev C (Boot Loader)  
0710:0001:0044=WhiteHEAT USB Rev D (Boot Loader)  
0710:8001=WhiteHEAT USB 4-Port RS-232  
0710:8001:0041=WhiteHEAT USB 4-Port RS-232 Rev A  
0710:8001:0042=WhiteHEAT USB 4-Port RS-232 Rev B  
0710:8001:0043=WhiteHEAT USB 4-Port RS-232 Rev C  
0710:8001:0044=WhiteHEAT USB 4-Port RS-232 Rev D  
0711=Magic Control Technology  
0711:0100=Hub  
0711:0180=IRXpress Infrared Device  
0711:0181=IRXpress Infrared Device  
0711:0200=BAY-3U1S1P Serial Port  
0711:0210=MCT1S Serial Port  
0711:0230=PA090 Serial Port  
0711:0231=PS/2 Mouse Port  
0711:0232=Serial On USB Port  
0711:0240=PS/2 to USB Converter  
0711:0300=BAY-3U1S1P Parallel Port  
0711:0302=Parallel Port  
0711:0900=SVGA Adapter  
0711:0903=USB 2.0 VGA DEVICE-2  
0711:0904=USB 2.0 VGA DEVICE-3  
0711:0905=USB 2.0 VGA DEVICE-4  
0711:0906=USB 2.0 VGA DEVICE-5  
0711:0907=USB 2.0 VGA DEVICE-6  
0711:0950=USB 2.0 Graphics Device-1  
0711:0951=USB 2.0 Graphics Device-2  
0711:0952=USB 2.0 Graphics Device-3  
0711:0953=USB 2.0 Graphics Device-4  
0711:0954=USB 2.0 Graphics Device-5  
0711:0955=USB 2.0 Graphics Device-6  
0711:5001=Trigger UV-002BD[Startech USBVGAE]  
0711:5100=Magic Control Technology Corp. (USB2VGA dongle)  
0713=Interval Research  
0714=NewMotion  
0714:0003=ADB to USB convertor  
0717=ZNK  
0718=Imation  
0718:0002=Imation SuperDisk USB 120MB  
0718:0003=Imation SuperDisk USB 120MB (Authenticated)  
0718:0060=Flash Drive  
0718:0061=Flash Drive  
0718:0062=Flash Drive  
0718:0063=Swivel Flash Drive  
0718:0064=Flash Drive  
0718:0065=Flash Drive

0718:0066=Flash Drive  
0718:0067=Flash Drive  
0718:0068=Flash Drive  
0718:0084=USB Flash Drive Mini  
0718:0582=Revo Flash Drive  
0718:B004=USB Imation Card Reader, Imation Corp.  
0718:D000=Disk Stakka CD Carousel  
0719=Tremon Enterprises  
071B=Domain Technologies  
071B:0002=DTI-56362-USB Digital Interface Unit  
071B:0101=Audio4-USB DSP Data Acquisition Unit  
071B:0201=Audio4-5410 DSP Data Acquisition Unit  
071B:0301=SB-USB JTAG Emulator  
071B:3203=Rockchip Media Player  
071B:32BB=Music Mediatouch  
071C=Xionics Document Technologies  
071D=Eicon  
071D:1000=DIVA 2.01 S/T  
071D:1003=Eicon Diva ISDN USB 2.0  
071D:2000=Teledat Surf  
071D:AC81=Eicon Networks USB ADSL Loader  
071D:AC82=Eicon Networks USB ADSL WAN Modem  
071D:CC81=Eicon Networks USB ADSL WAN Modem  
071E=Ariston Technologies  
0723=Centillium Communications  
0723:0002=Palladia 300/400 Adsl Modem  
0726=Vanguard International Semiconductor-America  
0729=Amitm  
0729:1000=USC-1000 Serial Port  
072E=Sunix  
072F=ACS  
072F:0001=ACR20U SmartCard Reader  
072F:0008=ACR 80 Smart Card Reader  
072F:1000=PLDT Drive  
072F:1000:01=PLDT USB Drive  
072F:1001=PLDT USB Drive  
072F:1100:01=ACR100 Smart Card Reader  
072F:1101=ACR100 Smart Card Reader  
072F:8002=AET63 BioTRUSTKey  
072F:8003=ACR120  
072F:8103=ACR120  
072F:9000=ACR38 Smart Card Reader  
072F:9007=ACR100 Smart Card Reader  
072F:90CC=ACR38 SmartCard Reader  
072F:90CF=ACR38 SAM Smart Card Reader  
072F:90D0=PertoSmart EMV - Card Reader  
0731=Susteen  
0731:0528=USB Cable DCU-11  
0732=Goldfull Electronics & Telecommunications  
0733=Intel  
0733:0101=Digital Video Camera  
0733:0110=VQ110  
0733:0401=Intel USB Video Camera III  
0733:0401:0100=Intel USB Video Camera III  
0733:0402=M318B Digital Video Camera  
0733:0430=Intel PC Camera Pro  
0733:0430:0100=Intel PC Camera Pro  
0733:0630=VQ630 Dual Mode Digital Camera(composite)  
0733:0630:01=VQ630 Dual Mode Digital Camera(Bulk)  
0733:0631=VQ680 4 in 1 Digital Camera(composite)



0733:0631:01=VQ680 4 in 1 Digital Camera(Bulk)  
0733:0780=Smart Cam Deluxe(composite)  
0733:1310=Epsilon 1.3/Jenoptik JD C1.3/UMAX AstraPix 470  
0733:1311=Digital Dream Epsilon 1.3  
0733:1314=Mercury 2.1MEG Deluxe Classic Cam  
0733:2152=Che-ez! H2O Waterproof Digital Camera  
0733:2211=Jenoptik  
0733:2221=Mercury Digital Pro 3.1p  
0733:3261=Concord 3045 spca536a Camera  
0733:3281=Cyberpix S550V  
0733:3350=ViewQuest Technologies, Inc. Digital Camera Jenoptiks JD3.3  
0734=Lasat Communications A/S  
0734:0001=560V Modem  
0734:0002=Lasat 560V USB Modem  
0734:0002:0100=Lasat 560V USB Modem  
0734:043A=DVS Audio  
0734:043B=3DeMon USB Capture  
0735=Asuscom Network  
0735:2100=ISDN Adapter (USB Active, DV)  
0735:2101=ISDN Adapter (USB Active, D)  
0735:6694=ISDN Adapter (USB Passive, D, W)  
0735:C541=ISDN TA 280  
0736=Lorom Industrial  
0738=Mad Catz  
0738:4507=XBox Device  
0738:4516=XBox Device  
0738:4520=XBox Device  
0738:4526=XBox Device  
0738:4536=XBox Device  
0738:4540=XBox Device  
0738:4556=XBox Device  
0738:4566=XBox Device  
0738:4576=XBox Device  
0738:4586=XBox Device  
0738:4588=XBox Device  
0738:8818=Street Fighter IV Arcade FightStick (PS3)  
073A=Chaplet Systems  
073A:2230=infrared dongle for remote  
073B=Suncom Technologies  
073C=Industrial Electronic Engineers  
073C:0305=Pole Display (PC305-3415 2 x 20 Line Display)  
073C:0322=Pole Display (PC322-3415 2 x 20 Line Display)  
073C:0324=Pole Display (LB324-USB 4 x 20 Line Display)  
073C:0330=Pole Display (P330-3415 2 x 20 Line Display)  
073C:0424=Pole Display (SP324-4415 4 x 20 Line Display)  
073C:0450=Pole Display (L450-USB Graphic Line Display)  
073C:0505=Pole Display (SPC505-3415 2 x 20 Line Display)  
073C:0522=Pole Display (SPC522-3415 2 x 20 Line Display)  
073C:0624=Pole Display (SP324-3415 4 x 20 Line Display)  
073D=Eutron S.p.a.  
073D:0005=Crypto Token  
073D:0007=CryptoIdentity CCID  
073D:0025=SmartKey 3  
073D:0C00=Pocket Reader  
073D:0D00=StarSign Bio Token 3.0 EU  
073E=NEC  
073E:0301=Game Pad  
0745=Syntech Information  
0746=ONKYO  
0746:5500=Onkyo SE-U55 Audio Device

0747=Labway  
0748=Strong Man Enterprise  
0749=EVER Electronics  
074A=Ming Fortune Industry  
074B=Polestar Tech.  
074C=C-C-C Group PLC  
074D=Micronas GmbH  
074D:3553=Composite USB-Device  
074D:3554=Composite USB-Device  
074D:3556=Composite USB-Device  
074E=Digital Stream  
074E:0001=PS/2 Adapter  
074E:0002=PS/2 Adapter  
0755=Aureal Semiconductor  
0757=Network Technologies  
075B=Sophisticated Circuits  
075B:0001=Kick-off! Watchdog  
075C=Ulan  
075D:0001=MicroDowell BBox UPS  
075D:0002=MicroDowell BBox UPS  
075E=ABIT  
0763=Midiman  
0763:0115=KeyRig 25  
0763:0117=Trigger Finger  
0763:0119=MidAir  
0763:0150=M-Audio Uno  
0763:0160=M-Audio 1x1  
0763:0192=M-Audio Keystation 88es  
0763:0193=ProKeys 88  
0763:0194=ProKeys 88sx  
0763:0195=Oxygen 8 v2  
0763:0196=Oxygen 49  
0763:0197=Oxygen 61  
0763:0198=Axiom 25  
0763:0199=Axiom 49  
0763:019A=Axiom 61  
0763:019B=KeyRig 49  
0763:019C=KeyStudio  
0763:1001=Midisport 2x2  
0763:1002=MidiSport 2x2  
0763:1003=MidiSport 2x2  
0763:1010=Midisport 1x1  
0763:1011=MidiSport 1x1  
0763:1014=M-Audio Keystation Loader  
0763:1015=M-Audio Keystation  
0763:1020=Midisport 4x4  
0763:1021=MidiSport 4x4  
0763:1030=Midisport 8x8  
0763:1031=MidiSport 8x8/s Loader  
0763:1033=MidiSport 8x8/s  
0763:1040=M-Audio MidiSport 2x4 Loader  
0763:1041=M-Audio MidiSport 2x4  
0763:1110=MidiSport 1x1  
0763:2001=M-Audio Quattro Legacy Driver  
0763:2001:03=M-Audio Quattro  
0763:2001:06=M-Audio Quattro Base Driver  
0763:2001:09=M-Audio USB Quattro Midi  
0763:2002=M Audio Duo  
0763:2002:03=M-Audio USB Duo ASIO  
0763:2003=M-Audio Audiophile DFU

0763:2003:01=M-Audio Audiophile  
0763:2003:06=M-Audio Audiophile USB Midi  
0763:2004=M-Audio MobilePre  
0763:2005=M-Audio Sonica  
0763:2006=M-Audio Transit  
0763:2007=M-Audio Sonica Theater  
0763:2008=M-Audio Ozone  
0763:200D=M-Audio OmniStudio  
0763:200D:03=M-Audio OmniStudio USB  
0763:200D:06=M-Audio OmniStudio USB Base Driver  
0763:200D:09=M-Audio USB Omni Midi  
0763:200F=M-Audio MobilePre  
0763:2010=M-Audio Fast Track  
0763:2012=M-Audio Fast Track Pro  
0763:2013=M-Audio JamLab  
0763:2015=M-Audio RunTime DFU  
0763:2016=M-Audio RunTime DFU  
0763:2019=M-Audio Ozone Academic  
0763:201A=M-Audio Micro  
0763:201B=M-Audio RunTime DFU  
0763:201D=M-Audio Producer  
0763:2024=M-Audio Fast Track MKII  
0763:2080=M-Audio RunTime DFU  
0763:2081=M-Audio RunTime DFU  
0763:2803=M-Audio Audiophile DFU  
0763:2804=M-Audio MobilePre DFU  
0763:2805=M-Audio Sonica DFU  
0763:2806=M-Audio Transit DFU  
0763:2815=M-Audio DFU  
0763:2816=M-Audio DFU  
0763:281B=M-Audio DFU  
0763:2880=M-Audio DFU  
0763:2881=M-Audio DFU  
0764=Cyber Power System  
0764:0005=CyberPower Battery Backup  
0764:0501=CyberPower Battery Backup  
0765=X-Rite  
0765:D094=X-Rite DTP94 [Quato Silver Haze Pro]  
0766=Jess-Link Products  
0766:0204=TopSpeed Cyberlink Remote Control  
0767=Tokheim  
0768=Camtel Technology  
0768:0006=Camtel Technology USB TV Genie Pro FM Model TVB330  
0768:0023=eHome Infrared Receiver (USBCIR)  
0769=Surecom Technology  
0769:11F2=EP-9001-g 802.11g 54M WLAN Adapter  
0769:11F2:0100=SURECOM EP-9001-g 802.11g 54M WLAN USB Adapter  
0769:11F3=SURECOM 802.11g WLAN USB Adapter  
0769:11F7=SURECOM 802.11g 54M WLAN USB Adapter  
0769:31F3=802.11g 54M Wireless LAN USB Adapter  
076A=Smart Technology Enablers  
076B=OMNIKEY  
076B:0596=Omnikey AG CardMan 2020 USB Smart Card Reader  
076B:1021=CardMan 1021  
076B:1221=CardMan 1221  
076B:1784=Omnikey AG CardMan 6020 USB Smart Card Reader  
076B:1BD0=CardMan 7120 Fingerprint  
076B:1BD1=CardMan 7120 Fingerprint  
076B:3010=CardMan 3020  
076B:3021=CardMan 3x21

076B:3610=CardMan 3620  
076B:3620=CardMan 3020  
076B:3621=CardMan 3621  
076B:3821=CardMan 3821  
076B:4321=CardMan 4321  
076B:5120=CardMan 5x21  
076B:5121=CardMan 5x21  
076B:5124=CardMan 5x25  
076B:5125=CardMan 5x25  
076B:5320=CardMan 5x21  
076B:5321=CardMan 5x21  
076B:6622=CardMan 6121  
076B:7021=CardMan 7x21  
076B:7121=CardMan 7120 Fingerprint with EEPROM  
076B:8630=CardMan 8630  
076B:9621:01=CardMan 9621  
076B:A011=CCID Smart Card Reader Keyboard  
076B:A011:01=USB CCID Smart Card Reader Keyboard  
076B:A012:01=USB CCID Smart Card Reader Keyboard  
076B:A021=USB CCID Smart Card Reader  
076B:A022=CardMan Smart@Link  
076B:C000=CardMan 3x21 CS  
076B:C001=CardMan 5121 CS  
076B:C100=CardMan 5x21  
076B:C101=CardMan 5x21  
076B:C104=CardMan 5x25  
076B:C105=CardMan 5x25  
076C=Partner Tech  
076D=Denso  
076E=Kuan Tech Enterprise  
076F=Jhen Vei Electronic  
0770=Welch Allyn  
0770:0450=Welch Allyn Spot Vital Signs LXi  
0770:1100=Welch Allyn Platform VSM  
0770:1110=Welch Allyn CP50  
0770:1115=Welch Allyn ProBP 3400  
0771=Observator Instruments BV  
0771:4455=OMC45III  
0771:AE0F=OMC45III  
0772=Your data Our Care  
0774=AmTRAN Technology  
0775=Longshine Electronics  
0776=Inalways  
0777=Comda Enterprise  
0778=Volex  
0779=Fairchild Semiconductor  
077A=Sankyo Seiki  
077B=Linksys  
077B:08B7=Linksys WCG200 Wireless-G Cable Gateway(B)  
077B:08BE=Linksys BEFCMU10 ver. 4 Cable Modem  
077B:08C1=Linksys WCG200 ver. 2 Wireless-G Cable Gateway  
077B:2219=WUSB11 V2.6 802.11b Adapter  
077B:2226=Linksys USB 2.0 10/100 Adapter  
077B:2227=Network Everywhere NWU11B  
077C=Forward Electronics  
077C:0005=NEC Keyboard  
077D=Griffin Technology  
077D:0223=IMic Audio In/Out  
077D:0405=iMate, ADB Adapter  
077D:0410=PowerMate

077D:041A=PowerWave  
077D:04AA=SoundKnob  
077D:07AF=iMic  
077D:1016=AirClick  
077D:627A=Radio SHARK  
077F=Well Excellent & Most  
0780=Sagem Monotel GmbH  
0780:1202=ORGA 900 Smart Card Terminal Virtual Com Port  
0780:1302=ORGA 6000 Smart Card Terminal Virtual Com Port  
0780:1303=ORGA 6000 Smart Card Terminal USB RNDIS  
0780:DF55=ORGA 900/6000 Smart Card Terminal DFU  
0781=SanDisk  
0781:0001=SanDisk USB ImageMate  
0781:0002=SanDisk USB ImageMate (Authenticated)  
0781:0005=SDDR-05b (CF II) ImageMate CompactFlash Reader  
0781:0100=SanDisk USB ImageMate Multimedia Card Reader  
0781:0200=SDDR-09 (SSFDC) ImageMate SmartMedia Reader [eusb]  
0781:0400=SecureMate SD/MMC Reader  
0781:0621=SDDR-86 Imagemate 6-in-1 Reader  
0781:0720=Sansa C200 series in recovery mode  
0781:0729=Sansa E200 series in recovery mode  
0781:0810=Redstone Digital Video Recorder (Emulated)  
0781:0830=ImageMate CF/MMC/SD Reader  
0781:1234=Cruzer Mini USB Flash Drive  
0781:5150=Cruzer Mini USB-Flash-Drive  
0781:5151=Cruzer Micro USB-Flash-Drive  
0781:5153=Cruzer USB-Flash-Drive  
0781:5402=U3 Cruzer Micro  
0781:5406=Cruzer Micro 4GB Flash Drive  
0781:5408=Cruzer Titanium U3  
0781:540E=Cruzer Contour Flash Drive  
0781:5530=Cruzer U3 4gb SDCZ36  
0781:5567=Cruzer Blade  
0781:5E10=Encrypted  
0781:6100=Ultra II SD Plus 2GB  
0781:7100=Cruzer Mini USB Flash Disk  
0781:7101=Cruzer Mini  
0781:7102=Cruzer Mini  
0781:7103=Cruzer Mini  
0781:7104=Cruzer Mini  
0781:7105=Cruzer Mini  
0781:7106=Cruzer Mini  
0781:7112=Cruzer Mini  
0781:7113=Cruzer Mini  
0781:7114=Cruzer Mini  
0781:7115=Cruzer Mini  
0781:7301=Sansa e100 series (mtp)  
0781:7302=Sansa e100 series (msc)  
0781:7400=Sansa M200 series (msc)  
0781:7401=Sansa M200 series (mtp)  
0781:7420=Sansa E200 series (mtp)  
0781:7421=Sansa E200 series  
0781:7422=Sansa E200 series v2 (mtp)  
0781:7423=Sansa E200 series v2 (msc)  
0781:7430=Sansa M200 series  
0781:7431=Sansa M200v4 (msc)  
0781:7432=Sansa Clip (mtp)  
0781:7433=Sansa Clip (msc)  
0781:7434=Sansa Clip V2 (mtp)  
0781:7435=Sansa Clip V2 (msc)

0781:7450=Sansa C250  
0781:7451=Sansa C240  
0781:7460=Sansa Express  
0781:7480=Sansa Connect  
0781:7481=Sansa Connect (in recovery mode)  
0781:74B0=Sansa View (msc)  
0781:74B1=Sansa View  
0781:74C0=Sansa Fuze (mtp)  
0781:74C1=Sansa Fuze (msc)  
0781:74C2=Sansa Fuze V2 (mtp)  
0781:74C3=Sansa Fuze V2 (msc)  
0781:74D0=Sansa Clip+  
0781:74D1=Sansa Clip+ (msc)  
0781:8181=Cruzer Mini  
0781:8183=Hi-Speed Mass Storage Device  
0781:8185=Cruzer Mini  
0781:8888=Cruzer Mini  
0781:8889=SDDR-88 Imagemate 8-in-1 Reader  
0781:8919=Card Reader  
0781:8989=ImageMate 12-in-1 Reader  
0781:9191=ImageMate CF  
0781:9219=Card Reader  
0781:9292=ImageMate CF Reader/Writer  
0781:9393=ImageMate SD-MMC  
0781:9595=ImageMate xD-SM  
0781:9797=ImageMate MS-PRO  
0781:9919=Card Reader  
0781:9999=SDDR-99 5-in-1 Reader  
0781:A7E8=SDDR-113 MicroMate SDHC Reader  
0781:B2B3=SDDR-103 MobileMate SD+ Reader  
0781:B4B5=SDDR-89 V4 ImageMate 12-in-1 Reader  
0782=Trackerball  
0783=C3PO  
0783:0003=LTC31 SmartCard Reader  
0783:0006=C3PO USB Smart Card Reader  
0783:0007:01=C3PO USB Smart Card Reader  
0783:0009=KBR36  
0783:0010=LTC32  
0784=Vivitar  
0784:0100=Vivicam 2655  
0784:1310=Vivicam 3305  
0784:1688=Vivicam 3665  
0784:1689=Gateway DC-M42/Labtec DC-505/Vivitar Vivicam 3705  
0784:2620=AOL Photocam Plus  
0784:2888=Polaroid DC700  
0784:3330=Nytec ND-3200 Camera  
0784:4300=Traveler D1  
0784:5260=Werlisa Sport PX 100 / JVC GC-A33 Camera  
0784:5300=Pretec dc530  
0785=NTT-ME  
0785:0001=MN128mini-V ISDN TA  
0785:0003=MN128mini-J USB  
0785:0003:0100=MN128mini-J USB  
0789=Logitech  
0789:0026=LHD USB Device  
0789:0033=DVD Multi-plus unit LDR-H443SU2  
0789:0063=LDR USB Device  
0789:0064=LDR-R Device  
0789:00B3=DVD Multi-plus unit LDR-H443U2  
0789:010C=Realtek RTL8187 Wireless 802.11g 54Mbps Network Adapter

0789:010C:0100=Realtek RTL8187 Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
0789:0162=Logitech LAN-WN22/U2 Wireless LAN Adapter  
0789:0163=Logitech LAN-WN12/U2 Wireless LAN Adapter  
0789:0164=Logitech LAN-W150/U2M Wireless LAN Adapter  
0789:0166=Logitech LAN-W300N/U2 LAN Adapter  
0789:0167=Logitech LAN-W150N/U2 Wireless LAN Adapter  
0789:0168=Logitech LAN-W150N/U2 LAN Adapter  
0789:0169=Logitech LAN-W300N/U2S LAN Adapter  
078B=Happ Controls  
078B:0010=Driving UGCI  
078B:0020=Flying UGCI  
078B:0030=Fighting UGCI  
078C=GTCO/CalComp  
078C:0090=Tablet Adapter  
078C:0100=Tablet Adapter  
078C:0200=Tablet Adapter  
078C:0300=Tablet Adapter  
078C:0400=Digitizer (Whiteboard)  
078E=Brincom  
0790=Pro-Image Manufacturing  
0791=Copartner Wire and Cable  
0792=Axis Communications AB  
0793=Wha Yu Industrial  
0794=ABL Electronics  
0795=RealChip  
0796=Certicom  
0797=Grandtech Semiconductor  
0797:6801=Flatbed Scanner  
0797:6802=InkJet Color Printer  
0797:8001=SmartCam  
0797:801A=Typhoon StyloCam  
0797:801C=Meade Binoculars/Camera  
0797:8901=ScanHex SX-35a  
0797:8909=ScanHex SX-35b  
0797:8911=ScanHex SX-35c  
0798=Optelec  
0798:0001=Braille Voyager  
0799=Altera  
0799:7651=Programming Unit  
079B=Sagem  
079B:0027=USB-Serial Controller  
079B:002F=Mobile  
079B:0030=Mobile Communication Device  
079B:0042=Mobile  
079B:004A=Wi-Fi Wireless LAN USB Adapter  
079B:004B=SAGEM Wi-Fi 11g USB adapter  
079B:0056=Agfa AP1100 Photo Printer  
079B:005D=my401C mobile phone  
079B:0062=Sagem Wi-Fi 802.11g USB Adapter  
079B:0078=Laser Pro Monochrome MFP  
079D=Alfadata  
079D:0201=GamePort Adapter  
079F=VMETRO  
079F:0006=VMETRO Vanguard (on USB)  
07A1=Digicom S.p.A.  
07A1:D952=Palladio USB V.92 Modem  
07A2=National Technical Systems  
07A3=ONNTO  
07A4=Be  
07A6=ADMtek

07A6:07C2=AN986A Ethernet  
07A6:0986=ADMtek AN986 USB To Fast Ethernet Adapter  
07A6:8266=Infineon WildCard-USB Wireless LAN Adapter  
07A6:8511=ADMtek ADM8511 USB To Fast Ethernet Adapter  
07A6:8513=AN8513 Ethernet  
07A6:8515=AN8515 Ethernet  
07AA=corega K.K.  
07AA:0001=Ether USB-T Ethernet [klsi]  
07AA:0004=FEther USB-TX Ethernet [pegasus]  
07AA:000C=WirelessLAN USB-11  
07AA:000D=FEther USB-TXS  
07AA:0011=Wireless LAN USB-11 mini  
07AA:0012=Stick-11 802.11b Adapter  
07AA:0017=corega FEther USB2-TX  
07AA:0018=Wireless LAN USB-11 mini 2  
07AA:001A=ULUSB-11 Key  
07AA:001C=CG-WLUSB2GT  
07AA:002E=CG-WLUSB2GPX  
07AA:002F=CG-WLUSB2GNL  
07AA:003C=CG-WLUSB2GNL  
07AA:003F=CG-WLUSB300AGN  
07AA:0041=CG-WLUSB300GNS  
07AA:0042=CG-WLUSB300GNM  
07AA:0043=CG-WLUSB300N  
07AA:0047=CG-WLUSBNM  
07AA:0051=CG-WLUSB300NM  
07AA:0056=Corega CG-WLUSB300NS  
07AA:7613=Stick-11 V2 802.11b Adapter  
07AA:9601=FEther USB-TXC  
07AB=Freecom Technologies  
07AB:FC01=IDE bridge  
07AB:FC02=Cable II USB-2  
07AB:FC03=USB2-IDE IDE bridge  
07AB:FC86=ToughDrivePro  
07AB:FCD6=Freecom HD Classic  
07AB:FCF6=DataBar 512 MB  
07AB:FCF8=Freecom Classic SL Network Drive  
07AB:FCFE=Hard Drive 80GB  
07AF=Microtech  
07AF:0004=SCSI-DB25 SCSI Bridge [shuttle]  
07AF:0005=SCSI-HD50 SCSI Bridge [shuttle]  
07AF:0006=CameraMate SmartMedia and CompactFlash Card Reader [eusb/shuttle]  
07AF:FC01=Freecom USB-IDE  
07B0=Trust Technologies  
07B0:0001=ISDN TA  
07B0:0002=USB ISDN TA128 Plus  
07B0:0003=USB ISDN TA128 Deluxe  
07B0:0005=Acer ISDN 128 Surf USB  
07B0:0006=Acer ISDN 128 Surf USB  
07B0:0007=USB ISDN TA  
07B0:0008=USB ISDN TA  
07B1=IMP  
07B2=Motorola BCS  
07B2:0100=Motorola SURFboard Voice over IP Cable Modem  
07B2:0900=Motorola SURFboard USB Gateway  
07B2:0950=Motorola SURFboard SBG950 USB Gateway  
07B2:1000=Motorola SURFboard SBG1000 USB Gateway  
07B2:4100=SB4100 Cable Modem  
07B2:4200=Motorola SurfBoard 4200 USB Cable Modem  
07B2:4210=Motorola SurfBoard 4210 USB Cable Modem



07B2:4220=SURFboard SB4220 Cable Modem  
07B2:4500=Motorola CG4500 Communications Gateway  
07B2:450B=Motorola CG4501 Communications Gateway  
07B2:450E=Motorola CG4500E Communications Gateway  
07B2:5100=Motorola SURFboard SB5100 USB Cable Modem  
07B2:5101=Motorola SURFboard SB5101 USB Cable Modem  
07B2:5120=Motorola SurfBoard SB5120 USB Cable Modem  
07B2:5121=Surfboard 5121 Cable Modem  
07B2:6001=Phone for Windows Live Messenger  
07B2:7030=Wireless Adapter WU830G  
07B3=Plustek  
07B3:0001=OpticPro 1212U Scanner  
07B3:0003=Scanner  
07B3:0005=Plustek Scanner  
07B3:0007=Plustek Scanner  
07B3:000F=Plustek Scanner  
07B3:0010=OpticPro U12 Scanner  
07B3:0011=OpticPro U24 Scanner  
07B3:0012=Plustek Scanner  
07B3:0013=Plustek Scanner  
07B3:0014=Scanner  
07B3:0015=OpticPro U24 Scanner  
07B3:0016=Plustek Scanner  
07B3:0017=OpticPro UT12/16/24 Scanner  
07B3:0204=Scanner  
07B3:0400=OpticPro 1248U Scanner  
07B3:0401=OpticPro 1248U Scanner #2  
07B3:0403=OpticPro U16B Scanner  
07B3:0404=Scanner  
07B3:0405=A8 Namecard-s Controller  
07B3:0406=A8 Namecard-D Controller  
07B3:0410=Scanner  
07B3:0412=Scanner  
07B3:0413=OpticSlim 1200 Scanner  
07B3:0443=BCR Scanner  
07B3:0601=OpticPro ST24 Scanner  
07B3:0800=OpticPro ST48 Scanner  
07B3:0906=OpticBook 3600 Scanner  
07B3:0A01=3 Axis Composite Device  
07B3:0A06=TVcam VD100  
07B3:0B00=SmartPhoto F50  
07B3:0C03=OpticPro ST64+ Scanner  
07B3:0C04=Optic Film 7200i scanner  
07B3:0C0C=PL806 Scanner  
07B3:0C26=OpticBook 4600 Scanner  
07B3:0C2B=Mobile Office D428 Scanner  
07B4=Olympus Optical  
07B4:0100=Olympus Digital Camera  
07B4:0102=Camedia E-10/C-220 Camera  
07B4:0105=Camedia C-700/C-3040/C-4000 Zoom Camera  
07B4:0109=C-370Z/D-535Z/X-450  
07B4:010A=MAUSB-10 xD and SmartMedia Card Reader  
07B4:0112=MAUSB-100 xD Card Reader  
07B4:0113=Mju 500  
07B4:0114=C-350Z Camera  
07B4:0118=Mju Mini Digital/Mju Digital 500 Camera  
07B4:0184=P-S100 port  
07B4:0200=DSSUSB Device  
07B4:0201=DSSUSB1 Device  
07B4:0202=DSSUSBF Device

07B4:0203=Digital Voice Recorder DW-90  
07B4:0205=DM\_1USB Device  
07B4:0206=Digital Voice Recorder DS-330  
07B4:0207=Digital Voice Recorder & Camera W-10  
07B4:0209=Digital Voice Recorder DM-20  
07B4:020D=Digital Voice Recorder VN-240PC  
07B4:0244=Digital Voice Recorder VN-8500PC  
07B4:0280=m:robe 100  
07B5=Mega World International  
07B5:0017=USB Joystick  
07B5:0213=Thrustmaster Firestorm Digital 3 Gamepad  
07B5:0312=Gamepad  
07B5:9902=GamePad  
07B6=Marubun  
07B7=TIME Interconnect  
07B8=AboCom Systems  
07B8:110C=XX1  
07B8:1201=IEEE 802.11b Adapter  
07B8:200C=XX2  
07B8:2573=Wireless LAN Card  
07B8:2770=802.11n/b/g Mini Wireless LAN USB2.0 Adapter  
07B8:2870=802.11n/b/g Wireless LAN USB2.0 Adapter  
07B8:3070=802.11n/b/g Mini Wireless LAN USB2.0 Adapter  
07B8:3071=802.11n/b/g Mini Wireless LAN USB2.0 Adapter  
07B8:3072=802.11n/b/g Mini Wireless LAN USB2.0 Adapter  
07B8:3073=802.11n/b/g Mini Wireless LAN USB2.0 Adapter  
07B8:3074=802.11n/b/g Mini Wireless LAN USB2.0 Adapter  
07B8:4000=DU-E10 Ethernet [klsi]  
07B8:4002=DU-E100 Ethernet [pegasus]  
07B8:4003=1/10/100 Ethernet Adapter  
07B8:4004=XX4  
07B8:4007=XX5  
07B8:400B=XX6  
07B8:400C=XX7  
07B8:401A=RTL8151  
07B8:4102=USB 1.1 10/100M Fast Ethernet Adapter  
07B8:4104=XX9  
07B8:420A=UF200 Ethernet  
07B8:5301=GW-US54ZGL 802.11bg (zd1211rw)  
07B8:6001=XPC 802.11b/g Wireless Kit Driver  
07B8:8178=802.11n/b/g Mini Wireless LAN USB2.0 Adapter  
07B8:8188=802.11n/b/g 2cm Wireless LAN USB2.0 Adapter  
07B8:8189=802.11n/b/g Mini Wireless LAN USB2.0 Adapter  
07B8:A001=Wireless Network Adapter  
07B8:ABC1=DU-E10 Ethernet [pegasus]  
07B8:B000=BWU613  
07B8:B02A=AboCom Bluetooth Device  
07B8:B02B=BCM92045DG-Flash  
07B8:B02C=BCM92045DG-Flash  
07B8:B02D=BCM92045DG-Flash  
07B8:B02E=BCM92045DG-Flash  
07B8:B030=BCM92045DG-Flash  
07B8:B031=BCM92045DG-Flash  
07B8:B032=BCM92045DG-Flash  
07B8:B033=BCM92045DG-Flash  
07B8:B21A=802.11g Wireless Adapter  
07B8:B21B=Hawking HWU54DM Hi-Gain Wireless-G USB Adapter  
07B8:B21C=RT73 USB Wireless LAN Card  
07B8:B21D=802.11b/g Mini Wireless LAN USB 2.0 Adapter  
07B8:B21E=802.11b/g High Gain Wireless LAN USB Adapter

07B8:B21F=WUG2700 USB Wireless LAN Card  
07B8:D011=MP3 Player  
07B8:E001=Mass Storage Device  
07B8:E002=Mass Storage Device  
07B8:E003=Mass Storage Device  
07B8:E004=Mass Storage Device  
07B8:E005=Mass Storage Device  
07B8:E006=Mass Storage Device  
07B8:E007=Mass Storage Device  
07B8:E008=Mass Storage Device  
07B8:E009=Mass Storage Device  
07B8:E00A=Mass Storage Device  
07B8:E4F0=Card Reader Driver  
07B8:F101=Abocom DSB-560 USB V.90 56K Fax Modem  
07B8:FFFF=Bluetooth Devices  
07BC=Canon Computer Systems  
07BD=Webgear  
07BE=Veridicom  
07C0=Code Mercenaries Hard- und Software GmbH  
07C0:0139=KeyWarrior16  
07C0:1121=The Claw  
07C0:1500=IO-Warrior 40  
07C0:1501=IO-Warrior 24  
07C0:1502=IO-Warrior 48  
07C0:1503=IO-Warrior 28  
07C0:1511=IO-Warrior 24 Power Vampire  
07C0:1512=IO-Warrior 24 Power Vampire  
07C1=Keisokugiken  
07C1:0068=HKS-0200 USBDAQ  
07C4=Datafab Systems  
07C4:0102=USB to LS120  
07C4:0103=USB to IDE  
07C4:1234=USB to ATAPI  
07C4:A000=CompactFlash Card Reader  
07C4:A001=CompactFlash & SmartMedia Card Reader [eusb]  
07C4:A002=Disk Drive  
07C4:A003=Datafab-based Reader  
07C4:A004=USB to MMC Class Drive  
07C4:A005=CompactFlash & SmartMedia Card Reader  
07C4:A006=SmartMedia Card Reader  
07C4:A007=Memory Stick Class Drive  
07C4:A103=MDSM-B reader  
07C4:A107=USB to Memory Stick (LC1) Drive  
07C4:A109=LC1 CompactFlash & SmartMedia Card Reader  
07C4:A10B=USB to CF+MS(LC1)  
07C4:A200=DF-UT-06 Hama MMC/SD Reader  
07C4:A400=CompactFlash & Microdrive Reader  
07C4:A600=Card Reader  
07C4:AD01=USB Mass Storage Device  
07C4:AE01=USB Mass Storage Device  
07C4:AF01=USB Mass Storage Device  
07C4:B000=USB to CF(LC1)  
07C4:B001=USB to CF+PCMCIA  
07C4:B004=MMC/SD Reader  
07C4:B006=USB to PCMCIA  
07C4:B00A=USB to CF+SD Drive(LC1)  
07C4:B00B=USB to Memory Stick(LC1)  
07C5=APG Cash Drawer  
07C6=ShareWave  
07C6:0002=Bodega Wireless Access Point

07C6:0003=Bodega Wireless Network Adapter  
07C7=Powertech Industrial  
07C8=B.U.G.  
07C8:0202=MN128-SOHO PAL (USB)  
07C9=Allied Telesyn International  
07C9:B100=AT-USB100  
07CA=AVerMedia Technologies  
07CA:0002=AVerTV PVR USB/EZMaker Pro Device  
07CA:0026=AVerTV  
07CA:0337=A867 DVB-T dongle  
07CA:0810=AVerMedia H810 USB Custom IR Receiver  
07CA:0810:01=AVerMedia H810 USB Hybrid DVB-T  
07CA:0826=AVerMedia H826 USB Hybrid ATSC/QAM  
07CA:0830=AVerMedia H830 USB Custom IR Receiver  
07CA:0830:01=AVerMedia H830 USB Hybrid DVB-T  
07CA:0833=AVerMedia A833 USB Custom IR Receiver  
07CA:0833:01=AVerMedia A833 USB Pure Analog  
07CA:0837=H837 Hybrid ATSC/QAM  
07CA:0868=AVerMedia H868 USB Custom IR Receiver  
07CA:0868:01=AVerMedia H868 USB Hybrid SBT-D-T  
07CA:1228=MPEG-2 Capture Device (M038)  
07CA:1826=AVerMedia H826D USB Pure ATSC/QAM  
07CA:1827=AVerMedia A827AC USB Pure Analog  
07CA:1830=AVerMedia H830 USB Custom IR Receiver  
07CA:1830:01=AVerMedia H830 USB DVB-T  
07CA:2826=AVerMedia H826 USB Hybrid ATSC/QAM  
07CA:2827=AVerTV Hybrid Volar HX - TV Starter Kit for Windows  
07CA:2830=AVerMedia H830 USB Custom IR Receiver  
07CA:2830:01=AVerMedia H830 USB Hybrid DVB-T  
07CA:3826=AVerMedia H826D USB Pure ATSC/QAM  
07CA:4826=AVerTV Hybrid Volar Max - TV Starter Kit for Windows  
07CA:850A=AverTV Volar Black HD (A850)  
07CA:850B=AverTV Red HD+ (A850T)  
07CA:A309=HP DVB-T TV Tuner [HP dv6-1190en]  
07CA:A801=AVerTV DVB-T (A800)  
07CA:A815=AVerTV DVB-T Volar X (A815)  
07CA:A827=AVerMedia A827 USB Hybrid DVB-T  
07CA:A835=AVerMedia A835 USB DVB-T  
07CA:A867=AVerTV DVB-T (A867)  
07CA:B800=MR800 FM Radio  
07CA:B827=AVerMedia A827A USB Pure Analog  
07CA:C039=AVerMedia C039 USB Custom IR Receiver  
07CA:C039:01=AVerMedia C039 USB Capture Card  
07CA:E880=MPEG-2 Capture Device (E880)  
07CA:E882=MPEG-2 Capture Device (E882)  
07CA:FF03=USB Video Camera for AverVision Digital Presenter 2  
07CB=Kingmax Technology  
07CC=Carry Computer Eng.,  
07CC:0000=CF Card Reader  
07CC:0001=Reader (UICSE)  
07CC:0002=Reader (UIS)  
07CC:0003=SM Card Reader  
07CC:0004=SM/CF/PCMCIA Card Reader  
07CC:0005=Reader (UISA2SE)  
07CC:0006=SM/CF/PCMCIA Card Reader  
07CC:0007=Reader (UISA6SE)  
07CC:000C=SM/CF Card Reader  
07CC:000D=SM/CF Card Reader  
07CC:000E=Reader (UISDA)  
07CC:000F=Reader (UICLIK)

07CC:0010=Reader (UISMA)  
07CC:0012=Reader (UISC6SE-FLASH)  
07CC:0014=Litronic Fortezza Reader  
07CC:0030=Mass Storage (UISDMC12S)  
07CC:0040=Mass Storage (UISDMC13S)  
07CC:0100=Reader (UID)  
07CC:0101=Reader (UIM)  
07CC:0102=Reader (UISDMA)  
07CC:0103=Reader (UISDMC)  
07CC:0104=Reader (UISDM)  
07CC:0200=6-in-1 Card Reader  
07CC:0201=Mass Storage (UISDMC1S & UISDMC3S)  
07CC:0202=Mass Storage (UISDMC5S)  
07CC:0203=Mass Storage (UISMC5S)  
07CC:0204=Mass Storage (UIM4/5S & UIM7S)  
07CC:0205=Mass Storage (UIS4/5S & UIS7S)  
07CC:0206=Mass Storage (UISDMC10S & UISDMC11S)  
07CC:0207=Mass Storage (UPIDMA)  
07CC:0208=Mass Storage (UCFC II)  
07CC:0210=Mass Storage (UPIXXA)  
07CC:0213=Mass Storage (UPIDA)  
07CC:0214=Mass Storage (UPIMA)  
07CC:0215=Mass Storage (UPISA)  
07CC:0217=Mass Storage (UPISDMA)  
07CC:0223=Mass Storage (UCIDA)  
07CC:0224=Mass Storage (UCIMA)  
07CC:0225=Mass Storage (UIS7S)  
07CC:0227=Mass Storage (UCIDMA)  
07CC:0234=Mass Storage (UIM7S)  
07CC:0235=Mass Storage (UIS4S-S)  
07CC:0237=Velper (UISDMC4S)  
07CC:0300=6-in-1 Card Reader  
07CC:0301=6-in-1 Card Reader  
07CC:0303=Mass Storage (UID10W)  
07CC:0304=Mass Storage (UIM10W)  
07CC:0305=Mass Storage (UIS10W)  
07CC:0308=Mass Storage (UIC10W)  
07CC:0309=Mass Storage (UISC3W)  
07CC:0310=Mass Storage (UISDMA2W)  
07CC:0311=Mass Storage (UISDMC14W)  
07CC:0320=Mass Storage (UISDMC4W)  
07CC:0321=Mass Storage (UISDMC37W)  
07CC:0330=WINTERREADER Reader  
07CC:0350=9-in-1 Card Reader  
07CC:0500=Mass Storage  
07CC:0501=Mass Storage  
07CC:B001=USB Mass Storage Device  
07CD=Elektor  
07CD:0001=USBuart Serial Port  
07CF=Casio Computer  
07CF:1001=Casio Digital Camera  
07CF:1002=Casio DSC  
07CF:1003=Exilim EX-S500  
07CF:1004=Exilim EX-Z120  
07CF:1011=USB-CASIO PC CAMERA  
07CF:1116=EXILIM EX-Z19  
07CF:1133=Exilim EX-Z350 Digital Camera (mass storage mode)  
07CF:1233=Exilim EX-Z350 Digital Camera (PictBridge mode)  
07CF:2001=CASIO USB Sync 2001  
07CF:2002=CASIO USB Sync 2002

07CF:2003=CASIO USB Sync 2003  
07CF:3801=Casio WMP-1 MP3-Watch  
07CF:4001=Label Printer KL-P1000  
07CF:4007=CW50 Device  
07CF:4104=Cw75 Device  
07CF:4107=CW-L300 Device  
07CF:4500=LV-20 Digital Camera  
07CF:6801=PL-40R  
07CF:6802=MIDI Keyboard  
07D0=Dazzle  
07D0:0001=Digital Video Creator I  
07D0:0002=Global Village VideoFX Grabber  
07D0:0003=Fusion Model DVC-50 Rev 1 (NTSC)  
07D0:0004=DVC-800 (PAL) Grabber  
07D0:0005=Fusion Video and Audio Ports  
07D0:0005:01=Fusion Video and Audio Ports  
07D0:0006=DVC 150 Loader Device  
07D0:0007=DVC 150  
07D0:0327=Fusion Digital Media Reader  
07D0:0327:01=Fusion Digital Media Reader  
07D0:1001=DM-FLEX DFU Adapter  
07D0:1002=DMHS2 DFU Adapter  
07D0:1102=CF Reader/Writer  
07D0:1103=SD Reader/Writer  
07D0:1104=SM Reader/Writer  
07D0:1105=MS Reader/Writer  
07D0:1106=xD/SM Reader/Writer  
07D0:1202=MultiSlot Reader/Writer  
07D0:2000=FX2 DFU Adapter  
07D0:2001=eUSB CompactFlash Reader  
07D0:4100=Kingsun SF-620 Infrared Adapter  
07D0:4101=Connectivity Cable (CA-42 clone)  
07D0:4959=Kingsun KS-959 USB Infrared Adapter  
07D1=D-Link  
07D1:13EC=VvBus for Helium 2xx  
07D1:13ED=VvBus for Helium 2xx  
07D1:13F1=D-Link DSL-302G Modem  
07D1:13F2=DSL-502G Router  
07D1:3300=D-Link DWA-130 Wireless N USB Adapter  
07D1:3302=D-Link DWA-130 Wireless N USB Adapter(rev.C2)  
07D1:3303=D-Link DWA-131 Wireless N Nano USB Adapter  
07D1:3306=D-Link DWL-G122 Wireless G USB Adapter (rev.F1)  
07D1:3A07=WUA-2340 Adapter  
07D1:3A08=predator Bootloader Download  
07D1:3A09=D-Link DWA-160 Xtreme N Dual Band USB Adapter(rev.A2)  
07D1:3A0B=Alice G-132  
07D1:3A0D=DWA-120 Wireless 108G Adapter  
07D1:3A0F=DWA-130 802.11n Wireless N Adapter(rev.D) [Atheros AR9001U-(2)NG]  
07D1:3A10=DWA-126 802.11n Wireless Adapter [Atheros AR9271]  
07D1:3B01=AirPlus G DWL-G122 Wireless Adapter  
07D1:3B02=D-Link WUA-1340 USB Adapter  
07D1:3B10=RangeBooster N Adapter  
07D1:3B11=Wireless N Adapter DWA-130  
07D1:3C03=DWL-G122 802.11g Adapter [ralink rt73]  
07D1:3C04=WUA-1340  
07D1:3C05=D-Link DUB-E100 USB 2.0 Fast Ethernet Adapter  
07D1:3C06=D-Link DWA-111 Wireless G USB Adapter  
07D1:3C07=Wireless G DWA-110 Adapter  
07D1:3C09=DWA-140 802.11n Adapter [ralink rt2870]  
07D1:3C0A=D-Link DWA-140 RangeBooster N USB Adapter (rev.B2)

07D1:3C0B=D-Link DWA-110 Wireless G USB Adapter(rev.B)  
07D1:3C0D=D-Link DWA-125 Wireless 150 USB Adapter(rev.A2)  
07D1:3C0E=D-Link WUA-2340 USB Adapter(rev.B)  
07D1:3C0F=D-Link AirPlus G DWL-G122 Wireless Adapter(rev.E)  
07D1:3C10=DWA 160A 802.11n (ar9170)  
07D1:3C11=D-Link DWA-160 Xtreme N Dual Band USB Adapter(rev.B)  
07D1:3C13=D-Link DWA-130 Wireless N USB Adapter(rev.B)  
07D1:3C15=D-Link DWA-140 Wireless N USB Adapter(rev.B3)  
07D1:3C16=D-Link DWA-125 Wireless N 150 USB Adapter(rev.A2)  
07D1:3C17=D-Link DWA-121 Wireless N 150 USB Adapter  
07D1:3D01=D-Link Wireless USB HWA  
07D1:3D02=D-Link Host Wire Adapter  
07D1:3D03=D-Link Cable Association Device  
07D1:3D04=D-Link Wireless USB Hub  
07D1:3D05=D-Link Cable Association Interface  
07D1:3E02=DWM-156 3.75G HSUPA Adapter  
07D1:5100=Remote NDIS Device  
07D1:A800=DWM-152 3.75G HSUPA Adapter  
07D1:F101=USB Bluetooth Adapter  
07D1:FC01=D-Link DBT-120 USB Bluetooth Adapter  
07D2=Aptio Products  
07D3=Cyberdata  
07D5=Radiant Systems  
07D7=GCC Technologies  
07DA=Arasan Chip Systems  
07DE=Diamond Multimedia  
07DE:2820=VC500 Video Capture Dongle  
07DF=David Electronics Company  
07E1=Ambient Technologies  
07E1:1002=Acer ISDN 128 Surf USB  
07E1:5201=V.90 Modem  
07E2=Elmeg  
07E2:0100=elmeg WIZ@RD BootUp  
07E2:0101=elmeg WIZ@RD  
07E2:0201=elmeg D@VOS  
07E2:0203=elmeg D@VOS.net  
07E2:0300=elmeg CS320 BootUp  
07E2:0301=elmeg CS320  
07E2:0301:0200=elmeg CS410  
07E2:0401=elmeg.net  
07E2:0401:0101=elmeg ICT  
07E2:0401:9999=elmeg Firmware Update Device  
07E3=Planex Communications  
07E3:0001=Plustek USB Scanner  
07E4=Movado Enterprise  
07E4:0967=SCard R/W CSR-145  
07E4:0968=SCard R/W CSR-145  
07E5=QPS  
07E5:05C2=IDE-to-USB2.0 PCA  
07E5:5C01=Que! CDRW  
07E6=Allied Cable  
07E7=Mirvo Toys  
07E8=Labsystems  
07EA=Iwatsu Electric  
07EB=Double-H Technology  
07EC=Taiyo Electric Wire & Cable  
07EE=Torex Retail (formerly Logware)  
07EE:0002=Cash Drawer I/F  
07EF=STSN  
07EF:0001=Internet Access Device

07F2=General CADD  
07F2:0001=USB Dongle - Software Protection Device  
07F6=Circuit Assembly  
07F7=Century  
07F7:0005=ScanLogic/Century Corporation uATA  
07F7:011E=Century USB Disk Enclosure  
07F8:9104=Eskape Labs MyTV2Go  
07F9=Dotop Technology  
07FA=Draytek  
07FA:0778=miniVigor 128 ISDN TA  
07FA:1012=BeWAN ADSL USB ST (grey)  
07FA:1196=BWIFI-USB54AR 802.11bg (zd1211rw)  
07FA:7712=Adaptateur reseau sans-fil Bewan 802.11n  
07FA:A904=BeWAN ADSL  
07FA:A905=BeWAN ADSL ST  
07FD=Mark of the Unicorn  
07FD:0000=FastLane Dual MIDI Interface  
07FD:0001=FastLane Quad MIDI Interface  
07FD:0002=MOTU Audio for 64 bit  
07FF=Unknown  
07FF:00FF=Portable Hard Drive  
0801=Mag-Tek  
0801:0001=Mini Swipe Reader (Keyboard Emulation)  
0801:0002=Mini Swipe Reader  
0801:0003=Magstripe Insert Reader  
0802=Mako Technologies, LLC  
0803=Zoom Telephonics  
0803:1300=V92 Faxmodem  
0803:3095=Conexant USB CX93010 ACF Modem  
0803:4310=Wireless-G  
0803:5241=Cable Modem  
0803:5551=DSL Modem  
0803:9700=2986L FaxModem  
0803:9700:0100=Zoom 2985 USB 56K Modem  
0803:9800=Cable Modem  
0803:A312=Zoom Wireless-G USB  
0809=Genicom Technology  
080A=Evermuch Technology  
080B=Cross Match Technologies  
080B:0002=Fingerprint Scanner (After ReNumeration)  
080B:0010=300LC Series Fingerprint Scanner (Before ReNumeration)  
080C=Datalogic S.p.A.  
080C:0300=Gryphon D120 Barcode Scanner  
080C:0400=Gryphon D120 Barcode Scanner  
080C:0500=Gryphon D120 Barcode Scanner  
080C:0600=Gryphon M100 Barcode Scanner  
080D=Teco Image Systems  
080D:0102=Hercules Scan@home 48  
080D:0104=3.2Slim  
080D:0110=UMAX AstraSlim 1200 Scanner  
0810=Personal Communication Systems  
0810:0001=Dual PSX Adaptor  
0810:0002=Dual PCS Adaptor  
0810:0003=HID-Compliant USB Game Controller  
0810:0005=USB Gamepad  
0813=Mattel  
0813:0001=Intel Play QX3 Microscope  
0813:0001:0160=Intel Play QX3 Microscope  
0813:0002=Dual Mode Camera Plus  
0815:0100=Siemens Mobile Phone USB Modem



0815:0100:01=Siemens Mobile Phone USB Modem (Debug)  
0819=eLicenser  
0819:0101=License Management and Copy Protection  
081A=MG Logic  
081A:1000=Duo Pen Tablet  
081B=Indigita  
081B:0600=USB Storage Adapter  
081B:0601=USB Storage Adapter  
081C=Mipsys  
081E=AlphaSmart  
081E:DF00=AlphaSmart Handheld  
0822=Reudo  
0822:2001=IRXpress Infrared Device  
0825=GC Protronics  
0826=Data Transit  
0827=BroadLogic  
0828=Sato  
0829=DirectTV Broadband  
082C:0001=Jdl Security Device USB Key  
082D=Handspring  
082D:0100=Handspring Visor Edge Personal Organiser  
082D:0200=Handspring Handheld  
082D:0300=Handspring Handheld  
082D:0400=Handspring Handheld  
082D:0500=Handspring Handheld  
082D:0600=Handheld  
0830=Palm  
0830:0001=Palm Handheld  
0830:0002=Palm M505  
0830:0003=Palm M515  
0830:0004=Palm Handheld  
0830:0005=Palm Handheld  
0830:0006=Palm Handheld  
0830:0010=Palm Handheld  
0830:0011=Palm Handheld  
0830:0012=Palm Handheld  
0830:0013=Palm Handheld  
0830:0014=Palm Handheld  
0830:0020=Palm I705  
0830:0021=Palm Handheld  
0830:0022=Palm Handheld  
0830:0023=Palm Handheld  
0830:0024=Palm Handheld  
0830:0030=Palm Handheld  
0830:0031=Palm Handheld  
0830:0032=Palm Handheld  
0830:0033=Palm Handheld  
0830:0034=Palm Handheld  
0830:0040=Palm M125  
0830:0041=Palm Handheld  
0830:0042=Palm Handheld  
0830:0043=Palm Handheld  
0830:0044=Palm Handheld  
0830:0050=Palm M130  
0830:0051=Palm Handheld  
0830:0052=Palm Handheld  
0830:0053=Palm Handheld  
0830:0054=Palm Handheld  
0830:0060=Palm, Inc. Palm Tungsten T / Zire 71  
0830:0061=Palm Handheld

0830:0062=Palm Handheld  
0830:0063=Palm Handheld  
0830:0064=Palm Handheld  
0830:0070=Palm Handheld  
0830:0071=Palm Handheld  
0830:0072=Palm Handheld  
0830:0080=Palm  
0830:0081=Palm Handheld  
0830:0082=Palm Handheld  
0830:00A0=Treo 800w  
0830:0101=Pre  
0832=Kouwell Electronics  
0832:5850=Cable  
0833=Sourcenext  
0833:012E=KeikaiDenwa 8 with charger  
0833:039F=KeikaiDenwa 8  
0835=Action Star Enterprise  
0839=Samsung Techwin  
0839:0005=Digimax Camera  
0839:0008=Digimax 230 Camera  
0839:0009=Digimax 340  
0839:000A=Digimax 410  
0839:000E=Digimax 360  
0839:0010=Digimax 300  
0839:1003=Digimax 210SE  
0839:1005=Samsung Digimax 220  
0839:1009=Samsung Digimax V4  
0839:1009:0100=Samsung Digimax V4 4.0 Mega Pixels  
0839:1012=6500 Document Camera  
0839:1058=S730 Camera  
0839:1064=Digimax D830 Camera  
0839:1542=Digimax 50 Duo  
0839:3000=Digimax 35 MP3  
083A=Accton Technology  
083A:1046=10/100 Ethernet [pegasus]  
083A:1060=HomeLine Adapter  
083A:1F4D=SMC EZ Connect Cable Modem Gateway RNDIS Device  
083A:3046=10/100 Series Adapter  
083A:3060=1/10/100 Adapter  
083A:3501=2664W  
083A:3502=Accton WN3501D Wireless USB Adapter  
083A:3503=T-Sinus 111 Wireless Adapter  
083A:4501=T-Sinus 154data  
083A:4502=Gigaset USB Adapter 54  
083A:4505=SMCWUSB-G 802.11g Wireless USB 2.0 Adapter  
083A:4507=SMCWUSB-T-G2 802.11g Wireless Adapter [Atheros AR5523]  
083A:4521=Gigaset USB Adapter 54  
083A:5046=SpeedStream 10/100 Ethernet [pegasus]  
083A:5501=Wireless Adapter 11g  
083A:6500=Accton USB Cable Modem  
083A:6618=802.11n Wireless Adapter  
083A:7511=802.11N Wireless USB Adapter  
083A:7512=802.11N Wireless USB Adapter  
083A:7522=802.11N Wireless USB Adapter  
083A:8002=SMC EZ Connect USB/ETH Cable Modem  
083A:8522=802.11N Wireless USB Adapter  
083A:8541=WN4501F 802.11g Wireless Adapter [Intersil ISL3887]  
083A:A512=802.11N Wireless USB Adapter  
083A:A618=SMC EZ Connect N Draft 11n Wireless Adapter  
083A:A701=SMC Networks EZ Connect N Wireless USB Adapter

083A:A702=SMC Networks EZ Connect N 802.11n Wireless USB 2.0 Adapter  
083A:A703=802.11n Wireless USB Adapter  
083A:B004=CPWUE001 USB/Ethernet Adapter  
083A:B522=EZ Connect N Draft 11n Wireless USB2.0 Adapter  
083A:BB01=BlueExpert Bluetooth Device  
083A:C003=802.11b Wireless Adapter  
083A:C501=Zoom Wireless-G  
083A:C522=802.11N Wireless USB Adapter  
083A:C561=802.11a/g Wireless Adapter  
083A:D522=Speedport W 102 Stick IEEE 802.11n USB 2.0 Adapter  
083A:E501=802.11g Wireless USB Adapter  
083A:E503=Arcadyan WN4501 802.11b/g  
083A:E506=WUS-201 802.11bg (zd1211rw)  
083A:F501=802.11g Wireless Adapter  
083A:F502=802.11g Wireless Adapter  
083A:F522=Arcadyan WN7512 802.11n (ar9170)  
083F=Global Village  
083F:B100=TelePort V.90 Fax/Modem  
0840=Argosy Research  
0840:0060=Storage Adapter Bridge Module  
0841=Rioport.com  
0841:0001=Rio 500  
0844=Welland Industrial  
0846=NETGEAR  
0846:1001=NETGEAR EA101 USB Ethernet Adapter  
0846:1002=NETGEAR EA101 USB Ethernet Adapter  
0846:1020=NETGEAR FA101 USB Fast Ethernet Adapter  
0846:1040=NETGEAR FA120 USB 2.0 Fast Ethernet Adapter  
0846:4110=MA111 WiFi (v1)  
0846:4200=WG121 WiFi (v1)  
0846:4210=WG121 WiFi (v2)  
0846:4220=WG111 WiFi (v1)  
0846:4230=MA111 WiFi  
0846:4240=WG111 WiFi (v2)  
0846:4250=WG111T 802.11g Wireless Adapter [Atheros AR5523]  
0846:4260=WG111v3 802.11g Adapter [realtek RTL8187B]  
0846:4300=WG111U  
0846:4301=WG111U (no firmware)  
0846:5F00=WPN111 802.11g Wireless Adapter [Atheros AR5523]  
0846:6A00=WG111 WiFi (v2)  
0846:6A00:0100=Realtek RTL8187 Wireless 802.11g 54Mbps USB 2.0 Network Adapter  
0846:7100=WN121T RangeMax Next Wireless-N [Marvell TopDog]  
0846:9000=WN111(v1) RangeMax Next Wireless [Marvell TopDog]  
0846:9001=WN111(v2) RangeMax Next Wireless [Atheros AR9001U-(2)NG]  
0846:9010=WNDA3100 RangeMax Dual Band Wireless-N [Atheros AR9001U-2NX]  
0846:9011=WNDA3100(v2) 802.11n  
0846:9018=WNDA3200 802.11abgn Wireless Adapter [Atheros AR7010]  
0846:9020=WNA3100(v1) Wireless-N 300 [Broadcom BCM43231]  
0846:9030=WNA1100 Wireless-N 150 [Atheros AR9271]  
0846:9040=WNA1000 Wireless-N 150 [Atheros AR9001U-(2)NG]  
0846:9041=NETGEAR WNA1000M N150 Wireless USB Micro Adapter  
0846:A001=NETGEAR PA101 USB Phoneline10X Adapter  
084B:A001=Çë°²×°³ŞÉİİá¹©µÄÇý¶³İĐò  
084D=Minton Optic Industry  
084D:0001=Jenoptik JD800i  
084D:0003=S-Cam F5 Digital Camera  
084D:0011=Argus DC3500 Digital Camera  
084D:0014=Praktica DC 32  
084D:0019=Praktica DPix3000  
084D:0025=Praktica DC 60

084D:1001=ScanHex SX-35d  
084E=KB Gear  
084E:0001=KBGear JamCam  
084E:1001=Jam Studio Tablet  
084E:1002=Pablo Tablet  
084F=Empeg  
084F:0001=Empeg-Car Mark I/II Player  
0850=Fast Point Technologies  
0851=Macronix International  
0851:1542=SiPix Blink  
0851:1543=Maxell WS30 Slim Digital Camera  
0851:1544=Acer DC300 Digital Camera  
0851:A168=MXIC  
0852=CSEM  
0853=Topre  
0853:0100=HHKB Professional  
0854=ActiveWire  
0854:0100=I/O Board  
0854:0101=I/O Board, rev1  
0856=B&B Electronics  
0856:AC01=uLinks USOTL4 RS422/485 Adapter  
0858=Hitachi Maxell  
0858:3102=Hitachi Bluetooth Device  
0858:FFFF=Maxell module with BlueCore in DFU mode  
0859=Minolta Systems Laboratory  
085A=Xircom  
085A:0001=Portstation Dual Serial Port  
085A:0003=Portstation Paraller Port  
085A:0008=PortGear Ethernet Adapter  
085A:0009=PortStation Ethernet module  
085A:000B=Portstation Dual PS/2 Port  
085A:0021=1 port to Serial Converter  
085A:0022=Parallel Port  
085A:0023=2 port to Serial Converter  
085A:0024=Parallel Port  
085A:0027=1 port to Serial Converter  
085A:0028=PortGear to SCSI Converter  
085A:0032=PortStation SCSI Module  
085A:003C=Bluetooth Adapter  
085A:0299=Colorvision, Inc. Monitor Spyder  
085A:8021=1 port to Serial  
085A:8023=2 port to Serial  
085A:8027=PGSDB9 Serial Port  
085C=ColorVision  
085C:0200=Monitor Spyder  
0862=Teletrol Systems  
0863=Filanet  
0864=NetGear  
0864:4100=MA101 802.11b Adapter  
0864:4102=MA101 802.11b Adapter  
0867=Data Translation  
0867:9812=ECON Data acquisition unit  
0867:9816=DT9816 ECON data acquisition module  
0867:9836=DT9836 data acquisition card  
086A=Emagic Soft-und Hardware Gmbh  
086A:0001=Unitor8  
086A:0002=AMT8  
086A:0003=MT4  
086B:030A=ScanExpress CardSmart WIA Scanner  
086C=DeTeWe - Deutsche Telephonwerke AG &

086C:1001=Eumex 504PC ISDN TA  
086C:1002=Eumex 504PC USB (FlashLoad)  
086C:1003=TA33 ISDN TA  
086C:1004=TA33 (FlashLoad)  
086C:1005=Eumex 604PC HomeNet (USB)  
086C:1006=Eumex 604PC HomeNet (FlashLoad)  
086C:1007=Eumex 704PC DSL (USB)  
086C:1008=Eumex 704PC DSL (FlashLoad)  
086C:1009=Eumex 724PC DSL (USB)  
086C:100A=Eumex 724PC DSL (FlashLoad)  
086C:100B=OpenCom 30  
086C:100C=OpenCom 30 (FlashLoad)  
086C:100D=BeeTel Home 100  
086C:100E=BeeTel Home 100 (FlashLoad)  
086C:1011=USB2DECT  
086C:1012=USB2DECT (FlashLoad)  
086C:1013=Eumex 704PC LAN (USB)  
086C:1014=Eumex 704PC LAN (FlashLoad)  
086C:1019=Eumex 504PC SE (USB)  
086C:101A=Eumex 504PC SE (FlashLoad)  
086C:1021=OpenCom 40  
086C:1022=OpenCom 40 (FlashLoad)  
086C:1023=OpenCom 45  
086C:1024=OpenCom 45 (FlashLoad)  
086C:1025=Sinus 61 data (USB)  
086C:1029=dect BOX  
086C:102C=Eumex 604PC HomeNet [FlashLoad]  
086C:1030=Eumex 704PC DSL [FlashLoad]  
086C:1032=OpenCom 40 [FlashLoad]  
086C:1033=OpenCom 30 plus  
086C:1034=OpenCom 30 plus (FlashLoad)  
086C:1037=Eumex 620 LAN (USB)  
086C:1038=Eumex 620 LAN (FlashLoad)  
086C:103D=T-Sinus 620data (USB)  
086C:103E=T-Sinus 620data (FlashLoad)  
086C:1041=Eumex 220PC (USB)  
086C:1042=Eumex 220PC (FlashLoad)  
086C:1043=Eumex 730 dsl (USB)  
086C:1044=Eumex 730 dsl (FlashLoad)  
086C:1047=Eumex 520PC (USB)  
086C:1055=Eumex 220 ISDN TA  
086C:1056=Eumex 220PC [FlashLoad]  
086C:1067=Eumex 200 (USB)  
086C:1068=Eumex 200 (FlashLoad)  
086C:2000=OpenCom 1000  
086E=System TALKS  
086E:1920=10M/100Mbps Fast Ethernet Adapter  
086F=MEC IMEX INC/HPT  
0870=Metricom  
0870:0001=Ricochet Wireless USB Modem  
0870:0001:0100=Ricochet Wireless USB Modem  
0871=SanDisk  
0871:0001=SDDR-01 Compact Flash Reader  
0871:0002=SDDR-31 Compact Flash Reader  
0871:0005=SDDR-05 Compact Flash Reader  
0873=Xpeed  
0874=A-Tec Subsystem  
0879=Comtrol  
087C=Adesso/Kbtek America  
087D=Jaton

087D:5704=Jaton USB Ethernet Device Adapter  
087E=Fujitsu Computer Products of America  
087F=QualCore Logic  
0880=APT Technologies  
0883=Recording Industry Association of America (RIAA)  
0885=Boca Research  
0886=XAC Automation  
0886:0630=Intel PC Camera CS630  
0887=Hannstar Electronics  
0888:0100=FireSpy400 firmware loader  
0888:0101=FireSpy800 firmware loader  
0888:0102=FireSpyX810 firmware loader  
0888:0105=FireSpy400  
0888:0106=FireSpy800  
0888:0107=FireSpyX810  
0888:0202=FireStealth firmware loader  
0888:0207=FireStealth810bN  
088B=MassWorks  
088B:4944=MassWorks ID-75 TouchScreen  
088C=Swecoin AB  
088C:2030=Ticket Printer TTP 2030  
088E=iLok  
088E:5036=Portable secure storage for software licenses  
0892=DioGraphy  
0892:0101=DioGraphy USB Smartdio Reader/Writer  
0897=Lauterbach  
0897:0001=Lauterbach System Controller Unit SCU-ETH/32  
0897:0002=Lauterbach POEBUS USB Controller  
0897:0003=Lauterbach Unknown USB Device  
089C=United Technologies Research Cntr.  
089D=Icron Technologies  
089E=NST  
089F=Primex Aerospace  
08A5=e9  
08A8=Andrea Electronics  
08AE=Macally (Mace Group)  
08B4=Sorenson Vision  
08B7=NATSU  
08B7:0001=Playstation adapter  
08B8=J. Gordon Electronic Design  
08B8:01F4=USBSIMM1  
08B9=RadioShack  
08B9:1197=WLAN USB ADAPTOR  
08BB=Texas Instruments Japan  
08BB:2702=USB Speakers  
08BB:2900=PCM2900 Audio Codec  
08BB:2901=PCM2901 Audio Codec  
08BB:2902=PCM2902 Audio Codec  
08BB:2904=PCM2904 Audio Codec  
08BB:2910=PCM2912 Audio Codec  
08BB:29B0=PCM2900B Audio CODEC  
08BB:29B2=PCM2902 Audio CODEC  
08BB:29B3=PCM2903B Audio CODEC  
08BB:29B6=PCM2906B Audio CODEC  
08BB:29C0=PCM2900C Audio CODEC  
08BB:29C2=PCM2902C Audio CODEC  
08BB:29C3=PCM2903C Audio CODEC  
08BB:29C6=PCM2906C Audio CODEC  
08BD=Citizen Watch  
08BD:0208=CLP-521 Label Printer

08BD:0302=CTZ-NS02 MOBILE DATA PLAYER  
08BD:1100=X1-USB Floppy  
08C3=Precise Biometrics  
08C3:0001=100 SC  
08C3:0001:0001=Precise 100 SC  
08C3:0001:0002=Precise 100 SC  
08C3:0002=100 A  
08C3:0002:0002=Precise 100 A  
08C3:0003=100 SC BioKeyboard  
08C3:0003:0002=Precise 100 SC BioKeyboard  
08C3:0003:0100=Precise 100 SC BioKeyboard  
08C3:0006=100 A BioKeyboard  
08C3:0006:0100=Precise 100 A BioKeyboard  
08C3:0100=Precise 100 MC ISP  
08C3:0101=Precise 100 MC FingerPrint and SmartCard Reader  
08C3:0300=Precise 100 AX  
08C3:0400=100 SC  
08C3:0401=150 MC  
08C3:0402=200 MC FingerPrint and SmartCard Reader  
08C3:0404=100 SC Upgrade  
08C3:0405=150 MC Upgrade  
08C3:0406=100 MC Upgrade  
08C4=Proxim  
08C4:0100=Skyline 802.11b Wireless Adapter  
08C4:02F2=Farallon USB Home Phonenumber Adapter  
08C7=TAI TWUN ENTERPRISE  
08C8=2Wire  
08C9=Nippon Telegraph and Telephone  
08CA=AIPTEK International  
08CA:0001=Tablet  
08CA:0010=Tablet  
08CA:0020=APT-6000U Tablet  
08CA:0021=APT-2 Tablet  
08CA:0022=Tablet  
08CA:0023=Tablet  
08CA:0024=Tablet  
08CA:0100=Pen Drive  
08CA:0102=DualCam  
08CA:0103=Pocket DV Digital Camera  
08CA:0103:01=Digital Video Camera(Still)  
08CA:0104=Pocket DVII  
08CA:0105=Mega DV(Disk)  
08CA:0106=Pocket DV3100+  
08CA:0107=Pocket DV 3100  
08CA:0109=Nisis DV4 Digital Camera  
08CA:010A=Trust 738AV LCD PV Mass Storage  
08CA:0111=PenCam VGA Plus  
08CA:2008=Mini PenCam 2  
08CA:2010=Pocket CAM 3 Mega (webcam)  
08CA:2011=Pocket CAM 3 Mega (storage)  
08CA:2016=PocketCam 2 Mega  
08CA:2018=Pencam SD 2  
08CA:2020=Slim 3000F  
08CA:2022=Slim 3200  
08CA:2024=Pocket DV3500  
08CA:2028=Pocket Cam4M  
08CA:2040=Pocket DV4100M  
08CA:2042=Pocket DV5100M Composite Device  
08CA:2043=Pocket DV5100M (Disk)  
08CA:2050=DV3X7R Video Digital Camera

08CA:2050:01=DV3X7R Still Digital Camera  
08CA:2060=Pocket DV5300  
08CD=Jue Hsun Ind.  
08CE=Long Well Electronics  
08CF=Productivity Enhancement Products  
08D1=smartBridges  
08D1:0001=smartNIC HOT-SYNC(tm) Network Adapter  
08D1:0003=smartNIC2 PnP Network Adapter  
08D3=Virtual Ink  
08D4=Siemens PC Systems  
08D4:0009=SCR SmartCard Reader  
08D8=IXXAT Automation GmbH  
08D8:0002=USB-to-CAN compact  
08D8:0003=USB-to-CAN II  
08D8:0100=USB-to-CAN  
08D9=Increment P  
08DD=Billionton Systems  
08DD:0112=Billionton USB Wireless LAN Adapter  
08DD:0113=USB Wireless LAN Adapter  
08DD:0120=RT73 USB Wireless LAN Card  
08DD:0986=Billionton USB 10/100 LAN Adapter  
08DD:0987=USBLP-100 HomePNA Ethernet [pegasus]  
08DD:0988=USBEL-100 Ethernet [pegasus]  
08DD:1986=Billionton USB 10/100 LAN Adapter  
08DD:2103=DVB-T TV-Tuner Card-R  
08DD:8511=Billionton USB 10/100 LAN Adapter  
08DD:90FF=USB2AR Ethernet  
08DE=???  
08DE:7A01=802.11b Adapter  
08DF=Spyrus  
08DF:0001=Rosetta Token V1  
08DF:0002=Rosetta Token V2  
08DF:0003=Rosetta Token V3  
08DF:0A00=Lynks Interface  
08E3=Olitec  
08E3:0002=USB-RS232 Bridge  
08E3:0100=Interface ADSL  
08E3:0101=Interface ADSL  
08E3:0102=ADSL  
08E3:0301=RNIS  
08E4=Pioneer  
08E5=Litronic  
08E6=GEMPLUS  
08E6:0001=GemPC-Touch 430  
08E6:0430=GEMPLUS GemPC430 USB Smart Card Reader  
08E6:0432=GemPC432 SmartCard Reader  
08E6:0435=American Express GCR435 USB Smart Card Reader  
08E6:0437=GemPC433 SL SmartCard Reader  
08E6:1359=UA SECURE STORAGE TOKEN  
08E6:1359:01=UA SECURE STORAGE TOKEN  
08E6:2202=Gem e-Seal Pro Token  
08E6:2202:01=Gem e-Seal Pro USB Token  
08E6:3437=GemPC Twin Smart Card Reader  
08E6:3438=GemPC Key SmartCard Reader  
08E6:3440=USB Smart Card Reader  
08E6:3441=USB Smart Card Reader  
08E6:3478=GemPC Pinpad USB Smart Card Reader  
08E6:3488=GemPC Pinpad USB Smart Card Reader  
08E6:34EC=GemPC Express  
08E6:4433=GemPC433-Swap



08E6:5501=Gemprox-XU PC/SC Contactless Reader  
08E6:ACE0=UA HYBRID TOKEN  
08E7=Pan-International Wire & Cable  
08E8=Integrated Memory Logic  
08E9=Extended Systems  
08E9:0100=XTNDAccess IrDA Dongle  
08EA=Ericsson  
08EA:00C9=ADSL Modem HM120dp Loader  
08EA:00CA=ADSL WAN Modem HM120dp  
08EA:00CE=HM230d Virtual Bus for Helium  
08EA:ABBA=Bluetooth USB Controller from TOSHIBA (Ericsson P3D)  
08EA:ABBB=Ericsson USB Bluetooth Device in DFU State  
08EC=M-Systems Flash Disk Pioneers  
08EC:0001=TravelDrive 2C  
08EC:0002=TravelDrive 2C  
08EC:0005=TravelDrive 2C  
08EC:0008=Data Traveler 2.0  
08EC:0008:0100=Data Traveler 2.0  
08EC:0010=DiskOnKey USB Flash Disk  
08EC:0011=DiskOnKey USB Flash Disk (64/128MB)  
08EC:0012=DiskOnKey USB Flash Disk  
08EC:0014=TravelDrive 2C  
08EC:0015=Kingston DataTraveler ELITE  
08EC:0016=Kingston DataTraveler U3  
08EC:0020=TravelDrive  
08EC:0021=TravelDrive  
08EC:0022=TravelDrive  
08EC:0023=TravelDrive  
08EC:0024=TravelDrive  
08EC:0025=TravelDrive  
08EC:0026=TravelDrive  
08EC:0027=TravelDrive  
08EC:0028=TravelDrive  
08EC:0029=TravelDrive  
08EC:0030=TravelDrive  
08EC:0822=TravelDrive 2C  
08EC:0832=Hi-Speed Mass Storage Device  
08EC:0834=M-Disk 220  
08EC:0998=Kingston Data Traveler2.0 Disk Driver  
08EC:0999=M-Systems DiskOnKey Disk Driver  
08EC:1000=TravelDrive 2C  
08EC:2000=TravelDrive 2C  
08EC:2038=TravelDrive  
08EC:2039=TravelDrive  
08EC:204A=TravelDrive  
08EC:204B=TravelDrive  
08ED=MediaTek  
08ED:0002=CECT M800 memory card  
08EE=CCSI/Hesso  
08F0=Corex Technologies  
08F1=CTI Electronics  
08F2=Gotop Information  
08F2:007F=Super Q2 Tablet  
08F5=SysTec  
08F6=Logic 3 International  
08F7=Vernier  
08F7:0001=LabPro  
08F7:0002=EasyTemp  
08F7:0003=Go!Link  
08F7:0004=Go!Motion

08F8=Keen Top International Enterprise  
08F9=Wipro Technologies  
08FA=Caere  
08FB=Socket Communications  
08FC=Sicon Cable Technology  
08FD=Digianswer A/S  
08FD:0001=Bluetooth Device  
08FF=AuthenTec  
08FF:1600=AuthenTec Inc. AES1610A  
08FF:1610=AuthenTec AES1610  
08FF:2500=AuthenTec Inc. AES2501  
08FF:2501=AuthenTec Inc. AES2501  
08FF:2502=AuthenTec Inc. AES2501  
08FF:2503=AuthenTec Inc. AES2501  
08FF:2504=AuthenTec Inc. AES2501  
08FF:2505=AuthenTec Inc. AES2501  
08FF:2506=AuthenTec Inc. AES2501  
08FF:2507=AuthenTec Inc. AES2501  
08FF:2508=AuthenTec Inc. AES2501  
08FF:2509=AuthenTec Inc. AES2501  
08FF:250A=AuthenTec Inc. AES2501  
08FF:250B=AuthenTec Inc AES2501  
08FF:250C=AuthenTec Inc. AES2501  
08FF:250D=AuthenTec Inc. AES2501  
08FF:250E=AuthenTec Inc. AES2501  
08FF:250F=AuthenTec Inc. AES2501  
08FF:2510=AuthenTec ETEK AES2510  
08FF:2550=AuthenTec Inc. AES2550  
08FF:2580=AuthenTec Inc. AES2501A  
08FF:2588=AuthenTec Inc. AES2501A  
08FF:2589=AuthenTec Inc. AES2501A  
08FF:258A=AuthenTec Inc. AES2501A  
08FF:258B=AuthenTec Inc. AES2501A  
08FF:258C=AuthenTec Inc. AES2501A  
08FF:258D=AuthenTec Inc. AES2501A  
08FF:258E=AuthenTec Inc. AES2501A  
08FF:258F=AuthenTec Inc. AES2501A  
08FF:2810=AuthenTec Inc. AES2810  
08FF:3400=Synaptics AES3400 Sensor  
08FF:3401=Synaptics AES3400 Sensor  
08FF:3402=Synaptics AES3400 Sensor  
08FF:3403=Synaptics AES3400 Sensor  
08FF:3404=AuthenTec AES3400 TruePrint Sensor  
08FF:3405=AuthenTec AES3400 TruePrint Sensor  
08FF:3406=AuthenTec AES3400 TruePrint Sensor  
08FF:3407=AuthenTec AES3400 TruePrint Sensor  
08FF:4902=BioMV with TruePrint AES3500  
08FF:4903=BioMV with TruePrint AES3400  
08FF:5500=AuthenTec AES4000  
08FF:5501=AuthenTec AES4000 TruePrint Sensor  
08FF:5503=AuthenTec AES4000 TruePrint Sensor  
08FF:5505=AuthenTec AES4000 TruePrint Sensor  
08FF:5507=AuthenTec AES4000 TruePrint Sensor  
08FF:55FF=AuthenTec AES4000 TruePrint Sensor  
08FF:5700=AuthenTec AES3500 TruePrint Sensor  
08FF:5701=AuthenTec AES3500 TruePrint Sensor  
08FF:5702=AuthenTec AES3500 TruePrint Sensor  
08FF:5703=AuthenTec AES3500 TruePrint Sensor  
08FF:5704=AuthenTec AES3500-BZ TruePrint Sensor  
08FF:5705=AuthenTec AES3500-BZ TruePrint Sensor

08FF:5706=AuthenTec AES3500-BZ TruePrint Sensor  
08FF:5707=AuthenTec AES3500-BZ TruePrint Sensor  
08FF:5710=AuthenTec AES3500 TruePrint Sensor  
08FF:5711=AuthenTec AES3500 TruePrint Sensor  
08FF:5712=AuthenTec AES3500 TruePrint Sensor  
08FF:5713=AuthenTec AES3500 TruePrint Sensor  
08FF:5714=AuthenTec AES3500-BZ TruePrint Sensor  
08FF:5715=AuthenTec AES3500-BZ TruePrint Sensor  
08FF:5716=AuthenTec AES3500-BZ TruePrint Sensor  
08FF:5717=AuthenTec AES3500-BZ TruePrint Sensor  
08FF:5730=AuthenTec AES3500 TruePrint Sensor  
08FF:5731=AuthenTec AES3500 Fingerprint Reader  
08FF:5732=AuthenTec AES3500 TruePrint Sensor  
08FF:5733=AuthenTec AES3500 TruePrint Sensor  
08FF:5734=AuthenTec AES3500-BZ TruePrint Sensor  
08FF:5735=AuthenTec AES3500-BZ TruePrint Sensor  
08FF:5736=AuthenTec AES3500-BZ TruePrint Sensor  
08FF:5737=AuthenTec AES3500-BZ TruePrint Sensor  
08FF:AFE3=FingerLoc Sensor Module (Anchor)  
08FF:AFE4=FingerLoc Sensor Module (Anchor)  
08FF:AFE5=FingerLoc Sensor Module (Anchor)  
08FF:AFE6=FingerLoc Sensor Module (Anchor)  
08FF:FFFD=AuthenTec AES2510 Sensor (USB Emulator)  
08FF:FFFF=AuthenTec AES1510 Sensor (USB Emulator)  
0900=Pinnacle Systems  
0901=VST Technologies  
0901:0001=USB Hard Drive Adapter (TPP)  
0901:0002=SigmaDrive USB Adapter (TPP)  
0906=FARADAY Technology  
0908=ShenZhen SANZHAI Technology  
0908:2701=Spy Pen VGA  
0909=Audio-Technica  
090A=Trumpion Microelectronics  
090A:1001=T33520 USB Flash Card Controller  
090A:1100=Comotron C3310 MP3 player  
090A:1200=MP3 player  
090A:1540=Digitex Container Flash Disk  
090B=Neurosmith  
090C=Silicon Motion  
090C:0371=Silicon Motion SM371 Camera  
090C:0373=Silicon Motion Camera  
090C:037A=Silicon Motion Camera  
090C:037B=Silicon Motion Camera  
090C:1000=Memory Bar  
090C:1132=5-in-1 Card Reader  
090C:337B=Silicon Motion Camera  
090C:3710=Silicon Motion Camera  
090C:3712=Lenovo EasyCamera  
090C:3713=Lenovo EasyCamera  
090C:3714=Lenovo EasyCamera  
090C:3715=Lenovo EasyCamera  
090C:3716=Lenovo EasyCamera  
090C:3720=Silicon Motion Camera  
090C:37A9=Lenovo EasyCamera  
090C:37B1=Lenovo EasyCamera  
090C:37C0=Silicon Motion Camera  
090C:6000=SD/SDHC Card Reader (SG365 / FlexiDrive XC+)  
090C:6200=microSD card reader  
090C:7371=Lenovo EasyCamera  
090C:837B=Silicon Motion Camera

090C:937B=Silicon Motion Camera  
090C:B370=Silicon Motion SM370 Camera  
090C:B371=Silicon Motion SM371 Camera  
090D=Multiport Computer Vertriebs GmbH  
090E=Shining Technology  
090F=Fujitsu Devices  
0910=Alation Systems  
0911=Philips Speech Processing  
0911:149A=SpeechMike II Pro Plus LFH5276  
0911:2512=Philips SpeechMike Pro  
0912=Voquette  
0915=GlobeSpan  
0915:0001=DSL Modem  
0915:0002=ADSL ATM Modem  
0915:0005=LAN Modem  
0915:2000=802.11 Adapter  
0915:2002=802.11 Adapter  
0915:8000=Eicon Networks USB ADSL WAN Modem  
0915:8005=D-Link DSL-302G Modem  
0915:8101=ADSL WAN Modem  
0915:8102=DSL-200 ADSL Modem  
0915:8103=DSL-200 ADSL Modem  
0915:8104=DSL-200 Modem  
0915:8400=DSL Modem  
0915:8401=DSL Modem  
0915:8402=DSL Modem  
0915:8500=DSL Modem  
0915:8501=DSL Modem  
0917=SmartDisk  
0917:0001=eFilm Reader-11 SM/CF  
0917:0002=eFilm Reader-11 SM  
0917:0003=eFilm Reader-11 CF  
0917:0200=SmartDisk FireFly USB 2.0  
0917:0201=SmartDisk FireLite USB 2.0  
0917:0202=Storage Adapter (FirePower)  
0917:0204=FlashTrax Storage  
0917:0205=Storage Adapter (CrossFire)  
0917:0206=FireFly 20G HDD  
0917:0207=FireLite  
0917:020F=STORAGE ADAPTER (FireLite)  
0917:DA01=eFilm Reader-11 Test  
0917:FFFF=eFilm Reader-11 (Class/PDR)  
0919=Tiger Electronics  
0919:0100=Fast Flicks Digital Camera  
091E=Garmin International  
091E:0003=Garmin USB GPS  
091E:0004=Garmin iQue 3600  
091E:0200=Garmin USB Data Card Programmer (install)  
091E:0400=Garmin USB HS Data Card Programmer (install)  
091E:1200=Garmin USB Data Card Programmer  
091E:21A5=etrex Cx (msc)  
091E:2271=Edge 605/705  
091E:2295=Colorado 300  
091E:22B6=eTrex Vista HCx (Mass Storage mode)  
091E:2353=Nüvi 205T  
091E:2535=Edge 800  
0920=Echelon  
0920:7500=Network Interface  
0921=GoHubs  
0921:1001=GoCOM232 Serial

0922=Dymo  
0922:0007=LabelWriter 330  
0922:0009=LabelWriter 310  
0922:001A=LabelWriter 400 Turbo  
0922:0020=LabelWriter 450  
0923=IC Media  
0923:010F=SIIG MobileCam  
0924=Xerox  
0924:1200=OpenCable Receiver Preproduction Test Device  
0924:23DD=DocuPrint M760 (X760\_USB)  
0924:2401=Xerox WorkCentre M940  
0924:2402=Xerox WorkCentre M950  
0924:3CE8=Phaser 3428 Printer  
0924:3D5B=XEROX Phaser 6115MFP Scanner  
0924:420F=WorkCentre PE220 Series  
0924:421F=M20 Scanner  
0924:423B=Printing Support  
0924:FFEF=WorkCenter M15  
0924:FFFB=DocuPrint M750 (X750\_USB)  
0925=Lakeview Research  
0925:0005=Gamtec.,Ltd SmartJoy PLUS Adapter  
0925:8101=Phidgets, Inc., 1-Motor PhidgetServo v2.0  
0925:8104=Phidgets, Inc., 4-Motor PhidgetServo v2.0  
0925:8800=WiseGroup Ltd, MP-8800 Quad Joypad  
0925:8866=WiseGroup Ltd, MP-8866 Dual Joypad  
0927=Summus  
0928=Oxford Semiconductor  
0928:0002=Oxford Semi USB Disk Drive  
0928:0007=USB2 to SATA Disk Drive #07  
0928:0007:01=USB2 to SATA Management #07  
0928:0008=USB2 to SATA Disk Drive #08  
0928:0008:01=USB2 to SATA Management #08  
0928:0009=USB2 to SATA Disk Drive #09  
0928:0009:01=USB2 to SATA Management #09  
0928:000A=USB2 to SATA Disk Drive #0A  
0928:000A:01=USB2 to SATA Management #0A  
0928:0017=USB2 to SATA Disk Drive  
0928:1000=OXUSB950 Serial Port  
0928:1001=OXUSB954 Serial Port 1  
0928:1001:01=OXUSB954 Serial Port 2  
0928:1001:02=OXUSB954 Serial Port 3  
0928:1001:03=OXUSB954 Serial Port 4  
0928:8000=Oxford USB Device, running upload acceleration fragment  
0928:FFFF=Oxford USB Device, blank no firmware  
0929=American Biometric  
092A=Toshiba Information & Industrial Sys. And Services  
092B=Sena Technologies  
092F=Northern Embedded Science/CAVNEX  
092F:0004=JTAG-4  
092F:0005=JTAG-5  
0930=Toshiba  
0930:0009=Gigabeat F/X (HDD audio player)  
0930:000C=Gigabeat F (mtp)  
0930:0010=Gigabeat S (mtp)  
0930:0200=TAIYO YUDEN Bluetooth Controller EYTFEBSAX-A  
0930:020F=ASKEY Bluetooth Controller BTU1030  
0930:0213=Bluetooth USB Controller-8 from TOSHIBA  
0930:0214=Bluetooth USB Controller-9 from TOSHIBA  
0930:0301=PCX1100U Cable Modem (WDM)  
0930:0302=PCX2000 Cable Modem (WDM)

0930:0305=Cable Modem PCX3000  
0930:0307=Cable Modem PCX2500  
0930:0308=MCCI USB Cable Modem Enumerator (WDM)  
0930:0309=PCX5000 Cable Modem (WDM)  
0930:030B=Cable Modem PCX2600  
0930:0501=Bluetooth USB Controller from TOSHIBA (ALPS/CSR)  
0930:0502=TOSHIBA Integrated Bluetooth  
0930:0502:1350=TOSHIBA Integrated Bluetooth  
0930:0503=Bluetooth USB Controller-2 from TOSHIBA  
0930:0505=TOSHIBA Integrated Bluetooth 2  
0930:0506=TOSHIBA Integrated Bluetooth 3  
0930:0507=TOSHIBA Bluetooth Adapter  
0930:0508=TOSHIBA Bluetooth Adapter  
0930:0509=TOSHIBA Bluetooth adapter  
0930:0700=TOSHIBA USB Sync 0700  
0930:0705=TOSHIBA Pocket PC e310  
0930:0706=TOSHIBA Pocket PC e740  
0930:0707=TOSHIBA Pocket PC e330 Series  
0930:0708=TOSHIBA Pocket PC e350 Series  
0930:0709=TOSHIBA Pocket PC e750 Series  
0930:070A=TOSHIBA Pocket PC e400 Series  
0930:070B=TOSHIBA Pocket PC e800 Series  
0930:0747=Askey BT Slim Module  
0930:0749=Broadcom Bluetooth 2.1 + EDR USB Device  
0930:0A05=TOSHIBA Bluetooth Adaptor-3  
0930:0A07=WLM-10U1 802.11abgn Wireless Adapter [Ralink RT3572]  
0930:0B05=PX1220E-1G25 External hard drive  
0930:0B09=PX1396E-3T01 External hard drive  
0930:1300=Toshiba Broadband (CDMA EV-DO) SM-Bus Minicard Modem  
0930:1300:01=Toshiba Broadband (CDMA EV-DO) SM-Bus Minicard Status Port  
0930:1300:02=Toshiba Broadband (CDMA EV-DO) SM-Bus Minicard Diagnostics Port  
0930:1300:03=Toshiba Broadband (CDMA EV-DO) SM-Bus Minicard GPS Port  
0930:1301=Toshiba Broadband (CDMA EV-DO) Minicard Modem  
0930:1301:01=Toshiba Broadband (CDMA EV-DO) Minicard Status Port  
0930:1301:02=Toshiba Broadband (CDMA EV-DO) Minicard Diagnostics Port  
0930:1301:03=Toshiba Broadband (CDMA EV-DO) Minicard GPS Port  
0930:1302=Toshiba Broadband (3G HSDPA) SM-Bus Minicard Modem  
0930:1302:01=Toshiba Broadband (3G HSDPA) SM-Bus Minicard Status Port  
0930:1302:02=Toshiba Broadband (3G HSDPA) SM-Bus Minicard Diagnostics Port  
0930:1302:03=Toshiba Broadband (3G HSDPA) SM-Bus Minicard EAP-SIM Port  
0930:1303=Toshiba Broadband (3G HSDPA) Minicard Modem  
0930:1303:01=Toshiba Broadband (3G HSDPA) Minicard Status Port  
0930:1303:02=Toshiba Broadband (3G HSDPA) Minicard Diagnostics Port  
0930:1303:03=Toshiba Broadband (3G HSDPA) Minicard EAP-SIM Port  
0930:1308=Broadband (3G HSDPA) SM-Bus Minicard Diagnostics Port  
0930:130B=Toshiba F3507g Mobile Broadband Network Adapter  
0930:130B:01=Toshiba F3507g Mobile Broadband Modem  
0930:130B:03=Toshiba F3507g Mobile Broadband Data Modem  
0930:130B:05=Toshiba F3507g Mobile Broadband Device Management  
0930:130C=F3607gw Mobile Broadband Module  
0930:1311=F3607gw v2 Mobile Broadband Module  
0930:1400=Memory Stick 2GB  
0930:642F=TravelDrive  
0930:6506=TravelDrive 2C  
0930:6507=TravelDrive 2C  
0930:6508=TravelDrive 2C  
0930:6509=TravelDrive 2C  
0930:6510=TravelDrive 2C  
0930:6517=TravelDrive 2C  
0930:6518=TravelDrive 2C

0930:6519=Kingston DataTraveler 2.0 USB Stick  
0930:651A=TravelDrive 2C  
0930:651B=TravelDrive 2C  
0930:651C=TravelDrive 2C  
0930:651D=TravelDrive 2C  
0930:651E=TravelDrive 2C  
0930:651F=TravelDrive 2C  
0930:6520=TravelDrive 2C  
0930:6521=TravelDrive 2C  
0930:6522=TravelDrive 2C  
0930:6523=TravelDrive  
0930:6524=TravelDrive  
0930:6525=TravelDrive  
0930:6526=TravelDrive  
0930:6527=TravelDrive  
0930:6528=TravelDrive  
0930:6529=TravelDrive  
0930:652A=TravelDrive  
0930:652B=TravelDrive  
0930:652C=TravelDrive  
0930:652D=TravelDrive  
0930:652F=TravelDrive  
0930:6530=TravelDrive  
0930:6531=TravelDrive  
0930:6532=256M USB Stick  
0930:6533=512M USB Stick  
0930:6534=TravelDrive  
0930:653C=Kingston DataTraveler 2.0 USB Stick (512M)  
0930:653D=USB Flash Memory  
0930:653E=USB Flash Memory  
0930:6540=TransMemory USB Flash Memory  
0930:6544=Kingston DataTraveler 2.0 USB Stick (2GB)  
0930:6545=Kingston DataTraveler 2.0 Stick (4GB) / PNY Attache 4GB Stick  
0931=Harmonic Data Systems  
0932=Crescentec  
0932:0300=VideoAdvantage  
0932:0302=Syntek DC-112X  
0932:0320=VideoAdvantage  
0932:0482=USB2.0 TVBOX  
0932:1100=Video Enhancement Device  
0932:1112=Vevo Web Camera  
0932:1112:01=Vevo Web Camera Control  
0932:1112:02=Vevo Web Camera Microphone  
0932:A311=Video Enhancement Device  
0933=Quantum  
0934=Netcom Systems  
0936=NuTesla  
0936:0030=Composite Device, Mass Storage Device (Flash Drive) and HID  
0936:003C=Rhythmmedics HID Bootloader  
0939=Lumberg  
0939:0B15=USB to SATA Bridge  
093A=Pixart Imaging  
093A:0007=CMOS 100K-R Rev. 1.90  
093A:010E=Digital camera, CD302N/Elta Medi@ digi-cam/HE-501A  
093A:010F=Argus DC-1610/DC-1620/Emprex PCD3600/Philips P44417B keychain camera/Precision Mini, Model HA513A/Vivitar Vivicam 55  
093A:020F=Bullet Line Photo Viewer  
093A:050F=Mars-Semi Pc-Camera  
093A:2460=Q-TEC WEBCAM 100  
093A:2468=Easy Snap Snake Eye WebCam

093A:2470=SoC PC-Camera  
093A:2471=SoC PC-Camera  
093A:2472=Eye 110  
093A:2476=e-Messenger 112  
093A:2500=USB Optical Mouse  
093A:2500:0100=USB Human Interface Device  
093A:2510=Hama Optical Mouse  
093A:2510:0100=USB Human Interface Device  
093A:2600=Typhoon Easycam USB 330K (newer)/Typhoon Easycam USB 2.0 VGA 1.3M/Sans  
un SN-508  
093A:2601=SPC 610NC Laptop Camera  
093A:2603=Philips SPC500NC Webcam  
093A:2608=PAC7311 Trust WB-3300p  
093A:260E=PAC7311 Gigaware VGA PC Camera:Trust WB-3350p:SIGMA cam 2350  
093A:260F=PAC7311 SnakeCam  
093A:2620=PC Camera  
093A:2621=PAC731x Trust Webcam  
093A:2622=Eye 312  
093A:2624=e-Messenger 310  
093A:2625=iSlim 310  
093A:2626=iLook 310  
093A:2628=PC Camera  
093A:262A=PC VGA Camer@ Plus  
093B=Plextor  
093B:0000=USB Storage Adapter  
093B:0010=USB Storage Adapter  
093B:0011=PlexWriter 40/12/40U  
093B:0041=PX-708A DVD RW  
093B:0042=PX-712UF DVD RW  
093B:A002=ConvertX M402U XLOADER  
093B:A003=ConvertX AV100U A/V Capture Audio  
093B:A004=ConvertX TV402U XLOADER  
093B:A005=KWorld EMP Audio Device  
093B:A102=ConvertX M402U A/V Capture  
093B:A104=ConvertX PX-TV402U/NA  
093C=Intrepid Control Systems  
093C:0601=ValueCAN  
093C:0701=NeoVI Blue vehicle bus interface  
093D=InnoSync  
093E=J.S.T.  
093F=Olympia Telecom Vertriebs GmbH  
0940=Japan Storage Battery  
0941=Photobit  
0942=i2Go.com, LLC  
0943=HCL Technologies  
0944=KORG  
0944:0001=PxR4 4-Track Digital Recorder  
0944:000F=USB 2.0 Mass Storage Device  
0944:0020=KAOSS Pad KP3 Dynamic Effect/Sampler  
0944:010D=nanoKEY MIDI keyboard  
0944:010E=nanoPAD pad controller  
0944:010F=nanoKONTROL studio controller  
0944:0F03=K-Series K61P MIDI studio controller  
0945=Pasco Scientific  
0948=Kronauer music in digital  
0948:0301=USB Pro (24/48)  
0948:0302=USB Pro (24/96 playback)  
0948:0303=USB Pro (24/96 record)  
0948:0304=USB Pro (16/48)  
0948:1105=USB One



094B=Linkup Systems  
094B:0001=Linkup Systems USB Sync  
094D=Cable Television Laboratories  
094F=Yano  
094F:0101=U640MO-03  
094F:05FC=METALWEAR-HDD  
0951=Kingston Technology  
0951:0008=Kingston Technology USB Ethernet Adapter  
0951:000A=KNU101TX 100baseTX Ethernet  
0951:1600=Data Traveler II Pen Drive  
0951:1601=Data Traveler II+ Pen Drive  
0951:1602=Data Traveler Mini  
0951:1603=Data Traveler 2.0 Pen Drive  
0951:1603:0200=Data Traveler 2.0 Pen Drive  
0951:1606=Eee PC 701 SD Card Reader [ENE UB6225]  
0951:1607=Data Traveler 2.0 Pen Drive  
0951:160B=Data Traveler 2.0 Pen Drive  
0951:160B:0100=Data Traveler 2.0 Pen Drive  
0951:1613=Data Traveler 8GB Pen Drive  
0951:1616=Kingston DataTraveler Locker (4GB)  
0951:1624=Data Traveler G2 Pen Drive  
0951:1625=DataTraveler 101 II  
0951:162A=DataTraveler 112 4GB Pen Drive  
0951:1642=DataTraveler 101 G2  
0951:1643=DataTraveler G3 4GB  
0954=RPM Systems  
0955=NVIDIA  
0955:0007=NVIDIA Stereoscopic 3D USB controller  
0955:7001=NVIDIA Stereoscopic 3D USB controller  
0955:7002=NVIDIA Stereoscopic 3D USB controller  
0955:7003=NVIDIA Stereoscopic 3D USB controller  
0955:7004=NVIDIA 3D Vision Pro Hub  
0955:7100=Notion Ink Adam  
0956=BSquare  
0957=Agilent Technologies  
0957:0200=E-Video DC-350 Camera  
0957:0202=E-Video DC-350 Camera  
0958=CompuLink Research  
0959=Cologne Chip AG  
0959:2BD0=Intelligent ISDN (Ver. 3.60.04)  
095A=Portsmith  
095A:3003=Portsmith Express Ethernet Adapter  
095B=Medialogic  
095C=K-Tec Electronics  
095D=Polycom  
095D:0001=Polycom ViaVideo  
0960:0065=BCOM USB Sync 0065  
0960:0066=BCOM USB Sync 0066  
0960:0067=BCOM USB Sync 0067  
0961:0010=Portatec USB Sync  
0967=Acer (??)  
0967:0204=WarpLink 802.11b Adapter  
0968=Catalyst Enterprises  
096E=Feitian Technologies  
096E:0001=Feitian ROCKEY4 USB  
096E:0802=ePass2000 (G&D STARCOS SPK 2.4)  
0971=Gretag-Macbeth AG  
0971:2000=eye-one  
0971:2001=eye-one monitor  
0971:2003=i1 Display

0971:2004=Eye-One iO  
0971:2005=Huey  
0971:2007=ColorMunki  
0973=Schlumberger  
0973:0001=e-gate Smart Card  
0973:0003=e-gate Smart Card  
0974=Datagraphix, a business unit of Anacomp  
0975=OL'E Communications  
0976=Adirondack Wire & Cable  
0977=Lightsurf Technologies  
0978=Beckhoff GmbH  
0979=Jeilin Technology  
0979:0224=JL2005A Toy Camera  
0979:0226=JL2005A Toy Camera  
0979:0227=JL2005B/C/D Toy Camera  
097A=Minds At Work LLC  
097A:0001=Digital Wallet  
097B=Knudsen Engineering  
097C=Marunix  
097D=Rosun Technologies  
097F=Barun Electronics  
0981=Oak Technology  
0984=Apricorn  
0984:0200=Apricorn USB Hard Drive Storage (TPP)  
0985=cab Produkttechnik  
0985:0045=Mach4/200 Label Printer  
0985:00A3=A3/200 or A3/300 Label Printer  
0986=Matsushita Electric Works  
098C=Vitana  
098D=INDesign  
098E=Integrated Intellectual Property  
098F=Kenwood TMI  
0993=Gemstar eBook Group  
0993:0001=REB1100 eBook Reader  
0993:0002=eBook  
0996=Integrated Telecom Express  
099A=Zippy Technology  
099A:0638=Sanwa Supply Inc. Small Keyboard  
099A:610C=EL-610 Super Mini Electron luminescent Keyboard  
099A:7160=Hyper Slim Keyboard  
099A:7501:01=Zippy Gaming Keyboard Controller  
099A:9000=Office Keyboard  
099E:0052=Trimble GeoExplorer  
099E:4000=TDS Data Collector  
09A3=PairGain Technologies  
09A4=Contech Research  
09A5=VCON Telecommunications  
09A6=Poinchips  
09A6:8001=USB Mass Storage Device  
09A7=Data Transmission Network  
09A8=Lin Shiung Enterprise  
09A9=Smart Card Technologies  
09AA=Intersil  
09AA:1000=IEEE 802.11g USB  
09AA:3642=Prism2.x 802.11b Adapter  
09AB=Japan Cash Machine  
09AE=Tripp Lite  
09B2=Franklin Electronic Publishers  
09B2:0001=eBookman Palm Computer  
09B3=Altius Solutions

09B4=MDS Telephone Systems  
09B5=Celltrix Technology  
09BC=Grundig  
09BC:0002=MPaxx MP150 MP3 Player  
09BE=MySmart.Com  
09BE:0001=MySmartPad  
09BF=Auerswald  
09BF:00C0=COMpact 2104 ISDN PBX  
09BF:00DB=COMpact 4410/2206 ISDN ISDN  
09BF:00F1=COMfort System Telephones  
09C0=Genpix Electronics, LLC  
09C0:0202=8PSK DVB-S tuner  
09C0:0203=Skywalker-1 DVB-S tuner  
09C0:0204=Skywalker-CW3K DVB-S tuner  
09C0:0205=Skywalker-CW3K DVB-S tuner  
09C0:0206=Skywalker-2 DVB-S tuner  
09C1=Arris Interactive LLC  
09C1:1337=ARRIS TOUCHSTONE DEVICE  
09C2=NISCA  
09C3=ACTIVCARD  
09C3:0002=SmartReader-BIO  
09C3:0003=ActivKey  
09C3:0004=SmartReader-USB  
09C3:0007=Reader V2  
09C3:0008=SmartCard Reader  
09C3:0013=USB Reader V3  
09C3:0014=ActivKey Sim  
09C3:0015=USB Reader V4  
09C3:0017=ActivKey Display  
09C4=ACTiSYS  
09C4:0011=ACT-IR2000U IrDA Dongle  
09C5=Memory  
09CC=Workbit  
09CC:0404=BAFO USB-ATA/ATAPI Bridge Controller  
09CD=Psion Dacom Home Networks  
09CD:2001=Psion WaveFinder DAB radio receiver  
09CE=City Electronics  
09CF=Electronics Testing Center, Taiwan  
09D1=NeoMagic  
09D2=Vreelin Engineering  
09D3=Com One  
09D3:0001=ISDN TA  
09D3:000A=Bluetooth Devices  
09D3:3001=Bluetooth Devices  
09D7=Novatel Wireless  
09D7:0100=NovAtel FlexPack GPS receiver  
09D9=KRF Tech  
09DA=A4Tech  
09DA:0006=USB Port Mouse  
09DA:000A=USB Port Mouse  
09DA:0018=USB Port Mouse  
09DA:001A=USB Port Mouse  
09DA:001E=USB Port Mouse  
09DA:002A=Wireless Optical Mouse NB-30  
09DA:0080=USB Laser Mouse  
09DA:0080:020C=USB Laser Mouse XL-750BF  
09DA:010B=USB Port Mouse  
09DA:022B=Wireless Mouse (Battery Free)  
09DA:024F=G6-20D Wireless Keyboard  
09DA:024F:01=G6-20D Wireless Mouse

09DA:032B=Wireless Mouse (Battery Free)  
09DA:8090=X-718BK Oscar Optical Gaming Mouse  
09DA:9090=XL-750BK Laser Mouse  
09DB=Measurement Computing  
09DB:0075=MiniLab 1008  
09DB:0076=PMD-1024  
09DB:007A=PMD-1208LS  
09DB:0081=USB-1616FS  
09DB:0082=USB-1208FS  
09DB:0088=USB-1616FS Internal USB Hub  
09DC=Aimex  
09DD=Fellowes  
09DF=Addonics Technologies  
09E1=Intellon  
09E1:5121=MicroLink dLAN  
09E5=Jo-Dan International  
09E6=Silutia  
09E7=Real 3D  
09E8=AKAI professional M.I.  
09E8:0062=MPD16 MIDI Pad Controller Unit  
09E8:006D=EWI electronic wind instrument  
09E8:0071=MPK25 MIDI Keyboard  
09E8:0076=LPK25 MIDI Keyboard  
09E9=CHEN-SOURCE INC.  
09EB=IM Networks  
09EB:4331=iRhythm Tuner Remote  
09EF=Xitel  
09EF:0101=MD-Port DG2 MiniDisc Interface  
09F3=GoFlight  
09F3:0018=GF-46 Multi-Mode Display Module  
09F3:0028=RP-48 Combination Pushbutton-Rotary Module  
09F3:0048=LGTII - Landing Gear and Trim Control Module  
09F3:0064=MCP Pro Airliner Auto-Pilot  
09F3:0300=EFIS - Electronic Flight Information System  
09F5=AresCom  
09F5:0168=Network Adapter  
09F5:0188=LAN Adapter  
09F5:0850=Adapter  
09F6=RocketChips  
09F7=Edu-Science (H.K.)  
09F8=SoftConnex Technologies  
09F9=Bay Associates  
09FA=Mtek Vision  
09FB=Altera  
09FB:6001=Blaster  
09FF=Gain Technology  
0A00=Liquid Audio  
0A01=Via  
0A07=Ontrak Control Systems  
0A07:0064=ADU100 Data Acquisition Interface  
0A07:0078=ADU120 Data Acquisition Interface  
0A07:0082=ADU130 Data Acquisition Interface  
0A07:00C8=ADU200 Relay I/O Interface  
0A07:00D0=ADU208 Data Acquisition Interface  
0A07:00DA=ADU218 Solid-State Relay I/O Interface  
0A0B=Cybex Computer Products  
0A0E:0011=Deutsche Telekom Eumex 5000PC  
0A11=Xentec  
0A12=Cambridge Silicon  
0A12:0001=Windigo BTM01C2AC Bluetooth Adapter

0A12:0001:0373=Wave Linker BTM01C2AC Bluetooth Adapter  
0A12:0002=Frontline Test Equipment Bluetooth Device  
0A12:0003=CSR Nanosira  
0A12:0004=CSR Nanosira WHQL Reference Radio  
0A12:0005=CSR Nanosira-Multimedia  
0A12:0006=CSR Nanosira-Multimedia WHQL Reference Radio  
0A12:0007=CSR Nanosira3-ROM  
0A12:0008=CSR Nanosira4-EDR  
0A12:0009=CSR Nanosira4-EDR WHQL Reference Radio  
0A12:000A=CSR Nanosira4-EDR-ROM  
0A12:000B=CSR Nanosira5-ROM  
0A12:0043=CSR Bluetooth Radio  
0A12:0044=PCSBU Host Controller  
0A12:0100=CSR Casira with BlueCore2-External Module  
0A12:0101=CSR Casira with BlueCore2-Flash Module  
0A12:0102=CSR Casira with BlueCore3-Multimedia Module  
0A12:0103=CSR Casira with BlueCore3-Flash Module  
0A12:0104=CSR Casira with BlueCore4-External Module  
0A12:0105=CSR Casira with BlueCore4-Multimedia Module  
0A12:1000=Bluetooth Dongle (HID proxy mode)  
0A12:1010=Bluetooth Device  
0A12:1011=Bluetooth Device  
0A12:1012=Bluetooth Device  
0A12:FFFF=CSR Bluetooth Device  
0A13=Telebyte  
0A14=Spacelabs Medical  
0A15=Scalar  
0A16=Trek Technology (S) Pte  
0A16:1111=ThumbDrive  
0A16:8888=IBM USB Memory Key  
0A16:9988=Trek2000 TD-G2  
0A17=PENTAX  
0A17:0004=Pentax Optio 330  
0A17:0006=Pentax Optio S  
0A17:0007=Pentax Optio 550  
0A17:0009=Pentax Optio 33WR  
0A17:000A=Pentax Optio 555  
0A17:000C=Pentax Optio 43WR (mass storage mode)  
0A17:000D=Pentax Optio 43WR  
0A17:0015=Pentax Optio S40/S5i  
0A17:003B=Pentax Optio 50 (mass storage mode)  
0A17:003D=Pentax Optio S55  
0A17:0043=Pentax \*ist DL  
0A17:0047=Pentax Optio S60  
0A17:0052=PENTAX Optio 60 Digital Camera  
0A17:0062=PENTAX Optio 50L Digital Camera  
0A17:0065=PENTAX Optio E10 Digital Camera  
0A17:006E=Pentax K10D  
0A17:0070=Pentax K100D  
0A17:0093=K200D  
0A17:00A7=Optio E50  
0A17:1001=Pentax EI2000 Camera powered by Digita!  
0A17:1001:0101=Pentax EI2000 Camera powered by Digita!  
0A18=Heidelberger Druckmaschinen AG  
0A19=Hua Geng Technologies  
0A1C:0001=SoftGSM Cable Adapter  
0A1C:1000=SoftGSM USB Modem  
0A21=Medtronic Physio Control  
0A21:8001=MMT-7305WW [Medtronic Minimed CareLink]  
0A22=Century Semiconductor USA

0A27=Datacard Group  
0A27:0102=SP35  
0A2C=AK-Modul-Bus Computer GmbH  
0A2C:0002=Modul-Bus GmbH, CompuLAB-USB  
0A2C:0008=Port-Chip GPIO Ports  
0A34=TG3 Electronics  
0A34:0101=TG82tp  
0A34:0110=Deck 82-key backlit keyboard  
0A35=Radikal Technologies  
0A35:002A=SAC - Software Assigned Controller  
0A35:008A=SAC Hub  
0A39=Gilat Satellite Networks  
0A3A=PentaMedia  
0A3A:0163=KN-W510U 1.0 USB Wireless LAN Adapter  
0A3C=NTT DoCoMo, Inc.  
0A3D=Varo Vision  
0A3F=Swissonic AG  
0A43=Boca Systems  
0A46=Davicom Semiconductor  
0A46:0268=ST268  
0A46:6688=ZT6688 Fast Ethernet Adapter  
0A46:8515=ADMtek ADM8515 NIC  
0A46:9000=DM9000E Fast Ethernet Adapter  
0A46:9601=DM9601 USB To Fast Ethernet Adapter  
0A47=Hirose Electric  
0A48=I/O Interconnect  
0A48:3233=Multimedia Card Reader  
0A48:3239=USB Multimedia Card Reader  
0A48:323A=USB Mass Storage Device  
0A48:323B=USB Mass Storage Device  
0A48:323C=USB Mass Storage Device  
0A48:3258=Dane Elec zMate SD Reader  
0A48:3259=Dane Elec zMate CF Reader  
0A48:3282=eHome Infrared Receiver (USBCIR)  
0A48:3302=Realtek USB 2.0 Card Reader  
0A48:5000=MediaGear xD-SM  
0A48:500A=Mass Storage Device  
0A48:500F=Mass Storage Device  
0A48:5010=Mass Storage Device  
0A48:5011=Mass Storage Device  
0A48:5014=Mass Storage Device  
0A48:5020=Mass Storage Device  
0A48:5021=Mass Storage Device  
0A48:5022=Mass Storage Device  
0A48:5023=Mass Storage Device  
0A48:5024=Mass Storage Device  
0A48:5025=Mass Storage Device  
0A4B=Fujitsu Media Devices  
0A4C=COMPUTEX  
0A4C:15D9=OPTICAL MOUSE  
0A4D=Evolution Electronics  
0A4D:0064=MK-225 Driver  
0A4D:0065=MK-225C Driver  
0A4D:0066=MK-225C Driver  
0A4D:0067=MK-425C Driver  
0A4D:0078=MK-37 Driver  
0A4D:0079=MK-37C Driver  
0A4D:007A=MK-37C Driver  
0A4D:008C=TerraTec MIDI MASTER  
0A4D:008D=MK-249C Driver

0A4D:008E=MK-249C MIDI Keyboard  
0A4D:008F=MK-449C Driver  
0A4D:0090=Keystation 49e Driver  
0A4D:0091=Keystation 61es Driver  
0A4D:00A0=MK-361 Driver  
0A4D:00A1=MK-361C Driver  
0A4D:00A2=MK-361C Driver  
0A4D:00A3=MK-461C MIDI Keyboard  
0A4D:00B5=Keystation Pro 88 Driver  
0A4D:00D2=E-Keys Driver  
0A4D:00F0=UC-16 Driver  
0A4D:00F1=X-Session Driver  
0A4D:00F5=UC-33e MIDI Controller  
0A4E=Steinberg Soft-und Hardware GmbH  
0A4F=Litton Systems  
0A50=Mimaki Engineering  
0A51=Sony Electronics  
0A52=Jebsee Electronics  
0A53=Portable Peripheral  
0A53:1000=Portable Scanner  
0A53:2000=Q-Scan A6 Scanner  
0A53:2001=Q-Scan A6 Scanner  
0A53:2013=Media Drive A6 Scanner  
0A53:2014=Media Drive A6 Scanner  
0A53:2015=BizCardReader 600C  
0A53:2016=BizCardReader 600C  
0A53:202A=Scanshell-CSSN  
0A53:3000=Q-Scan A8 Scanner  
0A53:3002=Q-Scan A8 Reader  
0A53:3015=BizCardReader 300G  
0A53:302A=LM9832 - PA570 Mini Business Card Scanner [Targus]  
0A53:5001=BizCardReader 900C  
0A5A=Electronics For Imaging  
0A5B=EAsics NV  
0A5C=Broadcom  
0A5C:0000=Dell ControlVault  
0A5C:0201=Broadcom USB iLine10(tm) Network Adapter  
0A5C:2000=Broadcom Bluetooth Firmware Upgrade Device  
0A5C:2001=Broadcom USB Bluetooth Adapter  
0A5C:2009=MSI BToes Bluetooth Device  
0A5C:200A=Blutonium BCM2035 Bluetooth 2.4 GHz Single Chip Transceiver  
0A5C:200F=BCM2033 Bluetooth 2.4 GHz Single Chip Transceiver  
0A5C:201D=BROADCOM Bluetooth Device  
0A5C:201E=IBM Integrated Bluetooth IV  
0A5C:2020=MSI BToes Bluetooth Device  
0A5C:2021=BCM2035B3 Bluetooth Adapter  
0A5C:2033=Broadcom Blutonium Device Firmware Downloader (BCM2033)  
0A5C:2035=BCM2035 Bluetooth  
0A5C:2038=Broadcom Blutonium Device Firmware Downloader (BCM2038)  
0A5C:2039=BROADCOM Bluetooth Device  
0A5C:2045=Broadcom USB Bluetooth Device  
0A5C:2046=Bluetooth Device  
0A5C:2047=Bluetooth Device  
0A5C:205E=Broadcom Bluetooth Firmware Upgrade Device  
0A5C:2070=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0A5C:2100=Broadcom 2045 Bluetooth 2.0 USB-UHE Device  
0A5C:2101=Broadcom 2045 Bluetooth 2.0+EDR USB Device  
0A5C:2102=ANYCOM Blue USB-200/250  
0A5C:2110=IBM Integrated Bluetooth module  
0A5C:2111=ANYCOM USB-200/250 Bluetooth Adapter

0A5C:2112=Teac BCM 2045 Bluetooth Device  
0A5C:2119=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0A5C:2120=Broadcom Ultimate Low Cost Bluetooth 2.0+EDR USB dongle  
0A5C:2121=Broadcom Ultimate Low Cost Bluetooth 2.0+EDR USB dongle  
0A5C:2122=Bluetooth 2.0+EDR dongle  
0A5C:2123=Broadcom 2045 Bluetooth 2.0 USB Dongle  
0A5C:2124=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:2130=Broadcom 2045 Bluetooth 2.0 USB-UHE Device  
0A5C:2131=Broadcom 2045 Bluetooth 2.0 USB Device  
0A5C:2131:01=Broadcom USB Wireless Modem  
0A5C:2132=Broadcom USB Wireless Modem  
0A5C:2140=2046 Flash UHE Class 2  
0A5C:2141=2046 Flash non UHE Class 2  
0A5C:2142=2046 Flash UHE Class 1  
0A5C:2143=2046 Flash non UHE Class 1  
0A5C:2144=2046 Flash non UHE module class 2  
0A5C:2145=ThinkPad Bluetooth 2.1 with Enhanced Data Rate  
0A5C:2146=Broadcom 2046 Bluetooth 2.1 USB UHE Dongle  
0A5C:2147=Broadcom 2046 Bluetooth 2.1 USB Dongle  
0A5C:2148=Broadcom 2046 Bluetooth 2.1 USB UHE Dongle  
0A5C:2149=Broadcom 2046 Bluetooth 2.1 USB Dongle  
0A5C:214A=Broadcom 2046 Bluetooth 2.1 USB Module  
0A5C:214B=Broadcom 2046 Bluetooth 2.1 USB Module  
0A5C:214C=Broadcom 2046 Bluetooth 2.1 USB Module  
0A5C:214D=Broadcom Bluetooth 2.1 UHE Module  
0A5C:214E=ThinkPad Bluetooth with Enhanced Data Rate II  
0A5C:214F=Broadcom 2046 Bluetooth 2.1 USB UHE Dongle  
0A5C:2150=BCM2046 Bluetooth Module  
0A5C:2151=BCM2046 Bluetooth Module  
0A5C:2152=Broadcom 2046 Bluetooth 2.1 USB UHE Dongle  
0A5C:2153=Broadcom 2046 Bluetooth 2.1 USB UHE Dongle.  
0A5C:2154=Broadcom 2046 Bluetooth 2.1 USB UHE Dongle.  
0A5C:2155=Broadcom Bluetooth 3.0 USB  
0A5C:2156=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:2157=BCM2046 B1 USB 500  
0A5C:2158=Broadcom 2046 Bluetooth 2.1 Device  
0A5C:2159=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:215A=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:215B=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:215C=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:215D=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:215E=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:215F=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:2160=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:2161=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:2162=Broadcom 2046 Bluetooth 2.1+EDR USB Device  
0A5C:2164=ThinkPad Bluetooth with Enhanced Data Rate II  
0A5C:2170=Broadcom Bluetooth 2.1 + EDR USB Device  
0A5C:2171=Broadcom Secure Bluetooth Device  
0A5C:2172=Broadcom Secure Bluetooth Device  
0A5C:2173=BCM94321COEX2REF  
0A5C:217D=HP Bluetooth module  
0A5C:217E=ThinkPad Bluetooth 3.0  
0A5C:217F=ThinkPad Bluetooth 2.1 with Enhanced Data Rate II  
0A5C:2180=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0A5C:2181=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0A5C:2182=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0A5C:2183=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0A5C:2184=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0A5C:2185=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device





0A5C:21C3=BCM20702 Bluetooth 4.0 +HS USB Device  
0A5C:21C4=BCM20702 Bluetooth 4.0 +HS USB Device  
0A5C:22BE=BCM2070 Bluetooth 3.0 + HS  
0A5C:4500=BCM2046B1 USB 2.0 Hub (part of BCM2046 Bluetooth)  
0A5C:4502=USB Human Interface Device  
0A5C:4503=USB Human Interface Device  
0A5C:5800=BCM5880 Secure Applications Processor  
0A5C:5800:0101=Dell ControlVault w/o Fingerprint Sensor  
0A5C:5800:0101:01=Broadcom Usbccid Smartcard Reader (WUDF)  
0A5C:5800:0101:02=Broadcom Usbccid Smartcard Reader (WUDF)  
0A5C:5801=BCM5880 Secure Applications Processor with fingerprint swipe sensor  
0A5C:5801:0101=Dell ControlVault w/ Fingerprint Swipe Sensor  
0A5C:5801:0101:01=Broadcom Usbccid Smartcard Reader (WUDF)  
0A5C:5801:0101:02=Broadcom Usbccid Smartcard Reader (WUDF)  
0A5C:5801:0101:03=Control Vault w/ Fingerprint Swipe Sensor  
0A5C:5802=BCM5880 Secure Applications Processor with fingerprint touch sensor  
0A5C:5802:0101=Dell ControlVault w/ Fingerprint Touch Sensor  
0A5C:5802:0101:01=Broadcom Usbccid Smartcard Reader (WUDF)  
0A5C:5802:0101:02=Broadcom Usbccid Smartcard Reader (WUDF)  
0A5C:5802:0101:03=Control Vault w/ Fingerprint Touch Sensor  
0A5C:5803=BCM5880 Secure Applications Processor with secure keyboard  
0A5C:5803:0101:01=Dell ControlVault w/ Secure Keyboard  
0A5C:5804=Dell ControlVault 0x5804  
0A5C:5804:0101=Dell ControlVault w/ Fingerprint Swipe Sensor  
0A5C:5804:0101:02=Broadcom Usbccid Smartcard Reader (WUDF)  
0A5C:5804:0101:03=Broadcom Usbccid Smartcard Reader (WUDF)  
0A5C:5805=Dell ControlVault 0x5805  
0A5C:5805:0101=Dell ControlVault w/ Fingerprint Touch Sensor  
0A5C:5805:0101:02=Broadcom Usbccid Smartcard Reader (WUDF)  
0A5C:5805:0101:03=Broadcom Usbccid Smartcard Reader (WUDF)  
0A5C:5810=Dell ControlVault 2  
0A5C:6300=Pirelli Remote NDIS Device  
0A5C:8170=Broadcom Secure Bluetooth Device  
0A5C:BD13=Arcadyan WN8522B [Broadcom BCM4323]  
0A5C:D11B=Eminent EM4045 [Broadcom 4320 USB]  
0A5D=Diatrend  
0A5F=Zebra  
0A5F:0009=LP2844 Printer  
0A5F:0081=GK420t Label Printer  
0A5F:008B=HC100 wristbands Printer  
0A5F:930A=USB Printer  
0A62=MpMan  
0A62:0010=MpMan MP-F40 MP3 Player  
0A66=ClearCube Technology  
0A67=Medeli Electronics  
0A68=COMAIDE  
0A69=Chroma ate  
0A6B=Green House  
0A6B:0001=Compact Flash R/W with MP3 player  
0A6B:000F=FlashDisk  
0A6C=Integrated Circuit Systems  
0A6D=UPS Manufacturing  
0A6E=Benwin  
0A6F=Core Technology  
0A6F:0400=Xanboo  
0A70=International Game Technology  
0A71=VIPColor Technologies USA  
0A71:0001=VP485 Printer  
0A72=Sanwa Denshi  
0A7A:6143=CHIPDRIVE SmartCardReader (USB)

0A7D=NSTL  
0A7E=Octagon Systems  
0A80=Rexon Technology  
0A81=CHESEN ELECTRONICS  
0A81:0101=Keyboard  
0A81:0103=Keyboard  
0A81:0203=Mouse  
0A81:0205=PS/2 Keyboard+Mouse Adapter  
0A81:0701=USB Missile Launcher  
0A82=SYSCAN  
0A82:4600=TravelScan 460/464  
0A83=NextComm  
0A84=Maui Innovative Peripherals  
0A85=Idexx Labs  
0A86=NITGen  
0A86:0100=Identix DFR2080 USB Isochronous Mode  
0A8D=Picturetel  
0A8E=Japan Aviation Electronics Industry  
0A8E:2011=Filter Driver For JAE XMC R/W  
0A8F=Young Chang  
0A90=Candy Technology  
0A91=Globlink Technology  
0A91:3801=Targus PAKP003 Mouse  
0A92=EGO SYStems  
0A92:0011=EGO SYS WaveTerminal U2A  
0A92:0021=GIGAPort  
0A92:0031=GIGAPortAG  
0A92:0053=AudioTrak Optoplay  
0A92:0061=Waveterminal U24  
0A92:0071=MAYA EX7  
0A92:0091=Maya 44  
0A92:00B1=MAYA EX5  
0A92:1000=MIDI Mate  
0A92:1010=RoMI/O  
0A92:1020=M4U  
0A92:1030=M8U  
0A92:1090=KeyControl49  
0A92:10A0=KeyControl25  
0A93=C Technologies AB (publ)  
0A93:0002=C-Pen 10  
0A93:0005=MyPen Light  
0A93:000D=Input Pen  
0A93:0010=C-Pen 20  
0A93:0A93=PayPen  
0A94=Intersense  
0AA3=Lava Computer  
0AA4=Develco Elektronik  
0AA5=First International Digital  
0AA5:0002=irock! 500 Series  
0AA5:0801=MP3 Player  
0AA6=Perception Digital  
0AA6:0101=Hercules Jukebox  
0AA6:1501=Store 'n' Go HD Drive  
0AA7=Wincor Nixdorf  
0AA7:0100=POS Keyboard, TA58P-USB  
0AA7:0101=POS Keyboard, TA85P-USB  
0AA7:0102=POS Keyboard, TA59-USB  
0AA7:0103=POS Keyboard, TA60-USB  
0AA7:0104=SNIkey Keyboard, SNIKey-KB-USB  
0AA7:0200=POS Display BA63

0AA7:0201=POS Display BA66  
0AA7:0202=Operator Display & Scanner, XiCheck-BA63  
0AA7:0203=Operator Display & Scanner, XiCheck-BA66  
0AA7:0204=Graphics Operator Display, BA63GV  
0AA7:0300=POS Printer TH210  
0AA7:0301=POS Printer (native mode), TH210  
0AA7:0302=POS Printer TH220  
0AA7:0303=POS Printer (native mode), TH220  
0AA7:0304=POS Printer, TH230  
0AA7:0305=Lottery Printer XiPrintPlus  
0AA7:0306=POS Printer TH320  
0AA7:0307=POS Printer (native mode), TH320  
0AA7:0308=POS Printer TH420  
0AA7:0309=POS Printer (native mode), TH420  
0AA7:030A=POS Printer, TH200B  
0AA7:0400=Lottery Scanner, Xiscan S  
0AA7:0401=Lottery Scanner, Xiscan 3  
0AA7:0402=Programmable Magnetic Swipe Card Reader, MSRP-USB  
0AA7:0500=IDE Adapter  
0AA7:0501=Hub Printer Interface  
0AA7:0502=Hub SNIKey Keyboard  
0AA7:4304=Banking Printer TP07  
0AA7:4305=Banking Printer TP07c  
0AA7:4500=WN Central Special Electronics  
0AA8=TriGem Computer  
0AA8:0060=TG 11Mbps WLAN Mini USB Adapter  
0AA8:1001=DreamComboM4100  
0AA8:3002=InkJet Color Printer  
0AA8:8001=TG\_iMON  
0AA8:8002=TG\_KLOSS  
0AA8:A001=TG\_X2  
0AA8:A002=TGVFD\_KLOSS  
0AA8:FFDA=iMON\_VFD  
0AA9=Baromtec  
0AA9:F01B=Medion MD 6242 MP3 Player  
0AAA=Japan CBM  
0AAB=Vision Shape Europe SA  
0AAC=iCompression  
0AAD=Rohde & Schwarz  
0AAE=NEC infrontia  
0AAE:001C:0100=EMOBILE D01NE Modem  
0AAE:001C:0100:01=EMOBILE D01NE Diagnostics Interface  
0AAE:001E:0100=FOMA N2502 HIGH-SPEED  
0AAE:001E:0100:02=FOMA N2502 HIGH-SPEED Command Port  
0AAF=Digitalway  
0AB0=Arrow Strong Electronics  
0AB0:0001=USB Scroll Mouse  
0AB1=FEIG ELECTRONIC GmbH  
0AB1:0002=OBID RFID-Reader  
0ABA=Ellisys  
0ABA:8001=USB Tracker 110 Protocol Analyzer  
0ABA:8002=Explorer 200 Protocol Analyzer  
0ABE=Stereo-Link  
0ABE:0101=SL1200 DAC  
0ABF=Diolan  
0ABF:3370=I2C/SPI Adapter - U2C-12  
0AC3=SANYO Semiconductor Company Micro  
0AC4=LECO  
0AC5=I & C  
0AC6=Singing Electrons

0AC7=Panwest  
0AC8=Vimicro  
0AC8:0301=Web Camera  
0AC8:0302=VM0305  
0AC8:0302:01=BenQ Web Camera Microphone  
0AC8:0303=VM321  
0AC8:0321=USB 2.0 Webcam  
0AC8:0323=Luxya WC-1200 USB 2.0 Webcam  
0AC8:0326=VM326  
0AC8:0328=A4Tech PK-130MG  
0AC8:0336=Elecom UCAM-DLQ30  
0AC8:301B=ZC0301 WebCam  
0AC8:303B=A4 TECH PC Camera H  
0AC8:305B=ZC0305 WebCam  
0AC8:307B=USB 1.1 WebCam  
0AC8:3313=Vimicro USB2.0 UVC PC Camera  
0AC8:332D=Vega USB 2.0 Camera  
0AC8:3330=Vimicro UVC control device  
0AC8:3332=Vimicro UVC control device  
0AC8:3333=Vimicro UVC control device  
0AC8:3340=Vimicro UVC control device  
0AC8:3342=Vimicro UVC control device  
0AC8:3343=Sirius USB 2.0 Camera  
0AC8:3420=Venus USB2.0 Camera  
0AC8:4330=USB2.0 UVC PC Camera  
0AC8:4332=USB2.0 UVC PC Camera  
0AC8:4333=USB2.0 UVC PC Camera  
0AC8:4340=USB2.0 UVC PC Camera  
0AC8:4342=USB2.0 UVC PC Camera  
0AC8:4343=USB2.0 UVC PC Camera  
0AC8:C001=Sony embedded vimicro Camera  
0AC8:C002=Sony Visual Communication Camera VGP-VCC1  
0AC8:C302=Vega USB 2.0 Camera  
0AC8:C303=Saturn USB 2.0 Camera  
0AC8:C326=Namuga 1.3M Webcam  
0AC8:C33F=Webcam  
0AC9=Micro Solutions  
0AC9:0000=Backpack CD-ReWriter  
0AC9:0001=BACKPACK 2 Cable  
0AC9:0010=BACKPACK  
0AC9:0011=Backpack 40GB Hard Drive  
0AC9:0110=BACKPACK  
0AC9:0111=BackPack  
0AC9:1234=BACKPACK  
0ACA=OPEN Networks  
0ACA:1060=OPEN NT1 Plus II  
0ACC=Koga Electronics  
0ACD=ID Tech  
0ACD:0401=ID TECH Spectrum III Hybrid Smartcard Reader  
0ACD:0630=ID TECH Spectrum III Mag-Only Insert Reader (SPT3-355 Series) USB-CDC  
0ACE=ZyDAS  
0ACE:1201=(ZD1201)IEEE 802.11b USB Adapter  
0ACE:1211=802.11b/g USB2 WiFi  
0ACE:1215=(ZD1211B)IEEE 802.11 b/g USB Adapter  
0ACE:1221=ZD1221 802.11n (ar9170)  
0ACE:1602=ZyXEL Omni 56K USB Modem  
0ACE:1608=ZyXEL Omni56K UNO  
0ACE:1611=ZyXEL Omni FaxModem 56K Plus  
0ACE:2011=Virtual media for 802.11bg (zd1211rw)  
0ACE:20FF=Virtual media for 802.11bg (zd1211rw)

0ACE:A211=ZyDAS ZD1211 802.11 a+b+g Wireless LAN  
0ACE:A215=Atheros AR5007UX Wireless Network Adapter  
0ACE:B215=HP 802.11abg wireless LAN  
0ACE:C215=(Wireless Adapter)IEEE 802.11 b+g USB Adapter  
0ACE:D215=(Wireless Adapter)IEEE 802.11 b+g USB Adapter  
0ACF=Intoto  
0AD0=Intellix  
0AD1=Remotec Technology  
0AD2=Service & Quality Technology  
0ADA=Data Encryption Systems  
0ADA:0005=DK2  
0AE3=Allion Computer  
0AE4=Taito  
0AE7=Neodym Systems  
0AE8=System Support  
0AE9=North Shore Circuit Design L.L.P.  
0AEA=SciEssence, LLC  
0AEB=TTP Communications  
0AEC=Neodio Technologies  
0AEC:2101=SmartMedia Card Reader  
0AEC:2102=CompactFlash Card Reader  
0AEC:2103=MMC/SD Card Reader  
0AEC:2104=MemoryStick Card Reader  
0AEC:2201=SmartMedia+CompactFlash Card Reader  
0AEC:2202=SmartMedia+MMC/SD Card Reader  
0AEC:2203=SmartMedia+MemoryStick Card Reader  
0AEC:2204=CompactFlash+MMC/SD Card Reader  
0AEC:2205=CompactFlash+MemoryStick Card Reader  
0AEC:2206=MMC/SD+MemoryStick Card Reader  
0AEC:2301=SmartMedia+CompactFlash+MMC/SD Card Reader  
0AEC:2302=SmartMedia+CompactFlash+MemoryStick Card Reader  
0AEC:2303=SmartMedia+MMC/SD+MemoryStick Card Reader  
0AEC:2304=CompactFlash+MMC/SD+MemoryStick Card Reader  
0AEC:3016=Generic MMC/SD+Memory Stick USB Card Reader  
0AEC:3050=Generic 6-in-1 USB Card Reader  
0AEC:3060=1.1 FS Card Reader  
0AEC:3101=MMC/SD Card Reader  
0AEC:3102=MemoryStick Card Reader  
0AEC:3201=MMC/SD+MemoryStick Card Reader  
0AEC:3216=HS Card Reader  
0AEC:3260=Generic USB 2.0 Card Reader  
0AEC:5010=ND5010 Card Reader  
0AF0=Option  
0AF0:0010=GT EDGE USB Wireless Modem  
0AF0:5000=Vodafone Mobile Connect - 3G Modem  
0AF0:5000:01=Vodafone Mobile Connect - 3G Diagnostics Interface  
0AF0:5000:02=Vodafone Mobile Connect - 3G Application Interface  
0AF0:5001=GlobeTrotter Fusion - 3G Modem  
0AF0:5001:01=GlobeTrotter Fusion - 3G Diagnostics Interface  
0AF0:5001:02=GlobeTrotter Fusion - 3G Application Interface  
0AF0:6000=Fusion UMTS GPRS WLAN - 3G Modem  
0AF0:6000:01=Fusion UMTS GPRS WLAN - 3G Diagnostics Interface  
0AF0:6000:02=Fusion UMTS GPRS WLAN - 3G Application Interface  
0AF0:6000:03=Fusion UMTS GPRS WLAN - 3G Smart Card Interface  
0AF0:6100=Fusion UMTS GPRS - 3G Modem  
0AF0:6100:01=Fusion UMTS GPRS - 3G Diagnostics Interface  
0AF0:6100:02=Fusion UMTS GPRS - 3G Application Interface  
0AF0:6100:03=Fusion UMTS GPRS - 3G Smart Card Interface  
0AF0:6200=Fusion UMTS GPRS WLAN - 3G Modem  
0AF0:6200:01=Fusion UMTS GPRS WLAN - 3G Diagnostics Interface

0AF0:6200:02=Fusion UMTS GPRS WLAN - 3G Application Interface  
0AF0:6200:03=Fusion UMTS GPRS WLAN - 3G Smart Card Interface  
0AF0:6300=Fusion UMTS GPRS - 3G Modem  
0AF0:6300:01=Fusion UMTS GPRS - 3G Diagnostics Interface  
0AF0:6300:02=Fusion UMTS GPRS - 3G Application Interface  
0AF0:6300:03=Fusion UMTS GPRS - 3G Smart Card Interface  
0AF0:6500:01=GlobeTrotter Module 3G+ Diagnostics Interface  
0AF0:6500:02=GlobeTrotter Module 3G+ Application Interface  
0AF0:6501=GlobeTrotter Module 3G+  
0AF0:6600=GlobeTrotter 3G+ datacard  
0AF0:6600:01=GlobeTrotter Module 3G+ Diagnostics Interface  
0AF0:6600:02=GlobeTrotter Module 3G+ Application Interface  
0AF0:6601=GlobeTrotter Module 3G+  
0AF0:6701=GlobeTrotter HSDPA  
0AF0:6711=GlobeTrotter HSxPA  
0AF0:6713=FOMA OP2502  
0AF0:6721=GlobeTrotter HSDPA  
0AF0:6731=GlobeTrotter HSxPA  
0AF0:6741=GlobeTrotter HSDPA  
0AF0:6751=GlobeTrotter HSxPA  
0AF0:6761=GlobeTrotter HSDPA  
0AF0:6771=GlobeTrotter HSxPA  
0AF0:6791=GlobeTrotter HSxPA  
0AF0:6800:01=GlobeTrotter Module 3G+ Diagnostics Interface  
0AF0:6800:02=GlobeTrotter Module 3G+ Application Interface  
0AF0:6811=GlobeTrotter Module HSxPA  
0AF0:6831=GlobeTrotter Module HSxPA  
0AF0:6901=GlobeTrotter Module HSDPA  
0AF0:6911=GlobeTrotter Module HSxPA  
0AF0:6951=GlobeTrotter HSxPA  
0AF0:6971=GlobeTrotter HSxPA  
0AF0:7001=GlobeTrotter HSDPA HSUPA  
0AF0:7011=GlobeTrotter HSxPA  
0AF0:7021=GlobeTrotter HSDPA HSUPA  
0AF0:7031=GlobeTrotter HSxPA  
0AF0:7041=GlobeTrotter HSDPA HSUPA  
0AF0:7051=GlobeTrotter HSxPA  
0AF0:7061=GlobeTrotter HSDPA HSUPA  
0AF0:7071=GlobeTrotter HSxPA  
0AF0:7100:01=GlobeTrotter HSDPA/HSUPA Diagnostics Interface  
0AF0:7100:02=GlobeTrotter HSDPA/HSUPA Application Interface  
0AF0:7111=GlobeTrotter Module HSxPA  
0AF0:7201=GlobeTrotter Module HSDPA HSUPA  
0AF0:7211=GlobeTrotter Module HSxPA  
0AF0:7251=GlobeTrotter HSxPA  
0AF0:7271=GlobeTrotter HSxPA  
0AF0:7301=GlobeTrotter GE40x  
0AF0:7311=GlobeTrotter HSxPA  
0AF0:7371=GlobeTrotter HSxPA  
0AF0:7401=GlobeTrotter GI40x  
0AF0:7411=GlobeTrotter Icon401  
0AF0:7501=GlobeTrotter GI4xx  
0AF0:7601=GlobeTrotter MO40x  
0AF0:7701=Globetrotter HSUPA Modem (aka icon 451)  
0AF0:C031=GlobeTrotter Icon Edge  
0AF0:D013=GlobeTrotter Module HSxPA  
0AF0:D031=GlobeTrotter Icon321  
0AF0:D033=GlobeTrotter Icon322  
0AF6=Silver I  
0AF7=B2C2

0AF7:0101=TechniSat DVB-PC TV Star USB  
0AF9=Hama  
0AF9:0010=USB SightCam 100  
0AF9:0011=Micro Innovations IC50C WebCam  
0AFC=Zaptronix  
0AFD=Tateno Dennou  
0AFE=Cummins Engine Company  
0AFF=Jump Zone Network Products  
0B00=INGENICO  
0B05=ASUSTek Computer  
0B05:1101=Mass Storage (UISDMC4S)  
0B05:166A=DPW632 802.11N USB Wireless Adapter  
0B05:1706=ASUS USB Wireless Network Adapter  
0B05:1707=802.11b/g USB Wireless Network Adapter  
0B05:1708=Mass Storage Device  
0B05:170B=Mass Storage Device  
0B05:170C=WL-159g  
0B05:170D=802.11b/g Wireless Network Adapter  
0B05:1712=BT-183 Bluetooth 2.0  
0B05:1715=Broadcom 2045 Bluetooth 2.0 USB Device  
0B05:1716=Bluetooth Device  
0B05:1717=WL169gE 802.11g Adapter [Broadcom 4320 USB]  
0B05:1718=Broadcom Bluetooth 2.1 + EDR USB Device  
0B05:171B=ASUS USB Wireless Network Adapter  
0B05:171C=802.11b/g USB Wireless Network Adapter  
0B05:171F=ASUS My Cinema-U3000 Mini  
0B05:1720=ASUS My Cinema-U3000 Mini  
0B05:1723=ASUS USB Wireless Network Adapter  
0B05:1724=802.11b/g USB Wireless Network Adapter  
0B05:1726=Laptop OLED Display  
0B05:172A=ASUS 802.11n Network Adapter  
0B05:172B=802.11n Network Adapter  
0B05:1730=ASUS My Cinema U3000I DVBT  
0B05:1731=ASUS 802.11n Network Adapter  
0B05:1732=802.11n Network Adapter  
0B05:1734=ASUS AF-200  
0B05:173C=BT-183 Bluetooth 2.0  
0B05:173F=ASUS My Cinema U3100 Mini DVBT  
0B05:1740=ASUS My Cinema MC3000U DVBT  
0B05:1742=802.11n Network Adapter  
0B05:1743=Xonar U1 Audio Station  
0B05:1746=Asus BT-183  
0B05:174F=BT-250  
0B05:1751=BT-253  
0B05:1758=BT-250  
0B05:1759=BT-253  
0B05:175B=Laptop OLED Display  
0B05:1760=802.11n Network Adapter  
0B05:1761=ASUS 802.11n Network Adapter  
0B05:1762=Broadcom Bluetooth 2.1 + EDR USB Device  
0B05:176B=Broadcom Bluetooth 2.1 + EDR USB Device  
0B05:176C=Broadcom Bluetooth 2.1 + EDR USB Device  
0B05:176D=Broadcom Bluetooth 2.1 + EDR USB Device  
0B05:1774=Gobi Wireless Modem (QDL mode)  
0B05:1776=Gobi Wireless Modem  
0B05:1779=My Cinema U3100 Mini Plus [AF9035A]  
0B05:1783=Broadcom Bluetooth 3.0 USB  
0B05:1784=ASUS 802.11n Network Adapter  
0B05:1786=ASUS EZ N 802.11b/g/n Wireless USB Adapter  
0B05:1788=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device



0B05:1789=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
0B05:178A=NB-290  
0B05:178B=NB-290  
0B05:1790=Ralink RT3572 802.11a/n Wireless Lan USB Device  
0B05:1791=ASUS WL-167G V3  
0B05:1793=Broadcom Bluetooth 2.1 + EDR USB Device  
0B05:179D=ASUS USB-N53 802.11a/b/g/n Network Adapter  
0B05:4200=ASUS USB Sync  
0B05:4201=ASUS USB Sync  
0B05:4202=ASUS USB Sync  
0B05:420F=ASUS USB Sync  
0B05:6101=Cable Modem  
0B05:620A=Remote NDIS Device  
0B05:9200=ASUS USB Sync  
0B05:9202=ASUS USB Sync  
0B05:B700=BT-253  
0B05:B703=BT-250  
0B0B=Datamax-O'Neil  
0B0B:106E=Datamax E-4304  
0B0C=Todos Data System AB  
0B0C:0002=Todos Argosmini Usb  
0B0C:0003=Todos SurfLite 2 USB PnP  
0B0C:0009=Argos Mini II  
0B0C:001E=e.dentifier2 (ABN AMRO electronic banking card reader NL)  
0B0C:002E=C200 smartcard controller (Nordea card reader)  
0B0C:003F=Todos C400 smartcard controller (Handelsbanken card reader)  
0B0C:0050=Argos Mini II Smart Card Reader (CCID)  
0B0D=ProjectLab  
0B0D:0000=CenturyCD  
0B0E=GN Netcom  
0B0E:1022=Jabra PRO 9450, Type 9400BS (DECT Headset)  
0B0E:8100=C-Media USB Sound Device  
0B0E:8100:03=USB Human Interface Device  
0B0F=AVID Technology  
0B10=Pcally  
0B11=I Tech Solutions  
0B1E=Electronic Warfare Assoc.  
0B1E:8007=Blackhawk USB560-BP JTAG Emulator  
0B1F=Insyde Software  
0B20=TransDimension  
0B21=Yokogawa Electric  
0B22=Japan System Development  
0B23=Pan-Asia Electronics  
0B24=Link Evolution  
0B27=Ritek  
0B28=Kenwood  
0B2C=Village Center  
0B30=PNY Technologies  
0B30:0006=SM Media-Shuttle Card Reader  
0B33=Contour Design  
0B33:0020=ShuttleXpress  
0B37=Hitachi ULSI Systems  
0B38=Gear Head  
0B38:0002:01=E-Mail Multimedia Keyboard for USB (64-bit)  
0B38:0002:0100:01=USB Human Interface Device  
0B38:0003=Keyboard  
0B38:0003:01=E-Mail Multimedia Keyboard for USB (64-bit)  
0B38:0010=107-Key Keyboard  
0B38:0010:01=E-Mail Multimedia Keyboard for USB (64-bit)  
0B39=Omnidirectional Control Technology

0B39:0001=Composite USB PS2 Converter  
0B39:0109=USB TO Ethernet  
0B39:0421=Serial  
0B39:0801=USB-Parallel Bridge  
0B39:0901=OCT USB To Fast Ethernet Converter  
0B39:0C03=LAN DOCK Serial Converter  
0B3A=IPaxess  
0B3B=Tekram Technology  
0B3B:0163=TL-WN320G 1.0 USB WLAN Adapter  
0B3B:1601=Allnet 0193 802.11b Adapter  
0B3B:1602=ZyXEL ZyAIR B200 802.11b Adapter  
0B3B:1612=AIR.Mate 2@net 802.11b Adapter  
0B3B:1613=TL-WN220M 3.0 USB WLAN Adapter  
0B3B:1620=Allnet USB 2.0 Wireless Network Adapter  
0B3B:1630=QuickWLAN  
0B3B:5630=ZD1211  
0B3B:6630=ZD1211  
0B3C=Olivetti Tecnost  
0B3C:A010=Simple\_Way Printer/Scanner/Copier  
0B3C:C000=Olicard 100  
0B3C:C700=Olicard 100 (Mass Storage mode)  
0B3E=Kikusui Electronics  
0B41=Hal  
0B41:0011=Crossam2+USB IR commander  
0B43=Play.com  
0B43:0003=PS2 Controller Converter  
0B47=Sportbug.com  
0B48=TechnoTrend AG  
0B48:1003=Technotrend/Hauppauge USB-Nova  
0B48:1004=TT-PCline  
0B48:1005=Technotrend/Hauppauge USB-Nova  
0B48:1006=Technotrend/Hauppauge DEC3000-s  
0B48:1007=TT-micro plus Device  
0B48:1008=Technotrend/Hauppauge DEC2000-t  
0B48:1009=Technotrend/Hauppauge DEC2540-t  
0B48:3001=TTUSB2BDA - TechnoTrend DVB-S USB 2.0 BDA Device  
0B48:3002=TTUSB2BDA - TechnoTrend DVB-C USB 2.0 BDA Device  
0B48:3003=TTUSB2BDA - TechnoTrend DVB-T USB 2.0 BDA Device  
0B48:3004=TTUSB2BDA - TechnoTrend DVB-T Stick USB 2.0 BDA Device  
0B48:3005=TTUSB2BDA - TechnoTrend DVB-T Stick USB 2.0 BDA Device (8 KB EEPROM)  
0B48:3006=TT-connect S-2400 DVB-S receiver  
0B48:3007=TT-connect S2-3600  
0B48:3008=TT-connect  
0B48:3009=TT-connect S-2400 DVB-S receiver (8kB EEPROM)  
0B48:300A=TT-connect S2-3650 CI  
0B48:300B=TT-connect C-3650 CI  
0B48:300C=TT-connect T-3650 CI  
0B48:300D=TT-connect CT-3650 CI  
0B48:300E=TT-connect C-2400  
0B49=ASCII  
0B49:064F=Trance Vibrator  
0B4B=Pine  
0B4B:0100=D'music MP3 Player  
0B4C:6800=MP3 Player  
0B4C:6810=MP3 Player  
0B4C:6900=MP3 Player  
0B4C:6910=MP3 Player  
0B4C:9910=MP3 Player  
0B4D=Graphtec America  
0B4D:110A=Graphtec CC200-20

0B4E=Musical Electronics  
0B4E:6500=MP3 Player  
0B4E:8028=MP3 Player  
0B4E:8920=MP3 Player  
0B50=Dumpries  
0B51=Comfort Keyboard  
0B51:0020=Comfort Keyboard  
0B52=Colorado MicroDisplay  
0B54=Sinbon Electronics  
0B56=TYI Systems  
0B57=Beijing HanwangTechnology  
0B59=Lake Communications  
0B5A=Corel  
0B5F=Green Electronics  
0B60=Nsine  
0B61=NEC Viewtechnology  
0B62=Orange Micro  
0B62:000B=BILLIONTON Bluetooth Device  
0B62:0059=iBOT2 WebCam  
0B63=ADLink Technology  
0B64=Wonderful Wire Cable  
0B65=Expert Magnetics  
0B69=CacheVision  
0B6A=Maxim Integrated Products  
0B6F=Nagano Japan Radio  
0B70=PortalPlayer  
0B70:00BA=iRiver H10 20GB  
0B71=SHIN-EI Sangyo  
0B72=Embedded Wireless Technology  
0B73=Computone  
0B75=Roland DG  
0B79=Sunrise Telecom  
0B7A=Zeevo  
0B7A:07D0=Zeevo Bluetooth Solution  
0B7A:07D0:0126=Zeevo Bluetooth Solution  
0B7A:07D0:0133=Zeevo Bluetooth Solution  
0B7B=Taiko Denki  
0B7C=ITRAN Communications  
0B7D=Astrodesign  
0B81=id3 Semiconductors  
0B81:0001=Biothetic II smartcard reader with fingerprint sensor  
0B81:0002=DFU-Enabled Devices (DFU)  
0B81:0012=BioPAD biometric module (DFU + CDC)  
0B81:0102=Certis V1 fingerprint reader  
0B81:0103=Certis V2 fingerprint reader  
0B81:0200=CL1356T smartcard reader  
0B81:0201=CL1356T / CL1356T5 / CL1356A smartcard readers (DFU + CCID)  
0B81:0220=CL1356A smartcard reader  
0B81:0221=CL1356A smartcard reader (DFU + CCID + HID)  
0B81:1003=CERTIS2 fingerprint reader  
0B81:1004=CERTIS2 fingerprint reader  
0B84=Rextron Technology  
0B85=Elkat Electronics (M) SDN. BHD.  
0B86=eXputer  
0B86:5100=eXputer XMC5100 USB Zippy Drive  
0B86:5110=J.M.TEK XMC5110 Flash USB Drive  
0B86:5200=eXputer XMC5200 USB Zippy Drive  
0B86:5201=eXputer XMC5200 USB Zippy Drive  
0B86:5202=eXputer XMC5200 USB Zippy Drive  
0B86:5280=eXputer XMC5280 USB Storage Drive

0B86:FFF0=eXputer ISP5200 USB Debugger  
0B87=Plus-One I & T  
0B88=Sigma Koki  
0B89=Advanced Digital Broadcast  
0B8C=SMART Technologies  
0B8C:00C3=Sympodium ID350  
0B95=ASIX Electronics  
0B95:1720=SMC EZ Networking Compact 10/100 USB 2.0 Adapter  
0B95:1780=AX88178  
0B95:7720=AX88772  
0B95:772A=ASIX AX88772A USB2.0 to Fast Ethernet Adapter  
0B96=SEWON TELECOM  
0B97=O2 Micro  
0B97:7732=Smart Card Reader  
0B97:7732:0110=O2Micro USB Smart Card Reader  
0B97:7732:0210=O2Micro USB Smart Card Reader  
0B97:7732:0310=O2Micro USB Smart Card Reader  
0B97:7732:0410=O2Micro USB Smart Card Reader  
0B97:7761=Oz776 1.1 Hub  
0B97:7762=Oz776 SmartCard Reader  
0B97:7762:0110=O2Micro OZ776 USB CCID Smartcard Reader  
0B97:7772=OZ776 CCID Smartcard Reader  
0B97:7772:0110=O2Micro OZ776 USB CCID Smartcard Reader  
0B98=Playmates Toys  
0B99=Audio International  
0B9B=Dipl.-Ing. Stefan Kunde  
0B9B:4012=Reflex RC-controller Interface  
0B9D=Softprotec  
0B9F=Chippo Technologies  
0BA8:4601=Broadcom 2046 Bluetooth 2.1 Device  
0BA8:4611=Broadcom Bluetooth 2.1 + EDR USB Device  
0BA8:4612=Broadcom Bluetooth 2.1 + EDR USB Device  
0BAF=U.S. Robotics  
0BAF:00E5=USR6000  
0BAF:00EB=USR1120 802.11b Adapter  
0BAF:00EC=56K Faxmodem  
0BAF:00F1=SureConnect ADSL ATM Adapter  
0BAF:00F2=SureConnect ADSL Loader  
0BAF:00F5=SureConnect ADSL ATM Adapter  
0BAF:00F6=SureConnect ADSL Loader  
0BAF:00F7=SureConnect ADSL ATM Adapter  
0BAF:00F8=SureConnect ADSL Loader  
0BAF:00F9=SureConnect ADSL ATM Adapter  
0BAF:00FA=SureConnect ADSL Loader  
0BAF:00FB=SureConnect ADSL Ethernet/USB Router  
0BAF:0111=U.S. Robotics 802.11g Wireless USB Adapter  
0BAF:0118=U5 802.11g Adapter  
0BAF:011B=Wireless MAXg Adapter  
0BAF:0121=USRobotics Wireless USB Adapter  
0BAF:6112=FaxModem Model 5633  
0BB0=Concord Camera  
0BB0:0100=Sound Vision Stream  
0BB0:5007=3340z/Rollei DC3100  
0BB0:6048=Digital Camera  
0BB0:604C=Digital Camera  
0BB0:7012=JENIMAGE JD C3.1 Z3  
0BB1=Infinilink  
0BB2=Ambit Microsystems  
0BB2:0302=WLAN  
0BB2:6098=USB Cable Modem 351000

0BB3=Ofuji Technology  
0BB4=High Tech Computer,  
0BB4:00CE=mm02 XDA GSM/GPRS Pocket PC  
0BB4:00CF=SPV C500 Smart Phone  
0BB4:0A01=PocketPC Sync  
0BB4:0A02=Himalaya GSM/GPRS Pocket PC  
0BB4:0A03=PocketPC Sync  
0BB4:0A04=PocketPC Sync  
0BB4:0A05=PocketPC Sync  
0BB4:0A06=PocketPC Sync  
0BB4:0A07=Magician PocketPC SmartPhone / 02 XDA  
0BB4:0A08=PocketPC Sync  
0BB4:0A09=PocketPC Sync  
0BB4:0A0A=PocketPC Sync  
0BB4:0A0B=PocketPC Sync  
0BB4:0A0C=PocketPC Sync  
0BB4:0A0D=PocketPC Sync  
0BB4:0A0E=PocketPC Sync  
0BB4:0A0F=PocketPC Sync  
0BB4:0A10=PocketPC Sync  
0BB4:0A11=PocketPC Sync  
0BB4:0A12=PocketPC Sync  
0BB4:0A13=PocketPC Sync  
0BB4:0A14=PocketPC Sync  
0BB4:0A15=PocketPC Sync  
0BB4:0A16=PocketPC Sync  
0BB4:0A17=PocketPC Sync  
0BB4:0A18=PocketPC Sync  
0BB4:0A19=PocketPC Sync  
0BB4:0A1A=PocketPC Sync  
0BB4:0A1B=PocketPC Sync  
0BB4:0A1C=PocketPC Sync  
0BB4:0A1D=PocketPC Sync  
0BB4:0A1E=PocketPC Sync  
0BB4:0A1F=PocketPC Sync  
0BB4:0A20=PocketPC Sync  
0BB4:0A21=PocketPC Sync  
0BB4:0A22=PocketPC Sync  
0BB4:0A23=PocketPC Sync  
0BB4:0A24=PocketPC Sync  
0BB4:0A25=PocketPC Sync  
0BB4:0A26=PocketPC Sync  
0BB4:0A27=PocketPC Sync  
0BB4:0A28=PocketPC Sync  
0BB4:0A29=PocketPC Sync  
0BB4:0A2A=PocketPC Sync  
0BB4:0A2B=PocketPC Sync  
0BB4:0A2C=PocketPC Sync  
0BB4:0A2D=PocketPC Sync  
0BB4:0A2E=PocketPC Sync  
0BB4:0A2F=PocketPC Sync  
0BB4:0A30=PocketPC Sync  
0BB4:0A31=PocketPC Sync  
0BB4:0A32=PocketPC Sync  
0BB4:0A33=PocketPC Sync  
0BB4:0A34=PocketPC Sync  
0BB4:0A35=PocketPC Sync  
0BB4:0A36=PocketPC Sync  
0BB4:0A37=PocketPC Sync  
0BB4:0A38=PocketPC Sync

0BB4:0A39=PocketPC Sync  
0BB4:0A3A=PocketPC Sync  
0BB4:0A3B=PocketPC Sync  
0BB4:0A3C=PocketPC Sync  
0BB4:0A3D=PocketPC Sync  
0BB4:0A3E=PocketPC Sync  
0BB4:0A3F=PocketPC Sync  
0BB4:0A40=PocketPC Sync  
0BB4:0A41=PocketPC Sync  
0BB4:0A42=PocketPC Sync  
0BB4:0A43=PocketPC Sync  
0BB4:0A44=PocketPC Sync  
0BB4:0A45=PocketPC Sync  
0BB4:0A46=PocketPC Sync  
0BB4:0A47=PocketPC Sync  
0BB4:0A48=PocketPC Sync  
0BB4:0A49=PocketPC Sync  
0BB4:0A4A=PocketPC Sync  
0BB4:0A4B=PocketPC Sync  
0BB4:0A4C=PocketPC Sync  
0BB4:0A4D=PocketPC Sync  
0BB4:0A4E=PocketPC Sync  
0BB4:0A4F=PocketPC Sync  
0BB4:0A50=HTC SmartPhone Sync  
0BB4:0A51=SPV C400 / T-Mobile SDA GSM/GPRS Pocket PC  
0BB4:0A52=SmartPhone Sync  
0BB4:0A53=SmartPhone Sync  
0BB4:0A54=SmartPhone Sync  
0BB4:0A55=SmartPhone Sync  
0BB4:0A56=SmartPhone Sync  
0BB4:0A57=SmartPhone Sync  
0BB4:0A58=SmartPhone Sync  
0BB4:0A59=SmartPhone Sync  
0BB4:0A5A=SmartPhone Sync  
0BB4:0A5B=SmartPhone Sync  
0BB4:0A5C=SmartPhone Sync  
0BB4:0A5D=SmartPhone Sync  
0BB4:0A5E=SmartPhone Sync  
0BB4:0A5F=SmartPhone Sync  
0BB4:0A60=SmartPhone Sync  
0BB4:0A61=SmartPhone Sync  
0BB4:0A62=SmartPhone Sync  
0BB4:0A63=SmartPhone Sync  
0BB4:0A64=SmartPhone Sync  
0BB4:0A65=SmartPhone Sync  
0BB4:0A66=SmartPhone Sync  
0BB4:0A67=SmartPhone Sync  
0BB4:0A68=SmartPhone Sync  
0BB4:0A69=SmartPhone Sync  
0BB4:0A6A=SmartPhone Sync  
0BB4:0A6B=SmartPhone Sync  
0BB4:0A6C=SmartPhone Sync  
0BB4:0A6D=SmartPhone Sync  
0BB4:0A6E=SmartPhone Sync  
0BB4:0A6F=SmartPhone Sync  
0BB4:0A70=SmartPhone Sync  
0BB4:0A71=SmartPhone Sync  
0BB4:0A72=SmartPhone Sync  
0BB4:0A73=SmartPhone Sync  
0BB4:0A74=SmartPhone Sync

0BB4:0A75=SmartPhone Sync  
0BB4:0A76=SmartPhone Sync  
0BB4:0A77=SmartPhone Sync  
0BB4:0A78=SmartPhone Sync  
0BB4:0A79=SmartPhone Sync  
0BB4:0A7A=SmartPhone Sync  
0BB4:0A7B=SmartPhone Sync  
0BB4:0A7C=SmartPhone Sync  
0BB4:0A7D=SmartPhone Sync  
0BB4:0A7E=SmartPhone Sync  
0BB4:0A7F=SmartPhone Sync  
0BB4:0A80=SmartPhone Sync  
0BB4:0A81=SmartPhone Sync  
0BB4:0A82=SmartPhone Sync  
0BB4:0A83=SmartPhone Sync  
0BB4:0A84=SmartPhone Sync  
0BB4:0A85=SmartPhone Sync  
0BB4:0A86=SmartPhone Sync  
0BB4:0A87=SmartPhone Sync  
0BB4:0A88=SmartPhone Sync  
0BB4:0A89=SmartPhone Sync  
0BB4:0A8A=SmartPhone Sync  
0BB4:0A8B=SmartPhone Sync  
0BB4:0A8C=SmartPhone Sync  
0BB4:0A8D=SmartPhone Sync  
0BB4:0A8E=SmartPhone Sync  
0BB4:0A8F=SmartPhone Sync  
0BB4:0A90=SmartPhone Sync  
0BB4:0A91=SmartPhone Sync  
0BB4:0A92=SmartPhone Sync  
0BB4:0A93=SmartPhone Sync  
0BB4:0A94=SmartPhone Sync  
0BB4:0A95=SmartPhone Sync  
0BB4:0A96=SmartPhone Sync  
0BB4:0A97=SmartPhone Sync  
0BB4:0A98=SmartPhone Sync  
0BB4:0A99=SmartPhone Sync  
0BB4:0A9A=SmartPhone Sync  
0BB4:0A9B=SmartPhone Sync  
0BB4:0A9C=SmartPhone Sync  
0BB4:0A9D=SmartPhone Sync  
0BB4:0A9E=SmartPhone Sync  
0BB4:0A9F=SmartPhone Sync  
0BB4:0B03=Ozone Mobile Broadband  
0BB4:0B04=Hermes / TyTN / T-Mobile MDA Vario II / O2 Xda Trion  
0BB4:0B05=P3600  
0BB4:0B06=Athena / Advantage x7500 / Dopod U1000 / T-Mobile AMEO  
0BB4:0B0C=Elf / Touch / P3450 / T-Mobile MDA Touch / O2 Xda Nova / Dopod S1  
0BB4:0B1F=Sony Ericsson XPERIA X1  
0BB4:0B2F=Rhodium  
0BB4:0B51=Qtek 8310 mobile phone [Tornado Noble]  
0BB4:0BCE=Generic RNDIS  
0BB4:0C01=HTC Dream  
0BB4:0C02=Dream / ADP1 / G1 Phone (Debug)  
0BB4:0C02:01=HTC Dream Composite ADB Interface  
0BB4:0C13=Diamond  
0BB4:0C1F=Sony Ericsson XPERIA X1  
0BB4:0C5F=Snap  
0BB4:0C87=Desire (Debug)  
0BB4:0C8D=EVO 4G (debug)

0BB4:0C91=Vision  
0BB4:0C94=Vision  
0BB4:0C97=Legend  
0BB4:0C99=Desire Phone (Debug)  
0BB4:0C9E=Incredible  
0BB4:0CA2=Desire HD (debug mode)  
0BB4:0FF8=Desire HD (Tethering Mode)  
0BB4:0FF9=Desire Phone  
0BB4:0FFE=Desire HD (modem mode)  
0BB4:0FFF=HTC Bootloader  
0BB5=Murata Manufacturing  
0BB6=Network Alchemy  
0BB7=Joytech Computer  
0BB8=Renesas Technology  
0BB9=Eiger M&C  
0BBA=ZAccess Systems  
0BBB=General Meters  
0BBC=Assistive Technology  
0BBD=System Connection  
0BC0=Knmlink Technology  
0BC1=Fuw Yng Electronics  
0BC2=Seagate RSS LLC  
0BC2:2000=USB Storage Adapter V3 (TPP)  
0BC2:2200=FreeAgent Go FW  
0BC2:5021=FreeAgent GoFlex 9ZFAD1-500 1.5 TB  
0BC2:5031=FreeAgent GoFlex USB 3.0  
0BC3=IPWireless  
0BC3:0001=UMTS-TDD (TD-CDMA) modem  
0BC4=Microcube  
0BC5=JCN  
0BC6=ExWAY  
0BC7=X10 Wireless Technology  
0BC7:0001=ActiveHome (ACPI-compliant)  
0BC7:0001:0100=X10 USB ActiveHome (ACPI-compliant)  
0BC7:0001:0200=X10 USB ActiveHome (ACPI-compliant)  
0BC7:0002=Firecracker Interface (ACPI-compliant)  
0BC7:0002:0100=X10 USB Firecracker Interface (ACPI-compliant)  
0BC7:0002:0200=X10 USB Firecracker Interface (ACPI-compliant)  
0BC7:0003=VGA Video Sender (ACPI-compliant)  
0BC7:0003:0100=X10 VGA Video Sender (ACPI-compliant)  
0BC7:0003:0200=X10 VGA Video Sender (ACPI-compliant)  
0BC7:0004=X10 Receiver  
0BC7:0004:0100=ATI Wireless Remote Receiver V2.36  
0BC7:0004:0200=ATI Remote Wonder Plus  
0BC7:0005=Wireless Transceiver (ACPI-compliant)  
0BC7:0005:0100=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:0005:0200=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:0006=Wireless Transceiver (ACPI-compliant)  
0BC7:0006:0100=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:0006:0200=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:0007=Wireless Transceiver (ACPI-compliant)  
0BC7:0007:0100=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:0007:0200=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:0008=Wireless Transceiver (ACPI-compliant)  
0BC7:0008:0100=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:0008:0200=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:0009=Wireless Transceiver (ACPI-compliant)  
0BC7:0009:0100=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:0009:0200=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:000A=Wireless Transceiver (ACPI-compliant)



0BC7:000A:0100=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:000A:0200=X10 USB Wireless Transceiver (ACPI-compliant)  
0BC7:000B=Transceiver (ACPI-compliant)  
0BC7:000B:0100=X10 USB Transceiver (ACPI-compliant)  
0BC7:000B:0200=X10 USB Transceiver (ACPI-compliant)  
0BC7:000C=Transceiver (ACPI-compliant)  
0BC7:000C:0100=X10 USB Transceiver (ACPI-compliant)  
0BC7:000C:0200=X10 USB Transceiver (ACPI-compliant)  
0BC7:000D=Transceiver (ACPI-compliant)  
0BC7:000D:0100=X10 USB Transceiver (ACPI-compliant)  
0BC7:000D:0200=X10 USB Transceiver (ACPI-compliant)  
0BC7:000E=Transceiver (ACPI-compliant)  
0BC7:000E:0100=X10 USB Transceiver (ACPI-compliant)  
0BC7:000E:0200=X10 USB Transceiver (ACPI-compliant)  
0BC7:000F=Transceiver (ACPI-compliant)  
0BC7:000F:0100=X10 USB Transceiver (ACPI-compliant)  
0BC7:000F:0200=X10 USB Transceiver (ACPI-compliant)  
0BC8=Telmax Communications  
0BC9=ECI Telecom  
0BCA=Startek Engineering  
0BCB=Perfect Technic Enterprise  
0BD7=Andrew Pargeter & Associates  
0BD7:A021=Amptek DP4 multichannel signal analyzer  
0BDA=Realtek Semiconductor  
0BDA:0001=Realtek Motorola BC8 Bluetooth 3.0+HS Adapter  
0BDA:0002=Realtek Motorola BC8 Bluetooth 4.0LE Adapter  
0BDA:0084=Realtek USB 2.0 Card Reader  
0BDA:0103=Realtek USB 2.0 Card Reader  
0BDA:0104=Mass Storage Device  
0BDA:0105=Realtek USB 2.0 Card Reader Download Mode  
0BDA:0106=Mass Storage Device  
0BDA:0107=Mass Storage Device  
0BDA:0108=Mass Storage Device  
0BDA:0111=Card Reader  
0BDA:0113=Mass Storage Device  
0BDA:0115=Mass Storage Device  
0BDA:0116=Mass Storage Device  
0BDA:0117=Mass Storage Device  
0BDA:0118=Mass Storage Device  
0BDA:0119=USB Mass Storage Device  
0BDA:0120=Realtek USB 2.0 Card Reader  
0BDA:0121=Realtek USB 2.0 Card Reader  
0BDA:0125=Realtek USB 2.0 Card Reader Download Mode  
0BDA:0136=Realtek USB 2.0 Card Reader  
0BDA:0138=Realtek USB 2.0 Card Reader  
0BDA:0151=Mass Storage Device  
0BDA:0152=Mass Storage Device  
0BDA:0153=Mass Storage Device  
0BDA:0155=Realtek USB 2.0 Card Reader  
0BDA:0156=Mass Storage Device  
0BDA:0157=Mass Storage Device  
0BDA:0158=Mass Storage Device  
0BDA:0159=Realtek USB 2.0 Card Reader  
0BDA:0161=Mass Storage Device  
0BDA:0161:01=Realtek USB 2.0 Card Reader  
0BDA:0161:02=eHome Infrared Receiver (USBCIR)  
0BDA:0163=Realtek USB 2.0 Card Reader  
0BDA:0166:01=Realtek USB 2.0 Card Reader  
0BDA:0167=Realtek USB 2.0 Card Reader  
0BDA:0168=Mass Storage Device

OBDA:0168:01=Realtek USB 2.0 Card Reader  
OBDA:0168:02=eHome Infrared Receiver (USBCIR)  
OBDA:0169=Mass Storage Device  
OBDA:0169:01=Realtek USB 2.0 Card Reader  
OBDA:0171=Mass Storage Device  
OBDA:0176=Mass Storage Device  
OBDA:0178=Mass Storage Device  
OBDA:0181=Realtek USB 2.0 Card Reader  
OBDA:0182=Realtek USB 2.0 Card Reader  
OBDA:0184=Realtek USB 2.0 Card Reader  
OBDA:0185=Realtek USB 2.0 Card Reader  
OBDA:0186=Realtek USB 2.0 Card Reader  
OBDA:0187=Realtek USB 2.0 Card Reader  
OBDA:2831=2831U Device  
OBDA:2832=RTL2832U DVB-T  
OBDA:5800=Realtek USB2.0 PC Camera  
OBDA:5801=Realtek USB2.0 PC Camera  
OBDA:5820=Realtek USB2.0 PC Camera  
OBDA:58F0=Realtek USB2.0 PC Camera  
OBDA:58F1=Realtek USB2.0 PC Camera  
OBDA:58F2=Realtek USB2.0 PC Camera  
OBDA:58F3=Realtek USB2.0 PC Camera  
OBDA:58F4=Realtek USB2.0 PC Camera  
OBDA:58F5=Realtek USB2.0 PC Camera  
OBDA:58F6=Realtek USB2.0 PC Camera  
OBDA:58F7=Realtek USB2.0 PC Camera  
OBDA:58F8=Realtek USB2.0 PC Camera  
OBDA:58F9=Realtek USB2.0 PC Camera  
OBDA:58FA=Realtek USB2.0 PC Camera  
OBDA:58FB=Realtek USB2.0 PC Camera  
OBDA:58FC=Realtek USB2.0 PC Camera  
OBDA:58FD=Realtek USB2.0 PC Camera  
OBDA:8150=RTL8150 Fast Ethernet Adapter  
OBDA:8151=RTL8151 Adapton Business Mobile Networks BV  
OBDA:8170=Realtek RTL8188CE-VAU Wireless LAN 802.11n USB minicard  
OBDA:8170:0200=Realtek RTL8188CE-VAU Wireless LAN 802.11n USB minicard  
OBDA:8171=Realtek RTL8188SU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8171:0200=Realtek RTL8188SU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8172=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8172:0200=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8173=Realtek RTL8192GU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8174=Realtek RTL8192SU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8175=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8176=RTL8188CUS 802.11n WLAN  
OBDA:8176:0200=Realtek RTL8188CU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8177=Realtek RTL8188CU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8177:0200=Realtek RTL8188CU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8178=Realtek RTL8192CU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8178:0200=Realtek RTL8192CU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8179=Realtek RTL8188EU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:817A=Realtek RTL8188CUS Wireless LAN 802.11n USB Slim Solo  
OBDA:817A:0200=Realtek RTL8188CUS Wireless LAN 802.11n USB Slim Solo  
OBDA:817B=Realtek RTL8188CUS Wireless LAN 802.11n USB Slim Combo  
OBDA:817B:0200=Realtek RTL8188CUS Wireless LAN 802.11n USB Slim Combo  
OBDA:817C=Realtek RTL8192CE-VAU Wireless LAN 802.11n USB minicard  
OBDA:817C:0200=Realtek RTL8192CE-VAU Wireless LAN 802.11n USB minicard  
OBDA:817E=Realtek RTL8188CE-VAU Wireless LAN 802.11n USB minicard  
OBDA:817E:0200=Realtek RTL8188CE-VAU Wireless LAN 802.11n USB minicard  
OBDA:817F=Realtek RTL8188RU Wireless LAN 802.11n USB High Power Dongle  
OBDA:817F:0200=Realtek RTL8188RU Wireless LAN 802.11n USB High Power Dongle

OBDA:8187=RTL8187 Wireless Adapter  
OBDA:8187:0100=Realtek RTL8187 Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
OBDA:8187:0200=Realtek RTL8187B Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
OBDA:8189=RTL8187B Wireless 802.11g 54Mbps Network Adapter  
OBDA:8189:0200=Realtek RTL8187B Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
OBDA:8192=RTL8192U 802.11n Wireless Adapter  
OBDA:8192:0100=Realtek RTL8192u 802.11n Wireless LAN USB 2.0 Network Adapter  
OBDA:8193=Realtek RTL8192DU Wireless LAN 802.11a/b/g/n USB 2.0 Network Adapter  
OBDA:8197=RTL8187B Wireless Adapter  
OBDA:8197:0200=Realtek RTL8187B Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
OBDA:8198=RTL8187B Wireless Adapter  
OBDA:8198:0200=Realtek RTL8187B Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
OBDA:8199:0200=Realtek RTL8187B Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
OBDA:8712=Realtek RTL8712 Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8724=Realtek RTL8723U Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:8724:02=Realtek RTL8723U Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDA:C047=Realtek RTL8188SU Wireless LAN 802.11n USB 2.0 Network Adapter  
OBDB=Ericsson Mobile  
OBDB:1000=Ericsson BV USB Bluetooth Device  
OBDB:1002=Ericsson USB Bluetooth Device 1.2  
OBDB:100E=Generic Flash Device  
OBDB:1049=C3607w Mobile Broadband Module  
OBDB:1900=F3507g Mobile Broadband Module  
OBDB:1902=F3507g v2 Mobile Broadband Module  
OBDB:1904=F3607gw Mobile Broadband Module  
OBDB:1905=F3607gw v2 Mobile Broadband Module  
OBDB:1906=F3607gw v3 Mobile Broadband Module  
OBDB:1909=F3307 v2 Mobile Broadband Module  
OBDB:190A=F3307 Mobile Broadband Module  
OBDB:190B=C3607w v2 Mobile Broadband Module  
OBDC=Y Media  
OBDD=Orange PCS  
OBE2=Kanda Tsushin Kogyo  
OBE3=TOYO  
OBE4=Elka International  
OBE5=DOME imaging systems  
OBE6=Dong Guan Humen Wonderful Wire Cable Factory  
OBED=Silicon Labs  
OBED:1100=MEI (TM) Cashflow-SC Bill/Voucher Acceptor  
OBEE=LTK Industries  
OBEF=Way2Call Communications  
OBF0=Pace Micro  
OBF1=Intracom S.A.  
OBF1:0001=netMod Driver Ver 2.4.17 (CAPI)  
OBF1:0002=netMod Driver Ver 2.4 (CAPI)  
OBF1:0003=netMod Driver Ver 2.4 (CAPI)  
OBF2=Konexx  
OBF6=Addonics Technologies  
OBF6:0103=Addonics USB Storage Device  
OBF6:1234=Addonics USB Storage Device  
OBF6:A000=USB Cable 205 (TPP)  
OBF6:A001=USB Cable 205 (TPP)  
OBF6:A002=IDE Bridge  
OBF7=Sunny Giken  
OBF8=Fujitsu Siemens

0BF8:1001=Fujitsu Pocket Loox 600 PDA  
0BF8:1002=connect2AIR WLAN E-1100 USB  
0BF8:1003=Fujitsu Siemens Bluetooth Device  
0BF8:1004=Fujitsu Siemens Keyboard KBPC SX  
0BF8:1005:01=SmartCard-Reader Keyboard USB 2A  
0BF8:1006=SmartCard-Reader USB 2A  
0BF8:1007=Connect2Air E-5400 802.11g Wireless Adapter  
0BF8:1009=Name: Connect2Air E-5400 D1700 802.11g Wireless Adapter [Intersil ISL3887]  
0BF8:100B=SmartCard-Reader USB 2C  
0BF8:100C=Keyboard FSC KBPC PX  
0BF8:100F=Fujitsu Siemens Computers WLAN 802.11b/g (SiS163u)  
0BFD=Kvaser AB  
0BFD:0004=USBcan II  
0BFD:000B=Leaf Light HS  
0BFD:000E=Leaf SemiPro HS  
0BFF:8160=Realtek RTL8188CU Wireless LAN 802.11n USB 2.0 Network Adapter  
0C04=MOTO Development Group  
0C05=Appian Graphics  
0C06=Hasbro  
0C07=Infinite Data Storage  
0C08=Agate  
0C08:0378=Q 16MB Storage Device  
0C09=Comjet Information System  
0C09:A5A5=Litto Version USB2.0  
0C0A=Highpoint Technologies  
0C0B=Dura Micro  
0C0B:27CB=6-in-1 Flash Reader and Writer  
0C0B:27D7=Multi Memory reader/writer MD-005  
0C0B:27DA=Multi Memory reader/writer MD-005  
0C0B:27DC=USB 2.0 Combo HDD  
0C0B:27E7=USB Storage Driver  
0C0B:27EE=USB Storage Driver  
0C0B:2814=USB Storage Driver  
0C0B:2815=USB Storage Driver  
0C0B:281D=3,5'' HDD case MD-231  
0C0B:5FAB=Storage Adaptor  
0C0B:A109=CF/SM Reader and Writer  
0C0B:A10C=SD/MS Reader and Writer  
0C0B:B001=USB 2.0 Storage Adaptor  
0C0B:B004=MMC/SD Reader and Writer  
0C10:0000=Silicon Wave Bluetooth Wireless Adapter  
0C10:0000:1350=Silicon Wave Bluetooth Wireless Adapter  
0C10:0001=BlueFRITZ! USB (WinXP/2000)  
0C12=ZeroPlus  
0C12:0005=PSX Vibration Feedback Converter  
0C12:0030=PSX Vibration Feedback Converter  
0C12:700E=Logic Analyzer (LAP-C-16032)  
0C12:8801=Xbox Controller  
0C12:8802=Xbox Controller  
0C12:8809=Red Octane Ignition Xbox DDR Pad  
0C12:880A=Pelican Eclipse PL-2023  
0C12:8810=Xbox Controller  
0C12:9902=VibraX  
0C15=Iris Graphics  
0C16=Gyration  
0C16:0002=RF Technology Receiver  
0C16:0003=RF Technology Receiver  
0C16:0008=RF Technology Receiver  
0C16:0080=eHome Infrared Receiver (USBCIR)

0C16:0081=eHome Infrared Receiver (USBCIR)  
0C17=Cyberboard  
0C18=SynerTek Korea  
0C19=cyberPIXIE  
0C1A=Silicon Motion  
0C1B=MIPS Technologies  
0C1C=Hang Zhou Silan  
0C22=Tally  
0C23=Lernout + Hauspie  
0C24=Taiyo Yuden  
0C24:0001=Taiyo Yuden Bluetooth Device  
0C24:0002=Taiyo Yuden Bluetooth Device2  
0C24:0005=Taiyo Yuden Bluetooth Device(BC04-External)  
0C24:000B=Taiyo Yuden Bluetooth Device(BC04-External)  
0C24:000C=Taiyo Yuden Bluetooth USB Adaptor  
0C24:000E=Taiyo Yuden Bluetooth Device(BC04-External)  
0C24:000F=USB Bluetooth Driver (V2.0+EDR)  
0C24:0010=Taiyo Yuden Bluetooth Device(BC04-External)  
0C24:0012=Taiyo Yuden Bluetooth Device(BC04-External)  
0C24:0018=Taiyo Yuden Bluetooth Device(BC04-External)  
0C24:0019=MATSUSHITA Bluetooth Device  
0C24:001B=Itronix Bluetooth Device  
0C24:001C=USB Bluetooth Driver (V2.0+EDR)  
0C24:001D=TAIYO YUDEN Bluetooth Device  
0C24:001E=TAIYO YUDEN Bluetooth Device  
0C24:001F=TAIYO YUDEN Bluetooth Device  
0C24:0020=TAIYO YUDEN Bluetooth Device  
0C24:0021=USB Bluetooth Driver (V2.1+EDR)  
0C24:0022=USB Bluetooth Driver (V2.1+EDR)  
0C24:0C24=Taiyo Yuden for NEC Bluetooth Device  
0C24:FFFF=Bluetooth module with BlueCore in DFU mode  
0C25=Sampo  
0C25:0310=Scream Cam  
0C26=Prolific Technology  
0C26:0018=USB-Serial Controller [Icom Inc. OPC-478UC]  
0C27=RFIDeas  
0C27:3BFA=pcProx Card Reader  
0C2E=Metrologic Instruments a Honeywell division  
0C2E:0007=Metrologic MS7120 Barcode Scanner (IBM SurePOS mode)  
0C2E:0200=Metrologic Scanner  
0C2E:0204=Metrologic MS7120 Barcode Scanner (keyboard mode)  
0C2E:0700=Metrologic USB Scanner  
0C2E:0701=Metrologic MX009  
0C2E:0702=Metrologic 5145  
0C2E:0703=Metrologic 7200  
0C2E:0704=Metrologic 7300  
0C2E:0705=Metrologic 7600  
0C2E:0720=Metrologic MS7120 Barcode Scanner (bi-directional serial mode)  
0C2E:0730=Honeywell Bidirectional Device  
0C2E:0731=Honeywell Bidirectional Device  
0C2E:090A=Xenon 1900 Area-Imaging Scanner  
0C2E:0914=Xenon 1900 Area-Imaging Scanner  
0C2E:092A=Xenon 1902 Wireless Area-Imaging Scanner  
0C2E:0934=Xenon 1902 Wireless Area-Imaging Scanner  
0C2E:094A=Honeywell Access Point  
0C2E:0954=Honeywell Access Point  
0C2E:096A=Honeywell N5600 Area-Imaging Engine  
0C2E:098A=Xenon 1500 Area-Imaging Scanner  
0C2E:0994=Xenon 1500 Area-Imaging Scanner  
0C2E:0A0A=Voyager 1200

0C2E:0A14=Voyager 1200  
0C2E:0A2A=Voyager-CCB00  
0C2E:0A34=Voyager-CCB00  
0C2E:0B0A=Hyperion 1300g  
0C2E:0B14=Hyperion 1300g  
0C2E:0B4A=Voyager-1250  
0C2E:0B54=Voyager-1250  
0C2E:0B6A=Vuquest 3310 Area-Imaging Scanner  
0C2E:0B74=Vuquest 3310 Area-Imaging Scanner  
0C35=Eagletron  
0C36=E Ink  
0C37=e.Digital  
0C38=Der An Electric Wire & Cable  
0C39=IFR  
0C3A=Furui Precise Component (Kunshan)  
0C3B=Komatsu  
0C3C=Radius  
0C3D=Innocom  
0C3E=Nextcell  
0C44=Motorola  
0C44:0020=Motorola iDEN USB Modem  
0C44:0021=iDEN P2k0 Device  
0C44:0022=iDEN P2k1 Device  
0C44:03A2=Motorola iDEN Smartphone  
0C44:41D9=i1 phone  
0C45=Creative Technology  
0C45:0011=EBUDDY  
0C45:1010=CF USB Mass Storage Controller(1010)  
0C45:1018=CF USB Mass Storage Controller(1018)  
0C45:1020=Mass Storage Reader  
0C45:1028=Mass Storage Reader  
0C45:1030=Mass Storage Reader  
0C45:1031=Mass Storage Device  
0C45:1032=Mass Storage Reader  
0C45:1033=Mass Storage Device  
0C45:1034=Mass Storage Reader  
0C45:1035=Mass Storage Reader  
0C45:1036=Mass Storage Reader  
0C45:1037=Sonix Mass Storage Device  
0C45:1050=CF Card Reader  
0C45:1058=HDD Reader  
0C45:1060=iFlash SM-Direct Card Reader  
0C45:1061=Mass Storage Reader  
0C45:1062=Mass Storage Reader  
0C45:1063=Sonix Mass Storage Device  
0C45:1064=Mass Storage Reader  
0C45:1065=Mass Storage Reader  
0C45:1066=Mass Storage Reader  
0C45:1067=Mass Storage Reader  
0C45:1158=A56AK  
0C45:184C=VoIP Phone  
0C45:6001=Genius VideoCAM NB  
0C45:6005=PC Camera (6005 CIF)  
0C45:6007=VideoCAM Eye  
0C45:6009=VideoCAM ExpressII  
0C45:600D=CIF USB Camera (2110A)  
0C45:6011=PC Camera (SN9C102)  
0C45:6019=PC Camera (SN9C102)  
0C45:6024=VideoCAM ExpressII  
0C45:6025=VideoCAM ExpressII

0C45:6028=USB PC Camera (SN9C102)  
0C45:6029=Triplex i-mini PC camera  
0C45:602A=Meade ETX-105EC Camera  
0C45:602B=VideoCAM NB 300  
0C45:602C=Clas Ohlson TWC-30XOP WebCam  
0C45:602D=VideoCAM ExpressII  
0C45:602E=VideoCAM Messenger  
0C45:6030=VideoCAM ExpressII  
0C45:603F=VideoCAM ExpressII  
0C45:6040=CCD PC Camera (PC390A)  
0C45:606A=CCD PC Camera (PC390A)  
0C45:607A=CCD PC Camera (PC390A)  
0C45:607B=Win2 PC Camera  
0C45:607C=CCD PC Camera (PC390A)  
0C45:607E=CCD PC Camera (PC390A)  
0C45:6080=Audio (Microphone)  
0C45:6082=VideoCAM Look  
0C45:6083=VideoCAM Look  
0C45:608B=USB PC Camera (SN9C103)  
0C45:608C=VideoCAM Look  
0C45:608E=VideoCAM Look  
0C45:608F=VideoCAM Look  
0C45:60A8=VideoCAM Look  
0C45:60AA=VideoCAM Look  
0C45:60AB=PC Camera  
0C45:60AF=VideoCAM Look  
0C45:60B0=Genius VideoCam Look  
0C45:60C0=PC Camera with Mic (SN9C105)  
0C45:60C2=USB PC Camera with Mic (SN9C105)  
0C45:60C8=Win2 PC Camera  
0C45:60CC=Composite Device  
0C45:60CE=USB PC Camera with Mic (SN9C105)  
0C45:60EC=Composite Device  
0C45:60EF=Win2 PC Camera  
0C45:60F2=USB PC Camera with Mic (SN9C105)  
0C45:60FA=PC Camera with Mic (SN9C105)  
0C45:60FB=Composite Device  
0C45:60FC=PC Camera with Mic (SN9C105)  
0C45:60FE=Audio (Microphone)  
0C45:6100=USB PC Camera (SN9C128)  
0C45:6102=USB PC Camera-168  
0C45:6108=Win2 PC Camera  
0C45:610A=USB PC Camera (SN9C128)  
0C45:610B=USB PC Camera (SN9C128)  
0C45:610C=USB PC Camera (SN9C128)  
0C45:610E=USB PC Camera (SN9C128)  
0C45:610F=USB PC Camera (SN9C120)  
0C45:6122=PC Camera (SN9C110)  
0C45:6123=PC Camera (SN9C110)  
0C45:6128=PC Camera (SN9C325 + OM6802)  
0C45:612A=PC Camera (SN9C325)  
0C45:612C=PC Camera (SN9C110)  
0C45:612E=PC Camera (SN9C110)  
0C45:612F=PC Camera (SN9C110)  
0C45:6130=PC Camera (SN9C120)  
0C45:6132=USB PC Camera-168  
0C45:6138=Win2 PC Camera  
0C45:613A=PC Camera (SN9C120)  
0C45:613B=Win2 PC Camera  
0C45:613C=PC Camera (SN9C120)

0C45:613E=PC Camera (SN9C120)  
0C45:6142=USB PC Camera-168  
0C45:6143=PC Camera (SN9C120 + SP80708)  
0C45:6148=USB PC Camera-168  
0C45:614A=USB PC Camera-168  
0C45:614C=USB PC Camera-168  
0C45:6240=PC Camera (SN9C201 + MI1300)  
0C45:6242=PC Camera (SN9C201 + MI1310)  
0C45:6243=PC Camera (SN9C201 + S5K4AAFX)  
0C45:6248=PC Camera (SN9C201 + OV9655)  
0C45:624B=PC Camera (SN9C201 + CX1332)  
0C45:624C=PC Camera (SN9C201 + MI1320)  
0C45:624E=PC Camera (SN9C201 + SOI968)  
0C45:624F=PC Camera (SN9C201 + OV9650)  
0C45:6251=PC Camera (SN9C201 + OV9650)  
0C45:6253=PC Camera (SN9C201 + OV9650)  
0C45:6260=PC Camera (SN9C201 + OV7670ISP)  
0C45:6262=PC Camera (SN9C201 + OM6802)  
0C45:6270=U-CAM PC Camera NE878  
0C45:627A=PC Camera (SN9C201 + S5K53BEB)  
0C45:627B=PC Camera (SN9C201 + OV7660)  
0C45:627C=PC Camera (SN9C201 + HV7131R)  
0C45:627F=PC Camera (SN9C201 + OV965x + EEPROM)  
0C45:6280=PC Camera with Microphone (SN9C202 + MI1300)  
0C45:6282=PC Camera with Microphone (SN9C202 + MI1310)  
0C45:6283=PC Camera with Microphone (SN9C202 + S5K4AAFX)  
0C45:6288=PC Camera with Microphone (SN9C202 + OV9655)  
0C45:628A=PC Camera with Microphone (SN9C202 + ICM107)  
0C45:628B=PC Camera with Microphone (SN9C202 + CX1332)  
0C45:628C=PC Camera with Microphone (SN9C202 + MI1320)  
0C45:628E=PC Camera with Microphone (SN9C202 + SOI968)  
0C45:628F=PC Camera with Microphone (SN9C202 + OV9650)  
0C45:62A0=PC Camera with Microphone (SN9C202 + OV7670ISP)  
0C45:62A2=PC Camera with Microphone (SN9C202 + OM6802)  
0C45:62B0=PC Camera with Microphone (SN9C201 + MI0360/MT9V011 or MI0360SOC/MT9V11)  
0C45:62B3=PC Camera with Microphone (SN9C202 + OV9655)  
0C45:62BA=PC Camera with Microphone (SN9C202 + S5K53BEB)  
0C45:62BB=PC Camera with Microphone (SN9C202 + OV7660)  
0C45:62BC=PC Camera with Microphone (SN9C202 + HV7131R)  
0C45:62BE=PC Camera with Microphone (SN9C202 + OV7663)  
0C45:62C0=Sonix USB 2.0 Camera  
0C45:62C1=ASUS USB2.0 Webcam  
0C45:62E0=MSI Starcam Racer  
0C45:62E1=ASUS USB2.0 Webcam  
0C45:62F0=ASUS USB2.0 Webcam  
0C45:62F1=ASUS USB2.0 Webcam  
0C45:6300=ASUS USB2.0 Webcam  
0C45:6301=ASUS USB2.0 Webcam  
0C45:6310=Sonix USB 2.0 Camera  
0C45:63E0=Sonix Integrated Webcam  
0C45:63E4=Integrated Webcam  
0C45:63E5=Integrated Webcam  
0C45:63E6=Integrated Webcam  
0C45:63F0=Integrated Webcam  
0C45:63F1=Integrated Webcam  
0C45:63F2=Integrated Webcam  
0C45:63F3=Integrated Webcam  
0C45:63F4=Integrated Webcam  
0C45:63F5=Integrated Webcam



0C45:63F6=Integrated Webcam  
0C45:63F7=Integrated Webcam  
0C45:63F8=Integrated Webcam  
0C45:63F9=Integrated Webcam  
0C45:63FA=Integrated Webcam  
0C45:63FB=Integrated Webcam  
0C45:63FC=Integrated Webcam  
0C45:63FD=Integrated Webcam  
0C45:63FE=Integrated Webcam  
0C45:63FF=Integrated Webcam  
0C45:6408=Integrated Webcam  
0C45:6409=Webcam  
0C45:6417=Integrated Webcam  
0C45:641D=1.3 MPixel Integrated Webcam  
0C45:6480=Sonix 1.3 MP Laptop Integrated Webcam  
0C45:6481=Integrated Webcam  
0C45:8000=DC31VC  
0C45:8001=Dual Mode Camera (8001 CIF)  
0C45:8006=Dual Mode Camera (8006 VGA)  
0C45:800A=Vivitar Vivicam3350B  
0C46=WaveRider  
0C4A=ALGE-TIMING GmbH  
0C4A:0889=Timy  
0C4A:088A=Timy 2  
0C4B=Reiner SCT Kartensysteme GmbH  
0C4B:0100=cyberJack e-com/pinpad  
0C4B:0300=cyberJack pinpad(a)  
0C4B:0400=cyberJack e-com(a)/Secoder USB  
0C4B:0401=cyberJack e-com(f) USB  
0C4B:0500=cyberJack RFID standard  
0C4B:0501=cyberJack RFID komfort  
0C4B:9102=cyberJack RFID basis contactless smartcard reader  
0C4C=Needham's Electronics  
0C4C:0021=EMP-21 Universal Programmer  
0C52=Sealevel Systems  
0C52:2101=Serial Converter  
0C53=ViewPLUS  
0C54=GLORY  
0C55=Spectrum Digital  
0C55:0510=Spectrum Digital XDS510 USB  
0C55:0540=Spectrum Digital SPI540  
0C55:5416=Spectrum Digital TMS320C5416 DSK  
0C55:6416=Spectrum Digital TMS320C6416 DDB  
0C56=Billion Bright  
0C57=Imaginative Design  
0C58=Vidar Systems  
0C59=Dong Guan Shinko  
0C5A=TRS International  
0C5E=Xytronix Research & Design  
0C60=Apogee Electronics  
0C62=Chant Sincere  
0C63=Toko  
0C64=Signality  
0C65=Eminence Enterprise  
0C66=Rexon Electronics  
0C67=Concept Telecom  
0C68=Whanam Electronics  
0C70=MCT Elektronikladen  
0C70:0000=USB08 Development board  
0C72=PEAK System

0C72:000C=PCAN-USB  
0C74=Optronic Laboratories  
0C74:0002=OL 700-30 Goniometer  
0C76=JMTek, LLC.  
0C76:0001=Mass Storage Controller  
0C76:0002=Mass Storage Controller  
0C76:0003=USBdisk  
0C76:0004=Mass Storage Controller  
0C76:0005=USBdisk  
0C76:0006=Transcend JetFlash  
0C76:0007=USB Mass Storage Device  
0C76:1605=SSS Headphone Set  
0C76:1607=audio controller  
0C77=Sipix Group  
0C77:1001=SiPix Web2  
0C77:1002=SiPix SC2100  
0C77:1010=SiPix Snap  
0C77:1011=SiPix StyleCam BlinkII Dual Mode Camera  
0C77:1015=SiPix CAMEleon  
0C78=Detto  
0C79=NuConnex Technologies Pte.  
0C7A=Wing-Span Enterprise  
0C7D:0001=ELEKTOR, USBuart  
0C86=NDA Technologies  
0C88=Kyocera Wireless  
0C88:0020=KYOCERA WIRELESS CORPORATION  
0C88:0021=Kyocera Handheld  
0C88:005A=Kyocera KX2 Wireless CDMA Modem  
0C88:005A:01=Kyocera KX2 Control Port  
0C88:0450=Kyocera KX3 Wireless CDMA Modem  
0C88:0450:01=Kyocera KX3 Control Port  
0C88:0839=Kyocera KX5 Wireless CDMA Modem  
0C88:0839:01=Kyocera KX5 Control Port  
0C88:17DA=Kyocera CDMA Wireless Modem  
0C88:17DA:01=Kyocera Control Port  
0C88:180A=Kyocera CDMA Wireless Modem  
0C88:180A:01=Kyocera Control Port  
0C89=Honda Tsushin Kogyo  
0C8A=Pathway Connectivity  
0C8B=Wavefly  
0C8C=Coactive Networks  
0C8D=Tempo  
0C8E=Cesscom  
0C8E:6000=Cesscom Luxian Series  
0C8F=Applied Microsystems  
0C94=Cryptera  
0C94:A000=EPP 1217  
0C98=Berkshire Products  
0C98:1140=USB PC Watchdog  
0C99=Innochips  
0C9A=Hanwool Robotics  
0C9B=Jobin Yvon  
0C9D=SemTek  
0C9D:0170=3873 Manual Insert card reader  
0CA0:1101=BOSCH USB Bluetooth Device  
0CA2=Zyfer  
0CA3=Sega  
0CA4=ST&T Instrument  
0CA5=BAE Systems Canada  
0CA6=Castles Technology

OCA6:0010=EZUSB PC/SC Smart Card Reader  
OCA6:0050=EZ220PU Reader Controller  
OCA6:1077=Bludrive Family Smart Card Reader  
OCA6:107E=VENUS Reader Controller  
OCA6:2010=myPad110 PC/SC Smart Card Reader  
OCA6:3050=EZ710 Smart Card Reader  
OCA7=Information Systems Laboratories  
OCAD=Motorola CGISS  
OCAD:9001=Motorola PowerPad Pocket PC Device  
OCAE=Ascom Business Systems  
OCAF=Buslink  
OCAF:2507=Hi-Speed USB-to-IDE Bridge Controller  
OCAF:2515=Flash Disk Embedded Hub  
OCAF:2516=Flash Disk Security Device  
OCAF:2517=Flash Disk Mass Storage Device  
OCAF:25C7=Hi-Speed USB-to-IDE Bridge Controller  
OCAF:3A00=Hard Drive  
OCAF:3A20=USB 2.0 Mass Storage Device  
OCAF:3ACD=USB 2.0 Mass Storage Device  
OCB0=Flying Pig Systems  
OCB1=Innovonics  
OCB6=Celestix Networks, Pte.  
OCB7=Singatron Enterprise  
OCB8=Opticis  
OCBA=Trust Electronic (Shanghai)  
OCBB=Shanghai Darong Electronics  
OCBC=Palmax Technology  
OCBC:0101=Pocket PC P6C  
OCBC:0201=Personal Digital Assistant  
OCBC:0301=Personal Digital Assistant P6M+  
OCBC:0401=Pocket PC  
OCBD=Pentel  
OCBE=Keryx Technologies  
OCBF=Union Genius Computer  
OCC0=Kuon Yi Industrial  
OCC1=Given Imaging  
OCC2=Timex  
OCC3=Rimage  
OCC4=emsys GmbH  
OCC4:0815=Siemens Mobile Phone USB Modem  
OCC4:0816=Siemens Mobile Phone USB Modem  
OCC4:0816:01=Siemens Mobile Phone USB Modem (Debug)  
OCC5=Sendo  
OCC6=Intermagic  
OCC7=Kontron Medical AG  
OCC8=Technotools  
OCC9=BroadMAX Technologies  
OCCA=AMPHENOL  
OCCB=SKNet  
OCCC=DOMEX TECHNOLOGY  
OCCD=TerraTec Electronic GmbH  
OCCD:0012=PHASE 26  
OCCD:0013=PHASE 26  
OCCD:0014=PHASE 26  
OCCD:0015=Flash Update for TerraTec PHASE 26  
OCCD:0021=Cameo Grabster 200  
OCCD:0023=Mystify Claw  
OCCD:0028=Aureon 5.1 MkII  
OCCD:0032=MIDI HUBBLE  
OCCD:0035=Miditech Play'n Roll

0CCD:0036=Cinergy 250 Audio  
0CCD:0036:01=Cinergy 250 USB Audio  
0CCD:0037=Cinergy 250 Audio  
0CCD:0037:01=Cinergy 250 USB Audio (FR)  
0CCD:0038=Cinergy T?(BDA)  
0CCD:0039=Grabster AV 400  
0CCD:003B=Cinergy 400  
0CCD:003C=Grabster AV 250  
0CCD:0042=Cinergy Hybrid T XS  
0CCD:0043=Cinergy T XS  
0CCD:004C=Cinergy Hybrid T USB XS (2880 FR)  
0CCD:004D=Cinergy HT Express  
0CCD:004E=Cinergy T XS  
0CCD:004F=Cinergy Analog XS  
0CCD:0055=Cinergy T XE (Version 1, AF9005)  
0CCD:0058=Cinergy HT USB XE IR  
0CCD:005A=Cinergy DT USB XS Diversity IR  
0CCD:005C=Cinergy T?(BDA)  
0CCD:005E=Cinergy Hybrid T USB XS (2882)  
0CCD:0062=Cinergy T Express Capture  
0CCD:0069=Cinergy T XE DVB-T Receiver  
0CCD:006B=Cinergy HT PVR (EU)  
0CCD:0072=Cinergy Hybrid T  
0CCD:0077=Aureon Dual USB  
0CCD:0078=Cinergy T XXS  
0CCD:0080=DMX 6fire Device  
0CCD:0086=Cinergy Hybrid XE  
0CCD:0097=Cinergy T RC MKII  
0CCD:0099=AfaTech 9015 [Cinergy T Stick Dual]  
0CCD:00A5=Cinergy Hybrid Stick  
0CCD:00A9=RTL2838 DVB-T COFDM Demodulator [TerraTec Cinergy T Stick Black]  
0CCD:00B3=NOXON DAB/DAB+ Stick  
0CCD:10A0=TerraTec T3  
0CCD:10A1=TerraTec T5 IR  
0CD2=C-Map  
0CD2:0001=C-Map USBCC Reader  
0CD2:1000=PXA Chart Plotter  
0CD2:1001=S3C Chart Plotter  
0CD2:FFFF=C-Map USBCC Reader without Firmware  
0CD4=Bang Olufsen  
0CD4:0101=BeoLink PC 2  
0CD5=LabJack  
0CD5:0003=U3  
0CD5:0009=UE9  
0CD7=NewChip S.r.l.  
0CD8=JS Digitech  
0CD8:2007=JS Digitech USB Smart Card Reader/JSTU-9700  
0CD9=Hitachi Shin Din Cable  
0CDE=Z-Com  
0CDE:0001=M4Y-750  
0CDE:0002=725/726 Prism2.5 802.11b Adapter  
0CDE:0003=Sagem 802.11b Dongle  
0CDE:0004=Sagem 802.11b Dongle  
0CDE:0005=XI-735 Prism3 802.11b Adapter  
0CDE:0006=Medion 40900 802.11b Adapter  
0CDE:0008=NB 802.11g Wireless LAN USB Adapter  
0CDE:0009=Wi-Fi Wireless LAN USB Adapter  
0CDE:0011=ZD1211  
0CDE:0012=AR5523  
0CDE:0013=AR5523 driver (no firmware)

0CDE:0014=FEC W-Client USB .11g  
0CDE:0015=FEC W-Client USB .11g  
0CDE:0016=FEC W-Client USB .11g  
0CDE:0018=FEC W-Client USB .11g  
0CDE:001A=Wi-Fi Wireless LAN USB Adapter  
0CDE:001C=802.11b/g Wireless Network Adapter  
0CDE:0020=Wi-Fi Wireless LAN USB Adapter  
0CDE:0022=802.11b/g/n Wireless Network Adapter  
0CDE:0023=UB81 802.11bgn (ar9170)  
0CDE:0025=802.11b/g/n USB Wireless Network Adapter  
0CDE:0026=UB82 802.11abgn (ar9170)  
0CDE:0030=Z-com  
0CE5=Validation Technologies International  
0CE5:0003=Matrix  
0CE9=pico Technology  
0CE9:1001=PicoScope3204  
0CF1=e-CONN ELECTRONIC  
0CF2=ENE Technology  
0CF2:6220=ENE USB Mass Storage Controller  
0CF2:6225=SD card reader (UB6225)  
0CF2:6250=SD card reader (UB6250)  
0CF3=Atheros Communications  
0CF3:0001=AR5523  
0CF3:0001:0001=AirLancer USB-54ag  
0CF3:0002=Atheros USB 2.0 Wireless Network Adapter  
0CF3:0002:0001=AirLancer USB 54 Wireless - Bootloader  
0CF3:0003=AR5523  
0CF3:0004=Atheros AR5005UG USB 2.0 Wireless Network Adapter  
0CF3:0005=AR5523  
0CF3:0006=Atheros AR5005UX USB 2.0 Wireless Network Adapter  
0CF3:1001=TG121N (ar9170)  
0CF3:1002=TP-Link TL-WN821N v2 [Atheros AR9001U-(2)NG]  
0CF3:1006=TP-Link TL-WN422G v2 802.11g [Atheros AR9271]  
0CF3:1010=3Com 3CRUSB275 802.11abgn Wireless Adapter [Atheros AR9170]  
0CF3:20FF=Virtual CD-ROM  
0CF3:3000=AR3011  
0CF3:3002=MotioninJoy Virtual Xinput device for Windows  
0CF3:3005=AR3011 Bluetooth  
0CF3:7015=TP-Link TL-WN821N  
0CF3:9170=AR9170 802.11n  
0CF3:9271=AR9271 802.11n  
0CF3:B002=Ubiquiti WiFiStation 802.11n [Atheros AR9271]  
0CF3:B003=AR9271 802.11n  
0CF4=Fomtex  
0CF5=Cellink  
0CF6=Compucable  
0CF7=ishoni Networks  
0CF8=Clarisys  
0CF8:0750=Claritel-i750 - vp  
0CF8:0750:01=Claritel-i750 - Speaker  
0CF8:0750:02=Claritel-i750 - Microphone  
0CF8:0750:03=Claritel-i750 - Keypad  
0CF8:0750:0198=Claritel-i750 - vp  
0CF9=Central System Research  
0CFA=Inviso  
0CFC=Minolta-QMS  
0CFC:2301=Magicolor 2300 DL  
0CFC:2350=Magicolor 2350EN/3300  
0CFC:3100=Magicolor 3100  
0CFC:7300=Magicolor 5450/5550

OCFF=SAFA MEDIA  
OCFF:0320=SR-380N  
OD06=telos EDV Systementwicklung GmbH  
OD08=UTStarcom  
OD08:0602=DV007 [serial]  
OD08:0603=DV007 [storage]  
OD0B=Contemporary Controls  
OD0C=Astron Electronics  
OD0D=MKNet  
OD0E=Hybrid Networks  
OD0F=Feng Shin Cable  
OD10=Elastic Networks  
OD10:0001=StormPort (WDM)  
OD11=Maspro Denkoh  
OD12=Hansol Electronics  
OD13=BMF  
OD14=Array Comm  
OD15=OnStream b.v.  
OD16=Hi-Touch Imaging Technologies  
OD16:0001=PhotoShuttle  
OD16:0002=Photo Printer 730 series  
OD16:0004=Photo Printer 63xPL/PS  
OD16:0100=Photo Printer 63xPL/PS  
OD16:0102=Photo Printer 64xPS  
OD16:0103=Photo Printer 730 series  
OD16:0104=Photo Printer 63xPL/PS  
OD16:0105=Photo Printer 64xPS  
OD16:0200=Photo Printer 64xDL  
OD17=NALTEC  
OD18=coaXmedia  
OD19=Hank Connection Industrial  
OD28=NXP  
OD28:0204=LPC1768  
OD32=Leo Hui Electric Wire & Cable  
OD33=AirSpeak  
OD34=Rearden Steel Technologies  
OD35=Dah Kun  
OD3A=Posiflex Technologies  
OD3C=SRI Cable Technology  
OD3D=Tangtop Technology  
OD3D:0001=HID Keyboard  
OD3D:0001:01=HID Mouse  
OD3D:4130=Intelligent USB Sharing Switch  
OD3E=Fitcom  
OD3F=MTS Systems  
OD40=Ascor  
OD41=Ta Yun Terminals Industrial  
OD42=FULL DER  
OD46=Kobil Systems GmbH  
OD46:2012=KAAN Standard Plus (Smartcard reader)  
OD46:3001=KAAN Base  
OD46:3002=KAAN Advanced  
OD46:3003=KOBIL mIDentity light  
OD46:3010=SecOVID Reader III  
OD46:3011=EMV CAP Reader  
OD46:4000=mIDentity (mass storage)  
OD46:4000:01=KOBIL mIDentity  
OD46:4001=mIDentity Basic/Classic (composite device)  
OD46:4001:01=KOBIL mIDentity  
OD46:4020=mIDentity SCR

0D46:4081=mIDentity Basic/Classic (installationless)  
0D49=Maxtor  
0D49:3000=Maxtor USB Drive  
0D49:3010=3000LE USB Drive  
0D49:3100=Hi-Speed USB-IDE Bridge Controller  
0D49:3200=Personal Storage 3200  
0D49:5000=5000XT USB Drive  
0D49:5010=5000LE USB Drive  
0D49:5020=5000DV USB Drive  
0D49:7000=Maxtor OneTouch  
0D49:7010=Maxtor OneTouch  
0D49:7350=Maxtor OneTouch USB Disk Drive  
0D49:7410=Mobile Hard Disk Drive (1TB)  
0D49:7450=Basics Portable USB Device  
0D4A=NF  
0D4B=Grape Systems  
0D4C=Tedas AG  
0D4D=Coherent  
0D4E=Agere Systems Netherland BV  
0D4E:047A=WLAN USB Card  
0D4E:1000=Wireless USB Card Model 0801  
0D4E:1001=Wireless USB Card Model 0802  
0D4F=EADS Airbus France  
0D50=Cleware GmbH  
0D50:0011=USB-Temp2 Thermometer  
0D51=Volex (Asia) Pte  
0D53=HMI  
0D54=Holon  
0D55=ASKA Technologies  
0D56=AVLAB Technology  
0D57=Solomon Microtech  
0D5C=Belkin  
0D5C:A001=SMC2662W EZ Connect Wireless USB Adapter  
0D5C:A002=F5D6050 802.11b Adapter  
0D5E=Myacom  
0D5E:2346=BT Digital Access adapter  
0D5F=CSI  
0D60=IVL Technologies  
0D61=MEILU ELECTRONICS (SHENZHEN)  
0D62=Darfon Electronics  
0D62:0003=Smartcard Reader  
0D62:0004=Filter Driver  
0D62:0004:01=Filter Driver  
0D62:001C=Benq X120 Internet Keyboard Pro  
0D62:0306=M530 Mouse  
0D62:0800=Magic Wheel  
0D62:104A=USB 2.0 UVC 2M AM Web cam  
0D62:104B=USB 2.0 UVC 2M AM Web cam  
0D62:2021=AM805 Keyboard  
0D62:2021:01=AM805 Mouse  
0D62:2026=TECOM Bluetooth Device  
0D62:2050=Mouse  
0D62:2106=Dell L20U Multimedia Keyboard  
0D62:A100=Benq Mouse  
0D63=Fritz Gegauf AG  
0D64=DXG Technology  
0D64:0105=Dual Mode Digital Camera 1.3M  
0D64:0107=Horus MT-409 Camera  
0D64:0108=Dual Mode Digital Camera  
0D64:0202=Dual Mode Video Camera Device

0D64:0202:01=Dual Mode Still Camera Device  
0D64:0303=DXG-305V Camera  
0D64:1001=SiPix Stylecam/UMAX AstraPix 320s  
0D64:1002=Fashion Cam 01 Dual-Mode DSC (Video Camera)  
0D64:1003=Fashion Cam Dual-Mode DSC (Controller)  
0D64:1021=Dual-Mode DSC (Still Camera)  
0D64:1021:01=Dual-Mode DSC (Video Camera)  
0D64:1208=Dual Mode Video Camera Device  
0D64:1208:01=Dual Mode Still Camera Device  
0D64:2208=Mass Storage  
0D64:3105=Dual Mode Digital Camera Disk  
0D64:3108=Digicam Mass Storage Device  
0D65=KMJP  
0D66=TMT  
0D67=Advanet  
0D68=Super Link Electronics  
0D69=NSI  
0D69:F007=NSI MUXy Meta (Prototype)  
0D69:F007:0100=MUXy Meta  
0D69:F008=NSI MUXy Meta  
0D69:F008:0100=MUXy Meta  
0D6A=Megapower International  
0D6B=And-Or Logic  
0D70=Try Computer  
0D71=Hirakawa Hewtech  
0D72=Winmate Communication  
0D73=Hit's Communications  
0D76=MFP Korea  
0D77=Power Sentry/Newpoint  
0D78=Japan Distributor  
0D7A=MARX Software Security GmbH  
0D7B=Wellco Technology  
0D7C=Taiwan Line Tek Electronic  
0D7D=Apacer?  
0D7D:0100=HandyDrive  
0D7D:0110=Gigabyte FlexDrive  
0D7D:0120=Disk Pro 64MB  
0D7D:0124=GIGABYTE Disk  
0D7D:0240=Apacer?6-in-1 Embedded Card Reader  
0D7D:110E=NEC uPD720121/130 USB-ATA/ATAPI Bridge  
0D7D:1240=Apacer 6-in-1 Card Reader 2.0  
0D7D:1270=Wolverine SixPac 6000  
0D7D:1300=USB Card Series Driver  
0D7D:1320=USB Card Series Driver  
0D7D:1400=Attache 256MB USB 2.0 Flash Drive  
0D7D:1420=PS2044 Pen Drive  
0D7D:1470=Voasonic X's-Drive II+ VP2160  
0D7D:1600=PNY Attache 1GB USB 2.0 Flash Drive  
0D7D:1620=USB Disk Pro  
0D7D:1900=USB Thumb Drive  
0D7D:AC01=ADD ON USB Cinema system  
0D7E=American Computer & Digital  
0D7E:2507=Hi-Speed USB-to-IDE Bridge Controller  
0D7E:2517=Hi-Speed Mass Storage Device  
0D7E:25C7=Hi-Speed USB-to-IDE Bridge Controller  
0D7F=Essential Reality LLC  
0D7F:0100=P5 Glove glove controller  
0D80=H.R. Silvine Electronics  
0D81=TechnoVision  
0D83=Think Outside



0D85:0001=DFR-200 USB Fingerprint Reader  
0D85:0002=DFR-300 USB Fingerprint Reader  
0D87=Dolby Laboratories  
0D89=Oz Software  
0D8A=KING JIM  
0D8A:0101=TEPRA PRO  
0D8B=Ascom Telecommunications  
0D8C=C-MEDIA ELECTRONICS INC.  
0D8C:0001=Audio Device  
0D8C:0002=Composite Device  
0D8C:0003=Sound Device  
0D8C:0003:02=USB Human Interface Device  
0D8C:0006=Storm HP-USB500 5.1 Headset  
0D8C:0006:03=USB Human Interface Device  
0D8C:000C=Audio Adapter  
0D8C:000C:03=USB Human Interface Device  
0D8C:000D=Composite Device  
0D8C:000D:03=USB Human Interface Device  
0D8C:000E=Audio Adapter (Planet UP-100, Genius G-Talk)  
0D8C:001F=CM108 Audio Controller  
0D8C:0102=CM106 Like Sound Device  
0D8C:0103=Turtle Beach Audio Advantage Micro  
0D8C:0104=CM103+ Audio Controller  
0D8C:0105=CM108 Audio Controller  
0D8C:0107=CM108 Audio Controller  
0D8C:010F=CM108 Audio Controller  
0D8C:0115=CM108 Audio Controller  
0D8C:0138=USB PnP Sound Device  
0D8C:0139=USB PnP Sound Device  
0D8C:013C=USB PnP Sound Device  
0D8C:0201=CM6501  
0D8C:5000=Mass Storage Controller  
0D8C:5200=Mass Storage Controller(0D8C,5200)  
0D8C:B213=USB Phone CM109 (aka CT2000,VPT1000)  
0D8D=Promotion & Display Technology  
0D8D:0234=V-234 Composite Device  
0D8D:0550=V-550 Composite Device  
0D8D:0551=V-551 Composite Device  
0D8D:0552=V-552 Composite Device  
0D8D:0651=V-651 Composite Device  
0D8D:0652=V-652 Composite Device  
0D8D:0653=V-653 Composite Device  
0D8D:0654=V-654 Composite Device  
0D8D:0655=V-655 Composite Device  
0D8D:0656=V-656 Composite Device  
0D8D:0657=V-657 Composite Device  
0D8D:0658=V-658 Composite Device  
0D8D:0659=V-659 Composite Device  
0D8D:0660=V-660 Composite Device  
0D8D:0661=V-661 Composite Device  
0D8D:0662=V-662 Composite Device  
0D8D:0850=V-850 Composite Device  
0D8D:0851=V-851 Composite Device  
0D8D:0852=V-852 Composite Device  
0D8D:0901=V-901 Composite Device  
0D8D:0902=V-902 Composite Device  
0D8D:0903=V-903 Composite Device  
0D8D:4754=Voyager DMP Composite Device  
0D8D:BB00=Bloomberg Composite Device  
0D8D:BB01=Bloomberg Composite Device

0D8D:BB02=Bloomberg Composite Device  
0D8D:BB03=Bloomberg Composite Device  
0D8D:BB04=Bloomberg Composite Device  
0D8D:BB05=Bloomberg Composite Device  
0D8D:FFFE=Global Tuner Composite Device  
0D8D:FFFF=Voyager DMP Composite Device  
0D8E=Global Sun Technology  
0D8E:0163=802.11g 54 Mbps Wireless USB Dongle  
0D8E:1621=802.11b Wireless USB Adapter  
0D8E:3762=802.11g Wireless Mini adapter  
0D8E:3763=802.11g Wireless dongle  
0D8E:7100=802.11b Adapter  
0D8E:7110=WL-210  
0D8E:7605=TRENDnet TEW-224UB 802.11b Wireless Adapter [Atmel AT76C503A]  
0D8E:7801=AR5523  
0D8E:7802=AR5523 (no firmware)  
0D8E:7811=AR5523  
0D8E:7812=AR5523 (no firmware)  
0D8E:7A01=PRISM25 802.11b Adapter  
0D8F=Pitney Bowes  
0D90=Sure-Fire Electrical  
0D96=Traveler  
0D96:0000=Jenoptik JD350 video  
0D96:3300=SX330z Digital Camera  
0D96:4100=SX410z Digital Camera  
0D96:4102=MD9721  
0D96:4104=Jenoptik JD-4100z3s  
0D96:410A=Medion 9801/Novatech SX-410z  
0D96:5200=SX-520z Camera  
0D97=Santa Barbara Instrument Group  
0D97:0001=SBIG Astronomy Camera (without firmware)  
0D97:0101=SBIG Astronomy Camera (with firmware)  
0D98=Mars Semiconductor  
0D98:0300=Avaya Wireless USB Card  
0D99=Trazer Technologies  
0D9A=RTX Telecom AS  
0D9A:0001=Formosa Bluetooth Device  
0D9B=Tat Shing Electrical  
0D9C=Chee Chen Hi-Technology  
0D9D=Sanwa Supply  
0D9E=Avaya  
0D9E:0300=Avaya Wireless USB Card  
0D9F=Powercom  
0D9F:0001=Uninterruptible Power Supply  
0D9F:0002=Uninterruptible power supply  
0D9F:00A2=Imperial Uninterruptible Power Supply (HID PDC)  
0D9F:00A3=Smart King PRO Uninterruptible Power Supply (HID PDC)  
0D9F:00A4=WOW Uninterruptible Power Supply (HID PDC)  
0D9F:00A5=Vanguard Uninterruptible Power Supply (HID PDC)  
0D9F:00A6=Black Knight PRO Uninterruptible Power Supply (HID PDC)  
0DA0=Danger Research  
0DA1=Suzhou Peter's Precise Industrial  
0DA2=Land Instruments International  
0DA3=Nippon Electro-Sensory Devices  
0DA4=Polar Electro OY  
0DA4:0001=Interface  
0DA7=IOGEAR  
0DA8=softDSP  
0DA8:0001=SDS 200A Oscilloscope  
0DAB=Cubig Group

ODAB:0100=DVR/CVR-M140 MP3 Player  
ODAD=Westover Scientific  
ODB0=Micro Star International  
ODB0:1020=MSI PC2PC WLAN Card  
ODB0:1967=MSI USB Bluetooth Device  
ODB0:3801=Motorola Bluetooth 2.1+EDR Device  
ODB0:3820=802.11bgn 1T1R Wireless Adapter  
ODB0:3821=802.11bgn 1T1R Wireless Adapter  
ODB0:3822=802.11bgn 1T1R Wireless Adapter  
ODB0:3870=802.11bgn 1T1R Wireless Adapter  
ODB0:3871=802.11bgn 1T1R Wireless Adapter  
ODB0:4011=Medion Flash XL V2.0 Card Reader  
ODB0:4260=BToes 2.0 Bluetooth Dongle  
ODB0:4270=Starkey 2.0 Bluetooth Dongle  
ODB0:4271=Broadcom Bluetooth 2.1 + EDR USB Device  
ODB0:4600=802.11b/g Turbo Wireless Adapter  
ODB0:5501=Mass Storage Device  
ODB0:5502=Mass Storage Device  
ODB0:5513=MP3 Player  
ODB0:5515=MP3 Player  
ODB0:5516=MP3 Player  
ODB0:5580=Digital TV USB Mini Receiver  
ODB0:5581=PC-DTV Receiver  
ODB0:5581:01=GL USB HID Keyboard Filter  
ODB0:6823=IEEE802.11b Wireless USB Adapter  
ODB0:6826=IEEE 802.11g USB 2.0 Wireless Network Adapter  
ODB0:6855=MSI USB Bluetooth Device  
ODB0:6855:2000=MSI Bluetooth Device  
ODB0:6861=802.11g PenType USB 2.0 Wireless Network Adapter  
ODB0:6865=802.11g Mini-USB 2.0 Wireless Network Adapter  
ODB0:6869=802.11g/Bluetooth Network Adapter  
ODB0:6874=802.11g MiniUSB 2.0 Wireless Bluetooth Combo  
ODB0:6877=802.11g Mini Card Wireless Adapter  
ODB0:6881=MSI Bluetooth Class I EDR Device  
ODB0:688A=USB Bluetooth Class I EDR Device  
ODB0:6895=BCM2046 B1 USB Bluetooth BT2.1 EDR Device  
ODB0:6898=Bluetooth 2.1 + EDR USB Device  
ODB0:6899=802.11bgn 1T1R Mini Card Wireless Adapter  
ODB0:689A=Bluetooth 2.1 + EDR USB Device  
ODB0:6970=MSI USB Bluetooth Device  
ODB0:697A=MSI USB Bluetooth Device  
ODB0:6982=Medion Flash XL V2.7A Card Reader  
ODB0:821A=802.11bg Wireless Adapter  
ODB0:822A=802.11bg Wireless Adapter  
ODB0:822B=Wireless Adapter  
ODB0:822C=Wireless Adapter  
ODB0:870A=802.11bg Wireless Adapter  
ODB0:871A=802.11bg Wireless Adapter  
ODB0:871B=Wireless Adapter  
ODB0:871C=Wireless Adapter  
ODB0:899A=802.11bg Mini Card Wireless Adapter  
ODB0:A861=802.11g USB 2.0 Stick  
ODB0:A870=Bluetooth 2.1+EDR USB Device  
ODB0:A871=Bluetooth 2.1+EDR USB Device  
ODB0:A872=Bluetooth 2.1+EDR USB Device  
ODB0:A874=802.11g MiniUSB 2.0 Wireless Bluetooth Combo  
ODB0:A970=MSI Bluetooth EDR Device  
ODB0:A97A=MSI Bluetooth EDR Device  
ODB0:B872=CSR Bluetooth Device  
ODB0:B970=MSI Bluetooth Device

0DB0:B97A=USB Bluetooth Device  
0DB0:FFFF=MSI USB Bluetooth Device Firmware Upgrade  
0DB1=Wen Te Electronics  
0DB2=Shian Hwi Plug Parts, Plastic Factory  
0DB3=Tekram Technology  
0DB4=Chung Fu Chen Yeh Enterprise  
0DB7=ELCON Systemtechnik  
0DB7:0002=Goldpfeil P-LAN  
0DBC=A&D Medical  
0DBC:0003=AND Serial Cable [AND Smart Cable]  
0DBE=Jiuh Shih Precision Industry  
0DBF=Quik Tech Solutions  
0DBF:0002=SmartDongle Security Key  
0DBF:0200=HDD Storage Solution  
0DBF:021B=USB-2.0 IDE Adapter  
0DBF:0300=USB 2.0 Storage Adapter  
0DBF:0333=Storage Adapter  
0DBF:0707=ZIV Drive  
0DC0=Great Notions  
0DC1=Tamagawa Seiki  
0DC3=Athena Smartcard Solutions  
0DC3:0801=Athena ASEDrive III USB  
0DC3:0802=Athena ASEDrive IIIe USB  
0DC3:1104=ASEDrive IIIe KB  
0DC3:1104:01=Athena ASEDrive IIIe KB  
0DC3:1701=ASEKey  
0DC3:1702=ASEKey  
0DC4=Macpower Peripherals  
0DC4:0040=USB Mass Storage Device  
0DC4:0041=USB Mass Storage Device  
0DC4:0042=USB Mass Storage Device  
0DC4:0101=Hi-Speed Mass Storage Device  
0DC4:020A=Oyen Digital MiniPro 2.5" hard drive enclosure  
0DC5=SDK Co  
0DC6=Precision Squared Technology  
0DC6:2301=Wireless Touchpad Keyboard  
0DC7=First Cable Line  
0DCA:0000=Ultra-Pocket Digital Camera Prototype:00  
0DCA:0000:01=Ultra-Pocket Digital Camera Prototype:00  
0DCA:0003=Logitech Pocket Digital  
0DCA:0003:01=Logitech Pocket Digital  
0DCA:0004=DS6618 Digital Camera  
0DCA:0005=Creative CardCam (BOOTLDR)  
0DCA:0013=Oregon Scientific DS6628 (BTLDR)  
0DCA:0025=Digital Camera  
0DCA:0029=Digital Camera  
0DCA:002A=Digital Camera  
0DCA:002C=Digital Camera  
0DCA:002D=Digital Camera  
0DCA:0040=Digital Camera  
0DCB:0004=DrivePod Mass Storage  
0DCC:0003=Chameleon Mega Video Camera  
0DCC:0003:01=Chameleon Mega Digital Camera  
0DCD=NetworkFab  
0DCD:0001=Remote Interface Adapter  
0DCD:0002=High Bandwidth Codec  
0DD0=Access Solutions  
0DD0:1002=Triple Talk Speech Synthesizer  
0DD1=Contek Electronics  
0DD2=Power Quotient International

ODD2:0003=Mass Storage (P)  
ODD3=MediaQ  
ODD4=Custom Engineering SPA  
ODD4:0183:01=CesiUsb.Sys for KUBE SCANNER Printers  
ODD4:4188=CeScanIO.Sys for SC216-SC216A Scanner  
ODD5=California Micro Devices  
ODD7=KOCOM  
ODD8=Netac Technology  
ODD8:1060=USB-CF-Card  
ODD8:E007=OnlyDisk U222 Pendrive  
ODD8:F607=OnlyDisk U208 1G flash drive [U-SAFE]  
ODD9=HighSpeed Surfing  
ODDA=Integrated Circuit Solution  
ODDA:0001=Multi-Card Reader 6in1  
ODDA:0002=Multi-Card Reader 7in1  
ODDA:0003=Flash Disk  
ODDA:0005=Internal Multi-Card Reader 6in1  
ODDA:0008=SD single card reader  
ODDA:0009=MS single card reader  
ODDA:000A=MS+SD Dual Card Reader  
ODDA:000B=SM single card reader  
ODDA:0101=All-In-One Card Reader  
ODDA:0102=All-In-One Card Reader  
ODDA:0301=MP3 Player  
ODDA:0302=Multi-Card MP3 Player  
ODDA:1001=Multi-Flash Disk  
ODDA:2001=Multi-Card Reader  
ODDA:2002=Q018 default PID  
ODDA:2003=Multi-Card Reader  
ODDA:2005=Datalux DLX-1611 16in1 Card Reader  
ODDA:2006=All-In-One Card Reader  
ODDA:2007=USB to ATAPI bridge  
ODDA:2008=All-In-One Card Reader  
ODDA:2013=SD/MS Combo Card Reader  
ODDA:2014=SD/MS Single Card Reader  
ODDA:2023=card reader SD/MS DEMO board with ICSI brand name (MaskROM version)  
ODDA:2024=card reader SD/MS DEMO board with Generic brand name (MaskROM version)  
ODDA:2026=USB2.0 Card Reader  
ODDA:2027=USB 2.0 Card Reader  
ODDA:2315=UFD MP3 player (model 2)  
ODDA:2318=UFD MP3 player (model 1)  
ODDA:2321=UFD MP3 player  
ODDA:5000:01=USB Audio Device  
ODDB=Tamarack  
ODDD=Datelink Technology  
ODDE=UBICOM  
ODE0=BD Consumer Healthcare  
ODEA=UTECH Electronic (D.G.)  
ODED=Novasonics  
ODEE=Lifetime Memory Products  
ODEE:4010=USB 2.0 Storage Adapter  
ODEF=Full Rise Electronic  
ODF4=NET&SYS  
ODF4:0201=MNG-2005  
ODF6=Sitecom Europe B.V.  
ODF6:0001=C-Media VOIP Device  
ODF6:0004=Bluetooth 2.0 USB Adapter 100m  
ODF6:0007=Bluetooth 2.0 USB Adapter 10m  
ODF6:000B=Bluetooth 2.0 USB adapter 10m  
ODF6:000C=Bluetooth 2.0 USB adapter 100m

ODF6:000D=WL-168 Wireless Network Adapter 54g  
ODF6:000D:0100=SITECOM WL-168 Wireless Network USB Adapter 54g  
ODF6:0017=WL-182  
ODF6:0019=Bluetooth 2.0 adapter 10m CN-512v2 001  
ODF6:001A=Bluetooth 2.0 adapter 100m CN-521v2 001  
ODF6:0024=Sitecom Wireless Network 54G-Turbo WPS USB adapter WL-212  
ODF6:0027=Sitecom Wireless Network USB Adapter 54G Turbo WL-177  
ODF6:002B=Sitecom Wireless Network 300N USB Adapter WL-188  
ODF6:002C=Wireless Network 300N USB adapter WL-301  
ODF6:002D=Wireless Network 300N USB dongle WL-302  
ODF6:002F=Wireless Network USB Adapter 54g-Turbo WL-178  
ODF6:0031=Wireless Network 300N USB dongle WL-314  
ODF6:0036=Wireless Network USB Adapter 54g WL-603  
ODF6:0039=Sitecom Wireless-N USB Adapter WL-315  
ODF6:003B=Sitecom 300N USB Gaming Adapter WL-321  
ODF6:003C=Sitecom Wireless-N USB Adapter WL-323  
ODF6:003D=Sitecom Wireless Network USB Adapter 300N WL-324  
ODF6:003E=Sitecom 150N USB Adapter X1 WL-343  
ODF6:003F=Wireless Network USB Adapter 54g WL-608  
ODF6:0040=Sitecom 300N USB adapter X2 WL-344  
ODF6:0041=Sitecom 300N Wireless Dualband USB adapter WL-329  
ODF6:0042=Sitecom 300N Wireless USB adapter X3 WL-345  
ODF6:0045=Sitecom Wireless Nano USB Adapter 150N WL-353  
ODF6:0047=Sitecom 300N Wireless USB Adapter WL-352v1 002  
ODF6:0048=Sitecom 150N Wireless USB Adapter WL-349v1 002  
ODF6:0049=Sitecom Wireless High-Gain USB Adapter 300N X2 WL-356  
ODF6:004A=Sitecom Wireless Micro USB Adapter 300N X3 WL-358v1 002  
ODF6:004B=Sitecom 150N Wireless USB adapter WL-349v3  
ODF6:004C=Sitecom 300N Wireless USB Adapter WL-352v3  
ODF6:004D=Sitecom Wireless Micro USB Adapter X3 WL-360  
ODF6:0050=WL-349v4 Wireless Micro Adapter 150N X1 [Ralink RT3370]  
ODF6:0051=Sitecom Wireless Micro USB Adapter 300N X3 WL-364  
ODF6:0052=Sitecom Wireless Ultra Nano USB Adapter 150N X1 WL-365  
ODF6:0053=Sitecom Wireless Network USB Adapter 54g WL-608v2 001  
ODF6:0057=Sitecom 150N Wireless USB Adapter WL-349v2 001  
ODF6:0058=Sitecom 300N Wireless USB Adapter WL-352v2 001  
ODF6:0059=Sitecom Wireless Network Micro USB Adapter 54g WL-608v3\_001  
ODF6:005C=Wireless Ultra Nano Network Adapter 150N  
ODF6:005F=Wireless Network USB Adapter 300N X3  
ODF6:0060=Wireless Network USB Adapter 300N X4  
ODF6:0062=Wireless Dualband Network Adapter 300N X5  
ODF6:0063=Wireless Network USB Adapter 150N X1  
ODF6:0064=Wireless Network USB Adapter 300N X2  
ODF6:061C=LN-028  
ODF6:21F4=44 St Bluetooth Device  
ODF6:2200=Sitecom USB Bluetooth 2.0 class 2 dongle CN-512  
ODF6:2208=Sitecom USB Bluetooth 2.0 class 2 dongle CN-520  
ODF6:2209=Sitecom USB Bluetooth 2.0 class 1 dongle CN-521  
ODF6:9071=zd1211 802.11g Adapter  
ODF6:9075=ZD1211B  
ODF6:90AC=Sitecom Wireless Network USB adapter Turbo g WL-172  
ODF6:9712=Sitecom Wireless Network USB adapter 54g WL-113v1.002  
ODF7=Mobile Action  
ODF7:0620=Mobile Action MA-620 USB Infrared Adapter  
ODF7:0620:01=Mobile Action MA-620 USB Infrared Adapter  
ODF7:0700=MA-700 Bluetooth Adapter  
ODF7:0720=MA-720 Bluetooth Adapter  
ODF7:0722=Bluetooth Dongle  
ODF7:0730=MA-730/MA-730G Bluetooth Adapter  
ODF7:0800=Data Cable

0DF7:0820=Data Cable  
0DF7:0900=MA i-gotU Travel Logger GPS  
0DF7:1800=Generic Card Reader  
0DF7:1802=Card Reader  
0DF8=Hoya Computer  
0DFA=Toyo Communication Equipment  
0DFC=GeneralTouch Technology  
0DFC:0001=Touchscreen  
0E02=Doowon  
0E03=Nippon Systemware  
0E07:0020=ViewTek CO.,Ltd USB Smart Card Reader  
0E07:0030=Viewtek Co.,Ltd USB 2K Smart Card Reader  
0E07:0314=Viewtek USB Smart Card Reader  
0E08=Winbest Technology  
0E0B=Amigo Technology  
0E0B:9031=802.11n Wireless USB Card  
0E0B:9041=802.11n Wireless USB Card  
0E0B:9051=802.11n wireless USB card  
0E0C=Gesytec  
0E0C:0101=LonUSB LonTalk Network Adapter  
0E0F=VMWare  
0E0F:0001=VMware USB Device  
0E0F:0002=Virtual USB Hub  
0E0F:0003=Virtual Mouse  
0E0F:0004=Virtual CCID  
0E0F:0005=Virtual Mass Storage  
0E0F:0006=Virtual Keyboard  
0E0F:F80A=Smoker FX2  
0E14=Hunter Engineering  
0E16=JMTEK, LLC  
0E17=Walex Electronic  
0E1B=Crewave  
0E20=Pegasus Technologies  
0E20:0101=NoteTaker  
0E21=Cowon Systems  
0E21:0300=iAudio CW200  
0E21:0400=MP3 Player  
0E21:0500=iAudio M3  
0E21:0510=iAudio X5  
0E21:0513=iAudio X5, side USB port  
0E21:0520=iAudio M5  
0E21:0601=iAudio G3  
0E21:0681=iAUDIO E2  
0E21:0700=iAudio U3  
0E21:0751=iAudio 7  
0E21:0760=iAUDIO U5 / iAUDIO G2  
0E21:0800=Cowon D2 (UMS mode)  
0E21:0801=Cowon D2 (MTP mode)  
0E21:0910=iAUDIO 9  
0E21:0920=J3  
0E22=Symbian  
0E23=Liou Yuane Enterprise  
0E25=VinChip Systems  
0E26=J-Phone East  
0E2E=Brady  
0E30=HeartMath LLC  
0E34=Micro Computer Control  
0E35=3Pea Technologies  
0E36=TiePie engineering  
0E36:0008=Handyscope HS3

0E36:0009=Handyscope HS3 (br)  
0E36:000A=Handyscope HS4  
0E36:000B=Handyscope HS4 (br)  
0E36:000E=Handyscope HS4 Diff  
0E36:000F=Handyscope HS4 Diff (br)  
0E36:0010=Handyscope HS2  
0E36:0011=TiePieSCOPE HS805 (br)  
0E36:0012=TiePieSCOPE HS805  
0E36:0018=Handyprobe HP2  
0E36:0042=TiePieSCOPE HS801  
0E36:00FD=USB To Parallel adapter  
0E36:00FE=USB To Parallel adapter  
0E38=Stratitec  
0E39=Smart Modular Technologies  
0E39:0137=SmartModular Bluetooth Device  
0E3A=Neostar Technology  
0E3A:1100=CW-1100 Wireless Network Adapter  
0E3B=Mansella  
0E41=Line6  
0E41:4147=TonePort GX  
0E41:4250=BassPODxt  
0E41:4252=BassPODxt Pro  
0E41:4642=BassPODxt Live  
0E41:4650=PODxt Live  
0E41:4750=GuitarPort  
0E41:5044=PODxt  
0E41:5050=PODxt Pro  
0E41:534D=SeaMonkey  
0E42=Puretek Industrial  
0E44=Sun-Riseful Technology  
0E46=Delphi  
0E48=Julia  
0E48:0100=CardPro SmartCard Reader  
0E4A=Shenzhen Bao Hing Electric Wire & Cable Mfr.  
0E4C=Radica Games  
0E4C:1097=Gamester Controller  
0E4C:2390=Games Jtech Controller  
0E4C:7288=funkey reader  
0E55=Speed Dragon Multimedia  
0E55:110A=Tanic S110-SG1 + ISSC IS1002N [Slow Infra-Red (SIR) & Bluetooth 1.2 (Class 2) Adapter]  
0E55:110B=MS3303H USB-to-Serial Bridge  
0E56=Cenix Digicom  
0E56:6012=MP3 Player  
0E56:6013=MP3 Player  
0E56:6014=MP3 Player  
0E56:6021=K-PEX 100  
0E5A=ACTIVE  
0E5B=Union Power Information Industrial  
0E5C=Bitland Information Technology  
0E5C:6118=LCD Device  
0E5C:6119=remote receive and control device  
0E5C:6441=C-Media Sound Device  
0E5C:6441:03=USB Human Interface Device  
0E5D=Neltron Industrial  
0E5E=Conwise Technology  
0E5E:6622=Conwise Bluetooth Device  
0E5E:6623=Conwise Bluetooth Device  
0E60:0102=Fujitsu USB ADSL WAN Modem  
0E66=Hawking



0E66:0001=HWUN1 Hawking Technologies Hi-Gain Wireless-300N USB Adapter w/ Upgradeable Antenna  
0E66:0003=HWDN1 Hawking Technologies Hi-Gain USB Wireless-300N Dish Adapter  
0E66:0009=HWUN2 Hawking Technologies Hi-Gain Wireless-150N USB Adapter w/ Upgradeable Antenna  
0E66:000B=HWDN2 Hawking Technologies Hi-Gain USB Wireless-150N Dish Adapter  
0E66:0013=Hi-Gain Wireless-N USB [rt2870]  
0E66:0015=Hawking Hi-Gain USB Wireless-N Dish Adapter  
0E66:0016=Hawking Hi-Gain USB Wireless-G Dish Adapter  
0E66:0017=Wireless-N Network Adapter [Ralink RT2870]  
0E66:0018=Wireless-N Network Adapter [Ralink RT2870]  
0E66:400B=UF100 10/100 Network Adapter  
0E66:400C=UF100 Ethernet [pegasus2]  
0E67=Fossil  
0E67:0002=Fossil Wrist PDA  
0E6A=Megawin Technology  
0E6A:0101=MA100 [USB-UART Bridge IC]  
0E6A:0310:0111:01=b-flex Audio Device  
0E6A:6001=GEMBIRD Flexible keyboard KB-109F-B-DE  
0E6F=Logic3  
0E6F:0003=Freebird wireless Controller  
0E6F:0005=Eclipse wireless Controller  
0E6F:0006=Edge wireless Controller  
0E70=Tokyo Electronic Industry Co,  
0E72=Hsi-Chin Electronics  
0E75=TVS Electronics  
0E79=ARCHOS  
0E79:1106=Pocket Medai Assistant - PMA400  
0E79:1202=Gmini200 Series  
0E79:1202:0104=Gmini220  
0E79:1204=Gmini XS 200  
0E79:1306=504 Portable Multimedia Player  
0E79:1330=5 Tablet  
0E79:1332=5 IMT  
0E79:1416=32 IT  
0E79:1417=A43 IT  
0E7B=On-Tech Industry  
0E7C:0300=Joynet WLAN USB Card  
0E7C:0309=Lenovo M8000 series  
0E7C:1205=MP3 Player  
0E7C:1209=MP3 Player  
0E7C:120A=MP3 Player  
0E7C:120D=MP3 Player  
0E7C:1220=MP3 Player  
0E7C:1225=MP3 Player  
0E7C:1227=MP3 Player  
0E7C:14F6=Lenovo M600 Series  
0E7C:2801=Legend Handheld  
0E7E=Gmate  
0E7E:0001=Yopy 3000 PDA  
0E7E:1001=YP3X00 PDA  
0E82=Ching Tai Electric Wire & Cable  
0E83=Shin An Wire & Cable  
0E87:0001=Internet Security Co., Ltd. SecureKey  
0E8A:0100=FinePoint USB Digitizer  
0E8B=KAO SHIN PRECISION INDUSTRY  
0E8C=Well Force Electronic  
0E8D=MediaTek  
0E8D:0003=MT6227 phone  
0E8D:0004=MT6227 phone

0E8D:1836=Samsung SE-S084 Super WriteMaster Slim External DVD writer  
0E8D:2225=MP3 Player  
0E8D:2277=MP3 Player  
0E8D:2325=MP3 Player  
0E8D:2424=MP3 Player  
0E8D:2626=MP3 Player  
0E8D:5025=MP3 Player  
0E8F=GreenAsia  
0E8F:0003=MaxFire Blaze2  
0E8F:0012=Joystick  
0E8F:0016=USB 4-Port Hub  
0E8F:0020=USB to PS/2 Adapter  
0E8F:0021=Multimedia Keyboard Controller  
0E8F:0201=SmartJoy Frag Xpad/PS2 adaptor  
0E8F:100C=Nostromo n52 HID SpeedPad 2.0 (Proto)  
0E8F:100C:01=Nostromo n52 HID SpeedPad 2.0 Mouse Wheel (proto)  
0E90=WiebeTech, LLC  
0E90:0100=USB2 Storage Adapter V1  
0E91=VTech Engineering Canada  
0E92=C'S GLORY ENTERPRISE  
0E93=eM Technics  
0E95=Future Technology  
0E96=APLUX Communications  
0E96:C001=TRUST 380 USB2 SPACECOM  
0E97=Fingerworks  
0E97:0908=Composite HID (Keyboard and Mouse)  
0E98=Advanced Analogic Technologies  
0E99=Parallel Dice  
0E9A=TA HSING Industries  
0E9B=ADTEC  
0E9C=Streamzap  
0E9C:0000=Streamzap Remote Control  
0E9D:3520=DCM-201 DOCSIS Cable Modem (WDM)  
0E9F=Tamura  
0EA0=Ours Technology  
0EA0:2126=7-in-1 Card Reader  
0EA0:2153=SD Card Reader Key  
0EA0:2168=U-Storage Controller  
0EA0:6803=Mobile USB Flash Disk (64/128MB)  
0EA0:6808=OTI-6808 Flash Disk  
0EA0:6828=U-Storage Controller  
0EA0:6858=Nokia CA-42 Comm Port  
0EA6=Nihon Computer  
0EA7=MSL Enterprises  
0EA8=CenDyne  
0EAB:4032=SENS CDMA 1x Modem  
0EAD=HUMAX  
0EB0=NovaTech  
0EB0:3464=Acer Modem 56 Surf USB  
0EB0:9020=IEEE 802.11g Wireless Pocket USB  
0EB0:9021=802.11G Wireless USB Card  
0EB0:9061=802.11n Wireless USB Card  
0EB0:9071=Wireless USB Card  
0EB1=WIS Technologies  
0EB1:6666=Lifeview TV Tuner EZ-LOADER  
0EB1:6668=WinFast WalkieTV TV Loader  
0EB1:7007=WIS GO7007 Camera  
0EB2=Y-S ELECTRONIC  
0EB3=Saint Technology  
0EB6:3232=GamePark GP32 USB

0EB7=Endor AG  
0EBE=VWeb  
0EBF=Omega Technology of Taiwan  
0EC0=LHI Technology (China)  
0EC1=Abit Computer  
0EC2=Sweetray Industrial  
0EC3=AXELL  
0EC4=Ballracing Developments  
0EC5=GT Information System  
0EC6=InnoVISION Multimedia  
0EC7=Theta Link  
0EC7:1008=So., Show 301 Digital Camera  
0ECA:0250=USB 2.0 Mass Storage  
0ECC:6011=SIR-601R PC/SC USB smart card reader  
0ECD=Lite-On IT  
0ECD:1400=LiteOn CD\RW 40X  
0ECD:A100=LDW-411SX DVD/CD Rewritable Drive  
0ECE=TaiSol Electronics  
0ECF=Phogenix Imaging, LLC  
0ED1=WinMaxGroup  
0ED1:6660=USB Flash Disk 64M-C  
0ED1:6680=USB Flash Disk 64M-B  
0ED1:7634=MP3 Player  
0ED2=Kyoto Micro Computer  
0ED3=Wing-Tech Enterprise  
0ED5=Fiberbyte  
0ED5:E000=USB-inSync Device  
0ED5:F000=Fiberbyte USB-inSync Device  
0ED5:F201=Fiberbyte USB-inSync DAQ-2500X  
0EDA=NORITAKE ITRON  
0EDF=e-MDT  
0EDF:2060=FID irock! 100 Series  
0EE0=SHIMA SEIKI MFG.,  
0EE1=Sarotech  
0EE2=AMI Semiconductor  
0EE3=ComTrue Technology  
0EE3:1000=Image Tank 1.5  
0EE4=Sunrich Technology  
0EEE=Digital Stream Technology  
0EEE:8810=USB Mass Storage Drive  
0EEF=D-WAV Scientific  
0EEF:0001=eGalax TouchScreen  
0EEF:0002=Touchkit USB Controller for TouchScreen  
0EF0=Hitachi Cable  
0EF1=Aichi Micro Intelligent  
0EF2=I/OMAGIC  
0EF3=Lynn Products  
0EF4=DSI Datotech  
0EF5=PointChips  
0EF5:2202=USB Mass Storage Device  
0EF5:2366=Flash Disk  
0EF6=Yield Microelectronics  
0EF7=Tulip Computers International  
0EFD=Oasis Semiconductor  
0EFE=WEM TECHNOLOGY INC.  
0F06=Visual Frontier Precision  
0F08=CSL Wire & Plug (Shen Zhen) Company  
0F0B:0001=GCC USB Serial On USB Port  
0F0C=CAS  
0F0D=Hori

0F0D:0011=Real Arcade Pro 3  
0F0E=Energy Full  
0F11=LD Didactic GmbH  
0F11:1000=CASSY-S  
0F11:1010=Pocket-CASSY  
0F11:1020=Mobile-CASSY  
0F11:1080=Joule and Wattmeter  
0F11:1081=Digital Multimeter P  
0F11:1090=UMI P  
0F11:1100=X-Ray Apparatus  
0F11:1101=X-Ray Apparatus  
0F11:1200=VideoCom  
0F11:2000=COM3LAB  
0F11:2010=Terminal Adapter  
0F11:2020=Network Analyser  
0F11:2030=Converter Control Unit  
0F11:2040=Machine Test System  
0F12=Mars Engineering  
0F13=Acetek Technology  
0F18=Finger Lakes Instrumentation  
0F18:0002=CCD  
0F18:0006=Focuser  
0F18:0007=Filter Wheel  
0F18:000A=ProLine CCD  
0F18:000B=Color Filter Wheel 4  
0F18:000C=PDF2  
0F18:000D=Guider  
0F19=Oracom  
0F1B=Onset Computer  
0F1C=Funai Electric  
0F1D=Iwill  
0F20=GENNUM  
0F21=IOI Technology  
0F22=SENIOR INDUSTRIES  
0F23=Leader Tech Manufacturer  
0F24=FLEX-P INDUSTRIES SDN.BHD.  
0F2D=ViPower  
0F2E=Geniality Maple Technology  
0F2F=Priva Design Services  
0F30=Jess Technology  
0F30:001C=PS3 Guitar Controller Dongle  
0F30:0110=10-Button Joypad  
0F30:0111=Colour Rumble Pad  
0F30:0208=Xbox & PC Gamepad  
0F31=Chrysalis Development  
0F32=YFC-BonEagle Electric  
0F37=Kokuyo  
0F38=Nien-Yi Industrial  
0F3D=Airprime  
0F3D:0112=CDMA 1xEVDO PC Card, PC 5220  
0F41=RDC Semiconductor  
0F42=Nital Consulting Services  
0F44=Polhemus  
0F44:EF11=Patriot (firmware not loaded)  
0F44:EF12=Patriot  
0F44:FF11=Liberty (firmware not loaded)  
0F44:FF12=Liberty  
0F4B=St. John Technology  
0F4C=WORLDWIDE CABLE OPTO  
0F4D=Microtune

0F4D:1000=Microtune Bluetooth Device  
0F4E=Freedom Scientific  
0F4E:0200=Freedom Scientific USB Sync  
0F4F:0050=Inventel Gateway  
0F52=WING KEI ELECTRICAL  
0F53=Taiyo Cable (Dongguan)  
0F54=Kawai Musical Instruments  
0F55=AmbiCom  
0F57:1002=WavePlus Bluetooth Device  
0F5C=Prairiecomm  
0F5D=NewAge International, LLC  
0F5D:9455=Compact Drive  
0F5F=Key Technology  
0F60=NTK (HK)  
0F61=Varian  
0F62=Acrox Technologies  
0F62:1001=Targus Mini Trackball Optical Mouse  
0F63=LeapFrog Enterprises  
0F63:0010=Leapster Explorer  
0F63:0500=Fly Fusion  
0F63:0600=Leap Port Turbo  
0F63:0700=POGO  
0F63:0800=Didj  
0F63:0900=TAGSchool  
0F63:0A00=Leapster 2  
0F63:0B00=Crammer  
0F63:0C00=Tag Jr  
0F63:0D00=My Pal Scout  
0F63:0E00=Tag32  
0F63:0F00=Tag64  
0F63:1000=Kiwi16  
0F63:1100=Leapster L2x  
0F63:1111=Fly Fusion  
0F63:1300=Didj UK/France (Leapster Advance)  
0F68=Kobe Steel  
0F69=DIONEX  
0F6A=Vibren Technologies  
0F6E=INTELLIGENT SYSTEMS  
0F6E:0100=GameBoy Color Emulator  
0F6E:0201=GameBoy Advance Flash Gang Writer  
0F6E:0202=GameBoy Advance Capture  
0F6E:0300=Gamecube DOL Viewer  
0F6E:0400=NDS Emulator  
0F6E:0401=NDS UIC  
0F6E:0402=NDS Writer  
0F6E:0403=NDS Capture  
0F6E:0404=NDS Emulator (Lite)  
0F73=DFI  
0F7C=DQ Technology  
0F7D=NetBotz  
0F7E=Fluke  
0F88=VTech Holdings  
0F88:02CF=Vtech 719 Control  
0F88:02CF:01=Vtech 719 Mouse  
0F88:3012=VTech Wireless 802.11g USB 2.0 Adapter  
0F88:3014=ZD1211B  
0F8B=Yazaki  
0F8C=Young Generation International  
0F8D=Uniwill Computer  
0F8E=Kingnet Technology

0F8F=SOMA NETWORKS  
0F97=CviLux  
0F98=CYBERBANK  
0F98:0201=Cyberbank USB Sync  
0F9C=Hyun Won  
0F9C:0301=M-Any Premium DAH-610 MP3/WMA Player  
0F9C:0332=mobiBLU DAH-1200 MP3/Ogg Player  
0F9C:0412=MP3 Player  
0F9C:0416=MP3 Player  
0F9C:0418=MP3 Player  
0F9C:0422=MP3 Player  
0F9C:0426=MP3 Player  
0F9E=Lucent Technologies  
0FA3=Starconn Electronic  
0FA4=ATL Technology  
0FA5=SOTEC  
0FA7=EpoX Computer  
0FA8=Logic Controls  
0FAF=Winpoint Electronic  
0FB0=Haurtian Wire & Cable  
0FB1=Inclose Design  
0FB2=Juan-Chern Industrial  
0FB6=Heber  
0FB6:3FC3=Firefly X10i I/O Board (with firmware)  
0FB6:3FC4=Firefly X10i USB I/O Board  
0FB8=Wistron  
0FB8:0002=eHome Infrared Receiver (USBCIR)  
0FB8:3001=Wistron USB Sync  
0FB8:3002=Wistron USB Sync  
0FB8:3003=Wistron USB Sync  
0FB8:4001=Wistron USB Sync  
0FB9=AACom  
0FBA=SAN SHING ELECTRONICS  
0FBB=Bitwise Systems  
0FC1=Mitac Internatinal  
0FC2=Plug and Jack Industrial  
0FC5=Delcom Engineering  
0FC5:1222=I/O Development Board  
0FC6=Dataplus Supplies  
0FCA=Research In Motion  
0FCA:0001=Blackberry Handheld  
0FCA:0004=Blackberry Handheld  
0FCA:0006=Blackberry Pearl  
0FCA:0008=Blackberry Pearl  
0FCA:8001=Blackberry Handheld  
0FCA:8004=Blackberry Bold  
0FCA:8007=Blackberry Handheld  
0FCA:8010=Research In Motion Network Device  
0FCE=Sony Ericsson Mobile Communications AB  
0FCE:0076=W910i (Multimedia mode)  
0FCE:00AF=V640i Phone [PTP Camera]  
0FCE:00D4=C902 [MTP]  
0FCE:00D9=C702 Phone  
0FCE:0107=Sony Ericsson USB Mobile Pseudo CDC Modem  
0FCE:0107:01=Sony Ericsson USB Mobile Pseudo CDC Trace  
0FCE:0107:02=Sony Ericsson USB Mobile Pseudo CDC Console  
0FCE:0112=W995 Walkman Phone  
0FCE:011C=Sony Ericsson USB Mobile Pseudo CDC Modem  
0FCE:011C:01=Sony Ericsson USB Mobile Pseudo CDC Trace  
0FCE:011C:02=Sony Ericsson USB Mobile Pseudo CDC Console

0FCE:0127=Sony Ericsson USB Mobile Pseudo CDC Modem  
0FCE:0127:01=Sony Ericsson USB Mobile Pseudo CDC Trace  
0FCE:0127:02=Sony Ericsson USB Mobile Pseudo CDC Console  
0FCE:1010=Sony Ericsson  
0FCE:1010:01=Sony Ericsson USB WMC Data Modem  
0FCE:1010:03=Sony Ericsson USB WMC Modem  
0FCE:10AF=V640i Phone [PictBridge]  
0FCE:10D4=C902 [PictBridge]  
0FCE:1107:02=Sony Ericsson USB Mobile Video Pseudo CDC Trace  
0FCE:111C:02=Sony Ericsson USB Mobile Video Pseudo CDC Trace  
0FCE:1127:02=Sony Ericsson USB Mobile Video Pseudo CDC Trace  
0FCE:20EF=Sony Ericsson Device 1018  
0FCE:20EF:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:20EF:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:20F1=Sony Ericsson Device 1018  
0FCE:20F1:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:20F1:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:2105=Sony Ericsson Device 1018  
0FCE:2105:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:2105:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:2108=Sony Ericsson Device 1018  
0FCE:2108:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:2108:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:2109=Sony Ericsson Device 1018  
0FCE:2109:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:2109:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:210B=Sony Ericsson Device 1018  
0FCE:210B:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:210B:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:210C=Sony Ericsson Device 1018  
0FCE:210C:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:210C:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:2112=Sony Ericsson Device 1018  
0FCE:2112:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:2112:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:2113=Sony Ericsson Device 1018  
0FCE:2113:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:2113:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:211A=Sony Ericsson Device 1018  
0FCE:211A:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:211A:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:211D=Sony Ericsson Device 1018  
0FCE:211D:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:211D:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:211E=Sony Ericsson Device 1018  
0FCE:211E:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:211E:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:2120=Sony Ericsson Device 1018  
0FCE:2120:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:2120:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:2121=Sony Ericsson Device 1018  
0FCE:2121:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:2121:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:2123=Sony Ericsson Device 1018  
0FCE:2123:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:2123:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:2126=Sony Ericsson Device 1018  
0FCE:2126:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:2126:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:2129=Sony Ericsson Device 1029

0FCE:2129:01=Sony Ericsson Device 1029 USB WMC Data Modem  
0FCE:2129:03=Sony Ericsson Device 1029 USB WMC Modem  
0FCE:212A=Sony Ericsson Device 1029  
0FCE:212A:01=Sony Ericsson Device 1029 USB WMC Data Modem  
0FCE:212A:03=Sony Ericsson Device 1029 USB WMC Modem  
0FCE:212C=Sony Ericsson Device 1029  
0FCE:212C:01=Sony Ericsson Device 1029 USB WMC Data Modem  
0FCE:212C:03=Sony Ericsson Device 1029 USB WMC Modem  
0FCE:212D=Sony Ericsson Device 1018  
0FCE:212D:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:212D:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:2137=Xperia X10 mini (USB debug)  
0FCE:2138=Xperia X10 mini pro (Debug)  
0FCE:2149=Xperia X8 (debug)  
0FCE:3137=Xperia X10 mini  
0FCE:3138=Xperia X10 mini pro  
0FCE:3149=Xperia X8  
0FCE:614F=Xperia X12 (debug mode)  
0FCE:8004=9000 Phone [Mass Storage]  
0FCE:ADDE=SEMC Flash Device  
0FCE:D008=Sony Ericsson V800-Vodafone 802SE  
0FCE:D008:01=Sony Ericsson V800-Vodafone 802SE USB WMC Data Modem  
0FCE:D008:03=Sony Ericsson V800-Vodafone 802SE USB WMC Modem  
0FCE:D013=au W31S  
0FCE:D013:01=au W31S Serial Port  
0FCE:D014=au W31S Memory Stick tool  
0FCE:D016=Sony Ericsson 750 USB WMC OBEX Interface  
0FCE:D016:01=Sony Ericsson 750 USB WMC Data Modem  
0FCE:D016:03=Sony Ericsson 750 USB WMC Modem  
0FCE:D017=Sony Ericsson 600i  
0FCE:D017:01=Sony Ericsson 600i USB WMC Data Modem  
0FCE:D017:03=Sony Ericsson 600i USB WMC Modem  
0FCE:D018=Sony Ericsson Z800  
0FCE:D018:01=Sony Ericsson Z800 USB WMC Data Modem  
0FCE:D018:03=Sony Ericsson Z800 USB WMC Modem  
0FCE:D019=Sony Ericsson VDC EGPRS Modem  
0FCE:D020=au W32S  
0FCE:D020:01=au W32S Serial Port  
0FCE:D021=au W32S Memory Stick tool  
0FCE:D022=Sony Ericsson Device 115  
0FCE:D022:01=Sony Ericsson Device 115 USB WMC Data Modem  
0FCE:D022:03=Sony Ericsson Device 115 USB WMC Modem  
0FCE:D024=Sony Ericsson Device 115  
0FCE:D024:01=Sony Ericsson Device 115 USB WMC Data Modem  
0FCE:D024:03=Sony Ericsson Device 115 USB WMC Modem  
0FCE:D025=Sony Ericsson 520  
0FCE:D025:01=Sony Ericsson 520 USB WMC Data Modem  
0FCE:D025:03=Sony Ericsson 520 USB WMC Modem  
0FCE:D026=Sony Ericsson W550  
0FCE:D026:01=Sony Ericsson W550 USB WMC Data Modem  
0FCE:D026:03=Sony Ericsson W550 USB WMC Modem  
0FCE:D028=Sony Ericsson W800  
0FCE:D028:01=Sony Ericsson W800 USB WMC Data Modem  
0FCE:D028:03=Sony Ericsson W800 USB WMC Modem  
0FCE:D029=Sony Ericsson 900i  
0FCE:D029:01=Sony Ericsson 900i USB WMC Data Modem  
0FCE:D029:03=Sony Ericsson 900i USB WMC Modem  
0FCE:D030=Sony Ericsson P990 Composite Device  
0FCE:D030:01=Sony Ericsson P990 PC-Connect Controller  
0FCE:D030:03=Sony Ericsson P990 USB Modem



0FCE:D030:05=Sony Ericsson P990 Application Port  
0FCE:D030:07=Sony Ericsson P990 Debug Port  
0FCE:D031=Sony Ericsson M600 Composite Device  
0FCE:D031:01=Sony Ericsson M600 PC-Connect Controller  
0FCE:D031:03=Sony Ericsson M600 USB Modem  
0FCE:D031:05=Sony Ericsson M600 Application Port  
0FCE:D031:07=Sony Ericsson M600 Debug Port  
0FCE:D032=Sony Ericsson W600  
0FCE:D032:01=Sony Ericsson W600 USB WMC Data Modem  
0FCE:D032:03=Sony Ericsson W600 USB WMC Modem  
0FCE:D035=au W41S Serial Port  
0FCE:D036=au W41S Memory Stick tool  
0FCE:D037=Sony Ericsson W950 Composite Device  
0FCE:D038=W850i Phone  
0FCE:D038:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D038:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D039=Sony Ericsson Device 116  
0FCE:D039:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D039:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D040=Sony Ericsson Z530 Driver  
0FCE:D040:01=Sony Ericsson Z530 USB WMC Data Modem  
0FCE:D040:03=Sony Ericsson Z530 USB WMC Modem  
0FCE:D041=K510i Phone  
0FCE:D041:01=Sony Ericsson K510 USB WMC Data Modem  
0FCE:D041:03=Sony Ericsson K510 USB WMC Modem  
0FCE:D042=W810i Phone  
0FCE:D042:01=Sony Ericsson W810 USB WMC Data Modem  
0FCE:D042:03=Sony Ericsson W810 USB WMC Modem  
0FCE:D043=Sony Ericsson Device 116  
0FCE:D043:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D043:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D044=Sony Ericsson Device 116  
0FCE:D044:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D044:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D045=Sony Ericsson Device 116  
0FCE:D045:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D045:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D046=K610i Phone  
0FCE:D046:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D046:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D047=Sony Ericsson Device 116  
0FCE:D047:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D047:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D048=Sony Ericsson Device 116  
0FCE:D048:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D048:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D049=Sony Ericsson Device 116  
0FCE:D049:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D049:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D050=Sony Ericsson Z525 Driver  
0FCE:D050:01=Sony Ericsson Z525 USB WMC Data Modem  
0FCE:D050:03=Sony Ericsson Z525 USB WMC Modem  
0FCE:D053=Sony Ericsson W300 Driver  
0FCE:D053:01=Sony Ericsson W300 USB WMC Data Modem  
0FCE:D053:03=Sony Ericsson W300 USB WMC Modem  
0FCE:D056=Sony Ericsson W700 Driver  
0FCE:D056:01=Sony Ericsson W700 USB WMC Data Modem  
0FCE:D056:03=Sony Ericsson W700 USB WMC Modem  
0FCE:D057=Sony Ericsson K310 Driver  
0FCE:D057:01=Sony Ericsson K310 USB WMC Data Modem

0FCE:D057:03=Sony Ericsson K310 USB WMC Modem  
0FCE:D058=Sony Ericsson W950 Composite Device  
0FCE:D058:01=Sony Ericsson W950 PC-Connect Controller  
0FCE:D058:03=Sony Ericsson W950 USB Modem  
0FCE:D058:05=Sony Ericsson W950 Application Port  
0FCE:D058:07=Sony Ericsson W950 Debug Port  
0FCE:D059=Sony Ericsson Z550  
0FCE:D059:01=Sony Ericsson Z550 USB WMC Data Modem  
0FCE:D059:03=Sony Ericsson Z550 USB WMC Modem  
0FCE:D062=Sony Ericsson Device 062  
0FCE:D062:01=Sony Ericsson Device 062 USB WMC Modem  
0FCE:D064=SEMC HCB-100 Device  
0FCE:D065=Sony Ericsson W960 Composite Device  
0FCE:D065:01=Sony Ericsson W960 PC-Connect Controller  
0FCE:D065:03=Sony Ericsson W960 USB Modem  
0FCE:D065:05=Sony Ericsson W960 Application Port  
0FCE:D065:07=Sony Ericsson W960 Debug Port  
0FCE:D067=Sony Ericsson Device 116  
0FCE:D067:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D067:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D068=Sony Ericsson Device 116  
0FCE:D068:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D068:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D069=Sony Ericsson Device 116  
0FCE:D069:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D069:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D070=Sony Ericsson Device 116  
0FCE:D070:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D070:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D071=Sony Ericsson Z558  
0FCE:D071:01=Sony Ericsson Z558 USB WMC Data Modem  
0FCE:D071:03=Sony Ericsson Z558 USB WMC Modem  
0FCE:D072=Sony Ericsson K320  
0FCE:D072:01=Sony Ericsson K320 USB WMC Data Modem  
0FCE:D072:03=Sony Ericsson K320 USB WMC Modem  
0FCE:D073=Sony Ericsson Device 716  
0FCE:D073:01=Sony Ericsson Device 716 USB WMC Data Modem  
0FCE:D073:03=Sony Ericsson Device 716 USB WMC Modem  
0FCE:D075=Sony Ericsson Device 117  
0FCE:D075:01=Sony Ericsson Device 117 USB WMC Data Modem  
0FCE:D075:03=Sony Ericsson Device 117 USB WMC Modem  
0FCE:D076=Sony Ericsson Device 117  
0FCE:D076:01=Sony Ericsson Device 117 USB WMC Data Modem  
0FCE:D076:03=Sony Ericsson Device 117 USB WMC Modem  
0FCE:D079=Sony Ericsson Device 716  
0FCE:D079:01=Sony Ericsson Device 716 USB WMC Data Modem  
0FCE:D079:03=Sony Ericsson Device 716 USB WMC Modem  
0FCE:D083=SEMC HCB-120 Device  
0FCE:D086=Sony Ericsson Device 116  
0FCE:D086:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D086:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D087=Sony Ericsson Device 116  
0FCE:D087:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D087:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D088=Sony Ericsson Device 616  
0FCE:D088:01=Sony Ericsson Device 616 USB WMC Data Modem  
0FCE:D088:03=Sony Ericsson Device 616 USB WMC Modem  
0FCE:D089=Sony Ericsson Device 616  
0FCE:D089:01=Sony Ericsson Device 616 USB WMC Data Modem  
0FCE:D089:03=Sony Ericsson Device 616 USB WMC Modem

0FCE:D090=Sony Ericsson W200  
0FCE:D090:01=Sony Ericsson W200 USB WMC Data Modem  
0FCE:D090:03=Sony Ericsson W200 USB WMC Modem  
0FCE:D091=Sony Ericsson Device 125  
0FCE:D091:01=Sony Ericsson Device 125 USB WMC Data Modem  
0FCE:D091:03=Sony Ericsson Device 125 USB WMC Modem  
0FCE:D092=Sony Ericsson P1 Composite Device  
0FCE:D092:01=Sony Ericsson P1 PC-Connect Controller  
0FCE:D092:03=Sony Ericsson P1 USB Modem  
0FCE:D092:05=Sony Ericsson P1 Application Port  
0FCE:D092:07=Sony Ericsson P1 Debug Port  
0FCE:D094=Sony Ericsson Device 716  
0FCE:D094:01=Sony Ericsson Device 716 USB WMC Data Modem  
0FCE:D094:03=Sony Ericsson Device 716 USB WMC Modem  
0FCE:D0A1=Sony Ericsson Device 116  
0FCE:D0A1:01=Sony Ericsson Device 116 USB WMC Data Modem  
0FCE:D0A1:03=Sony Ericsson Device 116 USB WMC Modem  
0FCE:D0A2=Sony Ericsson Z535  
0FCE:D0A2:01=Sony Ericsson Z535 USB WMC Data Modem  
0FCE:D0A2:03=Sony Ericsson Z535 USB WMC Modem  
0FCE:D0A3=Sony Ericsson Device 616  
0FCE:D0A3:01=Sony Ericsson Device 616 USB WMC Data Modem  
0FCE:D0A3:03=Sony Ericsson Device 616 USB WMC Modem  
0FCE:D0A5=Sony Ericsson Device 117  
0FCE:D0A5:01=Sony Ericsson Device 117 USB WMC Data Modem  
0FCE:D0A5:03=Sony Ericsson Device 117 USB WMC Modem  
0FCE:D0A7=Sony Ericsson Device 616  
0FCE:D0A7:01=Sony Ericsson Device 616 USB WMC Data Modem  
0FCE:D0A7:03=Sony Ericsson Device 616 USB WMC Modem  
0FCE:D0A8=SEMC HCB-100E Device  
0FCE:D0AA=SEMC HCB-105 Device  
0FCE:D0AB=Sony Ericsson Device 117  
0FCE:D0AB:01=Sony Ericsson Device 117 USB WMC Data Modem  
0FCE:D0AB:03=Sony Ericsson Device 117 USB WMC Modem  
0FCE:D0AC=Sony Ericsson Device 117  
0FCE:D0AC:01=Sony Ericsson Device 117 USB WMC Data Modem  
0FCE:D0AC:03=Sony Ericsson Device 117 USB WMC Modem  
0FCE:D0AF=V640i Phone  
0FCE:D0AF:01=Sony Ericsson Device 117 USB WMC Data Modem  
0FCE:D0AF:03=Sony Ericsson Device 117 USB WMC Modem  
0FCE:D0B3=Sony Ericsson Device 217  
0FCE:D0B3:01=Sony Ericsson Device 217 USB WMC Data Modem  
0FCE:D0B3:03=Sony Ericsson Device 217 USB WMC Modem  
0FCE:D0B5=Sony Ericsson Device 916  
0FCE:D0B5:01=Sony Ericsson Device 916 USB WMC Modem  
0FCE:D0B7=Sony Ericsson Device 816  
0FCE:D0B7:01=Sony Ericsson Device 816 USB WMC Data Modem  
0FCE:D0B7:03=Sony Ericsson Device 816 USB WMC Modem  
0FCE:D0B8=Sony Ericsson Device 816  
0FCE:D0B8:01=Sony Ericsson Device 816 USB WMC Data Modem  
0FCE:D0B8:03=Sony Ericsson Device 816 USB WMC Modem  
0FCE:D0B9=Sony Ericsson Device 217  
0FCE:D0B9:01=Sony Ericsson Device 217 USB WMC Data Modem  
0FCE:D0B9:03=Sony Ericsson Device 217 USB WMC Modem  
0FCE:D0BB=Sony Ericsson Device 217  
0FCE:D0BB:01=Sony Ericsson Device 217 USB WMC Data Modem  
0FCE:D0BB:03=Sony Ericsson Device 217 USB WMC Modem  
0FCE:D0C5=Sony Ericsson Device 217  
0FCE:D0C5:01=Sony Ericsson Device 217 USB WMC Data Modem  
0FCE:D0C5:03=Sony Ericsson Device 217 USB WMC Modem

0FCE:D0C6=Sony Ericsson Device 0017  
0FCE:D0C6:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0C6:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D0C7=Sony Ericsson Device 916  
0FCE:D0C7:01=Sony Ericsson Device 916 USB WMC Modem  
0FCE:D0CB=Sony Ericsson G900 Composite Device  
0FCE:D0CB:01=Sony Ericsson G900 PC-Connect Controller  
0FCE:D0CB:03=Sony Ericsson G900 USB Modem  
0FCE:D0CB:05=Sony Ericsson G900 Application Port  
0FCE:D0CB:07=Sony Ericsson G900 Debug Port  
0FCE:D0CD=Sony Ericsson G700 Composite Device  
0FCE:D0CD:01=Sony Ericsson G700 PC-Connect Controller  
0FCE:D0CD:03=Sony Ericsson G700 USB Modem  
0FCE:D0CD:05=Sony Ericsson G700 Application Port  
0FCE:D0CD:07=Sony Ericsson G700 Debug Port  
0FCE:D0CE=Sony Ericsson G700c Composite Device  
0FCE:D0CE:01=Sony Ericsson G700c PC-Connect Controller  
0FCE:D0CE:03=Sony Ericsson G700c USB Modem  
0FCE:D0CE:05=Sony Ericsson G700c Application Port  
0FCE:D0CE:07=Sony Ericsson G700c Debug Port  
0FCE:D0CF=MD300 Mobile Broadband Modem  
0FCE:D0D0=Sony Ericsson Device A016  
0FCE:D0D0:01=Sony Ericsson Device A016 USB WMC Modem  
0FCE:D0D4=C902 [Modem]  
0FCE:D0D4:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0D4:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D0D5=Sony Ericsson Device 0017  
0FCE:D0D5:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0D5:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D0D6=Sony Ericsson Device 0017  
0FCE:D0D6:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0D6:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D0D8=Sony Ericsson Device 0017  
0FCE:D0D8:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0D8:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D0D9=Sony Ericsson Device 0017  
0FCE:D0D9:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0D9:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D0DA=Sony Ericsson Device 0017  
0FCE:D0DA:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0DA:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D0DE=Sony Ericsson Device 0017  
0FCE:D0DE:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0DE:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D0E1=MD400 Mobile Broadband Modem  
0FCE:D0E3=Sony Ericsson Device 0017  
0FCE:D0E3:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0E3:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D0EC=Sony Ericsson Device 0017  
0FCE:D0EC:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0EC:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D0EF=Sony Ericsson Device 1018  
0FCE:D0EF:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D0EF:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D0F1=Sony Ericsson Device 1018  
0FCE:D0F1:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D0F1:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D0F3=Sony Ericsson Device 0017  
0FCE:D0F3:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0F3:03=Sony Ericsson Device 0017 USB WMC Modem

0FCE:D0F5=Sony Ericsson Device 0017  
0FCE:D0F5:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0F5:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D0F9=SEMC HCB-108 Device  
0FCE:D0FB=Sony Ericsson Device 0017  
0FCE:D0FB:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D0FB:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D100=Sony Ericsson Device 0017  
0FCE:D100:01=Sony Ericsson Device 0017 USB WMC Data Modem  
0FCE:D100:03=Sony Ericsson Device 0017 USB WMC Modem  
0FCE:D101=SEMC AB900 Device  
0FCE:D104=SEMC MBS-200 Device  
0FCE:D105=Sony Ericsson Device 1018  
0FCE:D105:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D105:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D107=Sony Ericsson Mobile Device  
0FCE:D108=Sony Ericsson Device 1018  
0FCE:D108:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D108:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D109=Sony Ericsson Device 1018  
0FCE:D109:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D109:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D10B=Sony Ericsson Device 1018  
0FCE:D10B:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D10B:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D10C=Sony Ericsson Device 1018  
0FCE:D10C:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D10C:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D112=Sony Ericsson Device 1018  
0FCE:D112:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D112:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D113=Sony Ericsson Device 1018  
0FCE:D113:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D113:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D11A=Sony Ericsson Device 1018  
0FCE:D11A:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D11A:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D11C=Sony Ericsson Mobile Device  
0FCE:D11D=Sony Ericsson Device 1018  
0FCE:D11D:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D11D:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D11E=Sony Ericsson Device 1018  
0FCE:D11E:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D11E:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D120=Sony Ericsson Device 1018  
0FCE:D120:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D120:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D121=Sony Ericsson Device 1018  
0FCE:D121:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D121:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D123=Sony Ericsson Device 1018  
0FCE:D123:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D123:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D126=Sony Ericsson Device 1018  
0FCE:D126:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D126:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D127=Sony Ericsson Mobile Device  
0FCE:D129=Sony Ericsson Device 1029  
0FCE:D129:01=Sony Ericsson Device 1029 USB WMC Data Modem  
0FCE:D129:03=Sony Ericsson Device 1029 USB WMC Modem

0FCE:D12A=Sony Ericsson Device 1029  
0FCE:D12A:01=Sony Ericsson Device 1029 USB WMC Data Modem  
0FCE:D12A:03=Sony Ericsson Device 1029 USB WMC Modem  
0FCE:D12C=Sony Ericsson Device 1029  
0FCE:D12C:01=Sony Ericsson Device 1029 USB WMC Data Modem  
0FCE:D12C:03=Sony Ericsson Device 1029 USB WMC Modem  
0FCE:D12D=Sony Ericsson Device 1018  
0FCE:D12D:01=Sony Ericsson Device 1018 USB WMC Data Modem  
0FCE:D12D:03=Sony Ericsson Device 1018 USB WMC Modem  
0FCE:D12E=Xperia X10  
0FCE:E010=Sony Ericsson Composite Device  
0FCE:E010:01=Sony Ericsson Master Port  
0FCE:E010:03=Sony Ericsson Slave Port  
0FCE:E011=Sony Ericsson Composite Device  
0FCE:E011:01=Sony Ericsson Master Port  
0FCE:E011:03=Sony Ericsson Slave Port  
0FCE:E012=Sony Ericsson Composite Device  
0FCE:E012:01=Sony Ericsson Master Port  
0FCE:E012:03=Sony Ericsson Slave Port  
0FCE:E030=Sony Ericsson P990 Composite Device  
0FCE:E031=Sony Ericsson M600 Composite Device  
0FCE:E039=K800i (msc mode)  
0FCE:E042=W810i Phone  
0FCE:E043=V630i Phone [Mass Storage]  
0FCE:E065=Sony Ericsson W960 Composite Device  
0FCE:E075=K850i  
0FCE:E076=W910i (Mass storage)  
0FCE:E089=W580i Phone  
0FCE:E090=W200 Phone (Mass Storage)  
0FCE:E092=Sony Ericsson P1 Composite Device  
0FCE:E0A3=W660i  
0FCE:E0AF=V640i Phone [Mass Storage]  
0FCE:E0CB=Sony Ericsson G900 Composite Device  
0FCE:E0CD=Sony Ericsson G700 Composite Device  
0FCE:E0CE=Sony Ericsson G700c Composite Device  
0FCE:E0D4=C902 [Mass Storage]  
0FCE:E0EF=C905 Phone [Mass Storage]  
0FCE:E0F3=W595  
0FCE:E105=W705  
0FCE:E107:01=Sony Ericsson USB Mobile Mass Storage Pseudo CDC Trace  
0FCE:E107:02=Sony Ericsson USB Mobile Mass Storage Pseudo CDC Console  
0FCE:E112=W995 Phone (Mass Storage)  
0FCE:E11C:01=Sony Ericsson USB Mobile Mass Storage Pseudo CDC Trace  
0FCE:E11C:02=Sony Ericsson USB Mobile Mass Storage Pseudo CDC Console  
0FCE:E127:01=Sony Ericsson USB Mobile Mass Storage Pseudo CDC Trace  
0FCE:E127:02=Sony Ericsson USB Mobile Mass Storage Pseudo CDC Console  
0FCE:E12E=X10i Phone  
0FCE:E133=Vivaz  
0FCE:E14F=Xperia Arc  
0FCE:F065=Sony Ericsson Composite Device  
0FCE:F065:01=Sony Ericsson Master Port  
0FCE:F065:03=Sony Ericsson Slave Port  
0FCE:F092=Sony Ericsson Composite Device  
0FCE:F092:01=Sony Ericsson Master Port  
0FCE:F092:03=Sony Ericsson Slave Port  
0FCE:F0AA=SEMC DFU Device  
0FCE:F0CB=Sony Ericsson Composite Device  
0FCE:F0CB:01=Sony Ericsson Master Port  
0FCE:F0CB:03=Sony Ericsson Slave Port  
0FCE:F0CD=Sony Ericsson Composite Device

0FCE:F0CD:01=Sony Ericsson Master Port  
0FCE:F0CD:03=Sony Ericsson Slave Port  
0FCE:F0CE=Sony Ericsson Composite Device  
0FCE:F0CE:01=Sony Ericsson Master Port  
0FCE:F0CE:03=Sony Ericsson Slave Port  
0FCE:F0F9=SEMC DFU Device  
0FCE:F101=SEMC DFU Device  
0FCE:F104=SEMC DFU Device  
0FCE:FFFF=SEMC DFU Device  
0FCF=Dynastream Innovations  
0FCF:0012=USB ANT USBXpress Device  
0FCF:1003=USB ANT USBXpress Device  
0FCF:1004=USB ANT USBXpress Device  
0FCF:1006=USB ANT USBXpress Device  
0FCF:1007=USB ANT USBXpress Device  
0FD0=Tulip Computers B.V.  
0FD1=Giant Electronics  
0FD1:0001=GIANT Bluetooth Device  
0FD1:FFFF=GIANT Bluetooth Device  
0FD4=Tenovis  
0FD5=Direct Access Technology  
0FD9=Elgato Systems GmbH  
0FD9:0011=EyeTV Diversity  
0FD9:0018=EyeTV Hybrid  
0FD9:0020=EyeTV DTT Deluxe  
0FD9:0021=EyeTV DTT  
0FD9:002A=EyeTV Sat  
0FD9:002C=EyeTV DTT Deluxe v2  
0FD9:0033=Video Capture  
0FD9:0037=Video Capture v2  
0FDC=Micro Plus  
0FDE:0100=MP3 Player  
0FDE:0120=MP3 Player  
0FDE:0200=MP3 Player  
0FDE:0210=MP3 Player  
0FDE:6628=Oregon Scientific DS6628  
0FDE:6868=Packard Bell DSC-3  
0FE0=Osterhout Design Group  
0FE0:0100=Bluetooth Mouse  
0FE0:0101=Bluetooth IMU  
0FE0:0200=Bluetooth Keypad  
0FE4=IN-Tech Electronics  
0FE5=GREENCONN (U.S.A.) INC.  
0FE6=Kontron (Industrial Computer Source / ICS Advent)  
0FE6:8101=DM9601 Fast Ethernet Adapter  
0FE6:811E=Parallel Adapter  
0FE6:9700=DM9601 Fast Ethernet Adapter  
0FE9=DVICO  
0FE9:4020=TViX M-6500  
0FE9:DB00=FusionHDTV DVB-T (MT352+LgZ201) (uninitialized)  
0FE9:DB01=FusionHDTV DVB-T (MT352+LgZ201) (initialized)  
0FE9:DB10=FusionHDTV DVB-T (MT352+Thomson7579) (uninitialized)  
0FE9:DB11=FusionHDTV DVB-T (MT352+Thomson7579) (initialized)  
0FE9:DB78=FusionHDTV DVB-T Dual Digital 4 (ZL10353+xc2028/xc3028) (initialized)  
0FEA=United Computer Accessories  
0FEB=CRS Electronic  
0FEC=UMC Electronics  
0FED=ACCESS  
0FEE=Xsido  
0FEF=MJ Research

0FF6=Core Valley  
0FF7=CHI SHING COMPUTER ACCESSORIES  
0FFF=Aopen  
1000=Speed Tech  
1001=Ritronics  
1002:A001=ATI TV WONDER USB 2.0 NTSC Device Driver  
1002:A002=ATI TV WONDER USB 2.0 PAL/SECAM Device Driver  
1002:A636=ATI TV Wonder OpenCable Receiver  
1002:AC14=ATI Unified AVStream Driver  
1003=Sigma  
1003:0003=SD14  
1003:0100=Sigma SD10  
1004=LG Electronics  
1004:1FAE=LGE U8110  
1004:1FAE:01=LGE U8XXX USB WMC Data Modem  
1004:1FAE:03=LGE U8XXX USB WMC Modem  
1004:6000=VX4400/VX6000 Cellphone  
1004:6005=T5100  
1004:6018=GM360/GD510/GW520  
1004:6091=LG Mobile  
1004:6091:01=LG Mobile USB WMC Data Modem  
1004:618E=LGE Android Platform USB Serial Port  
1004:618F=Ally  
1004:61A1=LG AndroidNet USB Serial Port  
1004:61A1:01=LG AndroidNet NDIS Ethernet Adapter  
1004:61A1:03=LG AndroidNet USB Modem  
1004:61A1:05=LG AndroidNet USB GPS NMEA Port  
1004:61A1:07=AndroidNet Sooner Single ADB Interface  
1004:61A2=LG AndroidNet USB Serial Port  
1004:61A2:01=LG AndroidNet NDIS Ethernet Adapter  
1004:61A2:03=LG AndroidNet USB Modem  
1004:61A2:05=LG AndroidNet USB GPS NMEA Port  
1004:61A3=LGE Android Platform USB Modem  
1004:61A3:02=LGE Android Platform USB Serial Port  
1004:61A3:03=LGE Android Platform USB GPS NMEA Port  
1004:61A3:05=Android Platform Sooner Single ADB Interface  
1004:61A4=LGE Android Platform USB Modem  
1004:61A4:02=LGE Android Platform USB Serial Port  
1004:61A4:03=LGE Android Platform USB GPS NMEA Port  
1004:61A4:05=LG AndroidNet Remote NDIS Device  
1004:61A5=LGE Mobile USB Modem  
1004:61A5:02=LGE Mobile USB Serial Port  
1004:61A5:03=LGE Mobile USB GPS NMEA Port  
1004:61A6:01=Android Sooner Single ADB Interface  
1004:61C6=Vortex (msc)  
1004:61CC=Optimus S  
1004:61D7=LG AndroidNet Remote NDIS Device  
1004:61D7:02=LG AndroidNet USB Modem  
1004:61D7:04=LG AndroidNet USB Serial Port  
1004:61D7:05=LG AndroidNet USB GPS NMEA Port  
1004:61D7:07=AndroidNet Sooner Single ADB Interface  
1004:61D8=LG AndroidNet Remote NDIS Device  
1004:61D8:02=LG AndroidNet USB Modem  
1004:61D8:04=LG AndroidNet USB Serial Port  
1004:61D8:05=LG AndroidNet USB GPS NMEA Port  
1004:61D9=LG AndroidNet Remote NDIS Device  
1004:61D9:02=AndroidNet Sooner Single ADB Interface  
1004:61DA=LG AndroidNet Remote NDIS Device  
1004:6800=CDMA Modem  
1004:7000=LG LDP-7024D (LD) USB



1004:A400=Renoir (KC910)  
1005=Apacer Technology  
1005:1001=MP3 Player  
1005:1004=MP3 Player  
1005:1006=MP3 Player  
1005:B113=Handy Steno 2.0 (256MB/512MB/1GB)  
1005:B223=CD-RW + 6in1 Card Reader Digital Storage / Converter  
1006=iRiver  
1006:3001=iHP-100  
1006:3002=iHP-100/120/140 MP3 Player  
1006:3003=H320/H340  
1006:3004=H340 (mtp)  
1006:4002=Appareil mobile MTP  
1006:4003=Appareil mobile MTP  
1009=Emuzed  
1009:000E=eHome Infrared Receiver (USBCIR)  
1009:0013=Angel USB MPEG Device  
1009:0015=Lumanate Wave PAL SECAM DVBT Device  
1009:0016=Lumanate Wave NTSC/ATSC Combo Device  
100A=AV Chaseway  
100A:2402=MP3 Player  
100A:2404=MP3 Player  
100A:2405=MP3 Player  
100A:2406=MP3 Player  
100A:A0C0=MP3 Player  
100B=Chou Chin Industrial  
100D=NETOPIA  
100D:3342=Cayman 3352 DSL Modem  
100D:3382=3380 Series Network Interface  
100D:6072=Netopia DSL-N Series USB Gateway  
100D:9031=Motorola 802.11n Dualband USB Wireless Adapter  
100D:9032=Motorola 802.11n 5G USB Wireless Adapter  
100D:CB01=Cayman 3341 Ethernet DSL Router  
1010=FUKUDA DENSHI  
1011=Mobile Media Tech.  
1011:0001=AccFast Mp3  
1012=SDKM Fibres, Wires & Cables Berhad  
1013=TST-Touchless Sensor Technology AG  
1014=Densitron Technologies PLC  
1015=Softronics  
1016=Xiamen Hung's Enterprise  
1017=SPEEDY INDUSTRIAL SUPPLIES  
1019=I-Buddie  
1019:0C55=IC Card Reader  
1019:0C55:0100=IC Card Reader (UCR-61S2B)  
1019:0F38=eHome Infrared Transceiver  
1019:0F52=Realtek USB 2.0 Card Reader  
1019:0F62=Realtek USB 2.0 Card Reader  
1019:0F64=Realtek USB 2.0 Card Reader  
1019:0F67=Realtek USB 2.0 Card Reader  
1019:0F71=Realtek USB 2.0 Card Reader  
101E:0001=Cherry USB Keyboard  
1020=Labtec  
1020:0006=Wireless Keyboard  
1020:000A=Wireless Optical Mouse  
1020:0106=Wireless Optical Mouse  
1022=Shinko Shoji  
1025=Hyper-Paltek  
1025:005E=USB DVB-T device  
1025:005F=USB DVB-T device

1025:0300=MP3 Player  
1025:0350=MP3 Player  
1026=Newly  
1027=Time Domain  
1028=Inovys  
1029=Atlantic Coast Telesys  
102A=RAMOS Technology  
102B=Infotronic America  
102C=Etoms Electronics  
102C:6151=Q-Cam Sangha CIF  
102C:6251=Q-Cam  
102D=Winic  
102F=WENZHOU YIHUA COMMUNICATED CONNECTOR  
1031=Comax Technology  
1032=C-One Technology  
1033=Nucam  
1033:0068=USB Storage Driver  
1038=Ideazon  
1038:0100=Zboard  
1038:0100:1096=Ideazon USB Zboard Device  
1039=devolo AG  
1039:0824=devolo WLAN USB Stick  
1039:1047=MicroLink 56k Fun USB  
1039:2140=dsl+ 1100 duo  
103C:1629=Realtek RTL8188CU Wireless LAN 802.11n USB 2.0 Network Adapter  
103D=Stanton  
103D:0100=ScratchAmp  
103D:0101=ScratchAmp  
103E=TTi  
103E:03E8=USB TTi PSU Serial Interface  
103E:03E8:0200=QL355TP Power Supply  
1043=iCreate Technologies  
1043:160F=Wireless Network Adapter  
1043:4901=AV-836 Video Capture Device  
1043:8006=Flash Disk  
1043:8012=USB 2.0 Flash Disk  
1044=Chu Yuen Enterprise  
1044:7001=U7000 TV tuner device  
1044:7002=Gigabyte U8000 DVB-T tuner  
1044:7004=Gigabyte U7100 DVB-T tuner  
1044:7005=Gigabyte U7200 DVB-T tuner [AF9035]  
1044:7006=Gigabyte U6000 DVB-T tuner [em2863]  
1044:8001=GN-54G  
1044:8002=GN-BR402W  
1044:8003=GN-WLBM101  
1044:8004=GN-WLBZ101 802.11b Adapter  
1044:8005=GN-WLBZ201 802.11b Adapter  
1044:8006=GN-WBZB-M 802.11b Adapter  
1044:8007=Gigabyte WBKG USB WLAN Card  
1044:8008=Gigabyte GN-WB01GS USB WLAN Card  
1044:800A=Gigabyte GN-WI05GS mini WLAN Card  
1044:800B=GN-WB30N 802.11n WLAN Card  
1044:800C=Gigabyte GN-WB31N 802.11n USB WLAN Card  
1044:800D=Gigabyte GN-WB32L 802.11n USB WLAN Card  
1046=Winbond Electronics  
1046:6694=Generic W6694 USB  
1046:8901=Winbond Bluetooth Device  
1046:9967=W9967CF/W9968CF WebCam IC  
1048=Targus Group International  
104B=Mylex / Buslogic

104C=AMCO TEC International  
104D=Newport  
104D:1003=Model-52 LED Light Source Power Supply and Driver  
104F=WB Electronics  
104F:0001=Infinity Phoenix  
104F:0002=Smartmouse  
104F:0003=FunProgrammer  
104F:0004=Infinity Unlimited  
104F:0006=Infinity Smart  
104F:0007=Infinity Smart module  
104F:0008=Infinity CryptoKey  
104F:0009=RE-BL PlayStation 3 IR-to-Bluetooth converter  
1050=Yubico.com  
1050:0010=Yubikey  
1053=Immanuel Electronics  
1054=BMS International Beheer N.V.  
1054:5004=DSL 7420 Loader  
1054:5005=DSL 7420 LAN Modem  
1055=Complex Micro Interconnection  
1056=Hsin Chen Ent  
1057=ON Semiconductor  
1058=Western Digital Technologies  
1058:0200=Firewire USB Combo  
1058:0400=External HDD  
1058:0401=External HDD  
1058:0500=USB HUB  
1058:0702=Passport External HDD  
1058:0704=Passport External HDD  
1058:070A=My Passport Essential SE  
1058:071A=My Passport 1TB  
1058:0740=My Passport 1TB  
1058:0742=My Passport Essential SE  
1058:0900=MyBook Essential External HDD  
1058:0901=MyBook External HDD  
1058:0903=My Book Premium Edition  
1058:0910=MyBook Essential External HDD  
1058:1001=External Hard Disk  
1058:1021=Elements 2TB  
1058:1100=Western Digital My Book  
1058:1103=My Book Studio  
1058:1104=My Book USB Disk Drive  
1058:1104:01=My Book USB Control  
1058:1123=My Book 3.0  
1059=Giesecke & Devrient GmbH  
1059:000B=StarSign Bio Token 3.0  
105C=Hong Ji Electric Wire & Cable (Dongguan)  
105D=Delkin Devices  
105E=Valence Semiconductor Design  
105F=Chin Shong Enterprise  
1060=Easthome Industrial  
1063=Motorola Electronics Taiwan  
1063:1555=MC141555 Hub  
1063:4100=SB4100 USB Cable Modem  
1065=CCYU Technology  
1065:0020=USB-DVR2 Dev Board  
1065:2136=EasyDisk ED1064  
1066:00CE=E-TEN USB Sync  
1066:0300=E-TEN P3XX Pocket PC  
1066:0500=E-TEN P5XX Pocket PC  
1066:0600=E-TEN P6XX Pocket PC

1066:0700=E-TEN P7XX Pocket PC  
106A=Loyal Legend  
106C=Curitel Communications  
106C:1101=CDMA 2000 1xRTT USB modem (HX-550C)  
106C:1102=Packet Service  
106C:1103=Packet Service Diagnostic Serial Port (WDM)  
106C:1104=Packet Service Diagnostic Serial Port (WDM)  
106C:1105=Composite Device  
106C:1106=Packet Service Diagnostic Serial Port (WDM)  
106C:1301=Composite Device  
106C:1302=Packet Service Diagnostic Serial Port (WDM)  
106C:1303=Packet Service  
106C:1304=Packet Service  
106C:1401=Composite Device  
106C:1402=Packet Service  
106C:1403=Packet Service Diagnostic Serial Port (WDM)  
106C:1501=Packet Service  
106C:1502=Packet Service Diagnostic Serial Port (WDM)  
106C:1503=Packet Service  
106C:1601=Packet Service  
106C:1602=Packet Service Diagnostic Serial Port (WDM)  
106C:1603=Packet Service  
106C:2101=AudioVox 8900 Cell Phone  
106C:2102=Packet Service  
106C:2103=Packet Service Diagnostic Serial Port (WDM)  
106C:2301=Packet Service  
106C:2302=Packet Service Diagnostic Serial Port (WDM)  
106C:2303=Packet Service  
106C:2401=Packet Service Diagnostic Serial Port (WDM)  
106C:2402=Packet Service  
106C:2403=Packet Service Diagnostic Serial Port (WDM)  
106C:2501=Packet Service  
106C:2502=Packet Service Diagnostic Serial Port (WDM)  
106C:2503=Packet Service  
106C:2601=Packet Service  
106C:2602=Packet Service Diagnostic Serial Port (WDM)  
106C:2603=Packet Service  
106C:3701=Broadband Wireless modem  
106C:3702=Pantech PX-500  
106C:3714=PANTECH USB MODEM [UM175]  
106C:3EB4=Packet Service Diagnostic Serial Port (WDM)  
106C:4101=Packet Service Diagnostic Serial Port (WDM)  
106C:4102=Packet Service  
106C:4301=Composite Device  
106C:4302=Packet Service Diagnostic Serial Port (WDM)  
106C:4401=Composite Device  
106C:4402=Packet Service  
106C:4501=Packet Service  
106C:4502=Packet Service Diagnostic Serial Port (WDM)  
106C:4601=Composite Device  
106C:4602=Packet Service Diagnostic Serial Port (WDM)  
106C:5101=Packet Service  
106C:5102=Packet Service Diagnostic Serial Port (WDM)  
106C:5301=Packet Service Diagnostic Serial Port (WDM)  
106C:5302=Packet Service  
106C:5401=Packet Service  
106C:5402=Packet Service Diagnostic Serial Port (WDM)  
106C:5501=Packet Service Diagnostic Serial Port (WDM)  
106C:5502=Packet Service  
106C:5601=Packet Service Diagnostic Serial Port (WDM)

106C:5602=Packet Service  
106C:7101=Composite Device  
106C:7102=Packet Service  
106C:A000=Packet Service  
106C:A001=Packet Service Diagnostic Serial Port (WDM)  
106C:C100=Packet Service  
106C:C200=Packet Service  
106C:C500=Packet Service Diagnostic Serial Port (WDM)  
106C:E200=Packet Service  
106D=San Chieh Manufacturing  
106E=ConectL  
106F=Money Controls  
1076=GCT Semiconductor  
1076:0031=GctSemi Bluetooth Device  
1076:0032=GctSemi Bluetooth Device  
107B=Gateway  
107B:3009=eHome Infrared Receiver (USBCIR)  
107B:55B2=WBU-110 802.11b Wireless Adapter [Intersil PRISM 3]  
107B:55F2=WGU-210 802.11g Adapter [Intersil ISL3886]  
107D=Arlec Australia  
107E=MIDORIYA ELECTRIC  
107F=KidzMouse  
1082=Shin-Etsukaken  
1083=CANON ELECTRONICS INC.  
1083:162C=P-150 Scanner  
1084=PANTECH  
1084:3100=PANTECH GSM Handset USB Mgmt  
1084:3101=PANTECH GSM Handset USB Mgmt  
1084:3102=PANTECH GSM Handset USB Device  
1084:3103=PANTECH GSM Handset USB Mgmt  
1084:3104=PANTECH GSM Handset USB Device  
1084:3105=PANTECH GSM Handset USB Mgmt  
1084:3106=PANTECH GSM Handset Mass Storage (WDM)  
1084:6000=PANTECH GSM Handset USB Mgmt  
1084:6001=PANTECH GSM Handset USB Mgmt  
1084:6002=PANTECH GSM Handset USB Device  
1084:6003=PANTECH GSM Handset USB Mgmt  
1084:6004=PANTECH GSM Handset USB Device  
1084:6005=PANTECH GSM Handset USB Mgmt  
1084:6006=PANTECH GSM Handset Mass Storage (WDM)  
1084:6010=PANTECH GSM Handset USB Mgmt  
1084:6011=PANTECH GSM Handset USB Mgmt  
1084:6012=PANTECH GSM Handset USB Device  
1084:6013=PANTECH GSM Handset USB Mgmt  
1084:6014=PANTECH GSM Handset USB Device  
1084:6015=PANTECH GSM Handset USB Mgmt  
1084:6016=PANTECH GSM Handset Mass Storage (WDM)  
1084:6020=PANTECH GSM Handset USB Mgmt  
1084:6021=PANTECH GSM Handset USB Mgmt  
1084:6022=PANTECH GSM Handset USB Device  
1084:6023=PANTECH GSM Handset USB Mgmt  
1084:6024=PANTECH GSM Handset USB Device  
1084:6025=PANTECH GSM Handset USB Mgmt  
1084:6026=PANTECH GSM Handset Mass Storage (WDM)  
1084:6030=PANTECH GSM Handset USB Mgmt  
1084:6031=PANTECH GSM Handset USB Mgmt  
1084:6032=PANTECH GSM Handset USB Device  
1084:6033=PANTECH GSM Handset USB Mgmt  
1084:6034=PANTECH GSM Handset USB Device  
1084:6035=PANTECH GSM Handset USB Mgmt

1084:6036=PANTECH GSM Handset Mass Storage (WDM)  
1084:6040=PANTECH GSM Handset USB Mgmt  
1084:6041=PANTECH GSM Handset USB Mgmt  
1084:6042=PANTECH GSM Handset USB Device  
1084:6043=PANTECH GSM Handset USB Mgmt  
1084:6044=PANTECH GSM Handset USB Device  
1084:6045=PANTECH GSM Handset USB Mgmt  
1084:6046=PANTECH GSM Handset Mass Storage (WDM)  
1084:6050=PANTECH GSM Handset USB Mgmt  
1084:6051=PANTECH GSM Handset USB Mgmt  
1084:6052=PANTECH GSM Handset USB Device  
1084:6053=PANTECH GSM Handset USB Mgmt  
1084:6054=PANTECH GSM Handset USB Device  
1084:6055=PANTECH GSM Handset USB Mgmt  
1084:6056=PANTECH GSM Handset Mass Storage (WDM)  
1084:6060=PANTECH GSM Handset USB Mgmt  
1084:6061=PANTECH GSM Handset USB Mgmt  
1084:6062=PANTECH GSM Handset USB Device  
1084:6063=PANTECH GSM Handset USB Mgmt  
1084:6064=PANTECH GSM Handset USB Device  
1084:6065=PANTECH GSM Handset USB Mgmt  
1084:6066=PANTECH GSM Handset Mass Storage (WDM)  
1084:6070=PANTECH GSM Handset USB Mgmt  
1084:6071=PANTECH GSM Handset USB Mgmt  
1084:6072=PANTECH GSM Handset USB Device  
1084:6073=PANTECH GSM Handset USB Mgmt  
1084:6074=PANTECH GSM Handset USB Device  
1084:6075=PANTECH GSM Handset USB Mgmt  
1084:6076=PANTECH GSM Handset Mass Storage (WDM)  
1084:6080=PANTECH GSM Handset USB Mgmt  
1084:6081=PANTECH GSM Handset USB Mgmt  
1084:6082=PANTECH GSM Handset USB Device  
1084:6083=PANTECH GSM Handset USB Mgmt  
1084:6084=PANTECH GSM Handset USB Device  
1084:6085=PANTECH GSM Handset USB Mgmt  
1084:6086=PANTECH GSM Handset Mass Storage (WDM)  
1084:6090=PANTECH GSM Handset USB Mgmt  
1084:6091=PANTECH GSM Handset USB Mgmt  
1084:6092=PANTECH GSM Handset USB Device  
1084:6093=PANTECH GSM Handset USB Mgmt  
1084:6094=PANTECH GSM Handset USB Device  
1084:6095=PANTECH GSM Handset USB Mgmt  
1084:6096=PANTECH GSM Handset Mass Storage (WDM)  
1084:60A0=PANTECH GSM Handset USB Mgmt  
1084:60A1=PANTECH GSM Handset USB Mgmt  
1084:60A2=PANTECH GSM Handset USB Device  
1084:60A3=PANTECH GSM Handset USB Mgmt  
1084:60A4=PANTECH GSM Handset USB Device  
1084:60A5=PANTECH GSM Handset USB Mgmt  
1084:60A6=PANTECH GSM Handset Mass Storage (WDM)  
1084:60B0=PANTECH GSM Handset USB Mgmt  
1084:60B1=PANTECH GSM Handset USB Mgmt  
1084:60B2=PANTECH GSM Handset USB Device  
1084:60B3=PANTECH GSM Handset USB Mgmt  
1084:60B4=PANTECH GSM Handset USB Device  
1084:60B5=PANTECH GSM Handset USB Mgmt  
1084:60B6=PANTECH GSM Handset Mass Storage (WDM)  
1084:A6CD=Pantech SmartPhone USB Sync  
108A=Chloride Power Protection  
108B=Grand-tek Technology

108C=Robert Bosch GmbH  
108E=Lotes  
1099=Surface Optics  
109A=DATASOFT Systems GmbH  
109F=eSOL  
109F:3163=Trigem Mobile SmartDisplay84  
109F:3164=Trigem Mobile SmartDisplay121  
109F:7148=4-Port USB Hub  
10A0=HIROTECH  
10A3=MITSUBISHI MATERIALS  
10A4:0105=The Bug  
10A9=SK Teletech  
10A9:1102=Sky IM-U460K  
10A9:1104=Sky Vega IM-A650S  
10A9:6021=SIRIUS alpha  
10AA=Cables To Go  
10AB=USI  
10AB:0816=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
10AB:081A=Bluetooth Module BCM92070-Auto-Pairing  
10AB:1002=Motion Computing USB Bluetooth Adapter  
10AB:1003=BC02-EXT in DFU  
10AB:1005=Motion Computing USB Bluetooth Adapter  
10AB:1006=BC04-EXT in DFU  
10AB:10C5=Sony-Ericsson / Samsung DataCable  
10AC=Honeywell  
10AC:10C6=Nokia Connectivity Adapter Cable DKU-5  
10AE=Princeton Technology  
10AF=Liebert  
10AF:0000=UPS  
10AF:0001=PowerSure PSA UPS  
10AF:0002=PowerSure PST UPS  
10AF:0003=PowerSure PSP UPS  
10AF:0004=PowerSure PSI UPS  
10AF:0005=UPStation GXT 2U UPS  
10AF:0006=UPStation GXT UPS  
10AF:0007=Nfinity Power Systems UPS  
10AF:0008=PowerSure Interactive UPS  
10B5=Comodo  
10B5:9060=Test Board  
10B8=DIBCOM  
10B8:0066=DiBcom DIB7700 based TV tuner device  
10B8:0066:01=Infrared Receiver  
10B8:0067:01=Infrared Receiver  
10B8:0BB8=DiBcom USB DVB-T reference design (MOD300) (cold)  
10B8:0BB9=VideoMate DVB-U2000  
10B8:0BC6=DiBcom USB2.0 DVB-T reference design (MOD3000P) (cold)  
10B8:0BC7=DiBcom USB2.0 DVB-T reference design (MOD3000P) (warm)  
10B8:0BC7:01=Infrared Receiver  
10B8:0E89:01=Infrared Receiver  
10B8:0ED9:01=Infrared Receiver  
10B8:0EED:01=Infrared Receiver  
10B8:1E14=Infrared Receiver  
10B8:1E14:01=Infrared Receiver  
10B8:1E15:01=Infrared Receiver  
10B8:1E16=Infrared Receiver  
10B8:1E16:01=Infrared Receiver  
10B8:1E78=Infrared Receiver  
10B8:1E78:01=Infrared Receiver  
10B8:1E79:01=Infrared Receiver  
10B8:1E7A=Infrared Receiver

10B8:1E7A:01=Infrared Receiver  
10B8:1E7C=DiBcom DIB7700 based TV tuner device  
10B8:1E8C=Infrared Receiver  
10B8:1E8C:01=Infrared Receiver  
10B8:1E90=DiBcom DIB7700 based TV tuner device  
10B8:1E90:01=Infrared Receiver  
10B8:1E96=Infrared Receiver  
10B8:1E96:01=Infrared Receiver  
10B8:1E98=Infrared Receiver  
10B8:1E98:01=Infrared Receiver  
10B8:1EBC=Infrared Receiver  
10B8:1EBC:01=Infrared Receiver  
10B8:1EBE=Infrared Receiver  
10B8:1EBE:01=Infrared Receiver  
10B8:1EC0=T14BR DVB-T Digital TV Receiver  
10B8:1EC6=T14BR DVB-T Digital TV Receiver  
10B8:1ECA=T14BR DVB-T Digital TV Receiver  
10B8:1EF0=Infrared Receiver  
10B8:1EF0:01=Infrared Receiver  
10B8:1EFC=Infrared Receiver  
10B8:1EFC:01=Infrared Receiver  
10B9:5619=USB Optical Storage Device  
10BB=TM Technology  
10BC=Dinging Technology  
10BD=TMT TECHNOLOGY  
10BD:1427=ASANTE USB To Ethernet Adapter  
10BF=SmartHome  
10BF:0001=SmartHome PowerLinc  
10C4=Cygnal  
10C4:0002=F32x Express USB Device  
10C4:0003=CommandIR  
10C4:8044=USB Debug Adapter  
10C4:804E=Software Bisque Paramount ME  
10C4:80A9=CP210x to UART Bridge Controller  
10C4:80CA=ATM2400 Sensor Device  
10C4:813F=tams EasyControl  
10C4:818A=Silicon Labs FM Radio Reference Design  
10C4:8460=Sangoma Wanpipe VoiceTime  
10C4:8461=Sangoma U100  
10C4:EA60=Silicon Labs CP210x USB to UART Bridge  
10C4:EA61=USBXpress Device  
10C5=Sanei Electric  
10C5:819A=FM Radio  
10C6=Intec  
10C7:C000=MP3 Player  
10C8=SIGMACOM  
10CB=eratech  
10CC=GBM Connector  
10CC:1101=MP3 Player  
10CD=Kycon  
10CE=Silicon Labs  
10CE:EA6A=MobiData EDGE USB Modem  
10CF=Velleman  
10CF:2011=R-Engine MPEG2 encoder/decoder  
10CF:5500=8055 Experiment Interface Board (address=0)  
10CF:5501=8055 Experiment Interface Board (address=1)  
10CF:5502=8055 Experiment Interface Board (address=2)  
10CF:5503=8055 Experiment Interface Board (address=3)  
10D1=Hottinger Baldwin Measurement  
10D1:0101=USB-Module for Spider8, CP32



10D1:0202=CP22 - Communication Processor  
10D1:0301=CP42 - Communication Processor  
10D4=Man Boon Manufactory  
10D5=Uni Class Technology  
10D5:5552=KVM Human Interface Composite Device (Keyboard/Mouse ports)  
10D5:55A2=2Port KVM Switcher  
10D6=Actions Semiconductor  
10D6:1000=MP3 Player  
10D6:1100=MpMan MP-Ki 128 MP3 Player/Recorder  
10D6:1101=D-Wave 2GB MP4 Player / AK1025 MP3/MP4 Player  
10D6:2200=Acer MP-120 MP3 player  
10D6:8888=ADFU Device  
10D6:FF51=ADFU Device  
10D6:FF61=MP4 Player  
10D6:FF63=USB 2.0 (HS) ADFU Device  
10D6:FF66=USB 2.0 (HS) ADFU Device  
10D6:FF69=Actions USB 2.0 (HS) WinUSB Device  
10D6:FF79=USB 2.0 (HS) ADFU Device  
10DE=Authenex  
10DF=In-Win Development  
10DF:0500=iAPP CR-e500 Card reader  
10E0=Bella  
10E1=CABLEPLUS  
10E2=Nada Electronics  
10E8=Sontheim Industrie Elektronik GmbH  
10E8:1408=Sontheim CANUSB  
10E8:1408:0100=CANUSB Sontheim GmbH  
10EC=Vast Technologies  
10F0=Nexio  
10F0:2002=iNexio Touchscreen controller  
10F1=Importek  
10F1:1A08=Internal Webcam  
10F1:1A1E=Laptop Integrated Webcam 1.3M  
10F5=Turtle Beach  
10F5:0200=Audio Advantage SRM  
10FB=Pictos Technologies  
10FD=Animation Technologies  
10FD:0116=TV Walker QQ  
10FD:0535=FlyTV Express mini DVB-T Hybrid  
10FD:0545=TV Walker Hybrid Lite  
10FD:1116=USB TV Device  
10FD:1535=Mini Card DVB-T Hybrid  
10FD:1545=Hybrid DVB-T Stick  
10FD:2116=TV Walker QQ  
10FD:2535=FlyTV Express mini  
10FD:2545=TV Walker Lite SE  
10FD:3116=USB TV Device  
10FD:3535=Mini Card TV  
10FD:3545=USB TV Stick SE  
10FD:7E50=FlyCam Usb 100  
10FD:804D=Typhoon Webshot II Webcam [zc0301]  
10FD:8050=FlyCAM-USB 300 XP2  
10FD:DE00=WinFast WalkieTV WDM Capture Driver.  
10FD:DE00:0001=LifeView TV Walker Ultra A/V Capture  
1100=VirTouch  
1100:0001=VTPlayer VTP-1 Braille Mouse  
1101=EASYPASS INDUSTRIAL  
1101:0001=FSK Electronics Super GSM Reader  
1108=BRIGHTCOM TECHNOLOGIES  
110A=MOXA Technologies

110A:1250=UPort 1250 2-Port RS-232/422/485  
110A:1251=UPort 1250I 2-Port RS-232/422/485 with Isolation  
110A:1410=UPort 1410 4-Port RS-232  
110A:1450=UPort 1450 4-Port RS-232/422/485  
110A:1451=UPort 1450I 4-Port RS-232/422/485 with Isolation  
110A:1613=UPort 1610-16 16-Port RS-232  
110A:1618=UPort 1610-8 8-Port RS-232  
110A:1653=UPort 1650-16 16-Port RS-232/422/485  
110A:1658=UPort 1650-8 8-Port RS-232/422/485  
1110=Analog Devices Canada  
1110:1110=VGA2USB  
1110:5C01=Huawei MT-882 Remote NDIS Network Device  
1110:6489=ADSL ETH/USB RTR  
1110:9000=USB ADSL Modem  
1110:9001=USB ADSL Modem  
1110:900F=AT-AR215 DSL Modem  
1110:9010=USB ADSL Modem  
1110:9021=USB ADSL Modem  
1110:9022=USB ADSL Modem  
1110:9023=USB ADSL Modem  
1110:9024=USB ADSL Modem  
1110:9031=USB ADSL WAN Adapter  
1110:9032=USB ADSL Loader  
1110:9041=USB ADSL2 WAN Adapter  
1110:9042=USB ADSL2 Loader  
1111=Pandora International  
1111:8888=Evolution Device  
1112=YM ELECTRIC  
1113=Medion AG  
1113:A0A2=Active Sync device  
111D=Centon Electronics  
111E=VSO Electric  
1120:1120=KVM2USB  
112A=RedRat  
112A:0001=RedRat3 IR Transceiver  
112A:0005=RedRat3II IR Transceiver  
112E=Master Hill Electric Wire and Cable  
112F=Cellon International  
112F:1005=Philips DF2000 GSM Handset Composite Device  
112F:1006=Philips DF2000 GSM Handset Modem  
1130=Tenx Technology  
1130:0002=iBuddy  
1130:0202=USB Missile Launcher  
1130:0202:01=USB Missile Targeting  
1130:6604=MCE IR-Receiver  
1130:660C=USB Foot Pedal [Generic]  
1130:6806=Keychain photo frame  
1130:F211=USB audio headset  
1131=Integrated System Solution  
1131:1001=ISSC Bluetooth Device  
1131:1001:0373=ISSC USB Bluetooth Device  
1131:1002=Bluetooth Device  
1131:1003=Bluetooth Device  
1131:1004=Bluetooth Device  
1132=Toshiba  
1132:4331=PDR-M4/M5/M70 Digital Camera  
1132:4332=PDR-M60 Digital Camera  
1132:4333=PDR-M2300/PDR-M700  
1132:4334=PDR-M65  
1132:4335=PDR-M61

1132:4337=PDR-M11  
1132:4338=PDR-M25  
1134:8000=Tri-L USB ISP Programmer USBISP  
1134:8001=Lattice USB ISP Programmer  
1136=CTS Electronincs  
1136:3131=CTS LS515  
113C=Arin Tech  
113D=Mapower Electronics  
113F=Testech  
1141=V ONE MULTIMEDIA  
1142=CYBERSCAN TECH. INC.  
1145=Japan Radio Company  
1145:0001=AirH PHONE AH-J3001V/J3002V  
1146=Shimane Sanyo Industrial  
1147=Ever Great Electric Wire and Cable  
114B=Sphairon Access Systems GmbH  
114B:0022=NT1+ web USB  
114B:0110=Turbolink UB801R WLAN USB Adapter  
114B:0150=Turbolink UB801RE Wireless 802.11g 54Mbps Network Adapter [RTL8187]  
114B:0150:0100=Realtek RTL8187 Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
114C=Tinius Olsen Testing Machine  
114D=Alpha Imaging Technology  
114D:8000=USB Video Capture  
114D:8100=USB PC Sync Device  
114E:0001=Pro-face GPW-CB03  
114F=Wavecom  
115B=Salix Technology  
115E:F100=GSPDA Handheld  
1161:0022=A4Tech USB Port Mouse  
1162=Secugen  
1162:0100=Identix DFR2080 USB Bulk Mode  
1163=DeLorme Publishing  
1163:0100=Earthmate GPS  
1163:0200=Earthmate GPS (LT-20, LT-40)  
1163:2020=Earthmate GPS (PN-40)  
1164=YUAN High-Tech Development  
1164:0300=DVB2GO UB300 DVB-T USB2.0 Receiver  
1164:0601=HP Analog TV Tuner  
1164:0602=GOTVIEW DVD USB Deluxe Encoder  
1164:0612=GOTVIEW DVD2 XC USB Encoder  
1164:0622=GOTVIEW DVD2 FM USB Encoder  
1164:0900=TigerBird BMP837 USB2.0 WDM Encoder  
1164:0BC7=Digital TV Tuner  
1164:1E8C=YUAN MC872 Dual DVB-T Tuner  
1164:1EFC=YUAN MC770A DVB-T/Analog Hybrid Tuner  
1164:1EFE=YUAN MC770A DVB-T/Analog Hybrid Tuner  
1164:1F06=YUAN MC770A DVB-T/Analog Hybrid Tuner  
1164:1F08=YUAN MC770A DVB-T/Analog Hybrid Tuner  
1164:2EDC=YUAN MC872-1D/MC872 DVB-T Tuner  
1164:2EFC=YUAN MC570QA ATSC/Analog Hybrid Tuner  
1164:2EFE=YUAN MC570QA ATSC/Analog Hybrid Tuner  
1164:2F06=YUAN MC570QA ATSC/Analog Hybrid Tuner  
1164:2F08=YUAN MC570QA ATSC/Analog Hybrid Tuner  
1164:3EDC=YUAN MC378H/AS378 DVB-T Tuner  
1164:521B=MC521A mini Card ATSC Tuner  
1164:6601=Digital TV Tuner Card [RTL2832U]  
1165=Telson Electronics  
1166=Bantam Interactive Technologies  
1167=Salient Systems  
1168=BizConn International

116E=Gigastorage  
116F=Silicon 10 Technology  
116F:0005=Flash Card Reader  
116F:C108=Flash Card Reader  
116F:C109=Flash Card Reader  
1175=Shengyih Steel Mold  
117D=Santa Electronic  
117E=JNC  
117F:3101=Princeton USB Bluetooth Adapter  
117F:3102=Princeton USB Bluetooth Adapter  
117F:3103=Princeton USB Bluetooth Adapter (PTM-UBT3)  
1182=Venture  
1182:1388=VES USB Sync  
1183=Digital Dream  
1183:0001=DigitalDream l'espion XS  
1183:19C7=ISDN TA  
1183:4008=Compaq 56K USB External Fax Modem  
1183:4008:02=Compaq USB Modem  
1183:504A=PJB-100 Personal Jukebox  
1184=Kyocera Elco  
1188=Bloomberg L.P.  
1188:03EE=Bloomberg Keyboard Comm Device (VID1188\_PID03EE\_V84)  
1189=Trisat Industrial  
1189:0893=EP-1427X-2 Ethernet Adapter  
1189:6000=USB Optical Storage Device  
1189:6001=USB Optical Storage Device  
1189:6002=USB Optical Storage Device  
1189:6003=USB Optical Storage Device  
1189:6004=USB Optical Storage Device  
1189:6005=USB Optical Storage Device  
1189:6006=USB Optical Storage Device  
1189:6007=USB Optical Storage Device  
118F=You Yang Technology  
1190=Tripace  
1191=Loyalty Founder Enterprise  
1196=Yankee Robotics, LLC  
1196:0010=Trifid Camera without code  
1196:0011=Trifid Camera  
1197=Technoimagia  
1198=StarShine Technology  
1199=Sierra Wireless  
1199:0019=AC595U  
1199:0021=AC597E  
1199:0024=MC5727 CDMA modem  
1199:0110=Composite Device  
1199:0112=CDMA 1xEVDO PC Card, AirCard 580  
1199:0120=AC595U  
1199:0218=MC5720 Wireless Modem  
1199:0220=Sierra Wireless MC5725 Device  
1199:0FFF=Sierra Wireless TRU-Install  
1199:6467=Sierra Wireless MP Series Network Adapter  
1199:6468=Sierra Wireless MP Series Network Adapter  
1199:6469=Sierra Wireless MP Series Network Adapter  
1199:6802=Sierra Wireless MC8755 Device  
1199:6803=Sierra Wireless MC8765 Device  
1199:6804=Sierra Wireless MC8755 Device  
1199:6805=Sierra Wireless MC8765 Device  
1199:6812=Sierra Wireless MC8775 Device  
1199:6813=Sierra Wireless MC8775 Device  
1199:6820=Sierra Wireless AC875 Device

1199:6821=Sierra Wireless AC875U Device  
1199:6822=Sierra Wireless AC875E Device  
1199:6832=Sierra Wireless MC8780 Device  
1199:6833=Sierra Wireless MC8781 Device  
1199:683A=Sierra Wireless MC8785 Device  
1199:683B=Sierra Wireless HSPA Device  
1199:683B:01=Sierra Wireless HSPA Device  
1199:683B:02=Sierra Wireless HSPA Device  
1199:683B:03=Sierra Wireless HSPA Device  
1199:683B:04=Sierra Wireless HSPA Device  
1199:683B:05=Sierra Wireless HSPA Device  
1199:683B:06=Sierra Wireless HSPA Device  
1199:683C=Sierra Wireless HSPA Device  
1199:683C:01=Sierra Wireless HSPA Device  
1199:683C:02=Sierra Wireless HSPA Device  
1199:683C:03=Sierra Wireless HSPA Device  
1199:683C:04=Sierra Wireless HSPA Device  
1199:683C:05=Sierra Wireless HSPA Device  
1199:683C:06=Sierra Wireless HSPA Device  
1199:683D=Sierra Wireless HSPA Device  
1199:683D:01=Sierra Wireless HSPA Device  
1199:683D:02=Sierra Wireless HSPA Device  
1199:683D:03=Sierra Wireless HSPA Device  
1199:683D:04=Sierra Wireless HSPA Device  
1199:683D:05=Sierra Wireless HSPA Device  
1199:683D:06=Sierra Wireless HSPA Device  
1199:683E=Sierra Wireless HSPA Device  
1199:6840=Sierra Wireless HSPA Device  
1199:6840:01=Sierra Wireless HSPA Device  
1199:6840:02=Sierra Wireless HSPA Device  
1199:6840:03=Sierra Wireless HSPA Device  
1199:6840:07=Sierra Wireless HSPA Network Adapter  
1199:6850=Sierra Wireless AirCard 880 Device  
1199:6851=Sierra Wireless AirCard 881 Device  
1199:6852=Sierra Wireless AirCard 880E Device  
1199:6853=Sierra Wireless AirCard 881E Device  
1199:6854=Sierra Wireless AirCard 885 Device  
1199:6855=Sierra Wireless AirCard 880U Device  
1199:6856=Sierra Wireless AirCard 881U Device  
1199:6857=Sierra Wireless AirCard 885U Device  
1199:6858=Sierra Wireless HSPA Device  
1199:6859=Sierra Wireless HSPA Device  
1199:6859:01=Sierra Wireless HSPA Device  
1199:6859:02=Sierra Wireless HSPA Device  
1199:6859:03=Sierra Wireless HSPA Device  
1199:6859:04=Sierra Wireless HSPA Device  
1199:6859:05=Sierra Wireless HSPA Device  
1199:6859:06=Sierra Wireless HSPA Device  
1199:685A=Sierra Wireless HSPA Device  
1199:685A:01=Sierra Wireless HSPA Device  
1199:685A:02=Sierra Wireless HSPA Device  
1199:685A:03=Sierra Wireless HSPA Device  
1199:685A:04=Sierra Wireless HSPA Device  
1199:685A:05=Sierra Wireless HSPA Device  
1199:685A:06=Sierra Wireless HSPA Device  
1199:6870=Sierra Wireless MC8780 Device  
1199:6871=Sierra Wireless MC8781 Device  
1199:6880=Sierra Wireless HSPA Device  
1199:6880:01=Sierra Wireless HSPA Device  
1199:6880:02=Sierra Wireless HSPA Device

1199:6880:03=Sierra Wireless HSPA Device  
1199:6880:04=Sierra Wireless HSPA Device  
1199:6880:05=Sierra Wireless HSPA Device  
1199:6880:06=Sierra Wireless HSPA Device  
1199:6881=Sierra Wireless HSPA Device  
1199:6881:01=Sierra Wireless HSPA Device  
1199:6881:02=Sierra Wireless HSPA Device  
1199:6881:03=Sierra Wireless HSPA Device  
1199:6881:04=Sierra Wireless HSPA Device  
1199:6881:05=Sierra Wireless HSPA Device  
1199:6881:06=Sierra Wireless HSPA Device  
1199:6882=Sierra Wireless HSPA Device  
1199:6882:01=Sierra Wireless HSPA Device  
1199:6882:02=Sierra Wireless HSPA Device  
1199:6882:03=Sierra Wireless HSPA Device  
1199:6882:04=Sierra Wireless HSPA Device  
1199:6882:05=Sierra Wireless HSPA Device  
1199:6882:06=Sierra Wireless HSPA Device  
1199:6890=Sierra Wireless HSPA Device  
1199:6890:01=Sierra Wireless HSPA Device  
1199:6890:02=Sierra Wireless HSPA Device  
1199:6890:03=Sierra Wireless HSPA Device  
1199:6890:04=Sierra Wireless HSPA Device  
1199:6890:05=Sierra Wireless HSPA Device  
1199:6890:06=Sierra Wireless HSPA Device  
1199:6891=Sierra Wireless HSPA Device  
1199:6891:01=Sierra Wireless HSPA Device  
1199:6891:02=Sierra Wireless HSPA Device  
1199:6891:03=Sierra Wireless HSPA Device  
1199:6891:04=Sierra Wireless HSPA Device  
1199:6891:05=Sierra Wireless HSPA Device  
1199:6891:06=Sierra Wireless HSPA Device  
1199:6892=Sierra Wireless HSPA Device  
1199:6893=Sierra Wireless HSPA Device  
1199:6893:01=Sierra Wireless HSPA Device  
1199:6893:02=Sierra Wireless HSPA Device  
1199:6893:03=Sierra Wireless HSPA Device  
1199:6893:04=Sierra Wireless HSPA Device  
1199:6893:05=Sierra Wireless HSPA Device  
1199:6893:06=Sierra Wireless HSPA Device  
1199:68A3=Sierra Wireless HSPA Device  
1199:68A3:01=Sierra Wireless HSPA Device  
1199:68A3:02=Sierra Wireless HSPA Device  
1199:68A3:03=Sierra Wireless HSPA Device  
1199:68A3:04=Sierra Wireless HSPA Device  
1199:68A3:05=Sierra Wireless HSPA Device  
1199:68A3:06=Sierra Wireless HSPA Device  
1199:68A3:07=Sierra Wireless HSPA Network Adapter  
1199:68A3:0A=Sierra Wireless HSPA Network Adapter  
1199:68A3:0B=Sierra Wireless HSPA Network Adapter  
1199:9000=Gobi 2000 Wireless Modem (QDL mode)  
1199:9001=Gobi 2000 Wireless Modem  
1199:9002=Gobi 2000 Wireless Modem  
1199:9003=Gobi 2000 Wireless Modem  
1199:9004=Gobi 2000 Wireless Modem  
1199:9005=Gobi 2000 Wireless Modem  
1199:9006=Gobi 2000 Wireless Modem  
1199:9007=Gobi 2000 Wireless Modem  
1199:9008=Gobi 2000 Wireless Modem  
1199:9009=Gobi 2000 Wireless Modem

1199:900A=Gobi 2000 Wireless Modem  
119A=ZHAN QI Technology  
119B=ruwido austria GmbH  
119B:0400=Infrared Keyboard V2.01  
11A0=Chipcon AS  
11A0:EB11=CC2400EB 2.0 ZigBee Sniffer  
11A3=Technovas  
11A3:8031=MP3 Player  
11A3:8032=MP3 Player  
11A8=Hoeft & Wessel AG  
11AA=GlobalMedia Group, LLC  
11AA:1518=iREZ K2  
11AB=Exitto Electronics  
11AF=Valence Semiconductor  
11B0=ATECH FLASH TECHNOLOGY  
11B0:6566=PRO-Gear XM-4U USB Mass Storage Controller  
11B0:6788=PRO-Gear SOLO USB Mass Storage Controller  
11B1=New Motion Tec.  
11C0=Sanmos Microelectronics  
11C5=Inmax  
11C5:0521=IMT-0521 Smartcard Reader  
11C8=Fullcom Technology  
11C9=Monster Cable Products  
11CF=Nemoto Kyorindo  
11D6=FUJIFILM AXIA  
11D9=Itronix  
11D9:1002=Rugged Pocket PC 2003  
11D9:1003=Rugged Pocket PC 2003  
11D9:2600=Itronix Bluetooth Device  
11DB=Topfield  
11DB:1000=PVR  
11DB:1100=PVR  
11E5=CHUFON Technology  
11E6=K.I. Technology  
11E7=Rockford  
11E8=NAAT Technology  
11E9=Wincan Technology  
11E9:1004=MP3 Flash Stick  
11EA=PAN RAM International  
11EB=VTech Innovation L.P. dba Advanced American Telephones  
11EC=Hitachi Computer Peripherals  
11EF=Cableplus Industrial  
11F5=Siemens Mobile Phones  
11F5:0001= SX1  
11F5:0003=Siemens Mobile Phone USB Modem  
11F5:0003:01=Siemens Mobile Phone USB Modem (Debug)  
11F5:0004=X75  
11F5:0004:01=Siemens Mobile Phone USB Modem  
11F5:0005=BenQ Siemens Mobile Phone  
11F5:0005:01=BenQ Siemens Diagnostics Interface  
11F5:0005:02=BenQ Siemens NMEA Device  
11F5:0006=Siemens Mobile Phone USB Modem  
11F5:0006:01=Siemens Mobile Phone USB Modem (Debug)  
11F5:0007=Siemens Mobile Phone USB Modem  
11F5:0007:01=Siemens Mobile Phone USB Modem (Debug)  
11F5:0008=UMTS/HSDPA Data Card  
11F5:0815=Siemens Mobile Phone USB Modem  
11F5:1004=Siemens Mobile Phone USB Modem  
11F5:1004:01=Siemens Mobile Phone USB Modem (Debug)  
11F6=Prolific

11F6:2001=Willcom WSIM  
11F7=Alcatel (?)  
11F7:02DF=TD10 Mobile phone USB cable  
1202=KUK JE TONG SHIN  
1203=TSC Auto ID Technology  
1203:0140=TTP-245C  
1207:1000=Micro Medical Ltd MicroLoop  
1207:1001=Micro Medical Ltd MicroLab  
1207:1002=Micro Medical Ltd SuperSpiro  
1207:1003=Micro Medical Ltd Spiro USB  
1207:1004=Micro Medical Ltd Micro Plus  
1207:1005=Micro Medical Ltd Micro GP  
1207:1006=Micro Medical Ltd Micro DL  
1207:2001=Micro Medical Ltd Respiratory Endurance Measurement  
1207:2002=Micro Medical Ltd Respiratory Pressure Meter  
1207:200F=Micro Medical Ltd Respiratory Muscle Analyzer  
1207:3001=Micro Medical Ltd Micro CO  
1207:3002=Micro Medical Ltd Smoke Check  
1207:3003=Micro Medical Ltd Micro H2  
1207:3004=Micro Medical Ltd Printer Nox  
1207:3005=Micro Medical Ltd Baby CO  
1207:4001=Micro Medical Ltd Negative Expiratory Pressure System  
1207:4002=Micro Medical Ltd USB Rint  
1207:5001=Micro Medical Ltd Micro DiaryCard  
1207:6001=Micro Medical Ltd Pulse Trace PCA2  
1207:6002=Micro Medical Ltd Pocket PCA  
1209=InterBiometrics  
1209:1001=USB Hub  
1209:1002=USB Relais  
1209:1003=IBSecureCam-P  
1209:1004=IBSecureCam-O  
1209:1005=IBSecureCam-N  
120E=HUDSON SOFT  
120F=Magellan  
120F:524E=RoadMate 1475T  
120F:5260=Triton Handheld GPS Receiver (300/400/500/1500/2000)  
1210=DigiTech  
1210:001B=RP155 Guitar Multi-Effects Processor  
1210:001C=RP255 Guitar Multi-Effects Processor  
1210:25F4=WebCam SCB-0350M  
1210:25F5=MCNEX\_1.3M\_WebCam  
1210:2604=WebCam SCB-0380M  
1210:2614=WebCam SCB-1300M  
1217=Goyatek Technology  
1218=Geutebrueck GmbH  
1219=COMPAL COMMUNICATIONS  
121E=Jungsoft  
121E:3403=Muzio JM250 Audio Player  
1222:FACE:01=Tipro Keyboard  
1223=SKYCABLE ENTERPRISE.  
1229=EPO Science & Technology  
122F=Takasic  
1230=Chipidea-Microelectronica, S.A.  
1231=CHI MEI COMMUNICATION SYSTEMS  
1231:CE01=USB Sync 03  
1231:CE02=USB Sync 03  
1233=Denver Electronics  
1233:5677=FUSB200 mp3 player  
1234=Unknown  
1234:ED02=Emotiv EPOC Developer Headset Wireless Dongle



1235=Novation EMS  
1235:0001=ReMOTE Audio/XStation  
1235:0002=Speedio  
1235:0003=ReMOTE ZeRO SL  
1235:4661=ReMOTE25  
123B=De La Rue Systems Automatizacao  
123C=K-Won C & C  
123C:1006=MP3 Player  
123C:1007=MP3 Player  
1241=Packard Bell  
1241:1111=Packard Bell Mouse  
1241:1111:0100=Packard Bell IO-3UP USB Mouse  
1241:1122=Typhoon Stream Optical Mouse USB+PS/2  
1241:1155=USB Browser Mouse  
1241:1166=USB Browser Mouse  
1241:1177=F8E842-DL Mouse  
1241:1503=USB Keyboard  
1241:1503:01=USB Hot Keys  
1241:1603=GE 98709 Teclado  
1242=MAC SYSTEM  
124A=AirVast Technology  
124A:168B=PRISM3 WLAN Adapter  
124A:4017=PC-Chips 802.11b Adapter  
124A:4023=Blitz Wireless G USB Controller  
124B=NYKO Technologies  
124B:4D01=Airflo EX Joystick  
124C=MXI - Memory Experts International  
124C:3200=Stealth MXP 1GB  
1251=Iwaya  
1252=Nextway  
1253=Erebus  
125A=Shintake Sangyo  
125C=Apogee  
125C:0010=Alta series CCD  
125F=A-DATA Technology  
125F:312A=Superior S102  
125F:A91A=Portable HDD CH91  
125F:C81A=Flash drive  
125F:C93A=4GB Pen Drive  
1260=Standard Microsystems  
1260:EE22=Intersil ISL3887 [EZ-Connect 802.11g Adapter v3]  
1261=All Ring Tech  
1262=MICRO VISION  
1263=Opti Japan  
1264=Covidien Energy-based Devices  
1266=Pirelli Broadband Solutions  
1266:6302=Fastweb DRG A226M ADSL Router  
1266:CB01=Access Gateway USB Network Interface  
1267=A4Tech  
1267:0103=G-720 Keyboard  
1267:0201=A4Tech USB Port Mouse  
1267:0210=PC Line PCL-SB1 USB Mouse  
1267:0210:2270=USB Human Interface Device  
1267:1111=USB Optical Mouse M-62WUP  
1267:A001=JP260 PC Game Pad  
1267:C002=Wireless Optical Mouse  
126B=Veridian Systems  
126C=Aristocrat Technologies  
126D=Bel Stewart  
126E=Strobe Data

126F=TwinMOS Technologies  
126F:1325=Mobile Disk  
126F:2168=Mobile Disk III  
126F:A006=G240  
1270=Procomp Informatics  
1271=Foxda Technology Industrial (Shenzhen)  
1272=Linear Technology  
1274=Ensoniq  
1275=Xaxero Marine Software Engineering  
1275:0002=WeatherFax 2000 Demodulator  
1275:0080=SkyEye Weather Satellite Receiver  
1278=Starlight Xpress  
1278:0105=SXV-M5  
1278:0107=SXV-M7  
1278:0109=SXV-M9  
1278:0110=SXVF-H16  
1278:0115=SXVF-H5  
1278:0119=SXV-H9  
1278:0135=SXVF-H35  
1278:0136=SXVF-H36  
1278:0200=SXV interface for paraller MX cameras  
1278:0305=SXV-M5C  
1278:0307=SXV-M7C  
1278:0319=SXV-H9C  
1278:0325=SXV-M25C  
1278:0326=SXVR-M26C  
1278:0507=Lodestar autoguider  
1278:0517=CoStar  
1280=Animeta Systems  
1281=Gean Sen Electronic  
1283=zebris Medical GmbH  
1283:0100=USB-RS232 Adaptor  
1283:0110=CMS20  
1283:0111=CMS 10  
1283:0112=CMS 05  
1283:0114=ARCUS digma PC-Interface  
1283:0115=SAM Axioquick recorder  
1283:0116=SAM Axioquick recorder  
1283:0120=emed-X  
1283:0121=emed-AT  
1283:0130=PDM  
1283:0150=CMS10GI (Golf)  
1286=MARVELL SEMICONDUCTOR  
1286:1FA8=Marvell Libertas 802.11a/g/b Wireless LAN Client Adapter - USB  
1286:1FAA=Marvell Libertas 802.11g/b Wireless LAN Client Adapter - USB  
1286:1FAB=88W8338 [Libertas] 802.11g  
1286:1FAC=Marvell Libertas 802.11g/b Wireless LAN Client Adapter - USB P2  
1286:2001=88W8388 802.11a/b/g WLAN  
1286:2006=Marvell TOPDOG 802.11n WLAN Client Adaptors - USB  
1286:8001=BLOB boot loader firmware  
1291=Flarion Technologies  
1291:0010=FDM 2xxx Flash-OFDM modem  
1291:0011=LR7F06/LR7F14 Flash-OFDM modem  
1292=Fire International  
1292:0258=Creative Labs VoIP Blaster  
1293=Belkin  
1293:0002=F5U002 Parallel Port [uss720]  
1293:2101=104-key keyboard  
1294=RISO KAGAKU  
129B=CyberTAN Technology

129B:160B=Siemens S30853-S1031-R351 802.11g Wireless Adapter [Atheros AR5523]  
129B:160C=Gigaset USB Stick 108  
129B:1666=Generic IEEE802.11g Wireless LAN  
129B:1667=Generic IEEE802.11g Wireless LAN  
129B:1828=Gigaset USB Adapter 300  
129C=Min Aik Technology  
129D=Yueqing Longhua Electronics Factory  
12A3=KENT WORLD  
12A4=Guangdong Matsunichi Communications Technology  
12A7=Trendchip Technologies  
12AB=Honey Bee Electronic International  
12AD=Asahi Seiko  
12B2=DICKSON Company  
12B3=Megaforce Company  
12B8=Zhejiang Xinya Electronic Technology  
12B9=Freehand Systems  
12BA=Sony Computer Entertainment America  
12BA:0100=RedOctane Guitar for PlayStation(R)3  
12BA:0120=RedOctane Drum Kit for PlayStation(R)3  
12BA:0200=Harmonix Guitar for PlayStation(R)3  
12BA:0210=Harmonix Drum Kit for PlayStation(R)3  
12BD=Sun Light Application  
12C4=Autocue Group  
12C4:0006=Teleprompter Two-button Hand Control (v1)  
12C4:0008=Teleprompter Foot Control (v1)  
12C7:2000=HST USB Smart Card Reader  
12C9=Newmen Technology  
12D1=Huawei Technologies  
12D1:1001=HUAWEI Mobile Connect - 3G Modem  
12D1:1001:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1001:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1001:05=HUAWEI Mobile Connect - 3G PC Voice Interface  
12D1:1003=HUAWEI Mobile Connect - 3G Modem  
12D1:1003:01=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1004=HUAWEI Mobile Connect - 3G Modem  
12D1:1004:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1004:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1004:03=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1009=U120  
12D1:1010=ETS2252+ CDMA Fixed Wireless Terminal  
12D1:1035=U8120  
12D1:1037=Ideos  
12D1:1038=Ideos  
12D1:1039=Ideos (tethering mode)  
12D1:1401=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1401:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1401:03=HUAWEI Mobile Connect - 3G Network Card  
12D1:1402=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1402:02=HUAWEI Mobile Connect - 3G Modem  
12D1:1402:03=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1403=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1403:01=HUAWEI Mobile Connect - 3G Network Card  
12D1:1403:02=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1403:03=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1405=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1405:02=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1405:03=HUAWEI Mobile Connect - 3G Network Card  
12D1:1406=HUAWEI Mobile Connect - 3G Modem  
12D1:1406:01=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1406:02=HUAWEI Mobile Connect - USB Smart Card Reader

12D1:1408=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1408:02=HUAWEI Mobile Connect - 3G Network Card  
12D1:1409=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1409:01=HUAWEI Mobile Connect - 3G GPS Interface  
12D1:1409:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1409:03=HUAWEI Mobile Connect - 3G Network Card  
12D1:140A=HUAWEI Mobile Connect - 3G Modem  
12D1:140A:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:140A:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:140A:03=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:140B=HUAWEI Mobile Connect - Modem  
12D1:140B:01=HUAWEI Mobile Connect - Application Interface  
12D1:140B:02=HUAWEI Mobile Connect - PC UI Interface  
12D1:140C=HUAWEI Mobile Connect - 3G Modem  
12D1:140C:01=HUAWEI Mobile Connect - 3G Network Card  
12D1:140C:02=HUAWEI Mobile Connect - 3G Application Interface  
12D1:140C:03=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:140E=HUAWEI Mobile Connect - 3G Network Card  
12D1:140E:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:140E:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:140E:03=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1411=HUAWEI Mobile Connect - 3G Modem  
12D1:1411:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1411:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1411:03=HUAWEI TV Partner - TV Tuner Device  
12D1:1411:04=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1412=HUAWEI Mobile Connect - 3G Modem  
12D1:1412:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1412:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1412:04=HUAWEI Mobile Connect - 3G GPS Interface  
12D1:1412:05=HUAWEI Mobile Connect - 3G PC Voice Interface  
12D1:1413=HUAWEI Mobile Connect - 3G Modem  
12D1:1413:01=HUAWEI Mobile Connect - 3G Network Card  
12D1:1413:02=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1413:03=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1413:04=HUAWEI Mobile Connect - 3G GPS Interface  
12D1:1413:07=HUAWEI Mobile Connect - 3G PC Voice Interface  
12D1:1414=HUAWEI Mobile Connect - 3G Modem  
12D1:1414:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1414:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1414:05=HUAWEI Mobile Connect - 3G GPS Interface  
12D1:1414:06=HUAWEI Mobile Connect - 3G PC Voice Interface  
12D1:1415=HUAWEI Mobile Connect - 3G Network Card  
12D1:1415:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1415:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1415:03=HUAWEI TV Partner - TV Tuner Device  
12D1:1415:04=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1416=HUAWEI Mobile Connect - 3G Modem  
12D1:1416:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1416:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1416:03=HUAWEI TV Partner - TV Tuner Device  
12D1:1416:04=HUAWEI Mobile Connect - 3G Network Card  
12D1:1416:05=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1417=HUAWEI Mobile Connect - 3G Modem  
12D1:1417:01=HUAWEI Mobile Connect - 3G Network Card  
12D1:1417:02=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1417:03=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1417:04=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1418=HUAWEI Mobile Connect - 3G Modem  
12D1:1418:01=HUAWEI Mobile Connect - 3G Application Interface

12D1:1418:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1418:05=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1418:06=HUAWEI Mobile Connect - 3G Network Card  
12D1:1419=HUAWEI Mobile Connect - 3G Modem  
12D1:1419:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1419:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1419:03=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1419:04=HUAWEI Mobile Connect - 3G GPS Interface  
12D1:1419:05=HUAWEI Mobile Connect - 3G Network Card  
12D1:141A=HUAWEI Mobile Connect - 3G Modem  
12D1:141A:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:141A:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:141B=HUAWEI Mobile Connect - 3G Modem  
12D1:141B:01=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:141C=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:141C:01=HUAWEI Mobile Connect - 3G Network Card  
12D1:141D=HUAWEI Mobile Connect - 3G Application Interface  
12D1:141D:01=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:141D:02=HUAWEI Mobile Connect - 3G Network Card  
12D1:141E=HUAWEI Mobile Connect - 3G Modem  
12D1:141E:01=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:141E:02=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:141F=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:141F:01=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:141F:02=HUAWEI Mobile Connect - 3G Network Card  
12D1:1420=HUAWEI Mobile Connect - 3G Modem  
12D1:1420:01=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1420:02=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1421=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1421:01=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1421:02=HUAWEI Mobile Connect - 3G Network Card  
12D1:1422=HUAWEI Mobile Connect - 3G Modem  
12D1:1422:01=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1422:02=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1422:03=HUAWEI Mobile Connect - USB Smart Card Reader  
12D1:1422:04=HUAWEI Mobile Connect - 3G Network Card  
12D1:1427=HUAWEI Mobile Connect - 3G Modem  
12D1:1427:01=HUAWEI Mobile Connect - 3G Network Card  
12D1:1427:02=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1427:03=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1427:04=HUAWEI Mobile Connect - 3G Interface  
12D1:1428=HUAWEI Mobile Connect - 3G Modem  
12D1:1428:02=HUAWEI Mobile Connect - 3G Application Interface  
12D1:1428:03=HUAWEI Mobile Connect - 3G PC UI Interface  
12D1:1428:06=HUAWEI Mobile Connect - 3G Network Card  
12D1:1446=E1552 (HSPA modem)  
12D1:1501=Pulse  
12D1:1505=E398 LTE/UMTS/GSM Modem/Networkcard  
12D1:1506=E398 LTE/UMTS/GSM Modem/Networkcard  
12D1:150A=E398 LTE/UMTS/GSM Modem/Networkcard  
12D1:1520=K3765 HSPA  
12D1:1521=K4505 HSPA+  
12D1:380B=WiMAX USB modem(s)  
12D2=LINE TECH INDUSTRIAL  
12D6=EMS Dr. Thomas Wuensche  
12D6:0444=CPC-USB/ARM7  
12D6:0888=CPC-USB/M16C  
12D7=BETTER WIRE FACTORY  
12D8=Araneus Information Systems Oy  
12D9=DIGITFAB INTERNATIONAL

12DD=Alec Electronics  
12DE=National Display Systems  
12E4=Bruel & Kjaer Sound & Vibration Meas. A/S  
12E6=Waldorf Music GmbH  
12E6:0013=Blofeld  
12E9=Mindspeed Technologies  
12EF=Tapwave  
12EF:0100=Tapwave Handheld [Tapwave Zodiac]  
12F4=Glovic Electronics  
12F5=Dynamic System Electronics  
12F7=Memorex Products  
12F7:1A00=TD Classic 003B  
12F7:1E23=TravelDrive 2007 Flash Drive  
12F9=RF-LINK SYSTEMS  
12FA=RF Micro Devices  
12FD=AIN Comm. Technology  
12FD:1001=AWU2000b 802.11b Stick  
12FE=E.U CONNECTOR(M) SDN BHD.  
12FF=Fascinating Electronics  
12FF:0101=Advanced RC Servo Controller  
1306=Torcon Instruments  
1307=USBest Technology  
1307:0163=512MB USB Flash Drive  
1307:0165=2GB/4GB Flash Drive  
1307:0190=Silicon Power Ultima 155 USB Flash Drive  
1307:0330=63-in-1 Multi-Card Reader/Writer  
1307:0361=CR-75: 51-in-1 Card Reader/Writer  
1307:0367=MultiCard reader 1.0  
1307:1169=TS2GJF210 JetFlash 210 2GB  
1307:1171=Fingerprint Reader  
1308=Shuttle  
1308:0003=VFD Module  
1308:C001=eHome Infrared Receiver (USBCIR)  
1310=Roper  
1310:0001=Air2U Bluetooth Device  
1310:0002=Broadcom ROM dongle  
1310:0003=Bluetooth EDR Dongle  
1312=ICS Electronics  
1317=PC-CRAFT  
1318=O'RITE TECHNOLOGY  
131D=Natural Point  
131D:0155=TrackIR 3 Pro Head Tracker  
131D:0156=TrackIR 4 Pro Head Tracker  
131F=Ayuttha Technology  
1323=Zeustech Company  
1324=H-Mod  
1329=Appairant Technologies  
132A=Envara  
132A:1502=WiND502 USB 2.0 Wireless Network Adapter  
132B=Konica Minolta Holdings  
132B:0000=Dimage A2 Camera  
132B:0001=Minolta DiMAGE A2 (ptp)  
132B:0003=Dimage Xg Camera  
132B:0005=KONICA\_MINOLTA DiMAGE Xg  
132B:0006=Dimage Z2 Camera  
132B:0007=Minolta DiMAGE Z2 (PictBridge mode)  
132B:0008=Dimage X21 Camera  
132B:000A=Minolta Scan Dual IV  
132B:000B=Dimage Z10 Camera  
132B:000D=Dimage X50 Camera [storage?]

132B:000F=KONICA\_MINOLTA DiMAGE X50  
132B:0010=Dimage G600 Camera  
132B:0012=Minolta Scan Elite 5400 2  
132B:0013=Dimage X31 Camera  
132B:0015=Dimage G530 Camera  
132B:0017=Dimage Z3 Camera  
132B:0018=Minolta DiMAGE Z3 (PictBridge mode)  
132B:0019=Dimage A200 Camera  
132B:0021=Dimage Z5 Camera  
132B:0022=Minolta DiMAGE Z5 (PictBridge mode)  
132B:002C=Dynax 5D camera  
132B:2001=Magicolor 2400w  
132B:2004=Magicolor 5430DL  
132B:2005=Magicolor 2430 DL  
132B:2016=KONICA MINOLTA 160 Scanner  
132B:2018=KONICA MINOLTA 161 Scanner  
132B:201A=KONICA MINOLTA 162 Scanner  
132B:201B=KONICA MINOLTA 162 PCL Scanner  
132B:201F=KONICA MINOLTA 180 Scanner  
132B:2020=KONICA MINOLTA 180 PCL Scanner  
132B:2022=KONICA MINOLTA 210 Scanner  
132B:2023=KONICA MINOLTA 210 PCL Scanner  
132B:2025=Generic 16BW-1/2 Scanner  
132B:2026=Generic 16BW-3 Scanner  
132B:2029=Magicolor 5440DL  
132B:202A=Generic 16BW-4 Scanner  
132B:202B=Generic 21BW-1 Scanner  
132B:202C=Generic 16BW-4 PCL Scanner  
132B:202E=Generic 21BW-1 PCL Scanner  
132B:2030=PagePro 1350E (N)  
132B:2033=PagePro 1400W  
132B:2043=Magicolor 2530DL  
132B:2045=Magicolor 2500W  
132B:2049=Magicolor 2490MF  
132C=Le Prestique International (H.K.)  
133B=FLASH SUPPORT GROUP  
133C=G-Design Technology  
1342=Sutter Instrument Company  
1342:0200=Mobility EasiDock 200 Hub  
1342:0201=Mobility EasiDock 200 Keyboard and Mouse Port  
1342:0202=Mobility EasiDock 200 Serial Port  
1342:0203=Mobility EasiDock 200 Printer Port  
1342:0204=Mobility USB-Ethernet Adapter  
1342:0304=EasiDock Ethernet  
1342:1001=Sutter Instrument Lambda 10-B  
1342:1002=Sutter Instrument Lambda SC  
1342:1003=Sutter Instrument Lambda 10-3  
1345=Sino Lite Technology  
1345:001C=Xbox Controller Hub  
1347=Moravian Instruments  
1347:0400=G2CCD USB 1.1 obsolete  
1347:0401=G2CCD-S with Sony ICX285 CCD  
1347:0402=G2CCD2  
1347:0403=G2/G3CCD-I KAI CCD  
1347:0404=G2/G3CCD-F KAF CCD  
1347:0410=G1-0400 CCD  
1347:0411=G1-0800 CCD  
1347:0412=G1-0300 CCD  
1347:0413=G1-2000 CCD  
1347:0414=G1-1400 CCD

1348=Katsuragawa Electric  
134C=PanJit International  
134C:0001=Touch Panel Controller  
134C:0002=Touch Panel Controller  
134C:0003=Touch Panel Controller  
134C:0004=Touch Panel Controller  
134E=Digby's Bitpile  
1356=Techpoint Electric Wire & Cable  
1357=P&E Microcomputer Systems  
1357:0001=Cyclone  
1357:0503=USB Multilink 2.0  
1357:0504=DEMOJM  
135B=M-System  
1366=SEGGGER  
1366:0101=J-Link ARM  
136A=Pelco  
136B=SimpleTech  
136C=Datastor Technology  
1370=Swissbit AG  
1370:0200=Swissbit Drive  
1370:0323=Swissmemory cirrusWHITE  
1370:2168=Swissbit Drive  
1370:6828=Swissbit Drive  
1371=Dick Smith Electronics  
1371:0001=CNUSB-611AR Wireless Adapter-G [AT76C503]  
1371:0002=WLAN 11Mbps USB ADAPTER-G  
1371:0013=CNUSB-611 Wireless Adapter [AT76C505]  
1371:0014=Wireless LAN 11Mbps USB Adapter  
1371:0019=CNet Wireless LAN 11Mbps USB Adapter V2  
1371:001A=Wireless-B USB Adapter  
1371:0021=Wireless-G USB Adapter  
1371:0022=Wireless-G USB Dongle  
1371:0023=Wireless-G USB Module  
1371:5743=WLAN 11Mbps USB ADAPTER  
1371:9022=RT2573  
1371:9032=CNet Wireless USB dongle  
1371:9401=CWD-854 Wireless 802.11g 54Mbps Network Adapter [RTL8187]  
1371:9401:0100=Realtek RTL8187 Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
1374=American Anko  
1375=TCL MOBILE COMMUNICATION  
1376=Vimtron Electronics  
137B=SCAPS GmbH  
137B:0002=SCAPS USC-2 Scanner Controller  
137C=Yaskawa Electric  
137D=Pericom Taiwan  
137E=XL Microwave  
1385=Netgear  
1385:4250=WG111T  
1385:4251=NETGEAR WG111T bootloader device  
1385:5F00=WPN111 RangeMax(TM) Wireless USB 2.0 Adapter  
1385:5F01=WPN111 (no firmware)  
1385:6E00=WPNT121 802.11g 240Mbps Wireless Adapter [Airgo AGN300]  
1389=Coolnection Technology  
138A=DigitalPersona  
138A:0001=Fingerprint Reader  
138A:0005=Validity Sensor (VFS301)  
138A:0007=VFS451 Fingerprint Reader  
138A:0008=Validity Sensor (VFS300)  
138A:0011=VFS5011 Fingerprint Reader  
138A:003C=VFS471 Fingerprint Reader



138E=Jungo  
138E:9000=Raisonance S.A. STM32 ARM evaluation board  
1390=TOMTOM B.V.  
1390:0001=GO 520 T  
1390:0001:0100=GO 950  
1391=IdealTEK  
1391:1000=USB Touch Controller  
1391:2000=USB Touch Controller  
1395=Sennheiser Communications A/S  
1395:3556=USB Headset  
1395:7471:0100=Best Data 56K USB External Fax Modem  
1396=Silicon Storage Technology  
1397=BEHRINGER International GmbH  
1397:00BC=BCF2000  
1398=Q-tec  
1398:2103=USB 2.0 Storage Device  
13A4=Equipment Systems & Devices  
13A5=Sammy  
13A6=Jeppesen Sanderson  
13A8=Grandtec Electronic  
13AD=Baltech  
13AD:9999=Card reader  
13B0=PerkinElmer Optoelectronics  
13B0:000A=Photon X25 MIDI Controller  
13B1=Cisco-Linksys, LLC  
13B1:000A=Linksys Wireless-G USB Network Adapter  
13B1:000B=WUSB11 v4.0 802.11b Adapter  
13B1:000C=WUSB54AG 802.11a/g Adapter [Intersil ISL3887]  
13B1:000D=Linksys Wireless-G USB Network Adapter  
13B1:000E=WUSB54GS v1 802.11g Adapter [Broadcom 4320 USB]  
13B1:0011=WUSB54GP v4.0 802.11g Adapter  
13B1:0013=Linksys Cable Gateway with 2 Phone Ports  
13B1:0014=WUSB54GS v2 802.11g Adapter [Broadcom 4320 USB]  
13B1:0018=USB200M 10/100 Ethernet Adapter  
13B1:0019=Linksys Bluetooth USB Adapter  
13B1:001A=HU200TS Wireless Adapter  
13B1:001E=WUSBF54G 802.11bg (zd1211rw)  
13B1:001F=Wireless-G Cable Gateway with 2 Phone Ports  
13B1:0020=WUSB54GC 802.11g Adapter [ralink rt73]  
13B1:0022=WUSB54GX4 802.11g 240Mbps Wireless Adapter [Airgo AGN300]  
13B1:0023=Wireless-G USB Network Adapter with RangeBooster  
13B1:0024=WUSBF54G v1.1 802.11g Adapter w/ Wi-Fi Finder  
13B1:0026=WUSB54GSC v1 802.11g Adapter [Broadcom 4320 USB]  
13B1:0028=WUSB200 [ralink rt73]  
13B1:0029=Wireless-N USB Network Adapter  
13B1:002F=AE1000 v1 802.11n [Ralink RT2870]  
13B1:0031=AM10 v1 802.11n [Ralink RT2870]  
13B1:0039=AE1200 802.11bgn Wireless Adapter [Broadcom BCM43235]  
13B1:003A=AE2500 802.11abgn Wireless Adapter [Broadcom BCM43236]  
13B1:13B1=WUSB200: Wireless-G Business Network Adapter with Rangebooster  
13B2=ALESIS  
13B2:0030=Multimix 8  
13B3=Nippon Dics  
13B8=PDM Electronic  
13BA=Unknown  
13BA:0017=PS/2 Keyboard+Mouse Adapter  
13BE=Hitachi Printing Solutions  
13BF=Accusys  
13C0=Stream Labs  
13C1=Vivitar

13C9=LinearX Systems  
13CA=Suzhou Jye Tai Precision Industrial  
13CB=JTEK Technology  
13CC=Cellvic  
13CF=Wisair  
13CF:1200=Olidata Wireless Multimedia Adapter  
13D0=Techsan Electronics  
13D0:2282=TechniSat DVB-PC TV Star 2  
13D1=A-MAX Technology  
13D1:7019=MD 82288  
13D1:ABE6=Wireless 802.11g 54Mbps Network Adapter [RTL8187]  
13D1:ABE6:0100=Realtek RTL8187 Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
13D2=Shark Multimedia  
13D2:0400=Pocket Ethernet [klsi]  
13D3=TwinHan Technology  
13D3:3201=TwinHan USB adapter firmware loader  
13D3:3202=USB DTT - USB DVB-T adapter  
13D3:3203=DTV-DVB UDST7020BDA DVB-S Box (DVBS for MCE2005)  
13D3:3204=DTV-DVB UDST7020BDA DVB-S Box (DVBS for MCE2005)  
13D3:3205=DTV-DVB USB2 DVB-T BDA adapter  
13D3:3206=DTV-DVB USB2 DVB-T BDA adapter  
13D3:3207=DTV-DVB UDST7020BDA DVB-S Box (DVBS for MCE2005)  
13D3:3208=DTV-DVB UDST7020BDA DVB-S Box (DVBS for MCE2005)  
13D3:3209=DTV-DVB UDST7022BDA DVB-S Box (Without HID)  
13D3:3211=Pinnacle PCTV 310e analog  
13D3:3211:03=Pinnacle PCTV 310e digital  
13D3:3212=DTV-DVB UDTT704C - DVBT/NTSC/PAL Driver (PCM4)  
13D3:3213=DTV-DVB UDTT704D - DVBT/NTSC/PAL Driver (PCM4)  
13D3:3214=DTV-DVB UDTT704F - (MiniCard) DVBT/NTSC/PAL Driver (Without HID)  
13D3:3215=DTV-DVB UDAT7240 - ATSC/NTSC/PAL Driver (PCM4)  
13D3:3216=DTV-DVB UDTT 7047-USB 2.0 DVB-T Driver  
13D3:3217=Digital-TV Receiver.  
13D3:3219=DTV-DVB UDTT7049 - DVB-T Driver (Without HID)  
13D3:3220=DTV-DVB UDTT 7047M-USB 2.0 DVB-T Driver  
13D3:3223=DNTV Live! Tiny USB2 BDA (With Remote)  
13D3:3224=DNTV Live! Tiny USB2 BDA (With Remote)  
13D3:3226=DigitalNow TinyTwin DVB-T Receiver  
13D3:3234=DVB-T FTA Half Minicard [RTL2832U]  
13D3:3236=DTV-DVB UDTT 7047A-USB 2.0 DVB-T Driver  
13D3:3237=DTV-DVB UDTT 704J - dual DVB-T Driver  
13D3:3239=DTV-DVB UDTT704D - DVBT/NTSC/PAL Driver (Without HID)  
13D3:3240=DTV-DVB UDXTTM6010 - A/D Driver (Without HID)  
13D3:3241=DTV-DVB UDXTTM6010 - A/D Driver (Without HID)  
13D3:3242=DTV-DVB UDAT7240LP - ATSC/NTSC/PAL Driver (Without HID)  
13D3:3243=DTV-DVB UDXTTM6010 - A/D Driver (Without HID)  
13D3:3244=DTV-DVB UDTT 7047Z-USB 2.0 DVB-T Driver  
13D3:3247=802.11 n/g/b Wireless LAN Adapter  
13D3:3248=Bluetooth 2.1 Module  
13D3:3249=Bluetooth 2.1 Module  
13D3:3250=Bluetooth 2.1 Module  
13D3:3255=Bluetooth 2.1 Module  
13D3:3256=Bluetooth 2.1 Module  
13D3:3257=Bluetooth 2.1 Module  
13D3:3262=802.11 n/g/b Wireless LAN USB Adapter  
13D3:3273=802.11 n/g/b Wireless LAN USB Mini-Card  
13D3:3274=DVB-T Dongle [RTL2832U]  
13D3:3282=DVB-T + GPS Minicard [RTL2832U]  
13D3:3284=Wireless LAN USB Mini-Card  
13D3:3286=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
13D3:3287=Bluetooth Module

13D3:3288=Bluetooth Module  
13D3:3295=Bluetooth Module  
13D3:3297=Broadcom Bluetooth 2.1 + EDR USB Device  
13D3:3298=Broadcom Bluetooth 2.1 + EDR USB Device  
13D3:3299=Broadcom Bluetooth 2.1 + EDR USB Device  
13D3:3300=Bluetooth module  
13D3:3301=Bluetooth module  
13D3:3302=Bluetooth module  
13D3:3303=Bluetooth Module  
13D3:3305=802.11 n/g/b Wireless LAN USB Mini-Card  
13D3:3306=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
13D3:3307=Wireless LAN USB Mini-Card  
13D3:3309=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
13D3:3309:0200=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
13D3:3310=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
13D3:3311=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
13D3:3313=Bluetooth module  
13D3:3314=Bluetooth Module  
13D3:3315=Bluetooth module  
13D3:3318=Broadcom BCM2070 Bluetooth 3.0 USB Device  
13D3:3319=Broadcom BCM2070 Bluetooth 3.0 USB Device  
13D3:3321=802.11 n/g/b Wireless LAN USB Mini-Card  
13D3:3322=802.11 n/g/b USB Wireless LAN Card  
13D3:3323=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
13D3:3325=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
13D3:3329=802.11n USB Wireless LAN Card  
13D3:3331=Bluetooth Module  
13D3:3333=Realtek RTL8191SU Wireless LAN 802.11n USB 2.0 Network Adapter  
13D3:3334=Realtek RTL8188SU Wireless LAN 802.11n USB 2.0 Network Adapter  
13D3:3335=Realtek RTL8191SU Wireless LAN 802.11 USB 2.0 Network Adapter  
13D3:3336=Realtek RTL8188SU Wireless LAN 802.11 USB 2.0 Network Adapter  
13D3:3339=Realtek RTL8188SU Wireless LAN 802.11n USB 2.0 Network Adapter  
13D3:3339:0200=Realtek RTL8188SU Wireless LAN 802.11n USB 2.0 Network Adapter  
13D3:3340=Realtek RTL8188SU Wireless LAN 802.11 USB 2.0 Network Adapter  
13D3:3340:0200=Realtek RTL8188SU Wireless LAN 802.11 USB 2.0 Network Adapter  
13D3:3341=Realtek RTL8191SU Wireless LAN 802.11 USB 2.0 Network Adapter  
13D3:3341:0200=Realtek RTL8191SU Wireless LAN 802.11 USB 2.0 Network Adapter  
13D3:3342=Realtek RTL8188SU Wireless LAN 802.11 USB 2.0 Network Adapter  
13D3:3357=Wireless USB Card  
13D3:3358=Realtek RTL8188CE-VAU Wireless LAN 802.11n USB minicard  
13D3:3359=Realtek RTL8188CE-VAU Wireless LAN 802.11 USB minicard  
13D3:5070=Webcam  
13D3:5082=USB2.0 UVC 1.3M WebCam  
13D3:5101=USB2.0 UVC 3M WebCam  
13D3:5102=USB2.0 UVC 1.3M WebCam  
13D3:5104=USB2.0 UVC 1.3M WebCam  
13D3:5105=USB2.0 UVC 1.3M WebCam  
13D3:5106=USB2.0 UVC 1.3M WebCam  
13D3:5108=USB2.0 UVC VGA WebCam  
13D3:5109=USB2.0 UVC VGA WebCam  
13D3:5111=Integrated Webcam  
13D3:5113=USB2.0 UVC 1.3M WebCam  
13D3:5114=USB2.0 UVC 1.3M WebCam  
13D3:5115=Integrated Webcam  
13D3:5116=Integrated Webcam  
13D3:5118=USB2.0 UVC VGA WebCam  
13D3:5120=USB2.0 UVC VGA WebCam  
13D3:5121=USB2.0 UVC 1M HD WebCam  
13D3:5122=USB2.0 UVC 2M WebCam  
13D3:5124=USB2.0 UVC VGA WebCam

13D3:5125=USB2.0 UVC VGA WebCam  
13D3:5127=USB2.0 UVC VGA WebCam  
13D3:5128=USB2.0 UVC VGA WebCam  
13D3:5129=USB2.0 UVC VGA WebCam  
13D3:5130=USB2.0 UVC VGA WebCam  
13D3:5131=USB2.0 UVC 1M HD WebCam  
13D3:5132=USB2.0 UVC VGA WebCam  
13D3:5133=USB2.0 UVC 1.3M WebCam  
13D3:5702=USB2.0 UVC VGA WebCam  
13D3:7020=DTV-DVB UDST7020BDA DVB-S Box(DVBS for MCE2005)  
13D3:7022=DTV-DVB UDST7022BDA DVB-S Box(Without HID)  
13DC=ALEREON  
13DD=i.Tech Dynamic  
13DD:0001=I.Tech Dynamic Bluetooth Device  
13DE=LANKOM ELECTRONICS  
13DF=Good Fancy Enterprise  
13E0=Taiwan Silicon Electronics  
13E1=Kaibo Wire & Cable (Shenzhen)  
13E2:0020=USB2SER  
13E2:0021=Board of Education USB  
13E2:0022=Propeller Plug/Clip  
13E2:0040=USB to Serial Adapter  
13E2:0041=Parallax BASIC Stamp Device  
13E2:0042=Propeller Demo Brd  
13E2:0060=Propeller Servo Controller  
13E2:0061=Parallax BASIC Stamp Device  
13E2:0062=PropStick USB  
13E2:0080=PropScope  
13E2:0081=Parallax BASIC Stamp Device  
13E2:0082=Propeller Proto Brd USB  
13E2:00A0=Parallax USB Device  
13E2:00A2=Propeller Prof Dev Brd  
13E2:00C0=Parallax USB Device  
13E2:00C2=Propeller Robot Control Brd  
13E2:00E0=Parallax USB Device  
13E2:00E2=Parallax Propeller Device  
13E2:0102=Parallax Propeller Device  
13E2:0122=Parallax Propeller Device  
13E5=Rane  
13E5:0001=SL-1  
13E5:0003=TTM 57SL  
13E6=TechnoScope  
13E8:0600=PalmSource Handheld  
13E8:FF00=PalmSource Handheld  
13EA=I/F - COM A/S  
13EA:0001=C-56 Thermal Printer  
13EC=Zydacron  
13EC:0006=HID Remote Control  
13EC:000A=Infra Red Remote Control Receiver Unit  
13EC:0034=Broadcom Bluetooth 2.1 + EDR USB Device  
13EE=MosArt  
13EE:0003=Optical Mouse  
13F4=Verisity Design  
13F6=Aspen Touch Solutions  
13F7=Corevalley  
13F8=EZPnP Technologies  
13FD=Initio  
13FD:0840=INIC-1618L USB to SATA Bridge  
13FD:0841=Samsung SE-T084M DVD-RW  
13FD:1340=Hi-Speed USB to SATA Bridge

13FD:160F=RocketFish SATA Bridge [INIC-1611]  
13FD:1640=ASUS SDRW-08D1S-U DVD-RW  
13FD:1840=Shintaro SH23SDOCK Hard Drive Docker [INIC-1608L]  
13FE=Phison Electronics  
13FE:1A00=512MB/1GB Flash Drive  
13FE:1A20=USB DISK Pro  
13FE:1A23=512MB Flash Drive  
13FE:1D00=DataTraveler 2.0 1GB/4GB Flash Drive  
13FE:1E00=Flash Drive 2 GB [ICIDU 2 GB]  
13FE:1F00=Data Traveler 2.0 Pen Drive  
13FE:1F00:0110=Data Traveler 2.0 Pen Drive  
13FE:2240=microSD card reader  
13FE:3100=2 GB USB stick  
13FE:3200=Pen Drive Mini 2.0 4GB  
13FE:3800=Rage XT Flash Drive  
13FF=VIEWCON ELECTRONIC  
1400=Axxion Group  
1401=Fullhua Microelectronics  
1402=Bowe Bell & Howell  
1403=Sitronix Technology  
1403:0001=Digital Photo Frame  
140E=Telechips  
140E:B011=TCC780X-based player (USB Boot mode)  
140E:B021=TCC77X-based players (USB Boot mode)  
1410=Novatel Wireless  
1410:0001=Novatel Wireless Modem  
1410:0001:01=Novatel Wireless Status Port  
1410:0001:02=Novatel Wireless Diagnostics Port  
1410:0001:03=Novatel Wireless Application Port  
1410:0002=Novatel Wireless Modem  
1410:0002:01=Novatel Wireless Status Port  
1410:0002:02=Novatel Wireless Diagnostics Port  
1410:0002:03=Novatel Wireless Application Port  
1410:0003=Novatel Wireless Modem  
1410:0003:01=Novatel Wireless Status Port  
1410:0003:02=Novatel Wireless Diagnostics Port  
1410:0003:03=Novatel Wireless Application Port  
1410:0004=Novatel Wireless Modem  
1410:0004:01=Novatel Wireless Status Port  
1410:0004:02=Novatel Wireless Diagnostics Port  
1410:0004:03=Novatel Wireless Application Port  
1410:1000=Novatel Wireless Merlin CDMA 1X Modem  
1410:1000:01=Novatel Wireless Merlin CDMA 1X Status Port  
1410:1000:02=Novatel Wireless Merlin CDMA 1X Diagnostics Port  
1410:1000:03=Novatel Wireless Merlin CDMA 1X GPS Port  
1410:1010=Novatel Wireless Merlin CDMA 1X Modem  
1410:1010:01=Novatel Wireless Merlin CDMA 1X Status Port  
1410:1010:02=Novatel Wireless Merlin CDMA 1X Diagnostics Port  
1410:1010:03=Novatel Wireless Merlin CDMA 1X GPS Port  
1410:1020=Novatel Wireless Merlin CDMA 1X Modem  
1410:1020:01=Novatel Wireless Merlin CDMA 1X Status Port  
1410:1020:02=Novatel Wireless Merlin CDMA 1X Diagnostics Port  
1410:1020:03=Novatel Wireless Merlin CDMA 1X GPS Port  
1410:1030=Novatel Wireless Merlin CDMA 1X Modem  
1410:1030:01=Novatel Wireless Merlin CDMA 1X Status Port  
1410:1030:02=Novatel Wireless Merlin CDMA 1X Diagnostics Port  
1410:1030:03=Novatel Wireless Merlin CDMA 1X GPS Port  
1410:1100=Novatel Wireless Merlin CDMA EV-DO Modem  
1410:1100:01=Novatel Wireless Merlin CDMA EV-DO Status Port  
1410:1100:02=Novatel Wireless Merlin CDMA EV-DO Diagnostics Port

1410:1100:03=Novatel Wireless Merlin CDMA EV-DO GPS Port  
1410:1110=Novatel Wireless Merlin CDMA EV-DO Modem  
1410:1110:01=Novatel Wireless Merlin CDMA EV-DO Status Port  
1410:1110:02=Novatel Wireless Merlin CDMA EV-DO Diagnostics Port  
1410:1110:03=Novatel Wireless Merlin CDMA EV-DO GPS Port  
1410:1120=Novatel Wireless Merlin CDMA EV-DO Modem  
1410:1120:01=Novatel Wireless Merlin CDMA EV-DO Status Port  
1410:1120:02=Novatel Wireless Merlin CDMA EV-DO Diagnostics Port  
1410:1120:03=Novatel Wireless Merlin CDMA EV-DO GPS Port  
1410:1130=Novatel Wireless Merlin CDMA EV-DO Modem  
1410:1130:01=Novatel Wireless Merlin CDMA EV-DO Status Port  
1410:1130:02=Novatel Wireless Merlin CDMA EV-DO Diagnostics Port  
1410:1130:03=Novatel Wireless Merlin CDMA EV-DO GPS Port  
1410:1140=Novatel Wireless Merlin CDMA EV-DO Modem  
1410:1140:01=Novatel Wireless Merlin CDMA EV-DO Status Port  
1410:1140:02=Novatel Wireless Merlin CDMA EV-DO Diagnostics Port  
1410:1140:03=Novatel Wireless Merlin CDMA EV-DO GPS Port  
1410:1200=Novatel Wireless Merlin EVDV Modem  
1410:1200:01=Novatel Wireless Merlin EVDV Status Port  
1410:1200:02=Novatel Wireless Merlin EV-DV Diagnostics Port  
1410:1200:03=Novatel Wireless Merlin EV-DV GPS Port  
1410:1210=Novatel Wireless Merlin EVDV Modem  
1410:1210:01=Novatel Wireless Merlin EVDV Status Port  
1410:1210:02=Novatel Wireless Merlin EV-DV Diagnostics Port  
1410:1210:03=Novatel Wireless Merlin EV-DV GPS Port  
1410:1220=Novatel Wireless Merlin EVDV Modem  
1410:1220:01=Novatel Wireless Merlin EVDV Status Port  
1410:1220:02=Novatel Wireless Merlin EV-DV Diagnostics Port  
1410:1220:03=Novatel Wireless Merlin EV-DV GPS Port  
1410:1230=Novatel Wireless Merlin EVDV Modem  
1410:1230:01=Novatel Wireless Merlin EVDV Status Port  
1410:1230:02=Novatel Wireless Merlin EV-DV Diagnostics Port  
1410:1230:03=Novatel Wireless Merlin EV-DV GPS Port  
1410:1300=Novatel Wireless Merlin UMTS Modem  
1410:1300:01=Novatel Wireless Merlin UMTS Status Port  
1410:1300:02=Novatel Wireless Merlin UMTS Diagnostics Port  
1410:1300:03=Novatel Wireless Merlin EAP-SIM Port  
1410:1310=Novatel Wireless Merlin UMTS Modem  
1410:1310:01=Novatel Wireless Merlin UMTS Status Port  
1410:1310:02=Novatel Wireless Merlin UMTS Diagnostics Port  
1410:1310:03=Novatel Wireless Merlin EAP-SIM Port  
1410:1320=Novatel Wireless Merlin UMTS Modem  
1410:1320:01=Novatel Wireless Merlin UMTS Status Port  
1410:1320:02=Novatel Wireless Merlin UMTS Diagnostics Port  
1410:1320:03=Novatel Wireless Merlin EAP-SIM Port  
1410:1330=Novatel Wireless Merlin UMTS Modem  
1410:1330:01=Novatel Wireless Merlin UMTS Status Port  
1410:1330:02=Novatel Wireless Merlin UMTS Diagnostics Port  
1410:1330:03=Novatel Wireless Merlin EAP-SIM Port  
1410:1400=Novatel Wireless Merlin HSDPA Modem  
1410:1400:01=Novatel Wireless Merlin HSDPA Status Port  
1410:1400:02=Novatel Wireless Merlin HSDPA Diagnostics Port  
1410:1400:03=Novatel Wireless Merlin EAP-SIM Port  
1410:1410=Novatel Wireless Merlin HSDPA Modem  
1410:1410:01=Novatel Wireless Merlin HSDPA Status Port  
1410:1410:02=Novatel Wireless Merlin HSDPA Diagnostics Port  
1410:1410:03=Novatel Wireless Merlin EAP-SIM Port  
1410:1420=Novatel Wireless Merlin HSDPA Modem  
1410:1420:01=Novatel Wireless Merlin HSDPA Status Port  
1410:1420:02=Novatel Wireless Merlin HSDPA Diagnostics Port

1410:1420:03=Novatel Wireless Merlin EAP-SIM Port  
1410:1430=Novatel Wireless Merlin HSDPA Modem  
1410:1430:01=Novatel Wireless Merlin HSDPA Status Port  
1410:1430:02=Novatel Wireless Merlin HSDPA Diagnostics Port  
1410:1430:03=Novatel Wireless Merlin EAP-SIM Port  
1410:1440=Novatel Wireless Merlin HSDPA Modem  
1410:1440:01=Novatel Wireless Merlin HSDPA Status Port  
1410:1440:02=Novatel Wireless Merlin HSDPA Diagnostics Port  
1410:1440:03=Novatel Wireless Merlin EAP-SIM Port  
1410:1440:04=Novatel Wireless Merlin HSDPA GPS Port  
1410:1450=Novatel Wireless Merlin HSDPA Modem  
1410:1450:01=Novatel Wireless Merlin HSDPA Status Port  
1410:1450:02=Novatel Wireless Merlin HSDPA Diagnostics Port  
1410:1450:03=Novatel Wireless Merlin EAP-SIM Port  
1410:1450:04=Novatel Wireless Merlin HSDPA GPS Port  
1410:1500=Novatel Wireless Merlin HSDPA Modem  
1410:1500:01=Novatel Wireless Merlin HSDPA Status Port  
1410:1500:02=Novatel Wireless Merlin HSDPA Diagnostics Port  
1410:1500:03=Novatel Wireless Merlin EAP-SIM Port  
1410:1500:04=Novatel Wireless Merlin HSDPA GPS Port  
1410:2000=Novatel Wireless Expedite CDMA 1X Modem  
1410:2000:01=Novatel Wireless Expedite CDMA 1X Status Port  
1410:2000:02=Novatel Wireless Expedite CDMA 1X Diagnostics Port  
1410:2000:03=Novatel Wireless Expedite CDMA 1X GPS Port  
1410:2010=Novatel Wireless Expedite CDMA 1X Modem  
1410:2010:01=Novatel Wireless Expedite CDMA 1X Status Port  
1410:2010:02=Novatel Wireless Expedite CDMA 1X Diagnostics Port  
1410:2010:03=Novatel Wireless Expedite CDMA 1X GPS Port  
1410:2020=Novatel Wireless Expedite CDMA 1X Modem  
1410:2020:01=Novatel Wireless Expedite CDMA 1X Status Port  
1410:2020:02=Novatel Wireless Expedite CDMA 1X Diagnostics Port  
1410:2020:03=Novatel Wireless Expedite CDMA 1X GPS Port  
1410:2030=Novatel Wireless Expedite CDMA 1X Modem  
1410:2030:01=Novatel Wireless Expedite CDMA 1X Status Port  
1410:2030:02=Novatel Wireless Expedite CDMA 1X Diagnostics Port  
1410:2030:03=Novatel Wireless Expedite CDMA 1X GPS Port  
1410:2100=Novatel Wireless Expedite EVDO Modem  
1410:2100:01=Novatel Wireless Expedite EVDO Status Port  
1410:2100:02=Novatel Wireless Expedite EV-DO Diagnostics Port  
1410:2100:03=Novatel Wireless Expedite EV-DO GPS Port  
1410:2110=Novatel Wireless Expedite EVDO Modem  
1410:2110:01=Novatel Wireless Expedite EVDO Status Port  
1410:2110:02=Novatel Wireless Expedite EV-DO Diagnostics Port  
1410:2110:03=Novatel Wireless Expedite EV-DO GPS Port  
1410:2120=Novatel Wireless Expedite EVDO Modem  
1410:2120:01=Novatel Wireless Expedite EVDO Status Port  
1410:2120:02=Novatel Wireless Expedite EV-DO Diagnostics Port  
1410:2120:03=Novatel Wireless Expedite EV-DO GPS Port  
1410:2130=Novatel Wireless Expedite EVDO Modem  
1410:2130:01=Novatel Wireless Expedite EVDO Status Port  
1410:2130:02=Novatel Wireless Expedite EV-DO Diagnostics Port  
1410:2130:03=Novatel Wireless Expedite EV-DO GPS Port  
1410:2200=Novatel Wireless Expedite EVDV Modem  
1410:2200:01=Novatel Wireless Expedite EVDV Status Port  
1410:2200:02=Novatel Wireless Expedite EV-DV Diagnostics Port  
1410:2200:03=Novatel Wireless Expedite EV-DV GPS Port  
1410:2210=Novatel Wireless Expedite EVDV Modem  
1410:2210:01=Novatel Wireless Expedite EVDV Status Port  
1410:2210:02=Novatel Wireless Expedite EV-DV Diagnostics Port  
1410:2210:03=Novatel Wireless Expedite EV-DV GPS Port

1410:2220=Novatel Wireless Expedite EVDV Modem  
1410:2220:01=Novatel Wireless Expedite EVDV Status Port  
1410:2220:02=Novatel Wireless Expedite EV-DV Diagnostics Port  
1410:2220:03=Novatel Wireless Expedite EV-DV GPS Port  
1410:2230=Novatel Wireless Expedite EVDV Modem  
1410:2230:01=Novatel Wireless Expedite EVDV Status Port  
1410:2230:02=Novatel Wireless Expedite EV-DV Diagnostics Port  
1410:2230:03=Novatel Wireless Expedite EV-DV GPS Port  
1410:2300=Novatel Wireless Expedite UMTS Modem  
1410:2300:01=Novatel Wireless Expedite UMTS Status Port  
1410:2300:02=Novatel Wireless Expedite UMTS Diagnostics Port  
1410:2300:03=Novatel Wireless Expedite UMTS EAP-SIM Port  
1410:2310=Novatel Wireless Expedite UMTS Modem  
1410:2310:01=Novatel Wireless Expedite UMTS Status Port  
1410:2310:02=Novatel Wireless Expedite UMTS Diagnostics Port  
1410:2310:03=Novatel Wireless Expedite UMTS EAP-SIM Port  
1410:2320=Novatel Wireless Expedite UMTS Modem  
1410:2320:01=Novatel Wireless Expedite UMTS Status Port  
1410:2320:02=Novatel Wireless Expedite UMTS Diagnostics Port  
1410:2320:03=Novatel Wireless Expedite UMTS EAP-SIM Port  
1410:2330=Novatel Wireless Expedite UMTS Modem  
1410:2330:01=Novatel Wireless Expedite UMTS Status Port  
1410:2330:02=Novatel Wireless Expedite UMTS Diagnostics Port  
1410:2330:03=Novatel Wireless Expedite UMTS EAP-SIM Port  
1410:2400=Novatel Wireless Expedite HSDPA Modem  
1410:2400:01=Novatel Wireless Expedite HSDPA Status Port  
1410:2400:02=Novatel Wireless Expedite HSDPA Diagnostics Port  
1410:2400:03=Novatel Wireless Expedite EAP-SIM Port  
1410:2410=Novatel Wireless Expedite HSDPA Modem  
1410:2410:01=Novatel Wireless Expedite HSDPA Status Port  
1410:2410:02=Novatel Wireless Expedite HSDPA Diagnostics Port  
1410:2410:03=Novatel Wireless Expedite EAP-SIM Port  
1410:2420=Novatel Wireless Expedite HSDPA Modem  
1410:2420:01=Novatel Wireless Expedite HSDPA Status Port  
1410:2420:02=Novatel Wireless Expedite HSDPA Diagnostics Port  
1410:2420:03=Novatel Wireless Merlin HSDPA GPS Port  
1410:2430=Novatel Wireless Expedite HSDPA Modem  
1410:2430:01=Novatel Wireless Expedite HSDPA Status Port  
1410:2430:02=Novatel Wireless Expedite HSDPA Diagnostics Port  
1410:2430:03=Novatel Wireless Merlin HSDPA GPS Port  
1410:3000=Novatel Wireless Freedom Box CDMA 1X Modem  
1410:3000:01=Novatel Wireless Freedom Box CDMA 1X Status Port  
1410:3000:02=Novatel Wireless Freedom Box CDMA 1X Diagnostics Port  
1410:3000:03=Novatel Wireless Freedom Box CDMA 1X GPS Port  
1410:3010=Novatel Wireless Freedom Box CDMA 1X Modem  
1410:3010:01=Novatel Wireless Freedom Box CDMA 1X Status Port  
1410:3010:02=Novatel Wireless Freedom Box CDMA 1X Diagnostics Port  
1410:3010:03=Novatel Wireless Freedom Box CDMA 1X GPS Port  
1410:3020=Novatel Wireless Freedom Box CDMA 1X Modem  
1410:3020:01=Novatel Wireless Freedom Box CDMA 1X Status Port  
1410:3020:02=Novatel Wireless Freedom Box CDMA 1X Diagnostics Port  
1410:3020:03=Novatel Wireless Freedom Box CDMA 1X GPS Port  
1410:3030=Novatel Wireless Freedom Box CDMA 1X Modem  
1410:3030:01=Novatel Wireless Freedom Box CDMA 1X Status Port  
1410:3030:02=Novatel Wireless Freedom Box CDMA 1X Diagnostics Port  
1410:3030:03=Novatel Wireless Freedom Box CDMA 1X GPS Port  
1410:3100=Novatel Wireless Freedom Box EVDO Modem  
1410:3100:01=Novatel Wireless Freedom Box EVDO Status Port  
1410:3100:02=Novatel Wireless Freedom Box EV-DO Diagnostics Port  
1410:3100:03=Novatel Wireless Freedom Box EV-DO GPS Port







1410:4330=Novatel Wireless Residential Gateway UMTS Modem  
1410:4330:01=Novatel Wireless Residential Gateway UMTS Status Port  
1410:4330:02=Novatel Wireless Ovation UMTS Diagnostics Port  
1410:4330:03=Novatel Wireless Ovation EAP-SIM Port  
1410:4400=Novatel Wireless Residential Gateway HSDPA Modem  
1410:4400:01=Novatel Wireless Residential Gateway HSDPA Status Port  
1410:4400:02=Novatel Wireless Ovation HSDPA Diagnostics Port  
1410:4400:03=Novatel Wireless Ovation HSDPA EAP-SIM Port  
1410:4410=Novatel Wireless Residential Gateway HSDPA Modem  
1410:4410:01=Novatel Wireless Residential Gateway HSDPA Status Port  
1410:4410:02=Novatel Wireless Ovation HSDPA Diagnostics Port  
1410:4410:03=Novatel Wireless Ovation HSDPA EAP-SIM Port  
1410:4420=Novatel Wireless Residential Gateway HSDPA Modem  
1410:4420:01=Novatel Wireless Residential Gateway HSDPA Status Port  
1410:4420:02=Novatel Wireless Ovation HSDPA Diagnostics Port  
1410:4420:03=Novatel Wireless Ovation HSDPA EAP-SIM Port  
1410:4430=Novatel Wireless Residential Gateway HSDPA Modem  
1410:4430:01=Novatel Wireless Residential Gateway HSDPA Status Port  
1410:4430:02=Novatel Wireless Ovation HSDPA Diagnostics Port  
1410:4430:03=Novatel Wireless Ovation HSDPA EAP-SIM Port  
1410:4500=Novatel Wireless Ovation HSDPA Modem  
1410:4500:01=Novatel Wireless Ovation HSDPA Status Port  
1410:A001=Gobi Wireless Modem  
1410:A008=Gobi Wireless Modem (QDL mode)  
1415=Sony Computer Entertainment Europe  
1415:0000=Sony SingStar USBMIC  
1415:0020=Sony Wireless SingStar  
1415:2000=Sony Playstation Eye  
1419=ABILITY ENTERPRISE  
141A=Realm Systems  
141B=METRAWARE  
141C=Leviton Manufacturing  
1421=Sensor Technologies America  
1424:0802=POSNET USB Smart Card Reader  
1429=Vega Technologies Industrial (Austria)  
142A=Thales E-Transactions  
142A:0003=Artema Hybrid  
142A:0005=Artema Modular  
142A:0043=medCompact  
142B=Arbiter Systems  
142B:03A5=933A Portable Power Sentinel  
1430=RedOctane  
1430:4734=Guitar Hero4 USB Hub  
1430:474B=Guitar Hero MIDI interface  
1431=Pertech Resources  
1432:7119=Edimax EW-7119 Series Wireless LAN Mini USB Adapter  
1434=Comart System  
1435=Wistron NeWeb  
1435:0210=802.11g USB 2.0 adapter  
1435:0427=802.11g USB 2.0 adapter  
1435:0711=UR055G  
1435:0804=AR9170+AR9104 802.11abgn Wireless Adapter  
1435:0826=AR5523  
1435:0827=AR5523 (no firmware)  
1435:0828=AR5523  
1435:0829=AR5523 (no firmware)  
1436=Denali Software  
1438=My3ia (Beijing) Technology  
1439=Wind River Systems  
143A=CP Technologies

143C=Altek  
1442=Canadian Bank Note Company  
1443=Digilent  
1443:0007=CoolRunner-II CPLD Starter Kit  
1445=JUSTER  
1453=RadioShack  
1453:4026=RadioShack USB to Serial Cable  
1455=Georgia Technology  
1456=Extending Wire & Cable  
1457=First International Computer  
1457:5000=FIC Development Device  
1457:5101=PONTUS HPK 300  
1457:5103=FIC 1st. PDA Cavalry series  
1457:5104=MobileCrossing WAYPOINT series  
1457:5117=OpenMoko Neol973 kernel usbnet (g\_ether, CDC Ethernet) mode  
1457:5118=OpenMoko Neol973 Debug board (V2+)  
1457:5119=OpenMoko Neol973 u-boot cdc\_acm serial port  
1457:5120=OpenMoko Neol973 u-boot usbtty generic serial  
1457:5121=OpenMoko Neol973 kernel mass storage (g\_storage) mode  
1457:5122=OpenMoko Neol973 kernel cdc\_ether USB network  
1457:5123=OpenMoko Neol973 internal USB CSR4 module  
1457:5124=OpenMoko Neol973 Bluetooth Device ID service  
1457:5202=FIC Bluetooth USB Device  
1459=Shanghai Simax Micro-electronics  
145B=Lead-Type Precision Electronics  
145E=Forschungszentrum Karlsruhe GmbH  
145F=Trust  
145F:0106=Trust 56K V92 USB Modem  
145F:010C=VideoMate DVB-U2000 firmware loader  
145F:010D=VideoMate DVB-U2000  
145F:0111=TRUST ALL IN ONE CARDREADER  
145F:013D=PC Camera (SN9C201 + OV7660)  
145F:013F=Megapixel USB2 Auto Focus Webcam  
145F:0142=WB-6250X Webcam  
145F:015A=WB-8300X 2MP Webcam  
145F:0161:0100=Realtek RTL8187 Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
145F:0167=Widescreen 3MP Webcam  
145F:017B=Broadcom Bluetooth 2.1 + EDR USB Device  
1460=Tatung  
1460:0066=USB Multi-Channel Audio Device  
1460:0088=USB Multi-Channel Audio Device  
1460:1016=Gateway USB Photo Jukebox  
1460:9150=eHome Infrared Receiver (USBCIR)  
1461=Staccato Communications  
1462=Bright Computech  
1462:5511=MSI MS-551X MEGA STICK  
1462:5511:0001=MSI MS-551X MEGA STICK  
1462:5512=MSI MS-551X MEGA STICK  
1462:5512:0001=MSI MS-551X MEGA STICK  
1462:5512:0001:01=MSI MS-551X MEGA STICK  
1462:5515=MP3 Player  
1462:5516=MP3 Player  
1462:8807=DIGIVOX mini III [af9015]  
1463=BBWM  
1464=Asiamajor  
146D=Progeny  
146E=ClearOne Communications  
146F=Unity Electrical Ind.  
1470=STARRIVER TECHNOLOGY  
1472=Hangzhou Huawei-3Com Tech.

1472:0007=Aolynk WUB300g [ZyDAS ZD1211]  
1472:0009=Aolynk WUB320g USB Wireless LAN Card  
1473=Dingo  
147A=Formosa Industrial Computing  
147A:E015=eHome Infrared Receiver (USBCIR)  
147A:E016=eHome Infrared Receiver (USBCIR)  
147A:E017=eHome Infrared Receiver (USBCIR)  
147A:E018=eHome Infrared Receiver (USBCIR)  
147A:E034=eHome Infrared Receiver (USBCIR)  
147A:E037=eHome Infrared Receiver (USBCIR)  
147A:E03A=eHome Infrared Receiver (USBCIR)  
147A:E03C=eHome Infrared Receiver (USBCIR)  
147A:E03E=Infrared Receiver [IR605A/Q]  
147E=UPEK  
147E:1000=TouchStrip Fingerprint Sensor  
147E:1001=TouchStrip Fingerprint Sensor  
147E:1002=TouchStrip Fingerprint Sensor  
147E:1003=TouchStrip Fingerprint Sensor  
147E:2015=TouchChip Fingerprint Reader  
147E:2016=TouchChip Fingerprint Coprocessor  
147E:3000=TouchChip Fingerprint Reader  
147E:3001=TouchChip Fingerprint Reader  
147E:5002=TouchStrip Fingerprint Sensor  
147E:5003=TouchStrip Fingerprint Sensor  
147F=Hama  
1482=Vaillant  
1482:1005=VRD PC-Interface  
1484=Elsa AG [hex]  
1484:1746=Ecomo 19H99 Monitor  
1484:7616=Elsa Hub  
1485=OrangeWare  
1485:0001=Silicom USB Ethernet Adapter  
1485:0002=Psion Gold Port Ethernet  
1485:001B=Silicom USB Home Phonenumber Network Adapter  
1485:001C=Silicom USB HomeRun Adapter  
1485:001D=Silicom USB LongRun Adapter  
1485:001E=Silicom USB Ethernet Adapter  
1487=DSP Group  
1487:1669=Phone for Windows Live Messenger  
1488=Orion Technology  
148D=DESMa  
148D:2430=Microlink-Foxlink Bluetooth Device  
148E=EVATRONIX SA  
148F=Ralink Technology,  
148F:1000=MotioninJoy Virtual Xinput device for Windows  
148F:1706=RT2500USB Wireless Adapter  
148F:2000=Ralink Motorola BC8 Bluetooth 3.0+HS Adapter  
148F:2070=802.11 USB Wireless LAN Card  
148F:2570=802.11g WiFi  
148F:2573=RT73 USB Wireless LAN Card  
148F:2671=RT73 USB Wireless LAN Card  
148F:2770=802.11n USB Wireless LAN Card  
148F:2870=802.11n USB Wireless LAN Card  
148F:3000=Ralink Motorola BC8 Bluetooth 4.0 Adapter  
148F:3070=802.11n USB Wireless LAN Card  
148F:3071=802.11n USB Wireless LAN Card  
148F:3072=802.11n USB Wireless LAN Card  
148F:3370=802.11n USB Wireless LAN Card  
148F:3572=802.11n USB Wireless LAN Card  
148F:3573=802.11n USB Wireless LAN Card

148F:5370=802.11n USB Wireless LAN Card  
148F:8070=802.11n USB Wireless LAN Card  
148F:9020=Wireless USB Card  
148F:9021=Wireless USB Card  
148F:F101=Huawei WS310 Wireless LAN Card  
1497=Panstrong Company  
1498=ULi Electronics  
1498:9206=DTV-DVB UDTT7049 - USB 2.0 DVB-T Driver  
1498:A090=DVB-T Tuner  
1499=G-STAR Communications  
149A=Imagination Technologies  
149A:0105=The Bug  
149A:2105=The Bug  
149A:2107=DBX1 DSP core  
149E=Amkor Technology  
149F=Wits Technologies Pte.  
14A5=I-ROCKS TECHNOLOGY  
14AA=AverMedia (again) or C&E  
14AA:0001=Avermedia AverTV DVBT USB1.1 (cold)  
14AA:0002=Avermedia AverTV DVBT USB1.1 (warm)  
14AA:0201=DVB2GO UB300 USB2.0 receiver Firmware Loader  
14AA:0221=Avermedia DVBT Tuner Dongle  
14AA:022B=WT-220U DVB-T dongle  
14AA:0301=Avermedia/Yakumo/Hama/Typhoon DVB-T USB2.0 (warm)  
14AD=CTK  
14AE=Printronic  
14AF=ATP Electronics  
14B0=StarTech.com  
14B2=Atheros Communications  
14B2:3300=Skyworth DWA-130-1 Wireless N USB Adapter (rev.C2)  
14B2:3301=Skyworth DWA-130-2 Wireless N USB Adapter (rev.C2)  
14B2:3302=Skyworth DWA-130-3 Wireless N USB Adapter (rev.C2)  
14B2:3A93=USB WLAN Device  
14B2:3A95=Toshiba WUS-G06G-JT 802.11bg Wireless Adapter  
14B2:3A98=Airlink101 AWLL4130 802.11bg Wireless Adapter [Atheros AR5523]  
14B2:3C02=Conceptronic 54Mbps USB adapter  
14B2:3C05=rt2570 802.11g WLAN  
14B2:3C06=Conceptronic 802.11n USB adapter (V1)  
14B2:3C07=AnyGate 11N W-LAN Adapter (XM-242U)  
14B2:3C08=IEEE802.11b/g/n Wireless USB Adapter  
14B2:3C09=802.11n adapter  
14B2:3C10=802.11g USB Wireless LAN Card  
14B2:3C11=IEEE802.11b/g/n Wireless USB Adapter  
14B2:3C12=AnyGate 11n W-LAN Adapter (XM-200U)  
14B2:3C22=Conceptronic 54Mbps USB adapter  
14B2:3C23=Airlink101 300N Wireless USB Adapter  
14B2:3C24=NEC NP01LM 802.11abg Wireless Adapter [Ralink RT2571W]  
14B2:3C25=Vigor N61 802.11n Wireless USB Adapter  
14B2:3C27=rt2870 802.11n WLAN  
14B2:3C28=Conceptronic 802.11n USB adapter (V2)  
14B2:3C2C=Wireless N 150 USB Adapter  
14B4=Inventec Appliances  
14B9=BP Microsystems  
14BA=FLOVEL  
14BB=Assembly Tech.  
14C0=Rockwell Automation  
14C2=Gemlight Computer  
14C2:0250=USB Storage Adapter V2  
14C2:0350=USB Storage Adapter V2  
14C3=Smart Link

14C8=Zytronic  
14CD=MOAI ELECTRONICS  
14CD:121C=microSD card reader  
14CD:123A=SD/MMC/RS-MMC Card Reader  
14CD:127B=SDXC Reader  
14CD:6116=M6116 SATA Bridge  
14CD:6600=USB 2.0 IDE DEVICE  
14CD:6700=M121 SD/MMC Reader  
14CD:6900=Card Reader  
14CD:8123=SD MMC Reader  
14CD:8125=SD MMC Reader  
14D8=JAMER INDUSTRIES  
14DD=Raritan Computer  
14E1=Dialogue Technology  
14E1:5000=PenMount 5000 Touch Controller  
14E5=SAIN Information & Communications  
14EA=Planex Communications  
14EA:AB10=GW-US54GZ  
14EA:AB11=GU-1000T  
14EA:AB13=GW-US54Mini  
14ED=Shure  
14F7=TechniSat Digital GmbH  
14F7:0001=SkyStar 2 HD CI  
14F7:0002=SkyStar 2 HD CI  
14F7:0003=CableStar Combo HD CI  
14F7:0004=AirStar TeleStick 2  
14F7:0500=DVB-PC TV Star HD  
14FF=Twinhead International  
1500=Ellisys  
1501=Pine-Tum Enterprise  
1503=Stretch  
1509=First International Computer  
1509:9242=eHome Infrared Receiver (USBCIR)  
1511=BridgeCo, AG  
1513=Hypercom  
1513:0444=medMobile  
1514=ACTEL  
1514:2003=FlashPro3 Programmer  
1514:2004=FlashPro3 Programmer  
1514:2005=FlashPro3 Programmer  
1515=Hexon Media Pte  
1516=Skymedi  
1516:1603=1GB Flash Drive  
1516:8628=128M Pen Drive  
1518=Cheshire Engineering  
1518:0001=HDReye High Dynamic Range Camera  
1518:0002=HDReye (before firmware loads)  
1519=Comneon  
151C=VeriSilicon  
1520=Bitwire  
1524=ENE Technology  
1524:6220=ENE USB Mass Storage Controller  
1524:6680=UTS 6680  
1527=Silicon Portals  
1527:0200=YAP Phone (no firmware)  
1527:0201=YAP Phone  
1529=UBIQUAM  
1529:3100=CDMA 1xRTT USB Modem (U-100/105/200/300/520)  
152A:8040=Colormask V1\_1 Device  
152D=JMicron

152D:0310=JMicron 310 USB Video Camera (SuYin)  
152D:0311=JMicron 311 USB Video Camera (SuYin)  
152D:0312=JMicron 312 USB Video Camera (SuYin)  
152D:0313=JMicron 313 USB Video Camera (SuYin)  
152D:2329=transcend storejet 25P  
152D:2335=ATA/ATAPI Bridge  
152D:2336=Hard Disk Drive  
152D:2337=ATA/ATAPI Bridge  
152D:2338=JM20338 USB to SATA Bridge  
152D:2339=JM20339 SATA Bridge  
152D:2352=ATA/ATAPI Bridge  
152D:2509=JMS539 SuperSpeed SATA II 3.0G Bridge  
152E=HLDS (Hitachi-LG Data Storage)  
152E:2507=PL-2507 IDE Controller  
152E:E001=GSA-5120D DVD-RW  
1532=Razer USA  
1532:0001=RZ01-020300 Optical Mouse [Diamondback]  
1532:0003=Krait Mouse  
1532:0007=DeathAdder Mouse  
1532:0017=Imperator Mouse  
1532:001C=RZ01-0036 Optical Gaming Mouse [Abyssus]  
1532:0101=Copperhead Mouse  
1532:0102=Razer Tarantula USB Keyboard  
1532:0102:01=Razer Tarantula USB Keyboard  
1532:0105=Razer ProType USB Keyboard  
1532:0105:01=Razer ProType USB Keyboard  
1532:0106=Razer ProType USB Keyboard  
1532:0106:01=Razer ProType USB Keyboard  
1532:0109=Lycosa Keyboard  
1532:0200=Razer Reclusa  
1532:0200:01=Razer Reclusa  
1540=Phihong Technology  
1543=Buxco Research Systems  
1546=U-Blox AG  
1546:01A4=u-blox ANTARIS 4 GPS Receiver  
1546:01A5=u-blox 5 GPS and GALILEO Receiver  
154A=Celectronic GmbH  
154A:8180=CARD STAR/medic2  
154B=PNY Technologies  
154B:0010=USB 2.0 Flash Drive  
154B:6545=FD Device  
154D=CONNECTCOUNTY SDN BHD  
154E=D & M Holdings  
154E:3000=Marantz RC9001 Remote Control  
1554=Prolink Microsystems  
1557=OQO  
1557:0002=model 01 WiFi interface  
1557:0003=model 01 Bluetooth interface  
1557:0004=OQO Bluetooth Radio v2.0  
1557:0A80=Gobi Wireless Modem (QDL mode)  
1557:7720=model 01+ Ethernet  
1557:8150=model 01 Ethernet interface  
1565=Advance Modules  
1568=Sunf Pu Technology  
156F=Quantum  
1570=ALLTOP TECHNOLOGY  
1577=MIYUKI ELEX  
1578=Beijing Huaqi Information Digital Technology  
1579=Reputed Industrial Company  
157A=Lowrance Electronics



157B=Ketron SRL  
157D=Tokyo Sokuteikizai  
157E=U-MEDIA Communications  
157E:3006=TEW-444UB EU  
157E:3007=TEW-444UB EU (no firmware)  
157E:300A=TRENDnet TEW-429UB 802.11g Wireless USB 2.0 Adapter  
157E:300B=TRENDnet TEW-429UB 802.11g Wireless USB 2.0 Adapter  
157E:300C=TRENDnet TEW-429UF 802.11g Wireless USB 2.0 Adapter  
157E:300D=TRENDnet TEW-429UB 802.11g Wireless USB 2.0 Adapter  
157E:3204=ALL0298 v2  
157E:3205=AR5523  
157E:3206=AR5523 (no firmware)  
157E:3207=TRENDnet TEW-509UB 802.11ag Wireless USB 2.0 Adapter  
157E:3208=TRENDnet TEW-509UB 802.11ag Wireless USB 2.0 Adapter  
1582=Fiberline  
1582:3001=RFMD Bluetooth Device  
1582:3006=USB Bluetooth 2.0 EDR Dongle  
1582:6003=WL-430U  
1584:6005=DiBcom DIB7700 based TV tuner device  
1584:9001=DiBcom DIB7700 based TV tuner device  
1585=IKeyInfinity  
1586=Shenzhen Shi Viton Technology City  
1587=SMA Regelsysteme GmbH  
1588=Fine Instruments  
158D=Oakley  
158E=JDS Uniphase  
158E:0820=SmartPocket Class Device  
158F=Tai Yip Electrical  
1590=Onsu Data Telecommunication Technology (Shenzhen) Fty.  
1598=Kunshan Guoji Electronics  
15A2=Freescall Semiconductor  
15A2:0042=OSBDM - Debug Port  
15A2:004F=i.MX28 SystemOnChip in RecoveryMode  
15A2:0052=i.MX50 SystemOnChip in RecoveryMode  
15A2:0054=i.MX6Q SystemOnChip in RecoveryMode  
15A4=Afa Technologies  
15A4:1000=AF9035 BDA Device  
15A4:1001=AF9035 BDA Device  
15A4:1336=SDHC/MicroSD/MMC/MS/M2/CF/XD Flash Card Reader  
15A4:9015=DTV-DVB UDTT 704J - USB 2.0 dual DVB-T Driver  
15A4:9016=DTV-DVB UDTT 704J - USB 2.0 dual DVB-T Driver  
15A8=Teams Power  
15A9=Gemtek Technology  
15A9:0004=USB Wireless 802.11 b/g Adaptor  
15A9:0006=Wireless 11n USB Adapter  
15A9:0010=802.11n USB Wireless Card  
15A9:0012=WUBR-208N 802.11abgn Wireless Adapter [Ralink RT2870]  
15A9:0016=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
15A9:0019=Bluetooth Module  
15A9:001E=Broadcom Bluetooth 2.1 + EDR USB Device  
15AA=Gearway Electronics (Dong Guan)  
15AB=Virgin Electronics, LLC  
15AD=VMware  
15B1:8090=eHome Infrared Receiver (USBCIR)  
15B4=Orient Power Multimedia  
15B5=ANUBIS ELECTRONIC GmbH  
15B8:6001=HP Camera  
15BA=Olimex  
15BA:0003=OpenOCD JTAG  
15BA:0004=OpenOCD JTAG TINY

15BA:002A=ARM-USB-TINY-H JTAG interface  
15C0=XL Imaging  
15C0:0001=2M pixel Microscope Camera  
15C0:0002=3M pixel Microscope Camera  
15C0:0003=1.3M pixel Microscope Camera (mono)  
15C0:0004=1.3M pixel Microscope Camera (colour)  
15C0:0005=3M pixel Microscope Camera (Mk 2)  
15C0:0006=2M pixel Microscope Camera (with capture button)  
15C0:0007=3M pixel Microscope Camera (with capture button)  
15C0:0008=1.3M pixel Microscope Camera (colour, with capture button)  
15C0:0009=1.3M pixel Microscope Camera (colour, with capture button)  
15C0:000A=2M pixel Microscope Camera (Mk 2)  
15C0:0010=1.3M pixel "Tinycam"  
15C0:0101=3M pixel Microscope Camera  
15C2=SoundGraph  
15C2:0036=LC16M VFD Display/IR Receiver  
15C2:0038=GD01 MX VFD Display/IR Receiver  
15C2:FFDA=iMON PAD Remote Controller  
15C2:FFDC=iMON PAD Remote Controller  
15C5=Advance Multimedia Internet Technology  
15C5:0008=WL532U 802.11g Adapter  
15C6=Laboratoires MXM  
15C6:1000=DigistimSP (cold)  
15C6:1001=DigistimSP (warm)  
15C6:1002=DigimapSP USB (cold)  
15C6:1003=DigimapSP USB (warm)  
15C7=IRI-Ubiteq  
15C8=KTF Technologies  
15C8:3201=EVER EV-W250  
15C9=D-Box Technologies  
15CA=TEXTECH INTERNATIONAL  
15CA:00C3=Mini Optical Mouse  
15CA:0101=MIDI Interface cable  
15CA:1806=MIDI Interface cable  
15D5=Coulomb Electronics  
15D6=Fitness Expert  
15D8:0001=DigtaMicDriver Steuerungsgerät  
15D8:0002=DigtaSoundboxDriver Steuerungsgerät  
15D8:0003=DigtaMicDriver x Steuerungsgerät  
15D9=Unknown  
15D9:0A33=Optical Mouse  
15D9:0A33:0100=USB Human Interface Device  
15D9:0A37=Mouse  
15D9:0A41=MI-2540D [Optical mouse]  
15D9:0A4C=USB+PS/2 Optical Mouse  
15D9:0A4C:0100=USB Human Interface Device  
15DB=Philip Harris Education  
15DC=Hynix Semiconductor  
15E0=Seong Ji Industrial  
15E1=RSA Security  
15E1:2007=RSA SecurID (R) Authenticator  
15E2=Bionopoly LLC  
15E4=Numark  
15E4:0024=Mixtrack  
15E8=SohoWare  
15E8:9100=SOHOware NUB100 10/100 USB Network Adapter  
15E8:9110=SOHOware NUB110 10/100 USB Network Adapter  
15E9=Pacific Digital  
15E9:04CE=MemoryFrame MF-570  
15E9:1968=MemoryFrame MF-570

15E9:1969=Digital Frame  
15EA=C-guys  
15EB=VIA Telecom  
15EC=Belcarra Technologies  
15ED=UCA Technology  
15F4=HanfTek  
15F4:0001=HanfTek UMT-010 USB2.0 DVB-T (cold)  
15F4:0025=HanfTek UMT-010 USB2.0 DVB-T (warm)  
15F6=ASICS World Services  
15F7=HANTEL  
15F8=Vianet  
15FC=Humen Xintai Electrical Wires Factory  
1601=Avenues in Leather  
1603=ERGODEX  
1604=Tascam  
1604:8000=US-428 Audio/Midi Controller (without fw)  
1604:8001=US-428 Audio/Midi Controller  
1604:8004=US-224 Audio/Midi Controller (without fw)  
1604:8005=US-224 Audio/Midi Controller  
1604:8006=US-122 Audio/Midi Interface (without fw)  
1604:8007=US-122 Audio/Midi Interface  
1606=Umax [hex]  
1606:0002=Astra 1236U Scanner  
1606:0010=UMAX Astra 1220U  
1606:0030=UMAX Astra 2000U  
1606:0050=Scanner  
1606:0060=UMAX Astra 3400  
1606:0070=UMAX Astra 4400  
1606:0130=UMAX Astra 2100U  
1606:0160=UMAX Astra 5400  
1606:0170=Uniscan D50  
1606:0230=UMAX Astra 2200 (USB)  
1606:0350=UMAX Astra 4800 Scanner  
1606:1030=UMAX Astra 4000U  
1606:1220=Genesys Logic Scanner Controller NT5.0  
1606:2010=UMAX AstraCam Digital Camera  
1606:2020=UMAX AstraCam 1000 Digital Camera  
1606:2030=UMAX AstraCam 1800 Digital Camera  
1608=Inside Out Networks  
1608:0001=Inside Out Networks Edgeport/4  
1608:0002=Inside Out Networks Edgeport/8  
1608:0003=Inside Out Networks Rapidport/4  
1608:0004=Inside Out Networks Edgeport/4  
1608:0005=Inside Out Networks Edgeport/2  
1608:0006=Inside Out Networks Edgeport/4i  
1608:0007=Inside Out Networks Edgeport/2i  
1608:0008=Inside Out Networks Edgeport/8  
1608:000C=Inside Out Networks Edgeport/421  
1608:000D=Inside Out Networks Edgeport/21  
1608:000E=Inside Out Networks Edgeport/4  
1608:000F=Inside Out Networks Edgeport/8  
1608:0010=Inside Out Networks Edgeport/2  
1608:0011=Inside Out Networks Edgeport/4  
1608:0012=Inside Out Networks Edgeport/416  
1608:0014=Inside Out Networks Edgeport/8i  
1608:0018=Inside Out Networks Edgeport/412  
1608:0019=Inside Out Networks Edgeport/412  
1608:001A=Inside Out Networks Edgeport/2+2i  
1608:0101=Inside Out Networks Edgeport/4  
1608:0105=Inside Out Networks Edgeport/2

1608:0106=Inside Out Networks Edgeport/4i  
1608:0107=Inside Out Networks Edgeport/2i  
1608:010C=Inside Out Networks Edgeport/421  
1608:010D=Inside Out Networks Edgeport/21  
1608:0110=Inside Out Networks Edgeport/2  
1608:0111=Inside Out Networks Edgeport/4  
1608:0112=Inside Out Networks Edgeport/416  
1608:0114=Inside Out Networks Edgeport/8i  
1608:0201=Inside Out Networks Edgeport/4  
1608:0203=Inside Out Networks Rapidport/4  
1608:0204=Inside Out Networks Edgeport/4  
1608:0205=Inside Out Networks Edgeport/2  
1608:0206=Inside Out Networks Edgeport/4i  
1608:0207=Inside Out Networks Edgeport/2i  
1608:020C=Inside Out Networks Edgeport/421  
1608:020D=Inside Out Networks Edgeport/21  
1608:020E=Inside Out Networks Edgeport/4  
1608:020F=Inside Out Networks Edgeport/8  
1608:0210=Inside Out Networks Edgeport/2  
1608:0211=Inside Out Networks Edgeport/4  
1608:0212=Inside Out Networks Edgeport/416  
1608:0214=Inside Out Networks Edgeport/8i  
1608:0215=Inside Out Networks Edgeport/1  
1608:0216=Inside Out Networks EPOS/44  
1608:0217=Inside Out Networks Edgeport/42  
1608:021A=Inside Out Networks Edgeport/2+2i  
1608:021B=Inside Out Networks Edgeport/2c  
1608:021C=Inside Out Networks Edgeport/221c  
1608:021D=Inside Out Networks Edgeport/22c  
1608:021E=Inside Out Networks Edgeport/21c  
1608:021F=Edgeport/62  
1608:0240=Inside Out Networks Edgeport/1  
1608:0241=Inside Out Networks Edgeport/1i  
1608:0242=Inside Out Networks Edgeport/4s  
1608:0243=Inside Out Networks Edgeport/8s  
1608:0244=Edgeport/8  
1608:0245=Edgeport/22c  
1608:0301=Inside Out Networks Watchport/P  
1608:0302=Inside Out Networks Watchport/M  
1608:0303=Inside Out Networks Watchport/W  
1608:0304=Inside Out Networks Watchport/T  
1608:0305=Inside Out Networks Watchport/H  
1608:0306=Inside Out Networks Watchport/E  
1608:0307=Inside Out Networks Watchport/L  
1608:0308=Inside Out Networks Watchport/R  
1608:0309=Inside Out Networks Watchport/A  
1608:030A=Watchport/D  
1608:030B=Inside Out Networks Watchport/D  
1608:030C=Inside Out Networks Power Management Port  
1608:030E=Inside Out Networks Power Management Port  
1608:030F=Watchport/G  
1608:0310=Watchport/Tc  
1608:0311=Watchport/Hc  
1608:1403=MultiTech Systems MT4X56 Modem  
1608:1A17=Agilent Technologies (E6473)  
1609=K-byte (ACI Group)  
160A=VIA Technologies  
160A:3184=VIA Networking Technologies USB Wireless LAN Adapter  
160D=Samtec  
1612=Soft DB

1613=Airconnect Solutions (Asia)  
1614=Amoi Electronics  
1614:0404=WMA9109 UMTS Phone  
1614:0404:01=MD-1 Diagnostics Interface  
1614:0404:02=MD-1 NMEA Device  
1614:0600=Vodafone VDA GPS / Toshiba Protege G710  
1614:0804=WP-S1 Phone  
1614:3100=Amoi USB CDC Modem 3100  
1614:3196=Amoi USB CDC Modem 3196  
1614:3197=Amoi USB Modem 3197  
1614:3197:01=Qualcomm Diagnostics Interface 3197  
1614:3198=Amoi USB Modem 3198  
1614:3198:01=Qualcomm Diagnostics Interface 3198  
1614:3199=Amoi USB Modem 3199  
1614:3199:01=Qualcomm Diagnostics Interface 3199  
1614:319A=Amoi USB Modem 319A  
1614:319A:01=Qualcomm Diagnostics Interface 319A  
1614:319B=Amoi USB Modem 319B  
1614:319B:01=Qualcomm Diagnostics Interface 319B  
1614:319C=Amoi USB Modem 319C  
1614:319C:01=Qualcomm Diagnostics Interface 319C  
1614:319D=Amoi USB Modem 319D  
1614:319D:01=Qualcomm Diagnostics Interface 319D  
1614:319E=Amoi USB Modem 319E  
1614:319E:01=Qualcomm Diagnostics Interface 319E  
1614:319F=Amoi USB Modem 319F  
1614:319F:01=Qualcomm Diagnostics Interface 319F  
1614:31A0=Amoi USB Modem 31A0  
1614:31A0:01=Qualcomm Diagnostics Interface 31A0  
1614:31A1=Amoi USB Modem 31A1  
1614:31A1:01=Qualcomm Diagnostics Interface 31A1  
1614:31A2=Amoi USB Modem 31A2  
1614:31A2:01=Qualcomm Diagnostics Interface 31A2  
1614:31A3=Amoi USB Modem 31A3  
1614:31A3:01=Qualcomm Diagnostics Interface 31A3  
1614:31A4=Amoi USB Modem 31A4  
1614:31A4:01=Qualcomm Diagnostics Interface 31A4  
1614:31A5=Amoi USB Modem 31A5  
1614:31A5:01=Qualcomm Diagnostics Interface 31A5  
1614:31A6=Amoi USB Modem 31A6  
1614:31A6:01=Qualcomm Diagnostics Interface 31A6  
1614:31A7=Amoi USB Modem 31A7  
1614:31A7:01=Qualcomm Diagnostics Interface 31A7  
1614:31A8=Amoi USB Modem 31A8  
1614:31A8:01=Qualcomm Diagnostics Interface 31A8  
1614:31A9=Amoi USB Modem 31A9  
1614:31A9:01=Qualcomm Diagnostics Interface 31A9  
1614:31AA=Amoi USB Modem 31AA  
1614:31AA:01=Qualcomm Diagnostics Interface 31AA  
1614:31AB=Amoi USB Modem 31AB  
1614:31AB:01=Qualcomm Diagnostics Interface 31AB  
1614:31AC=Amoi USB Modem 31AC  
1614:31AC:01=Qualcomm Diagnostics Interface 31AC  
1614:31AD=Amoi USB Modem 31AD  
1614:31AD:01=Qualcomm Diagnostics Interface 31AD  
1614:31AE=Amoi USB Modem 31AE  
1614:31AE:01=Qualcomm Diagnostics Interface 31AE  
1614:31AF=Amoi USB Modem 31AF  
1614:31AF:01=Qualcomm Diagnostics Interface 31AF  
1614:31B0=Amoi USB Modem 31B0

1614:31B0:01=Qualcomm Diagnostics Interface 31B0  
1614:31B1=Amoi USB Modem 31B1  
1614:31B1:01=Qualcomm Diagnostics Interface 31B1  
1614:31B2=Amoi USB Modem 31B2  
1614:31B2:01=Qualcomm Diagnostics Interface 31B2  
1614:31B3=Amoi USB Modem 31B3  
1614:31B3:01=Qualcomm Diagnostics Interface 31B3  
1614:31B4=Amoi USB Modem 31B4  
1614:31B4:01=Qualcomm Diagnostics Interface 31B4  
1614:31B5=Amoi USB Modem 31B5  
1614:31B5:01=Qualcomm Diagnostics Interface 31B5  
1614:31B6=Amoi USB Modem 31B6  
1614:31B6:01=Qualcomm Diagnostics Interface 31B6  
1614:31B7=Amoi USB Modem 31B7  
1614:31B7:01=Qualcomm Diagnostics Interface 31B7  
1614:7000:01=Qualcomm Diagnostics Interface 7000  
1614:7001=Qualcomm RRDM 7001  
1614:7001:02=Amoi USB Modem 7001  
1614:7001:03=Qualcomm Diagnostics Interface 7001  
1617=Navman  
1618=Redpine Signals  
1619=L & K Precision Technology  
161A=Celeraise Investments  
1621=Orion Microelectronics  
1626=Advance Data Technology  
1627=IPextreme  
1628=Stonestreet One  
1629=Erae Electronics  
162A=Airgo Networks  
162F=WiQuest Communications  
162F:0201=WiQuest WQST110 HWA WUSB Device  
162F:0204=WiQuest WQST110 Host Wire Adapter  
162F:0205=WiQuest WQST110 HWA WUSB Device  
162F:0220=WiQuest WQST110 Device Wire Adapter  
162F:0221=WiQuest Cable Association Device  
162F:0230=WiQuest WQST110 Device Wire Adapter  
162F:0244=WiQuest WQST110 Host Wire Adapter  
162F:0245=WiQuest WQST110 HWA WUSB Device  
162F:0280=WiQuest Cable Association Interface  
162F:02A0=WiQuest Cable Association Interface  
162F:4002=Lenovo WQST110 Host Wire Adapter  
162F:4003=Lenovo WQST110 WUSB Device  
162F:4004=Lenovo WQST110 Host Wire Adapter  
162F:4005=Lenovo WQST110 WUSB Device  
1630=QformX  
1630:0005=802.11g Wireless Adapter [Intersil ISL3886]  
1630:0011=2Wire PC Port  
1630:0041=2Wire Gateway USB  
1630:0042=2Wire Gateway USB  
1630:FF81=2Wire Wireless USB adapter  
1631=Focus Enhancements  
1631:6200=USB 2.0 10/100Base Ethernet Adapter  
1631:C019=RT73 USB Wireless LAN Card  
1631:C216=Bluetooth Radios  
1631:C217=Bluetooth Radios  
1638=Skyworks Solutions  
163E=HongLin Electronics  
163F=AVEX Technologies  
1641=eMagin  
1642=AquaSensors LLC

1645=Entrega [hex]  
1645:0001=1S Serial Port  
1645:0002=2S Serial Port  
1645:0003=1S25 Serial Port  
1645:0004=4S Serial Port  
1645:0005=PortGear Ethernet Adapter  
1645:0006=Parallel Port  
1645:0007=U1-SC25 SCSI  
1645:0008=Entrega USB Ethernet Adapter  
1645:0016=Bi-directional to Parallel Printer Converter  
1645:0080=1 port to Serial Converter  
1645:0081=1 port to Serial Converter  
1645:0093=1S9 Serial Port  
1645:8000=EZ-USB  
1645:8001=1 port to Serial  
1645:8002=2x Serial Port  
1645:8003=1 port to Serial  
1645:8004=2U4S serial/USB Hub  
1645:8005=PortGear Ethernet Adapter  
1645:8080=1 port to Serial  
1645:8081=1 port to Serial  
1645:8093=PortGear Serial Port  
1649=SofTec Microsystems  
1649:0102=uDART In-Circuit Debugger  
1649:0200=SpYder USBSPYDER08  
164A=ChipX  
164B=Lytech Technology  
164C=Matrix Vision GmbH  
164C:0101=mvBlueFOX camera (no firmware)  
164C:0103=mvBlueFOX camera  
164C:0201=mvBlueLYNX-X intelligent camera (bootloader)  
164C:0203=mvBlueLYNX-X intelligent camera  
1650=Remopro Technology  
1651=PACOMP  
1657=Struck Innovative Systeme GmbH  
1657:3150=SIS3150 USB2.0 to VME interface  
165A=E.D.P. SRL  
165B=Frontier Design Group  
165B:8101=Tranzport Control Surface  
165B:FAD1=Alphatrack Control Surface  
1660=Creatix Polymedia GmbH  
1665=General Dynamics Canada  
1668=Actiontec Electronics  
1668:0009=Actiontec Gateway  
1668:0333=Modem  
1668:0358=InternetPhoneWizard  
1668:0405=Gateway  
1668:0408=Prism2.5 802.11b Adapter  
1668:0413=Gateway  
1668:0421=Prism2.5 802.11b Adapter  
1668:0441=IBM Integrated Bluetooth II  
1668:0500=Broadcom Bluetooth 2.1 + EDR USB Device  
1668:1050=802.11g Wireless Mini adapter  
1668:1200=802AIN Wireless N Network Adapter [Atheros AR9001U]  
1668:1441=IBM Integrated Bluetooth II Firmware Upgrade  
1668:2441=IBM Integrated Bluetooth III  
1668:3441=IBM Integrated Bluetooth III Firmware Upgrade  
1668:6010=Actiontec Gateway  
1668:6097=802.11b Wireless Adapter  
1668:6106=ROPEX FreeLan 802.11b

1668:7605=UAT1 Wireless Ethernet Adapter  
1669=PiKRON  
1669:1001=uLan2USB Converter - PS1 protocol  
1677=China Integrated Circuit Design  
1677:0103=Token  
1678=Matsunichi Information Technology (Shenzhen)  
1679=Total Phase  
1679:2001=Beagle USB 12 Protocol Analyzer  
1679:2002=Cheetah SPI Host Adapter  
167B:4001=Cisco FlipShare TV  
1680=Golden Bridge Electech  
1680:A332=DVB-T Dongle [RTL2832U]  
1681=Prevo Technologies  
1681:0001=Tuner's Dashboard  
1681:0002=Tubachron  
1682=Maxwise Production Enterprise  
1683=DualCor Technologies  
1684=Godspeed Computer  
1685=Tanic Electroics  
1685:0200=Infrared adapter  
1686=ZOOM  
1686:0045=H4 Digital Recorder  
1687=Kingmax Digital  
1687:5289=FlashDisk  
1687:6211=FlashDisk  
1688=Saab AB  
168C=Atheros Communications  
168C:0001=AR5523  
168C:0002=Atheros USB 2.0 Wireless Network Adapter  
1690=Askey Computer  
1690:0101=Creative Modem Blaster DE5670  
1690:0101:0100=Modem Blaster USB DE5670  
1690:0102=CDC Modem Board  
1690:0103=Askey 1456 VQE-R3 Modem [conexant]  
1690:0104=HCF V90 Data Fax RTAD Modem  
1690:0107=HCF V.90 Data, Fax, RTAD Modem  
1690:0109=Askey MagicXpress V.90 Pocket Modem [conexant]  
1690:0203=Voyager ADSL Modem Loader  
1690:0204=Voyager ADSL Modem  
1690:0205=DSL Modem  
1690:0206=GlobeSpan ADSL WAN Modem  
1690:0208=DSL Modem  
1690:0209=Voyager 100 ADSL Modem  
1690:0211=Globespan Virata ADSL LAN Modem  
1690:0212=DSL Modem  
1690:0213=HM121d DSL Modem  
1690:0214=HM121d DSL Modem  
1690:0215=GlobeSpan USB ADSL LAN Modem  
1690:0601=Askey USB Sync  
1690:0701=WLAN  
1690:0710=SMCWUSBT-G  
1690:0711=SMCWUSBT-G (no firmware)  
1690:0712=AR5523  
1690:0713=AR5523 (no firmware)  
1690:0715=Remote NDIS 802.11 Wireless Adapter  
1690:0722=WLAN USB Wireless LAN Stick  
1690:0726=Wi-Fi Wireless LAN USB Adapter  
1690:0734=Broadcom Bluetooth 2.1 + EDR USB Device  
1690:0737=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
1690:0740=802.11n USB Wireless LAN Card



1690:0741=USB Bluetooth Driver (V2.1+EDR)  
1690:0742=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
1690:0744=802.11n USB Wireless LAN Card  
1690:0752=Realtek RTL8188SU Wireless LAN 802.11n USB 2.0 Network Adapter  
1690:0752:0200=Realtek RTL8188SU Wireless LAN 802.11n USB 2.0 Network Adapter  
1690:0754=BRCM Bluetooth Controller BCM2070  
1690:0757=Bluetooth Module  
1690:0901=Voyager 205 ADSL Router  
1696=Hitachi Advanced Digital  
1697=VTEC TEST  
1699=United RadioTek  
169A=Ten X Technology  
16A5=Shenzhen Zhengerya Cable  
16A6=Unigraf  
16A6:3000=VTG-3xxx Video Test Generator family  
16A6:4000=VTG-4xxx Video Test Generator family  
16A6:5000=VTG-5xxx Video Test Generator family  
16A6:5001=VTG-5xxx Special (update) mode of VTG-5xxx family  
16AB=InnoWireless  
16AB:7801=AR5523  
16AB:7802=AR5523 (no firmware)  
16AB:7811=AR5523  
16AB:7812=AR5523 (no firmware)  
16AC=Dongguan ChingLung Wire & Cable  
16AE=ELSA Japan  
16B4=iStation  
16B4:0801=U43  
16B5=Persentec  
16B5:0002=Otto driving companion  
16C0=VOTI  
16C0:03E8=free for internal lab use 1000  
16C0:03E9=free for internal lab use 1001  
16C0:03EA=free for internal lab use 1002  
16C0:03EB=free for internal lab use 1003  
16C0:03EC=free for internal lab use 1004  
16C0:03ED=free for internal lab use 1005  
16C0:03EE=free for internal lab use 1006  
16C0:03EF=free for internal lab use 1007  
16C0:03F0=free for internal lab use 1008  
16C0:03F1=free for internal lab use 1009  
16C0:0477=Teensy Rebooter  
16C0:0478=Teensy Halfkey Bootloader  
16C0:05DC=USBasp AVR Programmer  
16C0:05DD=BlackcatUSB2  
16C0:05E1=CDC-ACM class devices (modems)  
16C0:05E4=MIDI class devices  
16C0:076B=OpenPCD 13.56MHz RFID Reader  
16C0:076C=OpenPICC 13.56MHz RFID Simulator (native)  
16C0:08AC=OpenBeacon USB stick  
16C0:08CA=Alpermann+Velte Universal Display  
16C0:08CB=Alpermann+Velte Studio Clock  
16C0:08CC=Alpermann+Velte SAM7S MT Boot Loader  
16C0:08CD=Alpermann+Velte SAM7X MT Boot Loader  
16C0:27DA=Mouse  
16C0:27DB=Keyboard  
16C0:27DC=Joystick  
16C0:27DD=CDC-ACM class devices (modems)  
16C0:27DE=MIDI class devices  
16C3=Nihon Kaiheiki Ind.  
16C4=SavaJe Technologies

16C5=Cryptek  
16C6=TZero Technologies  
16CA=Wireless Cables  
16CA:1502=Bluetooth Dongle  
16CC=silex technology  
16CD=Brian Moore Guitars  
16D0=GrauTec  
16D0:054B=ReelBox OLED Display (external)  
16D3=Frontline Test Equipment  
16D5=AnyDATA  
16D5:6202=CDMA/UMTS/GPRS modem  
16D5:6500=AnyDATA CDMA USB CDC Modem (PID 6500)  
16D5:6501=AnyDATA CDMA USB Modem (PID 6501)  
16D5:6501:01=AnyDATA CDMA USB Serial Device (PID 6501)  
16D5:6502=CDMA/UMTS/GPRS modem  
16D5:6502:01=AnyDATA CDMA USB Serial Device (PID 6502)  
16D5:6502:02=AnyDATA CDMA USB NMEA Device (PID 6502)  
16D6=JABLOCOM s.r.o.  
16D6:8000=GDP-04 desktop phone  
16D6:8001=EYE-02  
16D6:8003=GDP-04 modem  
16D6:8004=Bootloader  
16D6:8005=GDP-04i  
16D6:8007=BTP-06 modem  
16D8=CMOTECH  
16D8:5141=CMOTECH CDMA Technologies USB modem  
16D8:5533=CCU-550 CDMA EV-DO modem  
16D8:5543=CDMA 2000 1xRTT/1xEVDO USB modem  
16D8:6280=CMOTECH CDMA Technologies USB modem  
16D8:6803=CNU-680 CDMA EV-DO modem  
16D8:8001=Gobi 2000 Wireless Modem (QDL mode)  
16D8:8002=Gobi 2000 Wireless Modem  
16DC=Wiener, Plein & Baus  
16DC:0001=CC  
16DC:000B=VM  
16DE:0002=TSX C USB 232  
16DE:0003=TSX C USB 485  
16DF=King Billion Electronics  
16EC=ASAHI GLASS  
16ED=Parker Vision  
16EE=Ryvor  
16F0=GN ReSound A/S  
16F0:0003=Airlink Wireless Programming Interface  
16F5=Futurelogic  
16F8=Ever Bright Wire Factory  
16FC=TRICOM TECHNOLOGIES  
16FE=Su Zhou Song Qing Electronical  
1706=BlueView Technologies  
1707=ARTIMI  
170B=Swissonic  
170B:0011=MIDI-USB 1x1  
170D=Avnera  
170E=Iris  
170F=UbiBro Technolgies  
1712:0B05=ASUS Bluetooth 2.0  
1715=NL Technology  
1725=Vitesse Semiconductor  
1726=Axesstel  
1726:1000=wireless modem  
1726:2000=wireless modem

1726:3000=wireless modem  
1727=RichIP  
172D=AccFast Technology  
172F=WALTOP International  
172F:0022=Tablet  
172F:0024=Tablet  
172F:0025=Tablet  
172F:0026=Tablet  
172F:0031=Slim Tablet 12.1"  
172F:0032=Slim Tablet 5.8"  
172F:0034=Slim Tablet  
172F:0038=Genius G-Pen F509  
172F:0500=Media Tablet 14.1"  
172F:0501=Media Tablet 10.6"  
172F:0502=Sirius Battery Free Tablet  
1733=Cellink Technology  
1733:0101=RF Wireless Optical Mouse OP-701  
1733:1000=Cellink Bluetooth Device  
1734=IPdrum AB  
1736=CANON IMAGING SYSTEM TECHNOLOGIES INC.  
1737=Hong Kong Applied Science and Technology Research Inst.  
1737:0039=USB1000  
1737:0070=Linksys WUSB100 RangePlus Wireless USB Adapter  
1737:0071=Linksys WUSB600N Dual-Band Wireless-N USB Network Adapter  
1737:0073=Linksys WUSB54GC Compact Wireless-G USB Network Adapter  
1737:0075=WUSB54GSC v2 802.11g Adapter  
1737:0077=Compact Wireless-G USB Network Adapter  
1737:0078=Linksys RangePlus Wireless USB Network Adapter  
1737:0079=Linksys WUSB600N Wireless-N USB Adapter with Dual-Band ver. 2  
1738:0010=AsicenUSBDTVBD\_A\_DM016.sys(v1.0) Asicen USB DTV driver  
1738:0010:01=AsicenHidIRKbd\_DM016.Sys(v1.0) Asicen USB Remote Control driver for DTV  
1738:5211=AS11Loader.Sys(1.0) AS11 USB firmware download driver...  
1740=Senao International  
1740:0605=LevelOne WUA-0605 N\_Max Wireless USB Adapter  
1740:0615=LevelOne WUA-0615 N\_Max Wireless USB Adapter  
1740:1000=NUB-350 802.11g Wireless Adapter [Intersil ISL3887]  
1740:2000=NUB-8301  
1740:3701=EnGenius 802.11b/g Wireless USB Adapter  
1740:7100=EnGenius 802.11b/g Wireless USB Adapter  
1740:9201=EnGenius 802.11n Wireless USB Adapter  
1740:9603=EnGenius 802.11n Wireless USB Adapter  
1740:9605=EnGenius 802.11n Wireless USB Adapter  
1740:9701=EnGenius 802.11n Wireless USB Adapter  
1740:9702=EnGenius 802.11n Wireless USB Adapter  
1740:9703=EnGenius 802.11n Wireless USB Adapter  
1740:9705=EnGenius 802.11n Wireless USB Adapter  
1740:9706=EnGenius 802.11n Wireless USB Adapter  
1740:9707=EnGenius 1T1R Mini Wireless USB Dongle  
1740:9708=EnGenius 1T2R Mini Wireless USB Dongle  
1740:9709=EnGenius 2T2R Mini Wireless USB Dongle  
1740:9801=EnGenius 802.11 a/b/g/n Wireless USB Adapter  
1743=General Atomics  
1744=Sanwa Electronic Instrument  
1748=MQP Electronics  
174B=BARACODA  
174B:0001=Bluetooth COM One Device  
174B:0002=Bluetooth COM One Device  
174B:0003=Bluetooth COM One Device  
174C=ASMedia

174C:5106=Transcend StoreJet 25M3  
174C:55AA=ASM1051 USB 3.0 to SATA Bridge  
174C:55AA:0100=ASM1051 USB 3.0 to SATA Bridge (Icy Box)  
174F=Syntek  
174F:1105=SM-MS/Pro-MMC-XD Card Reader  
174F:111A=Realtek USB2.0 PC Camera  
174F:1403=Integrated Webcam  
174F:1404=USB Camera device, 1.3 MPixel Web Cam  
174F:1408=USB2.0 UVC 1.3M WebCam  
174F:5212=USB 2.0 UVC PC Camera  
174F:5931=USB2.0 UVC 1.3M WebCam  
174F:5933=WebCam SCB-1800D  
174F:5A11=PC Camera  
174F:5A31=USB 2.0 1.3M UVC WebCam  
174F:5A35=USB 2.0 1.3M UVC WebCam  
174F:5A3D=USB2.0 UVC 1.3M WebCam  
174F:5A51=USB 2.0 2M UVC WebCam  
174F:5A53=USB 2.0 UVC 2M AM Web cam  
174F:6831=USB2.0 1.3M WebCam  
174F:6A11=USB2.0 VGA WebCam  
174F:6A14=USB2.0 VGA WebCam  
174F:6A31=Web Cam - Asus A8J, F3S, F5R, VX2S, V1S  
174F:6A31:01=USB2.0 Video Enhancement Device  
174F:6A32=USB2.0 1.3M WebCam  
174F:6A32:01=USB2.0 Video Enhancement Device  
174F:6A33=Web Cam - Asus F3SA, F9J, F9S  
174F:6A34=USB2.0 1.3M WebCam  
174F:6A51=2.0MPixel Web Cam - Asus Z96J, Z96S, S96S  
174F:6A54=Web Cam  
174F:6A56=USB2.0 2M WebCam  
174F:6A57=USB2.0 2M WebCam  
174F:6C31=USB2.0 1.3M WebCam  
174F:6C31:01=USB2.0 Video Enhancement Device  
174F:6D51=2.0Mpixel Web Cam - Eurocom D900C  
174F:8A11=USB2.0 UVC VGA WebCam  
174F:8A12=Syntek 0.3MPixel USB 2.0 UVC PC Camera  
174F:8A31=USB2.0 UVC 1.3M WebCam  
174F:8A32=USB2.0 UVC 1.3M WebCam  
174F:8A33=Syntek USB 2.0 UVC PC Camera  
174F:8A34=USB2.0 UVC 1.3M WebCam  
174F:8A35=USB2.0 UVC 1.3M WebCam  
174F:8A36=USB2.0 UVC 1.3M WebCam  
174F:8A37=USB2.0 UVC 1.3M WebCam  
174F:8A38=USB2.0 UVC 1.3M WebCam  
174F:8A39=USB2.0 UVC 1.3M WebCam  
174F:8A51=USB2.0 UVC 2M WebCam  
174F:8A53=USB2.0 UVC 2M WebCam  
174F:8A54=USB2.0 UVC 2M WebCam  
174F:8A55=USB2.0 UVC 2M WebCam  
174F:8A56=USB2.0 UVC 2M WebCam  
174F:A311=1.3MPixel Web Cam - Asus A3A, A6J, A6K, A6M, A6R, A6T, A6V, A7T, A7sv,  
A7U  
174F:A311:01=USB2.0 Video Enhancement Device  
174F:A312=1.3MPixel Web Cam  
174F:A351=USB2.0 VGA WebCam  
174F:A351:01=USB2.0 VGA WebCam Video Enhancement Device  
174F:A821=Web Cam - Packard Bell BU45, PB Easynote MX66-208W  
174F:A821:01=USB2.0 VGA WebCam Video Enhancement Device  
174F:A822=USB2.0 VGA WebCam  
174F:A823=USB2.0 VGA WebCam

174F:AA11=Web Cam  
174F:AA11:01=USB2.0 VGA WebCam Video Enhancement Device  
174F:AA12=USB2.0 VGA WebCam  
174F:AB11=USB2.0 1.3M WebCam  
174F:AB11:01=USB2.0 Video Enhancement Device  
1753=GERTEC Telecomunicacoes  
1753:C901=PPC900 Pinpad Terminal  
1755=Electronics and Telecommunication Research Institute  
1758=FUTURECOM SYSTEMS GROUP INC.  
1759=Lucid Port Technology  
175E=AT KidSystems  
1761=ASUSTek Computer  
1761:0B05=ASUS 802.11n Network Adapter  
1764=KANOMAX JAPAN INC.  
1765=VK  
176E=UD electronic corp  
176F=Astralink Technology Pte  
1770=precisionWave  
1771=Shenzhen Alex Connector  
1772=System Level Solutions  
1773=InSync Speech Technologies  
1776=Arowana  
1776:501C=300K CMOS Camera  
177F=Sweex  
177F:0153=LW153 802.11n Adapter [ralink rt3070]  
177F:0154=Sweex LW154 Wireless 150N Nano Adapter USB  
177F:0313=LW313 802.11n Adapter [ralink rt2770 + rt2720]  
1781=Multiple Vendors  
1781:083E=MetaGeek Wi-Spy  
1781:083F=MetaGeek Wi-Spy 2.4x  
1781:0938=Iguanaworks USB IR Transceiver  
1781:0C9F=USBTinyISP AVR Programmer  
1782=Spreadtrum Communications  
1784=TopSeed Technology  
1784:0001=eHome Infrared Receiver (USBCIR)  
1784:0002=eHome Infrared Receiver (USBCIR)  
1784:0004=RF Combo Device  
1784:0006=eHome Infrared Receiver (USBCIR)  
1784:0007=eHome Infrared Transceiver  
1784:0008=eHome Infrared Receiver (USBCIR)  
1784:000A=eHome Infrared Transceiver  
1787=ATI AIB  
1788=ShenZhen Litkconn Technology  
178B=Panduit  
178C=URTEK TECHNOLOGIES INC  
1796=Printrex  
1797=JALCO  
1799=Belkin  
1799:7051=F5D7051 802.11g Adapter v1000 [Broadcom 4320]  
1799:8051=N1 Wireless USB Network Adapter  
179C=Net-2Com  
179D=Ricavision International  
179D:0010=eHome Infrared Receiver (USBCIR)  
179D:0020=eHome Infrared Receiver (USBCIR)  
17A0=Samson Technologies  
17A0:0001=C01U condenser microphone  
17A0:0002=Q1U dynamic microphone  
17A0:0100=C03U multi-pattern microphone  
17A0:0101=UB1 boundary microphone  
17A0:0200=StudioDock monitors (Internal Hub)

17A0:0201=StudioDock monitors (Audio)  
17A0:0301=Q2U handheld microphone with XLR  
17A0:0302=GoMic compact condenser microphone  
17A0:0310=Meteor condenser microphone  
17A1=Taiwan Advanced Sensor  
17A1:0128=USB 2.0 Compliance JPEG Video Camera  
17A4=Concept2  
17A4:0001=Performance Monitor 3  
17A4:0002=Performance Monitor 4  
17A5=Advanced Connection Technology  
17A6=Astron Clinica  
17A7=MICOMSOFTE  
17B3=Grey Innovation  
17B3:0004=Linux-USB Midi Gadget  
17B8:044C=eHome Infrared Receiver (USBCIR)  
17B8:04B0=eHome Infrared Receiver (USBCIR)  
17B8:1100=eHome Infrared Receiver (USBCIR)  
17BA=SAURIS GmbH  
17BA:0001=SAU510-USB [no firmware]  
17BA:0510=SAU510-USB and SAU510-USP plus JTAG Emulators  
17BA:0511=SAU510-USB Iso Plus JTAG Emulator  
17BA:0520=SAU510-USB Nano JTAG Emulator  
17BA:1511=Onboard Emulator on SAUModule development kit  
17BB=Weihai Dongxing Electronics  
17BC=Advanced Peripherals Technologies  
17BD=Citron Electronic  
17BE=Dongguan Yangming Precision of Plastic Metal Elec.Co.Lt  
17BF=Ampere  
17C1=Sirius Satellite Radio  
17C3=Singim International  
17C9=Andros  
17CC=Native Instruments  
17CC:041C=Audio 2 DJ  
17CC:0808=Maschine Controller  
17CC:0815=Audio Kontrol 1  
17CC:0839=Audio 4 DJ  
17CC:0D8D=Guitarrig Mobile  
17CC:1915=Session I/O  
17CC:1940=RigKontrol3  
17CC:1969=RigKontrol2  
17CC:1978=Audio 8 DJ  
17CC:2280=Medion MDPNA1500 in card reader mode  
17CC:2305=Traktor Kontrol X1  
17CC:4711=Kore Controller  
17CC:4712=Kore Controller 2  
17CC:BAFF=Traktor Kontrol S4  
17CF=Hip Hing Cable & Plug Mfy.  
17D0=Sanford L.P.  
17D3=Korea Techtron  
17D6=Samsung Electronics Research Institute  
17D6:E020=SERI E02 SCOM 6200 UMTS Phone  
17D6:E020:01=SERI E02 SCOM 6200 UMTS Phone  
17D6:E020:0010=SERI E02 SCOM 6200ES UMTS Phone  
17D6:E020:0010:01=SERI E02 SCOM 6200ES UMTS Phone  
17D6:E020:0020=SERI E02 SCOM 6200CS UMTS Phone  
17D6:E020:0020:01=SERI E02 SCOM 6200CS UMTS Phone  
17D6:E020:0030:01=SERI E02 SCOM 6210-A UMTS Phone  
17D6:E021=SERI E02 SCOM 6200 Virtual UARTs  
17D6:E021:0010=SERI E02 SCOM 6200ES Virtual UARTs  
17D6:E021:0020=SERI E02 SCOM 6200CS Virtual UARTs

17D6:E021:0030=SERI E02 SCOM 6210-A Virtual UARTs  
17D6:E022=SERI E02 SCOM 6200 Flash Load Disk  
17D6:E022:0010=SERI E02 SCOM 6200ES Flash Load Disk  
17D6:E022:0020=SERI E02 SCOM 6200CS Flash Load Disk  
17E9=Newnham Research  
17E9:0010=DisplayLink Display Adapter (0010)  
17E9:0011=DisplayLink Display Adapter (0011)  
17E9:0012=DisplayLink Display Adapter (0012)  
17E9:0013=DisplayLink Display Adapter (0013)  
17E9:0014=DisplayLink Display Adapter (0014)  
17E9:0015=DisplayLink Display Adapter (0015)  
17E9:0016=DisplayLink Display Adapter (0016)  
17E9:0017=DisplayLink Display Adapter (0017)  
17E9:0018=DisplayLink Display Adapter (0018)  
17E9:0019=DisplayLink Display Adapter (0019)  
17E9:001A=DisplayLink Display Adapter (001A)  
17E9:001B=DisplayLink Display Adapter (001B)  
17E9:001C=DisplayLink Display Adapter (001C)  
17E9:001D=DisplayLink Display Adapter (001D)  
17E9:001E=DisplayLink Display Adapter (001E)  
17E9:001F=DisplayLink Display Adapter (001F)  
17E9:0020=DisplayLink Display Adapter (0020)  
17E9:0021=DisplayLink Display Adapter (0021)  
17E9:0022=DisplayLink Display Adapter (0022)  
17E9:0023=DisplayLink Display Adapter (0023)  
17E9:0024=DisplayLink Display Adapter (0024)  
17E9:0025=DisplayLink Display Adapter (0025)  
17E9:0026=DisplayLink Display Adapter (0026)  
17E9:0027=DisplayLink Display Adapter (0027)  
17E9:0028=DisplayLink Display Adapter (0028)  
17E9:0029=DisplayLink Display Adapter (0029)  
17E9:002A=DisplayLink Display Adapter (002A)  
17E9:002B=DisplayLink Display Adapter (002B)  
17E9:002C=DisplayLink Display Adapter (002C)  
17E9:002D=DisplayLink Display Adapter (002D)  
17E9:002E=DisplayLink Display Adapter (002E)  
17E9:002F=DisplayLink Display Adapter (002F)  
17E9:0030=DisplayLink Display Adapter (0030)  
17E9:0031=DisplayLink Display Adapter (0031)  
17E9:0032=DisplayLink Display Adapter (0032)  
17E9:0033=DisplayLink Display Adapter (0033)  
17E9:0034=DisplayLink Display Adapter (0034)  
17E9:0035=DisplayLink Display Adapter (0035)  
17E9:0036=DisplayLink Display Adapter (0036)  
17E9:0037=DisplayLink Display Adapter (0037)  
17E9:0038=DisplayLink Display Adapter (0038)  
17E9:0039=DisplayLink Display Adapter (0039)  
17E9:003A=DisplayLink Display Adapter (003A)  
17E9:003B=DisplayLink Display Adapter (003B)  
17E9:003C=DisplayLink Display Adapter (003C)  
17E9:003D=DisplayLink Display Adapter (003D)  
17E9:003E=DisplayLink Display Adapter (003E)  
17E9:003F=DisplayLink Display Adapter (003F)  
17E9:0040=DisplayLink Display Adapter (0040)  
17E9:0041=DisplayLink Display Adapter (0041)  
17E9:0042=DisplayLink Display Adapter (0042)  
17E9:0043=DisplayLink Display Adapter (0043)  
17E9:0044=DisplayLink Display Adapter (0044)  
17E9:0045=DisplayLink Display Adapter (0045)  
17E9:0046=DisplayLink Display Adapter (0046)

17E9:0047=DisplayLink Display Adapter (0047)  
17E9:0048=DisplayLink Display Adapter (0048)  
17E9:0049=DisplayLink Display Adapter (0049)  
17E9:004A=DisplayLink Display Adapter (004A)  
17E9:004B=DisplayLink Display Adapter (004B)  
17E9:004C=DisplayLink Display Adapter (004C)  
17E9:004D=DisplayLink Display Adapter (004D)  
17E9:004E=DisplayLink Display Adapter (004E)  
17E9:004F=DisplayLink Display Adapter (004F)  
17E9:0050=DisplayLink Display Adapter (0050)  
17E9:0051=DisplayLink Display Adapter (0051)  
17E9:0052=DisplayLink Display Adapter (0052)  
17E9:0053=DisplayLink Display Adapter (0053)  
17E9:0054=DisplayLink Display Adapter (0054)  
17E9:0055=DisplayLink Display Adapter (0055)  
17E9:0056=DisplayLink Display Adapter (0056)  
17E9:0057=DisplayLink Display Adapter (0057)  
17E9:0058=DisplayLink Display Adapter (0058)  
17E9:0059=DisplayLink Display Adapter (0059)  
17E9:005A=DisplayLink Display Adapter (005A)  
17E9:005B=DisplayLink Display Adapter (005B)  
17E9:005C=DisplayLink Display Adapter (005C)  
17E9:005D=DisplayLink Display Adapter (005D)  
17E9:005E=DisplayLink Display Adapter (005E)  
17E9:005F=DisplayLink Display Adapter (005F)  
17E9:0100=DisplayLink Display Adapter (0100)  
17E9:0101=DisplayLink Display Adapter (0101)  
17E9:0102=DisplayLink Display Adapter (0102)  
17E9:0103=DisplayLink Display Adapter (0103)  
17E9:0104=DisplayLink Display Adapter (0104)  
17E9:0105=DisplayLink Display Adapter (0105)  
17E9:0106=DisplayLink Display Adapter (0106)  
17E9:0107=DisplayLink Display Adapter (0107)  
17E9:0108=DisplayLink Display Adapter (0108)  
17E9:0109=DisplayLink Display Adapter (0109)  
17E9:010A=DisplayLink Display Adapter (010A)  
17E9:010B=DisplayLink Display Adapter (010B)  
17E9:010C=DisplayLink Display Adapter (010C)  
17E9:010D=DisplayLink Display Adapter (010D)  
17E9:010E=DisplayLink Display Adapter (010E)  
17E9:010F=DisplayLink Display Adapter (010F)  
17E9:0110=DisplayLink Display Adapter (0110)  
17E9:0111=DisplayLink Display Adapter (0111)  
17E9:0112=DisplayLink Display Adapter (0112)  
17E9:0113=DisplayLink Display Adapter (0113)  
17E9:0114=DisplayLink Display Adapter (0114)  
17E9:0115=DisplayLink Display Adapter (0115)  
17E9:0116=DisplayLink Display Adapter (0116)  
17E9:0117=DisplayLink Display Adapter (0117)  
17E9:0118=DisplayLink Display Adapter (0118)  
17E9:0119=DisplayLink Display Adapter (0119)  
17E9:011A=DisplayLink Display Adapter (011A)  
17E9:011B=DisplayLink Display Adapter (011B)  
17E9:011C=DisplayLink Display Adapter (011C)  
17E9:011D=DisplayLink Display Adapter (011D)  
17E9:011E=DisplayLink Display Adapter (011E)  
17E9:011F=DisplayLink Display Adapter (011F)  
17E9:0120=DisplayLink Display Adapter (0120)  
17E9:0121=DisplayLink Display Adapter (0121)  
17E9:0122=DisplayLink Display Adapter (0122)



17E9:0123=DisplayLink Display Adapter (0123)  
17E9:0124=DisplayLink Display Adapter (0124)  
17E9:0125=DisplayLink Display Adapter (0125)  
17E9:0126=DisplayLink Display Adapter (0126)  
17E9:0127=DisplayLink Display Adapter (0127)  
17E9:0128=DisplayLink Display Adapter (0128)  
17E9:0129=DisplayLink Display Adapter (0129)  
17E9:012A=DisplayLink Display Adapter (012A)  
17E9:012B=DisplayLink Display Adapter (012B)  
17E9:012C=DisplayLink Display Adapter (012C)  
17E9:012D=DisplayLink Display Adapter (012D)  
17E9:012E=DisplayLink Display Adapter (012E)  
17E9:012F=DisplayLink Display Adapter (012F)  
17E9:0130=DisplayLink Display Adapter (0130)  
17E9:0131=DisplayLink Display Adapter (0131)  
17E9:0132=DisplayLink Display Adapter (0132)  
17E9:0133=DisplayLink Display Adapter (0133)  
17E9:0134=DisplayLink Display Adapter (0134)  
17E9:0135=DisplayLink Display Adapter (0135)  
17E9:0136=DisplayLink Display Adapter (0136)  
17E9:0137=DisplayLink Display Adapter (0137)  
17E9:0138=DisplayLink Display Adapter (0138)  
17E9:0139=DisplayLink Display Adapter (0139)  
17E9:013A=DisplayLink Display Adapter (013A)  
17E9:013B=DisplayLink Display Adapter (013B)  
17E9:013C=DisplayLink Display Adapter (013C)  
17E9:013D=DisplayLink Display Adapter (013D)  
17E9:013E=DisplayLink Display Adapter (013E)  
17E9:013F=DisplayLink Display Adapter (013F)  
17E9:0140=DisplayLink Display Adapter (0140)  
17E9:0141=DisplayLink Display Adapter (0141)  
17E9:0142=DisplayLink Display Adapter (0142)  
17E9:0143=DisplayLink Display Adapter (0143)  
17E9:0144=DisplayLink Display Adapter (0144)  
17E9:0145=DisplayLink Display Adapter (0145)  
17E9:0146=DisplayLink Display Adapter (0146)  
17E9:0147=DisplayLink Display Adapter (0147)  
17E9:0148=DisplayLink Display Adapter (0148)  
17E9:0149=DisplayLink Display Adapter (0149)  
17E9:014A=DisplayLink Display Adapter (014A)  
17E9:014B=DisplayLink Display Adapter (014B)  
17E9:014C=DisplayLink Display Adapter (014C)  
17E9:014D=DisplayLink Display Adapter (014D)  
17E9:014E=DisplayLink Display Adapter (014E)  
17E9:014F=DisplayLink Display Adapter (014F)  
17E9:0150=DisplayLink Display Adapter (0150)  
17E9:0151=DisplayLink Display Adapter (0151)  
17E9:0152=DisplayLink Display Adapter (0152)  
17E9:0153=DisplayLink Display Adapter (0153)  
17E9:0154=DisplayLink Display Adapter (0154)  
17E9:0155=DisplayLink Display Adapter (0155)  
17E9:0156=DisplayLink Display Adapter (0156)  
17E9:0157=DisplayLink Display Adapter (0157)  
17E9:0158=DisplayLink Display Adapter (0158)  
17E9:0159=DisplayLink Display Adapter (0159)  
17E9:015A=DisplayLink Display Adapter (015A)  
17E9:015B=DisplayLink Display Adapter (015B)  
17E9:015C=DisplayLink Display Adapter (015C)  
17E9:015D=DisplayLink Display Adapter (015D)  
17E9:015E=DisplayLink Display Adapter (015E)

17E9:015F=DisplayLink Display Adapter (015F)  
17E9:0160=DisplayLink Display Adapter (0160)  
17E9:0161=DisplayLink Display Adapter (0161)  
17E9:0162=DisplayLink Display Adapter (0162)  
17E9:0163=DisplayLink Display Adapter (0163)  
17E9:0164=DisplayLink Display Adapter (0164)  
17E9:0165=DisplayLink Display Adapter (0165)  
17E9:0166=DisplayLink Display Adapter (0166)  
17E9:0167=DisplayLink Display Adapter (0167)  
17E9:0168=DisplayLink Display Adapter (0168)  
17E9:0169=DisplayLink Display Adapter (0169)  
17E9:016A=DisplayLink Display Adapter (016A)  
17E9:016B=DisplayLink Display Adapter (016B)  
17E9:016C=DisplayLink Display Adapter (016C)  
17E9:016D=DisplayLink Display Adapter (016D)  
17E9:016E=DisplayLink Display Adapter (016E)  
17E9:016F=DisplayLink Display Adapter (016F)  
17E9:0170=DisplayLink Display Adapter (0170)  
17E9:0171=DisplayLink Display Adapter (0171)  
17E9:0172=DisplayLink Display Adapter (0172)  
17E9:0173=DisplayLink Display Adapter (0173)  
17E9:0174=DisplayLink Display Adapter (0174)  
17E9:0175=DisplayLink Display Adapter (0175)  
17E9:0176=DisplayLink Display Adapter (0176)  
17E9:0177=DisplayLink Display Adapter (0177)  
17E9:0178=DisplayLink Display Adapter (0178)  
17E9:0179=DisplayLink Display Adapter (0179)  
17E9:017A=DisplayLink Display Adapter (017A)  
17E9:017B=DisplayLink Display Adapter (017B)  
17E9:017C=DisplayLink Display Adapter (017C)  
17E9:017D=DisplayLink Display Adapter (017D)  
17E9:017E=DisplayLink Display Adapter (017E)  
17E9:017F=DisplayLink Display Adapter (017F)  
17E9:0180=DisplayLink Display Adapter (0180)  
17E9:0181=DisplayLink Display Adapter (0181)  
17E9:0182=DisplayLink Display Adapter (0182)  
17E9:0183=DisplayLink Display Adapter (0183)  
17E9:0184=DisplayLink Display Adapter (0184)  
17E9:0185=DisplayLink Display Adapter (0185)  
17E9:0186=DisplayLink Display Adapter (0186)  
17E9:0187=DisplayLink Display Adapter (0187)  
17E9:0188=DisplayLink Display Adapter (0188)  
17E9:0189=DisplayLink Display Adapter (0189)  
17E9:018A=DisplayLink Display Adapter (018A)  
17E9:018B=DisplayLink Display Adapter (018B)  
17E9:018C=DisplayLink Display Adapter (018C)  
17E9:018D=DisplayLink Display Adapter (018D)  
17E9:018E=DisplayLink Display Adapter (018E)  
17E9:018F=DisplayLink Display Adapter (018F)  
17E9:0190=DisplayLink Display Adapter (0190)  
17E9:0191=DisplayLink Display Adapter (0191)  
17E9:0192=DisplayLink Display Adapter (0192)  
17E9:0193=DisplayLink Display Adapter (0193)  
17E9:0194=DisplayLink Display Adapter (0194)  
17E9:0195=DisplayLink Display Adapter (0195)  
17E9:0196=DisplayLink Display Adapter (0196)  
17E9:0197=DisplayLink Display Adapter (0197)  
17E9:0198=DisplayLink Display Adapter (0198)  
17E9:0199=DisplayLink Display Adapter (0199)  
17E9:019A=DisplayLink Display Adapter (019A)

17E9:019B=DisplayLink Display Adapter (019B)  
17E9:019C=DisplayLink Display Adapter (019C)  
17E9:019D=DisplayLink Display Adapter (019D)  
17E9:019E=DisplayLink Display Adapter (019E)  
17E9:019F=DisplayLink Display Adapter (019F)  
17E9:01A0=DisplayLink Display Adapter (01A0)  
17E9:01A1=DisplayLink Display Adapter (01A1)  
17E9:01A2=DisplayLink Display Adapter (01A2)  
17E9:01A3=DisplayLink Display Adapter (01A3)  
17E9:01A4=DisplayLink Display Adapter (01A4)  
17E9:01A5=DisplayLink Display Adapter (01A5)  
17E9:01A6=DisplayLink Display Adapter (01A6)  
17E9:01A7=DisplayLink Display Adapter (01A7)  
17E9:01A8=DisplayLink Display Adapter (01A8)  
17E9:01A9=DisplayLink Display Adapter (01A9)  
17E9:01AA=DisplayLink Display Adapter (01AA)  
17E9:01AB=DisplayLink Display Adapter (01AB)  
17E9:01AC=DisplayLink Display Adapter (01AC)  
17E9:01AD=DisplayLink Display Adapter (01AD)  
17E9:01AE=DisplayLink Display Adapter (01AE)  
17E9:01AF=DisplayLink Display Adapter (01AF)  
17E9:01B0=DisplayLink Display Adapter (01B0)  
17E9:01B1=DisplayLink Display Adapter (01B1)  
17E9:01B2=DisplayLink Display Adapter (01B2)  
17E9:01B3=DisplayLink Display Adapter (01B3)  
17E9:01B4=DisplayLink Display Adapter (01B4)  
17E9:01B5=DisplayLink Display Adapter (01B5)  
17E9:01B6=DisplayLink Display Adapter (01B6)  
17E9:01B7=DisplayLink Display Adapter (01B7)  
17E9:01B8=DisplayLink Display Adapter (01B8)  
17E9:01B9=DisplayLink Display Adapter (01B9)  
17E9:01BA=DisplayLink Display Adapter (01BA)  
17E9:01BB=DisplayLink Display Adapter (01BB)  
17E9:01BC=DisplayLink Display Adapter (01BC)  
17E9:01BD=DisplayLink Display Adapter (01BD)  
17E9:01BE=DisplayLink Display Adapter (01BE)  
17E9:01BF=DisplayLink Display Adapter (01BF)  
17E9:01C0=DisplayLink Display Adapter (01C0)  
17E9:01C1=DisplayLink Display Adapter (01C1)  
17E9:01C2=DisplayLink Display Adapter (01C2)  
17E9:01C3=DisplayLink Display Adapter (01C3)  
17E9:01C4=DisplayLink Display Adapter (01C4)  
17E9:01C5=DisplayLink Display Adapter (01C5)  
17E9:01C6=DisplayLink Display Adapter (01C6)  
17E9:01C7=DisplayLink Display Adapter (01C7)  
17E9:01C8=DisplayLink Display Adapter (01C8)  
17E9:01C9=DisplayLink Display Adapter (01C9)  
17E9:01CA=DisplayLink Display Adapter (01CA)  
17E9:01CB=DisplayLink Display Adapter (01CB)  
17E9:01CC=DisplayLink Display Adapter (01CC)  
17E9:01CD=DisplayLink Display Adapter (01CD)  
17E9:01CE=DisplayLink Display Adapter (01CE)  
17E9:01CF=DisplayLink Display Adapter (01CF)  
17E9:01D0=DisplayLink Display Adapter (01D0)  
17E9:01D1=DisplayLink Display Adapter (01D1)  
17E9:01D2=DisplayLink Display Adapter (01D2)  
17E9:01D3=DisplayLink Display Adapter (01D3)  
17E9:01D4=DisplayLink Display Adapter (01D4)  
17E9:01D5=DisplayLink Display Adapter (01D5)  
17E9:01D6=DisplayLink Display Adapter (01D6)

17E9:01D7=DisplayLink Display Adapter (01D7)  
17E9:01D8=DisplayLink Display Adapter (01D8)  
17E9:01D9=DisplayLink Display Adapter (01D9)  
17E9:01DA=DisplayLink Display Adapter (01DA)  
17E9:01DB=DisplayLink Display Adapter (01DB)  
17E9:01DC=DisplayLink Display Adapter (01DC)  
17E9:01DD=DisplayLink Display Adapter (01DD)  
17E9:01DE=DisplayLink Display Adapter (01DE)  
17E9:01DF=DisplayLink Display Adapter (01DF)  
17E9:01E0=DisplayLink Display Adapter (01E0)  
17E9:01E1=DisplayLink Display Adapter (01E1)  
17E9:01E2=DisplayLink Display Adapter (01E2)  
17E9:01E3=DisplayLink Display Adapter (01E3)  
17E9:01E4=DisplayLink Display Adapter (01E4)  
17E9:01E5=DisplayLink Display Adapter (01E5)  
17E9:01E6=DisplayLink Display Adapter (01E6)  
17E9:01E7=DisplayLink Display Adapter (01E7)  
17E9:01E8=DisplayLink Display Adapter (01E8)  
17E9:01E9=DisplayLink Display Adapter (01E9)  
17E9:01EA=DisplayLink Display Adapter (01EA)  
17E9:01EB=DisplayLink Display Adapter (01EB)  
17E9:01EC=DisplayLink Display Adapter (01EC)  
17E9:01ED=DisplayLink Display Adapter (01ED)  
17E9:01EE=DisplayLink Display Adapter (01EE)  
17E9:01EF=DisplayLink Display Adapter (01EF)  
17E9:01F0=DisplayLink Display Adapter (01F0)  
17E9:01F1=DisplayLink Display Adapter (01F1)  
17E9:01F2=DisplayLink Display Adapter (01F2)  
17E9:01F3=DisplayLink Display Adapter (01F3)  
17E9:01F4=DisplayLink Display Adapter (01F4)  
17E9:01F5=DisplayLink Display Adapter (01F5)  
17E9:01F6=DisplayLink Display Adapter (01F6)  
17E9:01F7=DisplayLink Display Adapter (01F7)  
17E9:01F8=DisplayLink Display Adapter (01F8)  
17E9:01F9=DisplayLink Display Adapter (01F9)  
17E9:01FA=DisplayLink Display Adapter (01FA)  
17E9:01FB=DisplayLink Display Adapter (01FB)  
17E9:01FC=DisplayLink Display Adapter (01FC)  
17E9:01FD=DisplayLink Display Adapter (01FD)  
17E9:01FE=DisplayLink Display Adapter (01FE)  
17E9:01FF=DisplayLink Display Adapter (01FF)  
17E9:037C=Plugable DC-125  
17E9:8010=DisplayLink Display Adapter (8010)  
17E9:8030=DisplayLink Display Adapter (8030)  
17E9:8031=DisplayLink Display Adapter (8031)  
17E9:8032=DisplayLink Display Adapter (8032)  
17E9:8033=DisplayLink Display Adapter (8033)  
17E9:8034=DisplayLink Display Adapter (8034)  
17E9:8040=DisplayLink Display Adapter (8040)  
17E9:8041=DisplayLink Display Adapter (8041)  
17E9:8042=DisplayLink Display Adapter (8042)  
17E9:8043=DisplayLink Display Adapter (8043)  
17E9:8044=DisplayLink Display Adapter (8044)  
17E9:8050=DisplayLink Display Adapter (8050)  
17E9:8051=DisplayLink Display Adapter (8051)  
17E9:8052=DisplayLink Display Adapter (8052)  
17E9:8053=DisplayLink Display Adapter (8053)  
17E9:8054=DisplayLink Display Adapter (8054)  
17E9:8060=DisplayLink Display Adapter (8060)  
17E9:8061=DisplayLink Display Adapter (8061)

17E9:8062=DisplayLink Display Adapter (8062)  
17E9:8063=DisplayLink Display Adapter (8063)  
17E9:8064=DisplayLink Display Adapter (8064)  
17E9:8070=DisplayLink Display Adapter (8070)  
17E9:8071=DisplayLink Display Adapter (8071)  
17E9:8072=DisplayLink Display Adapter (8072)  
17E9:8073=DisplayLink Display Adapter (8073)  
17E9:8074=DisplayLink Display Adapter (8074)  
17EB=Cornice  
17EF=Lenovo  
17EF:1003=Integrated Smart Card Reader  
17EF:1004=Integrated Camera  
17EF:100A=ThinkPad Mini Dock Plus Series 3  
17EF:3815=2GB USB Stick  
17EF:4802=Lenovo Vc0323+MI1310\_SOC Camera  
17EF:4807=Integrated Camera  
17EF:4808=Integrated Camera  
17EF:4809=Integrated Camera  
17EF:480A=Integrated Camera  
17EF:480B=Integrated Camera  
17EF:480C=Integrated Camera  
17EF:480D=Integrated Webcam [R5U877]  
17EF:480E=Integrated Webcam [R5U877]  
17EF:480F=Integrated Webcam [R5U877]  
17EF:4810=Integrated Webcam [R5U877]  
17EF:4811=Integrated Webcam [R5U877]  
17EF:4812=Integrated Webcam [R5U877]  
17EF:4813=Integrated Webcam [R5U877]  
17EF:4814=Integrated Webcam [R5U877]  
17EF:4815=Integrated Webcam [R5U877]  
17EF:4816=Integrated Camera  
17EF:4817=Integrated Camera  
17EF:4818=Integrated Camera  
17EF:4819=Integrated Camera  
17EF:481A=Integrated Camera  
17EF:481B=Integrated Camera  
17EF:481C=Integrated Webcam  
17EF:481D=Integrated Camera  
17EF:5700=Lenovo M800 Series  
17EF:6004=Wacom USB Pen  
17EF:6007=Smartcard Keyboard  
17EF:6009=ThinkPad Keyboard with TrackPoint  
17EF:6014=Mini Wireless Keyboard N5901  
17EF:7201=Lenovo Bluetooth 2.1 UHE Dongle  
17EF:FF50=Conexant USB CX93010 ACF Modem  
17F0=Bestronic Industry  
17F2=Xmultiple Technologies  
17F5=K.K. Rocky  
17F6=Unicomp  
17F6:0709=Model M Keyboard  
17F8=Enustech  
17FC=Vitesse Semiconductor  
1805=Digital Peripheral Solutions  
1809=Advantech  
1809:4761=USB-4761 Portable Data Acquisition Module  
180C=Power Digital Card  
180D=U3, LLC  
1814=Fashionow  
181A=Fotonation  
181E=Advanced Tracking Technologies

1822=Twinhan  
1822:3201=TwinHan USB adapter firmware loader  
1822:3202=USBDTT - USB DVB-T adapter  
1826=Xitron  
1827=Sanko Electronics  
1828=TSR Silicon Resources  
1829=Suzhou YuQiu Technology  
182D:096B=Sitecom Wireless Network USB adapter 100G+ WL-107  
1831=Gwo Jinn Industries  
1832=Huizhou Shenghua Industrial  
1836=ePoint Technology  
1836:0006=SCDTech UMP  
1839=AnexTEK Global  
183D=VIVOphone  
183D:0010=VoiceKey  
1842=Keen High Technologies (HK)  
1843=Vaisala  
1847=Global Payment Technologies  
1849=ASRock  
1852=TENOR ELECTRONICS  
1852:7922=Audiotrak DR.DAC2 DX  
1854=Memory Devices  
185B=Compro  
185B:0082=VideoMate Live  
185B:1000=Compro VideoMate for You  
185B:1001=Compro VideoMate for You  
185B:1040=Compro VideoMate for You  
185B:1041=Compro VideoMate for You  
185B:2200=VideoMate DVB U2200  
185B:2700=VideoMate DVB U2700  
185B:3000=VideoMate Action  
185B:3000:01=USB Audio Device  
185B:3000:03=VideoMate Action Remote Wake Up Device  
185B:3001=VideoMate Action  
185B:3001:01=USB Audio Device  
185B:3001:03=VideoMate Action Remote Wake Up Device  
185B:3020=K100 Infrared Receiver  
185B:3040=VideoMate Action  
185B:3040:01=USB Audio Device  
185B:3040:03=VideoMate Action Remote Wake Up Device  
185B:3041=VideoMate Action  
185B:3041:01=USB Audio Device  
185B:3041:03=VideoMate Action Remote Wake Up Device  
185B:3082=K100 Infrared Receiver v2  
185B:3100=VideoMate Action  
185B:3101=VideoMate Action  
185B:3140=VideoMate Action  
185B:3140:01=USB Audio Device  
185B:3140:03=VideoMate Action Remote Wake Up Device  
185B:3141=VideoMate Action  
185B:3141:01=USB Audio Device  
185B:3141:03=VideoMate Action Remote Wake Up Device  
185B:4000=VideoMate U8xx/U9xx  
185B:D000=VideoMate DVB-U2000 firmware loader  
185B:D001=VideoMate DVB-U2000  
1860=HYUPJIN I & C CO,  
1861=Tech Technology Industrial Company  
1862=Teridian Semiconductor  
1862:0000=Teridian Semiconductors USB CCID Smart Card Reader-5.0.0.8-Rel  
1870=Nexio

1870:0001=iNexio Touchscreen controller  
1871=Aveo Technology  
1871:0D01=USB2.0 Camera  
1872=Cobalt Technologies  
1872:1002=WDF Driver for Cobalt USB Stick K1  
1872:2001=WDF Driver for Cobalt USB Stick K2  
1872:3301=WDF Driver for Cobalt USB Stick K3  
1872:3302=WDF Driver for Cobalt USB Stick K2P  
1872:3303=WDF Driver for Cobalt USB Stick K3M  
1873=Etrovision Technology  
1873:EE93=EasyLogger  
187C=Alienware  
187C:0512=Quicksilver  
187C:0515=Logitech HID-compliant Merciless Gaming Mouse  
187C:0600=Dual Compatible Game Pad  
187F=Siano Mobile Silicon  
187F:0010=Stallar Board  
187F:0100=Stallar Board  
187F:0200=Nova A  
187F:0201=Nova B  
187F:0202=Nice  
187F:0300=Vega  
187F:0301=VeNice  
1880=Vericon  
188D=Across Techno  
1892=Vast Technologies  
1894=Topseed  
1894:5632=Atek Tote Remote  
1894:5641=TSAM-004 Presentation Remote  
1896=Legacy Electronics  
1897=Evertop Wire Cable  
1898=Summit Microelectronics  
1899=Linkiss  
189A=Earth Computer Technologies  
189B=Trimax Electronics  
189C=Walletex Microelectronics  
18A4=CSSN  
18A4:0001=Snapshell IDR  
18A5=Verbatim  
18A5:0214=Portable Hard Drive  
18A5:0216=External Hard Drive  
18A5:0218=External Hard Drive  
18A5:0227=Pocket Hard Drive  
18B1=Petalynx  
18B1:0037=Maxter Remote Control  
18B4=e3C Technologies  
18B4:1001=DUTV007  
18B4:1002=EC168 (v5) based USB DVB-T receiver  
18B4:1689=DUTV009  
18B4:FFFA=EC168 (v2) based USB DVB-T receiver  
18B4:FFFB=EC168 based USB DVB-T receiver  
18B6=Mikkon Technology  
18B7=Zotek Electronic  
18C5=AMIT  
18C5:0002=CG-WLUSB2GO, corega Wireless USB Adapter  
18C5:0008=CG-WLUSB2GMR, corega Wireless USB Adapter  
18C5:0012=CG-WLUSB10 corega Wireless USB Adapter  
18CD=Ecamm  
18CD:CAFE=Pico iMage  
18D1=Google

18D1:4E11=Nexus One Phone  
18D1:4E12=Nexus One Phone (Debug)  
18D1:4E13=Nexus One Phone (USB Tether)  
18D1:4E20=Nexus S (fastboot)  
18D1:4E21=Nexus S  
18D1:4E22=Nexus S (debug)  
18D1:4E24=Nexus S (tether)  
18D1:708C=Mot Single ADB Interface  
18D1:70AC=Mot Single ADB Interface  
18D1:7102=Toshiba Thrive tablet  
18D1:D00D=Android Sooner Single ADB Interface  
18D1:DDDD=Android Sooner ADB Testing Interface  
18D1:DEED:01=Android Sooner Composite ADB Interface  
18D1:DEED:02=Android Sooner Kernel Debug Interface  
18D5=Starline International Group  
18D9=Kaba  
18D9:0001=LEGIC advant desktop reader  
18D9:01A0=B-Net 91 07  
18DD=Planon System Solutions  
18DD:1000=DocuPen RC800  
18E3=Fitipower Integrated Technology  
18E3:7102=Multi Card Reader (Internal)  
18E3:9101=All-in-1 Card Reader  
18E3:9102=Multi car reader  
18E3:9512=Webcam  
18E8=Qcom  
18E8:2124=Broadcom Bluetooth 3.0 USB  
18E8:6144=LR802UA 802.11b Wireless Adapter [ALi M4301AU]  
18E8:6171=802.11b/g USB Wireless LAN Adapter  
18E8:6196=RT73 USB Wireless LAN Card  
18E8:6216=USB Bluetooth Driver (V2.1+EDR)  
18E8:6229=RT73 USB Wireless LAN Card  
18E8:6232=Wireless 802.11g 54Mbps Network Adapter [RTL8187]  
18E8:6232:0100=Realtek RTL8187 Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
18E8:6238=RT73 USB Wireless LAN Card  
18E8:6240=Broadcom Bluetooth 3.0 USB  
18E8:6252=Broadcom Bluetooth USB  
18E8:6253=Broadcom Bluetooth 2.1 + EDR USB Device  
18E8:6256=Broadcom Bluetooth 2.1 + EDR USB Device  
18E8:6258=Broadcom Bluetooth 2.1 + EDR USB Device  
18E8:6259=802.11n USB Wireless LAN Card  
18E8:6260=Broadcom BCM2070 Bluetooth 2.1+EDR USB Device  
18EA=Matrox Graphics  
18EA:0002=DualHead2Go [Analog Edition]  
18EA:0004=TripleHead2Go [Digital Edition]  
18EC=Arkmicro Technologies  
18EC:3118=USB to IrDA adapter [ARK3116T]  
18EC:3188=ARK3188 UVC Webcam  
18EF:E000=ELV Universal-Sound-Recorder  
18EF:E001=ELV Mini-Sound-Modul  
18EF:E004=WS 550  
18FA=Kuang Ying Computer Equipment  
18FD=FineArch  
1908=GEMBIRD  
1908:1320=PhotoFrame PF-15-1  
190D=Motorola GSG  
1914=Alco Digital Devices  
1915=Linksys  
1915:2233=WUSB11 v2.8 802.11b Adapter  
1915:2234=Linksys Wireless-G USB Network Adapter



1915:2235=Linksys Wireless-G Portable USB Adapter  
1915:2236=WUSB11 v3.0 802.11b Adapter  
1919=Pixelworks  
1926=NextWindow  
1926:0003=1900 HID Touchscreen  
1926:0003:01=NextWindow Multi-touch Device  
1926:0006=1950 HID Touchscreen  
1926:0064=1950 HID Touchscreen  
1926:0065=1950 HID Touchscreen  
1926:0066=1950 HID Touchscreen  
1926:0067=1950 HID Touchscreen  
1926:0068=1950 HID Touchscreen  
1926:0069=1950 HID Touchscreen  
1926:0071=1950 HID Touchscreen  
1926:0072=1950 HID Touchscreen  
1926:0073=1950 HID Touchscreen  
1926:0074=1950 HID Touchscreen  
1926:0075=1950 HID Touchscreen  
1926:0076=1950 HID Touchscreen  
1926:0077=1950 HID Touchscreen  
1926:0078=1950 HID Touchscreen  
1926:0079=1950 HID Touchscreen  
1926:007A=HID Touchscreen  
1926:007E=1950 HID Touchscreen  
1926:007F=1950 HID Touchscreen  
1926:0080=1950 HID Touchscreen  
1926:0081=1950 HID Touchscreen  
1926:0082=1950 HID Touchscreen  
1926:0083=1950 HID Touchscreen  
1926:0084=1950 HID Touchscreen  
1926:0085=1950 HID Touchscreen  
1926:0086=1950 HID Touchscreen  
1926:0087=1950 HID Touchscreen  
192F=Avago Technologies, Pte.  
192F:0000=Mouse  
1930=Shenzhen Xianhe Technology  
1931=Ningbo Broad Telecommunication  
1934=Feature Integration Technology  
1934:0602=eHome Infrared Receiver (USBCIR)  
1934:0702=eHome Infrared Receiver (USBCIR)  
1934:5168=F71610A or F71612A Consumer Infrared Receiver/Transceiver  
1940:AC01=USB PnP Sound Device  
1940:AC02=USB PnP Sound Device  
1940:AC03=USB PnP Sound Device  
1941=Dream Link  
1941:8021=USB Missile Launcher  
1943=Sensoray  
1943:2250=Model 2250 MPEG and JPEG Capture Card  
1943:2253=Model 2253 Audio/Video Codec Card  
1943:2255=Model 2255 4 Channel Capture Card  
1943:2257=Model 2257 4 Channel Capture Card  
1943:A250=Model 2250 MPEG and JPEG Capture Card (cold)  
1943:A253=Model 2253 Audio/Video Codec Card (cold)  
1949=Lab126  
1949:0002=Amazon Kindle  
1949:0004=Amazon Kindle 3  
1951=Hyperstone AG  
1953=Ironkey  
1954=Radiient Technologies  
1957=BIOS

195D=Itron Technology iONE  
195D:7002=Libra-Q11 IR remote  
195D:7006=Libra-Q26 / 1.0 Remote  
195D:7777=Scorpius wireless keyboard  
195D:7779=Scorpius-P20MT  
1963=Freecom  
1963:1300=USB Card Series Driver  
1965:0004=Phone for Windows Live Messenger  
1965:0005=Phone for Windows Live Messenger  
1967=CASIO HITACHI Mobile Communications  
196B=Wispro Technology  
1970=Dane-Elec  
1975=Dongguan Guneetal Wire & Cable  
1976=Chipsbrand Microelectronics (HK)  
1976:6025=Flash Drive 512 MB  
1977=T-Logic  
1977:0111=TL203 MP3 Player and Voice Recorder  
1989=Nuconn Technology  
198D=Fairchild Imaging  
198F=Beceem Communications  
198F:0210=BCS200 WiMAX Adapter  
198F:0220=BCSM250 WiMAX Adapter  
1990=Acron Precision Industrial  
1995=Trillium Technology  
1995:3202=REC-ADPT-USB (recorder)  
1995:3203=REC-A-ADPT-USB (recorder)  
199C=Richtek Technology  
199D=Dexxon  
199E=The Imaging Source Europe GmbH  
199E:8101=DFx 21BU04 Camera  
199F=Benica  
19A8=Biforst Technology  
19AB=Bodelin  
19AB:1000=ProScope HR  
19AF=S Life  
19AF:6611=Celestia VoIP Phone  
19B2=Batronix  
19B2:0010=BX32 Batupo  
19B2:0011=BX32P Barlino  
19B2:0012=BX40 Bagero  
19B2:0013=BX48 Batego  
19B4=Celestron  
19B4:0002=SkyScout Personal Planetarium  
19B4:0101=Handheld Digital Microscope 44302  
19B5=B & W Group  
19B6=Infotech Logistic, LLC  
19B9=Data Robotics  
19B9:8D20=Drobo Elite  
19CA=Mindtribe  
19CA:0001=Sandio 3D HID Mouse  
19CF=Parrot SA  
19D2=ONDA Communication S.p.A.  
19D2:0001=ONDA USB Modem  
19D2:0001:01=ONDA USB Diagnostics Port  
19D2:0001:03=ONDA USB Smart Card Reader  
19D2:0002=ET502HS/MT505UP ZTE MF632  
19D2:0007=ZTE TU25 WiMAX Adapter [Beceem BCS200]  
19D2:0010=ZTE Handset USB Modem 6000  
19D2:0010:01=ZTE Handset Diagnostics Interface  
19D2:0010:02=ZTE Handset NMEA Device

19D2:0031=ZTE MF636  
19D2:0063=ZTE K3565-Z HSDPA  
19D2:0064=ZTE MF627 AU  
19D2:0083=ZTE MF190  
19D2:0103=ZTE MF112  
19D2:0172=AX226 WIMAX MODEM (After Modeswitch)  
19D2:2000=ZTE MF627/MF628/MF628+ HSDPA  
19D2:FFF2=Gobi Wireless Modem (QDL mode)  
19D2:FFF3=Gobi Wireless Modem  
19E1=WeiDuan Electronic Accessory (S.Z.)  
19E8=Industrial Technology Research Institute  
19EF=Pak Heng Technology (Shenzhen)  
19F0=Jyh Woei Industrial  
19F7=RODE Microphones  
19F7:0001=Podcaster  
19FA=Gampaq  
19FA:0703=Steering Wheel  
19FF=Rocketfish (?)  
19FF:0102=1.3MP Webcam  
19FF:0200=Rocketfish Bluetooth Adapter  
19FF:0201=Wireless 2.4G Laser Mouse  
1A08=Bellwood International  
1A0A=USB-IF non-workshop  
1A0A:BADD=USB OTG Compliance test device  
1A12=KES  
1A1D=Veho  
1A1D:0407=Mimi WiFi speakers  
1A25=Amphenol East Asia  
1A2A=Seagate Branded Solutions  
1A32=Quanta Microsystems  
1A32:0304=802.11n Wireless LAN Card  
1A35=Astec Power, a division of Emerson Network Power  
1A36=Biwin Technology  
1A40=Terminus Technology  
1A40:0101=USB V2.0 4-Port Hub  
1A40:0201=Hub  
1A41=Action Electronics  
1A44=VASCO Data Security International  
1A44:0001=Digipass 905 SmartCard Reader  
1A4A=Silicon Image  
1A4B=SafeBoot International B.V.  
1A61=Abbott Diabetes Care  
1A6A=Spansion  
1A6D=SamYoung Electronics  
1A6E=Global Unichip  
1A6F=Sagem Orga GmbH  
1A74=Oberthur Technologies  
1A74:6354=On Chip Security USB driver  
1A79=Bayer Health Care LLC  
1A7B=Lumberg Connect  
1A7C=Kingsis Peripherals  
1A7C:0068=Evoluent VerticalMouse 3  
1A7C:0168=VerticalMouse 3 Wireless  
1A7C:0191=VerticalMouse 4  
1A81=Holtek Semiconductor  
1A81:2203=Laser Gaming mouse  
1A81:2204=Optical Mouse  
1A82=Proconn Technology  
1A86=QinHeng Electronics  
1A86:5523=CH341 in serial mode, usb to serial port converter

1A86:5584=CH341 in parallel mode, usb to printer port converter  
1A86:7523=HL-340 USB-Serial adapter  
1A86:752D=CH345 MIDI adapter  
1A86:7584=CH340S  
1A86:E008=HID-based USB-serial converter, full-speed, similar to HE2325U  
1A89=Dynalith Systems  
1A8A=Simula Technology  
1A8B=SGS Taiwan  
1A8D=BandRich  
1A8D:1002=BandLuxe 3.5G HSDPA Adapter  
1A8D:1009=BandLuxe 3.5G HSPA Adapter  
1A90=Mentor Graphics  
1A90:0001=USB Serial Host Device  
1A98=Leica Camera AG  
1AA4=Data Drive Thru  
1AA5=UBeacon Technologies  
1AA6=eFortune Technology  
1AA6:0201=USB Disk Drive  
1AAE=Johnson Component & Equipments  
1AB1=Rigol Technologies  
1AB1:0588=DS1000 SERIES  
1ACB=Salcomp Plc  
1AD1=Desay Wire  
1ADB=SEL C662 Serial Cable  
1AE4=ic-design Reinhard Gottinger GmbH  
1AE5=Jianduan Technology (Shenzhen)  
1AE7=X-TENSIONS  
1AE7:0381=VS-DVB-T 380U (af9015 based)  
1AE7:0802=SL-6697 Leather Force Feedback Wheel  
1AE7:0A07=SL-6696 USB Power Feedback Wheel  
1AE7:0A08=SL-6694 USB Power Feedback Wheel  
1AE7:0A20=SL-6693 Force Vibration Wheel  
1AE7:0C40=SL-6698 4in1 Power Feedback Leather Wheel  
1AE7:2001=SpeedLink SL-6825  
1AE7:3000=SL-6695 USB Power Feedback Leather Wheel  
1AED=High Top Precision Electronic  
1AEE=Dongguan Chang'an Jinxia Rex Electronics Factory  
1AEF=Conntech Electronic (Suzhou)  
1B04=Meilhaus Electronic GmbH  
1B04:0630=ME-630  
1B04:0940=ME-94  
1B04:0950=ME-95  
1B04:0960=ME-96  
1B04:1000=ME-1000  
1B04:100A=ME-1000  
1B04:100B=ME-1000  
1B04:1400=ME-1400  
1B04:140A=ME-1400A  
1B04:140B=ME-1400B  
1B04:140C=ME-1400C  
1B04:140D=ME-1400D  
1B04:140E=ME-1400E  
1B04:14EA=ME-1400EA  
1B04:14EB=ME-1400EB  
1B04:1604=ME-1600/4U  
1B04:1608=ME-1600/8U  
1B04:160C=ME-1600/12U  
1B04:160F=ME-1600/16U  
1B04:168F=ME-1600/16U8I  
1B04:4610=ME-4610

1B04:4650=ME-4650  
1B04:4660=ME-4660  
1B04:4661=ME-4660I  
1B04:4662=ME-4660  
1B04:4663=ME-4660I  
1B04:4670=ME-4670  
1B04:4671=ME-4670I  
1B04:4672=ME-4670S  
1B04:4673=ME-4670IS  
1B04:4680=ME-4680  
1B04:4681=ME-4680I  
1B04:4682=ME-4680S  
1B04:4683=ME-4680IS  
1B04:6004=ME-6000/4  
1B04:6008=ME-6000/8  
1B04:600F=ME-6000/16  
1B04:6014=ME-6000I/4  
1B04:6018=ME-6000I/8  
1B04:601F=ME-6000I/16  
1B04:6034=ME-6000ISLE/4  
1B04:6038=ME-6000ISLE/8  
1B04:603F=ME-6000ISLE/16  
1B04:6044=ME-6000/4/DIO  
1B04:6048=ME-6000/8/DIO  
1B04:604F=ME-6000/16/DIO  
1B04:6054=ME-6000I/4/DIO  
1B04:6058=ME-6000I/8/DIO  
1B04:605F=ME-6000I/16/DIO  
1B04:6074=ME-6000ISLE/4/DIO  
1B04:6078=ME-6000ISLE/8/DIO  
1B04:607F=ME-6000ISLE/16/DIO  
1B04:6104=ME-6100/4  
1B04:6108=ME-6100/8  
1B04:610F=ME-6100/16  
1B04:6114=ME-6100I/4  
1B04:6118=ME-6100I/8  
1B04:611F=ME-6100I/16  
1B04:6134=ME-6100ISLE/4  
1B04:6138=ME-6100ISLE/8  
1B04:613F=ME-6100ISLE/16  
1B04:6144=ME-6100/4/DIO  
1B04:6148=ME-6100/8/DIO  
1B04:614F=ME-6100/16/DIO  
1B04:6154=ME-6100I/4/DIO  
1B04:6158=ME-6100I/8/DIO  
1B04:615F=ME-6100I/16/DIO  
1B04:6174=ME-6100ISLE/4/DIO  
1B04:6178=ME-6100ISLE/8/DIO  
1B04:617F=ME-6100ISLE/16/DIO  
1B04:6259=ME-6200I/9/DIO  
1B04:6359=ME-6300I/9/DIO  
1B04:810A=ME-8100A  
1B04:810B=ME-8100B  
1B04:820A=ME-8200A  
1B04:820B=ME-8200B  
1B0E=BLUTRONICS S.r.l.  
1B0E:1078=BLUDRIVE II CCID  
1B1C=CORSAIR MEMORY INC.  
1B1C:0890=Flash Padlock  
1B1C:0A00=SP2500 Speakers

1B1C:1A90=Flash Voyager GT  
1B20=MStar Semiconductor  
1B22=WiLinx  
1B26=Cellex Power Products  
1B27=Current Electronics  
1B28=NAVIsis  
1B32=Ugobe  
1B32:0064=Pleo robotic dinosaur  
1B36=ViXS Systems  
1B3B=iPassion Technology  
1B3B:2933=PC Camera/Webcam controller  
1B3B:2935=PC Camera/Webcam controller  
1B3B:2936=PC Camera/Webcam controller  
1B3B:2937=PC Camera/Webcam controller  
1B3B:2938=PC Camera/Webcam controller  
1B3B:2939=PC Camera/Webcam controller  
1B3B:2950=PC Camera/Webcam controller  
1B3B:2951=PC Camera/Webcam controller  
1B3B:2952=PC Camera/Webcam controller  
1B3B:2953=PC Camera/Webcam controller  
1B3B:2955=PC Camera/Webcam controller  
1B3B:2956=PC Camera/Webcam controller  
1B3B:2957=PC Camera/Webcam controller  
1B3B:2958=PC Camera/Webcam controller  
1B3B:2959=PC Camera/Webcam controller  
1B3B:2960=PC Camera/Webcam controller  
1B3B:2961=PC Camera/Webcam controller  
1B3B:2962=PC Camera/Webcam controller  
1B3B:2963=PC Camera/Webcam controller  
1B3B:2965=PC Camera/Webcam controller  
1B3B:2966=PC Camera/Webcam controller  
1B3B:2967=PC Camera/Webcam controller  
1B3B:2968=PC Camera/Webcam controller  
1B3B:2969=PC Camera/Webcam controller  
1B3F=Generalplus Technology  
1B47=Energizer Holdings  
1B47:0001=Energizer USB Charger  
1B48=Plastron Precision  
1B59=K.S. Terminals  
1B5A=Chao Zhou Kai Yuan Electric  
1B64:0138=eHome Infrared Receiver (USBCIR)  
1B65=The Hong Kong Standards and Testing Centre  
1B72=ATERGI TECHNOLOGY  
1B73=Fresco Logic  
1B73:1000=xHC1 Controller  
1B75=Ovislink  
1B75:3071=Airlive WN-301USB  
1B75:3072=AirLive WN-360USB adapter  
1B75:7318=AirLive Turbo Wireless USB Adaptor  
1B75:8187=AirLive WL-1600USB 802.11g Adapter [Realtek RTL8187L]  
1B75:8187:0100=Realtek RTL8187 Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
1B75:9170=Airlive X.USB [AR9170]  
1B75:A200=AirLive WN-200USB wireless 11b/g/n dongle  
1B76=Legend Silicon  
1B80=Afatech  
1B80:C140=AF9015 BDA Device  
1B80:C141=AF9015 BDA Device  
1B80:C142=AF9015 BDA Device  
1B80:C160=AF9015 BDA Device  
1B80:C161=AF9015 BDA Device

1B80:C800=AF9015 BDA Device  
1B80:C810=AF9015 BDA Device  
1B80:C815=AF9015 BDA Device  
1B80:C820=AF9015 BDA Device  
1B80:D393=DVB-T receiver [RTL2832U]  
1B80:D396=UB396-T [RTL2832U]  
1B80:D397=DVB-T receiver [RTL2832U]  
1B80:D398=DVB-T receiver [RTL2832U]  
1B80:D700=FM Radio SnapMusic Mobile 700 (FM700)  
1B80:D715=USB Multi-Channel Audio Device  
1B80:E302=Roxio Video Capture USB  
1B80:E34A=Roxio Video Capture USB  
1B80:E383=DVB-T UB383-T [af9015]  
1B80:E385=DVB-T UB385-T [af9015]  
1B80:E386=DVB-T UB385-T [af9015]  
1B80:E395=AF9015 BDA Device  
1B80:E396=AF9015 BDA Device  
1B80:E397=AF9015 BDA Device  
1B80:E398=AF9015 BDA Device  
1B80:E399=AF9015 BDA Device  
1B80:E39A=DVB-T 395U  
1B80:E39B=DVB-T 395U  
1B80:E3D7=Roxio Video Capture USB  
1B80:E400=AF9015 BDA Device  
1B80:E409=IT9137FN Dual DVB-T [KWorld UB499-2T]  
1B86=Dongguan Guanshang Electronics  
1B88=ShenMing Electron (Dong Guan)  
1B8C=Altium  
1B8D=e-MOVE Technology  
1B8E=Amlogic  
1B8F=MA LABS  
1B96=N-Trig  
1B96:0001=Duosense Transparent Electromagnetic Digitizer  
1B98=YMax Communications  
1B99=Shenzhen Yuanchuan Electronic  
1BA1=JINQ CHERN ENTERPRISE  
1BA2=Lite Metals & Plastic (Shenzhen)  
1BA4=Ember  
1BA4:0001=InSight USB Link  
1BA6=Abilis Systems  
1BA8=China Telecommunication Technology Labs  
1BAD=Harmonix Music  
1BAD:0002=Harmonix Guitar for Xbox 360  
1BAD:0003=Harmonix Drum Kit for Xbox 360  
1BAE=Vuzix  
1BAE:0002=VR920 Immersive Eyewear  
1BBB=T & A Mobile Phones  
1BBB:0000=Application1 interface  
1BBB:0000:01=Application2 interface  
1BBB:0000:03=Modem Interface  
1BC4=Ford Motor  
1BC5=AVIXE Technology (China)  
1BCE=Contac Cable Industrial  
1BCF=Sunplus Innovation Technology  
1BCF:0007=Optical Mouse  
1BCF:0009:0112=USB Human Interface Device  
1BCF:0535:0610=USB Human Interface Device  
1BCF:053A=Targa Silvercrest OMC807-C optische Funkmaus  
1BCF:05C5=SPRF2413A [2.4GHz Wireless Keyboard/Mouse Receiver]  
1BCF:05C5:1110:01=USB Human Interface Device

1BCF:05CF=Micro keyboard & mouse receiver  
1BCF:0808:0008=USB Human Interface Device  
1BCF:0C31=Serial-ATA bridge  
1BD0=Hangzhou Riyue Electronic  
1BD5=BG Systems  
1BDE=P-TWO INDUSTRIES  
1BEF=Shenzhen Tongyuan Network-Communication Cables  
1BF0=RealVision  
1BF5=Extranet Systems  
1BF6=Orient Semiconductor Electronics  
1BFD=TouchPack  
1BFD:1268=Touch Screen  
1BFD:1368=Touch Screen  
1BFD:1568=Capacitive Touch Screen  
1BFD:1668=IR Touch Screen  
1BFD:1688=Resistive Touch Screen  
1BFD:2968=Touch Screen  
1BFD:5968=Touch Screen  
1BFD:6968=Touch Screen  
1C02=Kreton  
1C04=QNAP System  
1C0D=Relm Wireless  
1C10=Lanterra Industrial  
1C13=ALECTRONIC LIMITED  
1C1A=Datel Electronics  
1C1B=Volkswagen of America  
1C1F=Goldvish S.A.  
1C20=Fuji Electric Device Technology  
1C21=ADDMM LLC  
1C22=ZHONGSHAN CHIANG YU ELECTRIC  
1C26=Shanghai Haiying Electronics  
1C27=HuiYang D & S Cable  
1C31=LS Cable  
1C34=SpringCard  
1C34:7241=Prox'N'Roll RFID Scanner  
1C37=Authorizer Technologies  
1C3D=NONIN MEDICAL INC.  
1C3E=Wep Peripherals  
1C40=EZPrototypes  
1C40:0533=TiltStick  
1C40:0534=i2c-tiny-usb interface  
1C40:0535=glcd2usb interface  
1C40:0536=Swiss ColorPAL  
1C49=Cherng Weei Technology  
1C4F=SiGma Micro  
1C4F:0002=Keyboard TRACER Gamma Ivory  
1C4F:0003=HID controller  
1C4F:000E=Genius KB-120 Keyboard  
1C4F:3000=Micro USB Web Camera  
1C6B=Philips & Lite-ON Digital Solutions  
1C6B:A222=DVD Writer Slimtype eTAU108  
1C6C=Skydigital  
1C73=AMT  
1C73:861F=Anysee E30 USB 2.0 DVB-T Receiver  
1C77=Kaetat Industrial  
1C78=Datascope  
1C79=Unigen  
1C7A=LighTuning Technology  
1C7A:0801=Fingerprint Reader  
1C7A:0803=Fingerprint Reader



1C7B=LUXSHARE PRECISION INDUSTRY (SHENZHEN)  
1C87=2N TELEKOMUNIKACE a.s.  
1C88=Somagic  
1C88:0007=SMI Grabber (EasyCAP DC60+ clone) (no firmware) [SMI-2021CBE]  
1C88:003C=SMI Grabber (EasyCAP DC60+ clone) [SMI-2021CBE]  
1C89=HONGKONG WEIDIDA ELECTRON LIMITED  
1C8E=ASTRON INTERNATIONAL  
1C98=ALPINE ELECTRONICS  
1C9E=OMEGA TECHNOLOGY  
1C9E:3197=Modem Interface  
1C9E:3197:01=Application1 interface  
1C9E:6060=Modem Interface  
1C9E:6061=Modem Interface  
1CA0=ACCARIO  
1CA1=Symwave  
1CAC=Kinstone  
1CAC:A332=C8 Webcam  
1CAC:B288=C18 Webcam  
1CB3=Aces Electronic  
1CB4=OPEX  
1CBE=Luminary Micro  
1CBF=FORTAT SKYMARK INDUSTRIAL COMPANY  
1CC0=PlantSense  
1CCA=NextWave Broadband  
1CCD=Bodatong Technology (Shenzhen)  
1CD4=adp corporation  
1CD5=Firecomms  
1CD6=Antonio Precise Products Manufactory  
1CDE=Telecommunications Technology Association (TTA)  
1CDF=WonTen Technology  
1CE0=EDIMAX TECHNOLOGY  
1CE1=Amphenol KAE  
1CFC=ANDES TECHNOLOGY  
1CFD=Flextronics Digital Design Japan,  
1D07=Solid-Motion  
1D08=NINGBO HENTEK DRAGON ELECTRONICS  
1D09=TechFaith Wireless Technology  
1D09:1026=HSUPA Modem FLYING-LARK46-VER0.07 [Flying Angel]  
1D0A=Johnson Controls  
1D0B=HAN HUA CABLE & WIRE TECHNOLOGY (J.X.)  
1D14=ALPHA-SAT TECHNOLOGY LIMITED  
1D17=C-Thru Music  
1D17:0001=AXiS-49 Harmonic Table MIDI Keyboard  
1D19=Dexatek Technology  
1D19:1101=DK DVB-T Dongle  
1D19:1102=DK mini DVB-T Dongle  
1D19:1103=DK 5217 DVB-T Dongle  
1D19:6105=Video grabber  
1D19:8202=DK DVBC/T DONGLE  
1D1F=Diostech  
1D20=SAMTACK INC.  
1D29=Horng Tong Enterprise  
1D31=XINTRONIX LIMITED  
1D42=DRAGON JOY LIMITED  
1D43=Montage Technology  
1D44=Adirondack Digital Imaging Systems  
1D45=Qisda  
1D46=nSys Design Systems  
1D48=Shenzhen XinYonghui Precise Technology  
1D49=SHENZHEN LINKCONN ELECTRONICS

1D4D=Pegatron  
1D4D:0002=Ralink RT2770/2720 802.11b/g/n Wireless LAN Mini-USB Device  
1D4D:0003=Broadcom Bluetooth 2.1 + EDR USB Device  
1D4D:0004=Broadcom 2046B1 Bluetooth 2.1 + EDR USB Device  
1D4D:0008=BT183-V2  
1D4D:000A=BT-183 Bluetooth 2.1 + EDR  
1D4D:000C=Ralink RT3070 802.11b/g/n Wireless Lan USB Device  
1D4D:000D=Broadcom Bluetooth 2.1 + EDR USB Device  
1D4D:000E=Ralink RT3070 802.11b/g/n Wireless Lan USB Device  
1D4D:0010=Ralink RT3572 802.11a/b/g/n Wireless Lan USB Device  
1D4D:0011=Ralink RT3072 802.11b/g/n Wireless Lan USB Device  
1D4D:1000=USB2.0 UVC 1.3M WebCam  
1D4D:1001=USB2.0 UVC 1.3M WebCam  
1D4D:1002=USB2.0 UVC 1.3M WebCam  
1D4D:1005=USB2.0 UVC 1.3M WebCam  
1D4D:2002=BT-250  
1D4D:2003=BT-253  
1D4D:2005=BT-250  
1D4D:2006=BT-253  
1D4E=INPHI  
1D4F=ADVANCED CHIP EXPRESS INC.  
1D50=OpenMoko  
1D50:5119=GTA01/GTA02 U-Boot Bootloader  
1D5B=Smartronix  
1D5C=Fresco Logic  
1D5D=QIXING INDUSTRIAL (HK)  
1D5F=ViVotech  
1D60=ASLINK (H.K.) PRECISION  
1D69=Walta Electronic  
1D6A=ARICENT TECHNOLOGIES (HOLDINGS)  
1D6B=Linux Foundation  
1D6B:0001=USB V1.1 Root Hub  
1D6B:0002=USB V2.0 Root Hub  
1D6B:0003=USV V3.0 Root Hub  
1D6B:0100=PTP Gadget  
1D6B:0101=Audio Gadget  
1D6B:0102=EEM Gadget  
1D6B:0103=NCM (Ethernet) Gadget  
1D6B:0104=Multifunction Composite Gadget  
1D6B:0105=FunctionFS Gadget  
1D6B:0200=Qemu Audio Device  
1D71=Finisar  
1D76=LongCheng Electronic & Communication  
1D77=Yueqing Changling Electronic Instrument  
1D78=CAMBRIDGE SEMICONDUCTOR  
1D79=Shenzhen My-Power Technology  
1D7A=SHINWA INTERNATIONAL HOLDINGS  
1D7F=Ecricio  
1D80=PLDA  
1D81=YongXin Plastic & Hardware  
1D84=Kechenda Plastic Electronic Factory  
1D85=NINGBO SHUNSHENG COMMUNICATION APPARATUS  
1D8C=Wuxi AlphaScale IC Systems  
1D9E=CSR  
1D9F=KUNMING ELECTRONICS  
1DA0=Parade Technologies  
1DB7=SMedia Technology  
1DB8=HD MEDICAL INC.  
1DBD=Terawins  
1DBE=Rayco Electronics

1DBF=Signostics  
1DC2=Datalogic Mobile  
1DCC=Document Capture Technologies  
1DCD=HIN KUI MACHINE & METAL INDUSTRIAL  
1DD7=REDMERE TECHNOLOGY  
1DD8=BUFFALO KOKUYO SUPPLY INC.  
1DD9=EFFICERE TECHNOLOGIES  
1DDF=GDA Technologies  
1DE0=Shenzhen Excelstor Technology  
1DE1=Actions Microelectronics  
1DE2=ENTERY INDUSTRIAL  
1DE3=SHENZHEN REX ELECTRONICS  
1DE4=DAEWOO ELECTRONICS  
1DEA=Yesin Electronics Technology  
1DEB=SHIUH CHI PRECISION INDUSTRY  
1DF1=HUATIANYUAN ELECTRONIC INDUSTRY  
1DF2=Telecommunication Metrology Center of MII  
1DF3=CRESYN  
1DF4=SHEN ZHEN FORMAN PRECISION INDUSTRY  
1E00=Jupiter Systems  
1E02=GLOBEMASTER TECHNOLOGIES  
1E07=GETA ELECTRONICS (DONG GUAN)  
1E08=Inventure  
1E0E=Qualcomm / Option  
1E10=Point Grey Research  
1E10:2004=Sony 1.3MP 1/3" ICX445 IIDC video camera [Chameleon]  
1E11=Hoya Xponent  
1E17=Mirion Technologies Dosimetry Services Division  
1E17:0001=instadose dosimeter  
1E1C=CMS PRODUCTS  
1E1D=Kanguru Solutions  
1E1D:0165=Secure Pen drive  
1E1F=INVIA  
1E20=JDSU  
1E29=Festo AG &  
1E29:0101=CPX Adapter  
1E29:0102=CPX Adapter >=HW10.09 [CP2102]  
1E29:0401=iL3-TP  
1E29:0402=FTDI232 [EasyPort]  
1E29:0403=FTDI232 [EasyPort Mini]  
1E29:0404=FTDI232 [Netzteil-GL]  
1E29:0405=FTDI232 [MotorPrÄ¼fstand]  
1E29:0406=STM32F103 [EasyKit]  
1E29:0407=LPC2378 [Robotino]  
1E29:0408=LPC2378 [Robotino-Arm]  
1E29:0409=LPC2378 [Robotino-Arm Bootloader]  
1E29:040A=LPC2378 [Robotino Bootloader]  
1E29:0501=CP2102 [CMSP]  
1E29:0601=CMMP-AS  
1E2A=NANOFORTI INC.  
1E33=KOBIAN CANADA INC.  
1E3A=Temic Automotive of N.A.  
1E3D=Chipsbrand Technologies (HK)  
1E3D:4082=CBM4082 SD Card Reader  
1E41=Cleverscope  
1E41:0001=CS328A PC Oscilloscope  
1E47=Jen Jia Precision Industry  
1E4E=Etron Technology  
1E54=TypeMatrix  
1E54:2030=2030 USB Keyboard

1E68=TrekStor  
1E68:001B=DataStation maxi g.u  
1E6D=WAN SHIH ELECTRONIC (H.K.)  
1E71=NZXT  
1E71:0001=Avatar Optical Mouse  
1E73=COMLINK ELECTRONICS  
1E74=Coby Electronics  
1E74:6511=MP705-8G MP3 player  
1E74:6512=MP705-4G  
1E7D=ROCCAT  
1E7D:2C24=Pyra Mouse (wired)  
1E7D:2CED=Kone Mouse  
1E7D:2D51=Kone+ Mouse  
1E7D:30D4=Arvo Keyboard  
1E87=W&W Communications  
1E88=GBS Laboratories, LLC  
1E89=Vtion Information Technology (Fujian)  
1E8A=HIBEST Electronic (DongGuan)  
1EA3=Concraft Holding  
1EA6=novero GmbH  
1EA7:0004:01=USB Human Interface Device  
1EB7=WIN WIN PRECISION INDUSTRIAL  
1EBB=NuCORE Technology  
1EC9=MOSER BAER INDIA LIMITED  
1EDA=AIRTIES WIRELESS NETWORKS  
1EDA:2310=802.11n USB Wireless LAN Card  
1EDB=BLACKMAGIC DESIGN PTY.  
1EDB:BD3B=Intensity Shuttle  
1EE8=ONDA COMMUNICATION S.p.a.  
1EE8:0014=MT833UP  
1EF6=EADS Deutschland GmbH  
1F20=Shenzhen Tenwei Electronics  
1F28=Cal-Comp  
1F28:0020=CDMA USB Modem A600  
1F28:0021=CD INSTALLER USB Device  
1F29=Analogix Semiconductor  
1F31=SASKEN COMMUNICATION TECH  
1F35=Amphenol Shouh Min Industry  
1F39:2000=Device description: Broadcom 2046 Bluetooth 2.1+EDR USB Device  
1F3C=Chang Yang Electronics Company  
1F49=ITT  
1F4D=G-Tek Electronics Group  
1F4D:B803=Liferview LV5TDLX DVB-T [RTL2832U]  
1F75=Innoster  
1F82=TANDBERG  
1F82:0001=PrecisionHD Camera  
1F84=Inverness Medical Innovations  
1F87=Stantum  
1F87:0002=Multi-touch HID Controller  
1F89=Dongguan Goldconn Electronics  
1F8A=Morning Star Industrial  
1FAC=Franklin Technology  
1FAD=Cresta Technology  
1FB4=Owl Computing Technologies  
1FB5=Siemens Enterprise Communications  
1FBD=Delphin Technology AG  
1FBD:0001=Expert Key - Data aquisition system  
1FC9=NXP Semiconductors  
1FE7=Vertex Wireless  
1FE7:1000=VW100 series CDMA EV-DO Rev.A modem

1FEA:002D=Realtek USB2.0 PC Camera  
1FEA:002E=Realtek USB2.0 PC Camera  
1FEA:002F=Realtek USB2.0 PC Camera  
1FEA:0030=Realtek USB2.0 PC Camera  
1FEA:0031=Realtek USB2.0 PC Camera  
1FEC=NIAN YEONG ENTERPRISE  
1FF5=Changzhou Wujin BEST Electronic Cables  
2001=D-Link  
2001:0001=DWL-120 WIRELESS ADAPTER  
2001:0201=D-Link DHN-120 10Mb Home Phoneline USB Adapter  
2001:1A00=D-Link DUB-E100 USB 2.0 Fast Ethernet Adapter  
2001:200C=10/100 Ethernet  
2001:3200=DWL-120 802.11b (Atmel RFMD503A) [usbvnetr]  
2001:3301=D-Link DWA-130 Wireless N USB Adapter (rev.C)  
2001:3306=D-Link DWL-G122 Wireless G USB Adapter (rev.F1)  
2001:3307=D-Link DWA-130 Wireless N USB Adapter (rev.F1)  
2001:3308=D-Link DWA-121 Wireless N USB Adapter  
2001:3309=D-Link DWA-135 Wireless N USB Adapter  
2001:330A=D-Link DWA-133 Wireless N USB Adapter  
2001:3500=D-Link Air DWL-122 Wireless USB Adapter (rev.B)  
2001:3700=D-Link Air DWL-122 Wireless USB Adapter  
2001:3701=DWL-G120 Spinnaker 802.11b  
2001:3702=D-Link Air DWL-120 Wireless USB Adapter (rev.F)  
2001:3703=DWL-122 802.11b  
2001:3704=DWL-G122 802.11g rev. A2  
2001:3705=AirPlus G DWL-G120 Wireless Adapter (rev.C)  
2001:3761=IEEE 802.11g USB2.0 Wireless Network Adapter-PN  
2001:3762=Conceptronic Wireless 54Mbps USB adapter  
2001:3A00=DWL-AG132  
2001:3A01=DWL-AG132 (no firmware)  
2001:3A02=DWL-G132  
2001:3A03=DWL-G132 (no firmware)  
2001:3A04=DWL-AG122  
2001:3A05=DWL-AG122 (no firmware)  
2001:3A80=AirPlus Xtreme G DWL-G132 Wireless Adapter  
2001:3A81=predator Bootloader Download  
2001:3A82=AirPremier AG DWL-AG132 Wireless Adapter  
2001:3A83=predator Bootloader Download  
2001:3B00=D-Link AirPlus DWL-120+ Wireless USB Adapter  
2001:3B01=D-Link WLAN USB Boot Device  
2001:3C00=DWL-G122 802.11g rev. B1 [ralink]  
2001:3C01=AirPlus AG DWL-AG122 Wireless Adapter  
2001:3C02=AirPlus G DWL-G122 Wireless Adapter  
2001:3C05=DUB-E100 Fast Ethernet [asix]  
2001:3C17=D-Link DWA-123 Wireless N 150 USB Adapter  
2001:4000=DSB-650C Ethernet [klsi]  
2001:4001=DSB-650TX Ethernet [pegasus]  
2001:4002=DSB-650TX Ethernet [pegasus]  
2001:4003=DSB-650TX-PNA Ethernet [pegasus]  
2001:400B=10/100 Ethernet  
2001:4102=10/100 Ethernet  
2001:5100=DSL-200 ADSL ATM Modem  
2001:5102=DSL-200 ADSL Loader  
2001:5B00=Remote NDIS Network Device  
2001:9414=Cable Modem  
2001:9B00=D-Link DCM-202 Broadband Cable Modem  
2001:ABC1=D-Link DSB-650 USB Ethernet Adapter  
2001:F013=DLink 7 port USB2.0 Hub  
2001:F103=DUB-H7 7-port USB 2.0 Hub  
2001:F10D=Accent Communications Modem

2001:F110=DUB-AV300 A/V Capture  
2001:F111=Formosa 1  
2001:F112=DUB-T210 Audio Device  
2001:F116=Formosa 2  
2001:F117=Formosa 3  
2001:F118=Formosa 4  
200D=Belkin Electronic (Changzhou)  
2013=Unknown (Pinnacle?)  
2013:0245=PCTV 73e SE  
2013:0246=PCTV 74E  
2013:0248=Infrared Receiver  
2018:0100=elmeg WIZ@RD BootUp  
2018:0101=elmeg WIZ@RD  
2018:0201=elmeg D@VOS  
2018:0202=T-Concept XI521 (Boot)  
2018:0203=elmeg D@VOS.net  
2018:0300=elmeg CS320 BootUp  
2018:0301=elmeg CS320  
2018:0301:0200=elmeg CS410  
2018:0401=elmeg.net  
2018:0401:0101=elmeg ICT  
2018:0401:8888=T-Concept XI524 Firmware Update Device  
2018:0401:9999=elmeg Firmware Update Device  
2018:0402=T-Concept XI521  
2018:0403=T-Concept XI420  
2018:0404=elmeg USB Remote NDIS Network Device  
2018:0405=XI524 USB Remote NDIS Network Device  
2018:0406=elmeg - USB Remote NDIS Network Device  
2018:0406:0130=elmeg T240 - USB Remote NDIS Network Device  
2018:0406:0140=elmeg T444 - USB Remote NDIS Network Device  
2018:0406:0150=elmeg T484 - USB Remote NDIS Network Device  
2018:0501=elmeg ICT  
2019=PLANEX  
2019:3220=GW-US11S WLAN  
2019:4901=GW-USSuper300  
2019:5201=GW-USPico  
2019:5303=PCI GW-US54GXS  
2019:5304=GW-US54AGXS  
2019:AB01=PCI GW-US54HP  
2019:AB24=GW-US300MiniS  
2019:AB25=150N Wireless LAN USB Adapter  
2019:AB28=GW-USNano  
2019:AB29=GW-USMicro300  
2019:AB2A=GW-USNano2  
2019:AB2B=GW-USEco300  
2019:AB50=PCI GW-US54Mini2  
2019:C002=GW-US54SG  
2019:C007=GW-US54GZL  
2019:ED02=GW-USMM  
2019:ED06=PCI 802.11n Wireless LAN USB Adapter  
2019:ED10=GW-US300Mini2  
2019:ED14=GW-USMicroN  
2019:ED17=GW-USValue-EZ  
201C=Freeport Resources Enterprises  
2028=DETAS TECHNOLOGY  
202D=Snowbush IP (a division of Gennum)  
203D:1480=802.11 USB Wireless LAN Adapter  
203D:14A1=No Geek Needed's 802.11n USB Adapter  
203D:14A9=Encore 802.11n Wireless USB Adapter  
2040=Hauppauge Computer Works

2040:0C80=Windham  
2040:0C90=Windham  
2040:1100=Hauppauge WinTV-CI USB (11xxx)  
2040:1605=WinTV HVR-930C  
2040:1700=CataMount  
2040:1800=Okemo A  
2040:1801=Okemo B  
2040:2000=Tiger Minicard  
2040:2009=Tiger Minicard R2  
2040:200A=Tiger Minicard  
2040:2010=Tiger Minicard  
2040:2011=WinTV MiniCard [Dell Digital TV Receiver]  
2040:2019=Tiger Minicard  
2040:2400=Hauppauge PVR USB2 AVS Video Capture  
2040:2900=Hauppauge WinTV PVR2 USB2 Encoder  
2040:2950=Hauppauge WinTV PVR2 USB2 Encoder  
2040:4200=WinTV USB2  
2040:4200:01=WinTV USB2 Audio Device  
2040:4201=WinTV USB2  
2040:4201:01=WinTV USB2 Audio Device  
2040:4700=WinTV Nova-S-USB2  
2040:4902=HD PVR  
2040:4982=HD PVR  
2040:5200=Hauppauge Nova-T IR  
2040:5500=Windham  
2040:5510=Windham  
2040:5520=Windham  
2040:5530=Windham  
2040:5580=Windham  
2040:5590=Windham  
2040:6310=eHome Infrared Receiver (USBCIR)  
2040:6500=WinTV HVR-900  
2040:6500:01=WinTV HVR-900 Audio Device  
2040:6501=WinTV HVR-930  
2040:6501:01=WinTV HVR-930 Audio Device  
2040:6502=WinTV HVR-900  
2040:6503=WinTV HVR-930  
2040:6506=WinTV HVR-900  
2040:6507=WinTV HVR-930  
2040:650A=WinTV USB2  
2040:650E=WinTV USB2  
2040:6513=WinTV HVR-980  
2040:6517=HP Digital/Analog TV Tuner  
2040:651B=ReplayTV Personal HD  
2040:651F=WinTV HVR-850  
2040:6600=Hauppauge WinTV HVR-900H (66xxx)  
2040:6601=Hauppauge WinTV HVR-900H (66xxx)  
2040:6610=Hauppauge WinTV USB2-Stick (66xxx)  
2040:6611=Hauppauge WinTV USB2-Stick (66xxx)  
2040:7040=Hauppauge Nova-T IR  
2040:7050=Hauppauge Nova-T IR  
2040:7051:01=Hauppauge Nova-T Stick IR  
2040:7060=Hauppauge Nova-T IR  
2040:7070=Hauppauge Nova-T IR  
2040:7080=Eskape myTV.t IR  
2040:7200=WinTV HVR-950q NTSC Capture Device  
2040:7200:01=WinTV HVR-950q USB Audio Device  
2040:7200:03=WinTV HVR-950q ATSC/QAM Capture Device  
2040:7210=WinTV HVR-950q ATSC/QAM Capture Device  
2040:7217=HP Digital/Analog TV Tuner (Analog)

2040:7217:01=HP Digital/Analog TV Tuner (Audio)  
2040:7217:03=HP Digital/Analog TV Tuner (Digital)  
2040:721E=WinTV HVR-950q NTSC Capture Device  
2040:721E:01=WinTV HVR-950q USB Audio Device  
2040:721E:03=WinTV HVR-950q ATSC/QAM Capture Device  
2040:721F=Dell Digital TV Receiver (Analog)  
2040:721F:01=Dell Digital TV Receiver (Audio)  
2040:721F:03=Dell Digital TV Receiver (Digital)  
2040:7240=WinTV HVR-850 NTSC Capture Device  
2040:7240:01=WinTV HVR-850 USB Audio Device  
2040:7240:03=WinTV HVR-850 ATSC Capture Device  
2040:7280=Dell Digital TV Receiver (Digital)  
2040:7281=Dell Digital TV Receiver (Digital)  
2040:8200=WinTV HVR-950q NTSC Capture Device  
2040:8200:01=WinTV HVR-950q USB Audio Device  
2040:8200:03=WinTV HVR-950q ATSC/QAM Capture Device  
2040:8400=Hauppauge Nova-T IR  
2040:9300=Hauppauge WinTV NOVA-T USB2 (cold)  
2040:9301=Hauppauge WinTV NOVA-T USB2 (warm)  
2040:9500=Hauppauge Nova-T IR  
2040:9580=Hauppauge Nova-T IR  
2040:9900=Hauppauge Nova-DT FW Downloader  
2040:9901=Hauppauge Nova-DT Dual DVB-T Tuner Device  
2040:9910=Hauppauge Nova-DT FW Downloader  
2040:9911=Hauppauge Nova-DT Dual DVB-T Tuner Device (+IR)  
2040:9911:01=Hauppauge Nova-DT IR  
2040:9940=Hauppauge Nova-DT FW Downloader  
2040:9941=Hauppauge Nova-DT Dual DVB-T Tuner Device  
2040:9950=Hauppauge Nova-DT FW Downloader  
2040:9951=Hauppauge Nova-DT Dual DVB-T Tuner Device (+IR)  
2040:9951:01=Hauppauge Nova-DT IR  
2040:B910=Windham  
2040:B980=Windham  
2040:B990=Windham  
2040:C000=Windham  
2040:C010=Windham  
2047=Texas Instruments  
2047:0200=MSP430 USB HID Bootstrap Loader  
205C=Shenzhen Tronixin Electronics  
207D=CESI Technology  
2080=Barnes & Noble  
2080:0001=nook  
2080:0002=NOOKcolor  
2086:0100=Data Transit Bus Doctor Rx before ReNumeration (dtRxDr.sys)  
2086:0101=bus doctor  
2086:0130=Data Transit Bus Doctor Rx 108P before ReNumeration (dt108ldr.sys)  
2086:0131=bus doctor Rx 108p  
2087=Cando  
2087:0A01=Multi Touch Panel  
2087:0A02=Multi Touch Panel  
2087:0B03=Multi Touch Panel  
208E=ICT-LANTO LIMITED  
2095=China Electronics Technology  
2096=Microconn Electronic  
20A0=Clay Logic  
20A0:414A=MDE SPI Interface  
20AF=Shenzhen CARVE Electronics  
20B1=XMOS  
20B1:10AD=XUSB Loader  
20B1:F7D1=X2TAG - USB to JTAG interface



20B3=Hanvon  
20B3:0A18=10.1 Touch screen overlay  
20B7=Qi Hardware  
20B7:0713=Milkymist JTAG/serial  
20B7:1540=ben-wpan, AT86RF230-based  
20B7:1DB5=IDBG in DFU mode  
20B7:1DB6=IDBG in normal mode  
20B7:C25B=C2 Dongle  
20B7:CB72=ben-wpan, cntr  
20B8:8888=2EZ wifi N USB Router (EZ-R15NS)  
20C0=FENGHUA KINGSUN  
20C2=Sumitomo Electric Ind.  
20D8=Changzhou Xinchao Technologies  
20DF=Simtec Electronics  
20DF:0001=Entropy Key [UDEKEY01]  
20F0=Insight Technology  
20F4:646B=High Power 150Mbps Wireless N USB Adapter  
20F4:648B=TRENDnet 150Mbps Micro Wireless N USB Adapter  
20F7=SOFTHARD Technology  
20FD=NOVO NORDISK A/S  
20FE=Elektrobit  
2101=ActionStar  
2101:0201=ActionStar USB Sharing Control  
2101:0201:0100=SIIG USB Switch 4-to-2 Control  
2109=VIA Labs  
2109:0810=4-Port USB 3.0 Hub  
2109:3431=4-Port USB 2.0 Hub  
2116=KT Tech  
212C=Shenzhen Linoya Electronic  
212E=Amphenol AssembleTech (Xiamen)  
2138=iVina  
2147=Chin-Ban Electronics (Hong Kong)  
2148=Visteon Sistemas Automotives  
214C=Y Soft  
2162=Creative (?)  
2162:2031=Network Blaster Wireless Adapter  
2162:500C=DE5771 Modem Blaster  
2162:8001=Broadxent BritePort DSL Bridge 8010U  
2166=JVC KENWOOD Holdings  
2167=Zhejiang Fousine Science & Technology  
2173=HUIZHOU HUANGJI PRECISIONS FLEX ELECTRONICAL  
2174=Transcend Information  
2176=TMC/Allion Test Labs  
2184=GW Instek  
2184:0005=GDS-3000 Oscilloscope  
2184:0006=GDS-3000 Oscilloscope  
2184:0011=AFG Function Generator (CDC)  
2188=CalDigit  
21A1=Emotiv Systems  
21A1:0001=EPOC Consumer Headset Wireless Dongle  
21B5=SHENZHEN JASON ELECTRONICS  
21C4=Netcom Technology (HK)  
21D6=Agecodagis SARL  
21D6:0002=Seismic recorder [Tellus]  
21E9=Jiafuh Metal & Plastic (ShenZhen)  
21EE:1100=Broadcom Bluetooth 2.1 + EDR USB Device  
21EE:1101=Broadcom Bluetooth V3.0 USB  
21F7=Wuerth-Elektronik eiSos  
2201=Elan Digital Systems  
2202=Walex Electronic (Wu Xi)

2203=Shin Shin  
2205=3eYamaichi Electronics  
2206=Wiretek International Investment  
2207=Fuzhou Rockchip Electronics  
221E=Linktec Technologies  
2222=MacAlly  
2222:0004=iWebKey Keyboard  
2222:2222=DVI2USB  
2222:2520=Mini Tablet  
2222:4050=AirStick joystick  
2227=SAMWOO Enterprise  
2227:3105=SKYDATA SKD-U100  
2232:1005=WebCam SCB-0385N  
2233=RadioShack  
2233:6323=USB Electronic Scale  
2234=T-CONN PRECISION  
2237=Kobo  
2237:4161=eReader White  
2242=Zhihe Electronics Technology  
2250=Evernew Wire & Cable  
2251=QuieTek  
2252=TSANSUN TECH.  
2259=Skypine Electronics (Shenzhen)  
2264=Entourage Systems  
226F=Koyo Trading  
2270=XiaMen GaoLuChang Electronics  
227F=Granite River Labs  
2287=Shenzhen Oversea Win Technology  
2288=Digital EMC  
2289=Sun Fair Electric Wire & Cable (HK)  
228A=Hotron Precision Electronic Ind.  
228B=Shenzhen DLK Electronics Technology  
2297=Evolution Technology  
2299:4533=Socketcom Bluetooth Device  
22A6=Pie Digital  
22A6:FFFF=PieKey "beta" 4GB model 4E4F41482E4F5247 (SM3251Q BB)  
22A9=Valor Communication  
22AA=AppliedMicro  
22AB=Trigence Semiconductor  
22B8=Motorola PCS  
22B8:0001=Wally 2.2 chipset  
22B8:0002=Wally 2.4 chipset  
22B8:0005=Motorola USB Modem  
22B8:0007=Motorola USB Modem  
22B8:0830=2386C-HT820  
22B8:0833=2386C-HT820 [Flash Mode]  
22B8:0850=Broadcom Bluetooth 2.1 + EDR USB Device  
22B8:1001=Patriot 1.0 (GSM) chipset  
22B8:1002=Patriot 2.0 chipset  
22B8:1004=Motorola USB Modem  
22B8:1005=MOTOROLA\_V60\_V66\_V70 GSM Modem  
22B8:1101=Patriot 1.0 (TDMA) chipset  
22B8:1107=Motorola USB Modem  
22B8:1801=Rainbow chipset flash  
22B8:1C04=Motorola USB Modem  
22B8:1C09=Motorola USB Composite Device  
22B8:2035=Motorola USB Bluetooth Firmware Upgrade Device  
22B8:2805=Motorola USB Modem  
22B8:2821=T720 GSM Phone  
22B8:2822=V.120e GSM Phone

22B8:2823=Flash Interface  
22B8:2842=Motorola 1xEV-DO Handset  
22B8:2842:02=Motorola 1xEV-DO Handset Diagnostic Serial Port Drivers (WDM)  
22B8:2844=Motorola USB Modem  
22B8:2A01=MSM6050 chipset  
22B8:2A02=Motorola USB Modem  
22B8:2A03=MSM6050 chipset flash  
22B8:2A21=V710 GSM Phone (P2K)  
22B8:2A22=Motorola USB Modem  
22B8:2A23=MSM6100 chipset flash  
22B8:2A24=Motorola USB Modem  
22B8:2A24:01=Motorola USB Diagnostic Port  
22B8:2A41=MSM6300 chipset  
22B8:2A42=Motorola USB Modem  
22B8:2A43=MSM6300 chipset flash  
22B8:2A44=Motorola USB Modem  
22B8:2A44:01=Motorola USB Diagnostic Port  
22B8:2A61=E815 GSM Phone (P2K)  
22B8:2A62=E815 GSM Phone (AT)  
22B8:2A63=MSM6500 chipset flash  
22B8:2A64=Motorola USB Modem  
22B8:2A64:01=Motorola USB Diagnostic Port  
22B8:2A81=MSM6025 chipset  
22B8:2A82=Motorola USB Modem  
22B8:2A83=MSM6025 chipset flash  
22B8:2AC1=MSM6100 chipset  
22B8:2AC2=Motorola USB Modem  
22B8:2AC3=MSM6100 chipset flash  
22B8:2AC4=Motorola USB Modem  
22B8:2AC4:01=Motorola USB Diagnostic Port  
22B8:2B22=Motorola USB Modem  
22B8:2B24=Motorola USB Modem  
22B8:2B24:01=Motorola USB Diagnostic Port  
22B8:2B42=Motorola USB Modem  
22B8:2B44=Motorola USB Modem  
22B8:2B44:01=Motorola USB Diagnostic Port  
22B8:2BA2=Motorola USB Modem  
22B8:2BA4=Motorola USB Modem  
22B8:2BA4:01=Motorola USB Diagnostic Port  
22B8:2BA7=Motorola USB Modem  
22B8:2BA7:01=Motorola USB AP Diagnostic Port  
22B8:2BA7:02=Motorola USB BP Diagnostic Port  
22B8:2BC2=Motorola USB Modem  
22B8:2BC4=Motorola USB Modem  
22B8:2BC4:01=Motorola USB Diagnostic Port  
22B8:2C02=Motorola USB Modem  
22B8:2C04=Motorola USB Modem  
22B8:2C04:01=Motorola USB Diagnostic Port  
22B8:2C42=Motorola USB Modem  
22B8:2C44=Motorola USB Modem  
22B8:2C44:01=Motorola USB Diagnostic Port  
22B8:2C47=Motorola USB Modem  
22B8:2C47:01=Motorola USB AP Diagnostic Port  
22B8:2C47:02=Motorola USB BP Diagnostic Port  
22B8:2C52=Motorola USB Modem  
22B8:2C54=Motorola USB Modem  
22B8:2C54:01=Motorola USB Diagnostic Port  
22B8:2C62=Motorola USB Modem  
22B8:2C64=Motorola USB Modem  
22B8:2C64:01=Motorola USB Diagnostic Port

22B8:2C69=Motorola USB Modem  
22B8:2C69:01=Motorola USB Diagnostic Port  
22B8:2C69:02=Motorola USB Linux Diagnostic Port  
22B8:2C69:03=Motorola USB Networking Driver  
22B8:2C82=Motorola USB Modem  
22B8:2C84=Motorola USB Modem  
22B8:2C84:01=Motorola USB Diagnostic Port  
22B8:2CA2=Motorola USB Modem  
22B8:2CA4=Motorola USB Modem  
22B8:2CA4:01=Motorola USB Diagnostic Port  
22B8:2CA6=Motorola MTP Device  
22B8:2CC2=Motorola USB Modem  
22B8:2CC4=Motorola USB Modem  
22B8:2CC4:01=Motorola USB Diagnostic Port  
22B8:2CC8=Motorola USB Modem  
22B8:2CC8:01=Motorola USB Diagnostic Port  
22B8:2CC8:02=Motorola USB Linux Diagnostic Port  
22B8:2CE2=Motorola USB Modem  
22B8:2CE4=Motorola USB Modem  
22B8:2CE4:01=Motorola USB Diagnostic Port  
22B8:2CE7=Motorola MTP Device  
22B8:2CF1=Motorola USB Modem  
22B8:2CF2=Motorola USB Modem  
22B8:2CF2:01=Motorola USB Diagnostic Port  
22B8:2D01=WCDMA Mobile Phone  
22B8:2D01:01=WCDMA Diagnostics Interface  
22B8:2D09=WCDMA Mobile Phone  
22B8:2D09:01=WCDMA Diagnostics Interface  
22B8:2D32=Motorola USB Modem  
22B8:2D34=Motorola USB Modem  
22B8:2D34:01=Motorola USB Diagnostic Port  
22B8:2D37=Motorola MTP Device  
22B8:2D38=Motorola USB Composite Device  
22B8:2D3B=Motorola USB Modem  
22B8:2D3B:01=Motorola USB Diagnostic Port  
22B8:2D42=Motorola USB Modem  
22B8:2D44=Motorola USB Modem  
22B8:2D44:01=Motorola USB Diagnostic Port  
22B8:2D46=Motorola USB Diagnostic Port  
22B8:2D61=Motorola USB Diagnostic Port  
22B8:2D61:01=Motorola Composite ADB Interface  
22B8:2D61:02=Motorola USB Networking Driver  
22B8:2D61:03=Motorola AT COM Port  
22B8:2D62=Motorola Single ADB Interface  
22B8:2D63=Motorola USB Diagnostic Port  
22B8:2D63:01=Motorola USB Networking Driver  
22B8:2D63:02=Motorola AT COM Port  
22B8:2D64=Motorola USB Diagnostic Port  
22B8:2D64:01=Motorola Composite ADB Interface  
22B8:2D64:02=Motorola USB Networking Driver  
22B8:2D64:03=Motorola AT COM Port  
22B8:2D65=Motorola USB Diagnostic Port  
22B8:2D65:01=Motorola USB Networking Driver  
22B8:2D65:02=Motorola AT COM Port  
22B8:2D66=Motorola Composite ADB Interface  
22B8:2D68=Motorola USB Diagnostic Port  
22B8:2D68:01=Motorola Composite ADB Interface  
22B8:2D68:02=Motorola USB Networking Driver  
22B8:2D69=Motorola USB Diagnostic Port  
22B8:2D69:01=Motorola USB Networking Driver

22B8:2D71=Motorola USB Diagnostic Port  
22B8:2D71:01=Motorola USB Modem  
22B8:2D71:02=Motorola USB Networking Driver  
22B8:2D73=Motorola MTP Device  
22B8:2D74=Motorola USB Diagnostic Port  
22B8:2D74:01=Motorola USB Modem  
22B8:2D74:02=Motorola USB Networking Driver  
22B8:2D74:04=Mot Composite ADB Interface  
22B8:2D75=Motorola USB Diagnostic Port  
22B8:2D75:02=Mot Composite ADB Interface  
22B8:2D76=Motorola USB Diagnostic Port  
22B8:2D76:02=Mot Composite ADB Interface  
22B8:2D78=XT300[SPICE]  
22B8:2D79=Motorola USB Diagnostic Port  
22B8:2D79:01=Motorola USB Networking Driver  
22B8:2D7A=Motorola USB Diagnostic Port  
22B8:2D7A:01=Motorola USB Modem  
22B8:2D7A:02=Motorola USB Networking Driver  
22B8:2D7B=Motorola USB Diagnostic Port  
22B8:2D7B:01=Motorola USB Modem  
22B8:2D7B:02=Motorola USB Networking Driver  
22B8:2D7B:03=Mot Composite ADB Interface  
22B8:2D80=Motorola USB Modem  
22B8:2D80:01=Motorola USB Diagnostic Port  
22B8:2D83=Motorola MTP Device  
22B8:2DB0=Motorola USB Modem  
22B8:2DB2=Motorola MTP Device  
22B8:2DB3=Motorola USB Diagnostic Port  
22B8:2DB5=Motorola USB Diagnostic Port  
22B8:2DB5:01=Motorola USB Modem  
22B8:2DB6=Motorola USB Diagnostic Port  
22B8:2DB7=Motorola USB Diagnostic Port  
22B8:2DD0=Motorola USB Diagnostic Port  
22B8:2DD0:01=Motorola USB Modem  
22B8:2DD0:02=Motorola USB Networking Driver  
22B8:2DD2=Motorola MTP Device  
22B8:2DD3=Motorola USB Diagnostic Port  
22B8:2DD3:01=Motorola USB Modem  
22B8:2DD3:02=Motorola USB Networking Driver  
22B8:2DD3:04=Mot Composite ADB Interface  
22B8:2DD4=Motorola USB Diagnostic Port  
22B8:2DD4:02=Mot Composite ADB Interface  
22B8:2DD5=Motorola USB Diagnostic Port  
22B8:2DD5:02=Mot Composite ADB Interface  
22B8:2DD7=Motorola USB Device  
22B8:2DD8=Motorola USB Diagnostic Port  
22B8:2DD8:01=Motorola USB Networking Driver  
22B8:2DD9=Mot Single ADB Interface  
22B8:2DE5=Motorola AT COM Port  
22B8:2DE6:01=Motorola USB Diagnostic Port  
22B8:2DE6:02=Mot Composite ADB Interface  
22B8:2DE6:03=Motorola USB Modem  
22B8:2DE8:01=Mot Composite ADB Interface  
22B8:2DE9:02=Mot Composite ADB Interface  
22B8:2DEA:01=Mot Composite ADB Interface  
22B8:2DEA:02=Motorola USB Modem  
22B8:2DEB:02=Mot Composite ADB Interface  
22B8:2DEB:03=Motorola USB Diagnostic Port  
22B8:2DED=Motorola USB Diagnostic Port  
22B8:2DED:01=Motorola USB Modem

22B8:2DF1=Mot Single ADB Interface  
22B8:2DF2=Motorola USB Networking Driver  
22B8:2DF3=Motorola USB Networking Driver  
22B8:2DF3:01=Mot Composite ADB Interface  
22B8:2DF4=Motorola USB Modem  
22B8:2DF4:02=Motorola USB Networking Driver  
22B8:2DF5=Motorola USB Modem  
22B8:2DF5:02=Motorola USB Networking Driver  
22B8:2DF5:04=Mot Composite ADB Interface  
22B8:2DF7:01=Mot Composite ADB Interface  
22B8:2DF9:01=Mot Composite ADB Interface  
22B8:2DFA=Motorola MTP Device  
22B8:2DFB=Motorola USB Composite Device  
22B8:2DFB:01=Mot Composite ADB Interface  
22B8:2DFD=Motorola USB Composite Device  
22B8:2DFD:02=Mot Composite ADB Interface  
22B8:2DFE=Motorola USB Modem  
22B8:2DFE:02=Motorola USB Networking Driver  
22B8:2DFE:03=Motorola USB Diagnostic Port  
22B8:2DFF=Motorola USB Modem  
22B8:2DFF:02=Motorola USB Networking Driver  
22B8:2DFF:03=Motorola USB Diagnostic Port  
22B8:2DFF:05=Mot Composite ADB Interface  
22B8:2E00=Motorola USB Device  
22B8:2E01=Motorola USB Networking Driver  
22B8:2E01:01=Motorola USB Diagnostic Port  
22B8:2E02=Motorola USB Networking Driver  
22B8:2E02:01=Motorola USB Diagnostic Port  
22B8:2E02:02=Mot Composite ADB Interface  
22B8:2E12=Motorola USB Modem  
22B8:2E12:01=Motorola USB Diagnostic Port  
22B8:3001=A835/E1000 GSM Phone (P2K)  
22B8:3002=Motorola USB Modem  
22B8:3004=Motorola USB Modem  
22B8:3009=Motorola USB Modem  
22B8:3801=C350L/C450 (P2K)  
22B8:3802=C330 GSM Phone  
22B8:3803=Neptune LT chipset flash  
22B8:3804=Motorola USB Modem  
22B8:4001=OMAP 1.0 chipset  
22B8:4002=Motorola USB Modem  
22B8:4003=OMAP 1.0 chipset flash  
22B8:4004=Motorola USB Modem  
22B8:4007=Motorola USB Modem  
22B8:4008=OMAP 1.0 chipset RDL  
22B8:4040=Motorola USB Modem  
22B8:4041=Motorola Connectivity Port  
22B8:4043=Motorola Charging Port  
22B8:404B=Motorola USB Composite Device  
22B8:404B:02=Motorola USB Modem  
22B8:404C=Motorola USB Modem  
22B8:4081=Motorola USB Modem  
22B8:4083=Motorola Trace COM Port  
22B8:4083:01=Motorola AT COM Port  
22B8:4084=Motorola Trace COM Port  
22B8:4085=Motorola Trace COM Port  
22B8:4085:01=Motorola AT COM Port  
22B8:4191=Motorola USB Modem  
22B8:4192=Motorola USB Networking Driver  
22B8:41A1=Motorola USB Modem

22B8:41A3:01=Motorola Trace COM Port  
22B8:41A3:02=Motorola AT COM Port  
22B8:41A4:01=Motorola Trace COM Port  
22B8:41A5=Motorola Trace COM Port  
22B8:41A5:01=Motorola AT COM Port  
22B8:41A6:01=Motorola AT COM Port  
22B8:41A7=Motorola Trace COM Port  
22B8:41B2=Motorola USB Modem  
22B8:41B4=Motorola USB Modem  
22B8:41B5=Motorola USB Modem  
22B8:41B8=Motorola MTP Device  
22B8:41B9=Motorola USB Composite Device  
22B8:41BA=Motorola PTP Device  
22B8:41C2=Motorola USB Device  
22B8:41C3=Motorola USB Device  
22B8:41C3:01=Mot Composite ADB Interface  
22B8:41CD=Motorola USB Device  
22B8:41D1=Mot Single ADB Interface  
22B8:41D2=Mot Composite ADB Interface  
22B8:41D3=Motorola USB Modem  
22B8:41D4=Motorola USB Networking Driver  
22B8:41D5=Motorola USB Modem  
22B8:41D5:02=Motorola USB Networking Driver  
22B8:41D6=Droid X (Windows media mode)  
22B8:41D8=Motorola USB Modem  
22B8:41D8:02=Motorola USB Networking Driver  
22B8:41D9=Motorola Droid  
22B8:41DA=Motorola USB Modem  
22B8:41DA:02=Motorola USB Networking Driver  
22B8:41DA:04=Mot Composite ADB Interface  
22B8:41DB=Motorola Droid (USB Debug)  
22B8:41DB:01=Mot Composite ADB Interface  
22B8:41DC=Motorola USB Composite Device  
22B8:41DC:01=Mot Composite ADB Interface  
22B8:41DD=Motorola USB Modem  
22B8:41DE=Droid X (PC mode)  
22B8:41E2=Motorola USB Modem  
22B8:41E2:02=Motorola USB Networking Driver  
22B8:41E2:04=Mot Composite ADB Interface  
22B8:41E3=Motorola USB Modem  
22B8:41E3:02=Motorola USB Networking Driver  
22B8:41E5=Motorola USB Composite Device  
22B8:41E5:02=Mot Composite ADB Interface  
22B8:41E6=Motorola USB Networking Driver  
22B8:41E7=Motorola USB Networking Driver  
22B8:41E7:02=Mot Composite ADB Interface  
22B8:41E8=Motorola USB Modem  
22B8:41E8:02=Motorola USB Networking Driver  
22B8:41E9=Motorola USB Modem  
22B8:41E9:02=Motorola USB Networking Driver  
22B8:41E9:04=Mot Composite ADB Interface  
22B8:41EA=Motorola USB Networking Driver  
22B8:41EA:01=Mot Composite ADB Interface  
22B8:41EB=Motorola USB Device  
22B8:41EC=Motorola USB Device  
22B8:41EC:01=Mot Composite ADB Interface  
22B8:41ED=Motorola USB Modem  
22B8:41ED:02=Motorola USB Networking Driver  
22B8:41ED:03=Mot Composite ADB Interface  
22B8:41EE:06=Motorola USB Diagnostic Port

22B8:41EE:07=Motorola USB Device  
22B8:41EE:09=Mot Composite ADB Interface  
22B8:4204=Motorola MPx200 Smartphone  
22B8:4214=Motorola MPc GSM  
22B8:4220=Smartphone Wireless USB Modem  
22B8:4224=Motorola MPx220 Smartphone  
22B8:4234=Motorola MPc CDMA  
22B8:4244=Motorola MPx100 Smartphone  
22B8:4265=Motorola USB Composite Device  
22B8:4266=Motorola USB Composite Device  
22B8:4267=Motorola USB Composite Device  
22B8:4268=Motorola USB Composite Device  
22B8:4272=Motorola USB Networking Driver  
22B8:4273=Motorola USB Modem  
22B8:4274=Motorola USB Modem  
22B8:4283=Motorola USB Modem  
22B8:4283:02=Motorola USB Networking Driver  
22B8:4284=Motorola USB Modem  
22B8:4284:02=Motorola USB Networking Driver  
22B8:4284:04=Mot Composite ADB Interface  
22B8:4285=Droid X (Mass storage)  
22B8:4286:01=Mot Composite ADB Interface  
22B8:4288=Motorola MTP Device  
22B8:4289=Motorola USB Composite Device  
22B8:4289:01=Mot Composite ADB Interface  
22B8:428A=Motorola USB Networking Driver  
22B8:428B=Motorola USB Networking Driver  
22B8:428B:01=Mot Composite ADB Interface  
22B8:428C:01=Mot Composite ADB Interface  
22B8:42A1=Motorola USB Modem  
22B8:42A1:02=Motorola USB Networking Driver  
22B8:42A2=Motorola USB Modem  
22B8:42A2:02=Motorola USB Networking Driver  
22B8:42A2:04=Mot Composite ADB Interface  
22B8:42A4:01=Mot Composite ADB Interface  
22B8:42A6=Motorola MTP Device  
22B8:42A7=Motorola USB Composite Device  
22B8:42A7:01=Mot Composite ADB Interface  
22B8:42A8=Motorola USB Networking Driver  
22B8:42A9=Motorola USB Networking Driver  
22B8:42A9:01=Mot Composite ADB Interface  
22B8:42AA:01=Mot Composite ADB Interface  
22B8:42B1=Motorola USB Modem  
22B8:42B1:02=Motorola USB Networking Driver  
22B8:42B2=Motorola USB Modem  
22B8:42B2:02=Motorola USB Networking Driver  
22B8:42B2:04=Mot Composite ADB Interface  
22B8:42B4:01=Mot Composite ADB Interface  
22B8:42B6=Motorola MTP Device  
22B8:42B7=Motorola USB Composite Device  
22B8:42B7:01=Mot Composite ADB Interface  
22B8:42B8=Motorola USB Networking Driver  
22B8:42B9=Motorola USB Networking Driver  
22B8:42B9:01=Mot Composite ADB Interface  
22B8:42BA:01=Mot Composite ADB Interface  
22B8:42C1=Motorola USB Modem  
22B8:42C1:01=Mot Composite ADB Interface  
22B8:42C1:02=Motorola USB Networking Driver  
22B8:42C2=Motorola USB Modem  
22B8:42C2:02=Motorola USB Networking Driver



22B8:42C2:04=Mot Composite ADB Interface  
22B8:42C4:01=Mot Composite ADB Interface  
22B8:42C6=Motorola MTP Device  
22B8:42C7=Motorola USB Composite Device  
22B8:42C7:01=Mot Composite ADB Interface  
22B8:42C8=Motorola USB Networking Driver  
22B8:42C9=Motorola USB Networking Driver  
22B8:42C9:01=Mot Composite ADB Interface  
22B8:42CA:01=Mot Composite ADB Interface  
22B8:42D1=Mot Single ADB Interface  
22B8:42D2=Motorola USB Networking Driver  
22B8:42D3=Motorola USB Networking Driver  
22B8:42D3:01=Mot Composite ADB Interface  
22B8:42D4=Motorola USB Modem  
22B8:42D4:02=Motorola USB Networking Driver  
22B8:42D5=Motorola USB Modem  
22B8:42D5:02=Motorola USB Networking Driver  
22B8:42D5:04=Mot Composite ADB Interface  
22B8:42D7:01=Mot Composite ADB Interface  
22B8:42D9:01=Mot Composite ADB Interface  
22B8:42DA=Motorola MTP Device  
22B8:42DB=Motorola USB Composite Device  
22B8:42DB:01=Mot Composite ADB Interface  
22B8:42DD=Motorola USB Composite Device  
22B8:42DD:02=Mot Composite ADB Interface  
22B8:42E0=Motorola USB Device  
22B8:42F1=Mot Single ADB Interface  
22B8:42F2=Motorola USB Networking Driver  
22B8:42F3=Motorola USB Networking Driver  
22B8:42F3:01=Mot Composite ADB Interface  
22B8:42F4=Motorola USB Modem  
22B8:42F4:02=Motorola USB Networking Driver  
22B8:42F5=Motorola USB Modem  
22B8:42F5:02=Motorola USB Networking Driver  
22B8:42F5:04=Mot Composite ADB Interface  
22B8:42F7:01=Mot Composite ADB Interface  
22B8:42F9:01=Mot Composite ADB Interface  
22B8:42FA=Motorola MTP Device  
22B8:42FB=Motorola USB Composite Device  
22B8:42FB:01=Mot Composite ADB Interface  
22B8:42FD=Motorola USB Composite Device  
22B8:42FD:02=Mot Composite ADB Interface  
22B8:4300=Motorola USB Device  
22B8:4301=Motorola USB Modem  
22B8:4301:02=Motorola LTE BP Modem  
22B8:4301:04=Motorola QC BP Modem  
22B8:4301:06=Motorola QC Diag Port  
22B8:4301:08=Motorola USB Networking Driver  
22B8:4302=Motorola USB Modem  
22B8:4302:02=Motorola LTE BP Modem  
22B8:4302:04=Motorola QC BP Modem  
22B8:4302:06=Motorola QC Diag Port  
22B8:4302:08=Motorola USB Networking Driver  
22B8:4302:09=Mot Composite ADB Interface  
22B8:4303:02=Motorola USB Modem  
22B8:4303:04=Motorola LTE BP Modem  
22B8:4303:06=Motorola QC BP Modem  
22B8:4303:08=Motorola QC Diag Port  
22B8:4303:0A=Motorola USB Networking Driver  
22B8:4304:02=Motorola USB Modem

22B8:4304:04=Motorola LTE BP Modem  
22B8:4304:06=Motorola QC BP Modem  
22B8:4304:08=Motorola QC Diag Port  
22B8:4304:0A=Motorola USB Networking Driver  
22B8:4304:0B=Mot Composite ADB Interface  
22B8:4310=Motorola USB Networking Driver  
22B8:4311=Motorola USB Networking Driver  
22B8:4311:02=Mot Composite ADB Interface  
22B8:4312=Motorola USB Networking Driver  
22B8:4313=Motorola AT COM Port  
22B8:4313:02=Motorola USB Networking Driver  
22B8:4313:03=Mot Composite ADB Interface  
22B8:4314=Motorola USB Modem  
22B8:4314:02=Motorola USB Networking Driver  
22B8:4314:04=Mot Composite ADB Interface  
22B8:4315=Motorola USB Modem  
22B8:4315:02=Motorola USB Networking Driver  
22B8:4315:04=Mot Composite ADB Interface  
22B8:4317:01=Mot Composite ADB Interface  
22B8:4319:01=Mot Composite ADB Interface  
22B8:431B=Motorola USB Composite Device  
22B8:431B:01=Mot Composite ADB Interface  
22B8:431D=Motorola USB Composite Device  
22B8:431D:02=Mot Composite ADB Interface  
22B8:431F=Motorola USB Modem  
22B8:431F:02=Motorola AT COM Port  
22B8:431F:04=Motorola USB Networking Driver  
22B8:431F:06=Mot Composite ADB Interface  
22B8:4320=Motorola USB Device  
22B8:4330=Motorola USB Modem  
22B8:4330:02=Motorola USB Networking Driver  
22B8:4330:04=Mot Composite ADB Interface  
22B8:4331=Motorola USB Modem  
22B8:4331:02=Motorola USB Networking Driver  
22B8:4331:04=Mot Composite ADB Interface  
22B8:4333:01=Mot Composite ADB Interface  
22B8:4335:01=Mot Composite ADB Interface  
22B8:4337=Motorola USB Composite Device  
22B8:4337:01=Mot Composite ADB Interface  
22B8:4339=Motorola USB Composite Device  
22B8:4339:02=Mot Composite ADB Interface  
22B8:433A=Motorola USB Networking Driver  
22B8:433B=Motorola USB Networking Driver  
22B8:433B:02=Mot Composite ADB Interface  
22B8:4801=Neptune LTS chipset  
22B8:4802=Motorola USB Modem  
22B8:4803=Neptune LTS chipset flash  
22B8:4805=Motorola USB Modem  
22B8:4810=E398 Storage  
22B8:4901=Triplet GSM Phone (P2K)  
22B8:4902=Motorola USB Modem  
22B8:4903=Neptune LTE chipset flash  
22B8:4905=Motorola USB Modem  
22B8:4A01=Neptune LTX chipset  
22B8:4A02=Motorola USB Modem  
22B8:4A03=Neptune LTX chipset flash  
22B8:4A05=Motorola USB Modem  
22B8:4A32=L6-imode Phone  
22B8:5801=Neptune ULS chipset  
22B8:5802=Motorola USB Modem

22B8:5803=Neptune ULS chipset flash  
22B8:5804=Motorola USB Modem  
22B8:5901=Neptune VLT chipset  
22B8:5903=Neptune VLT chipset flash  
22B8:5904=Motorola USB Modem  
22B8:6001=Dalhart EZX  
22B8:6002=Motorola USB Modem  
22B8:6003=Dalhart flash  
22B8:6004=EZX GSM Phone (CDC Net)  
22B8:6006=MOTOROKR E6  
22B8:6008=Dalhart RDL  
22B8:6009=EZX GSM Phone (P2K)  
22B8:600A=Dalhart EZX config 17  
22B8:600B=Dalhart EZX config 18  
22B8:600C=A768i GSM Phone  
22B8:6021=JUIX chipset  
22B8:6022=Motorola USB Modem  
22B8:6023=JUIX chipset flash  
22B8:6024=Motorola USB Modem  
22B8:6026=Flash RAM Downloader/miniOS  
22B8:6027=Motorola USB Networking Driver  
22B8:604C=A780 GSM Phone (storage)  
22B8:6101=Talon integrated chipset  
22B8:6102=Motorola USB Modem  
22B8:6109=Motorola USB Composite Device  
22B8:6139=Motorola USB Composite Device  
22B8:6401=Argon chipset  
22B8:6402=Motorola USB Modem  
22B8:6403=Argon chipset flash  
22B8:6404=Motorola USB Modem  
22B8:6406=Motorola USB Modem  
22B8:6411=Motorola PTP Device  
22B8:6413=Motorola USB Modem  
22B8:6415=ROKR Z6 (MTP mode)  
22B8:6416=Motorola PTP Device  
22B8:6422=Motorola USB Modem  
22B8:6424=Motorola USB Networking Driver  
22B8:6424:01=Motorola USB Networking Driver  
22B8:6424:02=Motorola USB Networking Driver  
22B8:6424:03=Motorola USB Networking Driver  
22B8:6424:04=Motorola USB Networking Driver  
22B8:6425=Motorola USB Modem  
22B8:6425:01=Motorola USB Networking Driver  
22B8:6425:02=Motorola USB Networking Driver  
22B8:6425:03=Motorola USB Networking Driver  
22B8:6425:04=Motorola USB Networking Driver  
22B8:6427:01=Motorola USB Networking Driver  
22B8:6427:02=Motorola USB Networking Driver  
22B8:6427:03=Motorola USB Networking Driver  
22B8:6427:04=Motorola USB Networking Driver  
22B8:6490=Motorola USB Modem  
22B8:6493=Motorola USB Modem  
22B8:6604=Washington CDMA Phone  
22B8:6631=Motorola 1xEV-DO Handset  
22B8:6631:02=Motorola 1xEV-DO Handset Diagnostic Serial Port Drivers (WDM)  
22B8:7000:0001=Smartphone Wireless USB Modem  
22B8:7000:0002=Smartphone Wireless USB Modem  
22B8:7000:0003=Smartphone Wireless USB Modem  
22B8:7001=Q Smartphone  
22B8:7080=Motorola USB Networking Driver

22B8:7080:02=Mot Composite ADB Interface  
22B8:7081=Motorola USB Networking Driver  
22B8:7082=Motorola USB Networking Driver  
22B8:7082:01=Mot Composite ADB Interface  
22B8:7083=Motorola USB Networking Driver  
22B8:7087:01=Mot Composite ADB Interface  
22B8:7088=Motorola MTP Device  
22B8:7089=Motorola USB Composite Device  
22B8:7089:01=Mot Composite ADB Interface  
22B8:708A=Motorola USB Modem  
22B8:708A:02=Motorola USB Networking Driver  
22B8:708B=Motorola USB Modem  
22B8:708B:02=Motorola USB Networking Driver  
22B8:708B:04=Mot Composite ADB Interface  
22B8:708C=Mot Single ADB Interface  
22B8:708D=Motorola USB Device  
22B8:7090:01=Mot Composite ADB Interface  
22B8:7092=Motorola USB Composite Device  
22B8:7092:02=Mot Composite ADB Interface  
22B8:7093=Motorola USB Modem  
22B8:7093:02=Motorola LTE BP Modem  
22B8:7093:04=Motorola QC BP Modem  
22B8:7093:06=Motorola QC Diag Port  
22B8:7093:08=Motorola USB Networking Driver  
22B8:7094=Motorola USB Modem  
22B8:7094:02=Motorola LTE BP Modem  
22B8:7094:04=Motorola QC BP Modem  
22B8:7094:06=Motorola QC Diag Port  
22B8:7094:08=Motorola USB Networking Driver  
22B8:7094:09=Mot Composite ADB Interface  
22B8:7095:02=Motorola USB Modem  
22B8:7095:04=Motorola LTE BP Modem  
22B8:7095:06=Motorola QC BP Modem  
22B8:7095:08=Motorola QC Diag Port  
22B8:7095:0A=Motorola USB Networking Driver  
22B8:7096:02=Motorola USB Modem  
22B8:7096:04=Motorola LTE BP Modem  
22B8:7096:06=Motorola QC BP Modem  
22B8:7096:08=Motorola QC Diag Port  
22B8:7096:0A=Motorola USB Networking Driver  
22B8:7096:0B=Mot Composite ADB Interface  
22B8:70A2=Motorola USB Networking Driver  
22B8:70A2:01=Mot Composite ADB Interface  
22B8:70A3=Motorola USB Networking Driver  
22B8:70A9=Motorola USB Composite Device  
22B8:70A9:01=Mot Composite ADB Interface  
22B8:70AA=Motorola USB Modem  
22B8:70AA:02=Motorola USB Networking Driver  
22B8:70AB=Motorola USB Modem  
22B8:70AB:02=Motorola USB Networking Driver  
22B8:70AB:04=Mot Composite ADB Interface  
22B8:70AC=Mot Single ADB Interface  
22B8:70AD=Motorola USB Device  
22B8:70AF=Motorola USB Composite Device  
22B8:70AF:02=Mot Composite ADB Interface  
22B8:70B0=Motorola LTE BP Modem  
22B8:70B0:02=Motorola QC BP Modem  
22B8:70B0:04=Motorola QC Diag Port  
22B8:70B0:06=Motorola USB Networking Driver  
22B8:70B1=Motorola LTE BP Modem

22B8:70B1:02=Motorola QC BP Modem  
22B8:70B1:04=Motorola QC Diag Port  
22B8:70B1:06=Motorola USB Networking Driver  
22B8:70B1:07=Mot Composite ADB Interface  
22B8:70B2:02=Motorola LTE BP Modem  
22B8:70B2:04=Motorola QC BP Modem  
22B8:70B2:06=Motorola QC Diag Port  
22B8:70B2:08=Motorola USB Networking Driver  
22B8:70B3:02=Motorola LTE BP Modem  
22B8:70B3:04=Motorola QC BP Modem  
22B8:70B3:06=Motorola QC Diag Port  
22B8:70B3:08=Motorola USB Networking Driver  
22B8:70B3:09=Mot Composite ADB Interface  
22B8:70C1=Mot Single ADB Interface  
22B8:70C2=Motorola USB Networking Driver  
22B8:70C3=Motorola USB Networking Driver  
22B8:70C3:01=Mot Composite ADB Interface  
22B8:70C4=Motorola USB Modem  
22B8:70C4:02=Motorola USB Networking Driver  
22B8:70C5=Motorola USB Modem  
22B8:70C5:02=Motorola USB Networking Driver  
22B8:70C5:04=Mot Composite ADB Interface  
22B8:70C7:01=Mot Composite ADB Interface  
22B8:70C9:01=Mot Composite ADB Interface  
22B8:70CA=Motorola MTP Device  
22B8:70CB=Motorola USB Composite Device  
22B8:70CB:01=Mot Composite ADB Interface  
22B8:70CD=Motorola USB Composite Device  
22B8:70CD:02=Mot Composite ADB Interface  
22B8:70D0=Motorola USB Device  
22B8:A668=Motorola USB Modem  
22B8:FE01=StarTAC III MS900  
22B9=eTurboTouch Technology  
22B9:0006=Touch Screen  
22BA=Technology Innovation Holdings  
22C7=MEMUP  
22C8=Karming Electronic (Shenzhen)  
22DB=Phase One A/S  
22E4=Shenyang Tongzhen Precision Electronic Technology  
22FD=Miltope  
22FF=Avnet  
2304=Pinnacle  
2304:0109=Pinnacle Studio PCTV USB (SECAM)  
2304:0110=Pinnacle Studio PCTV USB (PAL)  
2304:0111=Miro PCTV USB  
2304:0112=Pinnacle Studio PCTV USB (NTSC) with FM radio  
2304:0201=Systems MovieBox Device  
2304:0204=MovieBox USB\_B  
2304:0205=DVC 150B  
2304:0206=Pinnacle Systems MovieBox Deluxe Device  
2304:0207=Dazzle DVC90 Video Device  
2304:0208=Pinnacle PCTV 100e/150e  
2304:0208:01=PCTV USB2 2821 Audio  
2304:020E=Pinnacle PCTV 200e  
2304:020F=PCTV 400e BDA Device  
2304:0210=Pinnacle Studio PCTV USB (PAL) with FM radio  
2304:0212=Pinnacle Studio PCTV USB (NTSC)  
2304:0213=Pinnacle Systems 500-USB Device  
2304:0214=Pinnacle Studio PCTV USB (PAL) with FM radio  
2304:0216=Pinnacle PCTV 60e

2304:0219=Pinnacle PCTV 260e  
2304:021A=Dazzle DVC100 Audio Device  
2304:021B=Dazzle DVC130/DVC170  
2304:021D=Dazzle DVC130  
2304:021E=Dazzle DVC170  
2304:021F=PCTV Sat HDTV Pro BDA Device  
2304:0222=PCTV Sat Pro BDA Device  
2304:0223=DazzleTV Sat BDA Device  
2304:0225=Remote Kit Infrared Transceiver  
2304:0226=Pinnacle PCTV 330e  
2304:0227=Pinnacle PCTV 800e  
2304:0228=Infrared Receiver  
2304:0229=Infrared Receiver  
2304:022A=PCTV 160e  
2304:022B=Pinnacle PCTV 71e  
2304:022C=Infrared Receiver  
2304:0231=Pinnacle PCTV 380e  
2304:0232=Pinnacle PCTV 170e  
2304:0233=Pinnacle PCTV 880e  
2304:0236=PCTV 72e [DiBcom DiB7000PC]  
2304:0237=Infrared Receiver  
2304:0239=Infrared Receiver  
2304:023A=PCTV 801e  
2304:023B=PCTV 801e SE  
2304:023D=PCTV 340e  
2304:023E=PCTV 340e SE  
2304:023F=Pinnacle PCTV 80e  
2304:0240=Pinnacle PCTV 80e SE  
2304:0242=Pinnacle PCTV 510e  
2304:0243=Infrared Receiver  
2304:0300=Pinnacle Studio Linx Video input cable (NTSC)  
2304:0301=Pinnacle Studio Linx Video input cable (PAL)  
2304:0302=Dazzle DVC120  
2304:0326=PCTV 72e  
2304:0419=Pinnacle PCTV Bungee USB (PAL) with FM radio  
2304:061D=PCTV Deluxe (NTSC) Device  
2304:061E=PCTV Deluxe (PAL) Device  
2313=Kunshan Jiahua Electronics  
2314=INQ Mobile  
2315=Avery Design Systems  
2316=DongGuan Potec Electric Industrial  
2317=Huawei Device  
2318=Shining Technologies  
2318:0011=CitiDISK Jr. IDE Enclosure  
2326=CHAO KUEI MOLD INDUSTRIAL  
2330=Tensorcom  
2331=PUZZLE LOGIC INC.  
2344=HAMBURG INDUSTRIES  
234C=Zenverge  
234D=Skype  
2358=Greenconn  
2359=Shenzhen Autone-Tronic Technology  
235A=Top Yang Technology Enterprise  
235B=KangXiang Electronic  
236C=ZheJiang Chunsheng Electronics  
236D=e-supplies  
2373=Pumatronix  
2373:0001=5 MegaPixel Digital Still Camera [DSC5M]  
2375=Digit@lway  
2375:0001=Digital Audio Player

2382=Trigaudio  
23AB=Shenzhen Zhengtong Electronics  
23AC=Marunix Electron  
23BB=EMI STOP  
23CD=Avconn Precise Connector  
23CE=Gembird Electronics  
23D5=SerialTek  
23D6=DONGGUAN LICHENG ELECTRONICS  
23DC=Phonic Ear  
23E0=BitifEye Digital Test Solutions GmbH  
23E1=Vidyo  
23F4=NXT Plc  
23F5=SpeedConn  
23FD=AWare  
23FE=Express Way  
2400=ChuangYi Hardware Precision Mould Com.  
2406=SANHO Digital Electronics  
2406:6688=PD7X Portable Storage  
2407=Incasolution  
2408=Catalyst Enterprises  
240F=Trantek Electronics  
241A=The Silanna Group  
241B=Dongguan City Qirui Electronics  
2438=Innopower Technology  
2474:3642=Intersil IEEE 802.11 LAN USB Adapter  
2478=Tripp-Lite  
2478:2008=U209-000-R Serial Port  
2522:0001=A4Tech USB Port Mouse  
2522:0002=A4Tech USB Port Mouse  
2632=TwinMOS  
2632:3209=7-in-1 Card Reader  
2645=Lead Data  
2650=Electronics For Imaging  
2703:035F:01=Nokia USB Phone Parent  
2730=Citizen  
2730:200F=CT-S310 Label printer  
2735=DigitalWay  
2735:0003=MPIO 1.5GB Hard Disc Drive  
2735:0091=TDK MOJO Player  
2735:1001=MPIO FY200  
2735:1002=MPIO FL100  
2735:1003=MPIO FD100  
2735:1004=MPIO HD200  
2735:1005=MPIO HD300  
2735:1006=MPIO FG100  
2735:1007=MPIO FG130  
2735:1008=MPIO FY300  
2735:1009=MPIO FY400  
2735:100A=MPIO FL300  
2735:100B=MPIO HS200  
2735:100C=MPIO FL350  
2735:100D=MPIO FY500  
2735:100E=MPIO FY500  
2735:100F=MPIO FY600  
2735:1012=MPIO FL400  
2735:1013=MPIO HD400  
2735:1014=MPIO HD400  
2735:1016=MPIO FY700  
2735:1017=MPIO FY700  
2735:1018=MPIO FY800

2735:1019=MPIO FY800  
2735:101A=MPIO FY900  
2735:101B=MPIO FY900  
2735:102B=MPIO FL500  
2735:102C=MPIO FL500  
2735:103F=MPIO FY570  
2735:1040=MPIO FY570  
2735:1041=MPIO FY670  
2735:1042=MPIO FY670  
2735:1043=HCT HMD-180A  
2735:1044=HCT HMD-180A  
2770=NHJ  
2770:0A01=HP ScanJet 4600 series  
2770:905C=Che-Ez Snap SNAP-U/Digigr8/Soundstar TDC-35  
2770:9060=A130  
2770:9080=MegaCam  
2770:9120=Che-ez! Snap / iClick Tiny VGA Digital Camera  
2770:9130=TCG 501  
2770:913C=Argus Digital Still Camera  
2770:9150=Mini Cam  
2770:9153=iClick 5X  
2770:915D=Cyberpix S-210S / Little Tikes My Real Digital Camera  
2770:930B=CCD Webcam(PC370R)  
2770:930C=CCD Webcam(PC370R)  
2821=Unknown  
2821:0161=ASUS 802.11b Wireless LAN Adapter  
2821:160F=WL-160g 802.11g Wireless Adapter [Envara WiND512]  
2821:3300=Wireless Adapter  
2899=Toptronic Industrial  
2899:012C=Camera Device  
2C02=Planex Communications  
2C02:14EA=GW-US11H WLAN  
2C1A=Dolphin Peripherals  
2C1A:0000=Wireless Optical Mouse  
2FB2=Fujitsu  
3001:044E=Bluetooth Devices  
3125=Eagletron  
3125:0001=TrackerPod Camera Stand  
3176=WHANAM ELECTRONICS  
3252:0004=Centrality Atlas Chip USB Utilites  
3275=VidzMedia Pte  
3275:4FB1=MonsterTV P2H  
3333:3333=VGA2USB Pro  
3334=AEI  
3334:1701=AEI USB To Fast Ethernet Adapter  
3337:3337=KVM2USB Pro  
3340=Yakumo  
3340:011C=Mio DigiWalker PPC StrongARM  
3340:0326=Mio DigiWalker 338  
3340:0426=Mio DigiWalker 338  
3340:043A=MiTAC Mio136 Sync  
3340:051C=MiTAC USB Sync 528  
3340:053A=Mio DigiWalker SmartPhone USB Sync  
3340:071C=MiTAC USB Sync  
3340:0B1C=Generic PPC StrongARM  
3340:0E3A=Pocket PC 300 GPS SL  
3340:0F1C=Itautec USB Sync  
3340:0F3A=Generic SmartPhone USB Sync  
3340:1326=Itautec USB Sync  
3340:191C=YAKUMO USB Sync



3340:2326=Vobis USB Sync  
3340:3326=Medion USB Sync  
3340:3340=VGA2USB LR  
3340:A0A3=deltaX 5 BT (D) PDA  
3344:3344=KVM2USB LR  
3344:D630=TeVii S630 BDA DVB-S  
3411:3411=DVI2USB Solo  
3422:3422=DVI2USB Duo  
3495:00E0=USB 2.0 Debug Connection Device  
3504=Micro Star  
3504:F110=Security Key  
3538=Power Quotient International  
3538:0001=Travel Flash  
3538:0008=Generic USB Mass Storage Device  
3538:0009=Generic USB Mass Storage Device  
3538:0011=Generic USB Mass Storage Device  
3538:0012=Generic USB Mass Storage Device  
3538:0015=Mass Storge Device  
3538:0022=Hi-Speed Mass Storage Device  
3538:0042=Cool Drive U339 Flash Disk  
3538:0054=Flash Drive (2GB)  
3574:000B=Bluetooth 2.0 USB adapter 10m  
3574:000C=Bluetooth 2.0 USB adapter 100m  
3574:21F4=Sitecom USB Bluetooth Dongle  
3574:21F6=Sitecom USB Bluetooth Dongle  
3579=DIVA  
3579:6901=Media Reader  
3636=InVibro  
3708:20CE=Legend USB Sync  
3708:21CE=Lenovo USB Sync  
3823:0001=Touchkit USB Controller for TouchScreen  
3823:0002=Touchkit USB Controller for TouchScreen  
3838=WEM  
3838:0001=5-in-1 Card Reader  
3923=National Instruments  
3923:0327=SCXI-1600  
3923:12C0=DAQPad-6020E  
3923:12D0=DAQPad-6507  
3923:12E0=NI 4350 for USB  
3923:12F0=NI 5102 for USB  
3923:1750=DAQPad-6508  
3923:17B0=USB-ISA-Bridge  
3923:1820=DAQPad-6020E (68 pin I/O)  
3923:1830=DAQPad-6020E (BNC)  
3923:1F00=DAQPad-6024E for USB  
3923:1F10=DAQPad-6024E for USB  
3923:1F20=DAQPad-6025E for USB  
3923:1F30=DAQPad-6025E for USB  
3923:1F40=DAQPad-6036E for USB  
3923:1F50=DAQPad-6036E for USB  
3923:2F80=DAQPad-6052E for USB  
3923:2F90=DAQPad-6052E for USB  
3923:702A=GPIB-USB-B  
3923:702B=GPIB-USB-B Initialization  
3923:703C=USB-485 RS485 Cable  
3923:709B=GPIB-USB-HS  
3923:70F9=USB Update Device  
3923:7254=NI MIO (data acquisition card) firmware updater  
3923:729E=USB-6251 (OEM) data acquisition card  
3923:C910:0100=GPIB-USB

3923:C920=GPIB-USB-A  
40BB=I-O Data  
40BB:0A09=USB2.0-SCSI Bridge USB2-SC  
4101=i-rocks  
4101:1301=IR-2510 usb phone  
4102=iRiver  
4102:1001=iRiver Internet Audio Player IFP-100  
4102:1003=iRiver Internet Audio Player IFP-300  
4102:1005=iRiver Internet Audio Player IFP-500  
4102:1007=iRiver Internet Audio Player IFP-700  
4102:1008=iRiver Internet Audio Player IFP-800  
4102:1009=iriver Internet Audio Player IFP-900  
4102:100A=iFP-1000 series mp3/ogg vorbis player  
4102:1010=iRiver Internet Audio Player IFP-1000  
4102:1011=iriver Internet Audio Player N10  
4102:1014=T20 series mp3/ogg vorbis player (ums firmware)  
4102:1019=T30  
4102:1034=T60  
4102:1040=M1Player  
4102:1041=E100 (ums)  
4102:1101=iFP-100 series mp3 player (ums firmware)  
4102:1103=iFP-300 series mp3 player (ums firmware)  
4102:1105=iFP-500 series mp3 player (ums firmware)  
4102:1113=T10 (alternate)  
4102:1117=T10  
4102:1119=T30 series mp3/ogg/wma player  
4102:1141=E100 (mtp)  
4102:2002=H10 6GB  
4102:2101=H10 20GB (mtp)  
4102:2102=H10 5GB (mtp)  
4102:2105=H10 5/6GB (mtp)  
4113:0210=Mobile Media Technology USB Sync  
4113:0211=Mobile Media Technology USB Sync  
4113:0400=Mobile Media Technology USB Sync  
4113:0410=Mobile Media Technology USB Sync  
413C=Dell  
413C:0000=DRAC 5 Virtual Keyboard and Mouse  
413C:0001=DRAC 5 Virtual Media  
413C:0058=Port Replicator  
413C:028F=Broadcom Bluetooth 2.1 + EDR USB Device  
413C:02B0=BCM2046 Bluetooth Device  
413C:02B9=Broadcom Bluetooth 2.1 + EDR USB Device  
413C:1001=Keyboard Hub  
413C:1002=Keyboard Hub  
413C:1003=Keyboard Hub  
413C:1005=Multimedia Pro Keyboard Hub  
413C:2001=Keyboard HID Support  
413C:2002=SK-8125 Keyboard  
413C:2003=Keyboard  
413C:2005=Dell USB Keyboard  
413C:2005:0105=Dell USB Keyboard Model RT7D50  
413C:2010=Keyboard  
413C:2011=Multimedia Pro Keyboard  
413C:2100=SK-3106 Keyboard  
413C:2100:01=USB Keyboard Smart Card Reader  
413C:2101=SmartCard Reader Keyboard  
413C:2101:01=Smart Card Reader Keyboard  
413C:2105=Model L100 Keyboard  
413C:2106=Dell QuietKey Keyboard  
413C:2500=DRAC4 Remote Access Card

413C:2513=internal USB Hub of E-Port Replicator  
413C:3010=Optical Wheel Mouse  
413C:3012=Optical Wheel Mouse  
413C:3016=Premium Tilt Wheel (HID)  
413C:3200=USB Mouse  
413C:4001=Axim X5  
413C:4002=Axim X3  
413C:4003=Axim X30  
413C:4004=Axim Sync  
413C:4005=Axim Sync  
413C:4006=Axim Sync  
413C:4007=Axim Sync  
413C:4008=Axim Sync  
413C:4009=Axim Sync  
413C:4011=Axim X51v  
413C:5103=Dell AIO Printer A940  
413C:5105=AIO Printer A920  
413C:5107=AIO Printer A960  
413C:5109=Dell Photo AIO Printer 922  
413C:5110=Photo AIO Printer 962  
413C:5111=Photo AIO Printer 942  
413C:5112=Dell Photo AIO Printer 924  
413C:5113=Photo AIO Printer 944  
413C:5114=Photo AIO Printer 964  
413C:5115=Photo AIO Printer 926  
413C:5116=AIO Printer 946  
413C:5117=Photo AIO Printer 966  
413C:5118=AIO 810  
413C:5124=Laser MFP 1815  
413C:5128=Photo AIO 928  
413C:5128:04=Dell Photo AIO 928 service driver  
413C:5200=Laser Printer  
413C:5202=Printing Support  
413C:5203=Printing Support  
413C:5210=Printing Support  
413C:5211=Printing Support  
413C:5220=Dell Laser MFP 1600n  
413C:5225=Printing Support  
413C:5226=Printing Support  
413C:5300=Laser Printer  
413C:5302:0001:01=Dell MFP 1125 Scanner  
413C:5302:0001:02=Dell MFP 1125 Status Monitor  
413C:5305=Dell V305  
413C:5400=Laser Printer  
413C:5401=Laser Printer  
413C:5513=WLA3310 Wireless Adapter [Intersil ISL3887]  
413C:5601=Laser Printer 3100cn  
413C:5602=Laser Printer 3000cn  
413C:5631=Laser Printer 5100cn  
413C:5905=Printing Support  
413C:8000=Dell TrueMobile Bluetooth Module  
413C:8010=Dell TrueMobile Bluetooth Module in Firmware Upgrade  
413C:8100=TrueMobile 1180 802.11b Adapter  
413C:8102=TrueMobile 1300 USB2.0 WLAN Card  
413C:8103=Dell Wireless 350 Bluetooth Module  
413C:8104=Wireless 1450 Dual-band (802.11a/b/g) USB2.0 Adapter  
413C:8105=U2 in HID - Driver  
413C:8106=Dell Wireless 350 Bluetooth Internal Card in Firmware Upgrade  
413C:8110=Dell Wireless 3xx Bluetooth Internal Card  
413C:8111=Dell Wireless 3xx Bluetooth Internal Card in Firmware Upgrade

413C:8114=Dell Wireless 5700 Mobile Broadband (CDMA EV-DO) Minicard Modem  
413C:8114:01=Dell Wireless 5700 Mobile Broadband (CDMA EV-DO) Minicard Status Port  
413C:8114:02=Dell Wireless 5700 Mobile Broadband (CDMA EV-DO) Minicard Diagnostics Port  
413C:8114:03=Dell Wireless 5700 Mobile Broadband (CDMA EV-DO) Minicard GPS Port  
413C:8115=Dell Wireless 5500 Mobile Broadband (3G HSDPA) Minicard Modem  
413C:8115:01=Dell Wireless 5500 Mobile Broadband (3G HSDPA) Minicard Status Port  
413C:8115:02=Dell Wireless 5500 Mobile Broadband (3G HSDPA) Minicard Diagnostics Port  
413C:8115:03=Dell Wireless 5500 Mobile Broadband (3G HSDPA) Minicard EAP-SIM Port  
413C:8116=Dell Wireless 5505 Mobile Broadband (3G HSDPA) Minicard Modem  
413C:8116:01=Dell Wireless 5505 Mobile Broadband (3G HSDPA) Minicard Status Port  
413C:8116:02=Dell Wireless 5505 Mobile Broadband (3G HSDPA) Minicard Diagnostics Port  
413C:8116:03=Dell Wireless 5505 Mobile Broadband (3G HSDPA) Minicard EAP-SIM Port  
413C:8117=Dell Wireless 5700 Mobile Broadband (CDMA EV-DO) Expresscard Modem  
413C:8117:01=Dell Wireless 5700 Mobile Broadband (CDMA EV-DO) Expresscard Status Port  
413C:8117:02=Dell Wireless 5700 Mobile Broadband (CDMA EV-DO) Expresscard Diagnostics Port  
413C:8117:03=Dell Wireless 5700 Mobile Broadband (CDMA EV-DO) Expresscard GPS Port  
413C:8118=Dell Wireless 5510 Mobile Broadband (3G HSDPA) Expresscard Modem  
413C:8118:01=Dell Wireless 5510 Mobile Broadband (3G HSDPA) Expresscard Status Port  
413C:8118:02=Dell Wireless 5510 Mobile Broadband (3G HSDPA) Expresscard Diagnostics Port  
413C:8118:03=Dell Wireless 5510 Mobile Broadband (3G HSDPA) Expresscard EAP-SIM Port  
413C:8120=Dell Bluetooth USB adapter  
413C:8121=Eastfold in HID  
413C:8122=Eastfold in DFU  
413C:8123=eHome Infrared Receiver (USBCIR)  
413C:8124=eHome Infrared Receiver (USBCIR)  
413C:8126=Dell Wireless 355 Module with Bluetooth 2.0 + EDR Technology  
413C:8127=Dell Wireless 355 Module with Bluetooth 2.0 + EDR Technology.  
413C:8128=Dell Wireless 5700 Sprint Mobile Broadband (CDMA EV-DO) Minicard  
413C:8128:01=Dell Wireless 5700 Sprint Mobile Broadband (CDMA EV-DO) Minicard Status Port  
413C:8129=Dell Wireless 5700 Telus Mobile Broadband (CDMA EV-DO) Minicard  
413C:8129:01=Dell Wireless 5700 Telus Mobile Broadband (CDMA EV-DO) Minicard Status Port  
413C:8130=Dell Wireless 355C Bluetooth 2.0 + EDR module  
413C:8131=Dell Wireless 355C Bluetooth 2.0 + EDR module.  
413C:8133=Dell Wireless 5720 VZW Mobile Broadband (EVDO Rev-A) Minicard  
413C:8133:01=Dell Wireless 5720 VZW Mobile Broadband (EVDO Rev-A) Minicard Status Port  
413C:8133:02=Dell Wireless 5720 VZW Mobile Broadband (EVDO Rev-A) Minicard Diagnostics Port  
413C:8133:03=Dell Wireless 5720 VZW Mobile Broadband (EVDO Rev-A) Minicard GPS Port  
413C:8134=Dell Wireless 5720 Sprint Mobile Broadband (EVDO Rev-A) Minicard  
413C:8134:01=Dell Wireless 5720 Sprint Mobile Broadband (EVDO Rev-A) Minicard Status Port  
413C:8134:02=Dell Wireless 5720 Sprint Mobile Broadband (EVDO Rev-A) Minicard Diagnostics Port  
413C:8134:03=Dell Wireless 5720 Sprint Mobile Broadband (EVDO Rev-A) Minicard GP

S Port  
413C:8135=Dell Wireless 5720 TELUS Mobile Broadband (EVDO Rev-A) Minicard  
413C:8135:01=Dell Wireless 5720 TELUS Mobile Broadband (EVDO Rev-A) Minicard Status Port  
413C:8135:02=Dell Wireless 5720 TELUS Mobile Broadband (EVDO Rev-A) Minicard Diagnostics Port  
413C:8135:03=Dell Wireless 5720 TELUS Mobile Broadband (EVDO Rev-A) Minicard GPS Port  
413C:8136=Dell Wireless 5520 Cingular Mobile Broadband (3G HSDPA) Minicard  
413C:8136:01=Dell Wireless 5520 Cingular Mobile Broadband (3G HSDPA) Minicard Status Port  
413C:8136:02=Dell Wireless 5520 Cingular Mobile Broadband (3G HSDPA) Minicard Diagnostics Port  
413C:8136:03=Dell Wireless 5520 Cingular Mobile Broadband (3G HSDPA) Minicard EAP-SIM Port  
413C:8136:04=Dell Wireless 5520 Cingular Mobile Broadband (3G HSDPA) Minicard GPS Port  
413C:8137=Dell Wireless 5520 Voda L Mobile Broadband (3G HSDPA) Minicard  
413C:8137:01=Dell Wireless 5520 Voda L Mobile Broadband (3G HSDPA) Minicard Status Port  
413C:8137:02=Dell Wireless 5520 Voda L Mobile Broadband (3G HSDPA) Minicard Diagnostics Port  
413C:8137:03=Dell Wireless 5520 Voda L Mobile Broadband (3G HSDPA) Minicard EAP-SIM Port  
413C:8137:04=Dell Wireless 5520 Voda L Mobile Broadband (3G HSDPA) Minicard GPS Port  
413C:8138=Dell Wireless 5520 Voda I Mobile Broadband (3G HSDPA) Minicard  
413C:8138:01=Dell Wireless 5520 Voda I Mobile Broadband (3G HSDPA) Minicard Status Port  
413C:8138:02=Dell Wireless 5520 Voda I Mobile Broadband (3G HSDPA) Minicard Diagnostics Port  
413C:8138:03=Dell Wireless 5520 Voda I Mobile Broadband (3G HSDPA) Minicard EAP-SIM Port  
413C:8138:04=Dell Wireless 5520 Voda I Mobile Broadband (3G HSDPA) Minicard GPS Port  
413C:8140=Dell Wireless 360 Bluetooth Module  
413C:8142=Mobile 360 in DFU  
413C:8145=Dell Wireless 400 Wireless USB Mini-card  
413C:8146=Dell Wireless 400 Host Wire Adapter  
413C:8147=Dell Wireless 5530 HSPA Mobile Broadband Minicard NetworkAdapter  
413C:8147:01=Dell Wireless 5530 HSPA Mobile Broadband Minicard Modem  
413C:8147:03=Dell Wireless 5530 HSPA Mobile Broadband Minicard Modem 2  
413C:8147:05=Dell Wireless 5530 HSPA Mobile Broadband Minicard  
413C:8152=Dell Wireless 410 Bluetooth&UWB Mini-card  
413C:8153=USB Human Interface Device  
413C:8154=USB Human Interface Device  
413C:8156=Dell Wireless 370 Bluetooth Mini-card  
413C:8157=Integrated Keyboard  
413C:8158=Integrated Touchpad / Trackstick  
413C:8160=Dell Wireless 365 Bluetooth Module  
413C:8161=USB Human Interface Device  
413C:8162=USB Human Interface Device  
413C:8164=Dell 19 in 1 Media Card Reader with Dell Bluetooth 2.1  
413C:8165=USB Human Interface Device  
413C:8166=USB Human Interface Device  
413C:8167=Dell Wireless 365 Secure Bluetooth Module  
413C:8168=Dell Wireless 370 Secure Bluetooth Mini-card  
413C:8169=Dell Wireless 410 Secure Bluetooth&UWB Mini-card  
413C:8170=Dell 19 in 1 Media Card Reader with Secure Bluetooth Module  
413C:8171=Gobi Wireless Modem (QDL mode)

413C:8172=Gobi Wireless Modem  
413C:8174=Dell Wireless 367 Bluetooth Module  
413C:8175=USB Human Interface Device  
413C:8176=USB Human Interface Device  
413C:8177=Dell Wireless 367 Secure Bluetooth Module  
413C:8183=F3607gw Mobile Broadband Module  
413C:8184=F3607gw v2 Mobile Broadband Module  
413C:8185=Gobi 2000 Wireless Modem (QDL mode)  
413C:8186=Gobi 2000 Wireless Modem  
413C:8187=Dell Wireless 375 Bluetooth Module  
413C:8188=Dell Wireless 375 Secure AMP-Enabled Bluetooth Module  
413C:8501=Dell Bluetooth USB adapter  
413C:8501:9999=Dell Elwood Bluetooth Module Firmware Upgrade  
413C:9500=USB CP210x UART Bridge Controller [DW700]  
413C:A001=Hub  
413C:A005=Internal 2.0 Hub  
413C:A700=Hub (in 1905FP LCD Monitor)  
4146=USB Best Technology  
4146:9281=Iomega Micro Mini 128MB Flash Drive  
4146:BA01=Intuix Flash Drive  
4146:BA63=USB Flash Drive  
4242=USB Design By Example  
4242:4201=Buttons and Lights HID device  
4242:4220=Echo 1 Camera  
4317=Broadcom  
4317:0700=U.S. RoboticsUSR5426 802.11g Adapter  
4317:0701=U.S. RoboticsUSR5425 Wireless MAXg Adapter  
4317:0711=Belkin F5D7051 v3000 802.11g  
4317:0720=Dynex DX-BUSB  
4348=Unknown  
4348:5523=USB-SERIAL CH341  
4348:5523:0250=USB-SERIAL CH340  
4348:5537=13.56Mhz RFID Card Reader and Writer  
4348:5584=CH34x printer adapter cable  
4371:5512=MP3 Player  
4483:0008=Quantum 3.2 WIA Device  
4505:0010=Smartphone  
4572=Shuttle  
4572:4572=Shuttle PN31 Remote  
4586=Panram  
4586:1026=Crystal Bar Flash Drive  
4670=EMS Production  
4670:9394=Game Cube USB Memory Adaptor 64M  
4752=Miditech  
4752:0011=Midistart-2  
4757=GW Instek  
4757:2009=PEL-2000 Series Electronic Load (CDC)  
4757:2010=PEL-2000 Series Electronic Load (CDC)  
4766=Aceeca  
4766:0001=MEZ1000 RDA  
4851:1103=CSR Bluetooth Device  
4855=Memorex  
4855:0090=FEIXUN Wireless LAN 802.11n USB 2.0 Network Adaptor  
4855:0091=FEIXUN Wireless LAN 802.11n USB 2.0 Network Adaptor  
4855:7288=Ultra Traveldrive 160G 2.5" HDD  
4856:0091=Netween Wireless LAN 802.11n USB 2.0 Network Adaptor  
4971=SimpleTech  
4971:CB01=SP-U25/120G  
4971:CE17=1TB SimpleDrive II USB External Hard Drive  
5032=Grandtec

5032:0BB8=Grandtec USB1.1 DVB-T (cold)  
5032:0BB9=Grandtec USB1.1 DVB-T (warm)  
5032:0FA0=Grandtec USB1.1 DVB-T (cold)  
5032:0FA1=Grandtec USB1.1 DVB-T (warm)  
5041=Linksys (?)  
5041:2234=Linksys Wireless-G USB Network Adapter  
5041:2235=Linksys Wireless-G Portable USB Adapter  
50C2=Averatec (?)  
50C2:4013=WLAN Adapter  
5173=Sweex  
5173:1809=ZD1211  
5219=I-Tetra  
5219:1001=Cetus CDC Device  
5300:5301=PCI GW-US54Pro  
5300:5302=PCI GW-US54GZL  
5345=Owon  
5345:1234=PDS6062T Oscilloscope  
544D=Transmeta  
5543=UC-Logic Technology  
5543:0001=Tablet WP3525 HID (Win2000/XP)  
5543:0002=SuperPen WP3325U Tablet  
5543:0003=Tablet WP4030 HID (Win2000/XP)  
5543:0004=Genius MousePen 5x4 Tablet  
5543:0005=Tablet WP8060 HID (Win2000/XP)  
5543:0006=Tablet WP2015 HID (Win2000/XP)  
5543:0007=Tablet WP6850 HID (Win2000/XP)  
5543:0008=Tablet WP1209 HID (Win2000/XP)  
5543:0009=Tablet WP8563 HID (Win2000/XP)  
5543:000A=Tablet WP1073 HID (Win2000/XP)  
5543:0041=Genius PenSketch 6x8 Tablet  
5543:0042=Genius PenSketch 12x9 Tablet  
5543:0064=Aiptek HyperPen 10000U  
5543:0101:01=Tablet/Mouse WP3525 HID (Win2000/XP)  
5543:0102:01=Tablet/Mouse WP3325 HID (Win2000/XP)  
5543:0103:01=Tablet/Mouse WP4030 HID (Win2000/XP)  
5543:0104:01=Tablet/Mouse WP5540 HID (Win2000/XP)  
5543:0105:01=Tablet/Mouse WP8060 HID (Win2000/XP)  
5543:0106:01=Tablet/Mouse WP2015 HID (Win2000/XP)  
5543:0107:01=Tablet/Mouse WP6850 HID (Win2000/XP)  
5543:0108:01=Tablet/Mouse WP1209 HID (Win2000/XP)  
5543:0109:01=Tablet/Mouse WP8563 HID (Win2000/XP)  
5543:0201:01=Tablet/Keyboard WP3525 HID (Win2000/XP)  
5543:0202:01=Tablet/Keyboard WP3325 HID (Win2000/XP)  
5543:0203:01=Tablet/Keyboard WP4030 HID (Win2000/XP)  
5543:0204:01=Tablet/Keyboard WP5540 HID (Win2000/XP)  
5543:0205:01=Tablet/Keyboard WP8060 HID (Win2000/XP)  
5543:0206:01=Tablet/Keyboard WP2015 HID (Win2000/XP)  
5543:0207:01=Tablet/Keyboard WP6850 HID (Win2000/XP)  
5543:0208:01=Tablet/Keyboard WP1209 HID (Win2000/XP)  
5543:0209:01=Tablet/Keyboard WP8563 HID (Win2000/XP)  
5543:0301:01=Tablet/Mouse WP3525 HID (Win2000/XP)  
5543:0302:01=Tablet/Mouse WP3325 HID (Win2000/XP)  
5543:0303:01=Tablet/Mouse WP4030 HID (Win2000/XP)  
5543:0304:01=Tablet/Mouse WP5540 HID (Win2000/XP)  
5543:0305:01=Tablet/Mouse WP8060 HID (Win2000/XP)  
5543:0306:01=Tablet/Mouse WP2015 HID (Win2000/XP)  
5543:0307:01=Tablet/Mouse WP6850 HID (Win2000/XP)  
5543:0308:01=Tablet/Mouse WP1209 HID (Win2000/XP)  
5543:0309:01=Tablet/Mouse WP8563 HID (Win2000/XP)  
5543:0401:01=Tablet/Keyboard WP3525 HID (Win2000/XP)

5543:0402:01=Tablet/Keyboard WP3325 HID (Win2000/XP)  
5543:0403:01=Tablet/Keyboard WP4030 HID (Win2000/XP)  
5543:0404:01=Tablet/Keyboard WP5540 HID (Win2000/XP)  
5543:0405:01=Tablet/Keyboard WP8060 HID (Win2000/XP)  
5543:0406:01=Tablet/Keyboard WP2015 HID (Win2000/XP)  
5543:0407:01=Tablet/Keyboard WP6850 HID (Win2000/XP)  
5543:0408:01=Tablet/Keyboard WP1209 HID (Win2000/XP)  
5543:0409:01=Tablet/Keyboard WP8563 HID (Win2000/XP)  
5555=Epiphany Systems  
5555:0101=KeyFive USB SmartCard Reader  
5555:1110=VGA2USB  
5555:1120=KVM2USB  
5555:2222=DVI2USB  
5555:3333=VGA2USB Pro  
5555:3337=KVM2USB Pro  
5555:3340=VGA2USB LR  
5555:3344=KVM2USB LR  
5555:3411=DVI2USB Solo  
5555:3422=DVI2USB Duo  
55AA=OnSpec Electronic  
55AA:0015=OnSpec USB Hard Drive  
55AA:0102=USB SuperDisk  
55AA:0103=OnSpec USB IDE Hard Drive  
55AA:0201=DDI to Reader-19  
55AA:1234=OnSpec USB CD-R/RW Drive  
55AA:A103=Sandisk SDDR-55 SmartMedia Card Reader  
55AA:B000=USB to CompactFlash Card Reader  
55AA:B004=OnSpec USB MMC/SD Reader/Writer  
55AA:B00B=USB to Memory Stick Card Reader  
55AA:B00C=USB to SmartMedia Card Reader  
55AA:B012=Mitsumi FA402M 8-in-2 Card Reader  
55AA:B200=OnSpec USB Compact Flash Reader (Authenticated)  
55AA:B204=OnSpec USB MMC/ SD Reader (Authenticated)  
55AA:B207=OnSpec USB Memory Stick Reader (Authenticated)  
5654:5254=GOTVIEW USB2.0 HYBRID MasterStick  
5654:5354=GOTVIEW USB2.0 HYBRID MasterStick  
5656=Uni-Trend Group  
5656:0832=UT2000/UT3000 Digital Storage Oscilloscope  
595A=IRTOUCHSYSTEMS  
595A:0001=Touchscreen  
5986=Acer  
5986:0100=Acer OrbiCam  
5986:0101=USB2.0 Camera  
5986:0102=Acer Crystal Eye webcam  
5986:0141=Lenovo EasyCamera  
5986:0145=Lenovo EasyCamera  
5986:0148=Lenovo EasyCamera  
5986:01A3=Realtek USB2.0 PC Camera  
5986:01A6=Lenovo Integrated Webcam  
5986:01A7=Lenovo Integrated Webcam  
5986:01A9=Lenovo Integrated Webcam  
5986:01AD=Realtek USB2.0 PC Camera  
5986:0200=Acer OrbiCam  
5986:0203=BisonCam NB Pro 1300  
5986:0241=Lenovo EasyCamera  
5986:02D0=Lenovo Integrated Webcam [R5U877]  
5986:03B0=HP Webcam [2 MP Fixed]  
5986:03B1=HP Webcam [2 MP Macro]  
5986:03D0=Lenovo Integrated Webcam [R5U877]  
5994:2005=GlobalSat Bluetooth Device



5A57=Zinwell  
5A57:0260=802.11g USB Adapter  
5A57:0280=802.11a/b/g/n USB Wireless LAN Card  
5A57:0282=802.11b/g/n USB Wireless LAN Card  
5A57:0283=802.11b/g/n USB Wireless LAN Card  
5A57:0284=802.11a/b/g/n USB Wireless LAN Card  
5A57:0290=802.11b/g/n USB Wireless LAN Card  
5A57:0291=802.11b/g/n USB Wireless LAN Card  
5A57:5257=Metronic 495257 wifi 802.11ng  
5E04:CE00=SAGEM Wireless Assistant  
6000=Beholder International  
6000:0001=TV Walker QQ  
6000:DEC0=Behold TV Wander  
6000:DEC1=Behold TV Voyage  
601A=Ingenic Semiconductor  
601A:4740=XBurst Jz4740 boot mode  
6189=Sitecom  
6189:182D=USB 2.0 Ethernet  
6189:2068=USB to serial cable (v2)  
6189:9071=Wi-Fi Wireless LAN USB Adapter  
6253=TwinHan Technology  
6253:0100=Ir reciver f. remote control  
636C=CoreLogic  
6400=Springer Design  
6472=Unknown (Sony?)  
6472:01C8=PlayStation Portable [Mass Storage]  
6547=Arkmicro Technologies  
6547:0232=USB Data Cable  
6615=IRTOUCHSYSTEMS  
6615:0001=Touchscreen  
6666=Prototype product Vendor ID  
6666:0667=Smart Joy PSX, PS-PC Smart JoyPad  
6666:2667=JCOP BlueZ Smartcard reader  
6666:8802=SmartJoy Dual Plus PS2 converter  
6666:8804=WiseGroup SuperJoy Box 5  
6677=WiseGroup  
6677:8802=SmartJoy Dual Plus PS2 converter  
6677:8811=Deluxe Dance Mat  
6891=3Com  
6891:A727=3CRUSB10075  
695C=Operal  
695C:3829=Operal DVB-S (warm state)  
6993=Freshtel  
6993:B001=FT-102 VoIP USB Phone  
6A75=Shanghai Jujo Electronics  
7104=CME (Central Music  
7104:2202=UF5/UF6/UF7/UF8 MIDI Master Keyboard  
7167:3840=RT73 USB Wireless LAN Card  
726C=StackFoundry LLC  
726C:2149=EntropyKing Random Number Generator  
734C=TBS Technologies China  
734C:5920=Q-Box II DVB-S2 HD  
734C:5928=Q-Box II DVB-S2 HD  
7392=Edimax Technology  
7392:4085=Conceptronic Nano Wireless 150Mbps USB Adapter  
7392:7318=Edimax 802.11g Wireless USB Adapter  
7392:7611=Edimax 802.11n Wireless USB Adapter  
7392:7612=Edimax 802.11n Wireless USB Adapter  
7392:7612:0100=Realtek RTL8187 Wireless 802.11b/g 54Mbps USB 2.0 Network Adapter  
7392:7618=Edimax 802.11g Wireless USB Adapter

7392:7622=Edimax 802.11n Wireless USB Adapter  
7392:7711=Edimax nLite Wireless USB Adapter  
7392:7717=Edimax 802.11n Wireless USB Adapter  
7392:7718=Edimax 802.11n Wireless USB Adapter  
7392:7722=300Mbps Wireless 802.11b/g/n USB Adapter  
7392:7811=EW-7811Un 802.11n Wireless Adapter [Realtek RTL8188CUS]  
7392:7822=Edimax 300Mbps wireless 802.11b/g/n USB adapter  
8020=Trinity  
8086=Intel  
8086:0001=AnyPoint (TM) Home Network 1.6 Mbps Wireless Adapter  
8086:0044=CPU DRAM Controller  
8086:0046=HD Graphics  
8086:0100=Personal Audio Player 3000  
8086:0101=Personal Audio Player 3000  
8086:0110=Intel(r) PC Camera CS110  
8086:0110:0100=Intel(r) PC Camera CS110  
8086:0120=PC Camera CS120  
8086:0180=WiMAX Connection 2400m  
8086:0181=WiMAX Connection 2400m  
8086:0182=WiMAX Connection 2400m  
8086:0183=Intel(R) Centrino(R) WiMAX 6250 Function Driver  
8086:0186=Intel(R) Centrino(R) WiMAX 6250 Function Driver  
8086:0187=Intel(R) Centrino(R) WiMAX 6250 Function Driver  
8086:0188=Intel(R) Centrino(R) WiMAX 6250 Function Driver  
8086:0200=AnyPoint(TM) Wireless II Network 11Mbps Adapter  
8086:0431=Intel Pro Video PC Camera  
8086:0510=Digital Movie Creator  
8086:0630=Intel(r) PC Camera CS630  
8086:0630:01=Intel(r) PC Camera CS630 Image Storage  
8086:0630:02=Intel(r) CS780 Still Image Driver  
8086:0780=CS780 Microphone Input  
8086:07D3=BLOB boot loader firmware  
8086:0DAD=Cherry USB MiniatureCard Keyboard  
8086:0DAD:01=USB Miniature Card Slot  
8086:1010=AnyPoint(TM) Home Network 10 Mbps Phoneline Adapter  
8086:110A=Bluetooth USB Controller from TOSHIBA (Ericsson P4A)  
8086:110B=Bluetooth USB Controller from TOSHIBA (Intel/CSR)  
8086:1110=Intel(R) PRO/Wireless LAN Module  
8086:1111=PRO/Wireless 2011B 802.11b Adapter  
8086:1134=Hollister Mobile Monitor  
8086:1139=In-Target Probe (ITP)  
8086:1234=Intel USB Prototype Reader/Writer  
8086:1403=WiMAX Connection 2400m  
8086:1405=WiMAX Connection 2400m  
8086:1406=WiMAX Connection 2400m  
8086:2448=82801 PCI Bridge  
8086:3100=Intel?PRO/DSL 3220 Modem - WAN  
8086:3101=Intel?PRO/DSL 3220 USB Modem Firmware Loader  
8086:3240=Intel?AnyPoint?3240 Modem - WAN  
8086:3241=Intel?AnyPoint?3240 USB Modem Firmware Loader  
8086:8602=Intel USB MiniatureCard Keyboard  
8086:8602:01=USB Miniature Card Slot  
8086:9303=Intel 8x930Hx USB Hub  
8086:9500=CE 9500 DVB-T  
8086:9890=Intel USB 82930 Test Board  
8086:A6CD=Intel XScale Reference Design  
8086:BEEF=SCM USB Miniature Card Reader/Writer  
8086:C013=Wireless HID Station  
8086:DF3B=Intel(R) Wireless UWB Link 1480M Device Firmware Utility  
8086:F001=XScale PXA27x Bulverde flash

8086:F1A5=Z-U130 [Value Solid State Drive]  
8087=Intel  
8087:0001=Intel(R) Wireless UWB Link 1480M Device Firmware Utility  
8087:0002=Intel(R) Wireless UWB Link 1480M Control Driver  
8087:0003=Intel(R) Wireless UWB Link 1480M Device Firmware Utility  
8087:0020=Integrated Rate Matching Hub  
8087:0024=Integrated Rate Matching Hub  
8087:07D6=Intel(R) Centrino(R) WiMAX 6150 Function Driver  
8087:07D7=Intel(R) Centrino(R) WiMAX 6150 Function Driver  
8087:07D9=Intel(R) Centrino(R) WiMAX 6150 Function Driver  
80EE=VirtualBox  
80EE:0021=USB Tablet  
80EE:CAFE=VirtualBox USB  
8282=Keio  
8282:3201=Retro Adapter  
8282:3301=Retro Adapter Mouse  
8341=EGO Systems  
8341:2000=Flashdisk  
8516:2070=ALLWIN Wireless LAN Card |AWM51G\_US  
8516:2770=ALLWIN Wireless LAN Card -AWM52N-US  
8516:2870=ALLWIN Wireless LAN Card |2870  
8516:3070=ALLWIN Wireless LAN Card |AWU51N-W  
8516:3071=ALLWIN Wireless LAN Card |3071  
8516:3072=ALLWIN Wireless LAN Card |3072  
8516:3572=ALLWIN Wireless LAN Card |3572  
8888:6666=USB Touch Controller  
9016=Sitecom  
9016:182D=WL-022  
9022=TeVii Technology  
9022:D620=TeVii S620 BDA DVB-S  
9022:D630=TeVii S630 BDA DVB-S  
9022:D650=TeVii S650 BDA DVB-S2  
9022:D660=TeVii S660 BDA DVB-S2  
9148=GeoLab  
9148:0004=R3 Compatible Device  
9696=Digital Arts  
9710=Moschip Semiconductor Technology  
9710:7703=MCS7703 Serial Port Adapter  
9710:7705=Printer cable  
9710:7715=Printer cable  
9710:7717=MCS7717 3-Port Hub with Serial and Parallel Adapter  
9710:7720=MCS7720 Dual serial port adapter  
9710:7730=FullSpeed USB-Ethernet Adapter  
9710:7780=USB-Infrared Adapter  
9710:7830=HighSpeed USB-Ethernet Adapter  
9710:7832=MCS7832 10/100 Mbps Ethernet adapter  
9710:7840=MCS7820/MCS7840 2/4 port serial adapter  
99FA=Grandtec  
99FA:8988=V.cap Camera Device  
9AC4=J. Westhues  
9AC4:4B8F=ProxMark-3 RFID Instrument  
A128=AnMo Electronics  
A128:0610=Dino-Lite Digital Microscope (SN9C201 + HV7131R)  
A128:0611=Dino-Lite Digital Microscope (SN9C201 + HV7131R)  
A128:0612=Dino-Lite Digital Microscope (SN9C120 + HV7131R)  
A128:0613=Dino-Lite Digital Microscope (SN9C201 + HV7131R)  
A128:0614=Dino-Lite Digital Microscope (SN9C201 + MI1310/MT9M111)  
A128:0615=Dino-Lite Digital Microscope (SN9C201 + MI1310/MT9M111)  
A128:0616=Dino-Lite Digital Microscope (SN9C120 + HV7131R)  
A128:0617=Dino-Lite Digital Microscope (SN9C201 + MI1310/MT9M111)

A128:0618=Dino-Lite Digital Microscope (SN9C201 + HV7131R)  
A168=AnMo Electronics  
A168:0610=Dino-Lite Digital Microscope  
A168:0611=Dino-Lite Digital Microscope  
A168:0613=Dino-Lite Digital Microscope  
A168:0614=Dino-Lite Pro Digital Microscope  
A168:0615=Dino-Lite Pro Digital Microscope  
A168:0617=Dino-Lite Pro Digital Microscope  
A168:0618=Dino-Lite Digital Microscope  
A600=Asix  
A600:E110=OK1ZIA Davac 4.x  
A727=3Com  
A727:6893=AR5523  
A727:6895=AR5523  
A727:6897=AR5523  
ABCD=Unknown  
ABCD:1234=PLC USB Device  
ABCD:CDEE=Petcam  
C251=Keil Software  
C251:2710=Keil ULINK  
C251:2711=Keil USB LPC900 EPM  
CACE=CACE Technologies  
CACE:0002=AirPCAP Classic 802.11 packet capture adapter  
CACE:0300=AirPcap NX [Atheros AR9001U-(2)NG]  
CD15:6711=Fingerprint Reader  
D209=Ultimarc  
D209:0301=I-PAC Arcade Control Interface  
D209:0501=Ultra-Stik Ultimarc Ultra-Stik Player 1  
E4E4=Xorcom  
E4E4:1130=Astribank series  
E4E4:1131=Astribank series  
E4E4:1132=Astribank series  
E4E4:1140=Astribank series  
E4E4:1141=Astribank series  
E4E4:1142=Astribank series  
E4E4:1150=Astribank series  
E4E4:1151=Astribank series  
E4E4:1152=Astribank series  
E4E4:1160=Astribank 2 series  
E4E4:1161=Astribank 2 series  
E4E4:1162=Astribank 2 series  
EB03=MakingThings  
EB03:0920=Make Controller Kit  
EB1A=Empia Technology  
EB1A:17DE=KWorld V-Stream XPERT DTV - DVB-T USB cold  
EB1A:17DF=KWorld V-Stream XPERT DTV - DVB-T USB warm  
EB1A:2571=M035 Compact Web Cam  
EB1A:2710=SilverCrest WebCam  
EB1A:2711=ET USB 2711 Camera  
EB1A:2711:01=USB EMP Audio Device  
EB1A:2750=ECS Elitegroup G220 integrated webcam  
EB1A:2751=ET USB 2751 Camera  
EB1A:2761=EeePC 701 integrated Webcam  
EB1A:2766:03=USB2.0 1.3M UVC WebCam  
EB1A:2776=Combined audio and video input device  
EB1A:2800=MSI MS8609 Video  
EB1A:2801=GrabBeeX+ Video Encoder  
EB1A:2801:01=Cinergy 250 USB Audio  
EB1A:2820=MSI MS8609 Video  
EB1A:2821=USB 2821 Video

EB1A:2821:01=PCTV EMP Audio Device  
EB1A:2840=USB 2840 Video  
EB1A:2841=USB 2841 Video  
EB1A:2841:01=USB EMP Audio Device  
EB1A:2860=USB 2860 Video  
EB1A:2861=USB 2861 Video  
EB1A:2863=Video Grabber  
EB1A:2870=Pinnacle PCTV 70e  
EB1A:2871=Pinnacle PCTV 70e  
EB1A:2875=Pinnacle PCTV 80e  
EB1A:2880=USB 2880 Video  
EB1A:2881=Pinnacle PCTV 320e  
EB1A:2881:01=PCTV Hybrid Pro\* Stick Audio  
EB1A:2885=Pinnacle PCTV 380e  
EB1A:2901:03=USB2.0 1.3M UVC WebCam  
EB1A:5033=USB2.0 1.3M UVC WebCam  
EB1A:50A3=Gadmei UTV380 TV Box  
EB1A:50A6=Gadmei UTV330 TV Box  
EB1A:A310=USB ATSC Hybrid Device  
EB1A:A310:01=USB EMP Audio Device  
EB1A:A313=USB ATSC Hybrid Device  
EB1A:A315=USB ATSC Hybrid Device  
EB1A:A315:01=USB EMP Audio Device  
EB1A:A316=USB ATSC Hybrid Device  
EB1A:E300=USB PVR-TV Device  
EB1A:E300:01=USB EMP Audio Device  
EB1A:E301=USB PVR-TV Device  
EB1A:E301:01=USB EMP Audio Device  
EB1A:E303=USB PVR-TV Device  
EB1A:E305=USB PVR-TV Device  
EB1A:E305:01=USB EMP Audio Device  
EB1A:E306=USB PVR-TV Device  
EB1A:E310=USB DVB-T Hybrid Device  
EB1A:E310:01=USB EMP Audio Device  
EB1A:E311=USB DVB-T Hybrid Device  
EB1A:E311:01=USB EMP Audio Device  
EB1A:E313=USB DVB-T Hybrid Device  
EB1A:E320=USB DVB-T Hybrid Device  
EB1A:E320:01=USB EMP Audio Device  
EB1A:E323=USB DVB-T Hybrid Device  
EB1A:E350=USB DVB-T Device - XC  
EB1A:E355=USB DVB-T Device - QT  
EB1A:E356=USB DVB-T Device - MT  
EB1A:E357=USB DVB-T Device - QT  
EB1A:E358=USB DVB-T Device - QT  
EB1A:E359=USB DVB-T Device - QT  
EB2A=KWorld  
EB2A:17DE=KWorld - DVBT-USB2.0 firmware loader  
EB2A:17DF=KWorld - DVBT-USB2.0  
EB2A:17DF:01=Infrared Receiver  
F003=Hewlett Packard  
F003:6002=HP C500 Digital Camera  
F003:6002:0100=HP Digital Camera  
F003:6002:0101=HP PhotoSmart C500 Camera  
F4EC=Atten Electronics / Siglent Technologies  
F4EC:EE38=Digital Storage Oscilloscope  
F717:0022=Broadcom Bluetooth 3.0 USB  
FEDA:0201=D-Link DHN-120 10Mb Home Phonenumber USB Adapter  
FFFF:FFFF=USB Diagnostic Device