



ELITE Series™

PORTABLE GENERATORS

Illustrated Parts List

Questions? Help is just a moment away!

Preguntas? La ayuda es justa un momento lejos!

Call: **Generator Helpline**

Llame: **Línea Directa del Generador**

1-800-743-4115 M-F 8-5 CT

BRIGGSandSTRATTON.COM


030207
(10000W)



BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC
JEFFERSON, WISCONSIN, U.S.A.


Manual No. 200079A Revision E (09/09/2008)

EXPLODED VIEW - MAIN UNIT



Copyright © 2008 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.


EXPLODED VIEW AND PARTS LIST - CONTROL PANEL



Item	Part #	Description	Item	Part #	Description
1	M199022GS	PANEL, Control	20	74190GS	OUTLET, 120V, 20A
2	201864GS	BOX, Control Panel	21	68759GS	OUTLET, 120V, 20A, Duplex
3	*	WASHER, Flat, #10 - M5	22	*	PHTS, 6 - 32 x 3/8"
4	*	LOCKWASHER, M5	23	195406GS	ASSY, PCB, Control, Stepper Motor
5	*	PPHMS, M5 - 0.8 x 12	24	64525GS	STANDOFF, Hex, 3/4"
6	*	WASHER, M6 - 1/4, Int. Shakeproof	25	62265GS	GROMMET
7	90418GS	OUTLET, 12V DC Snap	26	92953GS	TERMINAL, Block
8	191480BGS	BREAKER, Circuit, 40A, 2P	27	*	PPHMS, M4 - 0.7 x 20
9	191480AGS	BREAKER, Circuit, 30A, 2P	28	84028GS	TRANSFORMER, Idle Control
10	82538GS	SWITCH, Rocker	29	*	LOCKWASHER, M3
11	78653GS	SWITCH, Eng, Run-Stop	30	*	PHMS, M3 - 0.5 x 10
12	*	WASHER, Shakeproof, Int. #8	31	87962GS	BREAKER, Circuit, 10A, 12V
13	*	WASHER, Flat, M4	32	77314GS	THERMAL, Relay
14	*	LOCKWASHER, M4	33	188632GS	BOOT, Rubber Wire Outlet
15	*	NUT, M4 - 0.7	34	194273GS	TUBING
16	B4262GS	RECEPTACLE	35	199532GS	STRIP, Dual Row, TPA, 6 Circuit
17	75207GS	BREAKER, Circuit, 20A with hardware	36	199528GS	PLUG, Dual Row, Housing, 6 Circuit
18	43437GS	OUTLET, 120/240V, 30A			
19	68868GS	OUTLET, 120V, 30A			

* - Items without part numbers are common fasteners and are available at your local hardware store.


EXPLODED VIEW AND PARTS LIST - ALTERNATOR



Item	Part #	Description
1	186059GS	ADAPTER, Mounting, Alternator
2	191952GS	ASSY, Rotor (Includes Item 11)
3	191953GS	STATOR
4	193336GS	RBC, (with O-Ring p/n 189197GS)
5	*	WASHER, 1/4-M6 Lock
6	66449KGS	BOLT, M6 - 1.0 x 200
7	66849GS	TAPTITE, M5 - 0.8 x 16
8	66386GS	ASSY, Holder, Brush
9	205858GS	BOARD, Circuit, System Control
10	81917GS	PIN, Roll, 4mm x 10
11	65791GS	BEARING

* - Items without part numbers are common fasteners and are available at your local hardware store.

EXPLODED VIEW AND PARTS LIST - WHEEL KIT



Item	Part #	Description
1	191267JGS	AXLE, 5/8" x 25.59"
2	B4966GS	WHEEL
3	191265GS	E-RING, 5/8
4	*	WASHER, 5/8
5	203977GS	ASSY, Leg, Support w/Vibration Mount

Parts Not Illustrated
 200913GS KIT, Hardware, Wheel

* - Items without part numbers are common fasteners and are available at your local hardware store.