



FEATURES

- + Reversible:
Lantern Becomes a Down Light
- + Rechargeable via USB
- + Back-Up Power via Hand Crank
- + 1W Ultra Bright LED
- + Non-Glare Frosted Globe
- + Reflector for Enhanced Lighting
- + Rubberized for Easy Grip
- + Foldable Steel Handle
- + Easy Push Button
- + Dimensions: 76 X 180mm, 7oz
- + Weather Resistant

SPECIFICATIONS

- + 95 Lumens
- + Modes: High / Low (Power Saver) / Off
- + Fully Charged via USB in 15 Hours
- + Burn Time High: 4 Hours
(with FULLY charged battery)
- + Burn Time Low: 10 Hours
(with FULLY charged battery)
- + Back-Up Power via Hand Crank:
3 Minutes of Crank Time =
6 Minutes of Burn Time (HIGH)
10 Minutes of Burn Time (LOW)
- + Rechargeable Internal Battery:
330 mAh, 3.6V Battery

WARNINGS & CAUTIONS

- This is not a toy. Children should be supervised when using the lantern.
- Before each use, inspect the lantern thoroughly. Regularly check for wear & tear on cable. If broken, replace immediately. Damaged cables may short-circuit the lantern.
- Charge as needed. During trips, always carry a secondary light source.
- While the lantern is weather resistant, it is not water proof. The lantern is only water resistant against mild splashing. Heavy rain should be avoided. Do not submerge the lantern. Extreme heat and cold may alter burn times.
- Optimal burn time efficiency is attained only when the SmartLite's internal battery is fully charged.
- The SmartLite contains a rechargeable internal battery. The full performance of a new battery is achieved after two or three complete charge and discharge cycles. Use only approved cables (as supplied) when charging this unit.
- DO NOT dispose of the SmartLite in fire. Dispose of the SmartLite according to local regulations. Please recycle when possible. Do not dispose as household waste.

OPERATION

RECHARGE INFORMATION:

IMPORTANT: Please follow all instructions for operation. Improper handling and use of the lantern may harm the user and/or property.

- For optimal performance and quoted burn times, the SmartLite should be fully powered prior to each use.

NOTE: Before the initial use of the SmartLite, please charge via USB for 24 hours; failure to do so may weaken the battery.

Battery Life (and Burn Times) may vary depending on:

- Charge Time (Battery Life)
- Temperature
- Mode (High or Low)

OPERATION

After the initial charge (24 hours), recharge the SmartLite via USB (with the cable included) as needed. Remember that burn times will depend on charge times.

When the battery is drained, attain the back-up power option by winding the hand crank. The burn times may vary depending on:

- Crank Speed (quoted times based on 120 rpm)
- Crank Time (quoted times based on 3 Minute Intervals)
- Temperature
- Mode (High or Low)

OPERATION

REVERSE INFORMATION:

The SmartLite has a reversible feature that allows you to quickly turn the lantern into a hanging down light.

To create a down light:

- Holding the lantern where the clear window and black middle band meet, gently twist the unit clockwise until the unit separates.
- Turn the lantern upside-down and screw the clear window into the black base.
- Repeat steps to turn the down light back into a lantern.

CARE & MAINTENANCE

- Protect your lantern from extreme heat, shocks and excessive exposure to direct sunlight.
- The lantern can be wiped clean with a lightly moistened cloth. Apply mild soap to the area if there are stubborn stains or marks.
- Do not expose your lantern to strong chemicals such as gasoline, cleaning solvents, acetone, alcohol, insect repellents, sunscreen and other toiletries, as they may damage the unit.
- Store your lantern in a dry place when you are not using it.

Warranty and Service information can be found on the Highgear website:
www.highgear.com
800-446-7587 / help@4implus.com

Highgear, a Division of Implus Footcare, LLC
2001 T.W. Alexander Drive / Box 13925
Durham, NC 27709-3925

Printed and Produced in PRC

©2011 Implus Footcare, LLC. All Rights Reserved