


4 in 1 Play Yard MODEL NO: 1350

Owner's Manual 01/09/2013_EV





READ ALL INSTRUCTIONS BEFORE ASSEMBLY AND USE OF GATE.
KEEP INSTRUCTIONS FOR FUTURE USE.

www.regalo-baby.com

Regalo International, LLC.

3200 Corporate Center Drive, Suite 100 Burnsville, MN 55306-9803, USA Toll Free: 866-272-5274

Made in China

Assembly and Installation Instructions

Read and follow all instructions carefully to ensure that your gate and extensions are properly installed. Improper installation could result in the gate becoming unstable or dislodged from the doorway. Always make sure extensions is securely attached to the gate before using. The safety of your child is your responsibility. Please keep these instructions for your reference.



Intended for young children aged 6 months through 24 months. Check the gate regularly to see if all the hardware and mountings are tight. To prevent serious injury or death, securely install gate or enclosure and use according to manufacturer's instructions. Never use with a child able to climb over or dislodge the gate or enclosure. Never leave child unattended. Use only with the locking/latching mechanism securely engaged. To prevent falls, NEVER used at the top of stairs.

IMPORTANT:

The four Wall Mounting Brackets must be used in securing the gate to the wall. These brackets prevent the gate from dislodging from its opening and becoming unstable. The maximum width opening for the gate is 194.5 inches.


Contact Regalo for questions and replacement parts. If in doubt about the use of your gate, call our customer care line 866-272-5274

Regalo International, LLC 3200 Corporate Center Drive, Suite 100 Burnsville, MN 55306-9803, USA

Made in China



Check to make sure you have all of the parts shown:



A. Folded Gate Frame and attached Wall Mounting Assembly (8 panels)

B. 8 Wall Mounting Screws


ADITIONAL EXTENSIONS SOLD SEPARATELY!

Installation Option A:

To install the Play Yard as a barrier between two walls.


Step 1.

Begin by unfolding the gate frame. To do this, simply loosen the Locking Knobs at each pivoting joint by turning the knob counter clockwise as shown in Diagram A. Loosen the knobs enough to allow the gate to swing open freely without fully removing the knobs.




Step 2.

Bring the Wall Mounting Bracket to the wall you intend to attach it to as shown in Diagram B.



Step 3.

Use a Phillips/crosshead screwdriver to fix the Wall Mounting Bracket to the Wall as shown in Diagram C



Step 4.

Repeat steps 2 & 3 on the other end of the gate. Arrange the panels into your desired configuration, then tighten each of the Locking Knobs.

Installation Option B: To set it up as a Play Yard enclosure.

Step 1.

Begin by unfolding the gate frame. To do this, simply loosen the Locking Knobs at each pivoting joint by turning the knob counter clockwise as shown in Diagram A. Loosen the knobs enough to allow the gate to swing open freely without fully removing the knobs.

Step 2.

Release the vertical Metal Pivot Bars at each end of the Play Yard by removing the following parts form the assembly:





Diagram D

Step 3.

Position the Play Yard into your desired configuration (Example: Octagon, Square, etc.) Then, join the free ends of the the Play Yard together at the plastic joints as shown in Diagram E1 and E2.






Diagram E1

Diagram E2

Step 4.

Insert one of the previously removed Metal Pivot Bars through the opening created by joining the upper plastic joints. Guide the Metal Pivot Bar downward into the circular housing on the lower plastic joint. See Diagrams F1, F2 and F3.




Diagram F1




Diagram F2





Diagram F3

Step 5.

Reassemble the upper locking joint by adding one of the previously removed Toothed Disks and Locking Knobs. See Diagram G1, G2 and G3.






Diagram G3



Step 5.

Finally, tighten each of the Locking Knobs by turning them clockwise, fixing the Play Yard into the configuration you have decided upon. To position the Play Yard into a new configuration or shape, simply loosen each of the Locking Knobs, adjust and re-tighten.




Diagram H

When adding or removing additional panel units to the configuration,

NOTE: panels must be added or subtracted in sets of 2 for the pet yard to function properly. ADDITIONAL PANELS SOLD SEPERATLY.

To fold your Play Yard

- **Step 1**: To fold your Play Yard begin by loosening all of the locking knobs so the Play Yard can move freely and becomes flexible at the joints.
- **Step 2**: Remove one of the locking knobs from the Play Yard and remove one vertical tube.
- **Step 3**: You will now be able to pull the two plastic joints and the top and bottom of the Play Yard apart.
- **Step 4**: Fold and put away.

Care and Maintenance

Periodically check the Play Yard for signs of damage, wear, or missing components.

Do not use if any part is missing, worn or damaged.

Check the Play Yard regularly to ensure all the hardware and mountings are tightened.

Do not use abrasive cleaners or bleach.


Clean by sponging with warm water and a mild detergent.

90 Days Limited Warranty:

If, during the first 90 days after consumer purchase of the item, under reasonable and non-commercial use and conditions of maintenance, it fails while owned by the original purchaser because of the quality of materials or workmanship of finish and assembly, Regalo International LLC will replace or repair it at Regalo's option. PROOF OF PURCHASE REQUIRED.

Replacement Parts Available

In the event of any damage or breakage, the following replacement parts are available for order by contacting Regalo Customer Service.





Regalo International, LLC.

3200 Corporate Center Drive, Suite 100 Burnsville, MN 55306-9803, USA Toll Free: 866-272-5274 Made in China