

FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

1. "Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product."

2. **NOTE:** This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."

www.sportline.com

Made in China.
Sportline® is a trademark of SPORTLINE,
a division of EB Sport Group,
Yonkers, NY 10701
Distributed in the United Kingdom by
EB Brands (UK), Worcester WR4 9FA.
All Rights Reserved. ©2012

WV2829IS01WAV

SPORTLINE®

2 3 2 S P O R T T I M E R

#2829

©2012 EB Sport Group

IMPORTANT: READ THROUGH ALL INSTRUCTIONS BEFORE BEGINNING TO USE YOUR SPORT TIMER

OPERATING INSTRUCTIONS:

1. Remove plastic film from LCD display before use.
2. Remove battery insulation tab from the battery compartment to start your stopwatch.

FEATURES:

- Easy to Set Count Down Times from One (1) Second to 100 Minutes
- Loud Alarm Signal at Zero
- One Touch Memory Reset

MAIN FUNCTION BUTTONS


- A**— Minute Setting Button
- B**— Start/Stop Button and Memory Reset Button (recalls the last Countdown time entered into the Timer)
- C**— Second Setting Button

SETTING THE COUNT DOWN TIME

Press the Minute and Second buttons to set the required time.

START COUNT DOWN TIMING

Press the Start/Stop button.

**STOP (PAUSE) COUNT DOWN TIMING**

Press the Start/Stop button.

RECALL THE LAST COUNT DOWN TIME SETTING

Press and hold the Start/Stop button until the time appears.

CLEARING THE SETTING


Press the Minute and Second buttons at the same time for about 2 seconds.

BATTERY REPLACEMENT

1. Twist battery cover open with a coin.
2. Remove spent battery and replace with an LR44, AG13 or equivalent 1.5V battery.
3. Replace battery cover.

CAUTION – Battery Safety Information

- Non-rechargeable batteries are not to be recharged
- Rechargeable batteries must be removed before recharging
- Rechargeable batteries only to be recharged under adult supervision
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries
- Do not mix old and new batteries
- Exhausted batteries to be removed
- Do not dispose of battery in fire; battery may explode or leak
- Do not dispose of product in fire; battery may explode or leak



GUARANTEE CERTIFICATE

For purchases made in the U.S.:

If at any time within two (2) year from the purchase date of this product, it fails to perform properly because of defects in material or manufacturing, return it prepaid to:

EB SPORT GROUP, 585 Oak Ridge Road, Hazleton, PA 18202

Complete this Guarantee Certificate and enclose it (or a copy of it) with the product.

(PLEASE PRINT CLEARLY)

NAME _____	TEL _____	STORE PURCHASED FROM _____
ADDRESS _____	DATE OF PURCHASE _____	
CITY _____	PURCHASE PRICE _____	
STATE _____	ZIP _____	

PROBLEM WITH PRODUCT _____

REPLACEMENT

This product has been carefully designed, manufactured and packaged. If any parts are missing or damaged, please contact us at the address above and we will replace unit at no charge. (Guarantee does not cover crystal or battery.)

For purchases made in the UK: Should you experience problems with this item, please return it to the point of purchase. This will not affect your statutory rights. Alternatively return it to the address shown below for a repair/replacement. **StarCase (UK) Ltd, Berkeley Business Park, Wainwright Road, Worcester WR4 9FA**

SPORTLINE®

EB SPORT GROUP, 585 Oak Ridge Road, Hazleton, PA 18202