

TROUBLE SHOOTING

TROUBLE	CAUSE
Video camera does not work	Check power supply
Video camera does not record	Check recording mode
Video camera does not show picture	Check video cable connection

Available Accessories:

- ADT120250 AC Power supply
- CA030Y 30'RCA Extension Cable
- CA060Y 60'RCA Extension Cable
- CB120Y 120'RCA Extension Cable



✓ Quality ✓ Price ✓ Service ✓ Synergy

(562)799-9999

USER'S INSTRUCTIONS

Video Cameras for your personal SAFETY and workplace SECURITY

Model#DC375



✓ Quality ✓ Price ✓ Service ✓ Synergy

www.cloverusa.com

TO THE USER'S OF CLOVER CAMERAS

CONNECTIONS

IMPORTANT SAFETY PRECAUTIONS

To prevent fire or shock hazard, do not expose this product to rain or moisture. Do not use near a bath tub, wash bowl, sink, or laundry tub; do not use in a wet basement or in or around a swimming pool.

To avoid electrical shock, do not open the case of this product.


Operate this product using only the power supply included.

Do not overload electrical outlets or extension cords as this can result in fire or electric shock.

Refer servicing to qualified personnel only.

INSTALLTION

1. Turn the dome camera counter-clockwise to open.
2. Attach the dome base to the ceiling, wherever you want to install.
3. Locate a ceiling joist and secure the dome base using the supplied screws.
4. Connect the yellow RCA plug into the VIDEO IN jack on your TV/monitor or VCR.
5. Connect the supplied AC power supply (DC 12V 250mA) to the red DC jack and plug it into AC 120V AC outlet.



OPERATION

Push the eyeball type camera and adjust the angle to the objects (push the camera body with two thumbs and move it up and down or left and right).

TROUBLE SHOOTING

If the system dose not function Property, check the following points before contacting the service center.

TROUBLES	CAUSE & REMEDIES
NO power (no picture / sound)	AC adaptor not plugged in Check the DC, audio, video cables between the TV and monitor
Picture flickering	Strong spotlight in the field of view
Normal sound, dim picture picture too bright, too dark	Improper brightness control; Setting on your TV / monitor Lighting source in the field of view
Picture rolls and Jumps Scrambled Picture	Improper V _{hold} control setting on your TV/monitor
Picture smaller than screen or volume weak	House current may be too low

HOW TO OBTAIN FACTORY SERVICE

1. Original purchaser must fill out a warranty card and mail to Clover Electronics USA with model number, serial number and date of purchase.
2. Please pack unit carefully and safely, and send it prepaid and insured parcel post to 10541 Humbolt St, Los Alamitos, CA 90720. Please include a note stating how the unit is defective.
3. If the unit is returned within the warranty period, please include a proof of purchase and check for \$15.00 to cover the cost of return postage and handling. If the unit is our of warranty, please include a check for \$15.00 to cover the cost of return postage and handing. An estimate of the repair cost will be sent for approval.
4. Clover will repair or replace and return to owner all units under this limited warranty.

LIMITED 2YEAR WARRANTY

This warranty gives the original purchaser specific legal rights and you may have other rights which vary from state to state if Clover products do not function because of any defect in material or parts workmanship, Clover will repair free for a period of 2 year on Parts & labor from the date of original purchase. this warranty does not cover incidental or consequential damages unless the state of owner's residence specifically prohibits limitations on incidental or consequential damages