



Digital Timer

15057-1

7/15/09

DO NOT EXCEED THE RATING OF THE TIMER 1000 WATTS FOR GENERAL PURPOSE AND TUNGSTEN LOAD (SUCH AS LIGHTING).

THIS TIMER IS FOR INDOOR USE ONLY. DO NOT USE IN WET LOCATIONS.

THIS TIMER HAS A BUILT-IN RECHARGEABLE BATTERY THAT IS USED TO RETAIN THE CURRENT TIME AND ON/OFF SETTINGS WHEN THE UNIT IS NOT PLUGGED IN AN OUTLET.

IN CASE OF A FAILURE OF THE TIMER. PRESS THE RESET BUTTON TO RESTART THE TIMER.

TO ACTIVATE YOUR TIMER

- 1. Display** - Remove the plastic film from display.
- 2. Installation** - Plug the timer into a grounded outlet and wait for at least 30 minutes to charge the built-in rechargeable battery. Once the battery has charged, unplug and press the "RESET" button.
- 3. Set Current Time** - While holding down the **CLK** (Clock) button, press the **DAY**, **HR** (Hour) and **MIN** (Minute) buttons to set the day, hour and minute. Note the **AM** or **PM** appears after the time.
4. Release the **CLK** (Clock) button.

Your Timer is now ready to be programmed.

PROGRAMMING AN EVENT

1. Press the **PROG** button once. The display will read

	MO TU WE TH FR SA SU
1 ON	AM

or if an event has already been programmed the current event will be displayed. It will show current settings if it has been previously The number 1 indicates that you are now programming Event until the day you choosen to program is displayed.

2. To select the day to be programmed press the **DAY** button repeatedly the display should show the day on which you want the timer to turn **ON**. The day options includes:

- All days of the week (**MO TU WE TH FR SA SU**)
- Any single day of the week (for example **WE**)

- Weekdays only (**MO TU WE TH FR**)
- Weekends only (**SA SU**)

3. Press the **HR** and **MIN** buttons to select the time of day to turn the Timer **ON** press the **HR** button repeatedly to change from **AM** to **PM**.
4. Press the **PROG** button again. The display will read:

	MO TU WE TH FR SA SU
1 OFF	AM

It will show current settings if it has been previously set.

5. Repeat steps 2 and 3 to program other events.
6. To set additional **ON** and **OFF** cycles (maximum of 7 events) press the **PROG** button and follow the procedures 2-5 above for each new **ON/OFF** event. When you are finished press the **CLK** button the display will now show the current time and the Timer will control the device plugged into it according to the programmed events.

REVIEWING EVENTS

Press the **PROG** button repeatedly and will cycle through all the programmed **ON/OFF** events. Press the **CLK** to return to normal operation.

CLEARING PROGRAMMED EVENT

Press the **PROG** button repeatedly to find the **ON/OFF** event you want to clear. While holding the **MODE** button down, press the **PROG** to clear the settings for the event.

ACTIVATING YOUR EVENTS

Automatic - For controlled operation according to programmed events, press the **MODE** button repeatedly until **AUTO** is displayed.

Random - For random operation press the **MODE** button until **RDM** is displayed. The Timer will turn **ON** and **OFF** at +/- 30 Minutes of programmed events randomly.

Manual - For manual operation, press the **MODE** button until **ON** (to turn and remain on) or **OFF** (to turn and remain off) is displayed.

OPERATING THE TIMER

Plug the Timer into an outlet near where you want time your lighting or appliance. Plug the lighting or appliance into the Timer. Check and adjust the Timer setting if needed.

