


TIME/CALENDAR SETTING

- Press **A** three times (from normal time mode) to reach time setting mode. The seconds and day of the week bar will flash to let you know you are time setting mode.
- Press **C** to select the time/calendar segment to be set. The sequence will be: minute > hour > year > month > date > seconds. (Seconds will reset to 00). The day of the week will automatically be set when the year, month and date are set.
- Press **B** to increase the setting value and change 12/24-hour format when setting the hour.
- Press **A** to return to the normal mode.



BATTERY REPLACEMENT

When the LCD becomes dim, replace with a new type CR2032, 3 Volt battery.

To replace battery, open battery compartment door with a coin and remove the door. Replace with a fresh CR2032 battery making sure to observe the correct +/- polarity. Replace the battery compartment door and close securely by twisting into place with a coin. The triangle on the battery door should align with the triangle on the red rim at the top to ensure the battery door is properly closed.

CAUTION – Battery Safety Information

- Non-rechargeable batteries are not to be recharged
- Rechargeable batteries must be removed before recharging
- Rechargeable batteries only to be recharged under adult supervision
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries
- Do not mix old and new batteries
- Exhausted batteries to be removed
- Do not dispose of battery in fire; battery may explode or leak
- Do not dispose of product in fire; battery may explode or leak

GUARANTEE CERTIFICATE

For purchases made in the U.S.

If at any time within one (1) year from the purchase date of this product, it fails to perform properly because of defects in material or manufacturing, return it prepaid to:
EB SPORT GROUP, 585 Oak Ridge Road, Hazleton, PA 18202

Complete this Guarantee Certificate and enclose it (or a copy of it) with the product.
(PLEASE PRINT CLEARLY)

NAME _____ TEL _____

ADDRESS _____

CITY _____

STATE _____ ZIP _____

STORE PURCHASED FROM _____

DATE OF PURCHASE _____ PURCHASE PRICE _____

PROBLEM WITH PRODUCT _____

REPLACEMENT

This product has been carefully designed, manufactured and packaged. If any parts are missing or damaged, please contact us at the address above and we will replace the unit at no charge. (Guarantee does not cover crystal or battery.)

For purchases made in the UK:

Should you experience problems with this item, please return it to the point of purchase. This will not affect your statutory rights. Alternatively return it to the address shown below for a repair/replacement: StarCase (UK) Ltd, Berkeley Business Park, Wainwright Road, Worcester WR4 9FA

www.sportline.com

Sportline® is a trademark of SPORTLINE, a division of E & B Exercise, LLC, Yonkers, NY 10701

Distributed in the UK by

StarCase (UK) Ltd., Worcester, WR4 9FA

All Rights Reserved. ©2008

WV4413IS01SPT

SPORTLINE®

480 Tough Timer Stopwatch

#4413

©2008 EB Sport Group

OPERATING INSTRUCTIONS

- Remove the plastic film from the LCD display on the front of the stopwatch.
- Slowly pull the battery protector tab out from the battery door located on the back to activate.

IMPORTANT: READ THROUGH ALL INSTRUCTIONS BEFORE BEGINNING TO USE YOUR STOPWATCH

FEATURES

- Time/Calendar Display
- Hour (12-24 Hour format), minute, second, year, month, date and day
- Stopwatch: Times to 1/100 second for 40 minutes, 1 second to 40 hours after the first 40 minutes
- Tally Counter: Counts up to 3999
- Electroluminescent Backlight



MAIN FUNCTION BUTTONS

A— Mode Button

Switch between normal time mode, stopwatch mode and tally counter mode and time setting mode.

B— Start/Stop Button

Used to start and stop the stopwatch function
Also for value setting when in time setting mode
Used to display the calendar screen.
Used in combination with the Split/Reset Button to clear the tally counter

C— Split/Reset Button

Used to split times in stopwatch mode
Clear timing records in stopwatch mode
Select time/calendar segment to be set in time setting mode
Used to advance 1 count in tally counting mode.
Used in combination with the Start/Stop Button to clear the tally counter


D—Light

Used to turn on the electroluminescent backlight

DISPLAY SYMBOLS


NORMAL TIME MODE

1. Day of the Week
2. Hour
3. Minute
4. Second



CALENDAR DISPLAY

1. Day of the Week
2. Month
3. Date
4. Year



TALLY COUNTER MODE

1. Press **A** two times (from normal time mode) to get to tally counting mode.
2. The tally counter symbol will appear on the display in the upper right hand side of the display with a '0'.
3. Press either **B** or **C** to count. Each press will advance the counter in values of 1.
4. To clear the count, press **B** and **C** simultaneously.

EL BACKLIGHT

To turn on the backlight simply press the light button (**D**)

Note: The light will remain on for about 5 seconds each time it is pressed. Please note that the more the light is used, the more drain it will put on the battery shortening the lifetime of the battery.

CALENDAR

To see the calendar display (month/date/year), press **B** and hold while in normal time mode.


STOPWATCH MODE BASIC FUNCTION

Press **A** to until you reach Stopwatch Mode.


Press **B** to activate the Stopwatch to count

Press **C** to reset the stopwatch to "0:00:00" before using the stopwatch.


1. Accumulate elapsed time measurement: B-B-B-B-C



2. Split time measurement: B-C-C-B-C



3. Measurement between two competitors: B-C-B-C-C



Press **A** to return to the normal time mode.