

K00152 KEY CARD KIT

Installation Instructions

Parts List

<u>Item</u>	Quantity	Part Number	<u>Description</u>
1.	1	2032623	Wiring Harness
2.	1	2502183	Bushing - Heyco
3.	1	5202063	Sheet Metal Screw
4.	2	5428781	#6 Hex Nut
5.	4	5429061	#8 Hex Nut
6.	2	5544541	#6 Lock Washer
7.	4	5544591	#8 Lock Washer
8.	1	6028781	Switch Cover
9.	1	6028861	Key Card Weldment
10.	1	6269914	Key Card Access Plate Studweld
11.	1	6270314	Access Switch
12.	1	8011233	Instruction Sheet
13.	1	8132303	Label - Insert Room Key Card
14.	1	8136153	Label - Wiring Diagram

Instructions

- 1. Disconnect power.
- 2. Cut out and tape hole pattern to outside of dispenser door.
- 3. Use a sharp punch to mark all six holes.
- 4. Remove pattern from dispenser door.
- 5. Drill six 1/4" diameter holes through the door liner using punch marks.
- 6. Cut out material between the two middle holes, as shown on pattern.
- 7. Insert the studs on the key card access plate into the four mounting holes from the front side.
- 8. Assemble the access switch assembly to the studs with the lock washers and #8-32 hex nuts (see diagram 1).
- 9. Disconnect the switch wire harness and plug the male end of the key card assembly wire harness in its place.
- 10. Plug the switch wire harness into the female end of the key card assembly wire harness.
- 11. Attach the wiring diagram sticker to wiring diagram on the control box cover (see diagram 2).
- 12. Attach switch cover to the key card assembly with sheet metal screw (see diagram 1).
- 13. Connect power and test. Insert room key card into slot and push ice button switch.