

## WAGAN Corp. Limited Warranty Registration Form

All WAGAN Corporation products are warranted to the original purchaser of this product. Warranty Duration: This product is warranted to the original purchaser for a period of one (1) Year from the original purchase date, to be free of defects in material and workmanship. WAGAN Corporation disclaims any liability for consequential damages. In no event will WAGAN Corporation be responsible for any amount of damages beyond the amount paid for the product at retail. In the even of a defective item, please ship the item, prepaid, with a complete explanation of the problem, your name, address and daytime phone number. WAGAN Corporation will, at its option, replaces or repair the defective part. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA and does not extend to any units which have been used in violation of written instructions furnished.

Warranty Disclaimers: This warranty is in-lieu of all warranties expressed or implied and no representative or person is authorized to assume any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one (1) Year warranty period, a product with a defect will be replaced with a comparable model when the product is returned to WAGAN Corporation with an original store receipt. The replacement product will be in warranty for the balance of the one (1) Year warranty period.

- Please activate my limited warranty for WAGAN Corp. Quick Flow 3 in 1 Air Compressor
- Enclosed copy of original sales receipt.

Name			
Mail Address			
City			
State, Zip Code			
Item Purchased	Quick Flow 3 in 1 Air Compressor		
Stores Name			
Date of Purchase			
Signature		Date	

All WAGAN Corporation Products must be registered within (30) days of purchased to activate this warranty. Mail the complete registration form, along with a copy of the original receipt to:

Attn: Customer Service  
 WAGAN Corporation  
 3589 Yale Way  
 Fremont, CA 94538

© 2004 WAGAN Corp.



Item no. 2014

# QUICK FLOW 3 IN 1 AIR COMPRESSOR™



**User's Manual**

# Quick Flow 3 in 1 Air Compressor by Wagan Tech

USER'S MANUAL — Please read before using this equipment.

Thank you for purchasing the Quick Flow 3 in 1 Air Compressor by Wagan Tech. With normal care and proper treatment it will provide years of reliable service. Please read all operating instructions carefully before use.

## AIR COMPRESSOR OPERATION:

- Pull out hose from compartment. Place quick connect chuck over valve stem of tire with thumb lever in the vertical position. Push down firmly and lock into place by pressing thumb lever to horizontal position. Turn compressor's switch on and monitor pressure using the built-in pressure gauge. **DO NOT OVERINFLATE PRODUCTS BEYOND THE MANUFACTURER'S RECOMMENDATIONS.**
- When desired pressure is reached, turn off compressor and disconnect hose.
- **NOTE:** If tire is completely deflated, it is possible that the seal between the tire and the rim could be broken allowing air to leak out when trying to inflate. This usually happens only on completely flat tires. In the event this situation occurs, you will have to jack up your car prior to inflating the tire. For inflating other articles, select the appropriate adaptor and insert into the hose nozzle as shown. Inflate as illustrated.
- **NOTE:** For athletic balls, moisten needle before inserting it into the ball valve. For other pneumatic articles, the nozzle should be inserted into valve and held tightly to insure a good seal.
- **CAUTION:** NEVER LEAVE COMPRESSOR UNATTENDED WHILE IN USE.

## WORKING LIGHT:

The Quick Flow 3 In 1 Air Compressor comes with a built-in 12V 6W crypton light for a powerful and bright torch. Once the Quick Flow 3 In 1 Air Compressor is connected to a 12V power outlet, just move the switch to the LIGHT position for easy use.

## EMERGENCY LIGHT:

In case of need, you can use the exchangeable amber colored lens to use the blinking light as an emergency function. Just move the switch to the EMERGENCY LIGHT position.

## CHANGING THE 12V 6W CRYPTON BULB:

- Unscrew ring from front of light moving anti clockwise.
- Unscrew bulb and replace with a new one.
- Place ring and lens on the unit by turning it clockwise.

## CHANGING COLORED AND CLEAR LENSES:

- Unscrew ring from front of light moving anti clockwise.
- Take lens from inside the ring holder and replace for the desired one.
- Place ring and lens on the unit by turning it clockwise.

## SPECIFICATIONS:

- Pressure Reader: 260 PSI GAUGE
- Air Hose: 14"
- 12Volt Cord: 125"
- Accessories: 3 Nozzles, collar, Inflator Nozzle, Sport Needle



Figure1



Figure2



© 2004 Wagan Corporation.  
All Rights Reserved.

Wagan and Wagan.com are trademarks used by Wagan Corporation.