

303 Messner Dr. • Wheeling, IL • 60090 847-459-1460 • FAX 847-459-1569 WWW.LUND-INDUSTRIES.COM

Datalux DL-TX200-MTU Keyboard and Tablet Mount





- **1.** Slide the computer over the 2 studs on the screen support plate. Engage the turn lock mechanism and tighten.
- **2.** Connect the power cable to the Tablet. When connecting cable to the computer, be careful to allow enough slack to operate the Tilt/Swivel without straining the cable.
- **3.** Pull the right side of the keyboard tray open and install the keyboard between the two sides. Allow the side to close snugly against the keyboard. Position the keyboard side brackets to the proper keyboard height and tighten. Adjust the front and back retaining brackets to position the keyboard at the desired depth (usually forward) and tighten.
- **4.** Use the side handle to adjust the tension or "Lock" the display. **Do not over-tighten.** The monitor should be loose enough so it can move up and down with a reasonable amount of force.
- **5.** The mount can be swiveled by grasping the keyboard plate and moving from side to side. Tilt/Swivel adjustment is a handle under the right side of the keyboard plate. Loosen the handle and position the mount, then tighten the handle to lock the mount in position.

<u>Caution:</u> When driving, the monitor should be lowered to keep it out of the airbag zone. If left up, the monitor should be close to the dashboard and **Not** in the airbag deployment zone. **Note: Most vehicles have an area just off the center of the dashboard that is not in the air bag deployment zone**.