


ENDURANCE T3 VERSION 0410




ENDURANCE T3 HARDWARE ILLUSTATION SHEET






ENDURANCE T3




After assembly and before turning power on position the rear roller using the 'T' wrench (refer to the drawing if needed).



If belt is too far to the left side


- 1) turn the left roller bolt 1/4 turn clockwise(tighten)
- 2) turn the right roller 1/4 turn counterclockwise(loosen)



If belt is too far to the right side

- 1) turn the right roller bolt 1/4 turn clockwise(tighten)
- 2) turn the left roller bolt 1/4 turn counterclockwise(loosen)

ENDURANCE T3



TENSIONING THE BELT

Running Belt

If when you plant your foot on the belt, you can feel a sliping sensation then the belt has been stretched and is slipping over the roller. This is normal and common adjustment on a new treadmill.

To eliminate this slipping, tighten both sides of the rear roller by wing a Allen wrench turn 1/4 of a TURN as shown above .Try the treadmill again to check for slipping. Repeat if necessary . but NEVER TURN the roller bolt more than 1/4 turn at a time. CAUTION:OVER TIGHTENING OF THE ROLLER WILL SEVERELY SHORTEN THE LIFE OF THE BELT AND MAY CAUSE FURTHER DAMAGE TO OTHER

Drive Belt

If you have tightened the running belt and are still experiencing a slipping sensation, call your Steel Flex Dealer. Tightening of the drive belt should only be performed by an authorized dealer.